

SIEMENS



Gigaset A18H

Issued by
Gigaset Communications GmbH
Schlavenhorst 66, D-46395 Bocholt
Gigaset Communications GmbH is a trademark licensee of Siemens AG


© Gigaset Communications GmbH 2008
All rights reserved.
Subject to availability. Rights of modifications reserved.

www.gigaset.com

UZZ01115AZ(0)

Gigaset

The handset at a glance



Note:

Pictures in this user manual may differ from the actual product.

- 1 **Display** in idle status
 - 2 **Charge status of the batteries** (page 2)
 - 3 **Display keys** (page 11)
 - 4 **Control key**
 - Access to base station's Calls list.
 - Access to base station's directory.
 - 5 **Mute key**
Mute/unmute microphone.
 - 6 **End Call key, On/Off key**
End call, cancel pending, go back to idle status, activate/deactivate handset (press and hold in idle status)
 - 7 **2.5 mm socket** (mono) for headset
 - 8 **Pound (#) key**
Enter symbol #
Keypad lock on/off (press and hold in idle status)
Switch between uppercase/lowercase letters for text entry.
 - 9 **Redial/Pause key**
Open redial list (in idle status) or insert a dialing pause (when editing a number).
 - 10 **Microphone**
 - 11 **Intercom/Hold/Conference key**
Set up an internal call
Switch between external call and internal handset, or transfer a call during external call.
Set up a conference call with an external line and an internal handset (press and hold in hold-intercom mode).
- Note:**
When only one handset is registered to the base station, the key is redundant and therefore has no function.
- 12 **Star (*) key**
Ring tone on/off (press and hold)
Switch temporarily to tone dialing (DTMF).
Switch between AM and PM during time setting.
Switch number format in the Calls list.
 - 13 **Talk/Flash key**
Answer or start a call.
Key flashes: incoming call.
Add a flash (in the directory)
Send FLASH (when off hook).
 - 14 **Handsfree key**
Answer or place a call in speaker mode.
Switch between speaker on and speaker off (in off hook mode).
 - 15 **Voice mail**
Connect to your voice mailbox.
 - 16 **Reception indicator** (page 2)

Overview of handset's display icons









Reception indicator

Handset is linked with the base station.
Flashes: the handset is out of range or not registered



Charge status of the batteries

   (empty to full)
 flashes: batteries almost empty
  flashes: batteries charging



Ringer off icon

Ring tone volume of handset is turned off



Off-Hook

Outgoing call initiated and during a call.
Flashes: indicates incoming call



Handsfree icon

Handsfree mode activated



Voice mail envelope

At least one new message on voice mailbox



Calls list icon

Entries stored in the base station's Calls list.
Flashes: New missed calls in the Calls list



Answering machine icon

Answering machine at the base station is switched on.
Flashes: answering machine is recording or is being operated by another handset

Contents

The handset at a glance	1
Overview of handset's display icons . . .	2
Safety precautions	4
Notes on the operating instructions	5
Symbols used	5
Example: menu input	5
Gigaset A18H – First Steps	6
Package contents	6
Setting up the handset for use	6
Making calls	9
Making an external call	9
Putting an external call on hold	9
Ending a call	9
Answering a call	9
Handsfree operation	9
Last number redial list	10
Operating the handset	10
Control key	10
Display keys	11
Returning to idle status	11
Menu guidance	11
Correcting incorrect entries	11
Using several handsets	12
Registering handsets	12
De-registering handsets	12
Changing the base station	12
Making internal calls	12
Handset settings	13
Changing the name of a handset	13
Changing the display language	13
Setting the display contrast	13
Activating/deactivating auto answer	13
Adjusting the loudspeaker and earpiece volume	13
Changing ring tones	13
Activating/deactivating the key-touch tone	14
Appendix	14
Care	14
Contact with liquid	14
Questions and answers	14
Troubleshooting	15
Specifications	15
Industry Canada Certification	16
Safety precautions	16
Service (Customer Care)	18
End-user limited warranty	18
Menu of the handset	22
Index	23

Safety precautions*



Only use the power supply unit supplied as indicated on the underside of the device.



Only insert **approved rechargeable batteries of the same type**.
Never use ordinary (non-rechargeable) batteries as they may pose a health hazard or cause injury.

Do not charge the handset in charging cradle or base station while the headset is connected.



Make sure the rechargeable battery is inserted the right way round.



Use the battery specified in these operating instructions.



The phone may affect medical equipment so always switch your phone off before entering hospitals or doctors' practices.



Notice to Hearing Aid Wearers:
This phone system is compatible with inductively coupled hearing aids.



Do not operate the phone in places where there is a risk of explosion (such as paint workshops).



The handset is not splash-proof (see page 14).



Drivers must not use the phone while driving.



The phone must be switched off at all times in an aircraft. Make sure it cannot be switched on accidentally.



If you give your telephone to someone else you should also give them the operating instructions.



Dispose of batteries and the phone carefully. Do not pollute the environment.

Emergency numbers cannot be dialed if the keypad lock is activated!

* also see page 16

Notes on the operating instructions

This section explains the meaning of certain symbols and typographical conventions used in this user guide.

Symbols used

On / Off (example)

Select one of the two menu functions specified.



Enter digits or letters.

Back

The display keys' current functions are shown reverse highlighted in the bottom display line. Press the display key below to launch the function.



Press the top or the bottom of the control key: scroll up or down.

Flash

Open

*** Δ** etc.

Press the corresponding key of the handset.

Example: menu input

In the user guide, the steps you need to perform are shown in abbreviated form. This is illustrated below using "Changing the display language" as an example.

Please proceed as described in the box below.

Menu → **Settings** → **Handset** → **Language**
→ **English / Español / Français**

- ▶ With the handset in idle status, press the right display key to open the main menu.
- ▶ Select **Settings** using the control key [↕] – press the control key at the top or bottom.
- ▶ Press the **OK** display key to confirm the function **Settings**.

The **Settings** submenu is displayed.

- ▶ Press the bottom of the control key [↕] repeatedly until **Handset** is selected.
- ▶ Press the **OK** display key to confirm the function.

The **Handset** submenu is displayed.

- ▶ Press the bottom of the control key [↕] repeatedly until **Language** is selected.
- ▶ Press the **OK** display key to confirm the function.

The **Language** submenu is displayed.

- ▶ Select the language you want using the control key [↕] – press the control key at the top or bottom.
- ▶ Press the **OK** display key to confirm the selected language.

The language is now changed for all text.

Gigaset A18H – First Steps

Package contents

- ◆ One Gigaset A18H handset with battery cover
- ◆ Two batteries
- ◆ One belt clip
- ◆ One Gigaset charging cradle
- ◆ One AC adapter for charging cradle
- ◆ One User Guide

Headset socket

Which headsets are compatible?

Please call the Service number 1-866-247-8758 or contact us at www.gigaset.com/customer-care for information.


Caution:

Do not charge the handset in charging cradle or base station while the headset is connected.

Setting up the handset for use

Connecting the charging cradle

- ▶ **First** connect the power adapter to the charging cradle (1) and **then** the AC power adapter to the 110V AC power socket (2) as shown below.



Underside of the charging cradle

Inserting the batteries


Caution:

Use only rechargeable Nickel-metal hydride (NiMH) UL-approved AAA batteries. Never use a conventional (non-rechargeable) battery or other battery types as this could result in significant health risks and personal injury. For example, the batteries could explode. The phone could also malfunction or be damaged as a result of using batteries that are not of the recommended type.

Note:

If attached, remove the belt clip before opening the battery cover.

- ▶ Open the battery cover.



- ▶ Insert the batteries according to the correct polarity (see diagram).



- ▶ Close the cover, and press the top so that it clicks into place.

Attaching the belt clip

There are notches on the sides of the handset for attaching the belt clip, nearly at the same height as the handset ear-piece.



- ▶ Press the belt clip onto the back of the handset so that the protrusions on the belt clip engage with the notches.

Placing the handset in the charging cradle


- ▶ Place the handset in the charging cradle with the handset's **display facing outwards**.

Charging the batteries for the first time

- ▶ To charge the batteries, leave the handset in the charging cradle **continuously** for **ten** hours.

The alternately flashing battery icons  and  at the upper right of the display screen indicate that the batteries are being charged.

Note:

- If the handset has turned itself off because its batteries are empty, and you then place the handset into the charging cradle, it will turn on automatically.
- Only place the handset into the base station or charging cradle specifically intended for it.
- During handset operation, the battery icon  indicates the charge status of the batteries (page 1).
- The batteries may feel warm as they are charging. This is not dangerous.

For questions and troubleshooting, see page 14.










Setting the date and time

You should set the date and time, for example, to ensure the correct time of incoming calls is recorded.

To change the time and date, open the input field using:

Menu →  → **Settings** → **Date/Time**
→ **Set Date/Time**



Enter the time and date with 10 digits, for example,         for November 15, 2008, 07:15 am. If the **12-hour** time format is set, use the  key to switch between am and pm.

OK Press the display key to save changes.

You can change the date and time format:

Menu →  → **Settings** → **Date/Time**
→ **Set Format**

▶ Choose between day/month and month/day date formats:

 → **Date Format** → **DD/MM** or **MM/DD**

▶ Choose between 12- and 24-hour time formats:

 → **Time Format** → **12 Hours / 24 Hours**


Note:

Date and time settings apply all registered handsets and the base station.

Date and time format settings apply only to your own handset. You must set date and time format at each device separately.

Display in idle status

Once the phone is registered to a base station (page 12) and the time set, the idle display looks as shown here (example).



Your phone is now ready to use.



This user manual describes the functions of your Gigaset A18H handset. For all base station related functions, please consult the Gigaset A180/A185 user manual.


Making calls

Making an external call

External calls are calls using the outside telephone network.



Enter the number and press the Talk key  or Handsfree key .

To cancel the dialing operation, press the End Call key .

You are shown the duration of the call while the call is in progress.

Putting an external call on hold





Press the Int/Hold key.

The external call is put on hold.



Press the display key to take the call back off hold.

Note:


If only one handset is registered to the base station, the  has no function. Use  key, if you want to talk to somebody else without being heard by the external party.

Ending a call






Press the End Call key.

Answering a call

The handset indicates an incoming call in three ways: by ringing, by a display on the screen, and by the flashing Talk key .

You can accept the call by:

- ▶ Pressing the Talk key .
- ▶ Pressing the Handsfree key .

If the handset is in the charger and the Auto Answer function is activated (page 13), the call will be answered automatically when you lift the handset from the charger. Lifting the handset from the base station or charger in this case has the same effect as pressing the Talk key .

You can press the **Quiet** display key to mute the ring tone of your handset without answering the call. The other registered handsets and the base station keep ringing.

You can answer the call as long the call is shown on the display.

Handsfree operation

You can activate the speakerphone at any time to provide handsfree operation during a call.

Activating/deactivating handsfree

Activating while dialing



Enter the number and press the Handsfree key.

- ▶ You should inform your caller before you use the handsfree function so that the caller knows someone else may be listening.

Switching between earpiece and handsfree mode



Press the Handsfree key.





During a call, turn handsfree on or off.

For how to adjust the volume, see page 13.



Last number redial list


The Last Number Redial list contains the ten numbers last dialed with the handset (max. 32 digits). If a number has been dialed several times, only the last try is shown in the list.

Last number redial

-  Press the key.
-  Select the entry.
-  /  Press the Talk key or the Handsfree key.
The number is dialed.

Managing entries in the Last Number Redial list

-  Press the key.
-  Select the entry.
- Menu** Open menu.

The following functions can be selected with :

View

In the list long numbers are shown abbreviated. Select **View** to show the whole number.

- ▶ Go back with **Back**.

Copy To Dir.

Copy the displayed entry to the directory of the base station.

- ▶ Complete the entry as described in the user guide of base station.

Delete

Delete the displayed entry from the list.


Delete List

- ▶ Confirm question **Delete?** by pressing **OK**.


All entries in the last number redial list will be deleted.

Operating the handset

Activating/deactivating the handset

-  Press and **hold** the End Call key to turn the handset on/off.


Activating/deactivating the keypad lock

-  Press and hold the pound key.


Keypad Locked appears in the display when the keypad lock is activated.

The keypad lock is deactivated automatically if someone calls you. It is re-activated when the call is finished.

Control key





1 Control key



In the description below, the top or bottom of the Control key (up, down), which you must press depending on the operating situation, is marked in black, for example,  for "press up on the Control key".

The Control key has different functions:



When the handset is in idle status

-  Open the base station's directory
-  Open the base station's Calls list

In input fields

You can use the Control key to move the cursor backwards  or  forwards.

When the handset is off the hook

-  /  Increase/decrease volume


In the main menu, lists and submenus

☐ / ☐ Scroll up/down line by line.

At the bottom/top of a menu or a list:
A feedback tone signals that the menu/list has wrapped around automatically (the first/last entry is selected in the display).

Display keys

The function of the display keys changes depending on the particular operating situation. Example:




- 1 The display keys' current functions are shown on the bottom display line.
- 2 Display keys

The most important display symbols are:

- Menu** Open the main menu (in idle mode) or the context-dependent menu.
- Back** Go back one menu level.
- OK** Confirm your choice or save edited characters.
- Clear** Clear key: deletes one character at a time from right to left (press briefly) or all characters (hold).

Returning to idle status

You can return to idle status from anywhere in the menu as follows:

- ▶ Press the End Call key .
- Or:
- ▶ Do not press any key: after 2 minutes, the display will **automatically** return to idle status.

Changes that you have not confirmed or saved by pressing **OK** will not be saved.

An example of the display in idle status is shown on page 8.

Menu guidance


Your phone's functions are accessed using a menu that has a number of levels.

Main menu (first menu level)

- ▶ Press the display key **Menu** with the handset in idle status to open the main menu.

The main menu functions are shown on the screen in a list.

To access a function, open the corresponding submenu (next menu level):


- ▶ Navigate to the function using the control key .
- ▶ Press the display key **OK**.

Submenus

The functions in the submenus are displayed as lists.

To access a function:

- ▶ Scroll to the function with the control key  and press **OK**.

Pressing the display key **Back** returns you to the previous menu level.  cancels the operation.

Correcting incorrect entries

You can correct incorrect characters in the text by navigating to the incorrect entry using the control key. You can then:

- ◆ Press **Clear** to delete the character to the left of the cursor.
- ◆ Insert characters to the left of the cursor.
- ◆ Overwrite the (flashing) character when entering the time and date, etc.

Using several handsets



Registering handsets


A Gigaset A18H handset can be registered with up to four base stations.

Registering Gigaset A18H handset

On the handset


Menu → **Settings** → **Registration**
→ **Register HS**

 Select the base you want to register your handset with and press **OK**. Bases that have been registered will be marked by .

 Enter the base station's system PIN and press **OK**.

The handset will be registered.


On the base station


Within 60 secs. press and **hold** the registration/page key  on the base station (approx. 5 secs.).

De-registering handsets

You can de-register any registered handset from your base station.

Menu → **Settings** → **Registration**
→ **Unregister HS**

 Enter the base station's system PIN and press **OK**.


 Select the handset you want to de-register and press **OK**.

OK Press the display key to confirm deletion.

Changing the base station

If your handset is registered to more than one base station, you can set it to a particular base station or to the base station that has the best reception (**Best Base**).


Menu → **Settings** → **Registration**
→ **Select Base**

 Select one of the registered base stations or **Best Base** and press **OK**.


Making internal calls

Internal calls to other handsets registered with the same base station are free.

 Initiate internal call.

 Select the handset you want to call and press **OK**.

Note:

If only two handsets are registered to the base, the internal call will be established immediately after pressing  key.

Ending a call

 Press the End Call key.

Handset settings

Your handset is preconfigured, but you can change these settings to suit your individual needs.

Changing the name of a handset

The names "INT 1", "INT 2", etc., are assigned automatically during registration. You can change these names. The number of the handset, however, never changes. The changed name is only displayed on this handset.

Menu → **Settings** → **Handset** → **Handset Name**



Enter the name and press **OK**.

The name must be no more than 12 characters.

Changing the display language

You can view the display texts in different languages.

Menu → **Settings** → **Handset** → **Language**

English / Español / Français

Select a language and press **OK**.

Setting the display contrast

You have a choice of five different contrast levels.

Menu → **Settings** → **Handset**
→ **Display Contr.**

Level 1 / ... / Level 5



Select your preferred level and press **OK**.

Activating/deactivating auto answer

This function is active by default, so that when you get a call, you can simply lift the handset out of the base station without having to press the Talk key .

Menu → **Settings** → **Handset**
→ **Auto Answer** → **On / Off**

Adjusting the loudspeaker and earpiece volume

You can set the loudspeaker volume and the earpiece volume to five different levels. You can only make these adjustments during a call.

The handsfree volume can only be adjusted when this function is in use.

You are conducting a call.



Increase or decrease the volume.

Changing ring tones

Volume

You can choose between five volumes (1–5; for example, volume 3 =).

Menu → **Settings** → **Audio Settings**
→ **HS Ring Volume**



Select the volume and press **OK**.

Ring tone melodies


You can choose between 15 different melodies.

Menu → **Settings** → **Audio Settings** → **HS Ring Tones**



Select your preferred melody and press **OK**.


Changing the ring tone volume during an incoming call


-  Press the key until the ring tone volume reaches the desired level.

Activating/deactivating the ring tone


You can deactivate the ring tone on your handset before you answer a call or when the handset is in idle status; the ring tone can be deactivated permanently or just for the current call.

Deactivating the ring tone permanently

-  Press and hold the star key until you no longer hear the ring tone.

The  icon appears in the display.


Reactivating the ring tone

-  Press and **hold** the star key.


Deactivating the ring tone for the current call

- Quiet** Press the display key.

Deactivating the ring tone during incoming call

-  Press key until you do not hear the ring tone any more.

Activating the ring tone during incoming call

-  Press key until ring tone volume reaches the desired level.

Activating/deactivating the key-touch tone

Each key press is acknowledged by a beep. You can deactivate this function:

- Menu** → **Settings** → **Audio Settings** → **Key Touch Tone** → **On / Off**

Appendix

Care

Wipe the handset with a **damp** cloth (do not use solvents) or an antistatic cloth.

Never use a dry cloth. This can cause static.

Contact with liquid

If the handset has come into contact with liquid:

1. **Immediately switch the handset off and remove the batteries.**
2. Allow the liquid to drain from the handset.
3. Pat all parts dry, then place the handset, with the battery compartment open and the keypad facing down, in a dry, warm place **for at least 72 hours** (not in a microwave oven, convection oven, etc.).
4. **Do not switch on the handset again until it has completely dried.**

When it has fully dried, you should be able to use it again normally.

Questions and answers


If you have any questions about the use of your telephone, you can contact us at any time at

<http://www.qigaset.com>

The troubleshooting section below (page 15) contains a list of common problems and possible solutions.


Troubleshooting

The display is blank.

1. The handset is not switched on.
 - ▶ Press  and hold the End Call key.
2. The batteries are empty.
 - ▶ Charge or replace the batteries (page 6).

The handset does not respond to a key press.

The keypad lock is activated.

- ▶ Press and hold the pound key  (page 10).

Base Search and is flashing on the display screen.



1. The handset is outside the range of the base station.
 - ▶ Reduce the distance between handset/ base station.
2. The handset has been de-registered. Please Register is flashing on the display screen.
 - ▶ Register the handset (page 12).
3. The base station is not switched on.
 - ▶ Check the base station power cord.


Handset does not ring.

The ring tone is switched off.

- ▶ Activate the ring tone (page 14).

The other party cannot hear you.

You have pressed the  or  key. The handset is on hold.

- ▶ Press the  key or the left display key to switch on the microphone again.

You hear an error tone when keying an input.

Action has failed/invalid input.

- ▶ Repeat the operation. Watch the display and refer to the operating instructions, if necessary.

Specifications

Recommended batteries

Nickel-metal hydride (NiMH):

The handset is supplied with the authorized AAA batteries.

Handset operating times/charging times

Capacity	550 mAh
Standby time	Approx. 300 hours (12.5 days)
Talk time	Approx. 10 hours
Charge time	Approx. 10 hours

The operating and charge times apply only when using the recommended batteries.

General specifications

DECT 6.0	is supported
No. of channels	60 duplex channels
Radio frequency range	1920–1930 MHz
Duplex method	Time multiplex, 10 ms frame length
Channel grid	1728 kHz
Bitrate	1152 kbit/s
Modulation	GFSK
Language code	32 kbit/s
Transmission power	10 mW, average power per channel
Range	up to 984 feet outdoors, up to 165 feet indoors
Charging cradle power supply	110 V ~/60 Hz
Environmental operating conditions	+41°F to +113°F; 20% to 75% relative humidity
Dialing mode	DTMF (tone dialing)/DP (pulse dialing)

Industry Canada Certification

Operation is subject to the following two conditions (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

NOTICE: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network, protective, operational and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together.

This precaution may be particularly important in rural areas

NOTE: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

This product meets the applicable Industry Canada technical specifications.

A copy of the supplier's Declaration of Conformity (SDoC) is available at this Internet address: <http://www.gigaset.com/docs>.

The Ringer Equivalence Number is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all devices does not exceed five.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Safety precautions

Before using your telephone equipment, basic safety instructions should always be followed to reduce the risk of fire, electric shock and injury to persons.

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall telephone jack and power outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use damp cloth for cleaning.
4. Do not use this product near water, for example, near a bathtub, wash bowl, kitchen sink, or laundry tub, in a wet basement or near a swimming pool.
5. Place this product securely on a stable surface. Serious damage and/or injury may result if the unit falls.
6. Slots or openings in the cabinet and the back and bottom are provided for ventilation, to protect it from overheating. These openings must not be blocked or covered. This product should never be placed near or over a radiator or heat register, or in a place where proper ventilation is not provided.
7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of AC line power to your home, consult your dealer or local power company.
8. Do not place objects on the power cord. Install the unit where no one can step or trip on the cord.
9. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.
10. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in the risk of fire or electric shock. Never spill liquid of any kind on this product.
11. To reduce the risk of electric shock or burns, do not disassemble this product. Take it to a qualified service center when service is required. Opening or removing covers may expose you to dangerous voltages, dangerous electrical current or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.

12. Unplug the product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a.) When the power cord is damaged or frayed.
- b.) If liquid has been spilled into the product.
- c.) If the product has been exposed to rain or water.
- d.) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions because improper adjustment of other controls may result in damage and may require extensive work by a qualified technician to restore the product to normal operation.
- e.) If the product has been dropped or physically has been damaged.
- f.) If the product exhibits a distinct change in performance.

13. Avoid using a telephone (other than a cordless type) during a thunderstorm. There may be a remote risk of electrical shock from lightning. Therefore we suggest a surge arrestor.

14. Do not use the telephone to report a gas leak in the vicinity of the leak.

15. Emergency/911 numbers may not be dialed if the keypad is locked.

BATTERY SAFETY PRECAUTIONS

To reduce the risk of fire, injury or electric shock, and to properly dispose of batteries, please read and understand the following instructions.

CONTAINS NICKEL METAL HYDRIDE BATTERY. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY. DO NOT DISPOSE OF IN MUNICIPAL WASTE.

1. Only use the batteries specified for use with this product.
2. **DO NOT USE NICKEL CADMIUM OR LITHIUM BATTERIES**, or mix batteries of different sizes or from different manufacturers in this product. **DO NOT USE NONRECHARGEABLE BATTERIES.**
3. Do not dispose of the batteries in a fire; the cells may explode. Do not expose batteries to water. Check with local codes for special disposal instructions.
4. Do not open or mutilate the batteries. Released electrolyte is corrosive and may cause damage to the eyes or skin. The electrolyte may be toxic if swallowed.
5. Exercise care in handling the batteries in order not to short the batteries with conducting materials such as rings, bracelets, and keys. The batteries or conducting material may overheat and cause burns or fire.
6. Charge the batteries provided with, or identified for use with, this product only in accordance with the instructions and limitations specified in the user's manual. Do not attempt to charge the batteries with any means other than that specified in the users manual.
7. Periodically clean the charge contacts on both the charger and handset.

Service (Customer Care)

Customer Care Warranty for Cordless Products
To obtain Customer Care Warranty service,
product operation information, or for problem resolution, call:
Toll Free: 1-866-247-8758
www.gigaset.com/customer-care

End-user limited warranty

This product is covered by a one year limited warranty. Any repair replacement or warranty service, and all questions about this product should be directed to: 1-866-247-8758.

This limited, non-transferable warranty is provided to the original buyer/end-consumer ("you") for systems, handsets and accessories (collectively, "Product") provided by Gigaset Communications USA LLC or Gigaset Communications Canada Inc. (collectively "Gigaset NAM"). Gigaset NAM warrants to you that at the date of purchase, the Product is free of defects in workmanship and materials and the software included in the Product will perform in substantial compliance to its program specifications.

1. WARRANTY PERIOD

The Product warranty period is one (1) year from the original date of purchase by you. Proof of purchase (e.g., sales slip or invoice) must be provided with any Product returned during the warranty period. Batteries supplied with the Products are warranted to be free from defects at the time of purchase only.

2. EXCLUSIVE REMEDY

Gigaset NAM's entire liability and your exclusive remedy if the Product is defective in materials or workmanship during the warranty period and is returned shall be that the Product will be repaired or replaced as set forth in Section 4 below. Reconditioned replacement components, parts or materials may be used in the replacement or repair. Data in the memory of the Product may be lost during repair.

3. THIS LIMITED WARRANTY DOES NOT COVER AND IS VOID WITH RESPECT TO THE FOLLOWING:

- Cosmetic damage, physical damage to the surface of the Product, including, without limitation, breakage, cracks, dents, scratches or adhesive marks on the LCD screen or outside casing of the Product.
- Products which have been repaired, maintained or modified (including the antenna) by anyone other than Gigaset NAM or a Gigaset NAM-approved repair facility, or that have been improperly installed.
- Cost of installation, removal or reinstallation.
- Damage due to any telephone, electronic, hardware or software program, network, Internet or computer malfunctions, failures, or difficulties of any kind, including without limitation, server failure or incomplete, incorrect, garbled or delayed computer transmissions.
- Equipment and components not manufactured, supplied or authorized by Gigaset NAM.
- Modification of the Product's components, or operation of the Product in an unsuitable environment or in a manner for which it is not intended, including but not limited to failures or defects caused by misuse, abuse, accidents, physical damage, abnormal operation, improper handling or storage, neglect, alterations, unauthorized installation, removal or repairs, failure to follow instructions, problems caused by the carrier's network coverage, exposure to fire, water or excessive moisture or dampness, floods, or extreme changes in climate or temperature, acts of God, riots, acts of terrorism, spills of food or liquids, viruses or other software flaws introduced into the Product or other acts which are not the fault of Gigaset NAM and which the Product is not specified to tolerate, including damage caused by mishandling or blown fuses.

- Products which have had warranty stickers, electronic serial number and/or serial number label removed, altered, rendered illegible or fraudulently applied to other equipment.
- Signal reception problems (unless caused by defect in material or workmanship in the Product).
- Products operated outside published maximum ratings.
- Performance of the Products when used in combination with other products or equipment not manufactured, supplied or authorized by Gigaset NAM.
- Consumables (such as batteries and fuses).
- Payments for labor or service to representatives or service centers not authorized to perform product maintenance by Gigaset NAM.
- Loss of data.
- Testing and examination discloses that the alleged defect or malfunction in the Product does not exist.

This warranty does not cover customer education, instruction, installation or removal, set up adjustments, problems related to service(s) provided by a carrier or other service provider, and/or signal reception problems. Gigaset NAM shall not be responsible for software, firmware, information, or memory data contained in, stored on, or integrated with any Products returned for repair, whether under warranty or not. This warranty is valid only in the country in which it is purchased (*i.e.*, the United States of America or Canada respectively, but not both).

USE WITH ACCESSORIES NOT SUPPLIED BY GIGASET NAM OR NOT OTHERWISE EXPRESSLY AUTHORIZED BY GIGASET NAM MAY VOID WARRANTY.

4. WARRANTY CLAIM PROCEDURE

All warranty claims must be made by notifying Gigaset NAM prior to the expiration of the warranty period. Gigaset NAM's obligation to provide warranty support shall not extend past the end of the warranty period, except that any product repaired or replaced during the warranty period shall continue to be warranted for the balance of such warranty period or thirty (30) days, whichever is greater.

Support service will be provided for you by accessing the toll free customer service number:

1-866-247-8758

5. LIMITATION OF WARRANTY

Gigaset NAM makes no warranty or representation that the software in the Products will meet your requirements or will work in combination with any hardware or applications software products provided by third parties, that the operation of the software will be uninterrupted or error free, or that all defects in the software products will be corrected.

6. LIMITATION ON REMEDIES; NO CONSEQUENTIAL OR OTHER DAMAGES

Your exclusive remedy for any breach of this limited warranty is as set forth above. Except for any refund elected by Gigaset NAM, **YOU ARE NOT ENTITLED TO ANY DAMAGES, INCLUDING BUT NOT LIMITED TO CONSEQUENTIAL DAMAGES**, if the Product does not meet the limited warranty, and, to the maximum extent allowed by applicable law, even if any remedy fails of its essential purpose. The terms below ("Exclusion of Incidental, Consequential and Certain Other Damages") are also incorporated into this limited warranty. Some states/jurisdictions/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This limited warranty gives you specific legal rights. You may have others which vary from state/jurisdiction/province to state/jurisdiction/province.

7. DISCLAIMER OF WARRANTIES

GIGASET NAM AND ITS SUPPLIERS PROVIDE THE PRODUCT AND SUPPORT SERVICES (IF ANY) AS IS AND WITH ALL FAULTS. THE LIMITED WARRANTY IS IN LIEU OF ANY OTHER EXPRESS WARRANTIES (IF ANY) CREATED BY ANY DOCUMENTATION OR PACKAGING EXCEPT FOR THE LIMITED WARRANTY, AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW IS IN LIEU OF ANY IMPLIED OR STATUTORY WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, OF ACCURACY OR COMPLETENESS OR RESPONSES, OF RESULTS, OF WORKMANLIKE EFFORT, OF LACK OF VIRUSES AND OF LACK OF NEGLIGENCE, ALL WITH REGARD TO THE PRODUCT, AND THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES. ALSO, THERE IS NO WARRANTY OR CONDITION OF TITLE, QUIET ENJOYMENT, QUIET POSSESSION, OR CORRESPONDENCE TO DESCRIPTION OR NON-INFRINGEMENT WITH REGARD TO THE PRODUCT. Some states/jurisdictions/provinces do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above exclusions or limitations may not apply to you. If an implied warranty or condition is created by your state/province and federal or state/provincial law prohibits disclaimer of it, you also have an implied warranty or condition, BUT ONLY AS TO DEFECTS DISCOVERED DURING THE PERIOD OF THIS LIMITED WARRANTY (ONE YEAR). AS TO ANY DEFECTS DISCOVERED AFTER THE ONE YEAR PERIOD, THERE IS NO WARRANTY OR CONDITION OF ANY KIND. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state/province to province. In no event shall Gigaset NAM's liability exceed the cost of repairing or replacing defective Products as provided herein, and any such liabilities will terminate upon expiration of the warranty period.

Any supplements or updates to the Product or the software in the Product, including without limitation, any (if any) software fixes or upgrades or bug fixes provided to you after the expiration of the one year limited warranty period are not covered by any warranty or condition, express, implied or statutory.

8. EXCLUSION OF INCIDENTAL, CONSEQUENTIAL AND CERTAIN OTHER DAMAGES

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL GIGASET NAM, SELLER OR THEIR SUPPLIERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS OR CONFIDENTIAL OR OTHER INFORMATION, FOR BUSINESS INTERRUPTION, FOR PERSONAL INJURY, FOR LOSS OF PRIVACY, FOR FAILURE TO MEET ANY DUTY INCLUDING OF GOOD FAITH OR OF REASONABLE CARE, FOR NEGLIGENCE, AND FOR ANY OTHER PECUNIARY OR OTHER LOSS WHATSOEVER) ARISING OUT OF OR IN ANY WAY RELATED TO THE USE OF OR INABILITY TO USE THE PRODUCT, THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES, OR OTHERWISE UNDER OR IN CONNECTION WITH ANY PROVISION OF THIS LIMITED WARRANTY, EVEN IN THE EVENT OF THE FAULT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY, BREACH OF CONTRACT OR BREACH OF WARRANTY OF GIGASET NAM OR SELLER OR ANY SUPPLIER, AND EVEN IF GIGASET NAM OR SELLER OR ANY SUPPLIER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. REPAIR OR REPLACEMENT, AS PROVIDED UNDER THE WARRANTY, IS YOUR SOLE AND EXCLUSIVE REMEDY FOR BREACH OF THE LIMITED WARRANTY.

9. LIMITATION OF LIABILITY AND REMEDIES

NOTWITHSTANDING ANY DAMAGES THAT YOU MIGHT INCUR FOR ANY REASON WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ALL DAMAGES REFERENCED ABOVE AND ALL DIRECT OR GENERAL DAMAGES), THE ENTIRE LIABILITY OF GIGASET NAM, SELLER AND ANY OF THEIR SUPPLIERS UNDER ANY PROVISION OF THIS LIMITED WARRANTY AND YOUR EXCLUSIVE REMEDY FOR ALL OF THE FOREGOING (EXCEPT FOR ANY REMEDY OF REPAIR OR REPLACEMENT ELECTED BY GIGASET NAM OR SELLER OR SUPPLIER WITH RESPECT TO ANY BREACH OF THE LIMITED WARRANTY) SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU FOR THE PRODUCT OR FIVE DOLLARS (\$5.00 USD/CAN). THE FOREGOING LIMITATIONS, EXCLUSIONS AND DISCLAIMERS SHALL APPLY TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, EVEN IF ANY REMEDY FAILS ITS ESSENTIAL PURPOSE.

10. GOVERNING LAW

If this Product was purchased in the United States of America this limited warranty will be governed by the laws of Texas, and exclude the United Nations Convention on Contracts for the International Sale of Goods. If this Product was purchased in Canada this limited warranty will be governed by the laws of the Province of Ontario and the federal laws of Canada applicable therein, and exclude the United Nations Convention on Contracts for the International Sale of Goods.

If you want to learn more about Gigaset Service or for Support on your Gigaset phone, visit our web site at <http://www.gigaset.com> or please call

1-866-247-8758.

Issued by

Gigaset Communications GmbH

Schlavenhorst 66, D-46395 Bocholt

Gigaset Communications GmbH is a licensee of the Siemens trademark.

© Gigaset Communications GmbH 2009

All rights reserved.

Subject to availability. Rights of modifications reserved.


Product attributes subject to change.

We reserve the right, to make changes without notice in equipment design and/or components.

Part Number:A31008-M1962-R401-1-5819

© Copyright 2009.

Menu of the handset



Index

Numerics

2.5 mm socket for headset. 1

A

Activating

auto answer. 13
handset 10
keypad lock 10
key-touch tone. 14
ring tone 14

Adjusting loudspeaker volume 13

Auto answer 9, 13

B

Base station, changing 12

Battery

fitting 6
recommended batteries 15

Best base station 12

C

Call

answering 9
duration 9
ending. 9
external. 9
history. 10
internal 12

Care of the telephone 14

Changing

base station. 12
display language 13
name of handset 13
ring tones 13

Charge status of the batteries 1, 2

Charging cradle, connecting 6

Conference key 1

Control key 1, 10

Correcting incorrect input 11

Customer Care 18

D

Date format 8

Deactivating

auto answer 13
handset 10
keypad lock. 10
key-touch tone 14
ring tone. 14

Deleting characters. 11

De-registering (handset). 12

Dialing pause, insert. 1

Display

changing display language 13
contrast 13
in idle status 11
keys 1, 11
setting 13

E

Earpiece mode 9

End Call key 1, 9

Ending call 9

Ending, see Deactivate

Entry, selecting (menu) 5

Example for menu input 5

F

flash, add in directory. 1

FLASH, send. 1

Format of Date, Time 8

H

Handset
 activating/deactivating 10
 changing name 13
 changing the base station 12
 changing to best reception 12
 charge times 15
 contact with liquid 14
 de-registering 12
 display language 13
 idle status 8, 11
 key-touch tone. 14
 loudspeaker volume. 13
 operating time. 15
 registering 12
 registering with another
 base station. 12
 ring tone melodies 13
 ring tone volume 13
 settings 13
 setup 6
 turning on/off 10
 using several handsets 12
Handsfree key 1
Handsfree talking 9
Headset socket 1
Hold key 1

I

Icon
 display. 11
 keypad lock 10
 ring tone 14
Idle status
 display. 8
 returning to 11
Incorrect input (correction) 11
Int/Hold key 9
Intercom key 1
Internal call. 12

K

Keypad lock 1, 10
Keys
 Control key 1, 10
 display keys. 1, 11
 End Call key 1, 9
 Handsfree Key. 1
 Int/Hold key 1, 9
 Intercom/Hold/Conference. 1
 Last Number Redial key 10
 menu key 11
 mute/unmute microphone. 1
 On/Off key 1, 10
 pound key. 1, 10
 Redial key 1
 star key. 1, 14
 Talk key 1
 Voice mail. 1
Key-touch tone. 14

L

Last number redial 10
Liquid 14
Lock keypad 10
Loudspeaker volume. 13

M

Making calls
 answering a call 9
 external 9
 internal. 12
Medical equipment. 4
Menu
 guidance 11
 input 5
 key 11
Microphone 1
 mute/unmute 1
Mute key 1

N

Name of a handset 13

O

On/Off key 1, 10

P

Package contents 6

Pound key 1, 10

Power supply unit 4

Q

Questions and answers 14

R

Redial key 1, 10

Registering (handset) 12

Ring tone

 activating/deactivating 14

 melodies (handset) 13

 setting volume 13

 setting volume during call 14

S

Safety precautions 4

Setting

 date 8

 display contrast 13

 loudspeaker/earpiece volume 13

 time 8

Setup handset 6

Socket for headset 1

Sound, see Ring tone

Specifications 15

Star key 1, 14

Switch between

 earpiece mode/handsfree mode 9

 uppercase/lowercase letters 1

T

Talk key 1

Time format 8

Troubleshooting 14, 15

U

Unmute Microphone 1

Uppercase letters, switching to 1

V

Voice mail key 1

Voice mailbox, connecting to 1

Volume

 loudspeaker 13

 ring tone 13