

HP ProLiant ML330 G6 Server Maintenance and Service Guide

Abstract

This guide is for an experienced service technician. HP assumes you are qualified in the servicing of computer equipment and trained in recognizing hazards in products with hazardous energy levels and are familiar with weight and stability precautions for rack installations.



Part Number: 534303-005
February 2011
Edition: 5

© Copyright 2009, 2011 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation.

Intel and Xeon are trademarks of Intel Corporation in the U.S and other countries.

Contents

Customer self repair	5
Parts only warranty service	5
Illustrated parts catalog	16
Mechanical components.....	16
System components	19
Removal and replacement procedures	25
Required tools.....	25
Safety considerations.....	25
Preventing electrostatic discharge	25
Server warnings and cautions	25
Rack warnings	26
Preparation procedures.....	27
Power down the server.....	27
Remove the server from the rack	27
Bezel.....	28
Bezel blank	29
Access panel	30
Media bay blank	30
Hard drive blank.....	31
Hot-plug hard drives	31
Power button/LED cable.....	32
USB diskette drive	33
Half-height media device.....	33
Full-height media device.....	35
Hot-plug expansion hard drive cage and backplane	37
Non-hot-plug expansion hard drive cage and drives	38
Air baffle	39
Hard drive fan assembly	41
Rear fan assembly	42
Hot-plug power supply	43
DIMMs.....	44
Processor board	45
Heatsink.....	48
Processor	50
Expansion boards	56
PCI-X extender board	57
System battery	58
Battery pack	59
Cache module	60
FBWC module and capacitor pack.....	61
System board	63
HP Trusted Platform Module	71
Cabling	72
Non-hot-plug SATA hard drive cabling.....	72

Non-hot-plug SATA/SAS hard drive cabling	73
Hot-plug SATA/SAS hard drive cabling	73
Non-hot-plug hard drive single power cabling	74
Hot-plug hard drive single power cabling	75
Non-hot-plug hard drive redundant power cabling	76
Hot-plug hard drive redundant power cabling	77
Diagnostic tools	78
Troubleshooting resources	78
HP Insight Diagnostics	78
HP Insight Diagnostics survey functionality	78
Integrated Management Log	79
ROMPaq disaster recovery	79
Component identification	80
Front panel components	80
Front panel LEDs and buttons	81
Rear panel components	82
Rear panel LEDs and buttons	83
System board components	84
System maintenance switch	85
NMI functionality	86
System board LEDs	86
System LEDs and internal health LED combinations	87
DIMM slots	88
DIMM identification	88
SAS and SATA device numbers	90
Hot-plug SATA or SAS hard drive LEDs	91
FBWC module LEDs	92
Fan locations	93
Specifications	94
Environmental specifications	94
Mechanical specifications	94
Power supply specifications	95
Acronyms and abbreviations	96
Index	98

Customer self repair

HP products are designed with many Customer Self Repair (CSR) parts to minimize repair time and allow for greater flexibility in performing defective parts replacement. If during the diagnosis period HP (or HP service providers or service partners) identifies that the repair can be accomplished by the use of a CSR part, HP will ship that part directly to you for replacement. There are two categories of CSR parts:

- **Mandatory**—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.
- **Optional**—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

NOTE: Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

Based on availability and where geography permits, CSR parts will be shipped for next business day delivery. Same day or four-hour delivery may be offered at an additional charge where geography permits. If assistance is required, you can call the HP Technical Support Center and a technician will help you over the telephone. HP specifies in the materials shipped with a replacement CSR part whether a defective part must be returned to HP. In cases where it is required to return the defective part to HP, you must ship the defective part back to HP within a defined period of time, normally five (5) business days. The defective part must be returned with the associated documentation in the provided shipping material. Failure to return the defective part may result in HP billing you for the replacement. With a customer self repair, HP will pay all shipping and part return costs and determine the courier/carrier to be used.

For more information about HP's Customer Self Repair program, contact your local service provider. For the North American program, refer to the HP website (<http://www.hp.com/go/selfrepair>).

Parts only warranty service

Your HP Limited Warranty may include a parts only warranty service. Under the terms of parts only warranty service, HP will provide replacement parts free of charge.

For parts only warranty service, CSR part replacement is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

Réparation par le client (CSR)

Les produits HP comportent de nombreuses pièces CSR (Customer Self Repair = réparation par le client) afin de minimiser les délais de réparation et faciliter le remplacement des pièces défectueuses. Si pendant la période de diagnostic, HP (ou ses partenaires ou mainteneurs agréés) détermine que la réparation peut être effectuée à l'aide d'une pièce CSR, HP vous l'envoie directement. Il existe deux catégories de pièces CSR:

Obligatoire - Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

Facultatif - Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

REMARQUE: Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

Les pièces CSR sont livrées le jour ouvré suivant, dans la limite des stocks disponibles et selon votre situation géographique. Si votre situation géographique le permet et que vous demandez une livraison le jour même ou dans les 4 heures, celle-ci vous sera facturée. Pour bénéficier d'une assistance téléphonique, appelez le Centre d'assistance technique HP. Dans les documents envoyés avec la pièce de rechange CSR, HP précise s'il est nécessaire de lui retourner la pièce défectueuse. Si c'est le cas, vous devez le faire dans le délai indiqué, généralement cinq (5) jours ouvrés. La pièce et sa documentation doivent être retournées dans l'emballage fourni. Si vous ne retournez pas la pièce défectueuse, HP se réserve le droit de vous facturer les coûts de remplacement. Dans le cas d'une pièce CSR, HP supporte l'ensemble des frais d'expédition et de retour, et détermine la société de courses ou le transporteur à utiliser.

Pour plus d'informations sur le programme CSR de HP, contactez votre Mainteneur Agréé local. Pour plus d'informations sur ce programme en Amérique du Nord, consultez le site Web HP (<http://www.hp.com/go/selfrepair>).

Service de garantie "pièces seules"

Votre garantie limitée HP peut inclure un service de garantie "pièces seules". Dans ce cas, les pièces de rechange fournies par HP ne sont pas facturées.

Dans le cadre de ce service, la réparation des pièces CSR par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

Riparazione da parte del cliente

Per abbreviare i tempi di riparazione e garantire una maggiore flessibilità nella sostituzione di parti difettose, i prodotti HP sono realizzati con numerosi componenti che possono essere riparati direttamente dal cliente (CSR, Customer Self Repair). Se in fase di diagnostica HP (o un centro di servizi o di assistenza HP) identifica il guasto come riparabile mediante un ricambio CSR, HP lo spedisce direttamente al cliente per la sostituzione. Vi sono due categorie di parti CSR:

Obbligatorie – Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.

Opzionali – Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto.

NOTA: alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

In base alla disponibilità e alla località geografica, le parti CSR vengono spedite con consegna entro il giorno lavorativo seguente. La consegna nel giorno stesso o entro quattro ore è offerta con un supplemento di costo solo in alcune zone. In caso di necessità si può richiedere l'assistenza telefonica di un addetto del centro di supporto tecnico HP. Nel materiale fornito con una parte di ricambio CSR, HP specifica se il cliente deve restituire dei componenti. Qualora sia richiesta la resa ad HP del componente difettoso, lo si deve spedire ad HP entro un determinato periodo di tempo, generalmente cinque (5) giorni lavorativi. Il componente difettoso deve essere restituito con la documentazione associata nell'imballo di spedizione fornito. La mancata restituzione del componente può comportare la fatturazione del ricambio da parte di HP. Nel caso di riparazione da parte del cliente, HP sostiene tutte le spese di spedizione e resa e sceglie il corriere/vettore da utilizzare.

Per ulteriori informazioni sul programma CSR di HP contattare il centro di assistenza di zona. Per il programma in Nord America fare riferimento al sito Web HP (<http://www.hp.com/go/selfrepair>).

Servizio di garanzia per i soli componenti

La garanzia limitata HP può includere un servizio di garanzia per i soli componenti. Nei termini di garanzia del servizio per i soli componenti, HP fornirà gratuitamente le parti di ricambio.

Per il servizio di garanzia per i soli componenti è obbligatoria la formula CSR che prevede la riparazione da parte del cliente. Se il cliente invece richiede la sostituzione ad HP, dovrà sostenere le spese di spedizione e di manodopera per il servizio.

Customer Self Repair

HP Produkte enthalten viele CSR-Teile (Customer Self Repair), um Reparaturzeiten zu minimieren und höhere Flexibilität beim Austausch defekter Bauteile zu ermöglichen. Wenn HP (oder ein HP Servicepartner) bei der Diagnose feststellt, dass das Produkt mithilfe eines CSR-Teils repariert werden kann, sendet Ihnen HP dieses Bauteil zum Austausch direkt zu. CSR-Teile werden in zwei Kategorien unterteilt:

Zwingend – Teile, für die das Customer Self Repair-Verfahren zwingend vorgegeben ist. Wenn Sie den Austausch dieser Teile von HP vornehmen lassen, werden Ihnen die Anfahrt- und Arbeitskosten für diesen Service berechnet.

Optional – Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

HINWEIS: Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

CSR-Teile werden abhängig von der Verfügbarkeit und vom Lieferziel am folgenden Geschäftstag geliefert. Für bestimmte Standorte ist eine Lieferung am selben Tag oder innerhalb von vier Stunden gegen einen Aufpreis verfügbar. Wenn Sie Hilfe benötigen, können Sie das HP technische Support Center anrufen und sich von einem Mitarbeiter per Telefon helfen lassen. Den Materialien, die mit einem CSR-Ersatzteil geliefert werden, können Sie entnehmen, ob das defekte Teil an HP zurückgeschickt werden muss. Wenn es erforderlich ist, das defekte Teil an HP zurückzuschicken, müssen Sie dies innerhalb eines vorgegebenen Zeitraums tun, in der Regel innerhalb von fünf (5) Geschäftstagen. Das defekte Teil muss mit der zugehörigen Dokumentation in der Verpackung zurückgeschickt werden, die im Lieferumfang enthalten ist. Wenn Sie das

defekte Teil nicht zurückschicken, kann HP Ihnen das Ersatzteil in Rechnung stellen. Im Falle von Customer Self Repair kommt HP für alle Kosten für die Lieferung und Rücksendung auf und bestimmt den Kurier-/Frachtdienst.

Weitere Informationen über das HP Customer Self Repair Programm erhalten Sie von Ihrem Servicepartner vor Ort. Informationen über das CSR-Programm in Nordamerika finden Sie auf der HP Website unter (<http://www.hp.com/go/selfrepair>).

Parts-only Warranty Service (Garantieservice ausschließlich für Teile)

Ihre HP Garantie umfasst möglicherweise einen Parts-only Warranty Service (Garantieservice ausschließlich für Teile). Gemäß den Bestimmungen des Parts-only Warranty Service stellt HP Ersatzteile kostenlos zur Verfügung.

Für den Parts-only Warranty Service ist das CSR-Verfahren zwingend vorgegeben. Wenn Sie den Austausch dieser Teile von HP vornehmen lassen, werden Ihnen die Anfahrt- und Arbeitskosten für diesen Service berechnet.

Reparaciones del propio cliente

Los productos de HP incluyen muchos componentes que el propio usuario puede reemplazar (*Customer Self Repair*, CSR) para minimizar el tiempo de reparación y ofrecer una mayor flexibilidad a la hora de realizar sustituciones de componentes defectuosos. Si, durante la fase de diagnóstico, HP (o los proveedores o socios de servicio de HP) identifica que una reparación puede llevarse a cabo mediante el uso de un componente CSR, HP le enviará dicho componente directamente para que realice su sustitución. Los componentes CSR se clasifican en dos categorías:

- **Obligatorio:** componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.
- **Opcional:** componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

NOTA: Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

Según la disponibilidad y la situación geográfica, los componentes CSR se enviarán para que lleguen a su destino al siguiente día laborable. Si la situación geográfica lo permite, se puede solicitar la entrega en el mismo día o en cuatro horas con un coste adicional. Si precisa asistencia técnica, puede llamar al Centro de asistencia técnica de HP y recibirá ayuda telefónica por parte de un técnico. Con el envío de materiales para la sustitución de componentes CSR, HP especificará si los componentes defectuosos deberán devolverse a HP. En aquellos casos en los que sea necesario devolver algún componente a HP, deberá hacerlo en el periodo de tiempo especificado, normalmente cinco días laborables. Los componentes defectuosos deberán devolverse con toda la documentación relacionada y con el embalaje de envío. Si no

enviara el componente defectuoso requerido, HP podrá cobrarle por el de sustitución. En el caso de todas sustituciones que lleve a cabo el cliente, HP se hará cargo de todos los gastos de envío y devolución de componentes y escogerá la empresa de transporte que se utilice para dicho servicio.

Para obtener más información acerca del programa de Reparaciones del propio cliente de HP, póngase en contacto con su proveedor de servicios local. Si está interesado en el programa para Norteamérica, visite la página web de HP siguiente (<http://www.hp.com/go/selfrepair>).

Servicio de garantía exclusivo de componentes

La garantía limitada de HP puede que incluya un servicio de garantía exclusivo de componentes. Según las condiciones de este servicio exclusivo de componentes, HP le facilitará los componentes de repuesto sin cargo adicional alguno.

Para este servicio de garantía exclusivo de componentes, es obligatoria la sustitución de componentes por parte del usuario (CSR). Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

Customer Self Repair

Veel onderdelen in HP producten zijn door de klant zelf te repareren, waardoor de reparatieduur tot een minimum beperkt kan blijven en de flexibiliteit in het vervangen van defecte onderdelen groter is. Deze onderdelen worden CSR-onderdelen (Customer Self Repair) genoemd. Als HP (of een HP Service Partner) bij de diagnose vaststelt dat de reparatie kan worden uitgevoerd met een CSR-onderdeel, verzendt HP dat onderdeel rechtstreeks naar u, zodat u het defecte onderdeel daarmee kunt vervangen. Er zijn twee categorieën CSR-onderdelen:

Verplicht: Onderdelen waarvoor reparatie door de klant verplicht is. Als u HP verzoekt deze onderdelen voor u te vervangen, worden u voor deze service reiskosten en arbeidsloon in rekening gebracht.

Optioneel: Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garantieservice voor het product.

OPMERKING: Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

Afhankelijk van de leverbaarheid en de locatie worden CSR-onderdelen verzonden voor levering op de eerstvolgende werkdag. Levering op dezelfde dag of binnen vier uur kan tegen meerkosten worden aangeboden, indien dit mogelijk is gezien de locatie. Indien assistentie gewenst is, belt u een HP Service Partner om via de telefoon technische ondersteuning te ontvangen. HP vermeldt in de documentatie bij het vervangende CSR-onderdeel of het defecte onderdeel aan HP moet worden geretourneerd. Als het defecte onderdeel aan HP moet worden teruggezonden, moet u het defecte onderdeel binnen een bepaalde periode, gewoonlijk vijf (5) werkdagen, retourneren aan HP. Het defecte onderdeel moet met de bijbehorende documentatie worden geretourneerd in het meegeleverde verpakkingsmateriaal. Als u het defecte onderdeel niet terugzendt, kan HP u voor het vervangende onderdeel kosten in rekening brengen. Bij reparatie door de klant betaalt HP alle verzendkosten voor het vervangende en geretourneerde onderdeel en kiest HP zelf welke koerier/transportonderneming hiervoor wordt gebruikt.

Neem contact op met een Service Partner voor meer informatie over het Customer Self Repair programma van HP. Informatie over Service Partners vindt u op de HP website (<http://www.hp.com/go/selfrepair>).

Garantieservice "Parts Only"

Het is mogelijk dat de HP garantie alleen de garantieservice "Parts Only" omvat. Volgens de bepalingen van de Parts Only garantieservice zal HP kosteloos vervangende onderdelen ter beschikking stellen.

Voor de Parts Only garantieservice is vervanging door CSR-onderdelen verplicht. Als u HP verzoekt deze onderdelen voor u te vervangen, worden u voor deze service reiskosten en arbeidsloon in rekening gebracht.

Reparo feito pelo cliente

Os produtos da HP são projetados com muitas peças para reparo feito pelo cliente (CSR) de modo a minimizar o tempo de reparo e permitir maior flexibilidade na substituição de peças com defeito. Se, durante o período de diagnóstico, a HP (ou fornecedores/parceiros de serviço da HP) concluir que o reparo pode ser efetuado pelo uso de uma peça CSR, a peça de reposição será enviada diretamente ao cliente. Existem duas categorias de peças CSR:

Obrigatória – Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

Opcional – Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

OBSERVAÇÃO: Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

Conforme a disponibilidade e o local geográfico, as peças CSR serão enviadas no primeiro dia útil após o pedido. Onde as condições geográficas permitirem, a entrega no mesmo dia ou em quatro horas pode ser feita mediante uma taxa adicional. Se precisar de auxílio, entre em contato com o Centro de suporte técnico da HP para que um técnico o ajude por telefone. A HP especifica nos materiais fornecidos com a peça CSR de reposição se a peça com defeito deve ser devolvida à HP. Nos casos em que isso for necessário, é preciso enviar a peça com defeito à HP dentro do período determinado, normalmente cinco (5) dias úteis. A peça com defeito deve ser enviada com a documentação correspondente no material de transporte fornecido. Caso não o faça, a HP poderá cobrar a reposição. Para as peças de reparo feito pelo cliente, a HP paga todas as despesas de transporte e de devolução da peça e determina a transportadora/serviço postal a ser utilizado.

Para obter mais informações sobre o programa de reparo feito pelo cliente da HP, entre em contato com o fornecedor de serviços local. Para o programa norte-americano, visite o site da HP (<http://www.hp.com/go/selfrepair>).

Serviço de garantia apenas para peças

A garantia limitada da HP pode incluir um serviço de garantia apenas para peças. Segundo os termos do serviço de garantia apenas para peças, a HP fornece as peças de reposição sem cobrar nenhuma taxa.

No caso desse serviço, a substituição de peças CSR é obrigatória. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

顧客自己修理保証サービス

修理時間を短縮し、故障部品の交換における高い柔軟性を確保するために、HP製品には多数の顧客自己修理（CSR）部品があります。診断の際に、CSR部品を使用すれば修理ができるとHP（HPまたはHP正規保守代理店）が判断した場合、HPはその部品を直接、お客様に発送し、お客様に交換していただきます。CSR部品には以下の2通りがあります。

- 必須 - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。
- 任意 - 顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、別途費用を負担していただくことなく保証サービスを受けることができます。

注： HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

部品供給が可能な場合、地域によっては、CSR部品を翌営業日に届くように発送します。また、地域によっては、追加費用を負担いただくことにより同日または4時間以内に届くように発送することも可能な場合があります。サポートが必要なときは、HPの修理受付窓口にご電話いただければ、技術者が電話でアドバイスします。交換用のCSR部品または同梱物には、故障部品をHPに返送する必要があるかどうかが表示されています。故障部品をHPに返送する必要がある場合は、指定期限内（通常は5営業日以内）に故障部品をHPに返送してください。故障部品を返送する場合は、届いた時の梱包箱に関連書類とともに入れてください。故障部品を返送しない場合、HPから部品費用が請求されます。顧客自己修理の際には、HPは送料および部品返送費を全額負担し、使用する宅配便会社や運送会社を指定します。

部品のみ保証サービス

HP保証サービスには、部品のみ保証サービスが適用される場合があります。このサービスでは、交換部品は無償で提供されます。

部品のみ保証サービスにおいては、CSR部品をお客様により交換作業していただくことが必須となります。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費はお客様の負担となります。

客户自行维修

HP 产品提供许多客户自行维修 (CSR) 部件，以尽可能缩短维修时间和在更换缺陷部件方面提供更大的灵活性。如果在诊断期间 HP（或 HP 服务提供商或服务合作伙伴）确定可以通过使用 CSR 部件完成维修，HP 将直接把该部件发送给您进行更换。有两类 CSR 部件：

- **强制性的** — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。
- **可选的** — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据为您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

注：某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

CSR 部件将在下一个工作日发运（取决于备货情况和允许的地理范围）。在允许的地理范围内，可在当天或四小时内发运，但要收取额外费用。如果需要帮助，您可以致电 HP 技术支持中心，将会有技术人员通过电话为您提供帮助。HP 会在随更换的 CSR 部件发运的材料中指明是否必须将有缺陷的部件返还给 HP。如果要求您将有缺陷的部件返还给 HP，那么您必须在规定期限内（通常是五 (5) 个工作日）将缺陷部件发给 HP。有缺陷的部件必须随所提供的发运材料中的相关文件一起返还。如果未能送还有缺陷的部件，HP 可能会要求您支付更换费用。客户自行维修时，HP 将承担所有相关运输和部件返回费用，并指定快递商/承运商。

有关 HP 客户自行维修计划的详细信息，请与您当地的服务提供商联系。有关北美地区的计划，请访问 HP 网站 (<http://www.hp.com/go/selfrepair>)。

仅部件保修服务

您的 HP 有限保修服务可能涉及仅部件保修服务。根据仅部件保修服务条款的规定，HP 将免费提供更换的部件。

仅部件保修服务要求进行 CSR 部件更换。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

客戶自行維修

HP 產品設計了許多「客戶自行維修」(CSR) 的零件以減少維修時間，並且使得更換瑕疵零件時能有更大的彈性。如果在診斷期間 HP（或 HP 服務供應商或維修夥伴）辨認出此項維修工作可以藉由使用 CSR 零件來完成，則 HP 將直接寄送該零件給您作更換。CSR 零件分為兩種類別：

- **強制的** — 客戶自行維修所使用的零件是強制性的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。
- **選購的** — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。

備註：某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

基於材料取得及環境允許的情況下，CSR 零件將於下一個工作日以快遞寄送。在環境的允許下當天或四小時內送達，則可能需要額外的費用。若您需要協助，可致電「HP 技術支援中心」，會有一位技術人員透過電話來協助您。不論損壞的零件是否必須退回，HP 皆會在與 CSR 替換零件一起運送的材料中註明。若要將損壞的零件退回 HP，您必須在指定的一段時間內（通常為五 (5) 個工作天），將損壞的零件寄回 HP。損壞的零件必須與寄送資料中隨附的相關技術文件一併退還。如果無法退還損壞的零件，HP 可能要向您收取替換費用。針對客戶自行維修情形，HP 將負責所有運費及零件退還費用並指定使用何家快遞/貨運公司。

如需 HP 的「客戶自行維修」方案詳細資訊，請連絡您當地的服務供應商。至於北美方案，請參閱 HP 網站 (<http://www.hp.com/go/selfrepair>)。

僅限零件的保固服務

您的「HP 有限保固」可能包含僅限零件的保固服務。在僅限零件的保固服務情況下，HP 將免費提供替換零件。

針對僅限零件的保固服務，CSR 零件替換是強制性的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

고객 셀프 수리

HP 제품은 수리 시간을 최소화하고 결함이 있는 부품 교체 시 더욱 융통성을 발휘할 수 있도록 하기 위해 고객 셀프 수리(CSR) 부품을 다량 사용하여 설계되었습니다. 진단 기간 동안 HP(또는 HP 서비스 공급업체 또는 서비스 협력업체)에서 CSR 부품을 사용하여 수리가 가능하다고 판단되면 HP는 해당 부품을 바로 사용자에게 보내어 사용자가 교체할 수 있도록 합니다. CSR 부품에는 두 가지 종류가 있습니다.

- **고객 셀프 수리가 의무 사항인 필수 부품.** 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.
- **고객 셀프 수리가 선택 사항인 부품.** 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

참고: 일부 HP 부품은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 만족스러운 고객 보증을 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다. 이러한 부품들은 Illustrated Parts Catalog에 "No"라고 표시되어 있습니다.

CSR 부품은 재고 상태와 지리적 조건이 허용하는 경우 다음 영업일 납품이 가능하도록 배송이 이루어집니다. 지리적 조건이 허용하는 경우 추가 비용이 청구되는 조건으로 당일 또는 4시간 배송이 가능할 수도 있습니다. 도움이 필요하시면 HP 기술 지원 센터로 전화하십시오. 전문 기술자가 전화로 도움을 줄 것입니다. HP는 결함이 발생한 부품을 HP로 반환해야 하는지 여부를 CSR 교체 부품과 함께 배송된 자료에 지정합니다. 결함이 발생한 부품을 HP로 반환해야 하는 경우에는 지정된 기간 내(통상 영업일 기준 5일)에 HP로 반환해야 합니다. 이 때 결함이 발생한 부품은 제공된 포장 재료에 넣어 관련 설명서와 함께 반환해야 합니다. 결함이 발생한 부품을 반환하지 않는 경우 HP가 교체 부품에 대해 비용을 청구할 수 있습니다. 고객 셀프 수리의 경우, HP는 모든 운송 및 부품 반환 비용을 부담하며 이용할 운송업체 및 택배 서비스를 결정합니다.

HP 고객 셀프 수리 프로그램에 대한 자세한 내용은 가까운 서비스 제공업체에 문의하십시오. 북미 지역의 프로그램에 대해서는 HP 웹 사이트(<http://www.hp.com/go/selfrepair>)를 참조하십시오.


부품 제공 보증 서비스

HP 제한 보증에는 부품 제공 보증 서비스가 포함될 수 있습니다. 이러한 경우 HP는 부품 제공 보증 서비스의 조건에 따라 교체 부품만을 무료로 제공합니다.

부품 제공 보증 서비스 제공 시 CSR 부품 교체는 의무 사항입니다. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

Illustrated parts catalog

Mechanical components



Item	Description	Spare part number	Customer self repair (on page 5)
1	Front bezel	519731-001	Mandatory ¹
2	Hard drive blank	459187-001	Mandatory ¹
3	Access panel	460024-001	Mandatory ¹
4	Air baffle	536643-001	Mandatory ¹

¹Mandatory—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

²Optional—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

³No—Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

¹Mandatory: Obligatoire—Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

²Optional: Facultatif—Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

³No: Non—Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

¹Mandatory: Obbligatorie—Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.

²Optional: Opzionali—Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese aggiuntive a seconda del tipo di garanzia previsto per il prodotto.

³No: Non CSR—Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

¹Mandatory: Zwingend—Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand- und Arbeitskosten für diesen Service berechnet.

²Optional: Optional—Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

³No: Kein—Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

¹Mandatory: Obligatorio—componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

²Optional: Opcional— componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

³No: No—Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

¹Mandatory: Verplicht—Onderdelen waarvoor Customer Self Repair verplicht is. Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening.

²Optional: Optioneel—Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garantieservice voor het product.

³No: Nee—Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievoorwaarden moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

¹Mandatory: Obrigatória—Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

²Optional: Opcional—Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

³No: Nenhuma—Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

¹Mandatory : 必須 - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。

²Optional : 任意 - 顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、費用を負担していただくことなく保証サービスを受けることができます。

³No : 除外 - HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

¹Mandatory: 强制性的 — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

²Optional: 可选的 — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据为您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

³No: 否 — 某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

¹Mandatory: 強制的 — 客戶自行維修所使用的零件是強制的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

²Optional: 選購的 — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。


³No: 否 — 某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

¹ Mandatory: 필수 — 고객 셀프 수리가 의무 사항인 필수 부품. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

² Optional: 옵션 — 고객 셀프 수리가 선택 사항인 부품. 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

³ No: No — 고객 셀프 수리가 불가능하도록 설계된 HP 부품. 이 부품들은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 고객 보증을 만족시키기 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다.

System components



Item	Description	Spare part number	Customer self repair (on page 5)
5	Hard drive fan assembly with holder (fan 3)	487109-001	Mandatory ¹
6	Hard drive fan assembly with holder (fan 1 or fan 1.5)	536632-001	Mandatory ¹
7	Rear fan assembly (with holder)	519740-001	Mandatory ¹
8	DVD-RW drive	447466-001	Mandatory ¹
9	Hot-plug expansion hard drive cage	519733-001	Mandatory ¹
	Hard drives		
10	LFF SATA hard drives	—	—
	a) 80-GB, 7200-rpm, hot-plug	397551-001	Mandatory ¹
	b) 160-GB, 7200-rpm, hot-plug*	397552-001	Mandatory ¹
	c) 160-GB, 7200-rpm, hot-plug, NCQ*	483095-001	Mandatory ¹
	d) 250-GB, 7200-rpm, hot-plug*	397553-001	Mandatory ¹
	e) 250-GB, 7200-rpm, hot-plug, NCQ*	459318-001	Mandatory ¹
	f) 500-GB, 7200-rpm, hot-plug*	395501-001	Mandatory ¹
	g) 500-GB, 7200-rpm, hot-plug*	495319-001	Mandatory ¹
	h) 750-GB, 7200-rpm, hot-plug, NCQ*	432401-001	Mandatory ¹
	i) 750-GB, 7200-rpm, hot-plug, 3G, NCQ*	459320-001	Mandatory ¹
	j) 1-TB, 7200-rpm, hot-plug, 3G, NCQ*	454273-001	Mandatory ¹

Item	Description	Spare part number	Customer self repair (on page 5)
	k) 2-TB, 7200-rpm, hot-plug, 3G, NCQ*	508040-001	Mandatory ¹
11	LFF SAS hard drives*	—	—
	a) 72-GB, 15,000-rpm, hot-plug*	376594-001	Mandatory ¹
	b) 72-GB, 15,000-rpm, hot-plug, dual-port*	389343-001	Mandatory ¹
	c) 146-GB, 15,000-rpm, hot-plug*	376595-001	Mandatory ¹
	d) 146-GB, 15,000-rpm, hot-plug, dual-port*	389344-001	Mandatory ¹
	e) 300-GB, 15,000-rpm, hot-plug, dual-port*	416248-001	Mandatory ¹
	f) 300-GB, 15,000-rpm, hot-plug, dual-port*	432146-001	Mandatory ¹
	g) 400-GB, 10,000-rpm, hot-plug*	456896-001	Mandatory ¹
	h) 450-GB, 15,000-rpm, hot-plug, dual-port*	454274-001	Mandatory ¹
	i) 750-GB, 15,000-rpm, hot-plug*	461288-001	Mandatory ¹
	j) 1-TB, 15,000-rpm, hot-plug*	461289-001	Mandatory ¹
	k) 1-TB, 7200-rpm, hot-plug*	508011-001	Mandatory ¹
	l) 2-TB, 7200-rpm, hot-plug*	508010-001	Mandatory ¹
	m) 300-GB, 6G/s*	586875-001	Mandatory ¹
	n) 450-GB, 6G/s*	586876-001	Mandatory ¹
	o) 600-GB, 6G/s*	586877-001	Mandatory ¹
	p) 1-TB, 6G/s*	601884-001	Mandatory ¹
	q) 2-TB, 6G/s*	601883-001	Mandatory ¹
12	System board	536623-001	Mandatory ¹
	Memory		
13	RDIMM	—	—
	a) 2-GB PC3-10600 (DDR3-1333) (RoHS)	501533-001	Mandatory ¹
	b) 4-GB PC3-10600 (DDR3-1333) (RoHS)*	501534-001	Mandatory ¹
	c) 4-GB PC3-8500 (DDR3-1066) (RoHS)*	501535-001	Mandatory ¹
	d) 8-GB PC3-8500 (DDR3-1066) (RoHS)*	501537-001	Mandatory ¹
	e) 16-GB PC3-8500 (DDR3-1066) (RoHS)	501538-001	Mandatory ¹
	f) PC3L-10600 (DDR3-1333) 4-GB (low voltage)* **	595422-001	Mandatory ¹
	g) PC3L-10600 (DDR3-1333) 8-GB (low voltage)* **	595423-001	Mandatory ¹
14	UDIMM*	—	—
	a) PC3-10600 (DDR3-1333) 1-GB (RoHS)	501539-001	Mandatory ¹
	b) PC3-10600 (DDR3-1333) 2-GB (RoHS)	501540-001	Mandatory ¹
	c) PC3-10600 (DDR2-1333) 4-GB (RoHS)	501541-001	Mandatory ¹
15	Heatsink	—	—

Item	Description	Spare part number	Customer self repair (on page 5)
	a) Heatsink, system board	519067-001	Mandatory ¹
	b) Heatsink, processor board*	519326-001	Mandatory ¹
16	System battery	234556-001	Mandatory ¹
17	Processors	—	—
	a) 2.00-GHz Intel® Xeon® E5503 processor	594889-001	Optional ²
	b) 2.13-GHz Intel® Xeon® E5506 processor*	506013-001	Optional ²
	c) 2.40-GHz Intel® Xeon® E5620 processor*	594887-001	Optional ²
	d) 2.53-GHz Intel® Xeon® E5630 processor*	594886-001	Optional ²
	e) 2.66-GHz Intel® Xeon® E5640 processor*	594885-001	Optional ²
	f) 2.66-GHz Intel® Xeon® W3520 processor*	612164-001	Optional ²
	g) 2.66-GHz Intel® Xeon® X5650 processor*	594884-001	Optional ²
	h) 2.53-GHz Intel® Xeon® E5649 processor*	628695-001	Optional ²
	i) 2.40-GHz Intel® Xeon® E5645 processor*	628696-001	Optional ²
	j) 2.26-GHz Intel® Xeon® E5607 processor*	628698-001	Optional ²
	k) 2.13-GHz Intel® Xeon® E5606 processor*	628699-001	Optional ²
	l) 1.60-GHz Intel® Xeon® E5603 processor*	628700-001	Optional ²
	m) 2.53-GHz Intel® Xeon® E5540 processor*	490071-001	Optional ²
	n) 2.26-GHz Intel® Xeon® E5520 processor*	490073-001	Optional ²
	o) 2.26-GHz Intel® Xeon® E5507 processor*	594888-001	Optional ²
	p) 2.00-GHz Intel® Xeon® E5504 processor*	490074-001	Optional ²
	q) 1.86-GHz Intel® Xeon® E5502 processor*	490075-001	Optional ²
	r) 2.53-GHz Intel® Xeon® W3505 processor*	538619-001	Optional ²
	s) 2.40-GHz Intel® Xeon® W3503 processor*	538618-001	Optional ²
	t) 2.93-GHz Intel® Xeon® W3540 processor*	517817-001	Optional ²
	u) 2.40-GHz Intel® Xeon® E5530 processor*	490072-001	Optional ²
	v) 3.06-GHz Intel® Xeon® W3550 processor*	612165-001	Optional ²
18	Hot-plug power supply, 460-W	536404-001	Mandatory ¹
19	Processor board*	536624-001	Mandatory ¹
20	Metal board, processor board*	536625-001	Mandatory ¹
21	Power backplane, DC converter, 750-W, 2U*	536628-001	Mandatory ¹
22	Non-hot-plug hard drive expansion cage*	536630-001	Mandatory ¹
23	Redundant power supply cable	—	—
	a) 24-pin to 24-pin cable*	536638-001	Mandatory ¹
	b) 8-pin to 8-pin cable*	536640-001	Mandatory ¹
	c) Redundant power supply, HDD converter*	536641-001	Mandatory ¹

Item	Description	Spare part number	Customer self repair (on page 5)
	d) Redundant power supply, ODD converter*	536642-001	Mandatory ¹
24	Mini-SAS cable*	536639-001	Mandatory ¹
25	PCI-X extender board*	536636-001	Mandatory ¹
26	PCIe pass-through board*	536637-001	Mandatory ¹
	Cables		
27	Optical drive cable*	459189-001	Mandatory ¹
28	SAS/SATA hard drive cable*	459190-001	Mandatory ¹
29	SAS hard drive cable*	459934-001	Mandatory ¹
30	Power button/LED cable*	459186-001	Mandatory ¹
31	Temperature sensor cable*	460423-001	Mandatory ¹
32	Front USB cable*	459184-001	Mandatory ¹
33	Non-hot-plug SATA drive data cable*	448180-001	Mandatory ¹
34	Non-hot-plug SAS drive data cable*	487736-001	Mandatory ¹
35	Hot-plug SAS drive data cable*	493228-006	Mandatory ¹
36	Hard drive LED cable*	508543-001	Mandatory ¹
	Miscellaneous		
37	T-10/T-15 Torx screwdriver*	413965-001	Mandatory ¹
38	Bezel key*	405168-001	Mandatory ¹
	Options		
39	Diskette drive*	392545-001	Mandatory ¹
40	HP Smart Array Controllers*	—	—
	a) HP Smart Array E200 Controller*	412749-001	Mandatory ¹
	b) HP Smart Array E500 Controller*	444843-001	Mandatory ¹
	c) HP Smart Array P212 Controller*	462594-001	Mandatory ¹
	d) HP Smart Array P400 Controller*	405832-001	Mandatory ¹
	e) HP Smart Array P410 Controller*	462919-001	Mandatory ¹
	f) HP Smart Array P411 Controller*	462918-001	Mandatory ¹
	g) HP Smart Array P800 Controller*	398647-001	Mandatory ¹
41	HP Smart Array cache module	—	—
	a) Smart Array cache module, 256 MB* (Smart Array P212, P410 and P411 controllers only)	462974-001	Optional ²
	b) Smart Array cache module, 512 MB* (Smart Array P212, P410 and P411 controllers only)	462975-001	Optional ²
42	Smart Array BBWC battery*	462976-001	Optional ²
43	Smart Array BBWC battery cable*	—	—
	a) 14-in cable*	488137-001	Optional ²
	b) 24-in cable*	488138-001	Optional ²
44	FBWC capacitor pack*	587324-001	Optional ²
45	FBWC module, 512-MB*	578882-001	Optional ²

Item	Description	Spare part number	Customer self repair (on page 5)
46	FBWC module, 1-GB*	505908-001	Optional ²
47	HP Trusted Platform Module*	505836-001	No ³

* Not shown

** If LVDIMMs are mixed with standard DDR3 DIMMs on the same server, the LVDIMMs operate at 1.5V. LVDIMMs are only supported for use with the Intel® Xeon® 5600 series of processors.

¹Mandatory—Parts for which customer self repair is mandatory. If you request HP to replace these parts, you will be charged for the travel and labor costs of this service.

²Optional—Parts for which customer self repair is optional. These parts are also designed for customer self repair. If, however, you require that HP replace them for you, there may or may not be additional charges, depending on the type of warranty service designated for your product.

³No—Some HP parts are not designed for customer self repair. In order to satisfy the customer warranty, HP requires that an authorized service provider replace the part. These parts are identified as "No" in the Illustrated Parts Catalog.

¹Mandatory: Obligatoire—Pièces pour lesquelles la réparation par le client est obligatoire. Si vous demandez à HP de remplacer ces pièces, les coûts de déplacement et main d'œuvre du service vous seront facturés.

²Optional: Facultatif—Pièces pour lesquelles la réparation par le client est facultative. Ces pièces sont également conçues pour permettre au client d'effectuer lui-même la réparation. Toutefois, si vous demandez à HP de remplacer ces pièces, l'intervention peut ou non vous être facturée, selon le type de garantie applicable à votre produit.

³No: Non—Certaines pièces HP ne sont pas conçues pour permettre au client d'effectuer lui-même la réparation. Pour que la garantie puisse s'appliquer, HP exige que le remplacement de la pièce soit effectué par un Mainteneur Agréé. Ces pièces sont identifiées par la mention "Non" dans le Catalogue illustré.

¹Mandatory: Obbligatorie—Parti che devono essere necessariamente riparate dal cliente. Se il cliente ne affida la riparazione ad HP, deve sostenere le spese di spedizione e di manodopera per il servizio.

²Optional: Opzionali—Parti la cui riparazione da parte del cliente è facoltativa. Si tratta comunque di componenti progettati per questo scopo. Se tuttavia il cliente ne richiede la sostituzione ad HP, potrebbe dover sostenere spese addizionali a seconda del tipo di garanzia previsto per il prodotto.

³No: Non CSR—Alcuni componenti HP non sono progettati per la riparazione da parte del cliente. Per rispettare la garanzia, HP richiede che queste parti siano sostituite da un centro di assistenza autorizzato. Tali parti sono identificate da un "No" nel Catalogo illustrato dei componenti.

¹Mandatory: Zwingend—Teile, die im Rahmen des Customer Self Repair Programms ersetzt werden müssen. Wenn Sie diese Teile von HP ersetzen lassen, werden Ihnen die Versand- und Arbeitskosten für diesen Service berechnet.

²Optional: Optional—Teile, für die das Customer Self Repair-Verfahren optional ist. Diese Teile sind auch für Customer Self Repair ausgelegt. Wenn Sie jedoch den Austausch dieser Teile von HP vornehmen lassen möchten, können bei diesem Service je nach den für Ihr Produkt vorgesehenen Garantiebedingungen zusätzliche Kosten anfallen.

³No: Kein—Einige Teile sind nicht für Customer Self Repair ausgelegt. Um den Garantieanspruch des Kunden zu erfüllen, muss das Teil von einem HP Servicepartner ersetzt werden. Im illustrierten Teilekatalog sind diese Teile mit „No“ bzw. „Nein“ gekennzeichnet.

¹Mandatory: Obligatorio—componentes para los que la reparación por parte del usuario es obligatoria. Si solicita a HP que realice la sustitución de estos componentes, tendrá que hacerse cargo de los gastos de desplazamiento y de mano de obra de dicho servicio.

²Optional: Opcional— componentes para los que la reparación por parte del usuario es opcional. Estos componentes también están diseñados para que puedan ser reparados por el usuario. Sin embargo, si precisa que HP realice su sustitución, puede o no conllevar costes adicionales, dependiendo del tipo de servicio de garantía correspondiente al producto.

³No: No—Algunos componentes no están diseñados para que puedan ser reparados por el usuario. Para que el usuario haga valer su garantía, HP pone como condición que un proveedor de servicios autorizado realice la sustitución de estos componentes. Dichos componentes se identifican con la palabra "No" en el catálogo ilustrado de componentes.

¹Mandatory: Verplicht—Onderdelen waarvoor Customer Self Repair verplicht is. Als u HP verzoekt deze onderdelen te vervangen, komen de reiskosten en het arbeidsloon voor uw rekening.

²Optional: Optioneel—Onderdelen waarvoor reparatie door de klant optioneel is. Ook deze onderdelen zijn ontworpen voor reparatie door de klant. Als u echter HP verzoekt deze onderdelen voor u te vervangen, kunnen daarvoor extra kosten in rekening worden gebracht, afhankelijk van het type garanteservice voor het product.

³No: Nee—Sommige HP onderdelen zijn niet ontwikkeld voor reparatie door de klant. In verband met de garantievooraardelen moet het onderdeel door een geautoriseerde Service Partner worden vervangen. Deze onderdelen worden in de geïllustreerde onderdelencatalogus aangemerkt met "Nee".

¹Mandatory: Obrigatória—Peças cujo reparo feito pelo cliente é obrigatório. Se desejar que a HP substitua essas peças, serão cobradas as despesas de transporte e mão-de-obra do serviço.

²Optional: Opcional—Peças cujo reparo feito pelo cliente é opcional. Essas peças também são projetadas para o reparo feito pelo cliente. No entanto, se desejar que a HP as substitua, pode haver ou não a cobrança de taxa adicional, dependendo do tipo de serviço de garantia destinado ao produto.

³No: Nenhuma—Algumas peças da HP não são projetadas para o reparo feito pelo cliente. A fim de cumprir a garantia do cliente, a HP exige que um técnico autorizado substitua a peça. Essas peças estão identificadas com a marca "No" (Não), no catálogo de peças ilustrado.

¹Mandatory : 必須 - 顧客自己修理が必須の部品。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、その修理サービスに関する交通費および人件費がお客様に請求されます。

²Optional : 任意 - 顧客自己修理が任意である部品。この部品も顧客自己修理用です。当該部品について、もしもお客様がHPに交換作業を依頼される場合には、お買い上げの製品に適用される保証サービス内容の範囲内においては、費用を負担していただくことなく保証サービスを受けることができます。

³No : 除外 - HP製品の一部の部品は、顧客自己修理用ではありません。製品の保証を継続するためには、HPまたはHP正規保守代理店による交換作業が必須となります。部品カタログには、当該部品が顧客自己修理除外品である旨が記載されています。

¹Mandatory: 强制性的 — 要求客户必须自行维修的部件。如果您请求 HP 更换这些部件，则必须为该服务支付差旅费和人工费用。

²Optional: 可选的 — 客户可以选择是否自行维修的部件。这些部件也是为客户自行维修设计的。不过，如果您要求 HP 为您更换这些部件，则根据为您的产品指定的保修服务类型，HP 可能收取或不再收取任何附加费用。

³No: 否 — 某些 HP 部件的设计并未考虑客户自行维修。为了满足客户保修的需要，HP 要求授权服务提供商更换相关部件。这些部件在部件图解目录中标记为“否”。

¹Mandatory: 強制的 — 客戶自行維修所使用的零件是強制的。如果您要求 HP 更換這些零件，HP 將會向您收取此服務所需的外出費用與勞動成本。

²Optional: 選購的 — 客戶自行維修所使用的零件是選購的。這些零件也設計用於客戶自行維修之用。不過，如果您要求 HP 為您更換，則可能需要也可能不需要負擔額外的費用，端視針對此產品指定的保固服務類型而定。

³No: 否 — 某些 HP 零件沒有消費者可自行維修的設計。為符合客戶保固，HP 需要授權的服務供應商更換零件。這些零件在圖示的零件目錄中，被標示為「否」。

¹ Mandatory: 필수 — 고객 셀프 수리가 의무 사항인 필수 부품. 사용자가 HP에 이 부품의 교체를 요청할 경우 이 서비스에 대한 출장비 및 작업비가 청구됩니다.

² Optional: 옵션 — 고객 셀프 수리가 선택 사항인 부품. 이 부품들도 고객 셀프 수리가 가능하도록 설계되었습니다. 하지만 사용자가 HP에 이 부품의 교체를 요청할 경우 사용자가 구입한 제품에 해당하는 보증 서비스 유형에 따라 추가 비용 없이 교체가 가능할 수 있습니다.

³ No: No — 고객 셀프 수리가 불가능하도록 설계된 HP 부품. 이 부품들은 고객 셀프 수리가 불가능하도록 설계되었습니다. HP는 고객 보증을 만족시키기 위해 공인 서비스 제공업체를 통해 부품을 교체하도록 하고 있습니다.

Removal and replacement procedures

Required tools

You need the following items for some procedures:

- T-10/T-15 Torx screwdriver (included with the server)
- HP Insight Diagnostics software ("[HP Insight Diagnostics](#)" on page 78)

Safety considerations

Before performing service procedures, review all the safety information.

Preventing electrostatic discharge

To prevent damaging the system, be aware of the precautions you need to follow when setting up the system or handling parts. A discharge of static electricity from a finger or other conductor may damage system boards or other static-sensitive devices. This type of damage may reduce the life expectancy of the device.

To prevent electrostatic damage:

- Avoid hand contact by transporting and storing products in static-safe containers.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free workstations.
- Place parts on a grounded surface before removing them from their containers.
- Avoid touching pins, leads, or circuitry.
- Always be properly grounded when touching a static-sensitive component or assembly.

Server warnings and cautions

Before installing a server, be sure that you understand the following warnings and cautions.



WARNING: To reduce the risk of electric shock or damage to the equipment:

- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
 - Plug the power cord into a grounded (earthed) electrical outlet that is easily accessible at all times.
 - Unplug the power cord from the power supply to disconnect power to the equipment.
 - Do not route the power cord where it can be walked on or pinched by items placed against it. Pay particular attention to the plug, electrical outlet, and the point where the cord extends from the server.
-



WARNING: To reduce the risk of personal injury from hot surfaces, allow the drives and the internal system components to cool before touching them.

-
-  **WARNING:** To reduce the risk of personal injury, electric shock, or damage to the equipment, remove the power cord to remove power from the server. The front panel Power On/Standby button does not completely shut off system power. Portions of the power supply and some internal circuitry remain active until AC power is removed.
-
-  **CAUTION:** Do not operate the server for long periods with the access panel open or removed. Operating the server in this manner results in improper airflow and improper cooling that can lead to thermal damage.
-
-  **CAUTION:** Protect the server from power fluctuations and temporary interruptions with a regulating uninterruptible power supply (UPS). This device protects the hardware from damage caused by power surges and voltage spikes and keeps the system in operation during a power failure.
-

Rack warnings

-
-  **WARNING:** To reduce the risk of personal injury or damage to the equipment, be sure that:
- The leveling jacks are extended to the floor.
 - The full weight of the rack rests on the leveling jacks.
 - The stabilizing feet are attached to the rack if it is a single-rack installation.
 - The racks are coupled together in multiple-rack installations.
 - Only one component is extended at a time. A rack may become unstable if more than one component is extended for any reason.
-
-  **WARNING:** To reduce the risk of personal injury or equipment damage when unloading a rack:
- At least two people are needed to safely unload the rack from the pallet. An empty 42U rack can weigh as much as 115 kg (253 lb), can stand more than 2.1 m (7 ft) tall, and may become unstable when being moved on its casters.
 - Never stand in front of the rack when it is rolling down the ramp from the pallet. Always handle the rack from both sides.
-
-  **WARNING:** When installing a server in a telco rack, be sure that the rack frame is adequately secured to the top and bottom of the building structure.
-
-  **WARNING:** This server is very heavy. To reduce the risk of personal injury or damage to the equipment:
- Observe local occupational health and safety requirements and guidelines for manual material handling.
 - Get help to lift and stabilize the product during installation or removal, especially when the product is not fastened to the rails. When the server weighs more than 22.5 kg (50 lb), at least two people must lift the server into the rack together. A third person may be required to help align the server if the server is installed higher than chest level.
 - Use caution when installing the server in or removing the server from the rack; it is unstable when not fastened to the rails.
-

Preparation procedures

Power down the server



WARNING: To reduce the risk of personal injury, electric shock, or damage to the equipment, remove the power cord to remove power from the server. The front panel Power On/Standby button does not completely shut off system power. Portions of the power supply and some internal circuitry remain active until AC power is removed.



IMPORTANT: If installing a hot-plug device, it is not necessary to power down the server.


1. Shut down the OS as directed by the OS documentation.
2. Press the Power On/Standby button to place the server in standby mode. When the server enters standby power mode, the system power LED changes to amber.
3. Disconnect the power cords.

The system is now without power.

Remove the server from the rack


If the server is installed with an optional rack enabling kit, remove the server from the rack before beginning any service procedures.

1. Power down the server (on page 27).
2. Disconnect peripheral device and power cables.
3. Loosen the thumbscrews and slide the locking bracket backward.



4. Extend the server and tray from the rack.
5. Disconnect the straps securing the server to the tray.

6. Remove the server from the tray and place it on a flat work surface.



Bezel

This server has a removable bezel that must be unlocked and opened before accessing the front panel components. The bezel should remain closed during normal server operations.


△ **CAUTION:** To avoid injury, HP recommends that only authorized technicians keep the bezel key.

△ **CAUTION:** To avoid breaking the bezel, remove the bezel before placing the server on its side.

To remove the component:

1. Power down the server (on page [27](#)).
2. Using the key provided with the server, unlock the bezel.

3. Remove the bezel.




To replace the component, reverse the removal procedure.

Bezel blank

To remove the component:

1. Power down the server (on page 27).
2. Remove the bezel ("[Bezel](#)" on page 28).
3. Remove a bezel blank.



To replace the component, reverse the removal procedure.

Access panel

To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Extend the server from the rack ("Remove the server from the rack" on page 27).
3. Loosen the access panel screws.
4. Slide the access panel back about 1.5 cm (0.5 in).
5. Lift and remove the access panel.

CAUTION: For proper cooling, do not operate the server without the access panel, baffles, expansion slot covers, hard drives, or blanks installed.

To replace the component, reverse the removal procedure.


Media bay blank

To remove the component:

1. Power down the server (on page 27).
2. Open or remove the tower bezel, as needed ("Bezel" on page 28).

CAUTION: Always populate each media bay with either a device or a blank. Proper airflow can only be maintained when the bays are populated. Unpopulated drive bays can lead to improper cooling and thermal damage.


3. Remove the media bay blank.



To replace the component, reverse the removal procedure.

Hard drive blank

Remove the component as indicated.



To replace the component, slide the component into the bay until it clicks.

Hot-plug hard drives

To remove the component:



CAUTION: To prevent improper cooling and thermal damage, do not operate the server unless all bays are populated with either a component or a blank.


1. Determine the status of the hard drive from the hot-plug hard drive LEDs ("[Hot-plug SATA or SAS hard drive LEDs](#)" on page 91).



IMPORTANT: When hot-plug SATA hard drives are installed, SATA LED functionality and full SATA hot-plug capability are not supported with the embedded controller. For full LED and hot-plug support, an optional SATA RAID or SAS controller must be installed.

2. Unlock and open the bezel ("[Bezel](#)" on page 28).

3. Remove the hard drive.



To replace the component:

1. Slide the drive into the cage until it clicks, locking the drive into place.
2. Close the lever.



IMPORTANT: When the drive is inserted, the drive LEDs flash for 2 seconds to indicate that the drive is seated properly and receiving power.


3. As the drive begins to spin, be sure that the drive LEDs illuminate one at a time and then turn off together to indicate that the system has recognized the new drive.
4. In fault-tolerant configurations, allow the replacement drive to be reconstructed automatically with data from the other drives. While reconstruction is in progress, the online LED flashes.

Power button/LED cable

To remove the component:

1. Power down the server (on page 27).
2. Remove the bezel ("[Bezel](#)" on page 28).
3. Remove the access panel ("[Access panel](#)" on page 30).
4. Remove the media drive in the bottom bay, if necessary ("[Half-height media device](#)" on page 33, "[Full-height media device](#)" on page 35).
5. Disconnect the power button/LED cable from the system board ("[System board components](#)" on page 84).


6. Remove the power button/LED cable.



To replace the component, reverse the removal procedure.

USB diskette drive

Disconnect a USB diskette drive from the USB connector on the server front panel.



To replace the component, reverse the removal procedure.


Half-height media device



CAUTION: To prevent improper cooling and thermal damage, do not operate the server unless all bays are populated with either a component or a blank.

To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Disconnect the cables from the half-height media device.
5. Remove the half-height media device.




To replace the component:

For clarity, the following illustrations include option cabling only.




CAUTION: To prevent improper cooling and thermal damage, do not operate the server unless all bays are populated with either a component or a blank.

1. Install the guide screws on the half-height media device.



2. Install the half-height media device.




3. Connect the power cable and the SATA cable to the rear of the drive.
4. Install the access panel.
5. Do one of the following:
 - Close or install the tower bezel, as needed.
 - Slide the server back into the rack.
6. Power up the server.

Full-height media device

To remove the component:


1. Power down the server (on page [27](#)).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("[Bezel](#)" on page [28](#)).
 - Remove the server from the rack (on page [27](#)).
3. Remove the access panel ("[Access panel](#)" on page [30](#)).
4. Disconnect the cables from the rear of the full-height media device.

5. Remove the full-height media device.




To replace the component:

1. Using a T-15 Torx screwdriver, install the guide screws.



2. Install the full-height media device.




3. Connect the power cable and the data cable to the rear of the device.
4. Connect the data cable to the rear of the drive and to the SAS controller.
5. Remove the applicable bezel blanks from the bezel ("[Bezel blank](#)" on page [29](#)).
6. Install the access panel.
7. Do one of the following:
 - Close or install the tower bezel, as needed.
 - Slide the server back into the rack.
8. Power up the server.

Hot-plug expansion hard drive cage and backplane


To remove the component:

1. Power down the server (on page [27](#)).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("[Bezel](#)" on page [28](#)).
 - Remove the server from the rack (on page [27](#)).
3. Remove the access panel ("[Access panel](#)" on page [30](#)).
4. Remove all hot-plug hard drives ("[Hot-plug hard drives](#)" on page [31](#)).
5. Disconnect the power and data cables from the hard drive backplane and the system board ("[System board components](#)" on page [84](#)).

6. Using a T-15 Torx screwdriver, remove the hard drive cage.



7. Remove the backplane.




To replace the component, reverse the removal procedure.

Non-hot-plug expansion hard drive cage and drives


To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Disconnect the cables from the non-hot-plug hard drives.

5. Using a T-15 Torx screwdriver, remove the hard drive cage.



6. Using a T-15 Torx screwdriver, remove the non-hot-plug hard drives.



CAUTION: To prevent improper cooling and thermal damage, do not operate the server unless all bays are populated with either a component or a blank.


To replace the components, reverse the removal procedures.

Air baffle

To remove the component:


1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).

3. Remove the access panel ("Access panel" on page 30).
4. Remove the air baffle.




To replace the component:

1. If necessary, configure the air baffle (for 2P models only):
 - a. Press and hold the release button.



- b. Remove the partition.



2. Install the air baffle.
3. Install the access panel.
4. Do one of the following:
 - o Close or install the tower bezel, as needed.
 - o Slide the server back into the rack.
5. Power up the server.

Hard drive fan assembly


In the standard fan configuration, two hard drive fans are installed. In the redundant fan configuration, three hard drive fans are installed. The removal and replacement procedures are the same for all fans.

To determine the fan configuration, see "Fan locations (on page 93)".


To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - o Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - o Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Remove the air baffle, if necessary ("Air baffle" on page 39).
5. Remove the fan.

- Fan slots 1 and 1.5:



- Fan slot 3




To replace the component, reverse the removal procedure.

Rear fan assembly

To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Remove the air baffle, if installed ("Air baffle" on page 39).

5. Using a T-15 Torx screwdriver, remove the screws.
6. Remove the rear fan assembly.



To replace the component, reverse the removal procedure.


Hot-plug power supply

-
- ⚠ WARNING:** To reduce the risk of electric shock, do not disassemble the power supply or attempt to repair it. Replace it only with the specified spare part.
-
- ⚠ CAUTION:** Do not attempt to remove and replace a power supply as a hot-plug procedure unless both bays are populated with power supplies.
-

To remove the component:

1. Access the product rear panel.
2. Disconnect the power cord from the AC source.
3. Disconnect the power cord from the power supply.

4. Remove the power supply.



CAUTION: To prevent improper cooling and thermal damage, do not operate the server unless all bays are populated with either a component or a blank.

To replace the component, reverse the removal procedure.

DIMMs



CAUTION: To avoid damage to the hard drives, memory, and other system components, the air baffle, drive blanks, and access panel must be installed when the server is powered up.




IMPORTANT: This server may not support mixing RDIMMs and UDIMMs. Attempting to mix these two types can cause the server to halt during BIOS initialization. For more information, see the server product documentation.

To identify the DIMMs installed in the server, see "DIMM identification (on page 88)."

To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Remove the air baffle ("Air baffle" on page 39).
5. Open the DIMM slot latches.

6. Remove the DIMM.




To replace the component, reverse the removal procedure.

Processor board


To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - o Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - o Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Place the tower server on its side.
5. Remove the air baffle ("Air baffle" on page 39).
6. Disconnect the power cable from the processor board.
7. Remove the seven T-15 Torx screws securing the processor board.

8. Remove the processor board.




9. Using the wrench from the kit, remove the mezzanine support stand-offs.
10. Remove the metal plate.




To replace the component:

1. Remove the seven T-15 Torx screws on the system board.

Save the screws.




2. Using the wrench from the kit, install the seven mezzanine base stand-offs.




3. Install the metal plate on the mezzanine base stand-offs.

4. Using the wrench from the kit, install the mezzanine support stand-offs.



5. Install the processor board.
6. Secure the processor board with the screws removed from the system board.




Heatsink

To remove the component:


1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Place the tower server on its side.
4. Remove the access panel ("Access panel" on page 30).

5. Remove the air baffle ("Air baffle" on page 39).
6. Open the heatsink locking levers.
7. Remove the heatsink.




To replace the component:

1. Use the alcohol swab to remove all the existing thermal grease from the processor. Allow the alcohol to evaporate before continuing.
2. Remove the heatsink protective cover.



3. Install the heatsink.

4. Close the heatsink locking levers.



5. Install the air baffle.
6. Install the access panel.
7. Do one of the following:
 - Close or install the tower bezel, as needed.
 - Slide the server back into the rack.
8. Power up the server.

Processor


The server supports single- and dual-processor operation. With two processors installed, the server supports boot functions through the processor installed in processor socket 1. However, if processor 1 fails, then the system boots automatically from processor 2 and displays a processor failure message.

-
- △ **CAUTION:** To avoid damage to the processor and system board, only authorized personnel must replace or install the processor in this server.
-
- △ **CAUTION:** To help avoid damage to the processor and system board, do not install the processor without using the processor installation tool.
-
- △ **CAUTION:** To prevent possible server malfunction and damage to the equipment, multiprocessor configurations must contain processors with the same part number.
-


To remove the component:

1. Power down the server (on page [27](#)).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("[Bezel](#)" on page [28](#)).
 - Remove the server from the rack (on page [27](#)).
3. Place the tower server on its side.
4. Remove the access panel ("[Access panel](#)" on page [30](#)).

5. Remove the air baffle ("Air baffle" on page 39).
6. Remove the heatsink.




7. Open the processor locking lever and the processor socket retaining bracket.




8. Using the processor tool, remove the processor from the system board:
 - a. Line up the processor tool, ensuring the locking lever graphic on the tool is oriented correctly.
 - b. Press in on the plastic tabs, and then place the tool on the processor.

- c. Release the tabs, and then carefully lift the processor and tool straight up.




9. Carefully rotate the tool, and then push in and release the tabs to secure the processor in the tool.




CAUTION: To avoid damage to the processor, do not touch the bottom of the processor, especially the contact area.

To replace a processor:

1. Carefully insert the processor into the processor installation tool. Handle the processor by the edges only, and do not touch the bottom of the processor, especially the contact area.




2. Be sure the tool is oriented correctly. Align the processor installation tool with the socket, and then install the processor. **THE PINS ON THE SYSTEM BOARD ARE VERY FRAGILE AND EASILY DAMAGED.**



CAUTION: THE PINS ON THE SYSTEM BOARD ARE VERY FRAGILE AND EASILY DAMAGED. To avoid damage to the system board:

- Never install or remove a processor without using the processor installation tool.
- Do not touch the processor socket contacts.
- Do not tilt or slide the processor when lowering the processor into the socket.


3. Press and hold the tabs on the processor installation tool to separate it from the processor, and then remove the tool.




4. Close the processor socket retaining bracket and the processor locking lever.



CAUTION: Be sure to close the processor socket retaining bracket before closing the processor locking lever. The lever should close without resistance. Forcing the lever closed can damage the processor and socket, requiring system board replacement.



5. Install the heatsink.



6. Install the air baffle.
7. Install the access panel.
8. Do one of the following:
 - Close or install the tower bezel, as needed.
 - Slide the server back into the rack.
9. Power up the server.


Expansion boards



CAUTION: To prevent damage to the server or expansion boards, power down the server and remove all AC power cords before removing or installing the expansion boards.

1. Power down the server (on page [27](#)).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("[Bezel](#)" on page [28](#)).
 - Remove the server from the rack (on page [27](#)).
3. Remove the access panel ("[Access panel](#)" on page [30](#)).
4. Open the slot cover retainer.

5. Remove the expansion board.




To replace the component, reverse the removal procedure.

PCI-X extender board

To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Remove the air baffle ("Air baffle" on page 39).
5. Disconnect the cables from the PCI-X extender board.
6. Remove any expansion boards from the PCI-X extender board.
7. Remove fan 3.

8. Remove the extender board.



To replace the component, reverse the removal procedure.

System battery

If the server no longer automatically displays the correct date and time, you may need to replace the battery that provides power to the real-time clock. Under normal use, battery life is 5 to 10 years.




WARNING: The computer contains an internal lithium manganese dioxide, a vanadium pentoxide, or an alkaline battery pack. A risk of fire and burns exists if the battery pack is not properly handled. To reduce the risk of personal injury:

- Do not attempt to recharge the battery.
- Do not expose the battery to temperatures higher than 60°C (140°F).
- Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.
- Replace only with the spare designated for this product.

To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).

4. Remove the battery.



IMPORTANT: Replacing the system board battery resets the system ROM to its default configuration. After replacing the battery, reconfigure the system through RBSU.

To replace the component, reverse the removal procedure.


For more information about battery replacement or proper disposal, contact an authorized reseller or an authorized service provider.

Battery pack


To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).

4. Disconnect the cable from the cache module.



5. Remove the battery pack.




To replace the component, reverse the removal procedure.

Cache module


To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).

4. Disconnect the cable from the cache module.



5. Open the cache module latches.
6. Remove the cache module on the controller.



To install the component, reverse the removal procedure.

FBWC module and capacitor pack

CAUTION: Do not use this controller with cache modules designed for other controller models, because the controller can malfunction and you can lose data. Also, do not transfer this cache module to a different controller module, because you can lose data.


To remove the component:

1. Power down the server (on page [27](#)).




CAUTION: In systems that use external data storage, be sure that the server is the first unit to be powered down and the last to be powered back up. Taking this precaution ensures that the system does not erroneously mark the drives as failed when the server is powered up.


2. Do one of the following:
 - Open or remove the tower bezel, as needed ("[Bezel](#)" on page [28](#)).
 - Extend the server from the rack ("[Remove the server from the rack](#)" on page [27](#)).
3. Remove the access panel ("[Access panel](#)" on page [30](#)).
4. Disconnect the cable from the FBWC cache module.



5. Remove the FBWC cache module.



6. Remove the capacitor pack.




To replace the component, reverse the removal procedure.

System board


To remove the component:

1. Power down the server (on page 27).
2. Do one of the following:
 - Open or remove the tower bezel, as needed ("Bezel" on page 28).
 - Remove the server from the rack (on page 27).
3. Remove the access panel ("Access panel" on page 30).
4. Remove the air baffle ("Air baffle" on page 39).
5. Remove all DIMMs ("DIMMs" on page 44).
6. Remove all PCI expansion boards ("Expansion boards" on page 56).
7. Remove the PCI-X extender board, if installed ("PCI-X extender board" on page 57).
8. Remove the processor board, if installed ("Processor board" on page 45).
9. Disconnect all cables from the system board ("System board components" on page 84).

10. Remove the heatsink.




11. Open the processor locking lever and the processor socket retaining bracket.




12. Using the processor tool, remove the processor from the system board:
- a. Line up the processor tool, ensuring the locking lever graphic on the tool is oriented correctly.
 - b. Press in on the plastic tabs, and then place the tool on the processor.

- c. Release the tabs, and then carefully lift the processor and tool straight up.




13. Carefully rotate the tool, and then push in and release the tabs to secure the processor in the tool.



CAUTION: To avoid damage to the processor, do not touch the bottom of the processor, especially the contact area.


14. Remove the thumbscrews that secure the system board.

15. Remove the failed system board.



To replace the system board:

1. Install the spare system board.




2. Install the processor board, if removed ("[Processor board](#)" on page 45).




CAUTION: Failure to completely open the processor locking lever prevents the processor from seating during installation, leading to hardware damage.

3. Open the processor locking lever and the processor socket retaining bracket. **Do not remove the processor socket cover.**




IMPORTANT: Be sure the processor remains inside the processor installation tool.

4. If the processor has separated from the installation tool, carefully re-insert the processor in the tool. Handle the processor by the edges only, and do not touch the bottom of the processor, especially the contact area.




5. Align the processor installation tool with the socket, and then install the processor. **THE PINS ON THE SYSTEM BOARD ARE VERY FRAGILE AND EASILY DAMAGED.**




CAUTION: THE PINS ON THE SYSTEM BOARD ARE VERY FRAGILE AND EASILY DAMAGED. To avoid damage to the system board:

- Never install or remove a processor without using the processor installation tool.
- Do not touch the processor socket contacts.
- Do not tilt or slide the processor when lowering the processor into the socket.

6. Press the tabs on the processor installation tool to separate it from the processor, and then remove the tool.




7. Close the processor socket retaining bracket and the processor locking lever. **The processor socket cover is automatically ejected.** Remove the cover.




CAUTION: Be sure to close the processor socket retaining bracket before closing the processor locking lever. The lever should close without resistance. Forcing the lever closed can damage the processor and socket, requiring system board replacement.

8. Install the processor socket cover onto the processor socket of the failed system board.
9. Clean the old thermal grease from the heatsink and the top of the processor with the alcohol swab. Allow the alcohol to evaporate before continuing.

10. Apply all the grease to the top of the processor in the following pattern to ensure even distribution.



11. Install the heatsink.



IMPORTANT: Install all components with the same configuration that was used on the failed system board.

12. Install all components removed from the failed system board.
13. Install the access panel.
14. Do one of the following:
 - Close or install the tower bezel, as needed.
 - Slide the server back into the rack.
15. Power up the server.

After you replace the system board, you must re-enter the server serial number and the product ID.

1. During the server startup sequence, press the **F9** key to access RBSU.
2. Select the **Advanced Options** menu.
3. Select **Service Options**.

4. Select **Serial Number**. The following warnings appear:
WARNING! WARNING! WARNING! The serial number is loaded into the system during the manufacturing process and should NOT be modified. This option should only be used by qualified service personnel. This value should always match the serial number sticker located on the chassis.
Warning: The serial number should ONLY be modified by qualified personnel. This value should always match the serial number located on the chassis.
5. Press the **Enter** key to clear the warning.
6. Enter the serial number and press the **Enter** key.
7. Select **Product ID**. The following warning appears:
Warning: The Product ID should ONLY be modified by qualified personnel. This value should always match the Product ID on the chassis.
8. Enter the product ID and press the **Enter** key.
9. Press the **Esc** key to close the menu.
10. Press the **Esc** key to exit RBSU.
11. Press the **F10** key to confirm exiting RBSU. The server automatically reboots.

HP Trusted Platform Module

The TPM is not a customer-removable part.




CAUTION: Any attempt to remove an installed TPM from the system board breaks or disfigures the TPM security rivet. Upon locating a broken or disfigured rivet on an installed TPM, administrators should consider the system compromised and take appropriate measures to ensure the integrity of the system data.

If you suspect a TPM board failure, leave the TPM installed and remove the system board. Contact an HP authorized service provider for a replacement system board and TPM board.


Cabling

Non-hot-plug SATA hard drive cabling




Item	Description
1	Media bay 11
2	Media bay 10
3	Media bay 9
4	Hard drive bay (hard drives 1-4)
5	Hard drive bay (hard drives 5-8)

Non-hot-plug SATA/SAS hard drive cabling



Item	Description
1	Media bay 11
2	Media bay 10
3	Media bay 9
4	Hard drive bay (hard drives 1-4)


Hot-plug SATA/SAS hard drive cabling



Item	Description
1	Media bay 11
2	Media bay 10

Item	Description
3	Media bay 9
4	Hard drive bay (hard drives 1-4)

Non-hot-plug hard drive single power cabling




The hard drive backplane uses the 4-pin power connectors.

When connecting SATA hard drives, be sure to use the black SATA power connectors.

Item	Description
1	Media bay 11
2	Media bay 10
3	Hard drive bay (hard drives 1-4)
4	Power supply
5	4-pin power connector (P14)
6	4-pin power connector (P2)
7	24-pin power connector

Hot-plug hard drive single power cabling




The hard drive backplane uses the 4-pin power connectors.

When connecting SATA hard drives, be sure to use the black SATA power connectors.

Item	Description
1	Media bay 11
2	Media bay 10
3	Hard drive bay (hard drives 1-4)
4	Power supply
5	4-pin power connector (P14)
6	4-pin power connector (P2)
7	24-pin power connector

Non-hot-plug hard drive redundant power cabling




The hard drive backplane uses the 4-pin power connectors.

When connecting SATA hard drives, be sure to use the black SATA power connectors.

Item	Description
1	Media bay 11
2	Media bay 10
3	Media bay 9
4	Hard drive bay (hard drives 1-4)
5	Hard drive bay (hard drives 5-8)
6	Power supply
7	4-pin power connector (P19)
8	16-pin power connector
9	4-pin power connector (P3)
10	8-pin power connector
11	24-pin power connector

Hot-plug hard drive redundant power cabling



The hard drive backplane uses the 4-pin power connectors.

When connecting SATA hard drives, be sure to use the black SATA power connectors.

Item	Description
1	Media bay 11
2	Media bay 10
3	Media bay 9
4	Hard drive bay (hard drives 1-4)
5	Hard drive bay (hard drives 5-8)
6	Power supply
7	4-pin power connector (P19)
8	16-pin power connector
9	4-pin power connector (P3)
10	8-pin power connector
11	24-pin power connector

Diagnostic tools

Troubleshooting resources

The *HP ProLiant Servers Troubleshooting Guide* provides procedures for resolving common problems and comprehensive courses of action for fault isolation and identification, error message interpretation, issue resolution, and software maintenance on ProLiant servers and server blades. This guide includes problem-specific flowcharts to help you navigate complex troubleshooting processes. To view the guide, select a language:

- English (http://www.hp.com/support/ProLiant_TSG_en)
- French (http://www.hp.com/support/ProLiant_TSG_fr)
- Italian (http://www.hp.com/support/ProLiant_TSG_it)
- Spanish (http://www.hp.com/support/ProLiant_TSG_sp)
- German (http://www.hp.com/support/ProLiant_TSG_gr)
- Dutch (http://www.hp.com/support/ProLiant_TSG_nl)
- Japanese (http://www.hp.com/support/ProLiant_TSG_jp)

HP Insight Diagnostics

HP Insight Diagnostics is a proactive server management tool, available in both offline and online versions, that provides diagnostics and troubleshooting capabilities to assist IT administrators who verify server installations, troubleshoot problems, and perform repair validation.

HP Insight Diagnostics Offline Edition performs various in-depth system and component testing while the OS is not running. To run this utility, launch the SmartStart CD.

HP Insight Diagnostics Online Edition is a web-based application that captures system configuration and other related data needed for effective server management. Available in Microsoft® Windows® and Linux versions, the utility helps to ensure proper system operation.

For more information or to download the utility, refer to the HP website (<http://www.hp.com/servers/diags>).

HP Insight Diagnostics survey functionality

HP Insight Diagnostics (on page 78) provides survey functionality that gathers critical hardware and software information on ProLiant servers.

This functionality supports operating systems that may not be supported by the server. For operating systems supported by the server, see the HP website (<http://www.hp.com/go/supportos>).

If a significant change occurs between data-gathering intervals, the survey function marks the previous information and overwrites the survey data files to reflect the latest changes in the configuration.

Survey functionality is installed with every SmartStart-assisted HP Insight Diagnostics installation, or it can be installed through the HP PSP.

NOTE: The current version of SmartStart provides the memory spare part numbers for the server. To download the latest version, see the HP website (<http://www.hp.com/support>).

Integrated Management Log

The IML records hundreds of events and stores them in an easy-to-view form. The IML timestamps each event with 1-minute granularity.

You can view recorded events in the IML in several ways, including the following:

- From within HP SIM
- From within Survey Utility
- From within operating system-specific IML viewers
 - For NetWare: IML Viewer
 - For Windows®: IML Viewer
 - For Linux: IML Viewer Application
- From within the iLO 2 user interface
- From within HP Insight Diagnostics (on page 78)

For more information, see the Management CD in the HP Insight Foundation suite for ProLiant.


ROMPaq disaster recovery

If the current version of the ROM is corrupt, perform ROMPaq disaster recovery procedures:

1. Create a ROMPaq diskette using the Autorun Menu on the SmartStart CD.
2. Power down the server (on page 27).
3. Insert the ROMPaq diskette.
4. Power up the server.
 - a. The server generates one long beep and two short beeps to indicate that you are in disaster recovery mode. If the diskette is not in place, the system continues to beep until a valid ROMPaq diskette is inserted.
 - b. The ROMPaq diskette flashes the system ROM image. If successful, a sequence of ascending audible beeps is generated. If unsuccessful, a sequence of descending audible beeps is generated and you need to repeat the disaster recovery process.
5. Power down the server (on page 27).
6. Remove the ROMPaq diskette.
7. Power up the server.


Component identification

Front panel components




Item	Description
1	Optical drive
2	USB connectors (4)
3	Standard hard drive bays (4)
4	Expansion hard drive bays (4)
5	Media bays (2)

Front panel LEDs and buttons




Item	Description	Status
1	System health LED	Green = System health is normal. Amber = System health is degraded. To identify the component in a degraded state, see "System board LEDs (on page 86)." Red = System health is critical. To identify the component in a critical state, see "System board LEDs (on page 86)." Off = System health is normal (when in standby mode).
2	NIC 1 link/activity LED	Green = Linked to network Green flashing = Linked and activity on the network Off = No connection If power is off, view the LEDs on the RJ-45 connector. See "Rear panel LEDs and buttons (on page 83)."
3	NIC 2 link/activity LED	Green = Linked to network Green flashing = Linked and activity on the network Off = No connection If power is off, view the LEDs on the RJ-45 connector. See "Rear panel LEDs and buttons (on page 83)."
4	Drive activity LED	Green = Drive activity is normal. Off = No drive activity exists.
5	Power On/Stand by button and system power LED	Green = Power is on. Amber = System is in standby mode.

Rear panel components




Item	Description
1	Dedicated iLO 2 management port (optional)
2	Serial connector
3	10/100/1000 NIC 2 connector
4	10/100/1000 NIC 1 connector/shared iLO 2 management port
5	Mouse connector
6	Power supply 1
7	Power supply blank
8	Slot 1 PCI-X*
9	Slot 2 PCI-X*
10	Slot 3 PCIe1 x8 (1)
11	Slot 4 PCIe2 x16 (16, 8, 4, 2, 1)
12	Slot 5 PCIe2 x8 (4, 2, 1)
13	Slot 6 PCIe2 x8 (4, 2, 1)
14	Video connector
15	USB connectors (2)
16	Keyboard connector

*Slots 1 and 2 are available only when an optional PCI-X extender board is installed.




Rear panel LEDs and buttons



Item	Description	Status
1	UID button/LED	Blue = Activated Flashing = System is being managed remotely. Off = Deactivated
2	NIC/iLO 2 activity	Flashing green = Activity exists. Off = No activity exists.
3	NIC/iLO 2 link	Green = Link exists. Off = No link exists.

System board components


For this server, some system board slots and connectors are reserved.



Item	Description
1	Hard drive backplane connectors (2)
2	Internal USB connector
3	Redundant power supply connector
4	Front panel connector
5	Reserved
6	SATA connectors 1-4 (hard drive)
7	Hard drive LED connector
8	System maintenance switch
9	SATA connectors 5-6 (optical drive)
10	Slot 3 PCIe1 x8 (1)
11	SD card slot
12	Slot 4 PCIe2 x16 (16, 8, 4, 2, 1)
13	Slot 5 PCIe2 x8 (4, 2, 1)
14	Slot 6 PCIe2 x8 (4, 2, 1)
15	Fan 6 connector
16	Dedicated iLO 2 module connector (optional)
17	Hard drive backplane connector
18	NMI jumper
19	Processor board connectors
20	TPM connector
21	Processor 1 DIMMs (1-9)
22	USB connector

Item	Description
23	System power connector
24	Fan 1 connector
25	Fan 1.5 or 2 connector
26	Fan 3 connector
27	Reserved
28	Processor socket 1 (populated)
29	Battery
30	Reserved
31	Power connector
32	Front USB connector

* The server supports one optical drive that can be connected to either SATA connector 5 or SATA connector 6.



System maintenance switch

Position	Default	Function
S1	Off	Off = iLO 2 security is enabled. On = iLO 2 security is disabled.
S2	Off	Off = Normal operation On = RBSU will not commit any configuration changes.*
S3	Off	Reserved
S4	Off	Reserved
S5	Off	Off = Power-on password enabled On = Power-on password disabled*
S6	Off	Off = Normal operation On = BIOS will clear CMOS and NVRAM.*
S7	Off	Reserved
S8	Off	Reserved

* "On" activates the function.

NMI functionality

An NMI crash dump enables administrators to create crash dump files when a system is hung and not responding to traditional debug mechanisms.


Crash dump log analysis is an essential part of diagnosing reliability problems, such as hangs in operating systems, device drivers, and applications. Many crashes freeze a system, and the only available action for administrators is to cycle the system power. Resetting the system erases any information that could support problem analysis, but the NMI feature preserves that information by performing a memory dump before a hard reset.

To force the OS to invoke the NMI handler and generate a crash dump log, the administrator can do any of the following:

- Short the NMI jumper pins
- Press the NMI switch
- Use the iLO Virtual NMI feature

For additional information, see the whitepaper on the HP website (<http://h20000.www2.hp.com/bc/docs/support/SupportManual/c00797875/c00797875.pdf>).

System board LEDs



Item	LED description	Status
1	Processor failure	Amber = Processor has failed. Off = Normal
2	Fan 6 failure	Amber = Fan has failed or is missing. Off = Normal
3	Power supply	Off = No AC power or failed power supply Green = Power supply is on and is functioning.
4	Overtemperature	Amber = System has reached a cautionary or critical temperature level.

Item	LED description	Status
		Off = Normal
5	Fan 1 failure	Amber = Fan has failed or is missing. Off = Normal
6	Fan 1.5 or 2 failure	Amber = Fan has failed or is missing. Off = Normal
7	DIMM failure (1-9)	Amber = DIMM has failed or is missing. Off = Normal
8	Fan 3 failure	Amber = Fan has failed or is missing. Off = Normal

System LEDs and internal health LED combinations

When the internal health LED on the front panel illuminates either amber or red, the server is experiencing a health event. Combinations of illuminated system LEDs and the internal health LED indicate system status.


The front panel health LEDs indicate only the current hardware status. In some situations, HP SIM may report server status differently than the health LEDs because the software tracks more system attributes.

System LED and Color	Internal Health LED Color	Status
Processor failure (amber)	Red	One or more of the following conditions may exist: • Processor has failed. • Processor is not installed in the socket. • Processor is unsupported. • ROM detects a failed processor during POST.
	Amber	Processor is in a pre-failure condition.
DIMM failure, slot X (amber)	Red	• DIMM in slot X has failed. • DIMM in slot X is an unsupported type, and no valid memory exists in another channel.
	Amber	• DIMM in slot X has reached the single-bit correctable error threshold. • DIMM in slot X is in a pre-failure condition. • DIMM in slot X is an unsupported type, but valid memory exists in another channel.
DIMM failure, all slots in one channel (amber)	Red	No valid or usable memory is installed in the system.
	Amber	• The entire channel is not populated. • DIMMs do not match within the channel, but other valid memory is available.
Overtemperature (amber)	Amber	The Health Driver has detected a cautionary temperature level.
	Red	The server has detected a hardware critical temperature level.
Fan module (amber)	Red	The minimum fan requirements are not being met in one or more of the fan modules. One or more fans have failed or are missing.

System LED and Color	Internal Health LED Color	Status
Power supply (amber)	Red	One or more of the following conditions may exist: - There is no AC power. - The power supply has failed.
	Amber	There is a power supply mismatch at POST.

DIMM slots

DIMM slots are numbered sequentially (1 through 9) for each processor. The supported AMP modes use the letter assignments for population guidelines.




DIMM identification



IMPORTANT: This server does not support mixing RDIMMs and UDIMMs. Attempting to mix these two types causes the server to halt during BIOS initialization.

The memory subsystem may be populated with either RDIMMs or UDIMMs, but mixing the two types is not supported. To determine DIMM characteristics, use the label attached to the DIMM and the following illustration and table.




Item	Description	Definition
1	Size	—
2	Rank	1R = Single-rank 2R = Dual-rank 4R = Quad-rank
3	Data width	x4 = 4-bit x8 = 8-bit
4	Memory speed	10600 = 1333-MHz 8500 = 1066-MHz
5	DIMM type	R = RDIMM (registered) E = UDIMM (unbuffered with ECC)


For the latest supported memory information, see the QuickSpecs on the HP website (<http://www.hp.com>).

SAS and SATA device numbers


- Standard configuration



- Optional configuration with hard drive expansion cage



Hot-plug SATA or SAS hard drive LEDs




Item	LED description	Status
1	Fault/UID status	Amber = Drive failure Flashing amber = Fault-process activity Blue = Unit identification is active Off = No fault-process activity
2	Online/Activity status	Green = Drive activity Flashing green = High activity on the drive or drive is being configured as part of an array Off = No drive activity

The online/activity status LED will not illuminate if using SATA drives connected to the embedded storage device. In this configuration, SATA hard drive activity can be identified using the hard drive activity LED on the system front panel.

FBWC module LEDs


The FBWC module has two single-color LEDs (green and amber). The LEDs are duplicated on the reverse side of the cache module to facilitate status viewing.




Green LED	Amber LED	Interpretation
Off	On	A backup is in progress.
Flashing (1 Hz)	On	A restore is in progress.
Flashing (1 Hz)	Off	The capacitor pack is charging.
On	Off	The capacitor pack has completed charging.
Flashing (2 Hz) Alternating with amber LED	Flashing (2 Hz) Alternating with green LED	One of the following conditions exists: - The charging process has timed out. - The capacitor pack is not connected.
On	On	The flash code image failed to load.
Off	Off	The flash code is corrupt.

Fan locations

- Standard fan configuration



- Redundant fan configuration



Specifications

Environmental specifications

Specification	Value
Temperature	
Operating ¹	10°C to 35°C (50°F to 90°F)
Non-operating	30°C to 60°C (-22°F to 140°F)
Maximum rate of temperature change	
Operating ^{2,3}	10°C/hr (18°F/hr)
Non-operating	20°C/hr (36°F/hr)
Relative humidity (noncondensing)**	
Operating	10% to 90%
Non-operating	5% to 95%
Maximum wet bulb temperature (non-condensing)	
Operating	28°C (82.4°F)
Non-operating	38.7°C (101.7°F)
Altitude	
Operating ²	3,050 m (10,000 ft)
Non-operating	9144 m (30,000 ft)
Maximum rate of altitude change	
Operating	3,000 m (10,000 ft)
Non-operating	9,144 m (30,000 ft)

¹ All temperature ratings shown are for sea level. An altitude derating of 1°C per 300 m (1.8°F per 1,000 ft) to 3048 m (10,000 ft) is applicable. No direct sunlight is allowed.

² The type and number of options installed can limit the upper limit.

³ System performance may be reduced if operating with a fan fault above 30°C (86°F).

Mechanical specifications

Specification	Value
Height	20.0 cm (7.87 in)
Depth (without bezel)	42.70 cm (16.81 in)
Width	61.30 cm (24.13 in)
Weight (no drives installed)	16.04 kg (35.37 lb)

Power supply specifications

Depending on installed options, the server is configured with one of the following power supplies:

- HP ProLiant 750 W Power Supply

Specification	Value
Input requirements	
Rated input voltage	100 to 120 VAC, 200 to 240 VAC
Rated input frequency	50 Hz to 60 Hz
Rated input current	9.4 A at 100 VAC 4.7 A at 200 VAC
Rated input power	857 W at 100V AC input 852 W at 200V AC input
BTUs per hour	2924 at 100V AC input 2907 at 200V AC input
Power supply output	
Rated steady-state power	750 W at 100V to 120V AC input 750 W at 200V to 240V AC input
Maximum peak power	750 W at 100V to 120V AC input 750 W at 200V to 240V AC input

- HP ProLiant 460 W Power Supply

Specification	Value
Input requirements	
Rated input voltage	100 to 120 VAC, 200 to 240 VAC
Rated input frequency	50 Hz to 60 Hz
Rated input current	10.0 A at 100 VAC 5.0 A at 200 VAC
Rated input power	626 W at 100V AC input 676 W at 200V AC input
BTUs per hour	2306 at 100V AC input 2306 at 200V AC input
Power supply output	
Rated steady-state power	460 W at 100V to 120V AC input 460 W at 200V to 240V AC input
Maximum peak power	460 W at 100V to 120V AC input 460 W at 200V to 240V AC input

Acronyms and abbreviations

BBWC

battery-backed write cache

FBWC

flash-backed write cache

iLO

Integrated Lights-Out

IML

Integrated Management Log

LV DIMM

Low voltage DIMM

NCQ

Native Command Queuing

NIC

network interface controller

NMI

non-maskable interrupt

NVRAM

non-volatile memory

PCIe

peripheral component interconnect express

PCI-X

peripheral component interconnect extended

POST

Power-On Self Test

PSP

ProLiant Support Pack

RBSU

ROM-Based Setup Utility

RDIMM

Registered Dual In-line Memory Module

SAS

serial attached SCSI

SATA

serial ATA

TPM

trusted platform module

UDIMM

Unregistered Dual In-Line Memory Module

Index

A

access panel 16, 30
additional information 78
air baffle 40

B

battery 58, 87
battery pack, removing 59
bezel 28
bezel blank 29
bezel, procedures 28
blue screen event 87
buttons 81

C

cables 32, 72
cabling 72, 73, 74, 75, 76, 77
cache module 60
components 16, 25, 71, 81
components, identification 81, 87
components, mechanical 16, 25, 71
components, system 16
components, system board 87
connectors 81
crash dump analysis 87
CSR (customer self repair) 5
customer self repair (CSR) 5

D

device numbers 91
diagnostic tools 78
diagnostics utility 78
DIMM slot locations 90
DIMMs 44, 90
diskette drive 33
drive LEDs 92

E

electrostatic discharge 25
environmental specifications 95

expansion boards 56

F

fan assembly 41
fan module locations 94
fans 94
FBWC capacitor pack 61
FBWC module 61, 93
FBWC module LEDs 93
features 81
front panel buttons 82
front panel components 81
front panel LEDs 82, 88
full-height media drive 35
full-height tape drive 35

H

half-height media device 33
hard drive blanks 16, 31
hard drive cabling 72, 73, 74, 75, 76, 77
hard drive cage 37
hard drive LEDs 92
hard drives 31, 37, 38
health LEDs 87, 88
heatsink 48
HP Insight Diagnostics 78, 79

I

IML (Integrated Management Log) 79
Insight Diagnostics 78, 79
Integrated Management Log (IML) 79
internal health LED 88

L

LED, system power 27
LEDs 81, 88
LEDs, hard drive 92
LEDs, SAS hard drive 92
LEDs, troubleshooting 88, 92

M

- management tools 78
- mechanical components 16
- mechanical specifications 96
- media bay blank 30

N

- NMI switch 87
- non-hot-plug hard drive cage 38

P

- PCI-X extender board 57
- PCI-X extender board connector 85
- Power On/Standby button 27
- power supplies 43
- power supply specifications 96
- powering down 27
- preparation procedures 27
- processor board, removing 45
- processors 50

R

- rear fan assembly 42
- rear panel buttons 84
- rear panel components 83
- rear panel LEDs 84
- removing server from rack 27
- required tools 25
- ROMPaq Disaster Recovery 79

S

- safety considerations 25
- safety information 25
- SAS device numbers 91
- SAS hard drive LEDs 92
- SATA drives 91
- SATA hard drive LEDs 92
- specifications, environmental 95
- specifications, mechanical 96
- specifications, power supply 96
- specifications, server 95
- static electricity 25
- switches 87
- system battery 58
- system board 63
- system board components 85
- system board LEDs 88
- system components 19, 81, 85

- system maintenance switch 86, 87
- system power LED 27

T

- tape drives 35
- TPM (Trusted Platform Module) 71, 85
- troubleshooting 78
- troubleshooting resources 78
- Trusted Platform Module (TPM) 71

U

- USB devices 33
- utilities 78

W

- warnings 25, 26