

J7-LED-PICO

User Manual



FAVI ENTERTAINMENT®
technology + design

Product specification and user manual is subject to change without prior notice due to engineering improvement. Color and appearance of product and icons in user manual may vary from that of actual product.

TABLE OF CONTENTS

Product Registration	1
Warranties	2
Important Safety Notes	3
What's In the Box	4
Power Projector	5
Projector Overview	6
Top & Bottom	6
Back & Front	7
Left & Right	8
Image Size	9
Settings	10
Wi-Fi Setup	10
Image Display	11
Volume Adjustment	11
Web Browser	12
Connect	13
Apps	13
USB/Micro SD Card	13
Computer	14
Troubleshooting	15
Specification	16

PRODUCT REGISTRATION

Thank you for purchasing FAVI J7-LED-PICO.
To better serve you in the future, please take a
moment to register your product at:
www.favientertainment.com/register

Product Registration allows us to send you important updates, service information and helpful hints. It will also make it easier should you ever need to call in for Technical Support. FAVI values your privacy and will never share your information with other companies.

WARRANTIES

Your J7-LED-PICO projector is warrantied to be free of defects in material and workmanship for a period of 1 year from the date of receipt. Should your projector develop an issue requiring it to be repaired within this time frame, we will repair or exchange any defective unit at no cost to you.

FAVI Entertainment will pay round trip shipping for warranty claims within the USA. Excludes: HI, AK, APO, USA Territories, and international orders.

Our parts warranty is valid up to one year from the date of receipt. We will bill you a flat rate for repair and shipping costs before accepting the unit back for repair. You will not be billed for the cost of replacement parts. The above warranties will be considered null and void in the event of damage caused by misuse, neglect, improper handling, or improper installation.

FAQ's, and other support information can be found at
<http://www.favientertainment.com/help.asp>

For technical support, you may contact us at:
techsupport@favientertainment.com

IMPORTANT SAFETY NOTES

Before you use this projector, please read this manual carefully.

SAFETY

- Do not stare directly into the light of projector's lens.
- Do not expose projector to water or other sources of moisture to avoid electrical shock.
- Do not use projector in areas where flammable gases or fumes are present.
- Do not expose projector to extreme temperatures.
- Do not block air ventilation with any materials or objects, this may cause projector to overheat.

MAINTENANCE

- Use only the supplied power cable to power projector. Using other adapter may damage the projector.
- When cleaning projector, remove power cable and use a damp cloth.
- When not using projector, store projector in carrying case to keep dirt and dust from projector and lens.
- Place projector on stable surfaces.
- Unplug projector when not in use for long periods of time.
- Do not attempt to disassemble projector. Doing so will void your warranty.

WHAT'S IN THE BOX

1x J7-LED-PICO

1x Carrying Case

1x Projector Sleeve

1x Micro USB Cable

1x AV Cable

1x Power Adapter

1x User Manual

POWER PROJECTOR

Powering your projector:

- Step 1:** Connect one end of the AC adapter to the Projector 12V port and plug the other end into an electrical outlet.
- Step 2:** Slide the Power button to the right to turn on the projector.
- Step 3:** Wait for the Favi Pico+ start screen to appear.

Note: Manually adjust the focus by sliding up or down on the focus adjustment wheel to your preference.


Charging projector:

- Step 1:** Use the included AC Adapter to charge projector when:
- Using the projector for the first time.
 - Projector has not been use for a long period of time.
 - A low battery icon appears on the screen or shuts off due to low battery.
- Step 2:** Connect the AC Adapter to the projector and wall outlet.
- Indicator Light:
- Red = Charging
 - Blue = Fully Charged

Note: It takes approximately 3 to 5 hours to fully charge the projector. Fully charged projector lasts up to 2 hours.

PROJECTOR OVERVIEW


The following diagrams point out the features of your projector:



TOP

1. Menu
2. Directional Keys
3. Return / Back
4. OK / Select
5. Touchpad


tip: Double tap and hold to swipe and drag items



BOTTOM

1. Tripod Dock
2. Air Ventilation
3. Speaker


PROJECTOR OVERVIEW




BACK & FRONT

1. DC In 12V
2. Rest Button
3. AV IN / Audio Out
(see diagram below)
4. OTG
5. USB
6. Micro SD Card Slot

Connecting Audio and Video via AV IN / Audio Out




PROJECTOR OVERVIEW



RIGHT & LEFT

1. Power Switch
2. Air Ventilation
3. Focus Adjustment



Turning Projector ON/OFF

Switch Power Switch to the RIGHT to turn projector ON.
Switch Power Switch to the LEFT to turn projector OFF.

Focusing Images

Turn Focus Adjustment up or down until picture is clear.

IMAGE SIZE


Image Size

Image sizes are measured diagonally and are approximate.

Projected image size	Distance from screen
40"	55.9"
60"	83.9"
80"	111.8"
100"	139.8"

Image Adjustment

For best image results, the projector should be directly facing the screen. Adjustment to the focus dial will help to improve the picture. Please see the diagram below for examples of correct and incorrect setup.



SETTINGS


WI-FI Setup

From the main screen, select the Device Setting Icon and locate Wireless & Networks.



If Wi-Fi is not already ON, switch Wi-Fi ON. Projector will automatically scan for available wireless networks.

Choose your wireless network and enter your password to connect.



SETTINGS

Settings

From the main screen, select the Device Setting Icon



Image Display

From the main screen, select the Device Setting Icon and then Display



Rotate Screen

Select this option to flip the display vertically. Use this option for ceiling mount applications.

Brightness

Select this option to adjust the brightness of the projected image

Hide Status Bar

Select this option to hide the black status bar located along the bottom of the projected image.

Volume Adjustment

Press the Right or Left arrow on projector to adjust volume.
note: local video and music playback only

Click the Volume Icons in the status bar located along the bottom of the projected image to increase and decrease the volume level.



WEB BROWSER

Launch Web Browser

From the main screen, select the Web Browser Icon

Note: Web Browser will typically open on the last web page visited.



Set Web Browser Homepage

1. From the main screen, select the Web Browser Icon



2. Press the Menu Icon  to open the Browser Menu options.

Note: Menu icon is located in upper right corner of web browser.

3. Select Settings then Set homepage.

4. Select "Other" and input desired homepage url. Select Ok.

5. Browser will now open to the homepage of your choice when launched.

CONNECT

Apps

From the main screen select All Apps Icon  to access your apps

Download new apps:

1. From the main screen select the App Store Icon 
2. Search for desired app. select app, and click "Install."
3. All downloaded apps will appear on the All App page.

Note: Although there are many free apps available on the Google Play Store, some apps require an additional fee or subscription to download or use.

Local Media Playback (USB / Micro SD Card)

Insert USB or Micro SD Card into the projector.

Video:

From the main screen, select Local Video Icon



Video Format:

RM, RMVB, MPEG, MKV, AVI, MP4,
MOV, FLV, H.264, 3GP, DAT, VOB, TS, WMV

Image:

From the main screen, select Local Image Icon



Image Format:

JPG, PNG, GIF, BMP

Multimedia Files:

From the main screen, select Local Files Icon



Audio Format:

MP3, WMA, OGG, AAC, AMR, MIDI

File Format:


PDF, EPUD, TXT, POB

CONNECT

PC Computer

Transfer files between your computer and the SD card in your projector.

1. Connect projector (OTG) to computer (USB) using micro USB provided.
2. Follow the on screen instructions.



TROUBLESHOOTING

If you have any issues with using your J7-LED-PICO, please refer to the following solutions below:

Problem	Solution
Projector will not power on	• Check the power cord and power outlet. • Restart projector. • Reset the projector by long pressing reset button.
Cannot charge battery	• Make sure adapter is connected properly.
No sound from speaker	• Check if the sound is low or is on MUTE. • If using headphone or other AV cables, make sure they are connected properly. • Make sure audio decoder is supported by projector. • Remove AV Cable from projector when when not in use.
Cannot detect USB or Micro SD Card	• Check that USB or Micro SD Card is connected properly.
Blurry Image	• Use the Focus Adjustment to adjust image quality.

Additional support: techsupport@favientertainment.com

TECHNICAL SPECIFICATION

Native Resolution	854 x 480 (WVGA), Max 1080p
Display Technology	0.3" DMD, TI DLP
LED Brightness	100 ANSI Lumens
LED Lamp Life	Approximately 30,000 hours
Image Size	120"
Color Gamut	100% of NTSC
Projection Offset	100% offset
Contrast Ratio	1000:1
Screen Aspect Ratio	16:9
Uniformity	85%
Throw Ratio	1.6:1
Speaker	2x 1W Speakers
Power	7.4V 2000mAh Rechargeable Battery
Battery Life	2 Hours (fully charged)
DC IN	12V/1.5A
Dimension	3.9 x 3.9 x 1.06 inches