

Go to www.vtechphones.com to register your product for enhanced warranty support and the latest VTech product news

SN6307

Photo Speed Dial Handset for use with VTech CareLine™



vtech
User's manual



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.

For support, shopping, and everything new at VTech, visit our website at www.vtechphones.com.


Congratulations

on purchasing your new VTech product. Before using this product, please read **Important safety instructions**.

This user's manual provides you with installation and use instructions. Please read this manual thoroughly to ensure proper installation and operation of this VTech product.

Parts checklist

Your product package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.




Install the battery

Install the battery as shown below.

NOTES

- Use only supplied battery.
- If the handset will not be used for a long time, disconnect and remove the battery to prevent possible leakage.




Connect and charge the battery

NOTES

- Use only the adapter provided.
- Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual.
- The adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-table or cabinet outlet.

Connect the charger



Charge the battery




Once you have installed the battery and placed the handset in the charger, the **CHARGE** light indicates the battery status (see the table below).

NOTES

- For best performance, keep the handset in the charger when not in use.
- The battery is fully charged after 12 hours of continuous charging.

CHARGE light	Battery status	Action
Flashes red every 10 seconds	The battery has very little charge and the handset is not in charger. The handset cannot dial out.	Charge without interruption (at least 30 minutes).
Red	The battery has enough charge to be used for a short time.	Charge without interruption (at least 30 minutes).
Green	The battery is fully charged.	To keep the battery charged, place it in the charger when not in use.

Handset overview



Charger overview



1 – Charging pole

Lights overview

The following table summarizes the lights patterns on the handset under various conditions.

Light	Pattern
CHARGE light	<ul style="list-style-type: none"> Red when the handset battery is charging. Flashes red every 10 seconds when the handset battery is low and not charging. Green when the handset battery is fully charged. Alternates red and green quickly when handset registration is in progress. Alternates red and green slowly when the handset is not registered and not in charger.
Incoming call light	<ul style="list-style-type: none"> Flashes orange slowly when the handset received an incoming call.
Speaker	<ul style="list-style-type: none"> Green when the handset is on earpiece mode. Flashes green slowly when the handset received an incoming call. Flashes green twice every 3 seconds when line in use while the handset is idle.
Speaker	<ul style="list-style-type: none"> Orange when the handset is on speakerphone mode.

Voice prompts

The following table summarizes voice prompts you hear under certain conditions.

Voice Prompt	Condition
"Not registered"	Any key is pressed when the handset is not registered.
"Out of range"	Any key is pressed when the handset is out of range.
"Low battery"	A photo speed dial key, 1 , or SPEAKER is pressed when the handset battery is low.

Before use

There are two types of Careline series telephone. The instructions to register and configure your SN6307 handset are different for those two types of Careline systems series telephone.

Use the diagrams on the right to identify your Careline telephone, and then refer to the respective section for instructions.

Operating range

This cordless handset operates with the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and telephone base can communicate over only a certain distance - which can vary with the locations of the telephone base and handset, the weather, and the layout of your home or office.

When the handset is out of range, the handset plays the voice prompt "Out of range" if any key is pressed. If there is a call while the handset is out of range, it may not ring, or if it does ring, the call may not connect well when you press **1**. Move closer to the telephone base, then press **1** to answer the call.

During a call, if the handset is moved out of range, the call will end automatically, and you will hear a notification tone.

Identify your Careline telephone



Read the instructions for SN1157/SN1197/SN6147/SN6196/SN6197 telephone.



Read the instructions for SN6127/SN6187 telephone.

For SN1157/SN1197/SN6147/SN6196/SN6197 telephone:

Add and register a handset

Register each new SN6307 handset to your Careline series telephone base before use. Your telephone system supports a maximum of 12 devices.

NOTE

Charge the new handset without interruption for at least 30 minutes before registering it to the telephone base.

- Press **MENU** on the telephone base when it is not in use.



- Press **▼** or **▲** to scroll to **Settings**, and then press **SELECT**.



- Press **▼** or **▲** to scroll to **Registration**, then press **SELECT**. The telephone base shows **Registering... Please wait**.

- Put the handset in the charger. The handset **CHARGE** light alternates red and green quickly to indicate the registration is in progress.



You hear a confirmation tone when the registration process completes. It takes up to 60 seconds to complete the registration. If registration fails, you hear an error tone, and the **CHARGE** light alternates red and green slowly when it is taken out of the cradle. Start again from Step 1 above.

NOTES

- You cannot register a handset if any other system devices is in use.
- The telephone base shows **Registration slots are full** when you try to register more than 12 devices to it.

- To cancel the registration, press **CANCEL** or **BACK**.

Set photo speed dial entries

Your handset has four photo speed dial entries at the telephone base before, your handset is ready to use. Skip this part and read **Insert photos for speed dial keys**.

If you have assigned the photo speed dial entries at the telephone base, the speed dial entries of the pendant are the same as the first two photo speed dial entries of the telephone base and the handset.

NOTES

- You can store the same phone number in more than one photo speed dial slots.
- If you have a pendant (SN6167) registered to your telephone base, the speed dial entries of the pendant are the same as the first two photo speed dial entries of the telephone base and the handset.
- Editing or deleting an entry in phonebook does not affect the photo speed dial entries.

- Press **MENU** on the telephone base when it is not in use.



-OR-

Press an unassigned photo speed dial key on the telephone base, and then go to Step 4.




- Press **▼** or **▲** to scroll to **Photo speed dial**, and then press **SELECT**.



- Press **▼** or **▲** to choose an unassigned photo speed dial slot, and then press **SELECT**.



- When the base displays **MEMORY X NUMBER**, use the dialing keys to enter a number (up to 30 digits).
 - Press **▼** or **▲** to move the cursor to the left or right.
 - Press **X/DELETE** or **BACKSPACE** to erase a digit.
 - Press and hold **X/DELETE** to erase all digits.
 - Press and hold **PAUSE** to enter a dialing pause (a **P** appears).





- When the base displays **MEMORY X NAME**, use the dialing keys to enter a name (up to 15 characters). Press once or several times on the dialing keys to enter the selected character.

By default, the first character of each word is uppercase, and the rest is lowercase.

- Press **▼** or **▲** to move the cursor to the left or right.
- Press **0** to add a space.
- Press **X** to switch between the uppercase and lowercase characters.
- Press **X/DELETE** or **BACKSPACE** to erase a character.
- Press and hold **X/DELETE** to erase all characters.

- Press **SAVE**. The screen displays **Memory X saved** and you hear a confirmation tone.



For SN6127/SN6187 telephone:


Add and register a handset

Register each new SN6307 handset to your Careline series telephone base before use. Your telephone system supports a maximum of 12 devices.

NOTE

Charge the new handset without interruption for at least 30 minutes before registering it to the telephone base.

- Press and hold **1**/FIND HANDSET at the telephone base until the **IN USE** light turns red.



- Put the handset in the charger. The handset **CHARGE** light alternates red and green quickly to indicate the registration is in progress.

You hear a confirmation tone when the registration process completes. It takes up to 60 seconds to complete the registration. If registration fails, you hear an error tone, and the **CHARGE** light alternates red and green slowly when it is taken out of the cradle. Start again from Step 1 above.

NOTES

- You cannot register a handset if any other system device is in use.
- When you already have 12 registered devices and you try to register another handset to the telephone base, you hear four beeps from the telephone base.


Set photo speed dial entries

Your handset has four photo speed dial keys. It retrieves the photo speed dial entries from the phonebook in the telephone base.

Make sure you store the photo speed dial entries in the phonebook naming **Photo 1**, **Photo 2**, **Photo 3** and **Photo 4** respectively.

NOTES

- Names for the photo speed dial entries are case-sensitive.
- A space must be entered between "Photo" and the number when entering the name of a photo speed dial entry.
- Deleting an entry in phonebook will remove the associated photo speed dial entry.



- On a SN6127/SN6187 handset, press **MENU** when idle.
- Press **▼** or **▲** to scroll to **Phonebook**, and then press **SELECT**.
- Press **▼** or **▲** to scroll to **Add contact**, and then press **SELECT**.




- When the handset displays **ENTER NUMBER**, use the dialing keys to enter a number (up to 30 digits).



- Press **▼** or **▲** to move the cursor to the left or right.
- Press **DELETE** to erase a digit.
- Press and hold **DELETE** to erase all digits.
- Press and hold **PAUSE** to enter a dialing pause (a **P** appears).

-OR-

Copy a number from the redial list by pressing **REDIAL** then press **▼**, **▲** or **REDIAL** repeatedly to find the desired number. Press **SELECT** to copy the number.



- When the handset displays **ENTER NAME**, use the dialing keys to enter **Photo 1**, **Photo 2**, **Photo 3** or **Photo 4**.

Press once or several times on the dialing keys to enter the selected character.

By default, the first character of each word is uppercase, and the rest is lowercase.



- Press **▼** or **▲** to move the cursor to the left or right.
- Press **0** to add a space.
- Press **X** to switch between the uppercase and lowercase characters.
- Press **DELETE** to erase a character.
- Press and hold **DELETE** to erase all characters.

- Press **SELECT** to save. The handset displays **Saved** and you hear a confirmation tone.


Insert photos for speed dial keys

You can add desired photos into the photo speed dial compartments, or write the contact name on the photo speed dial cards.

To add a photo, use the photo speed dial card as a tool to crop your desired photo, and then insert it as shown below.

NOTE

The handset is shipped with protective stickers covering the photo speed dial compartments. Remove the protective sticker before use.



Settings

Adjust ringer volume

You can adjust the ringer volume level, or turn the ringer off.

- When the handset is not in use, press **VOL-** or **VOL+**.

NOTE

When the ringer volume is set to off, the handset still rings when you press **1**/FIND HANDSET or **FIND HS** at the telephone base.

Quiet mode

Your handset follows the quiet mode setting in the telephone base. When the quiet mode is on, all tones (except paging tone) are muted.

Refer to the **Quiet mode** section in the user's manual of your Careline series telephone base for the setting.

Caller ID announce

The voice announce caller ID feature lets you know who the caller is. When you have an incoming call, the handset speaks "Call from..." and the name of the caller based on the phonebook or caller ID information.

If the caller's name is private or unknown, the phone number up to the last 11 digits will be announced. If the caller's phone number is also private or unknown, no information will be announced.

To turn on or off this feature, refer to the **Caller ID announce** section in the user's manual of the telephone base.

NOTES

- To use the caller ID announce feature, you must subscribe to caller ID service from your telephone service provider.
- When there are up to five handsets/pendants registered, the telephone system supports caller ID announce for all handsets/pendants. If six or more handsets/pendants are registered, the system supports caller ID announce for the first four registered handsets/pendants only.

Using the photo speed dial handset

Make a call

- Press a photo speed dial key to dial.

-OR-

- Press or **SPEAKER** , and then a photo speed dial key to dial.

Answer a call

- Press or **SPEAKER** .

End a call

- Press or place the handset back in the charger.

Speakerphone

- During a call, press **SPEAKER** to switch between the speakerphone and the earpiece.

Adjust listening Volume

- During a call, press **VOL-** or **VOL+**.

Call waiting

When you subscribe to call waiting service from your telephone service provider, you hear an alert tone if there is an incoming call while you are already on a call.

- Press to put the current call on hold and take the new call.
- Press at any time to switch back and forth between calls.

Temporary ringer silence

When the telephone is ringing, you can temporarily silence the handset ringer without disconnecting the call. The next call rings normally at the preset volume.

- Press **VOL-** or .

- Press to turn off the ringer.
- Press to turn on the ringer.

If this product has memory dialling locations, you may choose to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency numbers, please Remain on the line and briefly explain the reason for the call before hanging up.

Perform such activities in off-peak hours, such as early morning or late evening.

Industry Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this telephone.

The term "IC:" before the certification/ registration number only signifies that the Industry Canada technical specifications were met.

The Ringer Equivalence Number (REN) for this terminal equipment is NAN. The REN is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

Remark: The word "NAN" means "Not Applicable".

This product meets the applicable Industry Canada technical specifications.

RF radiation exposure statement

The handset complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies also with Industry Canada RSS-102 with respect to Canada's Health Code 6 for Exposures of Humans to RF Fields.

Join a call in progress

You can use a maximum of four devices at a time on a call.

- Press or **SPEAKER** to join the call.
- To exit the call, press or place the handset back in the charger. The call continues until all devices hang up.

Find handset

You can use the **Find handset** feature on the telephone base to find misplaced handsets.

- Press a photo speed dial key, , or **SPEAKER** to stop paging.
- Press or **VOL-** to mute the paging tone.

Deregister handsets

Your telephone system supports a maximum of 12 devices.

If you have registered 12 devices, and you want to register a SN6307 handset, you have to deregister all devices first. Then register your desired devices individually.

CAUTION



Deregister with caution! Once done, **all devices** will be deregistered from your telephone system.

NOTES

- You cannot deregister all devices if any other system device is in use.
- Even if your devices have run out of battery, you can still deregister them by following the instructions in this section.
- To register any cordless handset or pendant back to the telephone base, refer to the user's manual of your Careline series telephone for details.

For SN1157/SN1197/SN6147/SN6196/SN6197 telephone:


- Press and hold **FIND HS** at the telephone base until the **IN USE** light flashes and the telephone base shows **Registering... Please wait** followed by **Deregister all devices?**



- You hear a confirmation tone when the registration process completes. It takes about 10 seconds to complete the deregistration.
- If deregistration fails, you need to reset the system and try again. To reset, unplug the power and the telephone line cord from the telephone base. Then plug the cords back in again.

For SN6127/SN6187 telephone:

- Press and hold **#FIND HANDSET** at the telephone base until the **IN USE** light flashes red.
- Immediately press **#FIND HANDSET** again within 5 seconds.



You hear a confirmation tone when the registration process completes. It takes about 10 seconds to complete the deregistration.

If deregistration fails, you need to reset the system and try again. To reset, unplug the power and the telephone line cord from the telephone base. Then plug the cords back in again.

ECO mode

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base.

General product care

Taking care of your telephone

Your cordless telephone contains sophisticated electronic parts, so it must be treated with care.

Avoid rough treatment

Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it.

Avoid water

Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower.

Electrical storms

Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electrical appliances during storms.

Cleaning your telephone

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use dampened cloth or cleaning solvents of any kind.

Storage

When you are not going to use the handset for some time, remove the rechargeable battery from the handset. Store the handset, the charger and the adapter in a cool and dry place.

Important safety instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

- Read and understand all instructions.
- Follow all warnings and instructions marked on the product.
- Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a dry non-abrasive cloth for cleaning.
- Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub or a swimming pool, or in a wet basement or shower.
- Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
- Avoid placing the telephone system in places with extreme temperature, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids and fumes.
- Slots and openings in the back or bottom of the charger and handset are provided for ventilation. To protect them from overheating,

My handset does not work at all.	Make sure the charger is installed properly, and battery is installed and charged correctly. For optimum daily performance, return the handset to the charger after use.
	Make sure the handset has registered to a Careline series telephone base.

For C-UL compliance only

Mesures de sécurité importantes

Afin de réduire les risques d'incendie, de blessures corporelles ou d'électrocution, suivez toujours ces mesures préventives de base lorsque vous utilisez votre téléphone :

- Lisez et comprenez bien toutes les instructions.
- Observez toutes les instructions et mises en garde inscrites sur l'appareil.
- Débranchez ce téléphone de la prise murale avant de le nettoyer. N'utilisez pas de nettoyeurs liquides ni en aérosol. N'utilisez qu'un chiffon doux et légèrement humecté.
- N'utilisez pas ce produit près de l'eau, tel que près d'un bain, d'un lavabo, d'un évier de cuisine, d'un bac de lavage ou d'une piscine, ou dans un sous-sol humide ou sous la douche.
- Ne déposez pas ce téléphone sur un chariot, support ou table chancelants. L'appareil pourrait tomber et être sérieusement endommagé.
- Évitez d'installer le système téléphonique dans les endroits soumis à une température extrême, à la lumière directe du soleil ou à proximité immédiate d'autres appareils électriques ou électroniques. Protégez votre téléphone contre les sources d'humidité, la poussière, les vapeurs et les liquides corrosifs.
- Le boîtier de l'appareil est doté de fentes et d'ouvertures d'aération situées à l'arrière ou en dessous. Afin d'empêcher la surchauffe, ces ouvertures ne doivent pas être obstruées en plaçant l'appareil sur un lit, divan, tapis ou autre surface similaires. Ne placez pas cet appareil à proximité d'un élément de chauffage ni d'une plinthe électrique. De plus, n'installez pas dans une unité murale ou un cabinet fermé qui ne possède pas d'aération adéquate.

- Register your handsets back to the telephone base. Refer to the **Add and register a handset** section of your Careline series user's manual and this manual.
- Ne faites fonctionner cet appareil qu'avec une alimentation adéquate.
- Évitez d'utiliser un téléphone (autre qu'un sans fil) pendant un orage. Les éclairs peuvent être à l'origine d'une électrocution.
- N'utilisez pas le téléphone pour rapporter une fuite de gaz à proximité de la fuite. En certaines circonstances, une flammeèche pourrait être provoquée lorsque l'adaptateur est branché à une prise de courant, ou lorsque le combiné est déposé sur le socle. Ceci est un événement commun associé à la fermeture d'un circuit électrique. L'utilisateur ne devrait pas brancher le téléphone à une

I cannot dial out.	For different type of Careline series telephone base, the photo speed dial setup procedure is different. Make sure you have set the photo speed dial entries in the telephone base as instructed.
--------------------	---

I experience poor sound quality when using the handset speakerphone.	For increased sound quality while using the handset speakerphone, place the handset on a flat surface with the keys facing up.
--	--

The handset does not ring when there is an incoming call.	Press VOL+ to increase the ringer volume when the handset is not in use.
---	---

	Make sure the quiet mode is off. Check the setting on your telephone base.
--	--

Frequently asked questions

Below are the questions most frequently asked about the cordless telephone. If you cannot find the answer to your question, visit our website at **www.vtechphones.com** or call **1 (800) 595-9511** for customer service. In Canada, go to **www.vtechcanada.com** or call **1 (800) 267-7377**.

- Read and understand all instructions.
- Follow all warnings and instructions marked on the product.
- Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a dry non-abrasive cloth for cleaning.
- Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub or a swimming pool, or in a wet basement or shower.
- Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
- Avoid placing the telephone system in places with extreme temperature, direct sunlight, or other electrical devices. Protect your phone from moisture, dust, corrosive liquids and fumes.
- Slots and openings in the back or bottom of the charger and handset are provided for ventilation. To protect them from overheating,

these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area where proper ventilation is not provided.

- This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home or office, consult your dealer or local power company.
- Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on.
- Never push objects of any kind into this product through the slots in the charger or handset because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the charger or handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.

- Do not overload wall outlets and extension cords.
- Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
 - When the power supply cord or plug is damaged or frayed.
 - If liquid has been spilled onto the product.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions.

- Improper adjustment of other controls may result in damage and often requires extensive work by an authorized technician to restore the product to normal operation.
 - If the product has been dropped and the charger and/or handset has been damaged.
 - If the product exhibits a distinct change in performance.
- Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning.

- Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not put a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.

- Only put the handset next to your ear when it is in normal talk mode.
- The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

SAVE THESE INSTRUCTIONS

- Battery**
- CAUTION:** Use Only Supplied Battery.
 - Do not dispose of the battery in a fire. Check with local waste management codes for special disposal instructions.
 - Do not open or mutilate the battery. Released electrolyte is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.

- Exercise care in handling batteries in order not to create a short circuit with conductive materials.**
- Charge the battery provided with this product only in accordance with the instructions and limitations specified in this manual.

Precautions for users of implanted cardiac pacemakers

Cardiac pacemakers (applies only to digital cordless telephones):
Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between cordless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:

Pacemaker patients

- Should keep wireless telephones at least six

inches from the pacemaker.

- Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is turned ON.
- Should use the wireless telephone at the ear opposite the pacemaker.

WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless telephones.

About cordless telephones

- Privacy:** The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones.

- Electrical power:** The telephone base of this cordless telephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless handset if the telephone base is unplugged, switched off or if the electrical power is interrupted.

- Potential TV interference:** Some cordless telephones operate at frequencies that may cause interference to televisions and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR often reduces or eliminates the interference.

- Rechargeable batteries:** Exercise care in handling batteries in order not to create a short circuit with conducting material such as rings, bracelets and keys. The battery or conductor may overheat and cause harm. Observe proper polarity between the battery and the battery charger.

- Nickel-metal hydride rechargeable batteries:** Dispose of these batteries in a safe manner. Do not burn or puncture the battery. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.

What is not covered by this limited warranty?

- This limited warranty does not cover:
- Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
 - The time remaining on the original one-year warranty; whichever is longer.

What is not covered by this limited warranty?

This limited warranty does not cover:

- Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or
- Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or
- Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or
- Product to the extent that the problem is caused by use with non-VTech accessories; or
- Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or
- Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or
- Product returned without a valid proof of purchase (see Item 2 on the next page); or
- Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

How long do you get warranty service?


NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call.
Except as provided by applicable law, you

The RBRC® seal

The RBRC® seal on the nickel-metal hydride battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada.

The RBRC® program provides a convenient alternative to placing used nickel-metal hydride batteries into the trash or municipal waste, which may be illegal in your area.

VTech's participation in RBRC® makes it easy for you to drop off the spent battery at local retailers participating in the RBRC® program or at authorized VTech product service centers. Please call **1 (800) 8 BATTERY®** for information on Ni-MH battery recycling and disposal bans/ restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.



RBRC® and 1 (800) 8 BATTERY® are registered trademarks of Rechargeable Battery Recycling Corporation.

FCC and IC regulations

FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this telephone.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria.

This Class B digital apparatus complies with Canadian regulation:
CAN ICES-3 (B)/NMB-3(B)

FCC Part 68 and ACTA

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US:AAAEQ##TXXX. This identifier must be provided to your telephone service provider upon request.

The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed

to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line and an RJ14 jack for two lines. See the installation instructions in the user's manual.

The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US; in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, please contact your telephone service provider.

This equipment may not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone service provider or a qualified installer.

If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents. For repair procedures, follow the instructions outlined under the Limited warranty.

If this equipment is causing harm to the telephone network, the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone service provider is required to inform you of your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned.

If this product is equipped with a corded or cordless handset, it is hearing aid compatible. If this product is equipped with a corded or cordless handset, it is hearing aid compatible.

Technical specifications

Frequency control	Crystal controlled PLL synthesizer
Transmit frequency	1921.536-1928.448 MHz
Channels	5
Nominal effective range	Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.
Power requirements	Battery: 2.4V 400mAh, Ni-MH battery pack <p>Power adapter: 6V AC @ 300mA</p>

Please retain your original sales receipt as proof of purchase.

- Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
- Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
- Provide your name, complete and correct mailing address, and telephone number.

Other limitations

This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.

State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

Limitations: Implied warranties, including those of fitness for a particular purpose and

VTech Communications, Inc.
A member of The VTECH GROUP OF COMPANIES.
VTech is a registered trademark of VTech Holdings Limited.
Specifications are subject to change without notice.
© 2014 VTech Communications, Inc.
All rights reserved. 12/14. SN6307_CIB_V4.0
Document order number: 91-007352-040-100

