



# Maintenance & Service Guide

Sprout Business PC

© Copyright 2015 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice.

Microsoft and Windows are trademarks of Microsoft Corporation in the U.S. and other countries.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

## **Maintenance & Service Guide**

First Edition (March 2015)

Document Part Number: 811522-001

## **Product notice**


This guide describes features that are common to most models. Some features may not be available on your computer.


Not all features are available in all editions of Windows 8. Your computer may require upgraded and/or separately purchased hardware, drivers, and/or software to take full advantage of Windows 8 functionality. See <http://www.microsoft.com> for details.

This computer may require upgraded and/or separately purchased hardware and/or a DVD drive to install the Windows 7 software and take full advantage of Windows 7 functionality. See <http://windows.microsoft.com/en-us/windows7/get-know-windows-7> for details.

## About This Book

---

 **WARNING!** Text set off in this manner indicates that failure to follow directions could result in bodily harm or loss of life.

 **CAUTION:** Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information.

 **NOTE:** Text set off in this manner provides important supplemental information.

---



---

# Table of contents

<b>1 Getting to know your Sprout .....</b>	<b>1</b>
Finding hardware and software information .....	1
Locating hardware .....	1
Locating software .....	1
Front .....	2
Sprout Illuminator .....	3
Top .....	4
Right side .....	5
Left side .....	6
Rear .....	7
Connecting the HP Touch Mat .....	8
Labels .....	9
Identifying the labels .....	9
<b>2 Illustrated parts catalog .....</b>	<b>11</b>
Computer covers .....	11
Computer boards .....	12
Computer misc parts .....	13
Computer cables .....	14
Column covers .....	15
Column misc parts .....	16
<b>3 Disassembly preparation and SATA drive guidelines .....</b>	<b>17</b>
Electrostatic discharge information .....	17
Generating static .....	18
Preventing electrostatic damage to equipment .....	18
Personal grounding methods and equipment .....	18
Grounding the work area .....	19
Recommended materials and equipment .....	19
Operating guidelines .....	20
Service considerations .....	20

Fan .....	20
Tools and software requirements .....	21
Screws .....	21
Cables and connectors .....	21
Hard Drives .....	21
Lithium coin cell battery .....	22
SATA hard drives .....	22
SATA hard drive cables .....	22
SATA data cable .....	22
SMART ATA drives .....	23
Cable management .....	23

#### **4 Removal and Replacement Procedures – Computer ..... 25**

Preparing to disassemble the computer .....	25
Removing the rear covers from the computer .....	26
Hard drive .....	28
Memory .....	30
Wireless USB dongle .....	32
Battery .....	33
Separating the computer from the column .....	35
Top rear cover (webcam) .....	38
Microphone module .....	40
Webcam module .....	41
Ambient light sensor (ALS) board .....	43
Power button board .....	45
System board cover .....	47
WLAN module .....	49
Converter board .....	51
Right I/O board .....	54
Left I/O board .....	56
Speakers .....	58
Heat sink .....	60
Processor .....	62
Fan assembly .....	63
Antennas .....	64
Hard drive connector .....	66
System board .....	68
System board callouts .....	72
Display assembly .....	73

<b>5 Removal and Replacement Procedures – Column</b>	<b>77</b>
Preparing to disassemble the column	77
Removing the rear covers from the computer	78
Separating the computer from the column	80
Bottom cover	83
Side and top cover	84
Inside cover	87
Docking board shield	89
Docking board	91
Docking board bracket	93
Subwoofer mesh cover	95
Subwoofer	97
Power supply	99
Rear I/O modules	102
POGO (Touch Mat) board	104
<b>6 Computer Setup (F10) Utility</b>	<b>107</b>
Computer Setup (F10) Utilities	107
Using Computer Setup (F10) Utilities	108
Computer Setup—File	109
Computer Setup—Storage	110
Computer Setup—Security	112
Computer Setup—Power	114
Computer Setup—Advanced	115
Updating the BIOS	116
Determining the BIOS version	116
Downloading a BIOS update	116
Recovering the Configuration Settings	117
<b>7 Using HP PC Hardware Diagnostics (UEFI)</b>	<b>119</b>
Downloading HP PC Hardware Diagnostics (UEFI) to a USB device	120
<b>8 Troubleshooting</b>	<b>121</b>
Wireless connection problems	121
Cannot connect to a WLAN	121
Cannot connect to a preferred network	121
Current network security codes are unavailable	122
Cannot connect to the wireless router	122
Network status icon is not displayed	123
Power problems	123

Sprout will not turn on or start .....	123
Hard drive error .....	123
Sprout is not responding .....	124
Sprout shuts down unexpectedly .....	124
Display problems .....	124
The display is blank .....	124
Images on the screen are too large or too small, or the images are fuzzy .....	124
Keyboard and mouse problems .....	125
Touch mat problems .....	125
Audio problems .....	126
No sound is produced through external speakers (purchased separately) .....	126
Software problems .....	127

## **9 Backing up, restoring, and recovering ..... 129**

Creating recovery media and backups .....	129
Creating HP Recovery media .....	129
Using Windows tools .....	130
Restore and recover .....	130
Recovering using HP Recovery Manager .....	131
What you need to know .....	131
Using the HP Recovery partition .....	131
Using HP Recovery media to recover .....	131
Changing the computer boot order .....	132

## **10 POST error messages ..... 133**

POST numeric codes and text messages .....	134
Interpreting POST diagnostic front panel LEDs .....	140

## **11 Password security and resetting CMOS ..... 143**

Resetting the password jumper .....	143
Establishing a setup or power-on password .....	144
Resetting the setup and power-on password .....	145
Changing a setup or power-on password .....	146
Clearing and resetting the CMOS .....	146

## **12 Maintaining peak performance ..... 149**

Performing routine maintenance .....	149
Using Disk Cleanup .....	149
Using Disk Defragmenter .....	149
Updating programs and drivers .....	149



Cleaning your Sprout .....	150
Cleaning procedures .....	150
Cleaning the display and glass surfaces .....	150
Cleaning the sides or cover .....	151
Cleaning the Touch mat .....	151
Cleaning the keyboard or mouse .....	151
<b>Appendix A Power cord set requirements .....</b>	<b>153</b>
General requirements .....	153
Japanese power cord requirements .....	153
Country-specific requirements .....	154
<b>Appendix B Statement of Volatility .....</b>	<b>155</b>
<b>Appendix C Specifications .....</b>	<b>157</b>
<b>Index .....</b>	<b>159</b>



---

# 1 Getting to know your Sprout

Your Sprout immersive computer is a powerful tool designed to enhance your work and entertainment. Read this chapter to learn about best practices after you set up your immersive computer and where to find additional HP resources.

## Finding hardware and software information

### Locating hardware

To find out what hardware is installed on your Sprout:

1. From the Start screen, type `control panel`, and then select **Control Panel**.  
– or –  
From the Windows desktop, right-click the **Start** button, and then select **Control Panel**.
2. Select **System and Security**, select **System**, and then click **Device Manager** in the left column.




### Locating software

To find out what software is installed on your immersive computer:

- ▲ From the Start screen, click the down arrow in the lower-left corner of the screen.  
– or –  
From the Windows desktop, right-click the **Start** button, and then select **Programs and Features**.  
A list displays all the devices installed on your Sprout.

# Front



Component		Description
(1)	WLAN antennas (2)*	Send and receive wireless signals.
(2)	Webcam light	On: The webcam is on.
(3)	Webcam	Records video and takes still photographs.  To use the webcam, from the Start screen, type <code>camera</code> , and then select <b>Camera</b> .
(4)	Speakers (3)	Produce sound.
(5)	 Keyboard button/light	Projects the keyboard on the touch mat.
(6)	 Home button/light	Displays Sprout Workspace.
(7)	 Projector/touch mat button/light	<ul style="list-style-type: none"><li>• Tap the projector/touch mat button to turn off the touch mat.</li><li>• Touch-and-hold the projector/touch mat button to turn off the projector.</li><li>• Tap the projector/touch mat button to turn both the projector and the touch mat on.</li></ul>

Component	Description
(8) HP Touch Mat	A touch-sensitive mat on which you can project the Sprout Workspace to create a horizontal touch screen.

\*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions. For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region.


To access this document:

- ▲ From the Start screen, type [support](#), and then select the **HP Support Assistant** app.

– or –

From the Windows desktop, click the question mark icon in the notification area, at the far right of the taskbar.


## Sprout Illuminator




**CAUTION:** To prevent damage to your vision, avoid staring directly at the lights on the Sprout Illuminator.





Component	Description
(1) Desk lamp touch sensor	Touch to turn the desk lamp on, to dim it, or to turn it off.
(2) High-resolution camera light	On: The high-resolution camera is on.
(3) Desk lamp (2)	Illuminates the touch mat.
(4) Depth camera (3)	Captures three-dimensional images.
(5) Depth camera light	On: The depth camera is on.
(6) High-resolution camera	Captures high-resolution images from the touch mat.
(7) Projector mirror	Projects the Sprout Workspace on the touch mat.




Component		Description
(1)	 Power button	<ul style="list-style-type: none"><li>• When the computer is off, press the button to turn on the computer.</li><li>• When the computer is in the Sleep state, press the button briefly to exit Sleep.</li><li>• When the computer is in Hibernation, press the button briefly to exit Hibernation.</li></ul> <p><b>CAUTION:</b> Pressing and holding down the power button will result in the loss of unsaved information.</p> <p>If the computer has stopped responding and Microsoft® Windows® shutdown procedures are ineffective, press and hold the power button down for at least 5 seconds to turn off the computer.</p> <p>To learn more about your power settings, from the Start screen, type <code>power</code>, and then select <b>Power Options</b>.</p> <p>– or –</p> <p>From the Windows desktop, right-click the <b>Start</b> button, and then select <b>Power Options</b>.</p>
(2)	Ambient light sensor	Automatically adjusts the display brightness based on the lighting conditions in your environment.



# Right side



Component		Description
(1)	Internal magnet	Allows you to attach the stylus.
(2)	 Volume up/down button	Increases or decreases the speaker volume.
(3)	 USB 3.0 port	Connects an optional USB 1.0, USB 2.0, or USB 3.0 device and provides enhanced USB power performance for USB 3.0 devices.
(4)	 USB 3.0 charging (powered) port	Connects an optional USB 1.0, USB 2.0, or USB 3.0 device. USB charging ports allow you to charge connected USB devices. Standard USB ports will not charge all USB devices or will charge using a low current. Some USB devices require power and require you to use a powered port. <b>NOTE:</b> USB charging ports can also charge select models of cell phones and MP3 players, even when the computer is off.
(5)	 Hard drive activity light	Blinking: The hard drive is being used.


# Left side









Component	Description
<div data-bbox="240 877 319 919">(1)</div> <div data-bbox="319 877 391 961"></div> <div data-bbox="391 877 837 919">Memory card reader</div>	<p data-bbox="837 877 1450 961">Reads optional memory (SD, SDHC and SDXC) cards that store, manage, share, or access information.</p> <p data-bbox="837 961 1450 1066">To insert a card, hold the card with connectors facing the slot, insert the card into the slot, and then push in on the card until it is firmly seated.</p> <p data-bbox="837 1066 1450 1108">To remove a card, pull the card out.</p>
<div data-bbox="240 1108 319 1150">(2)</div> <div data-bbox="319 1108 391 1192"></div> <div data-bbox="391 1108 837 1192">Audio-out (headphone)/Audio-in (microphone) jack</div>	<p data-bbox="837 1108 1450 1255">Connects optional powered stereo speakers, headphones, earbuds, a headset, or a television audio cable. Also connects an optional headset microphone. This jack does not support optional microphone-only devices.</p> <p data-bbox="837 1255 1450 1444"><b>WARNING!</b> To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, refer to the <i>Regulatory, Safety, and Environmental Notices</i>. To access this guide, from the Start screen, type <code>support</code>, and then select the <b>HP Support Assistant</b> app.</p> <p data-bbox="837 1444 1450 1486">– or –</p> <p data-bbox="837 1486 1450 1549">From the Windows desktop, click the question mark icon in the notification area, at the far right of the taskbar.</p> <p data-bbox="837 1549 1450 1633"><b>NOTE:</b> When a device is connected to the jack, the computer speakers are disabled.</p> <p data-bbox="837 1633 1450 1734"><b>NOTE:</b> Be sure that the device cable has a 4-conductor connector that supports both audio-out (headphone) and audio-in (microphone).</p>



# Rear



Component		Description
(1)	Vent	Enables airflow to cool internal components.
(2)	Power supply light	On: The AC power cord is connected.
(3)	 Security cable slot	Attaches an optional security cable to the computer. <b>NOTE:</b> The security cable may not prevent the computer from being mishandled or stolen.
(4)	 USB 2.0 ports (2)	Connect optional USB 2.0 devices.
(5)	 Power connector	Connects an AC power cord.
(6)	 RJ-45 (network) jack	Connects a network cable.
(7)	 HDMI output port	Projects the computer screen display to an external monitor. <b>NOTE:</b> The HDMI output port cannot be used as an input from a TV, a game console, or a set top box.

Component	Description
(8)  Audio-out (headphone) jack	<p>Connects optional powered stereo speakers, headphones, earbuds, a headset, or a television audio cable. Also connects an optional headset microphone. This jack does not support optional microphone-only devices.</p> <p><b>WARNING!</b> To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, see the Regulatory, Safety, and Environmental Notices.</p> <p><b>NOTE:</b> When a device is connected to the jack, the computer speakers are disabled.</p>
(9) Internal microphones (2)	Record audio, automatically filtering out the noise around you.

## Connecting the HP Touch Mat



Set up your Sprout on a flat, level surface.

**CAUTION:** To prevent damage to the touch mat:

- Do not cut or pierce the touch mat.
- Do not bend or fold the touch mat.
- Do not place any magnetic components on the touch mat.
- Do not use metal objects on or under the touch mat.
- When using a stylus on the touch mat, do not place your hand or palm on the touch mat because your hand or palm may be treated as contact points on the touch mat.

To connect the touch mat, place the touch mat on a flat, level surface in front of the monitor, and slide it toward the front of the monitor. The magnets in the Sprout Connector connect the touch mat to the monitor automatically.



---

**NOTE:** If you remove the touch mat, the projector will turn off.

---

To protect the touch mat from dirt or accidental damage when it is not being used, use the optional HP Touch Mat cover (purchased separately).

## Labels

### Identifying the labels

The labels affixed to the computer provide information you may need when you troubleshoot system problems. The labels are located on the bottom of the computer.

- Service label—Provides important information to identify your computer. When contacting support, you will probably be asked for the serial number, and possibly for the product number or the model number. Locate these numbers before you contact support.
- Regulatory label(s)—Provide(s) regulatory information about the computer.
- Wireless certification label(s)—Provide(s) information about optional wireless devices and the approval markings for the countries or regions in which the devices have been approved for use.




## 2 Illustrated parts catalog

### Computer covers



Item	Description
(1)	Left rear cover
(2)	Right rear cover
(3)	Bottom rear cover
(4)	Top rear cover (webcam)

# Computer boards



Item	Description
(1)	System board
(2)	Power button board
(3)	Ambient light sensor board
(4)	Microphone module
(5)	Right I/O board
(6)	Left I/O board
(7)	Webcam module
(8)	Converter board
	WLAN module (HP WLAN 802.11 a/b/g/n + Bluetooth 4.0; not illustrated)
	4-GB memory module (SODIMM; PC3-12800, 1666-MHz; not illustrated)
	Intel Core i7-4790S processor (3.2 GHz, 8 MB cache, 65 W) (includes replacement thermal material; not illustrated)

## Computer misc parts



Item	Description
(1)	<b>Heat sink (thermal module)</b> (includes replacement thermal material)
(2)	<b>Fan</b>
(3)	<b>Hard drive connector and cables</b>
(4)	<b>USB connector and cable (for wireless USB dongle)</b>
(5)	<b>Speakers</b>
(6)	<b>Display assembly</b>
	<b>Antenna kit</b>

Item	Description
	<b>Hard drive</b> (1 TB, 2.5-inch, SSHD)
	<b>Power cord</b>
	<b>Wireless keyboard and mouse kit</b>
	<b>Touch Mat cover</b>
	<b>Stylus</b>
	<b>HP Desktop Organizer</b>

## Computer cables

Description
<b>LVDS (display) cable</b>
<b>Webcam cable</b>
<b>Converter cable</b>
<b>Left I/O cable</b>
<b>Right I/O cable</b>
<b>Top board cable</b>
<b>TPK USB (display) cable</b>
<b>Backlight cable</b>
LG display panel
Samsung display panel
BOE display panel




## Column covers



Item	Description
(1)	<b>Main column cover (white)</b>
(2)	<b>Inside cover</b>
(3)	<b>Subwoofer mesh cover</b>
(4)	<b>Bottom cover</b>
(5)	<b>POGO board cover</b> (Touch Link cover)

# Column misc parts




Item	Description
(1)	Docking board
(2)	POGO board (connects to Touch Mat)
(3)	Touch Mat
(4)	Power supply, 350 W
(5)	Column assembly chassis
(6)	Subwoofer
(7)	Rear I/O modules
(8)	Power cable
	Cables (not illustrated)
	NFC board
	Projector power
	POGO power

---

## 3 Disassembly preparation and SATA drive guidelines

This chapter provides general service information for the computer. Adherence to the procedures and precautions described in this chapter is essential for proper service.

---

 **CAUTION:** When the computer is plugged into an AC power source, voltage is always applied to the system board. You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

---

### Electrostatic discharge information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs. An electronic device exposed to electrostatic discharge (ESD) may not appear to be affected at all and can work perfectly throughout a normal cycle. The device may function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

## Generating static

The following table shows that:

- Different activities generate different amounts of static electricity.
- Static electricity increases as humidity decreases.

Event	Relative Humidity		
	55%	40%	10%
Walking across carpet	7,500 V	15,000 V	35,000 V
Walking across vinyl floor	3,000 V	5,000 V	12,000 V
Motions of bench worker	400 V	800 V	6,000 V
Removing DIPs from plastic tube	400 V	700 V	2,000 V
Removing DIPs from vinyl tray	2,000 V	4,000 V	11,500 V
Removing DIPs from Styrofoam	3,500 V	5,000 V	14,500 V
Removing bubble pack from PCB	7,000 V	20,000 V	26,500 V
Packing PCBs in foam-lined box	5,000 V	11,000 V	21,000 V
These are then multi-packaged inside plastic tubes, trays, or Styrofoam.			



**NOTE:** 700 volts can degrade a product.

## Preventing electrostatic damage to equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent damage to electric components and accessories.

- To avoid hand contact, transport products in static-safe containers such as tubes, bags, or boxes.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their container.
- Always be properly grounded when touching a sensitive component or assembly.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

## Personal grounding methods and equipment

Use the following equipment to prevent static electricity damage to equipment:

- **Wrist straps** are flexible straps with a maximum of one-megohm  $\pm$  10% resistance in the ground cords. To provide proper ground, a strap must be worn snug against bare skin. The ground cord must be connected and fit snugly into the banana plug connector on the grounding mat or workstation.
- **Heel straps/Toe straps/Boot straps** can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of one-megohm  $\pm$  10% resistance between the operator and ground.

Static Shielding Protection Levels	
Method	Voltage
Antistatic plastic	1,500
Carbon-loaded plastic	7,500
Metallized laminate	15,000

## Grounding the work area

To prevent static damage at the work area, use the following precautions:

- Cover the work surface with approved static-dissipative material. Provide a wrist strap connected to the work surface and properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.
- Keep work area free of nonconductive materials such as ordinary plastic assembly aids and Styrofoam.
- Use field service tools, such as cutters, screwdrivers, and vacuums, that are conductive.

## Recommended materials and equipment

Materials and equipment that are recommended for use in preventing static electricity include:

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of one-megohm  $\pm$  10% resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing one-megohm  $\pm$  10% resistance

- Material handling packages
- Conductive plastic bags
- Conductive plastic tubes
- Conductive tote boxes
- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

## Operating guidelines

To prevent overheating and to help prolong the life of the computer:

- Keep the computer away from excessive moisture, direct sunlight, and extremes of heat and cold.
- Operate the computer on a sturdy, level surface. Leave a 10.2-cm (4-inch) clearance on all vented sides of the computer and above the monitor to permit the required airflow.
- Never restrict the airflow into the computer by blocking any vents or air intakes. Do not place the keyboard, with the keyboard feet down, directly against the front of the desktop unit as this also restricts airflow.
- Occasionally clean the air vents on all vented sides of the computer. Lint, dust, and other foreign matter can block the vents and limit the airflow. Be sure to unplug the computer before cleaning the air vents.
- Never operate the computer with the covers or panels removed.
- If the computer is to be operated within a separate enclosure, intake and exhaust ventilation must be provided on the enclosure, and the same operating guidelines listed above will still apply.
- Keep liquids away from the computer and keyboard.
- Never cover the ventilation slots on the monitor with any type of material.
- Install or enable power management functions of the operating system or other software, including sleep states.


## Service considerations

Listed below are some of the considerations that you should keep in mind during the disassembly and assembly of the computer.

### Fan

The fan is variable-speed based on the temperature in the computer.

---

 **CAUTION:** The cooling fan is always on when the computer is in the “On” mode. The cooling fan is off when the computer is in “Standby,” “Suspend,” or “Off” modes.

You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

---

## Tools and software requirements


To service the computer, you need the following:

- Torx T-15 screwdriver
- Flat-bladed screwdriver (may sometimes be used in place of the Torx screwdriver)
- Phillips #1 screwdriver
- Diagnostics software

## Screws

The screws used in the computer are not interchangeable. They may have standard or metric threads and may be of different lengths. If an incorrect screw is used during the reassembly process, it can damage the unit. HP strongly recommends that all screws removed during disassembly be kept with the part that was removed, then returned to their proper locations.

---

 **CAUTION:** Metric screws have a black finish. U.S. screws have a silver finish and are used on hard drives only.


**CAUTION:** As each subassembly is removed from the computer, it should be placed away from the work area to prevent damage.

---

## Cables and connectors

Most cables used throughout the unit are flat, flexible cables. These cables must be handled with care to avoid damage. Apply only the tension required to seat or unseat the cables during insertion or removal from the connector. Handle cables by the connector whenever possible. In all cases, avoid bending or twisting the cables, and ensure that the cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced.

---

 **CAUTION:** When servicing this computer, ensure that cables are placed in their proper location during the reassembly process. Improper cable placement can damage the computer.

---

## Hard Drives

Handle hard drives as delicate, precision components, avoiding all physical shock and vibration. This applies to failed drives as well as replacement spares.

- If a drive must be mailed, place the drive in a bubble-pack mailer or other suitable protective packaging and label the package “Fragile: Handle With Care.”
- Do not remove hard drives from the shipping package for storage. Keep hard drives in their protective packaging until they are actually mounted in the CPU.
- Avoid dropping drives from any height onto any surface.
- If you are inserting or removing a hard drive, turn off the computer. Do not remove a hard drive while the computer is on or in standby mode.
- Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector.

- Do not use excessive force when inserting a drive.
- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

## Lithium coin cell battery

The battery that comes with the computer provides power to the real-time clock and has a minimum lifetime of about three years.

See the appropriate removal and replacement chapter for the chassis you are working on in this guide for instructions on the replacement procedures.

**WARNING!** This computer contains a lithium battery. There is a risk of fire and chemical burn if the battery is handled improperly. Do not disassemble, crush, puncture, short external contacts, dispose in water or fire, or expose it to temperatures higher than 140°F (60°C). Do not attempt to recharge the battery.

**NOTE:** Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. In order to forward them to recycling or proper disposal, please use the public collection system or return them to HP, their authorized partners, or their agents.

## SATA hard drives

Serial ATA Hard Drive Characteristics	
Number of pins/conductors in data cable	7/7
Number of pins in power cable	15
Maximum data cable length	39.37 in (100 cm)
Data interface voltage differential	400-700 mV
Drive voltages	3.3 V, 5 V, 12 V
Jumpers for configuring drive	N/A
Data transfer rate	6.0 Gb/s

## SATA hard drive cables

### SATA data cable

Always use an HP approved SATA 6.0 Gb/s cable as it is fully backwards compatible with the SATA 1.5 Gb/s drives.

Current HP desktop products ship with SATA 6.0 Gb/s hard drives.

SATA data cables are susceptible to damage if overflexed. Never crease a SATA data cable and never bend it tighter than a 30 mm (1.18 in) radius.

The SATA data cable is a thin, 7-pin cable designed to transmit data for only a single drive.



## SMART ATA drives

The Self Monitoring Analysis and Recording Technology (SMART) ATA drives for the HP Personal Computers have built-in drive failure prediction that warns the user or network administrator of an impending failure or crash of the hard drive. The SMART drive tracks fault prediction and failure indication parameters such as reallocated sector count, spin retry count, and calibration retry count. If the drive determines that a failure is imminent, it generates a fault alert.

## Cable management

Always follow good cable management practices when working inside the computer.

- Keep cables away from major heat sources like the heat sink.
- Do not jam cables on top of memory modules. Printed circuit cards like these are not designed to take excessive pressure on them.
- Keep cables clear of sliding or moveable parts to prevent them from being cut or crimped when the parts are moved.
- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases may damage the wires.
- Do not bend any cable sharply. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in) radius.
- Never crease a SATA data cable.
- Do not rely on components to push cables down into the chassis. Always position the cables to lay properly by themselves.



---


## 4 Removal and Replacement Procedures – Computer

The following sections provide information about disassembling various components of the computer.


### Preparing to disassemble the computer

To avoid injury and equipment damage, always complete the following steps in order.

1. Remove all media from the computer.
2. Shut down the computer.
3. After the system has completely shut down, remove the Touch Mat and disconnect the power cord and all attached cables from the back of the computer.
4. Using caution, lay the computer down on a flat surface covered with a soft cloth. Make sure the head hangs off the front of the table (as shown).



---

 **WARNING!** Beware of sharp edges inside the chassis.

---


## Removing the rear covers from the computer

You must remove the rear covers from the computer before you can service the computer or the column. Each cover may be secured with one captive screw.

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. If a security screw is installed in the bottom of the rear cover, remove the screw **(1)**. Slide the left rear cover toward the left to disengage it from the computer **(2)**, and then lift the cover off the computer **(3)**.




3. If a security screw is installed in the bottom of the rear cover, remove the screw **(1)**. Slide the right rear cover toward the right to disengage it from the computer **(2)**, and then lift the cover off the computer **(3)**.



Reverse the removal procedures to install the covers.


## Hard drive

The hard drive **(1)** is located under the left rear cover. You do not have to remove the computer from the column to service the hard drive.





To remove the hard drive:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the left rear cover (see [Removing the rear covers from the computer on page 26](#)).
3. Loosen the captive Phillips screw that secures the drive **(1)**, slide the drive away from the connector **(2)**, and then remove the drive from the computer **(3)**.



4. To remove the drive from the drive cage, remove the four Phillips screws from the sides of the cage **(1)**, and then lift the cage off the drive **(2)**.


 **NOTE:** Be sure to note the orientation of the hard drive (which side is up and connector location) before removing from the hard drive cage.



To replace the hard drive, reverse the removal procedures.

## Memory

The memory modules (**2**) are located under the memory cover under left rear cover. You do not have to remove the computer from the column to replace the memory modules.



SODIMMs are small outline dual-inline memory modules. SODIMM modules must meet the following requirements:

- 204-pin DDR3L SODIMM
- PC3L-12800 (1600 MHz) DDR3L-SDRAM
- Unbuffered, non-ECC (64-bit) DIMMs
- 1.35 V memory only
- 16 GB maximum installable memory



**NOTE:** Because the memory uses dual channels, you must use the same SODIMM type for both sockets.

The actual memory transfer speed might vary based on the processor used in your computer.

Memory performance might vary due to different system configurations.


There are two memory sockets on the system board located behind the memory cover. To remove or install memory modules:

To remove a memory module:


1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the left rear cover (see [Removing the rear covers from the computer on page 26](#)).



3. Lift the top of the memory cover to disengage it from the computer (1), and then remove the cover (2).



4. Spread the two retention clips outward (1) until the memory module tilts up at a 45-degree angle. Remove the module (2). Use the same procedure to remove both memory modules.



**NOTE:** A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

The computer automatically recognizes the additional memory when you turn on the computer.


## Wireless USB dongle

Two wireless replacement kits are available:

- Wireless keyboard
- Wireless mouse with wireless receiver


The wireless USB dongle controls both kits.

The dongle **(3)** is located under the right rear cover. You do not have to remove the computer from the column to remove the wireless USB dongle.




To remove a wireless USB dongle:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the right rear cover (see [Removing the rear covers from the computer on page 26](#)).
3. Remove the old wireless receiver from the internal USB port, and then insert the new receiver into the port.



# Battery

The battery is located under the memory cover near the memory modules. You do not have to remove the computer from the column to replace the battery.



The battery that comes with the computer provides power to the real-time clock. When replacing the battery, use a battery equivalent to the battery originally installed in the computer. The computer comes with a 3-volt lithium coin cell battery.

**⚠ WARNING!** The computer contains an internal lithium manganese dioxide battery. There is a risk of fire and burns if the battery is not handled properly. To reduce the risk of personal injury:

Do not attempt to recharge the battery.

Do not expose to temperatures higher than 60° C (140° F).

Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.

Replace the battery only with the HP spare designated for this product.

**⚠ CAUTION:** Before replacing the battery, it is important to back up the computer CMOS settings. When the battery is removed or replaced, the CMOS settings will be cleared.


Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object.

**📝 NOTE:** The lifetime of the lithium battery can be extended by plugging the computer into a live AC wall socket. The lithium battery is only used when the computer is NOT connected to AC power.

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, go to <http://www.hp.com/recycle>.

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the left rear cover (see [Removing the rear covers from the computer on page 26](#)).
3. Remove the memory cover (see [Memory on page 30](#)).
4. To release the battery from its holder, squeeze the metal clamp that extends above one edge of the battery. When the battery pops up, lift it out (1).

5. To insert the new battery, slide one edge of the replacement battery under the holder's lip with the positive side up. Push the other edge down until the clamp snaps over the other edge of the battery **(2)**.



## Separating the computer from the column

You must remove the computer from the column before you can service any components other than the hard drive, memory, and battery. The computer is secured to the column using four Torx screws. One power cable connects the column to the computer as well.


1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Remove the two right screws that secure the computer to the column.



4. Remove the two left screws that secure the computer to the column.



5. Separate the computer from the column slightly – enough to access the cable that connects the column to the computer.






6. Disconnect the power connector cable from the computer.



Reverse the separation procedures to reattach the computer to the column.

## Top rear cover (webcam)

The top rear cover is located at the top of the computer. Under the cover are the microphone module and the webcam module.



To remove the webcam cover:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).




4. Use a tool to disengage the top of the cover from the top of the computer, and then rotate the cover off the computer.



To install the webcam cover, reverse the removal procedures.


## Microphone module

The microphone module is located at the top of the computer beneath the webcam cover. The microphone module sits on top of the webcam module.



To remove the microphone module:


1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the webcam cover (see [Top rear cover \(webcam\) on page 38](#)).
5. Disconnect the cables from each side of the module **(1)**.
6. Remove the Torx screw **(2)** that secures the microphone module bracket to the computer, and then remove the module.



To install a microphone module, reverse the removal procedures.

## Webcam module

The webcam module is located at the top of the computer beneath the webcam cover and microphone module.



To remove the webcam module:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the webcam cover (see [Top rear cover \(webcam\) on page 38](#)).
5. Remove the microphone module (see [Microphone module on page 40](#)).
6. Remove the Torx screw that secures the webcam module bracket to the computer.



7. Lift and rotate the assembly to gain access to the connector on the module, and then disconnect the cable from the module.




For reinstallation, note the cable routing on the back of the module.



To install a webcam module, reverse the removal procedures.

## Ambient light sensor (ALS) board

The ambient light sensor board is located in the top left corner of the computer.



To remove the ALS board:


1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the Torx screw **(1)** that secures the ALS bracket to the computer.



5. Lift the bracket up enough to disconnect the cable (2).




6. Disconnect the cable from the board.



To install the ambient light sensor board, reverse the removal procedures.


## Power button board

The power button board is located in the top right corner of the computer.




To remove the power button board:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the Torx screw **(1)** that secures the power button board bracket to the computer.
5. Lift the bracket up enough to disconnect the cable **(2)**.



6. Disconnect the cable from the board.



To install the power button board, reverse the removal procedures.




## System board cover


The system board cover protects the system board. You must remove a plastic cover from atop the system board cover before you can remove it.

To remove the system board cover:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Rotate the bottom of the bottom rear plastic cover upward to remove it.




5. Remove the four Torx screws **(1)** that secure the system board cover to the computer, and then lift the cover off the computer **(2)**.




To replace the system board cover, reverse the removal procedures.

## WLAN module

The WLAN module is located on the left side of the system board.




 **NOTE:** WLAN module appearance may vary.


To remove the WLAN module:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).
5. Disconnect the antenna cables from the module **(1)**.

6. Remove the Phillips screw (2) that secures the module to the computer.



7. Lift the module to a 45-degree angle (1), and then pull it away to remove it from the socket (2).



To install the WLAN module, reverse the removal procedures.

When connecting the antennas cables, connect the cable labeled “1” to the MAIN connector on the module and the cable labeled “2” to the AUX connector on the module.




**NOTE:** WLAN modules are designed with a notch to prevent incorrect insertion.



## Converter board

The converter board is located to the left of the system board.



Use the same converter spare part for all display panels; however, you must change jumper settings, backlight cable, and cable connection on the board based on the display panel manufacturer.

To remove the converter board:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).
5. Disconnect the two cables from the board **(1)**.




**NOTE:** Use the backlight cable specific to the display manufacturer.


6. Remove the two Torx screws (2) that secure the board to the computer.

Be sure to correctly position the jumpers on the converter board for the installed display panel. Proper jumper settings are printed on the converter board.

Be sure to connect the converter cable into the correct connector on the converter board for the manufacturer of the installed display panel.



7. Lift the converter board from the computer.



To install the converter board, reverse the removal procedures.

Be sure to correctly position the jumpers on the converter board for the manufacturer of the installed display panel. The jumper settings are printed on the converter board.

LG – 1:2, 3:4

Samsung – 1:2, 5:6

BOE – 3:4, 5:6



Be sure to connect the converter cable into the correct connector on the converter board for the manufacturer of the installed display panel. The jumper settings are shown on a label near the converter board.

LG: CON816

BOE: CON817


Samsung: CON820





## Right I/O board

The right I/O board is located on the right side of the computer.



To remove the right I/O board:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).



5. Disconnect the cable from the top of the board **(1)**, and then remove the two Torx screws **(2)** that secure the board to the computer **(2)**.




6. Remove the board from the computer.

To install the right I/O board, reverse the removal procedures.

## Left I/O board


The left I/O board is located on the left side of the computer.



To remove the left I/O board:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).

5. Disconnect the cable from the top of the board **(1)**, and then remove the two Torx screws **(2)** that secure the board to the computer **(2)**.



6. Remove the board from the computer.


To install the left I/O board, reverse the removal procedures.

## Speakers

The speakers are located at the bottom and left side of the computer. Two separate speakers are each secured by three Torx screws and are wired together.


To remove the speakers:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).
5. Remove three Torx screws **(1)** that secure the bottom speaker to the computer.
6. Remove the wire that connects the speakers from its routing path **(2)** near the wireless USB dongle.



7. Disconnect the speaker cable from the system board connector **(1)**, and then remove the three Torx screws **(2)** that secure the bottom speaker to the computer.

8. Remove the speakers from the computer.



To install the speakers, reverse the removal procedures.


## Heat sink

The heat sink is secured with four captive Torx screws, four captive Phillips #1 screws, and one non-captive Torx screw.

To remove the heat sink:


1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).
5. In the order indicated on the heat sink, loosen the four captive Torx screws **(1) – (4)** from the larger part of the heat sink over the processor.

---

 **CAUTION:** Remove heat sink retaining screws in diagonally opposite pairs (as in an X) to even the downward forces on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

---
6. In the order indicated on the heat sink, loosen the four captive Phillips #1 screws **(1) – (4)** from the smaller part of the heat sink over the graphics chip.

---


 **CAUTION:** Remove heat sink retaining screws in diagonally opposite pairs (as in an X) to even the downward forces on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

---
7. Remove the Torx screw on the right part of the heat sink **(5)** above the fan.



8. Lift the heat sink out of the computer.

**⚠ CAUTION:** To reduce a degradation in thermal performance, be sure not to touch the thermal grease on the surface of the processor or the heat sink.



To replace the heat sink, reverse the removal procedures.


# Processor

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).
5. Remove the heat sink (see [Heat sink on page 60](#)).
6. Rotate the locking lever to its full open position **(1)**.

---

**CAUTION:** Do NOT handle the pins in the processor socket. These pins are very fragile and handling them could cause irreparable damage. Once pins are damaged it may be necessary to replace the system board.

---



7. Raise and rotate the microprocessor retainer to its fully open position **(2)**.
8. Lift the processor **(3)** straight up and remove it.

---

**NOTE:** After installing a new processor onto the system board, update the system ROM to ensure that the latest version of the BIOS is being used on the computer. The latest system BIOS can be found on the Web at: <http://www.hp.com>.


---



## Fan assembly

To remove the fan assembly:


1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).
5. Remove the three Torx screws that secure the fan assembly to the computer **(1)**.
6. Disconnect the fan cable **(2)** from the system board.
7. Remove the USB cable from the clip **(3)** in the fan.
8. Remove the fan from the computer.



To install the fan assembly, reverse the removal procedures.


## Antennas

The antennas route from the WLAN card to transceivers at the top of the computer (transceivers highlighted in following image).



To remove the antennas:


1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
4. Remove the system board cover (see [System board cover on page 47](#)).
5. Peel the transceivers off the frame. The transceivers are secured using strong adhesive.



6. Disconnect the antennas from the WLAN module.



7. Remove the antenna cables from their routing path and the clips built into the frame.



To install the antenna, reverse the removal procedures.




**NOTE:** When connecting the antennas cables to the WLAN module, connect the cable labeled “1” to the MAIN connector on the module and the cable labeled “2” to the AUX connector on the module.



## Hard drive connector


The hard drive connector is located above the system board.



To remove the hard drive connector:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Remove the hard drive (see [Hard drive on page 28](#)).
4. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
5. Remove the system board cover (see [System board cover on page 47](#)).
6. Disconnect the hard drive cable from the system board **(1)**.
7. Remove two Torx screws **(2)** that secure the hard drive connector to the computer.

8. Remove the connector from the computer.



To install the hard drive connector, reverse the removal procedures.


# System board

Description
System board for use in models without Windows 8
System board for use in models with Windows 8 Standard
System board for use in models with Windows 8 Professional


To remove the system board:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Remove the hard drive (see [Hard drive on page 28](#)).
4. Remove the memory modules (see [Memory on page 30](#)).
5. Remove the wireless USB dongle (see [Wireless USB dongle on page 32](#)).
6. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
7. Remove the system board cover (see [System board cover on page 47](#)).
8. Remove the heat sink (see [Heat sink on page 60](#)).
9. Remove the fan (see [Fan assembly on page 63](#)).
10. Remove the processor (see [Processor on page 62](#)).
11. Remove the WLAN module (see [WLAN module on page 49](#)).

12. Disconnect all cables from the system board, noting their location for reinstallation.




13. Remove the 11 Torx screws that secure the system board to the computer, and then remove the system board.



To install the system board, reverse the removal procedures.

Make sure the thermal pads below the system board are installed as shown in the following image.





### Updating the display panel manufacturer setting in BIOS

After replacing the system board, make sure the display panel manufacturer setting is correct in BIOS. If the incorrect panel manufacturer is set in BIOS, the display panel may function incorrectly.

The display panel manufacturer is identified on the jumper setting label on the base pan.

After confirming the manufacturer of the display panel on the computer, go into BIOS and make sure the **LVDS Panel Select** setting is correct.

To update BIOS with display panel model information:

1. Boot the computer.
2. Repeatedly press **F10** when the monitor light turns green to access the F10 Setup utility.
3. Select **Advanced**, select **Device Options**, select **LVDS Panel Select**, and then select the manufacturer for the new display panel.
4. Save your settings, exit F10 Setup, and allow the computer to continue to the operating system.


When you change the LVDS setting to the installed panel type, the BIOS reprograms the EDID with the correct data. You must set the panel before the Auto-select setting functions correctly.

### Updating SMBIOS Information

When replacing the system board, you must reprogram the SMBIOS information on the affected computer. Failure to reprogram the board will result in eventual failure, such as an activation failure (need to reactivate the system) or a system recovery failure.




To update SMBIOS information in Computer Setup:

1. Turn on or restart the computer.
  2. Press **Esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
- 
-  **NOTE:** If you do not press **Esc** at the appropriate time, you must restart the computer and again press **Esc** when the monitor light turns green to access the utility.
- 
3. Press **F10** to enter Computer Setup.
  4. Go to **Security > System ID's**.
  5. If necessary, press **Ctrl+A** to initiate edit mode.
  6. Edit the fields listed. If the feature byte has data or is not editable, then it was not cleared and cannot be edited.

### System ID Setup Page

Setup Field Name	Comment	Label
Product Name	Enter the Model name/number or marketing name.	Flexbuild
Serial Number	Enter the Serial Number of Unit.	Support
SKU Number	Enter the SKU or Product Number including Localization Code.	Support
Asset Tag	Enter the 18-byte identifier assigned to the computer.	Support
Feature Byte	<p>Enter the Feature Byte string. The feature byte string is case sensitive.</p> <p>The label includes spaces after every four characters. You can enter or ignore these spaces – their only purpose is to help with data entry. There is a character limitation of 40 bytes per line. When you reach this limit, go to the next line to continue data entry. BIOS ignores the spaces and lines.</p> <p>If you make an error during data entry, the data will not validate, and the computer asks you to correct your data input.</p>	Flexbuild
Build ID	The Build ID of the unit.	Flexbuild

## System board callouts





Sys Bd Label	Color	Component	Sys Bd Label	Color	Component
SATA0	Black	Hard drive data	CONVERTER	White	Converter board
DC-IN	Black	Power connector	SPEAKER	White	Speaker
POWER_BTN	White	Power button board	SIDEIO	Silver/black	Left I/O board
DOCKING	White	Column docking connector	MINI_CARD1	White	WLAN module connector
LVDS1	White	Display connector	BATTERY	Black	RTC battery
CPUFAN	White	Fan connector	MINI_CARD2	White	Mini card connector
PROCESSOR	Black	Processor socket	WCAM_ARMIC	Black	Webcam
XMM1	White	Memory socket	TP_USB	White	Touch connector
XMM2	Black	Memory socket	KB/MS_USB	White	Wireless USB dongle
RSIDEIO	Silver/black	Right I/O board	SATAPWR	White	Hard drive power connector
CMOS+PW	Blue	Clear CMOS and system passwords			


## Display assembly

To remove the display assembly:

1. Prepare the computer for disassembly (see [Preparing to disassemble the computer on page 25](#)).
2. Remove the rear covers (see [Removing the rear covers from the computer on page 26](#)).
3. Remove the hard drive (see [Hard drive on page 28](#)).
4. Separate the computer from the column (see [Separating the computer from the column on page 35](#)).
5. Remove the system board cover (see [System board cover on page 47](#)).
6. Remove the system board (see [System board on page 68](#)).
7. Disconnect the backlight cable from the display (at bottom left), and then remove the 14 Torx screws that secure the display to the main system frame assembly.

 **NOTE:** The screws required to remove the display assembly are marked with an arrow that is stamped into the frame.

 **CAUTION:** A cable that is mounted on the frame is connected to the touch board on the display assembly. After removing the screws, be sure to separate the frame from the display only enough to gain access to and disconnect this cable.



8. Separate the frame from the display only enough to access the touch board and cable, and disconnect the cable from the touch board.



Be sure to correctly position the jumpers on the converter board for the manufacturer of the installed display panel. The jumper settings are printed on the converter board.

LG – 1:2, 3:4

Samsung – 1:2, 5:6

BOE – 3:4, 5:6



Be sure to connect the converter cable into the correct connector on the converter board for the manufacturer of the installed display panel. The jumper settings are shown on a label near the converter board.

LG: CON816

BOE: CON817

Samsung: CON820



**CAUTION:** Incorrect jumper placement can result in damage to the converter board and display panel.

To install a display panel, reverse the removal procedures.

#### Updating BIOS with new display panel information

If you install a display panel from a different manufacturer than what was previously installed (for example, replace an LG panel with a Samsung panel), you need to update BIOS with the new panel information. Failure to do so may cause the new panel to function incorrectly.

To update BIOS with the new panel model information:

1. Boot the computer.
2. Repeatedly press **F10** when the monitor light turns green to access the F10 Setup utility.
3. Select **Advanced**, select **Device Options**, select **LVDS Panel Select**, and then select the manufacturer for the new display panel.
4. Save your settings, exit F10 Setup, and allow the computer to continue to the operating system.

When you change the LVDS setting to the installed panel type, the BIOS reprograms the EDID with the correct data. You must set the panel before the Auto-select setting functions correctly.



---


## 5 Removal and Replacement Procedures – Column

The following sections provide information about disassembling various components of the computer.


### Preparing to disassemble the column

To avoid injury and equipment damage, always complete the following steps in order, when opening the Sprout.

1. Remove all media from the computer.
2. Shut down the computer.
3. After the system has completely shut down, remove the Touch Mat and disconnect the power cord and all attached cables from the back of the computer.
4. Using caution, lay the computer down on a flat surface covered with a soft cloth. Make sure the head hangs off the front of the table (as shown).



---

 **WARNING!** Beware of sharp edges inside the chassis.

---



## Removing the rear covers from the computer

You must remove the rear covers from the computer before you can service the computer or the column. Each cover may be secured with one captive screw.

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. If a security screw is installed in the bottom of the rear cover, remove the screw **(1)**. Slide the left rear cover toward the left to disengage it from the computer **(2)**, and then lift the cover off the computer **(3)**.





3. If a security screw is installed in the bottom of the rear cover, remove the screw **(1)**. Slide the right rear cover toward the right to disengage it from the computer **(2)**, and then lift the cover off the computer **(3)**.



Reverse the removal procedures to install the covers.

## Separating the computer from the column

You must remove the computer from the column before you can service the column. The computer is secured to the column using four Torx screws. One power cable connects the column to the computer as well.


1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Remove the two right screws that secure the computer to the column.



4. Remove the two left screws that secure the computer to the column.



5. Separate the computer from the column slightly – enough to access the cable that connects the column to the computer.



6. Disconnect the power connector cable from the computer.



Reverse the separation procedures to reattach the computer to the column.

## Bottom cover

The bottom cover is on the bottom of the column. It is secured with four Phillips screws.

To remove the bottom cover:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the four Phillips screws **(1)** that secure the cover to the bottom of the column, and then remove the cover from the column **(2)**. You may need to use a flat tool to release the cover from the column.



To replace the bottom cover, reverse the removal procedures.

## Side and top cover


The white side and top cover is one large piece that is secured to the sides and top of the column. Tabs secure the bottom of the cover to the bottom of the column. Double-sided tape secures the sides to the column.



To remove the side and top cover:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).

5. From the bottom of the column under the bottom cover, insert a flat tool into the two slots to disengage the bottom of the left and right side covers.



6. Pry the sides away from the column (1) until the tape that secures the side covers (2) releases from the column.





7. Lift the right side cover upward to disengage the top of the cover from the column, and then remove the cover from the column.



To install the side and top cover, reverse the removal procedures.



## Inside cover

The inside cover is located on the inside of the column, facing the computer.




1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).

6. Remove the two Torx screws that secure the cover to the column **(1)**. Note the power supply cable routes through a hole in the front of the cover **(2)**.




7. Use a flat tool to disengage the tabs that secure the cover to the column **(1)**, and then lift the cover off the column **(2)**.



To install the inside cover, reverse the removal procedures.

## Docking board shield


The docking board shield is located under the inside cover. It is secured with four Torx screws.



To remove the docking board shield:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the four Phillips Torx screws **(1)** that secure the shield to the computer. Note the location through which the power cable is routed **(2)**.

8. Remove the shield.



To install the docking board shield, reverse the removal procedures.

## Docking board

The docking board is secured with five Torx screws. Seven cables are connected to the top of the board and four cables are connected to the bottom of the board.

To remove the docking board:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the docking board shield (see [Docking board shield on page 89](#)).
8. Disconnect the following cables:

**(1):** NFC Touchmat

**(2):** Lamp


**(3):** Projector

**(4):** Projector power


**(5):** Hi-res camera

**(6):** Main power

**(7):** HDMI




9. Remove the five Torx screws that secure the board to the column.



10. Disconnect the following cables:

- (1): Rear I/O
- (2): Subwoofer
- (3): Line out



To install the docking board, reverse the removal procedures.




## Docking board bracket


The docking board bracket is secured with three Torx screws. Two cables are routed along the bottom of the bracket.

To remove the docking board bracket:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the docking board shield (see [Docking board shield on page 89](#)).
8. Remove the docking board (see [Docking board on page 91](#)).
9. Remove the three Torx screws that secure the bracket to the column.



10. Position the bracket upside down, and then remove the cables from the routing paths on the bottom of the bracket.



The install the bracket, reverse the removal procedures.

To replace the docking board bracket, reverse the removal procedures.




## Subwoofer mesh cover

The subwoofer mesh cover sits over the subwoofer at the bottom of the column.



1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the docking board shield (see [Docking board shield on page 89](#)).
8. Remove the docking board (see [Docking board on page 91](#)).
9. Remove the docking board bracket (see [Docking board bracket on page 93](#)).

10. Push in on the side of the cover near the bottom of the column to disengage it from the column **(1)**, and then lift the cover from the column **(2)**.



To install the cover, reverse the removal procedures.

## Subwoofer

To remove the subwoofer:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the docking board shield (see [Docking board shield on page 89](#)).
8. Remove the docking board (see [Docking board on page 91](#)).
9. Remove the docking board bracket (see [Docking board bracket on page 93](#)).
10. Remove the subwoofer cover (see [Subwoofer mesh cover on page 95](#)).
11. Remove the four Torx screws that secure the subwoofer to the column.



12. Lift the subwoofer out of the column.



To install the subwoofer, reverse the removal procedures.

## Power supply

The power supply is located in the column just above the subwoofer.



To remove the power supply:


1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the docking board shield (see [Docking board shield on page 89](#)).
8. Remove the docking board (see [Docking board on page 91](#)).

9. Remove the docking board bracket (see [Docking board bracket on page 93](#)).
10. Remove the subwoofer cover (see [Subwoofer mesh cover on page 95](#)).
11. Remove the subwoofer (see [Subwoofer on page 97](#)).
12. Remove the four Torx screws that secure the power supply to the column, and the lift the power supply enough to access the connector underneath.





13. Disconnect the small cable from the POGO board (1), and slide the power connector from the slot (2).



To install the power supply, reverse the removal procedures.



**NOTE:** When connecting the antennas cables, connect the cable labeled “1” to the MAIN connector on the module and the cable labeled “2” to the AUX connector on the module.



## Rear I/O modules


The rear I/O modules are located at the bottom of the column under the power supply.



To remove the rear I/O modules:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the docking board shield (see [Docking board shield on page 89](#)).
8. Remove the docking board (see [Docking board on page 91](#)).
9. Remove the docking board bracket (see [Docking board bracket on page 93](#)).
10. Remove the subwoofer cover (see [Subwoofer mesh cover on page 95](#)).
11. Remove the subwoofer (see [Subwoofer on page 97](#)).

12. Remove the power supply (see [Power supply on page 99](#)).
13. Remove the two Torx screws from each module (1), and then lift the modules straight up and out of the column (2).



To replace the rear I/O modules, reverse the removal procedures.

## POGO (Touch Mat) board

The POGO board is located at the bottom of the column under a cover and above the rear I/O modules. The Touch Mat connects to the POGO board.

**POGO COVER**




**POGO BOARD**




To remove the POGO board:

1. Prepare the computer for disassembly (see [Preparing to disassemble the column on page 77](#)).
2. Remove the rear covers from the computer (see [Removing the rear covers from the computer on page 78](#)).
3. Separate the computer from the column (see [Separating the computer from the column on page 80](#)).
4. Remove the bottom cover (see [Bottom cover on page 83](#)).
5. Remove the side and top cover (see [Side and top cover on page 84](#)).
6. Remove the inside cover (see [Inside cover on page 87](#)).
7. Remove the docking board shield (see [Docking board shield on page 89](#)).
8. Remove the docking board (see [Docking board on page 91](#)).

9. Remove the docking board bracket (see [Docking board bracket on page 93](#)).
10. Remove the subwoofer cover (see [Subwoofer mesh cover on page 95](#)).
11. Remove the subwoofer (see [Subwoofer on page 97](#)).
12. Remove the POGO board cover by using a flat tool to press in the slots on the bottom of the column while at the same time lifting up on the tab on the cover.



13. Remove the POGO board by disconnecting the Touch Mat cable (1), removing the two Torx screws (2) that secure the board to the column, and then lifting the board out of the column (3).



To install the POGO board, reverse the removal procedures.



---

## 6 Computer Setup (F10) Utility

### Computer Setup (F10) Utilities

Use Computer Setup (F10) Utility to do the following:

- Change factory default settings.
- Set the system date and time.
- Set, view, change, or verify the system configuration, including settings for processor, graphics, memory, audio, storage, communications, and input devices.
- Modify the boot order of bootable devices such as hard drives, optical drives, or USB flash media devices.
- Enable Quick Boot, which is faster than Full Boot but does not run all of the diagnostic tests run during a Full Boot. You can set the system to:
  - always Quick Boot (default);
  - periodically Full Boot (from every 1 to 30 days); or
  - always Full Boot.
- Select Post Messages Enabled or Disabled to change the display status of Power-On Self-Test (POST) messages. Post Messages Disabled suppresses most POST messages, such as memory count, product name, and other non-error text messages. If a POST error occurs, the error is displayed regardless of the mode selected. To manually switch to Post Messages Enabled during POST, press any key (except **F1** through **F12**).
- Establish an Ownership Tag, the text of which is displayed each time the system is turned on or restarted.
- Enter the Asset Tag or property identification number assigned by the company to this computer.
- Enable the power-on password prompt during system restarts (warm boots) as well as during power-on.
- Establish a setup password that controls access to the Computer Setup (F10) Utility and the settings described in this section.
- Secure integrated I/O functionality, including the serial, USB, audio, or embedded NIC, so that they cannot be used until they are unsecured.
- Enable or disable removable media boot ability.

- Solve system configuration errors detected but not automatically fixed during the Power-On Self-Test (POST).
- Replicate the system setup by saving system configuration information on a USB device and restoring it on one or more computers.
- Execute self-tests on a specified ATA hard drive (when supported by drive).

## Using Computer Setup (F10) Utilities

Computer Setup can be accessed only by turning the computer on or restarting the system. To access the Computer Setup Utilities menu, complete the following steps:

1. Turn on or restart the computer.
2. Repeatedly press **F10** when the monitor light turns green to access the utility.

You can also press **Esc** to a menu that allows you to access different options available at startup, including the Computer Setup utility.



**NOTE:** If you do not press **F10** at the appropriate time, you must restart the computer and again repeatedly press **F10** when the monitor light turns green to access the utility.

3. A choice of five headings appears in the Computer Setup Utilities menu: File, Storage, Security, Power, and Advanced.
4. Use the arrow (left and right) keys to select the appropriate heading. Use the arrow (up and down) keys to select the option you want, then press **Enter**. To return to the Computer Setup Utilities menu, press **Esc**.
5. To apply and save changes, select **File > Save Changes and Exit**.
  - If you have made changes that you do not want applied, select **Ignore Changes and Exit**.
  - To reset to factory settings or previously saved default settings (some models), select **Apply Defaults and Exit**. This option will restore the original factory system defaults.



**NOTE:** Not all settings shown in the following sections are available for all models



**CAUTION:** Do NOT turn the computer power OFF while the BIOS is saving the Computer Setup (F10) changes because the CMOS could become corrupted. It is safe to turn off the computer only after exiting the F10 Setup screen.



## Computer Setup—File



**NOTE:** Support for specific Computer Setup options may vary depending on the hardware configuration.

**Table 6-1 Computer Setup—File**

Option	Description
<b>System Information</b>	<p>Lists:</p> <ul style="list-style-type: none"><li>• Manufacturer</li><li>• Product name</li><li>• SKU number</li><li>• Serial number</li><li>• Born on date</li><li>• System Board ID</li><li>• System Board CT Number</li><li>• BIOS revision</li><li>• BIOS date</li><li>• Processor type/speed</li><li>• Installed memory size/speed, number of channels (single or dual) (if applicable)</li><li>• Integrated MAC address for embedded, enabled NIC (if applicable)</li></ul>
<b>About</b>	Displays copyright notice.
<b>Set Time and Date</b>	Allows you to set system time and date.
<b>Default Setup</b>	<p><b>Save Current Settings as Default</b></p> <p>Saves the current system configuration settings as the default.</p> <p><b>Restore Factory Settings as Default</b></p> <p>Restores the factory system configuration settings as the default.</p>
<b>Apply Defaults and Exit</b>	Applies the currently selected default settings and clears any established passwords.
<b>Ignore Changes and Exit</b>	Exits Computer Setup without applying or saving any changes.
<b>Save Changes and Exit</b>	Saves changes to system configuration or default settings and exits Computer Setup.

# Computer Setup—Storage



**NOTE:** Support for specific Computer Setup options may vary depending on the hardware configuration.

**Table 6-2 Computer Setup—Storage**

Option	Description
Device Configuration	<p>Lists all installed BIOS-controlled storage devices.</p> <p>When a device is selected, detailed information and options are displayed. The following options may be presented:</p> <ul style="list-style-type: none"><li>• <b>Hard Disk:</b> Size, model, firmware version, serial number.</li></ul>
Storage Options	<p><b>SATA Emulation</b></p> <p>Allows you to choose how the SATA controller and devices are accessed by the operating system. There are two supported options: IDE and AHCI (default).</p> <p><b>CAUTION:</b> SATA emulation changes may prevent access to existing hard drive data and degrade or corrupt established volumes.</p> <p>IDE - This is the most backwards-compatible setting of the three options. Operating systems usually do not require additional driver support in IDE mode.</p> <p>AHCI (default option) - Allows operating systems with AHCI device drivers loaded to take advantage of more advanced features of the SATA controller.</p>
DPS Self-Test	<p>Allows you to execute self-tests on ATA hard drives capable of performing the Drive Protection System (DPS) self-tests.</p> <p><b>NOTE:</b> This selection will only appear when at least one drive capable of performing the DPS self tests is attached to the system.</p>

**Table 6-2 Computer Setup—Storage (continued)**

<b>Boot Order</b>	<p>Allows you to configure:</p> <ul style="list-style-type: none"><li>• <b>UEFI Boot Sources:</b> Specify the order in which UEFI boot sources (such as a internal hard drive, USB hard drive, USB optical drive, or ethernet controller) are checked for a bootable operating system image. Each device on the list may be individually excluded from or included for consideration as a bootable operating system source.</li></ul> <p>UEFI boot sources always have precedence over legacy boot sources.</p> <ul style="list-style-type: none"><li>• <b>Legacy Boot Sources:</b> Specify the order in which legacy boot sources (such as a network interface card, internal hard drive, or USB optical drive) are checked for a bootable operating system image. Each device on the list may be individually excluded from or included for consideration as a bootable operating system source.</li></ul> <p>Specify the order of attached hard drives. The first hard drive in the order will have priority in the boot sequence and will be recognized as drive C (if any devices are attached).</p> <p><b>NOTE:</b> You must disable Secure Boot before you can configure this option.</p>
	<p><b>NOTE:</b> To drag a device to a preferred place, press <b>Enter</b>. To remove the device from consideration as a bootable device, press <b>F5</b>.</p> <p>You can use <b>F5</b> to disable individual boot items, as well as disable UEFI boot and/or legacy boot.</p> <p><b>NOTE:</b> MS-DOS drive lettering assignments may not apply after a non-MS-DOS operating system has started.</p> <p><b>Shortcut to Temporarily Override Boot Order</b></p> <p>To boot <b>one time</b> from a device other than the default device specified in Boot Order, restart the computer and press <b>Esc</b> (to access the boot menu) and then <b>F9</b> (Boot Order), or only <b>F9</b> (skipping the boot menu) when the monitor light turns green. After POST is completed, a list of bootable devices is displayed. Use the arrow keys to select the preferred bootable device and press <b>Enter</b>. The computer then boots from the selected non-default device for this one time.</p>

## Computer Setup—Security



**NOTE:** Support for specific Computer Setup options may vary depending on the hardware configuration.

**Table 6-3 Computer Setup—Security**

Option	Description
<b>Setup Password</b>	<p>Allows you to set and enable a setup (administrator) password.</p> <p><b>NOTE:</b> If the setup password is set, it is required to change Computer Setup options, flash the ROM, and make changes to certain plug and play settings under Windows.</p>
<b>Power-On Password</b>	<p>Allows you to set and enable a power-on password. The power-on password prompt appears after a power cycle or reboot. If the user does not enter the correct power-on password, the unit will not boot.</p>
<b>Device Security</b>	<p>Allows you to set Device Available/Device Hidden (default is Device Available) for:</p> <ul style="list-style-type: none"><li>• System audio</li></ul> <p><b>NOTE:</b> Set this value to 'Device hidden' to disable all system volume.</p> <ul style="list-style-type: none"><li>• Network controller</li></ul> <p><b>NOTE:</b> You must disable AMT before trying to hide the network controller.</p> <ul style="list-style-type: none"><li>• Onboard card reader</li><li>• SATA ports</li></ul>
<b>USB Security</b>	<p>Allows you to set Enabled/Disabled (default is Enabled) for:</p> <ul style="list-style-type: none"><li>• Front USB Ports</li><li>• Rear USB Ports</li><li>• Internal USB Ports</li></ul>
<b>Slot Security</b>	<p>Allows you to disable the mini card slot. Default is enabled.</p>
<b>Network Boot</b>	<p>Enables/disables the computer's ability to boot from an operating system installed on a network server. Default is enabled.</p>
<b>System IDs</b>	<p>Allows you to view:</p> <ul style="list-style-type: none"><li>• Product Name</li><li>• Serial Number</li><li>• Universal Unique Identifier (UUID) number. The UUID can only be updated if the current chassis serial number is invalid. (These ID numbers are normally set in the factory and are used to uniquely identify the system.)</li><li>• SKU Number</li><li>• Family Name</li><li>• Feature Byte</li><li>• Build ID</li><li>• Keyboard locale setting for System ID entry.</li></ul>

**Table 6-3 Computer Setup—Security (continued)**

<b>System Security</b> (these options are hardware dependent)	Virtualization Technology (VTx/VTd) (enable/disable). Controls the virtualization features of the processor. Changing this setting requires turning the computer off and then back on. Default is disabled.
<b>Secure Boot Configuration</b>	<p>This is a feature of Windows 8.</p> <ul style="list-style-type: none"> <li>• <b>Legacy Support—Enable/Disable.</b> Allows you to turn off all legacy support on the computer, including booting to DOS, running legacy graphics cards, booting to legacy devices, and so on. If set to disable, legacy boot options in <b>Storage &gt; Boot Order</b> are not displayed. Default is enabled.</li> <li>• <b>Secure Boot—Enable/Disable.</b> Allows you to make sure an operating system is legitimate before booting to it, making Windows resistant to malicious modification from preboot to full OS booting, preventing firmware attacks. UEFI and Windows Secure Boot only allow code signed by pre-approved digital certificates to run during the firmware and OS boot process. Default is disabled, except for Windows 8 systems which have this setting enabled. Secure Boot enabled also sets <b>Legacy Support</b> to disabled.</li> <li>• <b>Key Management—</b>This option lets you manage the custom key settings. <ul style="list-style-type: none"> <li>◦ <b>Clear Secure Boot Keys—Don't Clear/Clear.</b> Allows you to delete any previously loaded custom boot keys. Default is Don't Clear.</li> <li>◦ <b>Key Ownership—HP Keys/Custom Keys.</b> Selecting Custom Mode allows you to modify the contents of the secure boot signature databases and the platform key (PK) that verifies kernels during system start up, allowing you to use alternative operating systems. Selecting HP Keys causes the computer boot using the preloaded HP-specific boot keys. Default is HP Keys.</li> </ul> </li> <li>• <b>Fast Boot—Enable/Disable.</b> Fast boot disables the ability to interrupt boot, such as pressing f keys to access items before the operating system loads. Default is disabled.</li> </ul> <p><b>NOTE:</b> If Windows 8 detects a serious error, it will interrupt the boot process automatically and display advanced boot options.</p> <p>From Windows 8, you can press <b>Shift</b> and select <b>Restart</b> to access the screen that lets you boot to a device or troubleshoot your computer.</p>

# Computer Setup—Power



**NOTE:** Support for specific Computer Setup options may vary depending on the hardware configuration.

**Table 6-4 Computer Setup—Power**

Option	Description
OS Power Management	<ul style="list-style-type: none"><li>Runtime Power Management— Enable/Disable. Allows certain operating systems to reduce processor voltage and frequency when the current software load does not require the full capabilities of the processor. Default is enabled.</li><li>Idle Power Savings—Extended/Normal. Allows certain operating systems to decrease the processors power consumption when the processor is idle. Default is extended.</li></ul>
Hardware Power Management	<p>SATA Power Management – Enables or disables SATA bus and/or device power management. Default is enabled.</p> <p>S4/S5 Wake on LAN – Enables or disables remotely waking up the computer from S4 (hibernation) or S5 (power is off) power state. Default is disabled.</p> <p>Enable/Disable USB Charging Port – The USB charging port allows an external device to charge until a specified battery charge level is reached. Default is enabled.</p>
Thermal	<p>CPU Fan Speed – Displays fan speed.</p> <p><b>NOTE:</b> This setting only changes the minimum fan speed. The fans are still automatically controlled.</p>

## Computer Setup—Advanced



**NOTE:** Support for specific Computer Setup options may vary depending on the hardware configuration.

**Table 6-5 Computer Setup—Advanced (for advanced users)**

Option	Heading
<b>Power-On Options</b>	<p>Allows you to set:</p> <ul style="list-style-type: none"><li>• POST messages (enable/disable). Enabling this feature will cause the system to display POST error messages, which are error messages displayed on the monitor during the Power On Self Test if the BIOS encounters some kind of problem while starting the PC. A POST error message will only display on screen if the computer is capable of booting this far. If the POST detects an error before this point, a beep code is generated instead. Default is disabled.</li><li>• After Power Loss (off/on/previous state). Default is Off. Setting this option to:<ul style="list-style-type: none"><li>◦ Off—causes the computer to remain powered off when power is restored.</li><li>◦ On—causes the computer to power on automatically as soon as power is restored.</li><li>◦ Previous state—causes the computer to power on automatically as soon as power is restored, if it was on when power was lost.</li></ul></li></ul> <p><b>NOTE:</b> If you turn off power to the computer using the switch on a power strip, you will not be able to use the suspend/sleep feature or the Remote Management features.</p> <ul style="list-style-type: none"><li>• POST Delay (in seconds). Enabling this feature will add a user-specified delay to the POST process. This delay is sometimes needed for hard disks on some PCI cards that spin up very slowly, so slowly that they are not ready to boot by the time POST is finished. The POST delay also gives you more time to select <b>F10</b> to enter Computer (F10) Setup. Default is None.</li></ul>
<b>BIOS Power-On</b>	<p>Allows you to set the computer to turn on automatically at a time you specify.</p>
<b>Onboard Devices</b>	<p>Allows you to set resources for or disable Legacy devices.</p> <p>Select the Legacy device's IRQ, DMA, and I/O Range. The settings may not take effect for all operating systems. To hide a device from the operating system, see Security &gt; Device Security.</p>
<b>Bus Options</b>	<p>Allows you to enable or disable:</p> <ul style="list-style-type: none"><li>• PCI SERR# Generation. Default is enabled.</li><li>• PCI VGA Palette Snooping, which sets the VGA palette snooping bit in PCI configuration space; only needed when more than one graphics controller is installed. Default is disabled.</li></ul>
<b>Device Options</b>	<p>Allows you to set:</p> <ul style="list-style-type: none"><li>• Num Lock State at Power-On (off/on). Enables numlock at boot. Default is On.</li><li>• Multi-Processor (enable/disable). Controls whether or not the BIOS reports multiple processor cores to the OS. Default is enabled.</li><li>• Hyper-Threading (enable/disable). Controls hyper-threading capability on Intel processors. Some programs may run better with this feature disabled. Default is enabled.</li><li>• NIC PXE Option ROM Download (enable/disable). Controls whether or not NIC option ROM is downloaded and executed. Some systems may need to disable this feature to save NIC Option ROM address space for use by other devices. Default is enabled.</li></ul>



# Updating the BIOS

Updated versions of the BIOS may be available on the HP website.

Most BIOS updates on the HP website are packaged in compressed files called *SoftPaqs*.

Some download packages contain a file named *Readme.txt*, which contains information regarding installing and troubleshooting the file.

## Determining the BIOS version

To determine whether available BIOS updates contain later BIOS versions than the one currently installed on the computer, you need to know the version of the system BIOS that is installed.


BIOS version information (also known as *ROM date* and *System BIOS*) can be revealed by pressing **fn+esc** (if you are already in Windows) or by using Setup Utility (BIOS).

1. Start Setup Utility (BIOS).
2. Use the arrow keys to select **File**, select **System Information**, and then make note of your BIOS version.


To exit Setup Utility (BIOS):

1. Use the arrow keys to select **Ignore Changes and Exit**, and then press **enter**.
2. Select **Yes**.

## Downloading a BIOS update

 **CAUTION:** To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the AC power cord. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

- Do not disconnect power from the computer by unplugging the power cord from the AC outlet.
- Do not shut down the computer or initiate Sleep.
- Do not insert, remove, connect, or disconnect any device, cable, or cord.

 **NOTE:** If your computer is connected to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

1. From the Start screen, type *support*, and then select the **HP Support Assistant** app.

– or –

From the Windows desktop, click the question mark icon in the notification area, at the far right of the taskbar.

2. Click **Updates and tune-ups**, and then click **Check for HP updates now**.
3. Follow the on-screen instructions.
4. At the download area, follow these steps:

- a. Identify the most recent BIOS update and compare it to the BIOS version currently installed on your computer. If the update is more recent than your BIOS, make a note of the date, name, or other identifier. You may need this information to locate the update later, after it has been downloaded to your hard drive.
- b. Follow the on-screen instructions to download your selection to the hard drive.

If the update is more recent than your BIOS, make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

BIOS installation procedures vary. Follow any instructions that appear on the screen after the download is complete. If no instructions appear, follow these steps:

1. From the Start screen, type *file*, and then select **File Explorer**.

— or —

From the Windows desktop, right-click the **Start** button, and then select **File Explorer**.

2. Click your hard drive designation. The hard drive designation is typically Local Disk (C:).
3. Using the hard drive path you recorded earlier, open the folder on your hard drive that contains the update.
4. Double-click the file that has an .exe extension (for example, *filename.exe*).

The BIOS installation begins.

5. Complete the installation by following the on-screen instructions.



**NOTE:** After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

## Recovering the Configuration Settings

This method of recovery requires that you first perform the **Save to Removable Media** command with the Computer Setup (F10) Utility before **Restore** is needed. (See [Computer Setup—File on page 109](#) in the Computer Setup—File table.)



**NOTE:** It is recommended that you save any modified computer configuration settings to a USB flash media device and save the device for possible future use.

To restore the configuration, insert the USB flash media device with the saved configuration and perform the **Restore from Removable Media** command with the Computer Setup (F10) Utility. (See [Computer Setup—File on page 109](#) in the Computer Setup—File table.)



---

## 7 Using HP PC Hardware Diagnostics (UEFI)

HP PC Hardware Diagnostics is a Unified Extensible Firmware Interface (UEFI) that allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs outside the operating system so that it can isolate hardware failures from issues that are caused by the operating system or other software components.

To start HP PC Hardware Diagnostics (UEFI):

1. Turn on or restart the computer, quickly press [esc](#), and then press [f2](#).

The BIOS searches 3 places for the diagnostic tools, in the following order:

- a. Connected USB drive



**NOTE:** To download the HP PC Hardware Diagnostics (UEFI) tool to a USB drive, see [Downloading HP PC Hardware Diagnostics \(UEFI\) to a USB device on page 120](#).

- b. Hard drive
- c. BIOS

2. When the diagnostic tool opens, use the keyboard arrow keys to select the language and the type of diagnostic test you want to run, and then follow the on-screen instructions.



**NOTE:** If you need to stop a diagnostic test, press [esc](#).

# Downloading HP PC Hardware Diagnostics (UEFI) to a USB device



**NOTE:** Instructions for downloading HP PC Hardware Diagnostics (UEFI) are provided in English only.

There are two options to download HP PC Hardware Diagnostics to a USB device:

**Option 1: HP PC Diagnostics homepage**— Provides access to the latest UEFI version

1. Go to <http://hp.com/go/techcenter/pcdiags>.
2. Click the **UEFI Download** link, and then select **Run**.

**Option 2: Support and Drivers pages**—Provide downloads for a specific product for earlier and later versions

1. Go to <http://www.hp.com>.
2. Point to **Support**, located at the top of the page, and then click **Download Drivers**.
3. In the text box, enter the product name, and then click **Go**.

– or –

Click **Find Now** to let HP automatically detect your product.

4. Select your computer model, and then select your operating system.
5. In the **Diagnostic** section, click **HP UEFI Support Environment**.

– or –

Click **Download**, and then select **Run**.

---

## 8 Troubleshooting

### Wireless connection problems

Some possible causes for wireless connection problems include the following:

- Wireless device is not turned on.
- Wireless device is not installed correctly or has been disabled.
- Wireless device encountered interference from other devices.
- Wireless device or router hardware has failed.

#### Cannot connect to a WLAN

If you have a problem connecting to a WLAN, confirm that the integrated WLAN device is turned on and properly installed on your Sprout.

1. Be sure that the wireless device is turned on.
2. Then try connecting to the WLAN again.

If you are still unable to connect, follow the steps below.

1. From the Start screen, type `control panel`, and then select **Control Panel**.
2. Select **System and Security**, select **System**, and then click **Device Manager**.
3. Click the arrow next to **Network adapters** to expand the list and show all adapters.
4. Identify the WLAN device from the Network adapters list. The listing for a WLAN device may include the term *wireless*, *wireless LAN*, *WLAN*, or *802.11*.

If no WLAN device is listed, either your Sprout does not have an integrated WLAN device, or the driver for the WLAN device is not properly installed.

For more information about troubleshooting WLANs, see the website links provided in Help and Support.

#### Cannot connect to a preferred network

You may not be able to connect to a preferred network because it is a security-enabled WLAN. You must have the security code to connect to this type of WLAN. See the next section for additional information.

If entering a security code is not the problem, you may have a corrupted WLAN connection. Many times, Windows can automatically repair a corrupted WLAN connection.

- If there is a network status icon in the notification area, at the far right of the taskbar, right-click the icon, and then click **Troubleshoot problems**.

Windows resets your network device and attempts to reconnect to one of the preferred networks.

- If there is no network status icon in the notification area, follow these steps:
  1. From the Start screen, type `control panel`, and then select **Control Panel**.
  2. Select **Network and Internet**, and then select **Network and Sharing Center**.
  3. Select **Troubleshoot problems**, and then select the network you want to repair.

## Current network security codes are unavailable

If you are prompted for a security code (or network key) or a name (SSID) when connecting to a WLAN, the network is protected by security. The SSID and security code are alphanumeric codes that you enter into your Sprout to identify your Sprout to the network. You must have the current codes to connect to a secure network.

- For a network connected to your personal wireless router, review the router user guide for instructions on setting up the same codes on both the router and the WLAN device.
- For a private network, such as a network in an office or at a public Internet chat room, contact the network administrator to obtain the codes, and then enter the codes when you are prompted to do so.

Some networks change the SSID or network keys used in their routers or access points on a regular basis to improve security. You must change the corresponding code in your Sprout accordingly.

If you are provided with a new wireless network key and SSID for a network, and if you have previously connected to that network, follow the steps below to reconnect to the network:

1. From the Windows desktop, click the network status icon in the notification area, at the far right of the taskbar.

A list showing the available WLANs is displayed. If you are in a hotspot where several WLANs are active, several will be displayed.

2. Right-click the network, and then click **Properties**.



**NOTE:** If the network you want is not listed, check with the network administrator to be sure that the router or access point is operating.

3. Click the **Security** tab and enter the correct wireless encryption data into the **Network security key** box.
4. Click **OK** to save these settings.

## Cannot connect to the wireless router

If you are trying to connect to the wireless router and are unsuccessful, reset the wireless router by removing power from the router for 10 to 15 seconds.

If the Sprout still cannot connect to a WLAN, restart the wireless router. For details, see the router manufacturer's instructions.



## Network status icon is not displayed

If the network status icon is not displayed in the notification area after you configure the WLAN, the software driver is either missing or corrupted. A Windows “Device not Found” error message may also be displayed.

To resolve this problem, get the latest version of the WLAN device software and drivers for your Sprout from <http://www.hp.com>.

1. Open your Internet browser.
2. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to [http://welcome.hp.com/country/us/en/wwcontact\\_us.html](http://welcome.hp.com/country/us/en/wwcontact_us.html).
3. Click the option for software and driver downloads, and then type your computer model number in the search box.
4. Press **enter**, and then follow the on-screen instructions.



**NOTE:** If the WLAN device you are using was purchased separately, consult the manufacturer's website for the latest software.

## Power problems

### Sprout will not turn on or start

1. Test the AC outlet by connecting a different electrical device to it.
2. Reconnect the computer's cables, being sure that the connection from the AC power cord to the computer and the connection from the AC power cord to the AC outlet are secure.
3. Try to turn on the Sprout.
  - If the power lights turn on, the AC power cord is working properly.
  - If the connections are secure and the power lights remain off, the AC power cord is not functioning and should be replaced.

Contact support for information about obtaining a replacement AC power cord.

### Hard drive error

1. Press the **ctrl+alt+delete** keys simultaneously.
2. Click the **Power** icon in the lower-right corner of the screen, and then click **Restart**.

Or, press and hold the power button on the Sprout for 5 or more seconds to turn off the Sprout, and then press the power button to turn on the Sprout.
3. If Windows opens, immediately back up all important information to an external hard drive.
4. Whether Windows started or not, contact support. Either the hard drive or the system board may need to be replaced.

## Sprout is not responding

Use the Windows Task Manager to close any programs that are not responding.

1. Press the **ctrl+alt+delete** keys.
2. Click **Task Manager**.
3. Select any program that is not responding, and then click **End Task**.

If closing programs does not work, restart the Sprout.

1. Press the **ctrl+alt+delete** keys.
2. Click the **Power** icon, and then click **Restart**.

– or –

Press and hold the power button for 5 or more seconds to turn off the Sprout, and then press the power button to turn on the Sprout.

## Sprout shuts down unexpectedly

- The Sprout might be in an exceedingly hot environment. Turn it off and let it cool down.
- Be sure that the Sprout vents are not blocked and that the internal fan is running. See [Getting to know your Sprout on page 1](#) for the location of the computer vents.

## Display problems

### The display is blank

- Exit Sleep to redisplay the screen image.
  - Press the power button briefly.
  - Press a key on the keyboard.
  - Press the space bar.
  - Press the **esc** key.
- Press the power button to turn on the Sprout.

### Images on the screen are too large or too small, or the images are fuzzy

Adjust the resolution settings.

1. From the Start screen, type `control panel`, and then select **Control Panel**.
2. Select **Appearance and Personalization**.
3. Under **Display**, select **Adjust Screen Resolution**.
4. Adjust resolution as necessary, and then click **Apply**.

## Keyboard and mouse problems

- Be sure that you are using the keyboard or mouse within range of the receiver.
- Be sure that the mouse is not in Suspend mode, which occurs after 20 minutes of inactivity. Click the left mouse button to reactivate it.
- Replace the batteries in the keyboard and mouse.
- Re-pair the keyboard and mouse to the receiver.



**NOTE:** The illustrations below may look slightly different from your keyboard and mouse.



**IMPORTANT:** During these steps, place the keyboard and mouse on the same level as the receiver.

To re-pair the keyboard and mouse:

1. Be sure that the mouse is on **(1)**, and then press and hold the Connect button **(2)** for 5 to 10 seconds. To confirm the connection, move the mouse and check for a response on the screen.
2. After the mouse connection is established, complete the following steps to re-pair the keyboard.
3. On the keyboard, press and hold the Connect button **(3)** for 5 to 10 seconds.

## Touch mat problems

**Projection remains when the touch mat is removed.**

1. Restart **HPPCSERVICE**:
  - a. Press **ctrl+alt+delete**.
  - b. Click **Task Manager**, and then click the **Services** tab.
  - c. In the Name column, click **HPPCSERVICE**.
  - d. Right-click **HPPCSERVICE**, and then select **Stop**.
  - e. Right-click **HPPCSERVICE**, and then select **Start**.
2. Click the **Power** icon, and then click **Restart**.

– or –

Press and hold the power button on the Sprout for 5 or more seconds to turn off the Sprout, and then press the power button to turn on the Sprout.

**Projection does not come back when the touch mat is connected again.**

1. If the touch mat workspace icon is amber, touch the icon to enable the projector. When the projector is on, the icon is white.
2. Remove the touch mat, and remove any debris from the touch mat or the connector that would interrupt the connection.

– or –

Clean the touch mat and the connector with a cloth.

3. Click the Power icon, and then click **Restart**. Or,

– or –

Press and hold the power button on the Sprout for 5 or more seconds to turn off the Sprout, and then press the power button to turn on the Sprout.

**The touch mat is not registering touches.**

1. If the touch mat workspace icon is amber, touch the icon to enable the projector. When the projector is on, the icon is white.
2. Remove the touch mat, and remove any debris from the touch mat or the connector that would interrupt the connection.

– or –

Clean the touch mat and the connector with a cloth.

3. Click the Power icon, and then click **Restart**.

– or –

Press and hold the power button for 5 or more seconds to turn off the Sprout, and then press the power button to turn on the Sprout.

4. Remove any metal objects from the touch mat.

## Audio problems

### No sound is produced through external speakers (purchased separately)

- Be sure that you connected powered speakers and that they are turned on.
- Adjust the volume, either on the speakers or through the computer operating system.
- Turn off your Sprout, and then unplug and reconnect the speakers. Be sure that the speakers are properly connected.
- Unplug headphones if they are connected to your Sprout (or speaker system).
- If the Sprout is in the Sleep state, exit Sleep by briefly pressing the power button.
- Check the audio functions.

To check the audio functions on your Sprout, follow these steps:

1. From the Start screen, type `control panel`, and then select **Control Panel**.
2. Select **Hardware and Sound**, and then select **Sound**.
3. When the Sound window opens, click the **Sounds** tab. Under **Program Events**, select any sound event, such as a beep or alarm, and click the **Test** button.

You should hear sound through the speakers or through connected headphones.

To check the recording functions on your Sprout, follow these steps:

1. From the Start screen, type `sound`, and then select **Sound Recorder**.
2. Click **Start Recording** and speak into the microphone. Save the file to your Windows desktop.
3. Open a multimedia program and play back the sound.



---

**NOTE:** To confirm or change the audio settings on your Sprout, from the Start screen, type `control panel`, and then select **Control Panel**. Select **Hardware and Sound**, and then select **Sound**.

---

## Software problems

- Shut down the Sprout, and then turn it on again.
- Update or reinstall the drivers. See [Updating programs and drivers on page 149](#).
- Refresh or restore your Sprout. See [Backing up, restoring, and recovering on page 129](#).



---

## 9 Backing up, restoring, and recovering

This chapter provides information about the following processes. The information in the chapter is standard procedure for most models.

- Creating recovery media and backups
- Restoring and recovering your system

For additional information, refer to HP Support Assistant.

- ▲ From the Start screen, type `support`, and then select the **HP Support Assistant** app.

– or –

From the Windows desktop, click the question mark icon in the notification area, at the far right of the taskbar.

### Creating recovery media and backups

- Use HP Recovery Manager after you successfully set up the computer, to create HP Recovery media. This step creates a backup of the HP Recovery partition on the computer. The backup can be used to reinstall the original operating system in cases where the hard drive is corrupted or has been replaced.

For information on creating recovery media, see [Creating HP Recovery media on page 129](#). For information on the recovery options that are available using the recovery media, see [Recovering using HP Recovery Manager on page 131](#)

- Use Windows tools to create system restore points and create backups of personal information.

### Creating HP Recovery media

HP Recovery Manager is a software program that allows you to create recovery media after you successfully set up the computer. HP Recovery media can be used to perform system recovery if the hard drive becomes corrupted. System recovery reinstalls the original operating system and the software programs installed at the factory and then configures the settings for the programs. HP Recovery media can also be used to customize the system or restore the factory image if you replace the hard drive.

- Only one set of HP Recovery media can be created. Handle these recovery tools carefully, and keep them in a safe place.
- HP Recovery Manager examines the computer and determines the required storage capacity for the blank USB flash drive or the number of blank DVD discs that will be required.
- If you would like to create DVD recovery media, you can use an external optical drive with DVD writer capability (purchased separately) to create recovery discs, and you must use only high-quality blank



DVD-R, DVD+R, DVD-R DL, or DVD+R DL discs. Do not use rewritable discs such as CD±RW, DVD±RW, double-layer DVD±RW, or BD-RE (rewritable Blu-ray) discs; they are not compatible with HP Recovery Manager software. Or, instead, you can use a high-quality blank USB flash drive.

- You can obtain recovery discs for your computer from support. See the *Worldwide Telephone Numbers* booklet included with the computer. You can also find contact information from the HP website. Go to <http://www.hp.com/support>, select your country or region, and follow the on-screen instructions. If you use an external optical drive, it must be connected directly to a USB port on the computer; the drive cannot be connected to a USB port on an external device, such as a USB hub.
- The creation process can take an hour or more. Do not interrupt the creation process.
- If necessary, you can exit the program before you have finished creating all of the recovery DVDs. HP Recovery Manager will finish burning the current DVD. The next time you start HP Recovery Manager, you will be prompted to continue, and the remaining discs will be burned.

To create HP Recovery media:

1. From the Start screen, type `recovery`, and then select **Recovery Media Creation**.
2. Follow the on-screen instructions.

If you ever need to recover the system, see [Recovering using HP Recovery Manager on page 131](#).

## Using Windows tools

You can create system restore points and create backups of personal information using Windows tools. For more information and steps, see Help and Support.

- ▲ From the Start screen, type `help`, and then select **Help and Support**.

– or –

From the Windows desktop, right-click the **Start** button, and then select **Search**. In the search field, type `help`, and then select **Help and Support**.

## Restore and recover

There are several options for recovering your system. Choose the method that best matches your situation and level of expertise:

- Windows offers several options for restoring from backup, refreshing the computer, and resetting the computer to its original state. For more information and steps, see Help and Support.
  - ▲ From the Start screen, type `help`, and then select **Help and Support**.
- or –
  - From the Windows desktop, right-click the **Start** button, and then select **Search**. In the search field, type `help`, and then select **Help and Support**.
- To correct a problem with a preinstalled driver, use the Hardware Driver Reinstallation option of HP Recovery Manager to reinstall the individual driver.
  - ▲ From the Start screen, type `recovery`, select **Recovery Manager**, select **Hardware Driver Reinstallation**, and then follow the on-screen instructions.

- On select models, if you want to recover the computer's original factory partitioning and content, you can choose the System Recovery option from the HP Recovery partition or use the HP Recovery media that you have created. For more information, see [Recovering using HP Recovery Manager on page 131](#). If you have not already created recovery media, see [Creating HP Recovery media on page 129](#).
- On select models, if you have replaced the hard drive, you can use the Factory Reset option of HP Recovery media to restore the factory image to the replacement drive. For more information, see [Recovering using HP Recovery Manager on page 131](#).

## Recovering using HP Recovery Manager

HP Recovery Manager software allows you to recover the computer to its original factory state by using the HP Recovery media that you created or by using the HP Recovery partition. If you have not already created recovery media, see [Creating HP Recovery media on page 129](#).

From the Start screen, type `recovery`, select **Recovery Manager**, select **System Recovery**, and then follow the on-screen instructions.

### What you need to know

- HP Recovery Manager recovers only software that was installed at the factory. For software not provided with the computer, you must either download the software from the manufacturer's website or reinstall the software from the media provided by the manufacturer.



**IMPORTANT:** Recovery through HP Recovery Manager should be used as a final attempt to correct computer issues.

- HP Recovery media must be used if the computer hard drive fails. If you have not already created recovery media, see [Creating HP Recovery media on page 129](#).
- If the HP Recovery media does not work, you can obtain recovery media for your system from support. See the *Worldwide Telephone Numbers* booklet included with the computer. You can also find contact information from the HP website. Go to <http://www.hp.com/support>, select your country or region, and follow the on-screen instructions.



**IMPORTANT:** HP Recovery Manager does not automatically provide backups of your personal data. Before beginning recovery, back up any personal data you want to retain.

### Using the HP Recovery partition

The HP Recovery partition allows you to perform a system recovery without the need for recovery discs or a recovery USB flash drive. This type of recovery can be used only if the hard drive is still working.

To start HP Recovery Manager from the HP Recovery partition:

1. From the Start screen, type `recovery`, select **Recovery Manager**, and then select **HP Recovery Environment**.
2. Select **Troubleshoot** from the boot options menu.
3. Select **Recovery Manager**, and then follow the on-screen instructions.

### Using HP Recovery media to recover

You can use HP Recovery media to recover the original system. This method can be used if your system does not have an HP Recovery partition or if the hard drive is not working properly.

1. If possible, back up all personal files.
2. Insert the HP Recovery media that you created, and then restart the computer.



---

**NOTE:** If the computer does not automatically restart in HP Recovery Manager, change the computer boot order. See [Changing the computer boot order on page 132](#).

---

3. Follow the on-screen instructions.

## Changing the computer boot order

If the computer does not restart in HP Recovery Manager, you can change the computer boot order, which is the order of devices where the computer searches for startup information. You can specify that an optical drive or a USB flash drive should be checked first.

To change the boot order:

1. Insert the HP Recovery media you created.
2. Restart the computer, quickly press **esc**, and then press **f9** for boot options.
3. Select the optical drive or USB flash drive you want to boot from.
4. Follow the on-screen instructions.

---

## 10 POST error messages

This appendix lists the error codes, error messages, and the various indicator light and audible sequences that you may encounter during Power-On Self-Test (POST) or computer restart, the probable source of the problem, and steps you can take to resolve the error condition.

POST Message Disabled suppresses most system messages during POST, such as memory count and non-error text messages. If a POST error occurs, the screen will display the error message. To manually switch to the POST Messages Enabled mode during POST, press any key (except **F10**, **F11**, or **F12**). The default mode is POST Message Disabled.

The speed at which the computer loads the operating system and the extent to which it is tested are determined by the POST mode selection.

Full Boot may also be enabled to run every 1 to 30 days on a regularly scheduled basis. To establish the schedule, reconfigure the computer to the Full Boot Every x Days mode, using Computer Setup.

## POST numeric codes and text messages

This section covers those POST errors that have numeric codes associated with them. The section also includes some text messages that may be encountered during POST.



**NOTE:** The computer will beep once after a POST text message is displayed on the screen.

Control panel message	Description	Recommended action
101-Option ROM Checksum Error	System ROM checksum.	<ol style="list-style-type: none"><li>1. Verify the correct ROM.</li><li>2. Flash the ROM if needed.</li><li>3. Clear CMOS. (See Appendix B, <a href="#">Password security and resetting CMOS on page 143.</a>)</li><li>4. Replace the system board.</li></ol>
103-System Board Failure	DMA or timers.	<ol style="list-style-type: none"><li>1. Clear CMOS. (See Appendix B, <a href="#">Password security and resetting CMOS on page 143.</a>)</li><li>2. Replace the system board.</li></ol>
162-System Options Not Set	Configuration incorrect.  RTC (real-time clock) battery may need to be replaced.	Run Computer Setup and check the configuration in <b>Advanced &gt; Onboard Devices</b> .  Reset the date and time under <b>Control Panel</b> . If the problem persists, replace the RTC battery. See the Removal and Replacement section for instructions on installing a new battery, or contact an authorized dealer or reseller for RTC battery replacement.
163-Time & Date Not Set	Invalid time or date in configuration memory.  RTC (real-time clock) battery may need to be replaced.	Reset the date and time under <b>Control Panel</b> (Computer Setup can also be used). If the problem persists, replace the RTC battery. See the Removal and Replacement section for instructions on installing a new battery, or contact an authorized dealer or reseller for RTC battery replacement.
163-Time & Date Not Set	CMOS jumper may not be properly installed.	Check for proper placement of the CMOS jumper if applicable.
164-MemorySize Error	Memory amount has changed since the last boot (memory added or removed).	Press the <b>F1</b> key to save the memory changes.
164-MemorySize Error	Memory configuration incorrect.	<ol style="list-style-type: none"><li>1. Run Computer Setup or Windows utilities.</li><li>2. Make sure the memory module(s) are installed properly.</li><li>3. If third-party memory has been added, test using HP-only memory.</li><li>4. Verify proper memory module type.</li></ol>

Control panel message	Description	Recommended action
201-Memory Error	RAM failure.	<ol style="list-style-type: none"> <li>1. Ensure memory modules are correctly installed.</li> <li>2. Verify proper memory module type.</li> <li>3. Remove and replace the identified faulty memory module(s).</li> <li>4. If the error persists after replacing memory modules, replace the system board.</li> </ol>
213-Incompatible Memory Module in Memory Socket(s) X, X, ...	A memory module in memory socket identified in the error message is missing critical SPD information, or is incompatible with the chipset.	<ol style="list-style-type: none"> <li>1. Verify proper memory module type.</li> <li>2. Try another memory socket.</li> <li>3. Replace DIMM with a module conforming to the SPD standard.</li> </ol>
214-DIMM Configuration Warning	Populated DIMM Configuration is not optimized.	Rearrange the DIMMs so that each channel has the same amount of memory.
219-ECC Memory Module Detected ECC Modules not supported on this Platform	Recently added memory module(s) support ECC memory error correction.	<ol style="list-style-type: none"> <li>1. If additional memory was recently added, remove it to see if the problem remains.</li> <li>2. Check product documentation for memory support information.</li> </ol>
301-Keyboard Error	Keyboard failure.	<ol style="list-style-type: none"> <li>1. Reconnect keyboard with computer turned off.</li> <li>2. Check connector for bent or missing pins.</li> <li>3. Ensure that none of the keys are depressed.</li> <li>4. Replace keyboard.</li> </ol>
303-Keyboard Controller Error	I/O board keyboard controller.	<ol style="list-style-type: none"> <li>1. Reconnect keyboard with computer turned off.</li> <li>2. Replace the system board.</li> </ol>
304-Keyboard or System Unit Error	Keyboard failure.	<ol style="list-style-type: none"> <li>1. Reconnect the keyboard with computer turned off.</li> <li>2. Ensure that none of the keys are depressed.</li> <li>3. Replace the keyboard.</li> <li>4. Replace the system board.</li> </ol>
510-Flash Screen Image Corrupted	Flash Screen image has errors.	Reflash the system ROM with the latest BIOS image.
511-CPU, CPUA, or CPUB Fan not Detected	Fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> <li>1. Reseat fan.</li> <li>2. Reseat fan cable.</li> <li>3. Replace fan.</li> </ol>

Control panel message	Description	Recommended action
512-Chassis, Rear Chassis, or Front Chassis Fan not Detected	Fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> <li>1. Reseat fan.</li> <li>2. Reseat fan cable.</li> <li>3. Replace fan.</li> </ol>
514-CPU or Chassis Fan not Detected	Fan is not connected or may have malfunctioned.	<ol style="list-style-type: none"> <li>1. Reseat fan.</li> <li>2. Reseat fan cable.</li> <li>3. Replace fan.</li> </ol>
660-Display cache is detected unreliable	Integrated graphics controller display cache is not working properly and will be disabled.	Replace system board if minimal graphics degrading is an issue.
1720-SMART Hard Drive Detects Imminent Failure	Hard drive is about to fail. (Some hard drives have a hard drive firmware patch that will fix an erroneous error message.)	<ol style="list-style-type: none"> <li>1. Determine if hard drive is giving correct error message. Enter Computer Setup and run the Drive Protection System test under <b>Storage &gt; DPS Self-test</b>.</li> <li>2. Apply hard drive firmware patch if applicable. (Available at <a href="http://www.hp.com/support">http://www.hp.com/support</a>.)</li> <li>3. Back up contents and replace hard drive.</li> </ol>
1801-Microcode Patch Error	Processor is not supported by ROM BIOS.	<ol style="list-style-type: none"> <li>1. Upgrade BIOS to proper version.</li> <li>2. Change the processor.</li> </ol>
2200-PMM Allocation Error during MEBx Download	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. Unplug the power cord, reseat the memory modules, and reboot the computer.</li> <li>3. If the memory configuration was recently changed, unplug the computer, restore the original memory configuration, and reboot the computer.</li> <li>4. If the error persists, replace the system board.</li> </ol>
2201-MEBx Module did not checksum correctly	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. Unplug the power cord, re-seat the memory modules, and reboot the computer.</li> <li>3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer.</li> <li>4. If the error persists, replace the system board.</li> </ol>




Control panel message	Description	Recommended action
2202-PMM Deallocation Error during MEBx cleanup	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. Unplug the power cord, re-seat the memory modules, and reboot the computer.</li> <li>3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer.</li> <li>4. If the error persists, replace the system board.</li> </ol>
2203-Setup error during MEBx execution	MEBx selection or exit resulted in a setup failure.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. Unplug the power cord, re-seat the memory modules, and reboot the computer.</li> <li>3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer.</li> <li>4. If the error persists, replace the system board.</li> </ol>
2204-Inventory error during MEBx execution	BIOS information passed to the MEBx resulted in a failure.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2205-Interface error during MEBx execution	MEBx operation experienced a hardware error during communication with ME.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2211-Memory not configured correctly for proper MEBx execution.	XMM1 is not installed.	Make sure there is a memory module in the white XMM1 socket and that it is properly seated.
2212-USB Key Provisioning failure writing to device	USB device used for USB key provisioning will not allow BIOS to update provision file properly.	<ol style="list-style-type: none"> <li>1. Try a different USB key device for provisioning.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2217-ME Firmware Version request failure	ME firmware is not properly responding to BIOS query for version information.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>


Control panel message	Description	Recommended action
2218-ME Firmware Version should be updated	ME firmware must be updated to match current functionality contained in the system BIOS.	<ol style="list-style-type: none"> <li>1. Update to the latest ME firmware version.</li> <li>2. If the error persists and system BIOS has been recently updated, restore previous system BIOS version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2219-USB Key Provisioning file has invalid header identifier	Provisioning file contained on the USB key has been corrupted or is not a valid version for the current ME firmware.	<ol style="list-style-type: none"> <li>1. Recreate the provisioning file using third party management console software.</li> <li>2. If the error persists and system BIOS has been recently updated, restore previous system BIOS version. Otherwise, update the ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2220-USB Key Provisioning file has mismatch version	Provisioning file contained on the USB key is not a valid version for the current ME firmware.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists and system BIOS has been recently updated, restore previous system BIOS version. Otherwise, update the ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2230-General error during MEBx execution	Error occurred during MEBx execution which fails into the "General" grouping. Status information displayed along with the error provides further clarity into the failure. MEBx handles transference of information between the system BIOS and ME firmware.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2231-ME error during MEBx execution	Error occurred during MEBx execution which fails into "ME" grouping.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2232-AMT error during MEBx execution	Error occurred during MEBx execution which fails into "AMT" grouping.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2233-HECI error during MEBx execution	Error occurred during MEBx execution which fails into "MEI or HECI" grouping.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>

Control panel message	Description	Recommended action
2239-ME image lock failure	Special system configurations with reduced ME firmware image require BIOS control of ME firmware upgrading. A failure has occurred after the ME firmware update process in which the BIOS could not relock the ME firmware region.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
2240-ME image unlock failure	Special system configurations with reduced ME firmware image require BIOS control of ME firmware upgrading. A failure has occurred prior to the ME firmware update process in which the BIOS could not unlock the ME firmware region.	<ol style="list-style-type: none"> <li>1. Reboot the computer.</li> <li>2. If the error persists, update to the latest BIOS version and ME firmware version.</li> <li>3. If the error still persists, replace the system board.</li> </ol>
Invalid Electronic Serial Number	Electronic serial number is missing.	Enter the correct serial number in Computer Setup.
Network Server Mode Active and No Keyboard Attached	Keyboard failure while Network Server Mode enabled.	<ol style="list-style-type: none"> <li>1. Reconnect keyboard with computer turned off.</li> <li>2. Check connector for bent or missing pins.</li> <li>3. Ensure that none of the keys are depressed.</li> <li>4. Replace keyboard.</li> </ol>
Parity Check 2	Parity RAM failure.	Run Computer Setup and Diagnostic utilities.

## Interpreting POST diagnostic front panel LEDs

This section covers the front panel LED codes as well as the audible codes that may occur before or during POST that do not necessarily have an error code or text message associated with them.

 **WARNING!** When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet and allow the internal system components to cool before touching.

 **NOTE:** Recommended actions in the following table are listed in the order in which they should be performed.

Not all diagnostic lights and audible codes are available on all models.

Activity	Beeps	Possible Cause	Recommended Action
White Power LED On.	None	Computer on.	None
White Power LED flashes every two seconds.	None	Computer in Suspend to RAM mode (some models only) or normal Suspend mode.	None required. Press any key or move the mouse to wake the computer.
Red Power LED flashes two times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	2	Processor thermal protection activated:  A fan may be blocked or not turning.  OR  The heat sink assembly is not properly attached to the processor.	<ol style="list-style-type: none"><li>1. Ensure that the computer air vents are not blocked and the cooling fan is running.</li><li>2. Check whether the fan spins. If the fan is not spinning, make sure the fan's cable is plugged onto the system board header.</li><li>3. If fan is plugged in, but is not spinning, then replace fan assembly.</li><li>4. Contact an authorized reseller or service provider.</li></ol>
Red Power LED flashes three times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	3	Processor not installed (not an indicator of bad processor).	<ol style="list-style-type: none"><li>1. Check to see that the processor is present.</li><li>2. Reseat the processor.</li></ol>
Red Power LED flashes four times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	4	Power failure (power supply is overloaded).	<ol style="list-style-type: none"><li>1. Ensure the power supply cable is seated into the connector on the system board.</li><li>2. Check if a device is causing the problem by removing ALL attached devices. Power on the system. If the system enters the POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device that is causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly.</li><li>3. Replace the power supply.</li><li>4. Replace the system board.</li></ol>

Activity	Beeps	Possible Cause	Recommended Action
Red Power LED flashes five times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	5	Pre-video memory error.	<p><b>CAUTION:</b> To avoid damage to the SODIMMs or the system board, you must unplug the computer power cord before attempting to reseat, install, or remove a SODIMM module.</p> <ol style="list-style-type: none"> <li>1. Reseat SODIMMs.</li> <li>2. Replace SODIMMs one at a time to isolate the faulty module.</li> <li>3. Replace third-party memory with HP memory.</li> <li>4. Replace the system board.</li> </ol>
Red Power LED flashes six times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	6	Pre-video graphics error.	Replace the system board.
Red Power LED flashes seven times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	7	System board failure (ROM detected failure prior to video).	Replace the system board.
Red Power LED flashes eight times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	8	Invalid ROM based on bad checksum.	<ol style="list-style-type: none"> <li>1. Reflash the system ROM with the latest BIOS image.</li> <li>2. Replace the system board.</li> </ol>
Red Power LED flashes nine times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	9	System powers on but is unable to boot.	<ol style="list-style-type: none"> <li>1. Unplug the AC power cord from the computer, wait 30 seconds, then plug the power cord back in to the computer.</li> <li>2. Replace the system board.</li> <li>3. Replace the processor.</li> </ol>

Activity	Beeps	Possible Cause	Recommended Action
Red Power LED flashes eleven times, once every second, followed by a two second pause. Beeps stop after fifth iteration but LEDs continue until problem is solved.	11	The current processor does not support a feature previously enabled on this system.	<ol style="list-style-type: none"> <li>1. Install a TXT capable processor.</li> <li>2. Disable TXT in the Computer Setup (F10) utility.</li> <li>3. Reinstall the original processor.</li> </ol>
System does not power on and LEDs are not flashing.	None	System unable to power on.	<p>Press and hold the power button for less than 4 seconds. If the hard drive LED turns white, the power button is working correctly. Try the following:</p> <p>▲ Replace the system board.</p> <p>OR</p> <p>Press and hold the power button for less than 4 seconds. If the hard drive LED does not turn on white then:</p> <ol style="list-style-type: none"> <li>1. Check that the unit is plugged into a working AC outlet.</li> <li>2. Check that the power button cable is properly connected to the system board.</li> <li>3. Replace the AC adapter.</li> </ol>

---

# 11 Password security and resetting CMOS


This computer supports security password features, which can be established through the Computer Setup Utilities menu.

This computer supports two security password features that are established through the Computer Setup Utilities menu: setup password and power-on password. When you establish only a setup password, any user can access all the information on the computer except Computer Setup. When you establish only a power-on password, the power-on password is required to access Computer Setup and any other information on the computer. When you establish both passwords, only the setup password will give you access to Computer Setup.

When both passwords are set, the setup password can also be used in place of the power-on password as an override to log in to the computer. This is a useful feature for a network administrator.

If you forget the password for the computer, you can clear that password so you can gain access to the information on the computer by resetting the password jumper.

---

 **CAUTION:** Resetting CMOS will reset CMOS values to factory defaults. It is important to back up the computer CMOS settings before resetting them in case they are needed later. Back up is easily done through Computer Setup. See [Computer Setup \(F10\) Utility on page 107](#) for information.


---


## Resetting the password jumper

To disable the power-on or setup password features, or to clear the power-on or setup passwords, complete the following steps:

1. Shut down the operating system properly, then turn off the computer and any external devices, and disconnect the power cord from the power outlet.
2. With the power cord disconnected, press the power button again to drain the system of any residual power.

---

 **WARNING!** To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet, and allow the internal system components to cool before touching.

 **CAUTION:** When the computer is plugged in, the power supply always has voltage applied to the system board even when the unit is turned off. Failure to disconnect the power cord can result in damage to the system.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. See the *Safety & Regulatory Information* guide for more information.

---

3. Remove the right rear cover and the memory cover.

4. Locate the CMOS+PW header and jumper.



**NOTE:** The password jumper is blue so that it can be easily identified. For assistance locating the password jumper and other system board components, see the system board components image at [System board callouts on page 72](#).

5. Remove the jumper from pins 3 and 5.
6. Place the jumper on pins 1 or 3.
7. Replace the memory cover and rear cover and reconnect the external equipment.
8. Plug in the computer and turn on power. Allow the operating system to start. This clears the current passwords and disables the password features.
9. Shut down the computer, unplug the power, and disconnect the external equipment.
10. Remove the rear cover.
11. Place the jumper back on pins 3 and 5.
12. Replace the rear cover.
13. Reconnect the external equipment and plug in the computer.

## Establishing a setup or power-on password

To establish the power-on or setup password features, complete the following steps:

1. Turn on or restart the computer.
2. As soon as the computer turns on, press the **Esc** key while “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
3. Press the **F10** key to enter Computer Setup.
4. To establish Setup password, select **Security > Setup Password** and follow the instructions.

– or –

To establish a power-on password, select **Security > Power-On Password** and follow the instructions on the screen

5. Before exiting, click **File > Save Changes and Exit**.





# Resetting the setup and power-on password

To disable the power-on or setup password features, or to clear the power-on or setup passwords, complete the following steps:

1. Shut down the operating system properly, then turn off the computer and any external devices, and disconnect the power cord from the power outlet.
2. With the power cord disconnected, press the power button again to drain the system of any residual power.

---

 **WARNING!** To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet, and allow the internal system components to cool before touching.


 **CAUTION:** When the computer is plugged in, the power supply always has voltage applied to the system board even when the unit is turned off. Failure to disconnect the power cord can result in damage to the system.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. See the *Regulatory, Safety and Environmental Notices* guide for more information.

---

3. Remove the right rear cover and the memory cover.
4. Locate the header and jumper labeled CMOS+PW.

---

 **NOTE:** The password jumper is blue so that it can be easily identified. For assistance locating the password jumper and other system board components, see the Illustrated Parts & Service Map (IPSM). The IPSM can be downloaded from <http://www.hp.com/support>.

---

5. Remove the jumper.
6. Replace the jumper on the same pins.
7. Replace the memory cover and rear cover.
8. Reconnect the external equipment.
9. Plug in the computer and turn on power. Allow the operating system to start. This clears the current passwords and disables the password features.
10. Establish the new passwords in Computer Setup. See [Computer Setup \(F10\) Utility on page 107](#) for information.

## Changing a setup or power-on password

To change the power-on or setup password, complete the following steps:

1. Turn on or restart the computer.

To change the setup password, go to step 2.

To change the power-on password, go to step 3.

2. To change the setup password, as soon as the computer turns on:

- Press the Esc key while “Press the ESC key for Startup Menu” message is displayed.

- Press the F10 key to enter Computer Setup.

3. When the key icon appears, type your current password, a slash (/) or alternate delimiter character, your new password, another slash (/) or alternate delimiter character, and your new password again as shown:

*current password/new password/new password*



---

**NOTE:** Type the new password carefully since the characters do not appear on the screen.

---

4. Press **Enter**.

The new password will take effect the next time the computer is restarted.

## Clearing and resetting the CMOS

The computer's configuration memory (CMOS) stores information about the computer's configuration.

The CMOS jumper resets CMOS but does not clear the power-on and setup passwords.

Clearing CMOS will clear the Active Management Technology (AMT) settings in the Management Engine BIOS Extension (MEBx), including the password. The password will default to “admin” and will need to be reset. The AMT settings will also need to be reset. To access the MEBx, press **Ctrl+P** during POST.

1. Turn off the computer and any external devices, and disconnect the power cord from the power outlet.
2. Disconnect the keyboard, monitor, and any other external equipment connected to the computer.



---

**WARNING!** To reduce the risk of personal injury from electrical shock and/or hot surfaces, be sure to disconnect the power cord from the wall outlet, and allow the internal system components to cool before touching.



**CAUTION:** When the computer is plugged in, the power supply always has voltage applied to the system board even when the unit is turned off. Failure to disconnect the power cord can result in damage to the system.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. See the *Safety & Regulatory Information* guide for more information.

---

3. Remove the right rear cover and the memory cover.
4. Locate the CMOS+PW header and jumper.



---

**NOTE:** The password jumper is blue so that it can be easily identified. For assistance locating the password jumper and other system board components, see the system board components image at [System board callouts on page 72](#).

---

5. Remove the jumper from pins 4 and 6.
6. Place the jumper on pins 2 or 4.
7. Replace the memory cover and rear cover and reconnect the external equipment.
8. Plug in the computer and turn on power. Allow the operating system to start. This clears the current passwords and disables the password features.
9. Shut down the computer, unplug the power, and disconnect the external equipment.
10. Remove the rear cover.
11. Place the jumper back on pins 4 and 6.
12. Replace the rear cover.
13. Reconnect the external equipment, plug in the computer and turn on power.



---

**NOTE:** You will receive POST error messages after clearing CMOS and rebooting advising you that configuration changes have occurred. Use Computer Setup to reset any special system setups along with the date and time.

---

For instructions on Computer Setup, see [Computer Setup \(F10\) Utility on page 107](#).



---

# 12 Maintaining peak performance

Keep your Sprout at peak operating performance using the practices and tools described in this chapter. Start with routine maintenance, keep the equipment clean, and regularly update software. Also pay attention to important security issues, including passwords, virus protection, and anti-theft measures. Finally, find out how to access your system settings when you need to contact support or run diagnostics on your Sprout system.

## Performing routine maintenance

### Using Disk Cleanup

Disk Cleanup searches the hard drive for unnecessary files that you can safely delete to free up disk space and help the Sprout run more efficiently.

To run Disk Cleanup:

1. From the Start screen, type `disk`.
2. Select **Free up space on this PC**.
3. Follow the on-screen instructions.

### Using Disk Defragmenter

As you use your Sprout over time, the files on the hard drive become fragmented. Because of this, the hard drive works harder to locate files, and the Sprout slows down. Disk Defragmenter consolidates and reorganizes the fragmented files on the hard drive so that the system can run more efficiently.

Depending on the size of your hard drive and the number of fragmented files, Disk Defragmenter may need more than an hour to complete the task.

To run Disk Defragmenter:

1. From the Start screen, type `disk defrag`.
2. Select **Defragment and optimize your drives**.
3. Follow the on-screen instructions.

### Updating programs and drivers

HP recommends that you update your programs and drivers on a regular basis. Updates can resolve issues and bring new features and options to your Sprout. Without the latest driver, you would not be getting the most out of your equipment.

Go to <http://www.hp.com/support> to download the latest versions of HP programs and drivers. In addition, register to receive automatic notifications when updates become available.

If you would like to update your programs and drivers, follow these instructions:

1. From the Start screen, type `support`, and then select the **HP Support Assistant** app.

– or –

From the Windows desktop, click the question mark icon in the notification area, at the far right of the taskbar.

2. Click **Updates and tune-ups**, and then click **Check for HP updates now**.
3. Follow the on-screen instructions.

## Cleaning your Sprout

Use the following products to safely clean your Sprout:

- Dry microfiber cleaning cloth or a chamois (static-free cloth without oil)
- Static-free cloth wipes

---

**CAUTION:** Avoid strong cleaning solvents that can permanently damage your Sprout. If you are not sure that a cleaning product is safe for your Sprout, check the product contents to make sure that ingredients such as alcohol, acetone, ammonium chloride, methylene chloride, and hydrocarbons are not included in the product.

---

Fibrous materials, such as paper towels, can scratch the Sprout. Over time, dirt particles and cleaning agents can get trapped in the scratches.

## Cleaning procedures

Follow the procedures in this section to safely clean your Sprout.

---

**WARNING!** To prevent electric shock or damage to components, do not attempt to clean your Sprout while it is turned on.

Turn off the Sprout.

Disconnect external power.

Disconnect all powered external devices.

---

**CAUTION:** To prevent damage to internal components, do not spray cleaning agents or liquids directly on any Sprout surface. Liquids dripped on the surface can permanently damage internal components.

---

## Cleaning the display and glass surfaces

---

**CAUTION:** Do not spray or place the cleaner directly on the screen, projector, or other glass surfaces.

---

Gently wipe the sides and the surface of the display, projector, and cameras using a soft, lint-free cloth moistened with an alcohol-free glass cleaner.

### Cleaning the sides or cover

To clean the sides or cover, use a soft microfiber cloth or chamois moistened with one of the cleaning solutions listed previously or use an acceptable disposable wipe.



---

**NOTE:** When cleaning the cover of the Sprout, use a circular motion to aid in removing dirt and debris.

---

### Cleaning the Touch mat



---

**CAUTION:** Do not spray or place the cleaner directly on the touch mat.

---

- Gently wipe the surface of the touch mat using a soft, lint-free cloth moistened with an alcohol-free glass cleaner.
- To prevent damage to the touch mat, avoid using strong chemicals.

### Cleaning the keyboard or mouse



---

**WARNING!** To reduce the risk of electric shock or damage to internal components, do not use a vacuum cleaner attachment to clean the keyboard. A vacuum cleaner can deposit household debris on the keyboard surface.



---

**CAUTION:** To prevent damage to internal components, do not allow liquids to drip between the keys.

---

- To clean the keyboard or mouse, use a soft microfiber cloth or a chamois moistened with one of the cleaning solutions listed previously or use an acceptable disposable wipe.
- To prevent keys from sticking and to remove dust, lint, and particles from the keyboard, use a can of compressed air with a straw extension.





---

# A Power cord set requirements

The power supplies on some computers have external power switches. The voltage select switch feature on the computer permits it to operate from any line voltage between 100-120 or 220-240 volts AC. Power supplies on those computers that do not have external power switches are equipped with internal switches that sense the incoming voltage and automatically switch to the proper voltage.

The power cord set received with the computer meets the requirements for use in the country where you purchased the equipment.

Power cord sets for use in other countries must meet the requirements of the country where you use the computer.


## General requirements

The requirements listed below are applicable to all countries:

1. The power cord must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord set will be installed.
2. The power cord set must have a minimum current capacity of 10A (7A Japan only) and a nominal voltage rating of 125 or 250 volts AC, as required by each country's power system.
3. The diameter of the wire must be a minimum of 0.75 mm<sub>2</sub> or 18AWG, and the length of the cord must be between 1.8 m (6 feet) and 3.6 m (12 feet).

The power cord should be routed so that it is not likely to be walked on or pinched by items placed upon it or against it. Particular attention should be paid to the plug, electrical outlet, and the point where the cord exits from the product.

---


 **WARNING!** Do not operate this product with a damaged power cord set. If the power cord set is damaged in any manner, replace it immediately.

---

## Japanese power cord requirements

For use in Japan, use only the power cord received with this product.

---

 **CAUTION:** Do not use the power cord received with this product on any other products.

---

## Country-specific requirements

Additional requirements specific to a country are shown in parentheses and explained below.

Country	Accrediting Agency	Country	Accrediting Agency
Australia (1)	EANSW	Italy (1)	IMQ
Austria (1)	OVE	Japan (3)	METI
Belgium (1)	CEBC	Norway (1)	NEMKO
Canada (2)	CSA	Sweden (1)	SEMKO
Denmark (1)	DEMKO	Switzerland (1)	SEV
Finland (1)	SETI	United Kingdom (1)	BSI
France (1)	UTE	United States (2)	UL
Germany (1)	VDE		

1. The flexible cord must be Type H05VV-F, 3-conductor, 0.75mm<sub>2</sub> conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country where it will be used.
2. The flexible cord must be Type SVT or equivalent, No. 18 AWG, 3-conductor. The wall plug must be a two-pole grounding type with a NEMA 5-15P (15A, 125V) or NEMA 6-15P (15A, 250V) configuration.
3. Appliance coupler, flexible cord, and wall plug must bear a “T” mark and registration number in accordance with the Japanese Dentori Law. Flexible cord must be Type VCT or VCTF, 3-conductor, 0.75 mm<sub>2</sub> conductor size. Wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7A, 125V) configuration.

---

## B Statement of Volatility

HP confirms that Intel-based business desktop HP Sprout systems contain DDR3 volatile memory (memory amount depends on the customer configuration). In addition, the motherboard in the condition originally shipped without subsequent modification or the addition or installation of any applications, features, or functionality, contains the following nonvolatile memory: Real Time Clock battery backed-up configuration memory (256 Bytes), DIMM Serial Presence Detect (SPD) configuration data (256 Bytes per module, 128 Bytes programmable), Serial Peripheral Interface (SPI) ROM for System BIOS (16M Bytes) and Super I/O's: masked keyboard ROM (overall 2K Bytes).

The following procedure shows the steps that should be taken to restore the Non-Volatile memory found in the Intel-based HP Sprout systems.

1. Download the latest BIOS (system ROM) from the HP website.
2. Follow the instructions to flash the BIOS that are found on the website.  
  
Flashing the BIOS will reset it back to factory settings.
3. Turn on the system, and while system is powering on, and after the HP splash screen, press the **F10** key to enter BIOS setup screen.
4. Select **Security > System Security** from the main menu. If the Embedded Security Device Support option is set to "Disable", skip to step 7.
5. To erase all security keys from the TPM:

Under **Embedded Security Device** in the **System Security** menu, configure **Reset to Factory Settings** to **Reset**.



**NOTE:** Although the TPM security keys will be cleared, data in the non-volatile memory indices may not be. Data stored in these indices should not contain security sensitive information. If an application locks down and secures the non-volatile indices, these indices cannot be cleared.

6. Press **F10** to accept changes.
7. To clear the secure boot key database:
  - a. Enter the F10 setup utility.
  - b. Go to the **Security** menu.
  - c. Select **Secure Boot Configuration**.
  - d. In the **Key Management** section, select **clear Secure boot keys**.
  - e. Use space key to select **clear**.

- f. Press the **F10** key to accept changes.
  - g. From the main menu select **File > Save Changes and Exit**.
8. If the Ownership Tag or Asset Tag is set, manually clear it under **Security > System Ids**.
  9. Select **File > Save Changes and Exit**.
  10. To clear the setup or power-on passwords if set, and clear any other settings, power down the computer and remove the AC power cord and the computer hood.
  11. Locate the CMOS+PW header and jumper.



**NOTE:** The password jumper is blue so that it can be easily identified. For assistance locating the password jumper and other system board components, see the system board components image at [System board callouts on page 72](#).

12. Remove the jumper from pins 4 and 6.
13. Place the jumper on pins 2 or 4.
14. Replace the memory cover and rear cover and reconnect the external equipment.
15. Plug in the computer and turn on power. Allow the operating system to start. This clears the current passwords and disables the password features.
16. Enter the F10 setup utility.
17. Select **File > Default Setup > Restore Factory Settings as Default**. This will set the default settings back to the factory defaults.
18. Select **File > Apply Defaults and Exit**.
19. Shut down the computer, unplug the power, and disconnect the external equipment.
20. Remove the rear cover.
21. Place the jumper back on pins 4 and 6.
22. Replace the rear cover.

If Computrace is enabled on the computer, see the service provider for instruction to disable the feature.

## C Specifications

Dimensions		
Length	30.25 in	76.8 cm
Width	30.13 in	76.5 cm
Depth	16.0 in	40.6 cm
Approximate Weight		
	33.7 lbs	15.3 kg
Display size	23 in diagonal touch screen	58.4 cm diagonal touch screen
Display type	Full HD wide viewing angle, white-LED backlit LCD display	
Aspect ratio	16:9	
Recommended resolution (HxV)	1920 x 1080 pixels	
HP Illuminator	Powered by the HP DLP Projector, HP High-Resolution Camera with up to 14.6 megapixel resolution and the Intel RealSense 3D Camera for instant capture of 2D and 3D objects, along with an LED desk lamp	
HP Touch Mat	20 in diagonal, 20-point touch-enabled touch mat with an ultra-resistant top coating	
Temperature Range		
Operating	41° to 95°F	5° to 35°C
Storage	-22° to 149°F	-30° to 65°C
Relative Humidity (non-condensing)		
Operating	10-80% at 26°C	10-80% at 26°C
Maximum Altitude (unpressurized)		
Operating	0 - 6,561 ft	0 - 2,000 m
Storage	0 - 15,000 ft	4,572 m
Power Supply		
Rated Voltage Range	100-240 V	
Rated Line Frequency	50-60 Hz	
Max Operating Power	350 W	



---

# Index

## A

- ambient light sensor board
  - illustrated 12
  - removing 43
- ambient light sensor, identifying 4
- antennas
  - removing 64
- audible codes 140
- audio (headphone) jack, identifying 8
- audio-out (headphone)/audio-in (microphone) jack 6

## B

- backups 129
- battery
  - disposal 22
- battery replacement 33
- BIOS
  - determining version 116
  - downloading an update 116
  - updating 116
- Bluetooth label 9
- boards, illustrated 12
- boot order
  - changing 132
- booting options
  - Full Boot 133
- bottom 9
- bottom cover (column)
  - illustrated 15
  - removing 83
- bottom rear cover (computer)
  - illustrated 11
  - removing 47
- buttons
  - power 4
  - projector/touch mat 2
  - volume 5

## C

- cable management 23
- cable pinouts, SATA data 22
- caring for your Sprout 150
- cautions
  - AC power 17
  - cables 21
  - cooling fan 20
  - electrostatic discharge 17
- changing a power-on password 146
- changing a Setup password 146
- chassis types, illustrated 17
- cleaning your Sprout 150
- CMOS
  - backing up 143
  - clearing and resetting 146
- column
  - removing 35, 80
- column assembly
  - illustrated 16
- components
  - back 4
  - front 2
  - left side 6
  - rear 7
  - right side 5
- connector, power 7
- converter board
  - illustrated 12
  - removing 51
- country power cord set requirements 154
- covers
  - removing 26

## D

- deleted files, restoring 130
- depth camera light, identifying 3
- depth camera, identifying 3

- desk lamp sensor, identifying 3
- desk lamp, identifying 3
- Disk Cleanup 149
- Disk Defragmenter software 149
- display assembly
  - illustrated 13
  - removing 73
- docking board
  - illustrated 16
  - removing 91
- docking board bracket
  - removing 93
- docking board shield
  - removing 89
- drivers, updating 149

## E

- electrostatic discharge (ESD) 17
  - preventing damage 18
- error
  - codes 133, 140
  - messages 134

## F

- fan
  - illustrated 13
  - removing 63
- flashing LEDs 140

## G

- grounding methods 18

## H

- hard drive
  - proper handling 21
  - removing 28
  - SATA characteristics 22

- hard drive connector
  - illustrated 13
  - removing 66
- hard drive light 5
- HDMI port, identifying 7
- heat sink
  - illustrated 13
  - removing 60
- high-resolution camera light,
  - identifying 3
- high-resolution camera,
  - identifying 3
- home button/light, identifying 2
- HP PC Hardware Diagnostics (UEFI)
  - downloading 120
- HP Recovery Manager
  - correcting boot problems 132
  - starting 131
- HP Recovery media
  - creating 129
  - recovery 131
- HP Recovery partition
  - recovery 131
- HP Touch Mat
  - connecting 8
  - identifying 3

## I

- inside cover
  - illustrated 15
  - removing 87
- installing
  - battery 33
- internal magnet, identifying 5

## J

- jacks
  - audio-out (headphone)/audio-in (microphone) 6

## K

- keyboard button, identifying 2

## L

- labels
  - Bluetooth 9
  - regulatory 9
  - serial number 9
  - wireless certification 9
  - WLAN 9

- left I/O board
  - illustrated 12
- left rear cover
  - illustrated 11
  - removing 26, 78
- lights
  - hard drive 5
  - power supply 7

## M

- main column cover
  - illustrated 15
- maintenance, Disk Defragmenter 149
- memory card reader, identifying 6
- memory card, identifying 6
- memory module
  - removing 30
- microphone module
  - illustrated 12
  - removing 40
- microphones, identifying 8

## N

- numeric error codes 134

## O

- opening the computer 77
- operating guidelines 20
- original system recovery 131
- overheating, prevention 20

## P

- panels
  - removing 78
- password
  - clearing 143
  - power-on 143
  - setup 143
- passwords 146
- POGO board
  - illustrated 16
  - removing 104
- POGO board cover
  - illustrated 15
- ports
  - USB 3.0 5
  - USB 3.0 (powered) charging 5
- POST error messages 133

- power button board
  - illustrated 12
  - removing 45
- power button, identifying 4
- power cable, illustrated 16
- power connector, identifying 7
- power cord set requirements
  - country specific 154
- power supply 157
  - illustrated 16
  - removing 99
- power supply light, identifying 7
- power-on password 143, 146
- processor
  - removing 62
- product name and number,
  - computer 9
- programs, updating 149
- projector mirror, identifying 3
- projector/touch mat button/light,
  - identifying 2

## R

- re-pair, wireless keyboard and
  - mouse 125
- rear covers
  - removing 26, 78
- rear I/O modules
  - illustrated 16
  - removing 102
- recover
  - options 130
- recovery
  - discs 130, 131
  - HP Recovery Manager 131
  - media 131
  - starting 131
  - supported discs 130
  - system 131
  - USB flash drive 131
  - using HP Recovery media 130
- recovery media
  - creating 129
  - creating using HP Recovery Manager 130
- regulatory information
  - regulatory label 9
  - wireless certification labels 9
- removal and replacement procedures
  - All-in One chassis 25



- ambient light sensor board 43
- antennas 64
- bottom cover 83
- column 77
- converter board 51
- display assembly 73
- docking board 91
- docking board bracket 93
- docking board shield 89
- fan 63
- hard drive 28
- hard drive connector 66
- heat sink 60
- inside cover 87
- left I/O board 56
- memory 30
- microphone module 40
- POGO board 104
- power button board 45
- power supply 99
- preparing to disassemble the
  - column 25, 77
- processor 62
- rear I/O modules 102
- right I/O board 54
- side and top cover 84
- speakers 58
- subwoofer 97
- subwoofer mesh cover 95
- system board 68
- system board cover 47
- thermal module 60
- webcam cover 38
- webcam module 41
- wireless USB dongle 32
- WLAN module 49
- removing battery 33
- resetting
  - CMOS 143
  - password jumper 143
- right I/O board
  - illustrated 12
- right rear cover
  - illustrated 11
  - removing 26, 78
- RJ-45 jack, identifying 7

## S

- SATA
  - connectors on system board 22

- data cable pinouts 22
- hard drive characteristics 22
- screws, correct size 21
- security cable slot, identifying 7
- serial number 9
- serial number, computer 9
- service considerations 20
- Setup password 146
- setup password 143
- side and top cover
  - removing 84
- slots
  - memory card reader 6
- software
  - Disk Defragmenter 149
  - servicing computer 21
- speakers
  - identifying 2
  - illustrated 13
  - removing 58
- specifications
  - computer 157
- Sprout Illuminator 3
- static electricity 18
- subwoofer
  - illustrated 16
  - removing 97
- subwoofer mesh cover
  - illustrated 15
  - removing 95
- supported discs, recovery 130
- system board
  - illustrated 12
  - removing 68
- SATA connectors 22
- system board cover
  - removing 47
- system recovery 131
- system restore point
  - creating 130
- system restore point, creating 129

## T

- temperature control 20
- thermal module
  - removing 60
- tools, servicing 21
- top rear cover
  - illustrated 11, 38
- Torx T15 screwdriver 21

- Touch Mat
  - illustrated 16
- troubleshooting 121
  - audio functions 126
  - computer will not turn on 123
  - display is blank 124
  - hard drive error 123
  - images on screen problems 124
  - keyboard 125
  - mouse 125
  - repair the wireless keyboard and mouse 125
  - software problems 127
  - Sprout is not responding 124
  - Sprout shuts down
    - unexpectedly 124
  - touch mat 125
  - wireless connection 121

## U

- USB 3.0 charging (powered) port, identifying 5
- USB 3.0 port, identifying 5
- USB connector and cable
  - illustrated 13
- USB ports, identifying 7

## V

- vent, identifying 7
- ventilation, proper 20
- volume button, identifying 5

## W

- webcam
  - identifying 2
- webcam cover
  - illustrated 11
  - removing 38
- webcam light, identifying 2
- webcam module
  - illustrated 12
  - removing 41
- Windows
  - system restore point 129, 130
- Windows tools
  - using 130
- wireless certification label 9
- wireless USB dongle
  - removing 32
- WLAN device 9
- WLAN label 9

WLAN module	
illustrated	12
removing	49