



# **RPM1581EV6**

**(Remote Power Manager)**

## **User's Manual**

## Table of Contents

1. IMPORTANT SAFETY INSTRUCTIONS .....	2
2. Introduction .....	4
3. RPM Package .....	5
4. Function .....	6
5. Installation .....	7
6. Web Interface .....	8
7. Specifications .....	27
8. Obtaining Service .....	28
9. Limited Product Warranty .....	29

# 1. IMPORTANT SAFETY INSTRUCTIONS

This manual contains important instructions that should be followed during the installation and the operation of the Remote Power Manager (RPM).

## **SAVE THESE INSTRUCTIONS**

### **An Important Notice**

- To ensure safety a **Qualified Service Personnel** should perform the installation.
- Make sure that the AC Utility outlet is properly grounded.
- Do not open the unit there are no user serviceable parts inside. Servicing of RPM should be performed by Qualified Service Personnel Only.
- Please make sure that the input voltage of the RPM matches the supply voltage.
- Make sure the RPM is installed in the proper environment as specified.
- This RPM series is **ONLY** intended to be installed in an indoor temperature controlled environment that is free of conductive contaminants.
- Do not operate the RPM in: extremely dusty and/or unclean areas, locations near heating devices, water or excessive humidity, or where the RPM is exposed to direct sunlight.
- Select a location, which will provide good air circulation for the RPM at all times.
- **CAUTION** – To reduce the risk of fire, connect only to a branch circuit with over current protection in accordance with the National Electric Code.
- **CAUTION** - Connect the RPM to a two pole, three wire grounding AC wall outlet. The receptacle must be connected to the appropriate branch protection (circuit breaker or fuse). Connection to any other type of receptacle may result in a shock hazard and violate local electrical codes. Do not use extension cords, adapter plugs, or surge strips.
- Route power cords so they cannot be walked on or damaged.
- **CAUTION** - To reduce the risk of electrical shock with the installation of this RPM equipment and the connected equipment, the user must ensure that the combined sum of the AC leakage current does not exceed 3.5mA.
- **CAUTION** - To de-energize the outputs of the RPM: Disconnect the RPM from the AC wall outlet.
- **CAUTION** - Do not install this device if there is not at least 30 feet (10 meters) or more of wire between the electrical outlet and the electrical service panel.

## Receiving Inspection

After removing your RPM from its carton, it should be inspected for damage that may have occurred in shipping. Immediately notify the carrier and place of purchase if any damage is found. Warranty claims for damage caused by the carrier will not be honored. The packing materials that your RPM was shipped in are carefully designed to minimize any shipping damage. In the unlikely case that the RPM needs to be returned to MINUTEMAN, please use the original packing material. Since MINUTEMAN is not responsible for shipping damage incurred when the system is returned, the original packing material is inexpensive insurance. **PLEASE SAVE THE PACKING MATERIALS!**

## Para Systems Life Support Policy

As a general policy, Para Systems Inc. (Para Systems) does not recommend the use of any of its products in life support applications where failure or malfunction of the Para Systems product can be reasonably expected to cause failure of the life support device or to significantly affect its safety or effectiveness. Para Systems does not recommend the use of any of its products in direct patient care. Para Systems will not knowingly sell its products for use in such applications unless it receives in writing assurances satisfactory to Para Systems that (a) the risks of injury or damage have been minimized, (b) the customer assumes all such risks, and (c) the liability of Para Systems Inc. is adequately protected under the circumstances.

### **© COPYRIGHT 2015 BY PARA SYSTEMS, INC.**

All Rights Reserved. All rights of this User Manual ("Manual"), including but not limited to the content, information, and figures are solely owned and reserved by Para Systems, Inc. ("Para Systems"). The Manual can only be applied to the operation or the use of this product. Any disposition, duplication, dissemination, reproduction, modification, translation, extraction, or usage of this Manual in whole or in part is prohibited without the prior written permission of Para Systems. Given that Para Systems will continuously improve and develop the product, changes may be made to the information in this Manual at any time without obligation to notify any person of such revision or changes. Para Systems will make all possible efforts to secure the accuracy and the integrity of this Manual. Para Systems disclaims any kinds or forms of warranty, guarantee, or undertaking, either expressly or implicitly, including but not limited to the completeness, faultlessness, accuracy, non-infringement, merchantability or fitness for a particular purpose of the Manual.

## 2. Introduction

The RPM is an Internet ready device designed and equipped with an intelligent current-meter (True RMS) that will indicate the total power consumption of the RPM.

### Features:

- Built-in Web Server to support Remote Power Management
- Local LED displays Amps, IP Address ,Temperature or Humidity
- Daily, Weekly, Monthly & Yearly Power Consumption Data
- 10/100 Base-T Ethernet Port
- IPv4 and IPv6 support
- SNMP support (v1,v2c,v3)
- Telnet, SSHv2 Encryption support
- Radius Authentication
- User Account for three different permissions management systems
- Alarm notification via Email, SNMP, Syslog, LED or audible alarm
- SSL Web Browser (Https) for set up and operation
- IP Address filtering
- Maximum 5000 entries for each power consumption Data and Event log
- Remote firmware upgrade support
- SNMP Heart Beat Trap available
- Reports in Fahrenheit or Celsius
- Export and Import RPM configuration
- True RMS current measurement
- Provides Voltage, Frequency, Power Factor, Active power, Apparent power and kWh information
- Remote outlet On/Off power switching
- Remote outlet current monitoring
- User defined alarm thresholds for Warning and Overload
- User defined power On/OFF sequence timing
- Timed & Scheduled On/Off/Reboot switching
- Alternative outlet restart mode: Memorize previous status, Always On or Always Off
- Ping-No-Answer alarm
- Outlet Action via Pre-set Event, Including Power Event, Environment Event and Receiving Trap from other devices
- Circuit Breaker protection
- Free bundle Management Utility


### 3. RPM Package

The standard RPM package contains a Remote Power Manager unit with supporting hardware. The contents of the package are:


- Remote Power Manager Unit
- Rackmount Brackets
- CD-ROM, which contains:
  - User Manual
  - RPM Utility Manual
  - Warranty Card
  - MIB files
  - RPM Utility Software
  - Adobe Acrobat Reader

## 4. Function

FRONT PANEL



REAR PANEL



Functions	Description
Circuit Breaker	Overload protection.
LED Indicators	<ul style="list-style-type: none"> <li>ON / OFF (green) LEDs: On means the outlet is active. Off means the outlet is not active.</li> <li>Threshold (red) LEDs: On means the current has exceed the threshold setting. Off means the current has not exceed the threshold setting.</li> <li>Warning (red) LED: On means the RPM is Overloaded.</li> <li>SSL (blue) LED: On means the web access is protected by SSL.</li> <li>DHCP (green) LED: On means the RPM gets its IP address by DHCP.</li> </ul>
Meter	3 digits will display the current draw (in amps) or the IP Address or the temperature and humidity.
ID	1-digit will display the identification number of the RPM.
Function Button	<ul style="list-style-type: none"> <li>Press and release the function button to turn off the audible alarm.</li> </ul> <p><b>Note:</b> The overload alarm cannot be silenced.</p> <ul style="list-style-type: none"> <li>Press and hold the function button for 1 beep, then release will display the ID number, the temperature and the humidity for both of the Temperature/Humidity Probes.</li> <li>Press and hold the function button for 2 beeps, then release will display the IP address.</li> <li>Press and hold the function button for 3 beeps, then release will enable the SSL function.</li> <li>Press and hold the function button for 4 beeps, then release will change the way to set the IP address by either DHCP or fixed IP.</li> <li>Press and hold the function button for 6 beeps, then release resets the RPM back to the default setting.</li> </ul>
ENV1 & ENV2	The two RJ11 ports are for the Temperature/Humidity probes.
Audible Alarm	<ul style="list-style-type: none"> <li>Warning- 1 beep per 1 second.</li> <li>Overload- 3 beeps per 1 second.</li> </ul> <p><b>Note:</b> The audible alarm will continue to beep until the current is lower than the threshold by 0.5 amps.</p>
Ethernet	The RJ45 port is for the network communication.
Outlets A ~ H	Each individual outlet can be controlled and monitored.
Power Cord	Connect to utility power

## 5. Installation

This RPM series is **ONLY** intended to be installed in an indoor temperature controlled environment that is free of conductive contaminants. DO NOT operate the RPM in: extremely dusty and/or unclean areas, locations near heating devices, water or excessive humidity, or where the RPM is exposed to direct sunlight. Select a location, which will provide good air circulation for the RPM at all times. Route power cords so they cannot be walked on or damaged.

- To ensure safety a **Qualified Service Personnel** should perform the installation.
- Make sure that the AC Utility outlet is properly grounded.
- Do not install the RPM if there is not at least 30 feet (10 meters) or more of wire between the electrical outlet and the electrical service panel.

The RPM comes with brackets for mounting into a rack. To mount the RPM into a rack perform the following procedure:

1. Attach the mounting brackets to the RPM, using the four retaining screws provided for each of the brackets.
2. Select the desired location for the RPM.
3. Align the mounting holes of brackets with the notched hole on the vertical rail and attach with the retaining screws.
4. Connect the Ethernet cable to the RPM.
5. Connect the output devices to the RPM's outlets.
6. Connect the input power cord of the RPM to the wall outlet.

### **Note 1:**

The default setting for the IP address is DHCP enabled. If the RPM cannot get the IP from DHCP server, the IP address will stay at the **default IP address 192.168.0.216**

### **Note 2:**

To setup the network system for RPM, it is strongly recommended to build up the power monitoring network system, which is isolated from the others, in order to maintain reliable system operation.



## 6. Web Interface

### Login:

Enter the IP address of the RPM in a web browser.

#### Note:

The default setting for the IP address is DHCP enabled. If the RPM cannot get the IP from the DHCP server, the IP address will remain at the **default IP address 192.168.0.216**

The default user Name is **snmp**.

The default Password is **1234**.



Login Name:

Login Password:

## Information: Overview

This section shows the information about the RPM Power, the last five events that have occurred, and the status of the individual outlets. Because different models provide different information, the model you have may not display the same information.

Info. → Logout

**Remote Power Manager**  
MINUTE MAN  
POWER TECHNOLOGIES

**Information** Management Configuration  
**Overview** Power System Event Log Data Log

**Summary**

Total RPM Current	3.04 Amp	Normal
Main Energy	94.918 kWh	
Temperature(1)	86.00 °F	Normal
Humidity(1)	30 %	Normal
Temperature(2)	N/A	
Humidity(2)	N/A	

**Event Log**

Date	Time	Event
2015/06/02	14:04:10	OutletH has been turned on by (snmp)
2015/06/02	14:04:08	OutletG has been turned on by (snmp)
2015/06/02	14:04:07	OutletF has been turned on by (snmp)
2015/06/02	14:04:06	OutletE has been turned on by (snmp)
2015/06/02	14:04:05	OutletD has been turned on by (snmp)

**Outlet Status**

No	Stats	Setting	Name
1	●	E	OutletA
2	●	E	OutletB
3	●		OutletC
4	●		OutletD
5	●		OutletE
6	●		OutletF
7	●		OutletG
8	●		OutletH

**Status:**Normal2015/06/02 14:06:29

### Outlet Status

#### Setting Column:

<b>S</b>	The schedule function is set. The RPM will execute the preset action according to the schedule.
<b>P</b>	The ping function is active. If the specified device stops responding to the ping, the RPM will execute the preset action according to the ping function.
<b>E</b>	The RPM will execute the preset action when the event occurs according to the event action..



## Information: Event Log

This table lists all the events that have occurred. The existing values are overwritten when the maximum number of entries (5000) has been reached. You can filter the log based on specific dates and times. The event logs can be downloaded and saved for future reference.

[Info.](#) [Logout](#)

**Remote Power Manager**  
Information Management Configuration  
Overview Power System **Event Log** Data Log

**Log Setting**  
Event Time : ☒ Last ☐ From  to  All Logs ▾

**Event Log**

Date	Time	Event
2015/03/20	11:00:50	OutletH has been turned on by (snmp)
2015/03/20	11:00:49	OutletG has been turned on by (snmp)
2015/03/20	11:00:48	OutletF has been turned on by (snmp)
2015/03/20	11:00:47	OutletE has been turned on by (snmp)
2015/03/20	11:00:46	OutletD has been turned on by (snmp)
2015/03/20	11:00:45	OutletC has been turned on by (snmp)
2015/03/20	11:00:44	OutletB has been turned on by (snmp)
2015/03/20	11:00:43	OutletA has been turned on by (snmp)
2015/03/20	11:00:33	OutletH has been turned off by (snmp)
2015/03/20	11:00:32	OutletG has been turned off by (snmp)

Filter Clear < >

Status:Normal 2015/03/20 11:28:29

## Information: Data Log

This table lists all of the saved power and environmental data. The existing values are over written when the maximum number of entries (5000) has been reached. You can filter the log based on specific dates and times. The event logs can be downloaded and saved for future reference.

[Info.](#) [Logout](#)

**Remote Power Manager**  
Information Management Configuration  
Overview Power System Event Log **Data Log**

**Statistical Records**

Total energy consumption	43.348kWh
Total carbon emission data	21.674kgs

**Data Log**  
Log Filter  to

Date Time	kWh	V	Amp	Temp.-1.F	Temp.-2.F	Hum.-1.%	Hum.-2.%
2015/03/25 11:37:46	43.320	121.05	3.04	84.2	na	37	na
2015/03/25 11:27:46	43.275	120.77	3.03	84.2	na	39	na
2015/03/25 11:17:46	43.231	119.97	3.02	84.2	na	39	na
2015/03/25 11:07:45	43.187	119.90	3.02	84.2	na	39	na
2015/03/25 10:57:45	43.143	120.07	3.02	82.4	na	39	na
2015/03/25 10:47:45	43.099	120.20	3.02	82.4	na	39	na
2015/03/25 10:37:45	43.055	120.47	3.03	82.4	na	39	na
2015/03/25 10:27:44	43.010	120.43	3.03	82.4	na	39	na

Clear < >

Status:Normal 2015/03/25 11:44:16

## Management: Control

This allows the specified users to control the outlets.

Select the outlet by checking the box and then click the ON or the OFF button to control the outlet.

**ON:** Press the ON button to turn on the assigned outlets.

**OFF:** Press the OFF button to turn off the assigned outlets.

**Restart:** Press the Restart button to reboot (off/on) the assigned outlets.

**Make Group:** Press the Make Group button to set up groups for the outlets.

**Delete:** Delete a group.

**Rename:** Rename a group.

### Note:

After the RPM is plugged into the main power, the RPM will automatically start to sequentially turn on the outlets according to the preset delay time. The default setting for delay time is one second for each outlet; therefore the 8 outlet RPM will take 8-seconds to complete the start-up sequence.

If the RPM is unplugged from the main power before the start-up sequence is completed, the outlets, which were not turned on will remain off. The next time the RPM is plugged into the main power, these outlets will not be automatically turned on. These outlets can only be turned on via the web interface.

[Info.](#) [Logout](#)

**Remote Power Manager**

[Information](#) [Management](#) [Configuration](#)

[Control](#) [Schedule](#) [Ping Action](#) [Event Action](#) [Device](#) [Threshold](#)

**Outlet Control**

**No.** ☐ **Group**  **Outlet**

**Outlet Control**

No.	<input type="checkbox"/>	Outlet	Status	Task	Delay On (Sec)	Delay Off (Sec)	Load (Amp)
1	<input type="checkbox"/>	OutletA	ON	Free	1	1	3
2	<input type="checkbox"/>	OutletB	ON	Free	2	2	0
3	<input type="checkbox"/>	OutletC	OFF	Free	3	3	0
4	<input type="checkbox"/>	OutletD	ON	Free	4	4	0
5	<input type="checkbox"/>	OutletE	ON	Free	5	5	0
6	<input type="checkbox"/>	OutletF	OFF	Free	6	6	0
7	<input type="checkbox"/>	OutletG	ON	Free	7	7	0
8	<input type="checkbox"/>	OutletH	OFF	Free	8	8	0

**Status:**Normal 2015/05/11 15:42:22

**Make Group:** This allows the administrator to assign the outlets to make a group. Click on the Group button. Name the group (36 characters max), select the outlets to include in the group and click Add. Select the check box by the group that you want to control.

Remote Power Manager

Information **Management** Configuration

Control Schedule Ping Action Event Action Device Threshold

Outlet Control

ON OFF Restart Delete Rename

No.	<input type="checkbox"/>	Group	Outlet
01	<input checked="" type="checkbox"/>	Para	OutletA(1) OutletE(5) OutletG(7)

Outlet Control

ON OFF Restart Make Group

No.	<input type="checkbox"/>	Outlet	Status	Task	Delay On (Sec)	Delay Off (Sec)	Load (Amp)
1	<input type="checkbox"/>	OutletA	OFF	Free	1	1	0
2	<input type="checkbox"/>	OutletB	ON	Free	2	2	0
3	<input type="checkbox"/>	OutletC	ON	Free	3	3	0
4	<input type="checkbox"/>	OutletD	ON	Free	4	4	0
5	<input type="checkbox"/>	OutletE	OFF	Free	5	5	0
6	<input type="checkbox"/>	OutletF	ON	Free	6	6	0
7	<input type="checkbox"/>	OutletG	OFF	Free	7	7	0
8	<input type="checkbox"/>	OutletH	ON	Free	8	8	0

Status:Normal 2015/05/11 15:40:22

## Management: Schedule

This allows the administrator to schedule turning OFF/ON the RPM's outlets.

**Outlet:** Assign the outlet to be controlled in this schedule.

**Outlet Action:** Select the action you want to occur.

**Date:** When selecting the Once option a specific date must be entered. When selecting the 'Every' option you can set the schedule for an outlet using an assigned weekly day, or every day.

**Time:** Set the time for the action to occur.

Remote Power Manager

Information **Management** Configuration

Control **Schedule** Ping Action Event Action Device Threshold

Schedule Setting

Outlet : OutletA (1)

Outlet Action : ON

Date : (yyyy/mm/dd)

☒ Once:

☐ Every: Sunday

Time : (hh:mm)

Add Modify

Schedule List

Delete

No.	<input type="checkbox"/>	Outlet	Date	Time	Action
01	<input type="checkbox"/>	OutletA (1)	2015/03/20	12:35	OFF/ON

Status:Normal 2015/03/20 11:45:25

## Management: Ping Action

This allows the administrator to Ping the device that is connected to a specific outlet and if there is no response the RPM will automatically cycle power to a locked device connected to the specified outlet by rebooting the outlet.

**Outlet:** Select which outlet to perform the Outlet Action.

**IP Address:** Set the IP address of the device to be monitored by the RPM.

**Response 5 minutes:** The RPM will ping the assigned IP address once each minute. If the device does not respond, then the RPM will repeat the ping once every minute, if the device does not respond after 5 attempts (5 minutes), the RPM will carry out the assigned action automatically.

**Action:** Select the outlet action "OFF, ON, ON/OFF or "OFF/ON"

**Add:** Enables this function.

To delete a Ping action, select the action from the list and select Delete.

[Info.](#) [Logout](#)

**Remote Power Manager**

Information **Management** Configuration

Control Schedule **Ping Action** Event Action Device Threshold

**Ping Action Setting**

Outlet :

OutletA (1) ▼

IP Address :

Response Time :

5min ▼

Outlet Action :

ON ▼

Add

Modify

**Ping Action List**

Delete

No.		Outlet	IP Address	Response Time	Action
01	<input type="checkbox"/>	OutletA (1)	192.168.2.3	5 min(s)	OFF/ON

Status:Normal

2015/03/20 11:50:01

## Management: Event Action

This allows the administrator to setup specific actions based on a selected event. The RPM can also receive SNMP traps from a specified device and then perform the selected action.

### Event

**Device:** When the current for entire RPM exceeds the Warning or Overload thresholds the RPM will perform the action setup under the Action.

**Outlet:** When the current for an individual outlet exceeds the Warning or Overload thresholds the RPM will perform the action setup under the Action.

**ENV:** When the temperature or humidity exceeds the thresholds the RPM will perform the action setup under the Action.

**Receive Trap:** When the RPM receives a trap from the specified device the RPM will perform the action setup under the Action. Enter the specific trap OID information and the IP address of the device sending the trap to the RPM.

**Action:** The RPM will perform the action based on the configured event.

Once the Event and the Action have been setup click Add to saving the settings.

### Note:

To setup the thresholds for the Device, the Outlets or the ENV, see the Management Threshold section.

The **Event Address List** provides a list of all of the configured events. To delete an event select the box in front of the event then click Delete.

Info. → Logout

**Remote Power Manager**

Information Management Configuration

Control Schedule Ping Action Event Action Device Threshold

**Event Action Setting**

Event :	<input type="radio"/>	Device	Warning threshold	Occurs
	<input type="radio"/>	OutletA	Warning Threshold	Occurs
	<input type="radio"/>	ENV (1)	Temperature Overrun	Occurs
	<input type="radio"/>	Receive Trap .1.3.6.1.4.1. from Value Ignore		
Action :	All Outlet delay second(s) turn ON None			
<input type="button" value="Add"/> <input type="button" value="Modify"/>				

**Event Address List**

No.	<input type="checkbox"/>	Event	Action
01	<input type="checkbox"/>	OutletA over the overload threshold removed	OutletA (1) delay 1 second(s) and turn ON
02	<input type="checkbox"/>	OutletA over the overload threshold occurs	OutletA (1) delay 5 second(s) and turn OFF
03	<input type="checkbox"/>	ENV (1) over the temperature overrun removed	OutletF (6) delay 1 second(s) and turn ON
04	<input type="checkbox"/>	ENV (1) over the temperature overrun occurs	OutletF (6) delay 5 second(s) and turn OFF
05	<input type="checkbox"/>	Receive Trap .1.3.6.1.4.1.2254.2.4.20.0.3 from 192.168.2.16	OutletB (2) delay 1 second(s) and turn ON (Override)
06	<input type="checkbox"/>	Receive Trap .1.3.6.1.4.1.2254.2.4.20.0.4 from 192.168.2.16	OutletB (2) delay 30 second(s) and turn OFF (Override)

Status:Normal2015/06/05 10:26:55



## Management: Device

This allows the administrator to configure the outlet name, the delay time and setup different users for specific outlets.

### Outlet Configuration

**Outlet Name:** Rename the outlet.

**Delay ON:** Set the delay time in seconds for the power on sequence.

**Delay OFF:** Set the delay time in seconds for the power off sequence.

**After Restart:** Set the desired status you want the outlet to be after the outlet has been restarted.

**Owner:** The administrator can setup different users for specific outlets. The user accounts must be setup first, see the Configuration User tab.

Click Apply to save the settings, once the setup is complete.

### Note:

The maximum delay times are 9999 seconds.

### Energy Configuration

**Carbon Emission Rate:** Set the Carbon Emission Rate and then select Apply to saving the setting.

Info. → Logout

**Remote Power Manager**  
MINUTE MAN  
POWER TECHNOLOGIES

Information	Management	Configuration
Control	Schedule	Ping Action
Event Action	Device	Threshold

**Outlet Configuration**

No.	Outlet Name	Delay On(seconds)	Delay Off(seconds)	After Restart	Owner
0	All Outlet			Last Status ▾	snmp ▾
1	OutletA	1	1	ON ▾	man ▾
2	OutletB	2	2	Last Status ▾	snmp ▾
3	OutletC	3	3	OFF ▾	man ▾
4	OutletD	4	4	Last Status ▾	snmp ▾
5	OutletE	5	5	Last Status ▾	man ▾
6	OutletF	6	6	ON ▾	snmp ▾
7	OutletG	7	7	Last Status ▾	man ▾
8	OutletH	8	8	Last Status ▾	snmp ▾

Apply

**Energy Configuration**

Device	Carbon Emission Rate	0.5	Apply
--------	----------------------	-----	-------

Status:Normal

2015/06/02 15:14:57

### Note:

After the RPM is plugged into the main power, the RPM will automatically start to sequentially turn on the outlets according to the preset delay time. The default setting for delay time is one second for each outlet; therefore the 8 outlet RPM will take 8-seconds to complete the start-up sequence.

If the RPM is unplugged from the main power before the start-up sequence is completed, the outlets, which were not turned on will remain off. The next time the RPM is plugged into the main power, these outlets will not be automatically turned on. These outlets can only be turned on via the web interface.

## Management: Threshold

This allows the administrator to configure the thresholds for the environmental probe, the entire RPM and each individual outlet.

**ENV Threshold Configuration:** Set the lower and upper thresholds for the optional environmental probe then click Modify to change the settings. Once these thresholds are set see the management Event Actions to configure the actions based on these thresholds.

**Device Threshold Configuration:** Set the warning and overload thresholds for entire RPM then click Modify to change the settings. Once these thresholds are set see the management Event Actions to configure the actions based on these thresholds.

**Outlet Threshold Configuration:** Set the warning and overload thresholds for each individual outlet then click Modify to change the settings. Once these thresholds are set see the Management Event Actions to configure the actions based on these thresholds.

[Info.](#) [Logout](#)

**Remote Power Manager**

Information   **Management**   Configuration

Control   Schedule   Ping Action   Event Action   Device   **Threshold**

**ENV Threshold Configuration**

No.	Device	Temperature(*F)		Humidity(%)		
		Lower	Upper	Lower	Upper	
01	ENV 1	<input type="text" value="32"/>	<input type="text" value="99"/>	<input type="text" value="3"/>	<input type="text" value="99"/>	<input type="button" value="Modify"/>
02	ENV 2	<input type="text" value="0"/>	<input type="text" value="99"/>	<input type="text" value="0"/>	<input type="text" value="99"/>	<input type="button" value="Modify"/>

**Device Threshold Configuration**

No.	Device	Warning	Overload	
01	Device	<input type="text" value="12"/>	<input type="text" value="15"/>	<input type="button" value="Modify"/>

**Outlet Threshold Configuration**

No.	Outlet Name	Warning	Overload	
01	OutletA	<input type="text" value="12"/>	<input type="text" value="15"/>	<input type="button" value="Modify"/>
02	OutletB	<input type="text" value="2"/>	<input type="text" value="3"/>	<input type="button" value="Modify"/>
03	OutletC	<input type="text" value="12"/>	<input type="text" value="15"/>	<input type="button" value="Modify"/>
04	OutletD	<input type="text" value="12"/>	<input type="text" value="15"/>	<input type="button" value="Modify"/>
05	OutletE	<input type="text" value="1"/>	<input type="text" value="2"/>	<input type="button" value="Modify"/>
06	OutletF	<input type="text" value="12"/>	<input type="text" value="15"/>	<input type="button" value="Modify"/>
07	OutletG	<input type="text" value="12"/>	<input type="text" value="15"/>	<input type="button" value="Modify"/>
08	OutletH	<input type="text" value="5"/>	<input type="text" value="6"/>	<input type="button" value="Modify"/>

**Status:**Normal

2015/06/02 15:20:05

## Configuration: Network

This allows the administrator to configure the network settings.

### TCP/IP Settings for IPv4

**Host Name:** The host name of the RPM.

**DHCP Client:** Enable/Disable DHCP to get the IP address from a DHCP server. The default setting for DHCP is enabled.

**IP Address:** The IP address of the RPM. The default static IP address is 192.168.0.216.

**Subnet Mask:** The subnet mask for your network.

**Gateway IP:** The IP address of the IVP4 network gateway.

**DNS Server1:** The IP address of the primary DNS server.

**DNS Server1:** The IP address of the secondary DNS server.

Once the information has been entered click Apply to save the settings.

### TCP/IP Settings for IPv6

**DHCP Client:** Enable/Disable DHCP to get the IP address from DHCP server. The default setting for the IPv6 DHCP is disabled.

**IP Address:** The IPv6 address of the RPM.

**Default Gateway Address:** The IP address of the IPv6 network gateway.

Once the information has been entered click Apply to save the settings.

Info. → Logout

**Remote Power Manager**

Information

Management

**Configuration**

**Network** Security User Mail SNMP Time Radius Log System

**IPv4 Configuration**

Hostname	rpm
DHCP enable	<input type="radio"/> Active <input checked="" type="radio"/> Inactive
IP Address	192.168.2.23
Subnet Mask	255.255.255.0
Default Gateway Address	192.168.2.1
DNS Server 1	2.2.2.2
DNS Server 2	2.2.2.1
<input type="button" value="Apply"/>	

**IPv6 Configuration**

IPv6 enable	<input type="checkbox"/>
Manual Configuration Address	<input type="text"/> / <input type="text"/>
Default Gateway Address	<input type="text"/>
<input type="button" value="Apply"/>	

Status:Normal

2015/03/20 12:12:53

## Configuration: Security

This allows the administrator to configure the security settings to prevent unauthorized users from accessing the RPM.

### HTTP Configuration

**Server:** Enabling or disabling the HTTP connection with the RPM.

**SSL:** Enable or Disable the SSL function. The user may configure HTTPS protocol to use a port number other than standard HTTPS port (443).

**Redirect HTTP to HTTPS:** Change from the standard HTTP protocol to the HTTPS protocol.

**Port Number:** The user may configure port number for the HTTP port (default: 80) or the port number for the HTTPS port (default: 443).

Once the information has been entered click Apply to save the settings.

### Telnet Configuration

**Server:** Enabling or disabling the Telnet connection with the RPM.

**SSH:** Enabling or disabling the SSH connection with the RPM.

**Port Number:** The user may configure Telnet protocol to use a port number other than standard Telnet port (23).

Once the information has been entered click Apply to save the settings.

**IP Filter:** Use the IP filter to lockout unauthorized users. Once the information has been entered click Add to save the settings.

The screenshot shows the 'Remote Power Manager' web interface. At the top, there are links for 'Info.' and 'Logout'. Below the title bar, a navigation menu includes 'Information', 'Management', and 'Configuration'. Under 'Configuration', there are sub-menus: 'Network', 'Security' (highlighted), 'User', 'Mail', 'SNMP', 'Time', 'Radius', 'Log', and 'System'. The main content area is divided into three sections: 'HTTP Configuration', 'Telnet Configuration', and 'IP Filter'. The 'HTTP Configuration' section has fields for 'Server' (set to 'Enable'), 'SSL' (checkbox), 'Redirect HTTP to HTTPS' (checkbox), and 'Port Number' (set to '80'), with an 'Apply' button. The 'Telnet Configuration' section has fields for 'Server' (set to 'Enable'), 'SSH' (checkbox), and 'Port Number' (set to '23'), with an 'Apply' button. The 'IP Filter' section has a text input field and an 'Add' button. At the bottom, a status bar shows 'Status: Normal' and the timestamp '2014/12/11 08:40:25'.

HTTP Configuration	
Server	Enable
SSL	<input type="checkbox"/>
Redirect HTTP to HTTPS	<input type="checkbox"/>
Port Number	80
<input type="button" value="Apply"/>	

Telnet Configuration	
Server	Enable
SSH	<input type="checkbox"/>
Port Number	23
<input type="button" value="Apply"/>	

IP Filter	
<input type="text"/>	<input type="button" value="Add"/>

Status: Normal 2014/12/11 08:40:25

## Configuration: User

This allows the administrator to add users and give them specific rights.

**No.:** This is the number of users. The maximum number of users is eight.

**User:** This is the user's login name. The default administrator's name is **snmp**.

**Password:** This is the user's login password. The default password for the administrator is **1234**.

### Permission:

**Administrator:** Full authority to monitor, control and configure RPM. Default name is **snmp** and the default password is **1234**.

**Power user:** Monitor the RPM, control the specified outlets. No permission to configure RPM. Default password is password.

**View Only:** Monitor the RPM only. No permission to control or configure the RPM. Default password is password.

**Email:** Enter an email address for the recipient you want to receive the notification.

### To add a new user:

1. Enter the user name and then click New.
2. Enter the password
3. Confirm the password
4. Select the Permission rights
5. Enter the email address if the user is to receive emails
6. Select the pencil icon (Modify) to save the settings.

Select the X icon (Delete) to delete a user.

### Note:

See the Management Device tab to give each user rights to specific outlets.

The screenshot shows the 'Remote Power Manager' web interface. At the top, there are links for 'Info.' and 'Logout'. Below the title bar, there is a navigation menu with tabs: 'Information', 'Management', and 'Configuration'. Under 'Configuration', there are sub-tabs: 'Network', 'Security', 'User' (highlighted), 'Mail', 'SNMP', 'Time', 'Radius', 'Log', and 'System'. The main content area is titled 'Users (Max. 8 users)'. It contains a table with columns: 'No.', 'User', 'New Password', 'Confirm', 'Permission', and 'Email'. There are four rows of users: 01 snmp (Administrator), 02 para (Power User), 03 man (Power User), and 04 gen (View Only). Each row has a pencil icon for modification and a red X icon for deletion. A 'New' button is at the bottom right of the table. At the bottom of the page, there is a status bar showing 'Status: Normal' and the date/time '2015/05/12 15:56:27'.

No.	User	New Password	Confirm	Permission	Email		
01	snmp			Administrator	name@companyname.com		
02	para			Power User ▼	name@companyname.com		
03	man			Power User ▼	name@companyname.com		
04	gen			View Only ▼			
						<input type="button" value="New"/>	

Status: Normal 2015/05/12 15:56:27

## Configuration: Mail

This allows the administrator to setup the email notification. When an event occurs, the RPM can send out email messages to predefined accounts.

**Email Server:** Enter the Hostname or IP address of the SMTP Mail Server that will be used to send emails. If entering a Hostname, you are also required to enter the DNS Address, see the Configuration Network tab.

**Port:** Enter the port number for the SMTP server. The default port is 25.

**TLS/SSL:** Check this box if using secure email.

**Email Server Requires Authorization:** Check this box if the Mail Server requires authentication to send emails.

**Account Name:** Enter the account name if SMTP authentication is required.

**Password:** Enter the password if SMTP authentication is required.

**Test:** Input the recipient's email address.

Click on the Send button to send the test email.

Click Apply to save all of the settings.

The email message format is as follows:  
Indicates the Outlets A ~ H-XXXXXXXX status in order  
When X=0: It means the outlet is off.  
When X=1: It means the outlet is on.

The screenshot shows the 'Remote Power Manager' web interface. At the top right, there are links for 'Info.' and 'Logout'. Below the title bar, a navigation menu includes 'Information', 'Management', and 'Configuration'. Under 'Configuration', there are sub-tabs: 'Network', 'Security', 'User', 'Mail' (which is highlighted), 'SNMP', 'Time', 'Radius', 'Log', and 'System'. The 'Mail Configuration' section contains the following fields and controls:

Email Server	smtp@coname.com	
Port	25	
TLS/SSL	No	
Email Server Requires Authentication	No	
Account Name	name@companyname.com	
Password		
Test	name@companyname.com	<input type="button" value="Send"/>
	<input type="button" value="Apply"/>	

At the bottom of the page, there is a status bar showing 'Status: Normal' on the left and the timestamp '2015/05/12 16:01:31' on the right.

### NOTE:

The email recipient's email address must be entered in the Configuration User tab.

## Configuration: SNMP

The RPM supports the SNMPv1, v2c and v3 traps to satisfy most of the user's environment. This allows the administrator to setup the SNMP Traps. When an event occurs, the RPM can send out SNMP Traps to predefined targets.

Once the SNMP configuration is complete click the Apply button to save the settings.

Info. → Logout

Remote Power Manager

MINUTE-MAN  
PowerViewSystem

Information

Management

Configuration

Network

Security

User

Mail

SNMP

Time

Radius

Log

System

SNMP Configuration

SNMP enable ☒ Active ☐ Inactive

System Name rpm

System Contact admin

System Location office

Apply

Communication Configuration v1 & v2

No.	Access Type	Community
1.	read-only	public
2.	read-write	private
3.	Not Accessible	
4.	Not Accessible	
5.	Not Accessible	
6.	Not Accessible	
7.	Not Accessible	
8.	Not Accessible	

Apply

Communication Configuration v3

No.	Access Type	User	Auth Type	Authentication	Encryption
1.	Not Accessible		noauth	MD5	AES
2.	Not Accessible		noauth	MD5	AES
3.	Not Accessible		noauth	MD5	AES
4.	Not Accessible		noauth	MD5	AES
5.	Not Accessible		noauth	MD5	AES
6.	Not Accessible		noauth	MD5	AES
7.	Not Accessible		noauth	MD5	AES
8.	Not Accessible		noauth	MD5	AES

Apply

Trap Configuration v1 & v2

No.	Enable	IP Address	Community
1.	Yes	192.168.2.3	public
2.	No		
3.	No		
4.	No		

Apply

Trap Configuration v3

No.	Enable	IP Address	User	Auth Type	Authentication	Encryption
1.	Yes	192.168.2.4		auth	MD5	AES
2.	No			noauth	MD5	AES
3.	No			noauth	MD5	AES
4.	No			noauth	MD5	AES

Apply

Status:Normal

2015/03/20 12:26:05


## Configuration: Time

This allows the administrator to setup the system time for the scheduled events.

**Time Configuration:** Set the date and time manually, and then click the Apply button to save the settings.

**SNTP Configuration:** Activate and then setup the Timeserver. Click the Apply button to save the settings.

[Info.](#) [Logout](#)

**Remote Power Manager** 

[Information](#) [Management](#) [Configuration](#)

[Network](#) [Security](#) [User](#) [Mail](#) [SNMP](#) [Time](#) [Radius](#) [Log](#) [System](#)

**Time Configuration**

Set Date

2015 year 03 month 20 day

Set Time

12 : 31 : 20 (hh:mm:ss)

Apply

**SNTP Configuration**

SNTP

☐ Active ☒ Inactive

Primary Timer Server

pool.ntp.org

Secondary Time Server

asia.pool.ntp.org

Time Between Automatic Updates

10 mins

Time Zone (Relative to GMT)

GMT

Apply

**Status:**Normal

2015/03/20 12:31:25



## Configuration: Radius

This allows the administrator to configure the RADIUS parameters. Remote Authentication Dial-In User Service (RADIUS) is a widely deployed protocol enabling centralized authentication, authorization, and accounting for network access.

**RADIUS:** Enable or Disable the RADIUS function.

**Primary Server:** Input the Primary Server's IP address.

**Shared Secret:** Input the Shared Secret of Primary Server.

**Port:** Input the RADIUS UDP port for the primary server.

**Timeout:** Set the packet timeout interval.

**Retries:** Set the number of retries before locking out the user.

**Secondary Server:** Input the Secondary RADIUS Server's IP address.


**Shared Secret:** Input the Shared Secret of Secondary Server.

**Port:** Input the RADIUS UDP port for the secondary server.

**Timeout:** Set the packet timeout interval.

**Retries:** Set the number of retries before locking out the user.

Click on the **Apply** button to save the changes.



The screenshot shows the 'Remote Power Manager' web interface. At the top right, there are links for 'Info.' and 'Logout'. Below the title bar, a navigation menu includes 'Information', 'Management', 'Configuration' (highlighted), and 'System'. Under 'Configuration', there are sub-menus: 'Network', 'Security', 'User', 'Mail', 'SNMP', 'Time', 'Radius' (highlighted), 'Log', and 'System'. The main content area is titled 'Radius Configuration'. It contains a form with the following fields: 'RADIUS' (a dropdown menu set to 'Disable'), 'Primary Server' (text input), 'Shared Secret' (text input), 'Port' (text input), 'Timeout' (text input), 'Retries' (text input), 'Secondary Server' (text input), 'Shared Secret' (text input), 'Port' (text input), 'Timeout' (text input), and 'Retries' (text input). An 'Apply' button is located at the bottom right of the form. At the bottom of the page, a status bar shows 'Status: Normal' and the timestamp '2014/12/11 08:46:12'.

## Configuration: Log

This allows the administrator to setup the log information.

**Export Data Configuration:** Export the log files in csv format.

**Syslog Configuration:** Configure the RPM1581EV6 to send Systems logs.

**Data Log Configuration:** Set the time interval to record the data logs.

**Heartbeat Interval:** Enable or Disable the Heartbeat Trap and set the interval time.

**Event Log Configuration:** Check the events you want to receive notifications for via emails, SNMP traps, or SMS messages.

The screenshot shows the 'Remote Power Manager' web interface. At the top, there's a navigation bar with 'Info.' and 'Logout' links. Below it, a menu bar includes 'Information', 'Management', 'Configuration' (highlighted), 'Network', 'Security', 'User', 'Mail', 'SNMP', 'Time', 'Radius', 'Log' (highlighted), and 'System'. The main content area is divided into several sections:

- Export Data Configuration:** Contains three rows: 'Event Log' with an 'Export' button, 'Data Log' with an 'Export' button, and 'kWh Monthly Report / Send on' with a dropdown set to 'Disable' and a 'Modify' button.
- Syslog Configuration:** Contains three rows: 'Primary Server' with an empty text box, 'Secondary Server' with an empty text box, and 'Port' with an empty text box and an 'Apply' button.
- Data Log Configuration:** Contains one row: 'Data Log Interval' with a dropdown set to 'every 10 min' and an 'Apply' button.
- Heartbeat Trap Configuration:** Contains two rows: 'Heartbeat Interval' with a checked 'Disable' checkbox and an empty text box followed by 'Sec(s)', and an 'Apply' button.
- Event Log Configuration:** A table with two columns: event names and an 'Enable' checkbox column. It is divided into three categories: 'System Events', 'Power Events', and 'ENV Events'. Each category has a header row with the category name and an 'Enable' checkbox. The 'System Events' category has two rows: 'User Log in' and 'System Configuration Change'. The 'Power Events' category has five rows: 'Outlet On', 'Outlet Off', 'Outlet Reboot', 'Outlet Fault', and 'Current out of Warning Threshold'. The 'ENV Events' category has four rows: 'Environmental Temperature Overrun', 'Environmental Temperature Underrun', 'Environmental Humidity Overrun', and 'Environmental Humidity Underrun'. An 'Apply' button is at the bottom right of the table.

At the bottom of the page, there's a status bar showing 'Status: Normal' and the date/time '2014/12/11 08:47:25'.

## Configuration: System

This allows the administrator to configure the system.

**System Configuration:** Configure one RPM and then its configuration file can be saved and then uploaded to another RPM.

**Firmware Upgrade:** The firmware can be upgraded via the web page.

**Reset System:** Reset the system back to the factory default setting.

**Hardware Reset Button Definition:** Configure how the reset button functions.

**Temperature Scale:** Configure how the temperature for the external Temp/Humidity probe will be displayed.

**Auto Logout:** Configure the amount of time before the system will log you off.

The screenshot displays the 'Remote Power Manager' web interface. At the top, there is a navigation bar with tabs for 'Information', 'Management', and 'Configuration'. The 'Configuration' tab is active, and within it, the 'System' sub-tab is selected. The main content area is divided into several sections, each with a title bar and a table of settings:

- System Configuration:** Contains 'Configuration Export' with an 'Export' button, and 'Configuration Import' with a 'Browse...' button, 'No file selected.' text, an 'Upload' button, and an 'Update' button.
- Firmware Upgrade:** Contains 'Firmware Upload' with a 'Browse...' button, 'No file selected.' text, an 'Upload' button, and 'Update' and 'Update and Reset' buttons.
- Reset System:** Contains two radio button options: 'Reset All Setting Back to Factory Default' (selected) and 'Reset All Setting Back to Factory Default Excludes IP Address'. An 'Apply' button is at the bottom.
- Hardware Reset Button Definition:** Contains three radio button options: 'Reset All Setting Back to Factory Default' (selected), 'Reset Administrator's Password to Default Only', and 'Disable (Please note if you forgot password, you can not recovery system any more)'. An 'Apply' button is at the bottom.
- Temperature Scale:** Contains two radio button options: 'Fahrenheit °F' (selected) and 'Celsius °C'. An 'Apply' button is at the bottom.
- Auto Logout:** Contains a dropdown menu set to 'No' and the text 'minutes'. An 'Apply' button is at the bottom.

At the bottom of the page, a status bar shows 'Status: Normal' on the left and the timestamp '2014/12/11 08:49:53' on the right.

## 7. Specifications

Model Number	<b>RPM1581EV6</b>
Load Capacity (Max)	12Amps
<b>INPUT PARAMETERS</b>	
Number of Phases	Single (1Ø2W +G)
Nominal Voltage	100-120VAC
Frequency	50/60Hz
Input Protection	Re-settable circuit breaker
<b>OUTPUT PARAMETERS</b>	
Nominal Voltage	100-120VAC
Frequency	50/60Hz
Branch Circuit Protection	UL 60950-1
Circuit Quantity	One
<b>ENVIRONMENTAL</b>	
Operating Temperature	+32° - +122°F (0° - 50°C)
Storage Temperature	+32° - +149°F (0° - 65°C)
Operating/Storage Humidity	0 - 90%, non-condensing
Operating Elevation	0 to 3,000m (0 to +10,000 ft)
Storage Elevation	0 to 15,000m (0 to +50,000 ft)
<b>PHYSICAL</b>	
Input Power Cord	10-feet attached
Input Plug	NEMA 5-15P
Quantity Output Receptacles	8
Type Output Receptacles	NEMA 5-15/20R
Rack Mounting Format	Horizontal (1U) Vertical (Zero U)
Net Dimension L x W x H (mm)	17.01 x 8.5 x 1.75" (432 x 216 x 44.5)
Net Weight Lbs (Kgs)	7.94 (3.6)
Ship Dimensions L x W x H (mm)	19.29 x 12.99 x 6.1" (490 x 330 x 155)
Ship Weight Lbs (Kgs)	9.26 (4.2)
<b>REGULATORY COMPLIANCE</b>	
Safety/Approvals	cUL, UL 60950-1, CE, RoHS2 (EU Directive 2011/65/EU)

## 8. Obtaining Service

For Technical Support on the Web, please visit the Support section of our Web site or visit our online Discussion Forum.

1. Verify there are no tripped circuit breakers. A tripped circuit breaker is the most common issue.
2. Call your dealer for assistance. If you cannot reach your dealer, or if they cannot resolve the issue call or fax the Technical Support department at the following numbers; Voice phone (972) 446-7363, FAX line (972) 446-9011 or visit our Web site at [www.minutemanups.com](http://www.minutemanups.com) the "Discussion Board". Before calling the Technical Support Department have the following information available:
  - a) Contact name and address.
  - b) Where and when the unit was purchased.
  - c) All of the model information about your unit.
  - d) The serial number of your unit.
  - e) Any information on the failure, including LEDs that may be illuminated or error codes displayed.
  - f) A description of the protected equipment including model numbers, if possible.
  - g) A technician will ask you for the above information and if possible, help solve the issue over the phone. In the event that the unit requires factory service, the technician will issue you a Return Material Authorization Number (RMA #). **NOTE:** We must have the model number and the serial number of the product to issue the RMA #.
  - h) If the unit is under warranty, the repairs will be done at no charge. If the unit is not under warranty there will be a charge for the repair.
3. Pack the unit in its original packaging. If the original packaging is no longer available, ask the Technical Support Technician about obtaining a new set. It is important to pack the unit properly in order to avoid damage in transit. Never use Styrofoam beads for a packing material.
  - a) Include a letter with your name, address, day time phone number, RMA number, a copy of your original sales receipt, and a brief description of the problem.
4. Mark the RMA # on the outside of all packages. The factory cannot accept any package without the RMA # marked on the outside.
5. Return the unit by insured, prepaid carrier to:

Para Systems Inc.  
MINUTEMAN UPS  
1809 W. Frankford Road, Suite 150  
Carrollton, TX 75007  
ATTN: RMA # \_\_\_\_\_

## 9. Limited Product Warranty

Para Systems, Inc. (Para Systems) warrants this equipment, when properly applied and operated within specified conditions, against faulty materials (excluding the batteries) or workmanship for a period of three years from the date of purchase. Para Systems Inc. (Para Systems) warrants the batteries for a period of two years from the date of purchase. For equipment sites within the United States and Canada, this warranty covers depot repair or replacement of defective equipment at the discretion of Para Systems. Depot repair will be from the nearest authorized service center. The customer pays for shipping the product to Para Systems. Para Systems pays ground freight to ship the product back to the customer. Replacement parts and warranty labor will be borne by Para Systems. For equipment located outside of the United States and Canada, Para Systems only covers faulty parts. Para Systems products that are depot repaired or replaced pursuant to this warranty shall only be warranted for the unexpired portion of the warranty applying to the original product. This warranty applies only to the original purchaser who must have properly registered the product within 10 days of purchase.

The warranty shall be void if (a) the equipment is damaged by the customer, is improperly used, is subjected to an adverse operating environment, or is operated outside the limits of its electrical specifications; (b) the equipment is repaired or modified by anyone other than Para Systems or Para Systems approved personnel; or (c) has been used in a manner contrary to the product's User's Manual or other written instructions.

Any technical advice furnished before or after delivery in regard to use or application of Para Systems' equipment is furnished without charge and on the basis that it represents Para Systems' best judgment under the circumstances, but it is used at the recipient's sole risk.

EXCEPT AS PROVIDED HEREIN, PARA SYSTEMS MAKES NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation of implied warranties; therefore, the aforesaid limitation(s) may not apply to the purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL PARA SYSTEMS BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, Para Systems is not liable for any costs, such as; labor for on-site installation, on-site maintenance or on-site service, lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, cost of substitutes, claims by third parties, or otherwise. The sole and exclusive remedy for breach of any warranty, expressed or implied, concerning Para Systems' products and the only obligation of Para Systems hereunder, shall be depot repair or replacement of defective equipment, components, or parts; or, at Para Systems' option, refund of the purchase price or substitution with an equivalent replacement product. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

No employee, salesman, or agent of Para Systems is authorized to add to or vary the terms of this warranty.