



RSC-3ET

Rackmount Storage Chassis User Manual

CONTENTS

PREFACE.....	i
SAFETY INSTRUCTIONS.....	ii
Chapter 1. Prodcut Introduction	1
1.1 Box Content	1
1.2 Specifications	2
1.3 General Information.....	3
Chapter 2. Hardware Installation	6
2.1 Removing and Installing Top Cover	6
2.2 Removing/Installing a Drive Tray	7
2.3 Installing/ Removing a Hard Disk Drive.....	8
2.4 Removing and Installing a PSU Module	10
2.5 Removing and Installing a Fan Module	11
2.6 Removing and Installing HDD Backplane.....	13
2.7 Tool-less Blade Slide Installation Instruction	16
Chapter 3. Hardware Instruction.....	20
3.1 HARDWARE DESIGN SPECIFICATION	20
Chapter 4. HDD Blackplane Instruction.....	27
4.1 Expender firmware update through smart console port.....	27
4.2 Update the expander firmware through in-band.	40
4.3 12G expander EDFB setting	44
4.4 Slot HDD power setting.....	46
4.5 HDD BP thermal sensor temperature setting.....	51
Chapter 5. Technical Support.....	54



Copyright © 2014 AIC, Inc. All Rights Reserved.

This document contains proprietary information about AIC products and is not to be disclosed or used except in accordance with applicable agreements.

PREFACE

- **Copyright**

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photo-static, recording or otherwise, without the prior written consent of the manufacturer.

- **Trademarks**

All products and trade names used in this document are trademarks or registered trademarks of their respective holders.

- **Changes**

The material in this document is for information purposes only and is subject to change without notice.

- **Warning**

1. A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
2. Use only shielded cables to connect I/O devices to this equipment.
3. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

- **Disclaimer**

AIC shall not be liable for technical or editorial errors or omissions contained herein. The information provided is provided "as is" without warranty of any kind. To the extent permitted by law, neither AIC or its affiliates, subcontractors or suppliers will be liable for incidental, special or consequential damages including downtime cost; lost profits; damages relating to the procurement of substitute products or services; or damages for loss of data, or software restoration. The information in this document is subject to change without notice.

SAFETY INSTRUCTIONS

- Before getting started, please read the following important cautions:
- All cautions and warnings on the equipment or in the manuals should be noted.
- Most electronic components are sensitive to electrical static discharge. Therefore, be sure to ground yourself at all times when installing the internal components.
- Use a grounding wrist strap and place all electronic components in static-shielded devices. Grounding wrist straps can be purchased in any electronic supply store.
- Be sure to turn off the power and then disconnect the power cords from your system before performing any installation or servicing. A sudden surge of power could damage sensitive electronic components.
- Do not open the system's top cover. If opening the cover for maintenance is a must, only a trained technician should do so. Integrated circuits on computer boards are sensitive to static electricity. Before handling a board or integrated circuit, touch an unpainted portion of the system unit chassis for a few seconds. This will help to discharge any static electricity on your body.
- Place this equipment on a stable surface when install. A drop or fall could cause injury.
- Please keep this equipment away from humidity.
- Carefully mount the equipment into the rack, in such manner, that it won't be hazardous due to uneven mechanical loading.
- This equipment is to be installed for operation in an environment with maximum ambient temperature below 35°C.
- The openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- Never pour any liquid into ventilation openings. This could cause fire or electrical shock.
- Make sure the voltage of the power source is within the specification on the label when connecting the equipment to the power outlet. The current load and output power of loads shall be within the specification.
- This equipment must be connected to reliable grounding before using. Pay special attention to power supplied other than direct connections, e.g. using of power strips.
- Place the power cord out of the way of foot traffic. Do not place anything over the power cord. The power cord must be rated for the

- product, voltage and current marked on the product's electrical ratings label. The voltage and current rating of the cord should be greater than the voltage and current rating marked on the product.
- If the equipment is not used for a long time, disconnect the equipment from mains to avoid being damaged by transient over-voltage.
- Never open the equipment. For safety reasons, only qualified service personnel should open the equipment.
- If one of the following situations arise, the equipment should be checked by service personnel:
 1. The power cord or plug is damaged.
 2. Liquid has penetrated the equipment.
 3. The equipment has been exposed to moisture.
 4. The equipment does not work well or will not work according to its user manual.
 5. The equipment has been dropped and/or damaged.
 6. The equipment has obvious signs of breakage.
 7. Please disconnect this equipment from the AC outlet before cleaning. Do not use liquid or detergent for cleaning. The use of a moisture sheet or cloth is recommended for cleaning.
- Module and drive bays must not be empty! They must have a dummy cover.

Product features and specifications are subject to change without notice.

CAUTION :

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.


DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

AFTER PERFORMING ANY INSTALLATION OR SERVICING, MAKE SURE THE ENCLOSURE ARE LOCK AND SCREW IN POSITION, TURN ON THE POWER.


Chapter 1. Product Introduction

1.1 Box Content


Before removing the subsystem from the shipping carton, visually inspect the physical condition of the shipping carton. Exterior damage to the shipping carton may indicate that the contents of the carton are damaged. If any damage is found, do not remove the components; contact the dealer where the subsystem was purchased for further instructions. Before continuing, first unpack the subsystem and verify that the contents of the shipping carton are all there and in good condition.




- Enclosure(Power supply, fan, 16 x 3.5" HDD tray included)




- 3.5" HDD Tray



- Power cord



- Screws kit x 1pcs
- (Include console serial cable)



- Slide rail x 1set

◆ PACKAGE CONTENT MAY VARY PER REGION.

1.2 Specifications


Dimensions (mm)	W x D x H: 483 x 645 x 132		
Cooling	Middle : 3 x 8038mm fans		
Power Supply	800W 1+1 redundant PSU PMBUS 1.2. 80+		
Expansion	7 x full height slots		
Buttons	Power on/off and system reset , 2 x USB3.0		
Indicators	Power, LAN , HDD and alert LEDs		
System Board	Up to 12''(W) x 13''(D) E-ATX		
Drive Bay	External	3.5'' hot-swap	16
		2.5'' hot-swap	2(rear side for option)
	Internal	2.5'' HDD	2 or 4(front side for option)
Gross Weight	(w/ PSU & Rail)		32 kgs / 70.4 lbs
Backplane	16 ports HDD BP with 12G expander on board		

1.3 General Information


RSC-3ET is a 3U rackmount chassis with 16x3.5"HDD hot swap Bays at front and single 12G expander on HDD Backplane which is a high performance server storage product.

- Front Panel

Top Plate Optional:
1. 2 x 2.5" internal HDD + Slim CD-R
2. 4 x 2.5" internal HDD




- Rear Panel



- ❶ 2.5" HDD optional
option 1: 2 x 2.5" hot-swap HDD
option 2: 2 x 2.5" internal HDD
- ❷ Hot-swap redundant power supplies
- ❸ 7 PCI slots attribute to expansion and scalability
- ❹ Reserve optional 2 rear fans for optimized cooling
- ❺ Rear access power supply alarm reset

- Major Components



- 1 16 x 3.5" hotswap external HDD trays
- 2 option 1:
4 x internal 2.5" HDD trays or
option 2:
2 x internal 2.5" HDD trays & slim CD-ROM/ DVD-ROM bay
- 3 3 x 8038 mm fans
- 4 2 x internal 2.5" HDD or 2 x hot-swap HDD option
- 5 12"(W) x 13"(D) E-ATX/SSI EEB 3.6 compliant MB

Chapter 2. Hardware Installation

This chapter provides detailed instructions on hardware installation.

2.1 Removing and Installing Top Cover

Push the button on both sides

1



Push the top cover backward.

2



Lift up the top cover from the enclosure.

3



2.2 Removing/Installing a Drive Tray

Release a drive tray by pressing the unlock button.

1



Pull out the HDD tray handle and slide out the HDD tray.


2




2.3 Installing/ Removing a Hard Disk Drive

2.3.1 Installing a Hard Disk Drive

- 1 Directly place HDD into tool-less HDD tray until it snaps. Please check if the screw holes on HDD match the dimples on HDD tray.



- 2 HDD can also be screwed on HDD tray by reserve 2 screw holes at the bottom for optional screw mounting.



- 3 Insert the drive tray into chassis HDD cage. Make sure the drive tray is correctly secured in place when its front edge aligns with the bay edge. Push the tray lever until it reaches the end and clicks.



2.3.2 Removing a Hard Disk Drive

Push up HDD from the bottom.

1



Remove HDD out from HDD tray.

2



2.4 Removing and Installing a PSU Module

2.4.1 Removing a PSU module

- Removing power cable

2.4.2 Installing a PSU Module

- To install PSU module, follow the reverse order.

Loosen the screw



Pushing the latch



Hold the tray handle



Pull the PSU module tray handle out gently to slides out the PSU module.



2.5 Removing and Installing a Fan Module

2.5.1 Removing a fan module


Grabbing and removing the fan module from the fan slot.

1



Pull the fan module up gently and taking out the fan module by removing rubbers out from the fan bar.


2



2.5.2 Installing a Fan Module


Align the fan module and make sure insert 4 screws with the opening in the enclosure.

1



Make sure the 4 rubbers and connector insert firmly while fan module is inserted.

2




2.6 Removing and Installing HDD Backplane

2.6.1 Removing HDD Backplane


Unplugging all connectors & HDDs from HDD backplane.

1



Release the lock pin.

2



Lift up and remove the blackplane to the a little bit up from hook then can get out.



2.6.2 Installing a HDD Backplane


Align the backplane with the hooks, and insert it into the enclosure firmly.

1



Lock the backplane. Follow the reverse order.

2



2.7 Tool-less Blade Slide Installation Instruction


2.7.1 Release and detach the inner rail from the slide.



2.7.2 Attach inner rail to the system.



2.7.3 Attach outer rail to the rack.



① A L I G N

② P U S H

③ L O C K

- 2.7.4 1.CAUTION! Verify ball bearing retainer is locked forward.
 2.Pull out the intermediate rail until locked out.
 3.Slide release tab and push system into rack.




Chapter 3. Hardware Instruction

This chapter provides detailed instruction guide on hardware instruction

3.1 HARDWARE DESIGN SPECIFICATION



3.1.1 Placement

PCBA Placement




3.1.2 Connector Location

Connector Location




3.1.3 Power Connector


Power Connector



Power Connector – JPWR1




Power Connector – JPWR2



Pin	Description	Pin	Description
7	+12V	1	GND
8	+12V	2	GND
9	+3.3V	3	GND
10	+5V	4	MUTE_L
11	+5VSTBY	5	PSU_N1
12	PS_ON_L	6	GND

Pin	Description	Pin	Description
8	+12V	1	GND
9	+12V	2	GND
10	+12V	3	GND
11	+12V	4	GND
12	+5V	5	GND
13	+5V	6	GND
14	+5V	7	GND

3.1.4 Fan Connector




FAN Connector – JFAN1, JFAN2, JFAN3, JFAN4




Pin	Description
1	GND
2	+12V
3	TACH
4	PWM

3.1.5 Console for Expander


Smart Console for Expander



Debug Console for Expander




Console for Expander – JEXP_UART




Pin	Description	Pin	Description
2	DEBUG_RXD	1	SMART_RXD
4	GND	3	GND
6	DEBUG_TXD	5	SMART_TXD

3.1.6 FAN setting (if insert fan on HDD BP)




Jumper Setting - JFRONT



Pin[5,6]	Pin [3,4]	Pin [1,2]	Fan no. support	Active Fan Locate
Close	Close	Close	No fan	
Close	Close	Open	One Fan	JFAN1
Close	Open	Close	Two Fans	JFAN1 and JFAN2
Close	Open	Open	Three Fans	JFAN1,JFAN2 and JFAN3
Open	Open	Close	Four Fans	JFAN1,JFAN2,JFAN3 and JFAN4

3.1.7 Drive Slot Map



HBA card			
0	1	2	3
4	5	6	7
8	9	10	11
12	13	14	15
MegaRaid card			
1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16

Chapter 4. HDD Blackplane Instruction


4.1 Expender firmware update through smart console port

4.1.1 Update Expander firmware revision

Step 1: Set up RSC-3ET console serial cable.

Insert console serial cable into console port shown below also the other side inert serial port into motherboard.

YOU CAN FIND OUT CONSOLE SERIAL CABLE IN THE PACKAGE BOX.



Chapter 4 HDD Blackplane Instruction

Step 2: Set up RSC-3ET RS232 connection


Set up RS232 connection application into your RSC-3ET as shown in the example process below.

For example:


OS: Microsoft Windows

RS232 connection application: Hyperterminal

Step 2: Install HyperTrm.exe




Step 3: Enter a new name for the icon in the field below and click OK.




Step 4: Connecting by using selecting an option in the drop down menu circled in red below (we selected COM2 in this example) and click OK.



Step 5: For "Bits per second", select 38400. For "Flow control", select: None. Click OK when you have finished your selections.




Step 6 : Set up is complete. The diagram below depicts what screen should be displayed.



Step 7: To get **firmware image** & **MFG Configuration Image** version information from "AIC SAS Related Firmware Downloadne" website.


<http://ppms.aicpc.com.tw:8888/download/expander/>



Step 8:

Comand line for show current firmware revision.

cmd>rev



```
cmd >
cmd >rev
=====
Firmware Revision Information:-
=====
Active Firmware:
Revision: 1.12.2.1
Version Name:  LSISAS3xFW-01.12.02.01 11/21/13
Firmware Family: 0  OemFamily: 0
Fast Boot: Yes  Image Address: 0x10300000


cmd >
```


Chapter 4 HDD Blackplane Instruction

Step 9:


Start to update expander firmware

cmd>fdl 0 0_




Step 10:

Select the tool bar "Transfer" -> "Send File".




Step 11:

- Choose new firmware path file "fw 3A1_v1.12.2.1".
- Protocol have to choose "Xmodem".



Step 12:

Firmware download complete




Chapter 4 HDD Blackplane Instruction

Step 13:

Reset computer for success update firmware.

cmd>reset




4.1.2 Update expander configuration MFG

Step 1:

Comand line for show current configuration MFG

cmd> showmfg



```
cmd >showmfg
=====
Manufacturing Image Version Information:-
=====
Mfg Revision:          1.2.0.1
Product Name:          SAS3_E0B
Platform Name:         AIC 12G


cmd >_
```

Chapter 4 HDD Blackplane Instruction

Step 2:


Start to update expander configuration MFG

cmd>fdl 83 0_




Step 3:

Select the tool bar "Transfer" -> "Send File".




Step 4:

- Choose new MFG path file "mfg 3A1.0_eob_1.2.0.1.bin".
- Protocol have to choose "Xmodem".



Step 5:

MFG download complete.




Chapter 4 HDD Blackplane Instruction

Step 6:

Reset computer for success update MFG.

cmd>reset



4.2 Update the expander firmware through in-band.

FOR EXAMPLE

Step 1:

Download and install SG3_utils.exe which compatible with Linux OS.


From website http://sg.danny.cz/sg/sg3_utils.html website

Reference version [sg3_utils-1.40.tgz](#)

Step 2:

To get **firmware image** & **MFG Configuration Image** version information from "AIC SAS Related Firmware Downloadne" website.

<http://ppms.aicpc.com.tw:8888/download/expander/>




Chapter 4 HDD Blackplane Instruction

Step 3:


Execute terminal under the same new firmware folder.

example: Setting a new firmware folder on "Home" page. Open Terminal by click to the right button of mouse in the same window "Home".



Step 4:

Typing "sudo -s" to into administrator mode.



Chapter 4 HDD Blackplane Instruction

Step 5:

Find expander location.


```
$ sg_map -i
```

```
root@ubuntu: ~  
ubuntu@ubuntu:~$ sudo -s  
root@ubuntu:~# sg_map -i  
/dev/sg0 AIC 12G 2U12SAS3E0B 0c02  
/dev/sg1 /dev/sda SRT POLLEX 8G 1100  
/dev/sg2 /dev/sdb SRT POLLEX 8G 1100  
root@ubuntu:~#
```

Step 6:

Update Expander firmware

```
$ sg_write_buffer --id=0x0 --in=fw3A1_v1.12.2.1 --mode=0x2 --offset=0 /  
dev/sg0
```




Chapter 4 HDD Blackplane Instruction

Step 7:

Update Expander MFG


```
$ sg_write_buffer --id=0x83 --in=mfg3A1.0_eob_1.2.0.1.bin --mode=0x2  
--offset=0 /dev/sg0
```



Step 8:

Reboot computer for success update firmware & MFG.

```
root@ubuntu:~# reboot
```



4.3 12G expander EDFB setting

Step 1:

For Install HyperTerminal.exe refer to section 4.1

Step 2 :

Get EDFB status

```
cmd> edfb
```

[illegible]

4.4 Slot HDD power setting

(Only for system cooling Fan controled by expander.)


Step 1:

For Install sg3.exe tool and get new firmware from website refer to section 4.2

Step 2:

Execute terminal under the same new firmware folder.


example: Setting a new firmware folder on "Home" page. Open Terminal by click to the right button of mouse in the same window "Home".



Chapter 4 HDD Blackplane Instruction

Step 3:


Typing "sudo -s" to into administrator mode.



Step 4:

Find expander location.

\$ sg_map -i



Step 5:

For example:

If would like to turn the Disk004 power off under the HBA card. Need to check Disk004 power status.

```
$ sg_ses --page=7 /dev/sg0
```

Under HBA card the Element 3 = Disk004.

```
root@ubuntu: ~  
root@ubuntu:~# sg_ses --page=7 /dev/sg0  
AIC 12G 2U12SAS3E0B 0c02  
Primary enclosure logical identifier (hex): 500605b0000272bf  
Element Descriptor In diagnostic page:  
generation code: 0x0  
element descriptor list (grouped by type):  
Element type: Array device slot, subenclosure id: 0 [ti=0]  
Overall descriptor: ArrayDevicesInSubEnclsr0  
Element 0 descriptor: Disk001  
Element 1 descriptor: Disk002  
Element 2 descriptor: Disk003  
Element 3 descriptor: Disk004  
Element 4 descriptor: Disk005  
Element 5 descriptor: Disk006  
Element 6 descriptor: Disk007  
Element 7 descriptor: Disk008  
Element 8 descriptor: Disk009  
Element 9 descriptor: Disk010  
Element 10 descriptor: Disk011  
Element 11 descriptor: Disk012  
Element type: Temperature sensor, subenclosure id: 0 [ti=1]  
Overall descriptor: TempSensorsInSubEnclsr0  
Element 0 descriptor: TempSense01  
Element 1 descriptor: TempSense02
```

```
root@ubuntu: ~  
Element 5 descriptor: Disk006  
Element 6 descriptor: Disk007  
Element 7 descriptor: Disk008  
Element 8 descriptor: Disk009  
Element 9 descriptor: Disk010  
Element 10 descriptor: Disk011  
Element 11 descriptor: Disk012  
Element type: Temperature sensor, subenclosure id: 0 [ti=1]  
Overall descriptor: TempSensorsInSubEnclsr0  
Element 0 descriptor: TempSense01  
Element 1 descriptor: TempSense02  
Element type: Voltage sensor, subenclosure id: 0 [ti=2]  
Overall descriptor: VoltageSensorsInSubEnclsr0  
Element 0 descriptor: VoltageSense01  
Element 1 descriptor: VoltageSense02  
Element type: Enclosure, subenclosure id: 0 [ti=3]  
Overall descriptor: EnclosureElementInSubEnclsr0  
Element 0 descriptor: EnclosureElement01  
Element type: Power supply, subenclosure id: 0 [ti=4]  
Overall descriptor: PowerSupplyInSubEnclsr0  
Element 0 descriptor: PowerSupply01  
Element 1 descriptor: DiskPowerSupply
```

Step 6:

To check Disk004 (element 3) power status is ok

\$ sg_ses --page=2 /dev/sg0

```
root@ubuntu: ~  
ubuntu@ubuntu:~$ sudo -s  
root@ubuntu:~# sg_map -i  
/dev/sg0 AIC 12G 2U12SAS3E0B 0c02  
/dev/sg1 /dev/sda SRT POLLEX 8G 1100  
root@ubuntu:~# sg_ses --page=2 /dev/sg0
```

Status shows below:

The status of Element 3 is OK.

```
root@ubuntu: ~  
Ready to insert=0, RMV=0, Ident=0, Report=0  
App client bypass B=0, Fault sensed=0, Fault reqstd=0, Device off=0  
Bypassed A=0, Bypassed B=0, Dev bypassed A=0, Dev bypassed B=0  
Element 2 descriptor:  
Predicted failure=0, Disabled=0, Swap=1, status: Not installed  
OK=0, Reserved device=0, Hot spare=0, Cons check=0  
In crit array=0, In failed array=0, Rebuild/remap=0, R/R abort=0  
App client bypass A=0, Do not remove=0, Enc bypass A=0, Enc bypass B=0  
Ready to insert=0, RMV=0, Ident=0, Report=0  
App client bypass B=0, Fault sensed=0, Fault reqstd=0, Device off=0  
Bypassed A=0, Bypassed B=0, Dev bypassed A=0, Dev bypassed B=0  
Element 3 descriptor:  
Predicted failure=0, Disabled=0, Swap=1, status: OK  
OK=1, Reserved device=0, Hot spare=0, Cons check=0  
In crit array=0, In failed array=0, Rebuild/remap=0, R/R abort=0  
App client bypass A=0, Do not remove=0, Enc bypass A=0, Enc bypass B=0  
Ready to insert=0, RMV=0, Ident=0, Report=0  
App client bypass B=0, Fault sensed=0, Fault reqstd=0, Device off=0  
Bypassed A=0, Bypassed B=0, Dev bypassed A=0, Dev bypassed B=0  
Element 4 descriptor:  
Predicted failure=0, Disabled=0, Swap=0, status: Not installed  
OK=0, Reserved device=0, Hot spare=0, Cons check=0  
In crit array=0, In failed array=0, Rebuild/remap=0, R/R abort=0  
App client bypass A=0, Do not remove=0, Enc bypass A=0, Enc bypass B=0
```

Chapter 4 HDD Blackplane Instruction

Step 7:

Turn off a HDD power

\$ sg_ses --descriptor=Disk004 --set=3:4:1 /dev/sg0

```
root@ubuntu: ~  
ubuntu@ubuntu:~$ sudo -s  
root@ubuntu:~# sg_ses --descriptor=Disk004 --set=3:4:1 /dev/sg0  
root@ubuntu:~# sg_ses --descriptor=Disk004 --clear=3:4:1 /dev/sg0  
root@ubuntu:~#
```

Step 8:

Turn on a HDD power

\$ sg_ses --descriptor=Disk004 --clear=3:4:1 /dev/sg0

```
root@ubuntu: ~  
ubuntu@ubuntu:~$ sudo -s  
root@ubuntu:~# sg_ses --descriptor=Disk004 --set=3:4:1 /dev/sg0  
root@ubuntu:~# sg_ses --descriptor=Disk004 --clear=3:4:1 /dev/sg0  
root@ubuntu:~#
```

4.5 HDD BP thermal sensor temperature setting

(Only for system cooling Fan controled by expander.)


Step 1:

For Install HyperTerminal.exe refer to section 4.1

Step 2:

Get the current temperature settings

cmd> temperature



```
cmd >
cmd >temperature

Temperature in Celsius (t1=20 C, t2=50 C, warning=50 C, alarm=55 C)

cmd >
cmd >
cmd >
cmd >
cmd >
cmd >
cmd >
cmd >
cmd >
cmd >
cmd >_
```

Step 3.

For example:

Set new temperature

T1=20 C ▶ 18 C

T2=50 C ▶ 52 C


Warning threshold=50 C ▶ 48 C

Alarm threshold=55 C ▶ 54 C

The new setting will take effect after reset.

```
cmd> temperature 18 52 48 54
```

```
cmd> reset
```




```
cmd >  
cmd >  
cmd >  
cmd >  
cmd >  
cmd >  
cmd >  
cmd >  
cmd >  
cmd >  
cmd >  
  
cmd >temperature 18 52 48 54  
Succeeded to update temperature  
  
cmd >reset_
```

Step 4.

Check fan speed & temperature information.

cmd> sensor



```
cmd >sensor
==ENCLOSURE STATUS==
Total fan number      : 2
System Fan-0 speed    : 10888 RPM
System Fan-1 speed    : 10971 RPM
System PWN-0          : 82%
Expander Temperature  : 76 Celsius degree
Sytem Temperature-0   : 33 Celsius degree
T1                    : 20 Celsius degree
T2                    : 50 Celsius degree
TC                    : 55 Celsius degree
Voltage Sensor 0.9V    : 0.93V
Voltage Sensor 1.8V    : 1.80V

cmd >_
```


Chapter 5. Technical Support



www.aicipc.com

- **TAIWAN**

Tel: +886 3 433 9188

Fax: +886 3 287 1818

Email : sales@aicipc.com.tw

- **CHINA**

Tel: +86.21.54961421, +86.21.54961422

Fax: Extension: 608

Email Technical Support: support@aicipc.com

- **AMERICA - West coast**

Tel: +1.909.895.8989

Fax: +1.909.895.8999

Email : sales@aicipc.com

- **AMERICA - East coast**

Tel: +1.973.884.8886

Fax: +1.973.884.4794

Email : njsales@aicipc.com

- **EUROPE**

Tel: +31.30.6386789

Fax: +31.30.6360638

Email: sales@aicipc.nl

Email Technical Support: support@aicipc.com