

tapo

Quick Start Guide

?

**Visit [www.tapo.com/support](http://www.tapo.com/support)**

for technical support, user guides, warranty,  
and more information



# Welcome to Tapo!

## Installation Guide & Video

Scan QR code or visit

<https://www.tp-link.com/support/faq/4052/>



---

## Contact Us

Our expert Technical Support team is ready to assist you. Please don't hesitate to reach out with any questions.



EMAIL



CHAT



CALL



<https://www.tp-link.com/support/contact-technical-support/>




# Contents

Parts in the Box	1
Installation Preparation	4
Installation	6
Set Up	18
How to set the access code and register your fingerprint?	19
What if the battery is dead while you are outside?	20
Appearance	21

# Parts in the Box



Exterior Assembly




Interior Assembly



Battery Pack

## Install the Bolt & Strike Plate


### Packaged Together




Bolt




Strike Plate



Dust Box




Bolt Screws (ST4\*25)×2



Strike Plate Screws (ST4\*25)×2

## Install Mounting Plate




Mounting  
Plate




Installation  
Reference Line  
Sticker for Interior  
Assembly

Actual Size

**A** (M5\*58)×2



**B** (M5\*68)×2



## Install Exterior Assembly




### Installation Reference Line Sticker for Exterior Assembly

Actual Size

**C**


(M4\*7.5)×3




Actual Size

**D**

(ST4\*20)×1



USB Adapter  
Cable



Measuring  
Template



Keys ×2



Silicone  
Cover




Quick Start  
Guide

# Installation Preparation

# Charge Your Battery

Plug the provided USB cable into the battery pack's Type-C port, then connect it to a power outlet via a USB adapter with 5V output.



## LED Indication:




- **Charging:** Solid amber
- **Fully charged:** Solid green

## Note:

1. Charge the battery before use. This will take a few hours. It is recommended to use a **5V/2A** adapter for best charging performance.
2. The USB adapter is not provided.


# Check Door Lock Compatibility

Place the measuring template on the door, aligning the door edge line with the door edge. Use the dimensions on the template to measure your door.




# Installation

# Installation Overview





# 1 Remove your existing lock.

Remove your existing door lock.




## 2 Install the bolt.

- A** Ensure the word **TOP** is facing up.




- B** If the latch hub is not centered in the door hole, twist the bolt to extend it.




**Actual Size**

Packaged together  
with the bolt




### 3 Install the exterior assembly.


- A** If the door hole is 2-1/8" (54 mm), keep the spacer. If it's 1-1/2" (38 mm), remove the spacer first.




For 2-1/8" (54 mm) door hole




For 1-1/2" (38 mm) door hole




[OUTSIDE]




- B** Place the exterior assembly sticker on the outside door by aligning its door edge line with your door edge. Ensure you use the correct door edge line based on your backset distance.




**C** Cable goes under the bolt.




[OUTSIDE]



**D** Align the tailpiece with the center hole of the bolt, and insert it into the center hole.




## 4 Install the mounting plate.




- A** Place the interior assembly sticker on the inside door by aligning its door edge line with your door edge. Ensure you use the correct door edge line based on your backset distance.



- B** Route the cable through the mounting plate hole.



Do **NOT** use an electric drill to secure the screws.



- C** Align the mounting plate with sticker and secure it using **two** screws.

For door thickness of 1-3/8" to 1-49/64" (35-45 mm): choose screw A

For door thickness of 1-49/64" to 2-11/64" (45-55 mm): choose screw B

Actual Size


**A**

M5\*58


**OR**

**B**

M5\*68




## 5 Install the interior assembly.




- A** Remove the battery cover.




- B** Connect the cable tightly.  
Ensure the color side faces up.





- C** Tuck the excess cable into the groove.






- D** Align the tailpiece with the key cylinder. Attach the interior assembly to the mounting plate.



- E** Rotate the thumb latch to ensure the latch retracts normally.


Do NOT use an electric drill to secure the screws.



- F** Use the **three** provided M4\*7.5 screws to affix the interior assembly.

Actual Size

**C**



- G** (Optional) Use the provided ST4×20 screw to secure the interior assembly.

Actual Size


**D**




This screw will firmly secure the interior assembly and mounting plate to the inside door.

## 6 Install the battery.

- A** Insert the battery into the interior assembly with correct direction.





- B** Replace the cover by sliding it down.



- C** Insert the silicone cover into the bottom hole. Remove the stickers.

## 7 Install the strike plate.

Insert the dust box and strike plate into the strike hole on the door frame. Ensure the depth of the strike hole is at least 1" (25.4 mm).



If the bolt operates smoothly without pushing or pulling the door, you can use your original strike plate.

If you need to push or pull the door for smooth operation, adjust the strike plate's position on the door frame.


**Set Up**

# Set Up Your Lock

1. Get the **Tapo** app from the App Store or Google Play and log in with your TP-Link ID. If you do not have an account, create one first.




2. Tap the **+** button in the app. Select **Door Locks** and then your model. Follow the app instructions to complete setup.



The Tapo app is needed to use this lock. If this lock was professionally installed (or installed by someone other than the homeowner), make sure this step was performed by the homeowner.

# How to set the access code and register your fingerprint?

The access code (PIN code) and fingerprint should be set in the Tapo app. Tapo will guide you to set your access code and register your fingerprint.



# What if the battery is dead while you are outside?


- **Unlock via the provided key**

Gently pull out the doorbell cover to expose the cylinder. Unlock the door with the provided key.



- **Temporarily charge the lock**



Connect the lock to a power outlet or power bank using a USB cable. This will provide a temporary power supply and will not charge the battery. Note that this port is for power only and cannot transfer data.



# Appearance

# Appearance

## Exterior Assembly



### **1** Fingerprint Scanner

Lock/unlock with your fingerprint.

### **2** Status LED

Indicates the status of your device.

### **3** Key Pad

Lock/unlock the door by entering your PIN code.

### **4** Unlocking/Locking Button

- When you enter your PIN code starting with scramble digits, press this button to confirm unlocking.
- Press this button independently to lock the door.

### **5** Backspace

Press to delete the digit you entered.

### **6** Lock Cylinder

Used to unlock via the provided keys.


### **7** Ring Button

Press to ring the built-in doorbell.

### **8** Type-C Port

Connect to a power outlet to provide a temporary power supply.

## Interior Assembly



### **1** Wi-Fi On/Off Button

Turn on Wi-Fi and connect your device to a Wi-Fi network for remote control.

Turn off Wi-Fi and only control your device locally via Bluetooth.

### **2** Thumb Latch

Rotate to lock/unlock the door.

### **3** Battery Compartment

Insert the provided battery to power your lock.

### **4** Reset

- Press and hold for 5 seconds to reset Wi-Fi settings.
- Press and hold for 10 seconds to reset to factory default settings.

## Status LED Indications

Blinking red and green	Ready for setup
Pulsing green	Connecting to Wi-Fi
Blinking amber	Low battery
Blinking green	Lock updating
Solid red, then turn off after 3 seconds	Updating failed
Blinking red three times	Door jammed

## Specifications

Type-C Emergency Power Supply: 5V 

Battery Power: 3.6V 

Rainproof Rating: IP65 (only for the exterior assembly)

# Safety Information

- Do not use damaged charger or USB cable to charge the device.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed.
- Do not use any other chargers than those recommended.
- Keep the device away from water, fire, humidity or hot environments.
- Do not place near automatically controlled devices such as fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.
- Observe restrictions on using wireless products in fuel depots, chemical plants or when blasting operations are in progress.
- Never put metal objects inside the product. If a metal object enters the product turn off the circuit breaker and contact an authorised electrician.
- This product is not intended to be used when providing medical care. Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids to determine if they are adequately shielded from external RF (radio frequency) energy.
- Do not use this product in health care facilities. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.
- When you leave the product unused for a long time unplug the product from the power outlet.
- This product may interfere with other electronic products such as TV, radios, personal computers, phones or other wireless devices.

Interior Assembly Operating Temperature: -10 °C ~ 55°C (14°F ~ 131°F)

Exterior Assembly Operating Temperature: -30 °C ~ 70°C (-22°F ~ 158°F)

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

## CAUTION!

Risk of fire or explosion if the battery is replaced by an incorrect type

## CAUTION!

Avoid replacement of a battery with an incorrect type that can defeat a safeguard. Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion. Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas. Do not leave a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

\*Images may differ from your actual product.