



Cisco Catalyst 9400 Series Supervisor Module Installation Note

Cisco Catalyst 9400 Series Supervisor Module Installation Note	2
Safety Warnings	3
Statement 1071—Warning Definition	5
Cisco Catalyst 9400 Series Supervisor 1 Module Features	7
Cisco Catalyst 9400 Series Supervisor 1XL Module Features	9
Cisco Catalyst 9400 Series Supervisor 1XL-Y 25G Module Features	11
Cisco Catalyst 9400 Series Supervisor 2 Module Features	13
Cisco Catalyst 9400 Series Supervisor 2XL Module Features	15
Cisco Catalyst 9400 Series Supervisor Module LEDs	17
Example: Cisco Catalyst 9400 Series Supervisor 1 Module LEDs	20
Removal and Replacement Procedures	21
Module Interfaces	31
Installing Transceiver Modules and Cables	37
Related Documentation	38
Notices	40

Revised: December 14, 2022

Cisco Catalyst 9400 Series Supervisor Module Installation Note

This document describes the Cisco Catalyst 9400 Series Supervisor Module features and provides information about how to correctly remove or replace the module in the chassis.

Table 1: Product Numbers:

C9400-SUP-1 , C9400-SUP-1= (Spare), C9400-SUP-1/2 (Redundant Supervisor 1 Module)
C9400-SUP-1XL , C9400-SUP-1XL= (Spare), C9400-SUP-1XL/2 (Redundant Supervisor 1XL Module)
C9400-SUP-1XL-Y , C9400-SUP-1XL-Y= (Spare), C9400-SUP-1XL-Y/2 (Redundant Supervisor 1XL25 Module)
C9400X-SUP-2 , C9400X-SUP-2= (Spare), C9400X-SUP-2/2 (Redundant Supervisor 2 Module)
C9400X-SUP-2XL , C9400X-SUP-2XL= (Spare), C9400X-SUP-2XL/2 (Redundant Supervisor 2XL Module)

Table 2: Overview of Compatibility Information for All Available Supervisor Modules

PID	Minimum required software version ¹	Chassis compatibility and chassis slot restrictions	Backplane bandwidth for each payload module slot	Memory
C9400-SUP-1	Cisco IOS XE Everest 16.6.1 For redundant supervisor support, Cisco IOS XE Everest 16.6.2.	Catalyst 9404R Switch: Slots 2 and 3 only. Catalyst 9407R Switch: Slots 3 and 4 only. Catalyst 9410R Switch: Slots 5 and 6 only.	Catalyst 9404R, Catalyst 9407R, and Catalyst 9410R Switch: 80 Gbps	Synchronous Dynamic Random-Access Memory— 16GB of Double Data Rate Fourth-Generation (DDR4)
C9400-SUP-1XL	Cisco IOS XE Everest 16.6.2	Redundant supervisor modules are supported on all chassis. The primary supervisor module can be installed in either slot.	Catalyst 9404R: 240 Gbps Catalyst 9407R: 120 Gbps Catalyst 9410R: 80 Gbps	
C9400-SUP-1XL-Y	Cisco IOS XE Fuji 16.9.1		Catalyst 9404R: 240 Gbps Catalyst 9407R: 120 Gbps Catalyst 9410R: 80 Gbps	
C9400X-SUP-2	Cisco IOS XE Cupertino 17.7.1		Catalyst 9404R, Catalyst 9407R, and Catalyst 9410R Switch: 240 Gbps	
C9400X-SUP-2XL	Cisco IOS XE Cupertino 17.7.1	Catalyst 9404R, Catalyst 9407R, and Catalyst 9410R Switch: 480 Gbps		

¹ Refer to the [Release Notes for the Cisco Catalyst 9400 Series Switches](#) for the latest software release requirements

Safety Warnings

Safety warnings appear throughout this publication in procedures that may harm you if you perform them incorrectly. A warning symbol precedes each warning statement. The warnings below are general warnings that are applicable to the entire publication.



Warning

Power Cable and AC Adapter - When installing the product, please use the provided or designated connection cables/power cables/AC adaptors. Using any other cables/adaptors could cause a malfunction or a fire. Electrical Appliance and Material Safety Law prohibits the use of UL-certified cables (that have the "UL or CSA" shown on the code) for any other electrical devices than products designated by CISCO. The use of cables that are certified by Electrical Appliance and Material Safety Law (that have "PSE" shown on the code) is not limited to CISCO-designated products. **Statement 371**



Warning Read the installation instructions before using, installing or connecting the system to the power source. **Statement 1004**



Warning Class 1 laser product. **Statement 1008**



Warning This unit is intended for installation in restricted access areas. A restricted access area can be accessed only through the use of a special tool, lock and key, or other means of security. **Statement 1017**



Warning Only trained and qualified personnel should be allowed to install, replace, or service this equipment. **Statement 1030**



Warning Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing. **Statement 1034**



Warning Ultimate disposal of this product should be handled according to all national laws and regulations. **Statement 1040**



Warning Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. **Statement 1051**



Warning Class 1M laser radiation when open. Do not view directly with optical instruments. **Statement 1053**



Warning Class I (CDRH) and Class 1M (IEC) laser products. **Statement 1055**

**Warning**

Invisible laser radiation may be emitted from the end of the unterminated fiber cable or connector. Do not view directly with optical instruments. Viewing the laser output with certain optical instruments (for example, eye loupes, magnifiers, and microscopes) within a distance of 100 mm may pose an eye hazard. **Statement 1056**

Fiber type and Core diameter (µm)	Wavelength (nm)	Max. Power (mW)	Beam divergence (rad)
SM 11	1200 - 1400	39 - 50	0.1 - 0.11
MM 62.5	1200 - 1400	150	0.18 NA
MM 50	1200 - 1400	135	0.17 NA
SM 11	1400 - 1600	112 - 145	0.11 - 0.13

349377

**Warning****IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. Statement 1071

SAVE THESE INSTRUCTIONS

Statement 1071—Warning Definition

	<p>IMPORTANT SAFETY INSTRUCTIONS</p> <p>This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. Statement 1071</p> <p>SAVE THESE INSTRUCTIONS</p>
Waarschuwing	<p>BELANGRIJKE VEILIGHEIDSINSTRUCTIES</p> <p>Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van de standaard praktijken om ongelukken te voorkomen. Gebruik het nummer van de verklaring onderaan de waarschuwing als u een vertaling van de waarschuwing die bij het apparaat wordt geleverd, wilt raadplegen.</p> <p>BEWAAR DEZE INSTRUCTIES</p>


Varoitus	<p>TÄRKEITÄ TURVALLISUUSOHJEITA</p> <p>Tämä varoitusmerkki merkitsee vaaraa. Tilanne voi aiheuttaa ruumiillisia vammoja. Ennen kuin käsittelet laitteistoa, huomioi sähköpiirien käsittelemiseen liittyvät riskit ja tutustu onnettomuuksien yleisiin ehkäisytapoihin. Turvallisuusvaroitusten käännökset löytyvät laitteen mukana toimitettujen käännettyjen turvallisuusvaroitusten joukosta varoitusten lopussa näkyvien lausuntonumeroiden avulla.</p> <p>SÄILYTÄ NÄMÄ OHJEET</p>
Attention	<p>IMPORTANTES INFORMATIONS DE SÉCURITÉ</p> <p>Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant entraîner des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers liés aux circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents. Pour prendre connaissance des traductions des avertissements figurant dans les consignes de sécurité traduites qui accompagnent cet appareil, référez-vous au numéro de l'instruction situé à la fin de chaque avertissement.</p> <p>CONSERVEZ CES INFORMATIONS</p>
Warnung	<p>WICHTIGE SICHERHEITSHINWEISE</p> <p>Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu Verletzungen führen kann. Machen Sie sich vor der Arbeit mit Geräten mit den Gefahren elektrischer Schaltungen und den üblichen Verfahren zur Vorbeugung vor Unfällen vertraut. Suchen Sie mit der am Ende jeder Warnung angegebenen Anweisungsnummer nach der jeweiligen Übersetzung in den übersetzten Sicherheitshinweisen, die zusammen mit diesem Gerät ausgeliefert wurden.</p> <p>BEWAHREN SIE DIESE HINWEISE GUT AUF.</p>
Avvertenza	<p>IMPORTANTI ISTRUZIONI SULLA SICUREZZA</p> <p>Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe causare infortuni alle persone. Prima di intervenire su qualsiasi apparecchiatura, occorre essere al corrente dei pericoli relativi ai circuiti elettrici e conoscere le procedure standard per la prevenzione di incidenti. Utilizzare il numero di istruzione presente alla fine di ciascuna avvertenza per individuare le traduzioni delle avvertenze riportate in questo documento.</p> <p>CONSERVARE QUESTE ISTRUZIONI</p>
Advarsel	<p>VIKTIGE SIKKERHETSINSTRUKSJONER</p> <p>Dette advarselssymbolet betyr fare. Du er i en situasjon som kan føre til skade på person. Før du begynner å arbeide med noe av utstyret, må du være oppmerksom på farene forbundet med elektriske kretser, og kjenne til standardprosedyrer for å forhindre ulykker. Bruk nummeret i slutten av hver advarsel for å finne oversettelsen i de oversatte sikkerhetsadvarslene som fulgte med denne enheten.</p> <p>TA VARE PÅ DISSE INSTRUKSJONENE</p>

Aviso	<p>INSTRUÇÕES IMPORTANTES DE SEGURANÇA .</p> <p>Este símbolo de aviso significa perigo. Você está em uma situação que poderá ser causadora de lesões corporais. Antes de iniciar a utilização de qualquer equipamento, tenha conhecimento dos perigos envolvidos no manuseio de circuitos elétricos e familiarize-se com as práticas habituais de prevenção de acidentes. Utilize o número da instrução fornecido ao final de cada aviso para localizar sua tradução nos avisos de segurança traduzidos que acompanham este dispositivo</p> <p>GUARDE ESTAS INSTRUÇÕES</p>
¡Advertencia!	<p>INSTRUCCIONES IMPORTANTES DE SEGURIDAD</p> <p>Este símbolo de aviso indica peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considere los riesgos de la corriente eléctrica y familiarícese con los procedimientos estándar de prevención de accidentes. Al final de cada advertencia encontrará el número que le ayudará a encontrar el texto traducido en el apartado de traducciones que acompaña a este dispositivo.</p> <p>GUARDE ESTAS INSTRUCCIONES</p>
Varning!	<p>VIKTIGA SÄKERHETSANVISNINGAR</p> <p>Denna varningssignal signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanliga förfaranden för att förebygga olyckor. Använd det nummer som finns i slutet av varje varning för att hitta dess översättning i de översatta säkerhetsvarningar som medföljer denna anordning.</p> <p>SPARA DESSA ANVISNINGAR</p>
Figyelem	<p>FONTOS BIZTONSÁGI ELOÍRÁSOK</p> <p>Ez a figyelmeztető jel veszélyre utal. Sérülésveszélyt rejtő helyzetben van. Mielőtt bármely berendezésen munkát végezte, legyen figyelemmel az elektromos áramkörök okozta kockázatokra, és ismerkedjen meg a szokásos balesetvédelmi eljárásokkal. A kiadványban szereplő figyelmeztetések fordítása a készülékhez mellékelt biztonsági figyelmeztetések között található; a fordítás az egyes figyelmeztetések végén látható szám alapján kereshető meg.</p> <p>ORIZZE MEG EZEKET AZ UTASÍTÁSOKAT!</p>
Предупреждение	<p>Для обеспечения соответствия требованиям по предельным значениям облучения радиочастотами (РЧ) антенны данного устройства должны располагаться на расстоянии не ближе 2 м от пользователей.</p>
警告	<p>如果电源出现故障或中断，您将无法使用 Voice over IP (VoIP) 服务与紧急呼叫服务。电源恢复之后，您可能需要重新设置或重新配置设备，以便重新获得进入 VoIP 与紧急呼叫服务的权限。在美国，此紧急呼叫号码是 911。您必须知道本国的紧急呼叫号码。</p>
警告	<p>電源障害や停電の場合、ボイス オーバー アイピー (VoIP) サービスと緊急呼出しサービスは機能しません。電源の回復後、VoIP と緊急呼出しサービスにアクセスするには機器をリセットまたは再設定する必要があります。米国内の緊急呼出し番号は 911 です。お住まいの地域の緊急呼出し番号をあらかじめ調べておいてください。</p>

Cisco Catalyst 9400 Series Supervisor 1 Module Features

The following figure shows the front view of Cisco Catalyst 9400 Series Supervisor 1 Module, with the major features identified.

Figure 1: Cisco Catalyst 9400 Series Supervisor 1 Module



The following table describes the major features of the supervisor module in the serial number order called out in [Figure 1: Cisco Catalyst 9400 Series Supervisor 1 Module, on page 8](#):

Call Out No.	Feature	Description
1	USB Type A Host Port	This USB port is a host port for an external USB disk drive. It supports USB versions 3.0, 2.0, 1.1, and 1.0. See USB Type A Host Port, on page 31
2	USB mini Type B Console Port	This USB port can be used as a console port, allowing attachment to PCs that are not equipped with an RS-232 interface. See Console Ports, on page 31 .
3	10/100/1000 Ethernet Management Port (RJ-45 connector)	The Ethernet management port is a Layer 3 host port to which you can connect a PC. By default, the Ethernet management port is enabled. You can use the Ethernet management port instead of the switch console port for network management. This port is not active while the switch is operating normally. Note When connecting a PC to the Ethernet management port, you must assign an IP address. See Ethernet Management Port, on page 32
4	Console port (RJ-45 connector)	This is an RS-232 serial or console port for system management. See Console Ports, on page 31
5	RESET switch (recessed)	The RESET switch is used to reset and restart the switch. Note The reset switch is recessed into the front panel. Use a paper clip or a small, pointed object to press the RESET switch.


Call Out No.	Feature	Description
6	1-GigabitEthernet (GE) or 10-GE uplink ports	<p>The supervisor module has eight 1-GE or 10-GE ports. These ports require either small form-factor pluggable (SFP) or SFP+ transceivers. Ports are numbered 1 to 8.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
7	RFID	<p>Supervisor module Radio Frequency Identifier (RFID).</p> <p>The supervisor module has a built-in, front-facing, passive RFID tag that uses Ultra High Frequency (UHF) RFID technology and requires an RFID reader with compatible software. It provides auto-identification capabilities for asset management and tracking. The RFID tags are compatible with the Generation 2 GS1 EPC Global Standard and are ISO 18000-6C compliant. They operate in the 860- to 960-MHz UHF band. For more information, see Radio Frequency Identification (RFID) on Cisco Catalyst 9000 Family Switches.</p>
8	40-GE uplink ports	<p>The supervisor module has two 40-GE ports. These ports use QSFP transceivers. Ports are numbered 9 and 10.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
9	Model Number	Supervisor module model number.
10	Supervisor slot indicator	Bar on the fan tray front panel that indicates the supervisor slots in a chassis.

The ICON reference guide published at the following location provides a ready reference to the ICONs used on the faceplate: http://www.cisco.com/c/dam/en/us/td/docs/switches/lan/catalyst_icon/switch_icon_ref.pdf

Cisco Catalyst 9400 Series Supervisor 1XL Module Features

The following illustration shows the front view of Cisco Catalyst 9400 Series Supervisor 1XL Module, and the accompanying table describes the major features of the supervisor module.

Figure 2: Cisco Catalyst 9400 Series Supervisor 1XL Module



Call Out No.	Feature	Description
1	USB Type A Host Port	This USB port is a host port for an external USB disk drive. It supports USB versions 3.0, 2.0, 1.1, and 1.0. See USB Type A Host Port, on page 31
2	USB mini Type B Console Port	This USB port can be used as a console port, allowing attachment to PCs that are not equipped with an RS-232 interface. See Console Ports, on page 31
3	10/100/1000 Ethernet Management Port (RJ-45 connector)	The Ethernet management port is a Layer 3 host port to which you can connect a PC. By default, the Ethernet management port is enabled. You can use the Ethernet management port instead of the switch console port for network management. This port is not active while the switch is operating normally. Note When connecting a PC to the Ethernet management port, you must assign an IP address. See Ethernet Management Port, on page 32
4	Console port (RJ-45 connector)	This is an RS-232 serial or console port for system management. See Console Ports, on page 31
5	RESET switch (recessed)	The RESET switch is used to reset and restart the switch. Note The reset switch is recessed into the front panel. Use a paper clip or a small, pointed object to press the RESET switch.


Call Out No.	Feature	Description
6	1-GigabitEthernet (GE) or 10-GE uplink ports	<p>The supervisor module has eight 1-GE or 10-GE ports. These ports require either small form-factor pluggable (SFP) or SFP+ transceivers. Ports are numbered 1 to 8.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
7	RFID	<p>Supervisor module Radio Frequency Identifier (RFID).</p> <p>The supervisor module has a built-in, front-facing, passive RFID tag that uses Ultra High Frequency (UHF) RFID technology and requires an RFID reader with compatible software. It provides auto-identification capabilities for asset management and tracking. The RFID tags are compatible with the Generation 2 GS1 EPC Global Standard and are ISO 18000-6C compliant. They operate in the 860- to 960-MHz UHF band. For more information, see Radio Frequency Identification (RFID) on Cisco Catalyst 9000 Family Switches.</p>
8	40-GE uplink ports	<p>The supervisor module has two 40-GE ports. These ports use QSFP transceivers. Ports are numbered 9 and 10.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
9	Model Number	Supervisor module model number.
10	Supervisor slot indicator	Bar on the fan tray front panel that indicates the supervisor slots in a chassis.

The ICON reference guide published at the following location provides a ready reference to the ICONs used on the faceplate: http://www.cisco.com/c/dam/en/us/td/docs/switches/lan/catalyst_icon/switch_icon_ref.pdf

Cisco Catalyst 9400 Series Supervisor 1XL-Y 25G Module Features

The following figure shows the front view of Cisco Catalyst 9400 Series Supervisor 1XL-Y 25G Module , and the accompanying table describes the major features of the supervisor module.

Figure 3: Cisco Catalyst 9400 Series Supervisor 1XL-Y 25G Module



Call Out No.	Feature	Description
1	USB Type A Host Port	This USB port is a host port for an external USB disk drive. It supports USB versions 3.0, 2.0, 1.1, and 1.0. See USB Type A Host Port, on page 31
2	USB mini Type B Console Port	This USB port can be used as a console port, allowing attachment to PCs that are not equipped with an RS-232 interface. See Console Ports, on page 31
3	10/100/1000 Ethernet Management Port (RJ-45 connector)	The Ethernet management port is a Layer 3 host port to which you can connect a PC. By default, the Ethernet management port is enabled. You can use the Ethernet management port instead of the switch console port for network management. This port is not active while the switch is operating normally. Note When connecting a PC to the Ethernet management port, you must assign an IP address. See Ethernet Management Port, on page 32
4	Console port (RJ-45 connector)	This is an RS-232 serial or console port for system management. See Console Ports, on page 31
5	RESET switch (recessed)	The RESET switch is used to reset and restart the switch. Note The reset switch is recessed into the front panel. Use a paper clip or a small, pointed object to press the RESET switch.


Call Out No.	Feature	Description
6	1-GigabitEthernet (GE) or 10-GE, or 25-GE uplink ports	<p>The supervisor module has eight small form-factor pluggable (SFP) or SFP+ transceivers which support 1-GE or 10-GE modules. These ports are numbered 1 to 8.</p> <p>Ports 1 and 5 use SFP28 transceivers in 25G mode.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
7	RFID	<p>Supervisor module Radio Frequency Identifier (RFID).</p> <p>The supervisor module has a built-in, front-facing, passive RFID tag that uses Ultra High Frequency (UHF) RFID technology and requires an RFID reader with compatible software. It provides auto-identification capabilities for asset management and tracking. The RFID tags are compatible with the Generation 2 GS1 EPC Global Standard and are ISO 18000-6C compliant. They operate in the 860- to 960-MHz UHF band. For more information, see Radio Frequency Identification (RFID) on Cisco Catalyst 9000 Family Switches.</p>
8	40-GE uplink ports	<p>The supervisor module has two 40-GE ports. These ports use QSFP transceivers. Ports are numbered 9 and 10.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
9	Model Number	Supervisor module model number.
10	Supervisor slot indicator	Bar on the fan tray front panel that indicates the supervisor slots in a chassis.

The ICON reference guide that is published at the following location provides a ready reference to the ICONs used on the faceplate: http://www.cisco.com/c/dam/en/us/td/docs/switches/lan/catalyst_icon/switch_icon_ref.pdf

Cisco Catalyst 9400 Series Supervisor 2 Module Features

The following figure shows the front view of Cisco Catalyst 9400 Series Supervisor 2 Module , and the accompanying table describes the major features of the supervisor module.

Figure 4: Cisco Catalyst 9400 Series Supervisor 2 Module



357750


Call Out No.	Feature	Description
1	USB Type A Host Port	This USB port is a host port for an external USB disk drive. It supports USB versions 3.0, 2.0, 1.1, and 1.0. See USB Type A Host Port, on page 31
2	USB mini Type B Console Port	This USB port can be used as a console port, allowing attachment to PCs that are not equipped with an RS-232 interface. See Console Ports, on page 31
3	10/100/1000 Ethernet Management Port (RJ-45 connector)	The Ethernet management port is a Layer 3 host port to which you can connect a PC. By default, the Ethernet management port is enabled. You can use the Ethernet management port instead of the switch console port for network management. This port is not active while the switch is operating normally. Note When connecting a PC to the Ethernet management port, you must assign an IP address. See Ethernet Management Port, on page 32
4	Console port (RJ-45 connector)	This is an RS-232 serial or console port for system management. See Console Ports, on page 31
5	RESET switch (recessed)	The RESET switch is used to reset and restart the switch. Note The reset switch is recessed into the front panel. Use a paper clip or a small, pointed object to press the RESET switch.

Call Out No.	Feature	Description
6	10-GigabitEthernet (GE) or 25-GE uplink ports	<p>The supervisor module has four 10-GE or 25-GE uplink ports.</p> <p>These ports require SFP+ transceivers for 10-GE operation, and SFP28 transceivers for 25-GE operation.</p> <p>The ports are numbered 1 to 4.</p> <p>See Uplink Ports, on page 32</p>
7	RFID	<p>Supervisor module Radio Frequency Identifier (RFID).</p> <p>The supervisor module has a built-in, front-facing, passive RFID tag that uses Ultra High Frequency (UHF) RFID technology and requires an RFID reader with compatible software. It provides auto-identification capabilities for asset management and tracking. The RFID tags are compatible with the Generation 2 GS1 EPC Global Standard and are ISO 18000-6C compliant. They operate in the 860- to 960-MHz UHF band. For more information, see Radio Frequency Identification (RFID) on Cisco Catalyst 9000 Family Switches.</p>
8	40-GE or 100-GE uplink ports	<p>The supervisor module has four 40-GE or 100-GE uplink ports.</p> <p>These ports require QSFP transceivers for 40GE operation and QSFP28 transceivers for 100-GE operation.</p> <p>The ports are numbered 5 to 8.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the port numbers and LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
9	Model Number	Supervisor module model number.
10	Supervisor slot indicator	Bar on the fan tray front panel that indicates the supervisor slots in a chassis.

Cisco Catalyst 9400 Series Supervisor 2XL Module Features

The following figure shows the front view of Cisco Catalyst 9400 Series Supervisor 2XL Module, and the accompanying table describes the major features of the supervisor module.

Figure 5: Cisco Catalyst 9400 Series Supervisor 2XL Module




357751




Call Out No.	Feature	Description
1	USB Type A Host Port	This USB port is a host port for an external USB disk drive. It supports USB versions 3.0, 2.0, 1.1, and 1.0. See USB Type A Host Port, on page 31
2	USB mini Type B Console Port	This USB port can be used as a console port, allowing attachment to PCs that are not equipped with an RS-232 interface. See Console Ports, on page 31
3	10/100/1000 Ethernet Management Port (RJ-45 connector)	The Ethernet management port is a Layer 3 host port to which you can connect a PC. By default, the Ethernet management port is enabled. You can use the Ethernet management port instead of the switch console port for network management. This port is not active while the switch is operating normally. Note When connecting a PC to the Ethernet management port, you must assign an IP address. See Ethernet Management Port, on page 32
4	Console port (RJ-45 connector)	This is an RS-232 serial or console port for system management. See Console Ports, on page 31
5	RESET switch (recessed)	The RESET switch is used to reset and restart the switch. Note The reset switch is recessed into the front panel. Use a paper clip or a small, pointed object to press the RESET switch.

Call Out No.	Feature	Description
6	10-GigabitEthernet (GE) or 25-GE uplink ports	<p>The supervisor module has four 10-GE or 25-GE uplink ports.</p> <p>These ports require SFP+ transceivers for 10-GE operation, and SFP28 transceivers for 25-GE operation.</p> <p>The ports are numbered 1 to 4.</p> <p>See Uplink Ports, on page 32</p>
7	RFID	<p>Supervisor module Radio Frequency Identifier (RFID).</p> <p>The supervisor module has a built-in, front-facing, passive RFID tag that uses Ultra High Frequency (UHF) RFID technology and requires an RFID reader with compatible software. It provides auto-identification capabilities for asset management and tracking. The RFID tags are compatible with the Generation 2 GS1 EPC Global Standard and are ISO 18000-6C compliant. They operate in the 860- to 960-MHz UHF band. For more information, see Radio Frequency Identification (RFID) on Cisco Catalyst 9000 Family Switches.</p>
8	40-GE or 100-GE uplink ports	<p>The supervisor module has four 40-GE or 100-GE uplink ports.</p> <p>These ports require QSFP transceivers for 40GE operation and QSFP28 transceivers for 100-GE operation.</p> <p>The ports are numbered 5 to 8.</p> <p>Note In the accompanying figure, the ejector lever is not displayed in the redundant supervisor module only for the purpose of displaying the port numbers and LEDs behind it.</p> <p>See Uplink Ports, on page 32</p>
9	Model Number	Supervisor module model number.
10	Supervisor slot indicator	Bar on the fan tray front panel that indicates the supervisor slots in a chassis.


Cisco Catalyst 9400 Series Supervisor Module LEDs



Table 3: Cisco Catalyst 9400 Series Supervisor Module LEDs


LED	LED Color	Meaning
 STATUS	Green	All diagnostic tests have passed after correct image booting.
	Amber	System boot or a diagnostic test is in progress.
	Red	A diagnostic test failed.
	Off	The supervisor module is disabled or is not powered up.

LED	LED Color	Meaning
 LOCATE	Blue	Identifies the supervisor module receiving the beacon signal.
 ACTIVE	Green	Supervisor module is the active supervisor (in redundant supervisor module configurations).
	Off	Supervisor module is in standby mode (in redundant supervisor module configurations).
 MANAGEMENT	Green	The 10/100/1000 BASE-T Ethernet management port is operational (link up).
	Off	No signal is detected for the 10/100/1000 BASE-T Ethernet management port, or there is a link configuration failure, or the link is disabled by user (link down).



For C9400-SUP-1, C9400-SUP-1XL, and C9400-SUP-1XL-Y Only

LED	LED Color	Meaning
 SFP or SFP+ or SFP28 UPLINK STATUS Triangular LEDs pointing up or down, indicating the status of the corresponding port.	Green	SFP or SFP+ port link is up but there is no packet activity.
	Blinking Green	SFP or SFP+ port link is up and indicating packet activity.
	Amber	SFP or SFP+ link is disabled by the user, that is, administratively down.
	Blinking Amber	Hardware (PHY) has detected a faulty port link.
	Alternating Green and Amber	Error packets are being detected on the port link. The error packets could be bad Cyclic Redundancy Check (CRC) packets, jumbo packets, etc.
	Off	SFP or SFP+ port link is down or transceiver module is not installed.

For C9400-SUP-1, C9400-SUP-1XL, and C9400-SUP-1XL-Y Only		
LED	LED Color	Meaning
 <p>QSFP UPLINK STATUS</p> <p>LEDs next to each QSFP port number, indicating the status of the corresponding port.</p>	Green	QSFP port link is up but there is no packet activity.
	Blinking Green	QSFP port link is up and indicating packet activity.
	Amber	QSFP port link is disabled by the user, that is, administratively down.
	Alternating Green and Amber	Error packets are being detected on the QSFP port link. The error packets could be bad Cyclic Redundancy Check (CRC) packets, jumbo packets, etc.
	Off	QSFP port link is down or transceiver module is not installed.
 <p>PORT SET ENABLED</p> <p>There are four such LEDs on the supervisor module faceplate:</p> <ul style="list-style-type: none"> • One for port numbers 1 to 4 (G1). • One for port numbers 5 to 8 (G2). • One for port number 9 (G3). • One for port number 10 (G4). 	Green	The port set is enabled. Note Starting with Cisco IOS XE Fuji 16.8.1a, PORT SET ENABLED LEDs for SFP or SFP+ ports are supported.
	Off	The port set is not enabled.


For C9400X-SUP-2 and C9400X-SUP-2XL Only		
LED	LED Color	Meaning
 <p>SFP+ or SFP28 UPLINK STATUS</p> <p>Triangular LEDs pointing up or down, indicating the status of the corresponding port.</p>	Green	SFP+ port link is up but there is no packet activity.
	Blinking Green	SFP+ port link is up and indicating packet activity.
	Amber	SFP+ link is disabled by the user, that is, administratively down.
	Blinking Amber	Hardware (PHY) has detected a faulty port link.
	Alternating Green and Amber	Error packets are being detected on the port link. The error packets could be bad Cyclic Redundancy Check (CRC) packets, jumbo packets, etc.
	Off	SFP+ port link is down or transceiver module is not installed.

For C9400X-SUP-2 and C9400X-SUP-2XL Only

LED	LED Color	Meaning
 <p>QSFP UPLINK STATUS</p> <p>Triangular LEDs pointing up, indicating the status of the corresponding port.</p>	Green	QSFP port link is up but there is no packet activity.
	Blinking Green	QSFP port link is up and indicating packet activity.
	Amber	QSFP link is disabled by the user, that is, administratively down.
	Blinking Amber	Hardware (PHY) has detected a faulty port link.
	Alternating Green and Amber	Error packets are being detected on the port link. The error packets could be bad Cyclic Redundancy Check (CRC) packets, jumbo packets, etc.
	Off	QSFP port link is down or transceiver module is not installed.
 <p>PORT SET ENABLED</p> <p>There are five such LEDs on the supervisor module faceplate:</p> <ul style="list-style-type: none"> • One for port numbers 1 to 4. • One for port number 5. • One for port number 6. • One for port number 7. • One for port number 8. 	Green	The port set is enabled.
	Off	The port set is not enabled.

Example: Cisco Catalyst 9400 Series Supervisor 1 Module LEDs

The following illustration and accompanying table show where the various LEDs are located on a Cisco Catalyst 9400 Series Supervisor 1 Module. Other models also have similar LEDs.



1	STATUS	7	QSFP UPLINK STATUS For QSFP port number 10
2	LOCATE	8	PORT SET ENABLED For QSFP port number 10
3	ACTIVE	9	PORT SET ENABLED For QSFP port number 9
4	MANAGEMENT	10	PORT SET ENABLED For SFP/ SFP+ port numbers 5 to 8
5	SFP or SFP+ UPLINK STATUS	11	PORT SET ENABLED For SFP/ SFP+ port numbers 1 to 4
6	QSFP UPLINK STATUS For QSFP port number 9	-	-

Removal and Replacement Procedures

Preventing ESD Damage

ESD damage might occur when modules or other FRUs are improperly handled, resulting in intermittent or complete failure of the modules or FRUs. Modules consist of printed circuit boards that are fixed in metal carriers. EMI shielding and connectors are integral components of a carrier. Although the metal carrier helps to protect the board from ESD, always use an ESD-grounding strap when handling modules. To prevent ESD damage, follow these guidelines:

- Always use an ESD wrist or ankle strap and ensure that it makes good skin contact.
- Connect the equipment end of the strap to an unfinished chassis surface.
- When installing a component, use an available ejector lever or captive installation screws to properly seat the bus connectors in the backplane or midplane. These devices prevent accidental removal, provide proper grounding for the system, and help to ensure that bus connectors are properly seated.

- When removing a component, use an available ejector lever or captive installation screws to release the bus connectors from the backplane or midplane.
- Handle carriers by available handles or edges only; avoid touching the printed circuit boards or connectors.
- Place a removed component board-side-up on an antistatic surface or in a static-shielding container. If you plan to return the component to the factory, immediately place it in a static-shielding container.
- Avoid contact between the printed circuit boards and clothing. The wrist strap only protects components from ESD voltages on the body; ESD voltages on clothing can still cause damage.
- Never attempt to remove the printed circuit board from the metal carrier.

Removing and Replacing a Supervisor Module

While Cisco Catalyst 9400 Series supervisor modules support hot swapping or Online Insertion and Removal (OIR), which lets you install, remove, replace, and rearrange supervisor modules without powering off the system, you must observe a wait time before removal or replacement.



Note

- After you install a supervisor module in the chassis, allow *90 seconds* before removing it.
- After you remove a supervisor module from the chassis, allow *15 seconds* before re-installing the same supervisor module in the same slot. The wait time does not apply if you are installing a different supervisor module in the slot.
- After you power-off the chassis, allow *15 seconds* before turning it on again.
- After you power-on the chassis, allow *90 seconds* if you have to power it off again.

When the system detects that a supervisor module has been installed or removed, it runs diagnostic and discovery routines automatically, acknowledges the presence or absence of the module, and resumes the system operation with no operator intervention.



Warning

Only trained and qualified personnel should be allowed to install, replace, or service this equipment. **Statement 1030**



Warning

Ultimate disposal of this product should be handled according to all national laws and regulations. **Statement 1040**

Required Tools

You will need these tools to install or remove supervisor modules and line cards:

- Your own ESD-prevention equipment or the disposable grounding wrist strap included with all upgrade kits, field-replaceable units (FRUs), and spares.
- Antistatic mat or antistatic bag
- Number 1 and number 2 Phillips screwdrivers for the captive installation screws on most modules
- 3/16-inch flat-blade screwdriver for the captive installation screws on some modules

Installing a Supervisor Module



Warning Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing.
Statement 1034




Caution To prevent ESD damage, handle supervisor modules by the carrier edges only.

Before you begin

- Verify chassis compatibility and slot restrictions.
- Verify that both the supervisor modules (in a redundant configuration) are of the same type.
- You will need a Phillips screwdriver to tighten the captive installation screws.

Procedure


- Step 1** Take the necessary precautions to prevent ESD damage. Wear a grounded ESD wrist strap while handling the modules, and keep them in ESD-protective bags when they are not installed in a chassis.
- Step 2** Ensure that you have enough clearance to accommodate any interface equipment that you will connect directly to the supervisor module ports.
- Step 3** If a slot blank cover (C9400-S-BLANK=) is present, loosen the two captive installation screws that secure the cover and remove it. Save it for future use.
- Step 4** Remove the new supervisor module from the shipping packaging, being careful to handle the module using only the module's metal tray or the front panel. Do not touch the printed circuit board or the connector pins.
- Step 5** Pivot the two module ejector levers out and away from the faceplate
- Step 6** Grasp the supervisor module's front panel with one hand and place your other hand under the carrier to support the module.
- Step 7** Position the new module in the slot. Make sure that you align the sides of the printed circuit boards with the slot guides on each side of the chassis slot.
- Tip** The guide pin on the top-left corner of the supervisor module is designed to slide into a compatible slot only. So the guide pin on the supervisor module will not slide in all the way if you insert it into a non-supervisor module slot.



355118

1	Guide pin target indicating that this is a compatible slot for this module.	-	-
---	---	---	---

Step 8 Carefully slide the supervisor module into the slot. Pivot both ejector levers in simultaneously.



855117

1	Ejector levers to be pivoted in after the supervisor module slides in all the way.	-	-
---	--	---	---

When installed correctly

- The guide pin slides in completely.
- The notches on both the ejector levers engage the chassis sides.
- Both the ejector levers are parallel with the supervisor module faceplate to fully seat the module in the backplane connector.

Note Always use the ejector levers when installing or removing a supervisor module. A module that is partially seated in the backplane will not function correctly.

Step 9 Use a screwdriver to tighten the two captive installation screws on the supervisor module. Do not over tighten the captive installation screws.

Note After you install a supervisor module in the chassis, if you have to remove it for any reason, allow *90 seconds* before removing it.

Step 10 Check the status of the module:

- Verify that the supervisor module STATUS LED is lit.
- Periodically check the STATUS LED.

If the STATUS LED changes from amber to green, it means that the supervisor module has completed the boot process successfully, and is now online.

If the STATUS LED remains amber or turns red, it means that the supervisor module has not completed the boot process successfully, and may have encountered an error.

- c) When the switch is online, enter the **show module** command. Verify that the system acknowledges the new supervisor module and that the module status is OK.
- d) If the module is not operational, reseal it. If the module is still not operational, contact your Cisco customer service representative.

Removing a Supervisor Module



Warning Hazardous voltage or energy is present on the backplane when the system is operating. Use caution when servicing. **Statement 1034**



Warning Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. **Statement 1051**




Caution To prevent ESD damage, handle supervisor modules by the carrier edges only.

Before you begin

- You will need a Slot Blank Cover (C9400-S-BLANK) if the slot is to remain empty.
- You will need a Phillips screwdriver to loosen the captive installation screws.

Procedure

- Step 1** Take the necessary precautions to prevent ESD damage. Wear a grounded ESD wrist strap while handling the modules, and keep them in ESD-protective bags when they are not installed in a chassis.
- Step 2** Disconnect any network interface cables attached to the ports of the supervisor module that you intend to remove.
- Step 3** If the module is equipped with removable optical transceivers, immediately install dust plugs into the transceiver's optical bores. This prevents possible dust contamination, which can affect port performance.
- Step 4** Loosen the two captive installation screws on either end of the supervisor module faceplate.
- Step 5** Grasp the left and right ejector levers at either end of the supervisor module faceplate and simultaneously pivot the levers outward to disengage the supervisor module from the backplane connector.



355116

1	Captive installation screws that are loosened	2	Ejector levers that are pivoted-out, to disengage the module.
---	---	---	---

Step 6 Grasp the front panel of the supervisor module with one hand and place your other hand under the carrier to support and guide it out of the slot. Do not touch the printed circuit boards or connector pins.

Step 7 Carefully slide the supervisor module straight out of the slot, keeping your other hand under the carrier to guide it.

Step 8 Place the supervisor module on an antistatic mat or in an antistatic bag.

Step 9 Install a replacement supervisor module, or if the chassis slot is to remain empty, install a blank slot cover (C9400-S-BLANK).

Note After you remove a supervisor module from the chassis, allow *15 seconds* before re-installing the same supervisor module in the same slot. The wait time does not apply if you are installing a different supervisor module in the slot.

Blanks should only be removed when installing a module and must be replaced if a module is ever removed.

Warning Blank faceplates and cover panels serve three important functions: they prevent exposure to hazardous voltages and currents inside the chassis; they contain electromagnetic interference (EMI) that might disrupt other equipment; and they direct the flow of cooling air through the chassis. Do not operate the system unless all cards, faceplates, front covers, and rear covers are in place. **Statement 1029**

Removing and Replacing an M.2 SATA SSD Module

The Serial Advanced Technology Attachment (SATA) is a computer bus interface that connects host bus adapters to mass storage devices such as hard disk drives, optical drives, and solid-state drives.

The supervisor module provides a SATA port that is connected to the CPU SATA port0. An M.2 connector is used to accommodate a 22 x 80 mm M.2 SATA SSD module on the supervisor board.

Prerequisites for Removal and Installation

- If you are installing a new SATA module, we recommend that you install it - as is (raw SATA module, without partitioning). The system partitions the module as required.
- If you are installing a previously used SATA module, before installing, ensure that the filesystem is **ext2**.
If the filesystem is the wrong format or is unrepairable, then the system creates a new **ext2** filesystem; this will likely make any previously existing files unreadable and unrecoverable.
- If you are creating partitions in a SATA module (new or used), we recommend that you use a Linux system to perform this task, ensuring that the first partition is a usable partition when connected to the switch.
- Power down the system.



Note The M.2 SATA SSD Module does not support hot-swapping; you must power down the system to install a new SSD module or to replace an SSM module on the supervisor board.



Warning Only trained and qualified personnel should be allowed to install, replace, or service this equipment. **Statement 1030**



Warning Ultimate disposal of this product should be handled according to all national laws and regulations. **Statement 1040**

Removing an M.2 SATA SSD Module


This task describes how to correctly remove the SSD module.

Before you begin

You have powered down the system.

Procedure

-
- Step 1** Take the necessary precautions to prevent ESD damage. Wear a grounded ESD wrist strap while handling the modules, and keep them in ESD-protective bags when they are not installed in a chassis.
 - Step 2** Follow the procedure to remove the supervisor module from the chassis. See [Removing a Supervisor Module, on page 26](#).
 - Step 3** Handling supervisor module by the carrier edges, place the removed supervisor module on an antistatic mat.
 - Step 4** Completely loosen and remove the mounting screw of the SSD module.
 - Step 5** Slide the SSD module out of the connector.



What to do next

Install a new SSD Module

Installing an M.2 SATA SSD module


This task describes how to correctly install a new SSD module

Before you begin

You will need a Philips screwdriver to tighten the mounting screw

Procedure

-
- Step 1** Take the necessary precautions to prevent ESD damage. Wear a grounded ESD wrist strap while handling the modules, and keep them in ESD-protective bags when they are not installed in a chassis.
 - Step 2** Remove the new SSD module from the shipping packaging.
 - Step 3** Slide the SSD module into the mating connector at a 20 degree angle and then push it down.
 - Step 4** Install and tighten the mounting screw.



955134

1	SATA module and mounting screw	2	Supervisor module
---	--------------------------------	---	-------------------

Step 5 Follow the procedure to install the supervisor module. See [Installing a Supervisor Module, on page 23](#)

Step 6 Power up the chassis.

Replacing a Battery



Warning Only trained and qualified personnel should be allowed to install, replace, or service this equipment. **Statement 1030**



Warning There is the danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. **Statement 1015**

The Cisco Catalyst 9400 Series Supervisor Modules use a lithium battery. This is not a field replaceable unit. The following battery models are supported:

- Panasonic, Model 1632
- Renata, Model 700296 (CR1632)
- Varta, Model 06632 101 501 (CR1632)

Module Interfaces

The supervisor module has the following interfaces or ports: USB ports, console ports, management port, and uplink ports.



Warning To avoid electric shock, do not connect safety extra-low voltage (SELV) circuits to telephone-network voltage (TNV) circuits. LAN ports contain SELV circuits, and WAN ports contain TNV circuits. Some LAN and WAN ports both use RJ-45 connectors. Use caution when connecting cables. **Statement 1021**

USB Type A Host Port

The USB 2.0 and USB 3.0 Type A host port (disk0) is the only external storage interface for this switch. The port is connected to the route processor, which allows the Cisco IOS software to access the port. A flash memory device can plug into this connector. Cisco IOS software provides standard file system access to the flash device: read, write, erase, and copy. The software also provides the ability to format the flash device with a FAT file system (FAT32 and FAT16).

Observe these guidelines when using USB flash drives:

- There must be at least one partition on the USB flash drive. If the drive has more than one partition, then only the first partition is visible in the system (Cisco IOS).
- If you partition the flash drive, we recommend that you use a Linux system to perform this task. This ensures that the first partition is a usable partition when connected to the switch.

Using a Windows or MacBook machine utility to perform this task may result in two partitions on the drive by default (partition for system information + actual usable partition). When such a flash drive is connected to the switch, the system displays only the first system information partition, and not the actual usable partition.

Console Ports

The supervisor module provides two types of console ports on the supervisor module front panel:

- USB Console Port—This is the USB mini Type B Console Port.
- Console Port (RJ-45 connector)—This console port allows you to access the switch either locally (through a console terminal) or remotely (through a modem). The console is an EIA/TIA-232 asynchronous, serial connection with hardware flow control and an RJ-45 connector.

Only one of the consoles is active at a time. When a USB host (PC) is plugged into the USB console port the hardware automatically switches over to use the USB console. Only a PC which has the necessary USB console device driver causes the USB console to become active. Plugging in a PC that does not have the USB console driver support does not cause a switchover. When the USB cable is removed or the PC deactivates the USB connection, or a host is not detected on the USB console, the hardware automatically switches to the RJ45 console interface.

The default console port setting is 9600 baud, 8 data bits, no parity, 1 stop bit, and no flow control.

The console port allows you to perform the following functions:

- Configure the switch from the CLI
- Monitor network statistics and errors
- Configure SNMP agent parameters

Ethernet Management Port

The supervisor module provides a standard 10/100/1000 BASE-T Ethernet management port. When managing a switch, connect the PC to the Ethernet management port of a Cisco Catalyst 9400 Series switch supervisor module.

The Ethernet management port can be used (in ROMMON mode only), to recover a switch software image that has been corrupted or destroyed due to a network catastrophe. You can use the ethernet management port for out of band (OOB) ethernet network connectivity. It can be used for SSH/Telnet access and image download through the OOB IP network.

The specific implementation of Ethernet management port depends on the redundancy model you are applying.

The switch cannot route packets from the Ethernet management port to a network port, and from the network port to the Ethernet port. To obtain these, the GigabitEthernet 0/0 interface is automatically placed in a separate routing domain (or VRF domain), called Mgmt-vrf. (Observe the **vrf forwarding Mgmt-vrf** in the running configuration when you boot.)

Uplink Ports

The supervisor module has uplink ports that can be used to provide additional port capacity for a fully configured switch or can reduce the need to use a chassis slot for a module. These ports use hot-swappable optical transceivers.

Some uplink ports use small form-factor pluggable (SFP) transceivers, or SFP+ transceivers, or SFP28 transceivers, and some use Quad Small Form-Factor Pluggable (QSFP), or QSFP28 transceivers.

For more detailed information about uplink port configuration, see the *Configuring Interface Characteristics* chapter of the *Interface and Hardware Components Configuration Guide* of the required release.

SFP and SFP+ Ports

- SFP and SFP+: Numbered 1 to 8 on C9400-SUP-1, C9400-SUP-1XL, and C9400-SUP-1XL-Y.
These ports are divided into two groups where port numbers 1 through 4 form one port group and port numbers 5 through 8 form a second group.
- SFP+ only: Numbered 1 to 4 on C9400X-SUP-2 and C9400X-SUP-2XL.

These ports can be configured with SFP transceivers for 1-GE operations or SFP+ transceivers for 10-GE operations. 1 and 10-GE uplink ports operate in full-duplex mode only. Both transceivers use LC-type connectors (optical) or RJ-45 (copper). The SFP transceivers have LC connectors to interface with multimode fiber (MMF) cable and single-mode fiber (SMF) cable and RJ-45 connectors for the copper interfaces.

Each SFP module has an internal serial EEPROM that is encoded with security information. This encoding provides a way for Cisco to identify and validate that the SFP module meets the requirements for the device.

SFP28 Ports

- Numbered 1 and 5 on C9400-SUP-1XL-Y.
- Numbered 1 to 4 on C9400X-SUP-2 and C9400X-SUP-2XL.

These ports use SFP28 transceivers to support 25-GE uplinks.

QSFP Ports

- Numbered 9 and 10 on C9400-SUP-1, C9400-SUP-1XL, and C9400-SUP-1XL-Y.
- Numbered 5 to 8 on C9400X-SUP-2 and C9400X-SUP-2XL.

These ports can be configured with QSFP transceivers for 40-GE operations. QSFP transceivers use LC, copper, or MPO-12 connectors.



Note Breakout cables are not supported.

QSFP28 Ports

Numbered 5 to 8 on C9400X-SUP-2 and C9400X-SUP-2XL.

These ports can be configured with QSFP28 transceivers for 100-GE operations.

Uplink Port Configuration for C9400-SUP-1, C9400-SUP-1XL, and C9400-SUP-1XL-Y

Guidelines

These guidelines apply to a non-redundant (single supervisor) setup:

- SFP or SFP+ port numbers 1 through 4 and QSFP port 9 form a mutually exclusive set; Only one of them can operate at any given time – either the SFP/SFP+ port group or the QSFP port.
- SFP or SFP+ port numbers 5 through 8 and QSFP port 10 form a mutually exclusive set; Only one of them can operate at any given time – either the SFP/SFP+ port group or the QSFP port.

From the above, it follows that

- To use all 8 SFP or SFP+ ports, all QSFP ports must be disabled.
- To use both QSFP ports, all SFP or SFP+ ports must be disabled.
- To use SFP or SFP+ ports 1 through 4, QSFP port 9 must be disabled, and vice versa.
- To use SFP or SFP+ ports 5 through 8, QSFP port 10 must be disabled, and vice versa.

In addition to the above, this guideline applies to a redundant setup (dual supervisor) setup:






SFP or SFP+ port numbers 5 through 8 and QSFP port 10 of the active and standby supervisor modules are always inactive.




From the above, it follows that

- If QSFP port 9 is active on supervisor module 1 and inactive on supervisor module 2, SFP or SFP+ ports 1 through 4 are inactive on supervisor module 1 and active on supervisor module 2.
- If QSFP port 9 is active on supervisor module 2 and inactive on supervisor module 1, SFP or SFP+ ports 1 through 4 are inactive on supervisor module 2 and active on supervisor module 1.
- If QSFP port 9 is active on supervisor modules 1 and 2, SFP or SFP+ ports 1 through 4 on both supervisor modules are inactive.
- If QSFP port 9 is inactive on supervisor modules 1 and 2, SFP or SFP+ ports 1 through 4 on both supervisor modules are active.

The following table shows the major uplink redundancy port configurations; other port configurations are possible:

Table 4: Possible Uplink Port Configurations for C9400-SUP-1, C9400-SUP-1XL, and C9400-SUP-1XL-Y

No. of ports configured on active + No. of ports configured on standby	SFP Port numbers on Active Supervisor	SFP Port Numbers on Standby Supervisor	QSFP Port Numbers on Active Supervisor	QSFP Port Numbers on Standby Supervisor
<p>8 + 0 (standalone setup)</p>  <p>465287</p>	1 to 8	-	-	-
<p>2 + 0 (standalone setups)</p>  <p>465288</p>	-	-	9 and 10	-
<p>5 + 0 (standalone setup)</p>  <p>465289</p>	5 to 8	-	9	-
<p>5 + 0 (standalone setup)</p>  <p>465290</p>	1 to 4	-	10	-
<p>4 + 4 (redundant setup)</p>  <p>465291</p>	1 to 4	1 to 4	-	-

No. of ports configured on active + No. of ports configured on standby	SFP Port numbers on Active Supervisor	SFP Port Numbers on Standby Supervisor	QSFP Port Numbers on Active Supervisor	QSFP Port Numbers on Standby Supervisor
1 + 1 (redundant setup) 	-	-	9	9
4 + 1 (redundant setup) 	1 to 4	-	-	9
1 + 4 (redundant setup) 	-	1 to 4	9	-

Examples for Uplink Port Configuration

To use a QSFP port, enable the corresponding interface.

This example shows how to enable QSFP port number 9 to automatically disable port numbers 1 through 4.

Ensure that you specify the correct *supervisor* slot number when you configure the **interface fortygigabitethernet** command in global configuration mode. In the example below, the supervisor is installed in slot 3:

```
Device# configure terminal
Device(config)# interface fortygigabitethernet3/0/9
Device(config-if)# enable
```

To use an SFP or SFP+ port, disable the corresponding QSFP interface.

This example shows how to disable QSFP port number 9 to automatically enable port numbers 1 through 4:

```
Device# configure terminal
Device(config)# interface fortygigabitethernet3/0/9
Device(config-if)# no enable
```




Uplink Port Configuration for C9400X-SUP-2 and C9400X-SUP-2XL


Guidelines

- Port numbers 1 to 4 and port number 5 are mutually exclusive. This applies to a standalone setup and a redundant setup.
- Port numbers 7 and 8 are inactive in a redundant setup.
- Breakout cables are not supported on any of the uplink ports.

The following table shows the major uplink redundancy port configurations:

Table 5: Possible Uplink Port Configurations for C9400X-SUP-2 and C9400X-SUP-2XL

No. of Ports Configured on Active + No. of Ports Configured on Standby	SFP+ or SFP28 Port Numbers on Active Supervisor	SFP+ or SFP28 Port Numbers on Standby Supervisor	QSFP or QSFP28 Port Numbers on Active Supervisor	QSFP or QSFP28 Port Numbers on Standby Supervisor
7 + 0 (standalone setup) 	1 to 4	-	6 to 8	-
4 + 0 (standalone setup) 	-	-	5 to 8	-
5 + 5 (redundant setup) 	1 to 4	1 to 4	6	6

No. of Ports Configured on Active + No. of Ports Configured on Standby	SFP+ or SFP28 Port Numbers on Active Supervisor	SFP+ or SFP28 Port Numbers on Standby Supervisor	QSFP or QSFP28 Port Numbers on Active Supervisor	QSFP or QSFP28 Port Numbers on Standby Supervisor
2 + 2 (redundant setup) 	-	-	5 and 6	5 and 6

Examples for Uplink Port Configuration

To use a QSFP or QSFP28 port, enable the corresponding interface.

This example shows how to enable port number 5 and automatically disable port numbers 1 through 4.

Ensure that you specify the correct *supervisor* slot number when you configure the **interface hundredgigabitethernet** command in global configuration mode. In the example below, the supervisor is installed in slot 3:

```
Device# configure terminal
Device(config)# interface hundredgigabitethernet3/0/5
Device(config-if)# enable
```

To use an SFP+, or SFP28 port, disable the corresponding QSFP or QSFP28 port.

This example shows how to disable port number 5 and automatically enable port numbers 1 through 4:

```
Device# configure terminal
Device(config)# interface hundredgigabitethernet3/0/5
Device(config-if)# no enable
```

Installing Transceiver Modules and Cables

Use only Cisco modules on your Cisco device.

Supported Transceiver Media

For supported transceiver media types, refer to these documents on Cisco.com:

- [Cisco Gigabit Ethernet Transceiver Modules Compatibility Matrix](#)
- [Cisco 10-Gigabit Ethernet Transceiver Modules Compatibility Matrix](#)
- [Cisco 40-Gigabit Ethernet Transceiver Modules Compatibility Matrix](#)

Transceiver Cabling and Installation

Each port must match the wave-length specifications on the other end of the cable, and the cable must not exceed the stipulated cable length. For cabling specifications and installation information, refer to these documents on Cisco.com:

- [Cisco SFP and SFP+ Transceiver Module Installation Notes](#)
- To learn how to connect QSFP-40 GE transceiver modules with 10 GE, see the Cisco Optical Transceiver Tutorials series at this location: [QSFP-40 Gigabit Ethernet Optical Breakouts](#)

Related Reference Installation Information

- [Cisco Mode-Conditioning Patch Cord Installation Note](#)
- [Inspection and Cleaning Procedures for Fiber-Optic Connections](#)

Related Documentation

For related installation and configuration information, refer to the following:

Release and General Information

Release Notes: <https://www.cisco.com/c/en/us/support/switches/catalyst-9400-series-switches/products-release-notes-list.html>

Provides an overview of the hardware and software features introduced in every release, unsupported features, important restrictions and limitations, and open and resolved caveats with the software.

Hardware Documentation

- Hardware Installation Guide: https://www.cisco.com/c/en/us/td/docs/switches/lan/catalyst9400/hardware/install/b_c9400_hig.html
Provides a functional overview of the switch, describes how to install and rack-mount the switch, and make connections to the switch. It describes how to install the power supplies and how to replace the fan tray assembly. It also includes technical specifications and troubleshooting guidance.
- Supervisor Module Installation Note: https://www.cisco.com/c/en/us/td/docs/switches/lan/catalyst9400/hardware/sup_install/b-c9400-sup-note.html
Provides an overview of the available supervisor modules, major features, chassis compatibility information, slot restrictions, and describes how to correctly install and uninstall a supervisor module.
- Line Card Installation Note: https://www.cisco.com/c/en/us/td/docs/switches/lan/catalyst9400/hardware/sw_mod_install/b-c9400-mod-note.html
Provides an overview of the supported line cards, major features, describes how to correctly install and uninstall a line card, and transceiver support.
- Regulatory Compliance & Safety Information Document: <https://www.cisco.com/c/dam/en/us/td/docs/switches/lan/catalyst9400/hardware/regulatory/RCSI-0315-book.pdf>
Consolidated list of safety warnings relevant to Catalyst 9400 Series Switches (all chassis models), supervisor modules, line cards and any other hardware components.

Software Documentation

- Software Configuration Guide: <https://www.cisco.com/c/en/us/support/switches/catalyst-9400-series-switches/products-installation-and-configuration-guides-list.html>
Provides detailed software configuration information for the features supported on the switch. These guides are release-specific.

- Command Reference: <https://www.cisco.com/c/en/us/support/switches/catalyst-9400-series-switches/products-command-reference-list.html>

Provides command syntax, command history and usage guidelines for the Cisco IOS commands supported on the switch. These guides are release-specific.

Notices

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on standards documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
CiscoSystems(USA)Pte.Ltd.
Singapore

Europe Headquarters
CiscoSystemsInternationalBV
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.