

Product End-of-Life Disassembly Instructions

Product Category: Workstation 1U Chassis	
Marketing Name / Model [List multiple models if applicable.]	
HP ZCentral 4R Workstation/FCLSA-2001	

Purpose: The document is intended for use by end-of-life recyclers or treatment facilities. It provides the basic instructions for the disassembly of HP Inc. products to remove components and materials requiring selective treatment, as defined by EU directive 2012/19/EC, Waste Electrical and Electronic Equipment (WEEE).

NOTE: Recyclers should sort plastic materials into resin streams for recycling based on the ISO 11469 plastic marking code on the plastic part. For any questions on plastic marking or identification of location of parts or components requiring selective treatment, please contact <u>HP's Sustainability Contact</u>.

1.0 Items Requiring Selective Treatment

1.1 Items listed below are classified as requiring selective treatment. An "X" in the list of components and parts indicates the product contains the component or part requiring selective treatment

Item Description	Components and parts requiring selective treatments	Quantity of items included in product
Printed Circuit Boards (PCB) or Printed Circuit Assemblies (PCA) with a surface greater than 10 sq cm	 ✓ Main board (MB) PCB*1 ☐ Solid state drive (SSD) PCB ☐ Wireless WAN module (WWAN) PCB ☐ Touch module PCB ☒ Power supply PCB*4 ☒ External Keyboard (KB)*1 ☒ External Mouse*1 ☒ Graphic card PCB*1 ☒ Memory PCB *1 ☒ FIO Module PCB*1 ☒ HDD PCB*1 ☒ Riser transfer card PCB*1 	12
Batteries, excluding Li-Ion batteries. This includes standard alkaline, coin or button style batteries	☑ RTC/CMOS battery☐ Others:	1
Li-Ion batteries. Includes all Li-Ion batteries if more than one is provided with the product (such as a detachable notebook keyboard battery, etc.)	Li-ion battery(ies) are attached to the product by: ☐ screws ☐ snaps ☐ adhesive ☐ other. Explain	0

EL-MF877-00 Template Revision **D** Page 1

Item Description	Components and parts requiring selective treatments	Quantity of items included in product
Mercury-containing components. For example, mercury in lamps, display backlights, scanner lamps, switches, batteries		0
Liquid Crystal Displays (LCD) with a surface greater than 100 sq cm. Includes background illuminated displays with gas discharge lamps	☐ Panel LCD	0
Cathode Ray Tubes (CRT)		0
Capacitors / condensers (Containing PCB/PCT)		0
Electrolytic Capacitors / Condensers measuring greater than 2.5 cm in diameter or height	☑ Power Supply capacitor(s) or condenser(s)	1
External electrical cables and cords	☑ AC power cord☐ Audio, video or data cables☐ Other:	1
Gas Discharge Lamps		0
Plastics containing Brominated Flame Retardants (not including external electrical cables and cords, PCBs or PCAs already listed as a separate item above)		0
Components and parts containing toner and ink, including liquids, semi-liquids (gel/paste) and toner. Include the cartridges, print heads, tubes, vent chambers, and service stations.		0
Components and waste containing asbestos		0
Components, parts and materials containing refractory ceramic fibers		0
Components, parts and materials containing radioactive substances		0
Components containing chlorofluorocarbons (CFC), hydrochlorofluorocarbons (HCFC) or hydrofluorocarbons (HFC), hydrocarbons (HC)		0
2.0 Tools Required		
List the type and size of the tools that would typically be components and materials requirin selective treatment of tool Description	Tool Size (if	
Screwdriver	applicable))hilim #4 - #2
		Philip #1 or #2
Screwdriver		Torx T15

Page 2

Heatgun	N/A
Suction cup	N/A

3.0 Product Disassembly Process

3.1 List the basic steps that should typically be followed to remove components and materials requiring selective treatment including the required steps to remove the external enclosure.

- 1. Open access panel
- 2. Remove the cage from host up
- 3. Use PH1 screwdriver to loose the screws and remove the heatsink
- 4. Rotate the handle and open it up
- 5. Remove the CPU from the board
- 6. Remove memory from MB
- 7. Remove Graphic card from host up
- 8. Use PH1screwdriver to loose the screws
- 9. Press the Graphic card's latch and Remove it. The Graphic card area>10 sq cm
- 10. Use PH1 screwdriver to loose the screws and remove the PCIe card. See below PCIe Card PCB area>10 sq cm.
- 11. Use PH1 screwdriver to loose the screws and remove the cable
- 12. Use PH1 screwdriver to loose the screws and remove the iron
- 13. Use PH1 screwdriver to loose the screws and remove the iron.
- 14. Disconnect fan cable from MB.
- 15. Remove the fans
- 16. Disconnect cables from convert board
- 17. Use PH1 screwdriver to loose the screws and remove the iron
- 18. Press the button and remove the cable
- 19. Disconnect all cables from MB
- 20. Use PH1 screwdriver to loose the screws from board.
- 21. Remove MB from chassis
- 22. Remove the battery from the system board
- 23. Use PH1 screwdriver to loose the screws and remove the led flatiron
- 24. Press the bottom
- 25. Remove the HDD
- 26. Press the convert board latch
- 27. Remove convert board from the cage, See below PCB area>10 sq cm.
- 28. Press the PSU's latch on chassis and remove the PSU from chassis
- 29. Disconnect the speaker cable
- 30. Loose the 2 screws of speaker and remove it
- 31. Remove the front UI/Audio ASSY cable from hook
- 32. Disconnect front UI/Audio ASSY cable from PCA
- 33. Press the 4 latch and remove the front UI/Audio ASSY cable from FIO module
- 34. Loose the 4 screws of PCA and remove the PCA from FIO module. See below PCA area>10 sq cm.
- 35. Press the latch and remove the SD card holder from FIO module
- 36. Press the latch and remove the bezel from FIO module
- 37. Remove two small air ducts
- 38. Remove air duct
- 39. Remove rack hand brackets by screwdriver T15
- 40. Remove CABLE, GFX POWER, 8PIN, Z4 G4 RACK WS
- 41. Remove internal AC cable by drill to rivets

EL-MF877-00

Page 3


Template Revision **D**

- 42. Remove metal bracket of internal AC cable
- 43. Remove 2.5"HDD rail
- 44. Remove EMI shield and metal bracket
- 45. Remove cable bracket by screwdriver T15
- 46. Remove M2 bracket by screwdriver T15
- 47. Remove USB Cable
- 48. Remove audio cable
- 49. Remove Fans
- 50. Press latch to Remove Cable, HDD PWR Signal-Bay0-1, Z4 G4 Rack WS
- 51. Remove HDD cable bracket by screwdriver T15
- 52. Remove HDD cable 1-3 from metal bracket
- 53. Remove cable safety interlock Switch bracket by screwdriver T15
- 54. Remove Cable, Safety Interlock Switch, Z4 G4 Rack WS byScrewdriver Philip #1
- 55. Remove LED cable assembly by screwdriver T15
- 56. Remove LED Light pipe
- 57. Press the PSU's latch to remove PSU from Chassis
- 58. USE PH1 to unscrew five screws to loosen top cover
- 59. Slide top cover to unhook bottom chassis before top cover removal
- 60. Remove top cover from bottom chassis
- 61. Remove the Mylar from top cover by hand-pulling
- 62. Use PH1 to unscrew six screws to loosen PCBA from bottom chassis
- 63. Disconnect fan cable connector and LED cable connector from PCBA
- 64. Remove PCBA away from bottom chassis
- 65. Heat the solder of the Electrolytic Capacitors of greater than 2.5cm in diameter or height and Remove it
- 66. Remove the Mylar from bottom chassis by hand pulling
- 67. Use PH1 to unscrew two screws to loosen handle released module from bottom chassis
- 68. Use PH1 to unscrew on cross screw and tool#3 to unscrew one torx screw
- 69. Remove metal handle away from handle-released module
- 70. Slide handle-released module awany from bottom chassis.
- 71. No more treatment for bottom chassis and fan bracket
- 72. Identity PCBA > 10 cm2 for further treatment (DC-DC board: 33.79 cm2)
- 73. Identity PCBA > 10 cm2 for further treatment (AUX board:20.77 cm2).
- 74. Identity PCBA > 10 cm2 for further treatment (main board: 135 cm2).
- 75. Identity PCBA > 10 cm2 for further treatment (EMI board: 63.45 cm2).
- 76. Identity PCBA > 10 cm2 for further treatment (UP board: 13.64 cm2).
- 77. Identity electrolyte capacitor > 2.5 cm for further treatment (Length: 4 cm).
- 3.2 Location of components requiring selective treatment. The photos and/or graphics below identify the location of the parts or components requiring selective treatment within the main unit. For End-of-Life product disassembly instructions of external accessories including external power supply (EPS), external keyboard (KB) external mouse and external cables and cords, refer to the following URL: End-of-Life Product Disassembly Instructions (hp.com)

Step1 Open access panel



Step2 Remove the cage from host up.



Step3 Use PH1 screwdriver to loose the screws and remove the heatsink



Step4 Rotate the handle and open it up.



Step5 Remove the CPU from the board



Step6 Remove memory from MB.



See below Memory PCB area>10 sq cm.



Step7 Remove Graphic card from host up



Step8 Use PH1screwdriver to loose the screws



Step9 Press the Graphic card's latch and Remove it. The Graphic card area>10 sq cm




Step10 Use PH1 screwdriver to loose the screws and remove the Riser transfer card . See below the card PCB area>10 sq cm.





Step11 Use PH1 screwdriver to loose the screws and remove the cable




Step12 Use PH1 screwdriver to loose the screws and remove the iron




Page 6

Step13 Use PH1 screwdriver to loose the screws and remove the iron.



Step14 Disconnect fan cable from MB.



Step15 Remove the fans



Step16 Disconnect cables from convert board.



Step17 Use PH1 screwdriver to loose the screws and remove the iron



Step18 Press the button and remove the cable



 $Step 19 \ {\tt Disconnect\ all\ cables\ from\ MB}$



Step21 Remove MB from chassis



Step22 Remove the battery from the system board

 $Step 20 \ \ \text{Use PH1 screwdriver to loose the screws from board}.$




Step23 Use PH1 screwdriver to loose the screws and remove the led flatiron



Step24 Press the bottom



Step25 Remove the HDD



Step26 Press the convert board latch



Step27 Remove convert board from the cage, See below PCB area>10 sq cm.



Step28 Press the PSU's latch on chassis and remove the PSU from chassis




Figure 29 Disconnect the speaker cable




Figure 30 Loose the 2 screws of speaker and remove it




Figure 31 Remove the front UI/Audio ASSY cable from hook




Figure 33 Press the 4 latch and remove the front UI/Audio ASSY cable from FIO module



Figure 32 Disconnect front UI/Audio ASSY cable from PCA


Figure 34 Loose the 4 screws of PCA and remove the PCA from FIO module. See below PCA area>10 sq cm.



 $\label{lem:problem} \mbox{Figure35 Press the latch and remove the SD card holder } \mbox{from FIO module}$



Figure 36 Press the latch and remove the bezel from FIO module



EL-MF877-00 Template Revision **D** Page 10








Step38 Remove air duct

Step39 Remove rack hand brackets by screwdriver T15













Step42 Remove metal bracket of internal AC cable





EL-MF877-00 Template Revision **D** Page 11











Step47 Remove USB Cable









Page 12

Step49 Remove Fans





Step50 Press latch to Remove Cable, HDD PWR Signal-Bay0-1, Z4 G4 Rack WS








Step51 Remove HDD cable bracket by screwdriver T15







Step52 Remove HDD cable1-3 from metal bracket





Step53 Remove cable safety interlock Switch bracket by screwdriver T15







Step54 Remove cable, Safety Interlock Switch, Z4 G4 Rack WS by Screwdriver Philip #1







EL-MF877-00 Page 13 Template Revision **D**

Step55 Remove LED cable assembly by screwdriver T15

Step56 Remove LED Light pipe

Step57 Press the PSU's latch to remove PSU from Chassis



Step58 USE PH1 to unscrew five screws to loosen top cover



Step59 Slide top cover to unhook bottom chassis before top cover removal



Step60 Remove top cover from bottom chassis



Page 14

Step61 Remove the Mylar from top cover by hand-pulling



Step62 Use PH1 to unscrew six screws to loosen PCBA from bottom chassis.




Step63 Disconnect fan cable connector and LED cable connector from PCBA




Step64 Remove PCBA away from bottom chassis.



Step65 Heat the solder of the Electrolytic Capacitors of greater than 2.5cm in diameter or height and Remove it



Step66 Remove the Mylar from bottom chassis by hand pulling



Page 15

Step67 Use PH1 to unscrew two screws to loosen handle released module from bottom chassis



Step68 Use PH1 to unscrew on cross screw and tool#3 to unscrew one torx screw



Step69 Remove metal handle away from handle-released module




Step70 Slide handle-released module awany from bottom chassis.



Step71 No more treatment for bottom chassis and fan bracket



Step72 Identity PCBA > 10 cm2 for further treatment (DC-DC board: 33.79 cm2).




EL-MF877-00 Template Revision **D**


Step73 Identity PCBA > 10 cm² for further treatment (AUX board:20.77 cm²).




Step74 Identity PCBA > 10 cm² for further treatment (main board: 135 cm²).



Step75 Identity PCBA > 10 cm² for further treatment (EMI board: 63.45 cm²).



Step76 Identity PCBA > 10 cm² for further treatment (UP board: 13.64 cm²).



Step77 Identity electrolyte capacitor > 2.5 cm for further treatment (Length: 4 cm).

