



AC1200 MU-MIMO Dual Band Gigabit WiFi Router · AC10 / AC10U

User Guide

Copyright Statement

© 2018 Shenzhen Tenda Technology Co., Ltd. All rights reserved.

Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Copyright of the whole product as integration, including its accessories and software, belongs to Shenzhen Tenda Technology Co., Ltd. No part of this publication can be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means without the prior written permission of Shenzhen Tenda Technology Co., Ltd.

Disclaimer

Pictures, images and product specifications herein are for references only. To improve internal design, operational function, and/or reliability, Tenda reserves the right to make changes to the products without obligation to notify any person or organization of such revisions or changes. Tenda does not assume any liability that may occur due to the use or application of the product described herein. Every effort has been made in the

preparation of this document to ensure accuracy of the contents, but all statements, information and recommendations in this document do not constitute a warranty of any kind, express or implied.

Preface



Thank you for choosing Tenda! Please read this user guide before you start with AC10/AC10U.

Conventions

The typographical elements that may be found in this document are defined as follows.

Item	Presentation	Example
Cascading menus	>	System > Live Users
Parameter and value	Bold	Set User Name to Tom .
Variable	Italic	Format: <i>XX:XX:XX:XX:XX</i>
UI control	Bold	On the Policy page, click the OK button.
Message	“ ”	The “Success” message appears.

The symbols that may be found in this document are defined as follows.

Symbol	Meaning
 NOTE	This format is used to highlight information of importance or special interest. Ignoring this type of note may result in ineffective configurations, loss of data or damage to device.
 TIP	This format is used to highlight a procedure that will save time or resources.

Picture of **AC10U** is used for guidance in network topologies in this user guide.

Acronyms and Abbreviations

Acronym or Abbreviation	Full Spelling
ISP	Internet Service Provider
VPN	Virtual Private Network
WPS	WiFi Protected Setup
IPTV	Internet Protocol Television

PPPoE	Point-to-Point Protocol over Ethernet
DHCP	Dynamic Host Configuration Protocol
DNS	Domain Name System
AP	Access Point
WISP	Wireless Internet Service Provider
PPTP	Point to Point Tunneling Protocol
L2TP	Layer 2 Tunneling Protocol
MPPE	Microsoft Point-to-Point Encryption
PPP	Point To Point Protocol
DDNS	Dynamic Domain Name System
DMZ	Demilitarized Zone
VLAN	Virtual Local Area Network

Additional Information

For more information, search this product model on our website at <http://www.tendacn.com>.

Technical Support

If you need more help, contact us by any of the following means. We will be glad to assist you as soon as possible.



Hotline

Global: (86) 755-27657180

United States: 1-800-570-5892

Canada: 1-888-998-8966

Hong Kong: 00852-81931998



Website

<http://www.tendacn.com>

<http://www.tendaus.com>



Email

support@tenda.com.cn

support.usa@tenda.com.cn

Contents

1	Introduction	1
	1.1 Overview	1
	1.2 Appearance	2
2	Set up to access the internet	6
	2.1 Setting the new router to access the internet	6
	2.2 Replacing original router with AC10/AC10U	11
3	Web UI description	18
	3.1 Logging in to the web UI of the router	18
	3.2 Logging out of the web UI of the router	19
4	Internet Status	20
	4.1 Network status	20
	4.2 Online device/USB/WiFi extender	21
	4.3 WiFi information	24
	4.4 Other information	26
5	Internet Settings	27
	5.1 Overview	27
	5.2 Setting up an internet connection with PPPoE	28
	5.3 Setting up an internet connection with a dynamic IP address	30
	5.4 Set up an internet connection with a static IP address	31
6	WiFi Settings	33
	6.1 WiFi Name & Password	33
	6.2 WiFi Schedule	36
	6.3 Wireless Repeating	38
	6.4 Channel & Bandwidth	42
	6.5 Transmit Power	44
	6.6 WPS	46
	6.7 Beamforming+	51

6.8 AP Mode	52
6.9 Anti-interference.....	55
7 Guest Network.....	56
7.1 Overview.....	56
7.2 Setting guest network.....	57
8 Parental Control.....	58
8.1 Overview.....	58
8.2 Setting parental control rules	59
9 VPN	63
9.1 PPTP Server.....	63
9.2 Online PPTP Users.....	70
9.3 PPTP/L2TP Client.....	71
10 USB App	74
10.1 Overview.....	74
10.2 Modifying role information.....	78
10.3 Accessing USB resources through FTP/Samba servers	80
11 Advanced Settings	86
11.1 Bandwidth Control.....	86
11.2 Tenda App	87
11.3 Sleeping Mode	91
11.4 LED Control	92
11.5 Filter MAC Address	93
11.6 Firewall.....	97
11.7 IPTV	99
11.8 Static Route.....	101
11.9 DDNS.....	105
11.10 Virtual Server	110
11.11 DMZ Host	115
11.12 UPnP	116
12 System Settings.....	118

12.1 LAN Settings	118
12.2 DHCP Reservation	120
12.3 WAN Settings	122
12.4 Time Settings	124
12.5 Login Password	125
12.6 Reboot and Reset.....	126
12.7 Firmware Upgrade	128
12.8 Backup/Restore.....	130
12.9 Remote Management	131
12.10 System Status.....	134
12.11 System Log	137
12.12 Automatic Maintenance	138
Appendixes	141
A.1 Setting the IP address of your computer	141
A.2 FAQ	145

1

Introduction

1.1 Overview

AC10/AC10U is a high-performance router dedicated to fiber users. With the new 802.11ac wave2.0 standard and four 6 dBi high-gain external antennas, AC10/AC10U offers simultaneous dual-band data rate of as high as 1167 Mbps. With Beamforming+ technology, AC10/AC10U features robust wall penetration capacity, making full use of the FTTH's advantage. The integration of technology MU-MIMO also makes AC10/AC10U support more devices at one time, creating faster and better network for you.

Features

- Supports 4 gigabit auto-negotiation ports.
- Supports the MU-MIMO technology.
- With 4 external omnidirectional antennas.
- Supports to enable/disable the WiFi network of the router at a press of the **WiFi** button.
- Supports WiFi Schedule to disable the WiFi network of the router at specified period.
- Supports 12 V dc 1 A (for AC10), and 12 V dc 1.5 A (for AC10U) power output.
- With a wireless data rate of as high as 1167 Mbps.
- Supports Wireless Repeating and Bandwidth Control.
- Supports migration of ISP user name and password for quick setup.
- Supports remote management with **Tenda WiFi** App.

1.2 Appearance


1.2.1 Front panel



LED indicator	LED indicator name	Status	Description
SYS	System / USB LED indicator	Solid on	<ul style="list-style-type: none">The router is starting.If the indicator is still solid on after your router completes startup, it indicates that the system is faulty.
		Slowing blinking	The system is working properly.
		Fast blinking twice (AC10U only)	A portable USB device is connected to the USB port.
WAN	WAN LED indicator	Fast blinking	Data is being transmitted over the WAN port.
		Fast blinking (AC10U only)	Data is being transmitted over the WAN port.
		Off	The WAN port is disconnected or connected improperly.
LAN	LAN LED indicator	Solid on	Port 1, 2 or 3 is connected properly.
		Blinking twice	A device is connected to port 1, 2 or 3.
		Off	None of ports 1, 2 and 3 is connected or connected properly.
WiFi	WiFi / WPS LED indicator	Solid on	At least the 2.4 GHz or 5 GHz WiFi network is enabled.
		Fast blinking	Data is being transmitted wirelessly.

LED indicator	LED indicator name	Status	Description
		Slow blinking	The router is performing WPS negotiation.
		Off	The WiFi network is disabled.

1.2.2 Rear panel



AC10





AC10U

Port/Button	Description
WiFi	Used to enable/disable the WiFi network of the router.
RST/WPS	Used to start the WPS negotiation process of the router, or to reset the router. <ul style="list-style-type: none"> – WPS: Press the button of the router, and enable the WPS function of another device within 2 minutes to establish a WPS connection. – Reset: When the SYS indicator blinks, hold the button down for about 8 seconds. The router is reset successfully when the SYS indicator lights solid on.
3	By default, it is a LAN port. But after the IPTV function of the router is enabled, it functions only as an IPTV port used to connect to a set-top box.
1/2	They are LAN ports used to connect to devices such as computers and switches.
WAN	Used to connect this router to the internet.
POWER	Used to connect to the power adapter included with the package.
USB (AC10U only)	Used to connect to a portable USB device.

1.2.3 Label on the bottom of the router

The bottom label shows the SSID, WiFi password and login IP address/domain name, pin code of the router. See the following figures:





(1): It specifies the login IP address/domain name of the router. You can use this IP address/domain name to access the web UI of the router.

(2): It specifies the serial number of the router. If the router is faulty, you need to provide this serial number for repair.

(3): It specifies the default SSID of the router's WiFi network.

- When you use AC10/AC10U for the first time, connect smart phone or other wireless devices to this SSID to set up your router.
- After the router is connected to the internet, if this SSID is not changed, wireless devices (such as smart phones) connect to this SSID to access the internet. Otherwise, use the SSID and password you set to access the internet.

(4): It specifies the default WiFi password of the router.

- When you use AC10/AC10U for the first time, wireless devices connect the router's WiFi network using this WiFi password to set up internet access.
- After the router is connected to the internet, if this password is not changed, wireless devices (such as smart phones) connect the router's WiFi network using this WiFi password. Otherwise, use the SSID and password you set to access the internet.

(5): It specifies the pin code of the router. When you connect a device to the router by WPS, this pin code is required.

2

Set up to access the internet

2.1 Setting the new router to access the internet

2.1.1 Setting up on phone

Step 1 Connect devices.

1. Power on the router using the power adapter included in the package.
2. Plug the Ethernet cable that has connected to the internet into the WAN port of the router.




3. Connect your smart phone to the WiFi network of the router using the WiFi name and password labeled on the bottom of the router.



Step 2 Set up the router.

1. Start a web browser on the phone that has connected to the router, and visit tendawifi.com.




2. Tap **Start**.




3. The system detects your connection type automatically. Set the parameters based on your situation. (PPPoE is used for instructions.)

- **ISP User Name:** Enter the user name provided by your ISP.
- **ISP Password:** Enter the password provided by your ISP.



4. Tap **Next**.


5. Set the WiFi name, WiFi password, and login password.



6. Tap **Next**.

--End

Wait a moment. Connected. Connect wireless devices to the WiFi network of the router again using the WiFi name and password you set to access the internet. Wired devices can access the internet directly if they have connected to port 1, 2 or 3.



For more functions, refer to relevant contents in this user guide.

2.1.2 Setting up on computer

Step 1 Connect devices.

1. Power on the router using the power adapter included in the package.
2. Plug the Ethernet cable that has connected to the internet into the WAN port of the router.



3. Connect your computer to port 1, 2 or 3 of the router using an Ethernet cable.




A desktop computer can connect to the WiFi network of the router only when it is installed with a wireless adapter.

Step 2 Set up the router.

1. Start a web browser on the computer that has connected to the router. Enter **tendawifi.com** in the address bar and press **Enter**.



2. Click **Start**.



3. The system detects your connection type automatically. Please set the relevant parameters based on your actual situation. (PPPoE is used as an example for instructions here.)

- **ISP User Name:** Enter the user name provided by your ISP.
- **ISP Password:** Enter the password provided by your ISP.

The image shows a screen titled 'Please select your connection type.' Below the title, it says 'As detected, your connection type may be: PPPoE'. There are three input fields: 'Connection Type:' with a dropdown menu showing 'PPPoE', 'ISP User Name:' with a text box containing the placeholder 'Enter the user name from your ISP.', and 'ISP Password:' with a text box containing the placeholder 'Enter the password from your ISP.'. Below these fields, there is a blue link that says 'Import PPPoE user name and password from the original router.'. At the bottom, there is a green button labeled 'Next'.


4. Click **Next**.

5. Set the WiFi name (SSID), WiFi password and login password.

6. Click **Next**.

--End

Wait a moment. Connected. Connect wireless devices to the WiFi network of the router again using the WiFi name and password you set to access the internet. Wired devices can access the internet directly if they have connected to port 1, 2 or 3.



For more functions of the router, click **More**.

2.2 Replacing original router with AC10/AC10U

This setup method applies to users who use new routers to replace their original routers with PPPoE user names and passwords, which can migrate user names and passwords from original routers to new routers quickly.

2.2.1 Setting up on phone

Step 1 Migrate your PPPoE user name and password from your original router.

1. Power on your original and new routers.
2. Connect the WAN port of the original router to port 1, 2 or 3 of the new router using an Ethernet cable.

When the LAN and WAN indicators of the new router light solid on for 3 seconds after blinking fast, your PPPoE

user name and password are migrated successfully.

3. Remove the original router.



Step 2 Connect devices.

1. After successful migration, plug the Ethernet cable that has connected to the internet into the WAN port of the new router.
2. Connect your wireless device such as a smart phone to the WiFi network of the new router using the WiFi name and password on the bottom label of the router.




Step 3 Set up the router.


1. Start a web browser on the phone that has connected to the router, and visit **tendawifi.com**.




2. Tap **Start**.



3. The system populates your PPPoE user name and password automatically. Tap **Next**.




4. Set the WiFi name (SSID), WiFi password and login password.



5. Tap **Next**.

--End

Wait a moment. Connected. Connect wireless devices to the WiFi network of the router again using the WiFi name and password you set to access the internet. Wired devices can access the internet directly if they have connected to port 1, 2 or 3.



For more functions, refer to relevant contents in this user guide.

2.2.2 Setting up on computer

Step 1 Migrate your PPPoE user name and password from your original router.

1. Power on your original and new routers.
2. Connect the WAN port of the original router to port 1, 2 or 3 of the new router using an Ethernet cable.

When the LAN and WAN indicators of the new router light solid on for 3 seconds after blinking fast, your PPPoE user name and password are migrated successfully.

3. Remove the original router.



Step 2 Connect devices.

1. After successful migration, connect WAN port of the new router to an Ethernet cable that has connected to the internet.
2. Connect your computer to port 1, 2 or 3 of the new router using an Ethernet cable.




A desktop computer can connect to the WiFi network of the router only when it is installed with a wireless adapter

Step 3 Set up the router.

1. Start a web browser on the computer that has connected to the router. Enter **tendawifi.com** in the address bar and press **Enter**.



2. Click **Start**.



3. The system populates your PPPoE user name and password automatically. Click **Next**.

A screenshot of the 'Please select your connection type.' screen. It shows 'As detected, your connection type may be: PPPoE'. The 'Connection Type' dropdown is set to 'PPPoE'. The 'ISP User Name' field contains 'chenhao' and the 'ISP Password' field contains seven dots. A green message states: 'The PPPoE user name and password have been imported from the original router.' A green 'Next' button is at the bottom.

4. Set the WiFi name (SSID), WiFi password and login password.

WiFi Settings

Not Required

Set the WiFi password as the login password of the admin account.


Not Required

[Next](#)

5. Click **Next**.

--End

Wait a moment. Connected. Connect wireless devices to the WiFi network of the router again using the WiFi name and password you set to access the internet. Wired devices can access the internet directly if they have connected to port 1, 2 or 3.



If you want to configure more functions of the router, click **More**.

3

Web UI description


3.1 Logging in to the web UI of the router

This section describes how to log in to the web UI of the router to manage your router. For the first time to set up your router, refer to [Chapter 2 Set up to access the internet](#) for instructions.

1. Start a web browser on the computer connected to your router. Enter **tendawifi.com** in the address bar, and press **Enter**.



2. Enter the login password of your router, and click **Login**.




--End



If the figure above does not appear, set the **Local Area Connection** of your computer to **Obtain an IP address automatically** and **Obtain DNS server address automatically**. For detailed setting steps, refer to [A.1 Setting the IP address of your computer](#) in appendixes. Then try logging in again.

Log in to the web UI of the router successfully. See the following figure:



3.2 Logging out of the web UI of the router

If you log in to the web UI of the router and perform no operation within 5 minutes, the router logs you out. In addition, click **Exit** on the upper right corner of the web UI can log out as well.


4


Internet Status

The **Internet Status** page allows you to view the network status of the router, online devices, WiFi information and other status information.

4.1 Network status

This page shows the current network status of the router.


When the internet icon  is displayed, the router is connected to the internet successfully and devices can access the internet through the router.



Parameter description:


Parameter	Description
Current Speed	The upload and download rates of the WAN port.
WAN IP Address	The IP address of the WAN port.
Firmware Version	It specifies the current firmware version of the router. After upgrading the firmware version of the router, you can view the current firmware version here to check whether the upgrade is successful.

When **Connection failed** is displayed, click **Connection failed** to enter the **Internet Settings** page, and perform according to the onscreen instructions to solve the issue.




4.2 Online device/USB/WiFi extender

The right part of the **Internet Status** page shows the number of portable USB device inserted into the router, online devices, and gets you to know more about WiFi extender.




4.2.1 Online device

Click **Online** to find detailed information about online devices. See the following figure:



Add to Blacklist


Click **Add to Blacklist** to add unknown devices to the blacklist. Devices in the blacklist cannot access the internet through the router.



Remove from Blacklist


To remove a device from the blacklist, click **Online** on the **Internet Status** page. Then click **Blacklist** on the **Manage Device** page and locate the corresponding device. Click **Remove**.

Devices removed from the blacklist can access the internet through the router.




4.2.2 USB


Click **USB** to view detailed information about the USB devices connected to the router.




If a USB device is connected to your router, the USB page appears as follows: (USB Kingston DT 101 G2 is used as an example here)



To disconnect your USB, click **Unmount**.




After you disconnect your USB device, the USB page appears as follows:





For detailed information about USB function of your router (Only **AC10U** supports USB function), click **USB App Center** to access the **USB App** page.

4.3 WiFi information

The upper-right part of the **Internet Status** page displays the WiFi names (SSIDs) of 2.4 GHz and 5 GHz WiFi networks. After the router accesses the internet, you can connect wireless devices to 2.4 GHz and 5 GHz WiFi network SSIDs to access the internet.



To change WiFi names or passwords of 2.4/5 GHz WiFi network, click  on the **Internet Status** page, and configure the parameters on the **WiFi Settings** page. See the figure below:





Set your WiFi names and passwords. If WiFi password is not set before, you need to select the encryption mode before setting the WiFi password. After configuring the parameters, click **Save**. Refer to [Chapter 6 WiFi Name and Password](#) for detailed instructions.



Only devices supporting 5 GHz signal can scan and connect to the 5 GHz WiFi network of the router. You are recommended to encrypt your wireless network for higher network security.

4.4 Other information

Click the router icon  on **Internet Status** page. You can know more about the basic information, WAN port status, LAN port status and WiFi status of the router. See [Chapter 12 System Settings](#) for detailed parameter information.



5

Internet Settings

5.1 Overview

This page allows you to set internet parameters. Generally, the router detects your internet connection type automatically when you use the router for the first time or after you reset the router. You are recommended to select the detected connection type and follow the onscreen instructions to finish internet setup.

The following table may help you understand your internet connection type. If you are still uncertain about your internet connection type, consult your ISP.

Connection Type	Description
PPPoE	ISP user name and password are provided by your ISP.
Dynamic IP Address	Your ISP does not provide ISP user name, password or other information about IP address.
Static IP Address	Your ISP provides IP address, subnet mask, default gateway, DNS server(s).

To access the configuration page, click **Internet Settings**. PPPoE is used as an example here.

The screenshot shows the 'Internet Settings' configuration page. At the top left, there is a globe icon and the text 'Internet Settings'. At the top right, there is a language dropdown set to 'English' and an 'Exit' button. Below this, the 'WAN Port' is set to 'Ethernet cable connected'. The 'Connection Type' is a dropdown menu set to 'PPPoE'. The 'ISP User Name' is a text input field containing 'chenhao'. The 'ISP Password' is a text input field with masked characters '.....'. The 'DNS Settings' is a dropdown menu set to 'Automatic'. Below these fields, the 'Connection Status' is 'Connected. You can access the internet now.' and the 'Connection Duration' is '35s'. At the bottom center, there is a green 'Disconnect' button.

Parameter description:

Parameter	Description
WAN Port	It specifies the current status of the WAN port of the router, including Ethernet cable connected and Ethernet cable disconnected .
Connection Type	It specifies how the router is connected to the internet. This router supports three connection types: PPPoE, dynamic IP address, and static IP address. Please select your connection type according to your actual situation.
ISP User Name	Enter the user name provided by your ISP.
ISP Password	Enter the password provided by your ISP.
DNS Settings	It specifies how the router obtains DNS information. This item is only needed when you choose to connect the router to the internet by PPPoE or dynamic IP address. <ul style="list-style-type: none">- Automatic: The router obtains DNS information from upstream device automatically.- Manual: You need to enter correct DNS information manually.
IP Address	
Subnet Mask	
Default Gateway	The information is required only when you choose to connect the router to internet by static IP address. Enter the IP address and other information provided by your ISP manually.
Primary DNS Server	
Secondary DNS Server	
Connection Status	It specifies whether the router is connected to the internet. If the “Connected. You can access the internet now.” message appears, the router is connected to the internet successfully and you can access the internet through your router. Otherwise, the router fails to connect to the internet. Please perform according to the onscreen instructions.
Connection Duration	It specifies how long the router is connected to the internet successfully this time.

5.2 Setting up an internet connection with PPPoE

Procedures:

1. Click **Internet Settings**.
2. **Connection Type:** Select **PPPoE** from the drop-down list box.
3. **ISP User Name:** Enter the user name provided by your ISP.
4. **ISP Password:** Enter the password provided by your ISP.
5. Click **Connect**.

WAN Port: Ethernet cable connected

Connection Type:

ISP User Name:

ISP Password:

DNS Settings:

--End

Verification

Assume that the ISP user name is chenhao, and password is 1234567. If the “Connected. You can access the internet now.” message appears, you can access the internet through the router in a wired or wireless manner.

WAN Port: Ethernet cable connected

Connection Type:

ISP User Name:

ISP Password:

DNS Settings:


Connection Status: **Connected. You can access the internet now.**

Connection Duration: 9s

5.3 Setting up an internet connection with a dynamic IP address

Procedures:

1. Click **Internet Settings**.
2. **Connection Type**: Select **Dynamic IP**.
3. Click **Connect**.



WAN Port: Ethernet cable connected

Connection Type:


DNS Settings:

Connection Status: **Disconnected**

--End

Verification

If the “Connected. You can access the internet now.” message appears, you can access the internet through the router in a wired or wireless manner.



WAN Port: Ethernet cable connected

Connection Type:

DNS Settings:

Connection Status: **Connected. You can access the internet now.**

Connection Duration: 10s

5.4 Set up an internet connection with a static IP address

Procedures:

1. Click **Internet Settings**.
2. **Connection Type:** Click **Static IP Address**.
3. **IP Address, Subnet Mask, Default Gateway and Primary/Secondary DNS Server:** Enter the relevant information provided by your ISP. Assume that the IP address in this example is 192.168.20.1, subnet mask 255.255.255.0, default gateway and primary DNS server 192.168.20.100.
4. Click **Connect**.



WAN Port: Ethernet cable connected

Connection Type: Static IP Address

IP Address: 192.168.20.1

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.20.100

Primary DNS Server: 192.168.20.100

Secondary DNS Server:

Connect

--End

Verification

If the “Connected. You can access the internet now.” message appears, you can access the internet through the router in a wired or wireless manner.

WAN Port: Ethernet cable connected

Connection Type: ▼

IP Address:

Subnet Mask:

Default Gateway:

Primary DNS Server:

Secondary DNS Server:

Connection Status: **Connected.** You can access the internet now.

Connection Duration: 1min 16s

6 WiFi Settings

This module includes the following functions: [WiFi Name & Password](#), [WiFi Schedule](#), [Wireless Repeating](#), [Channel & Bandwidth](#), [Transmit Power](#), [WPS](#), [Beamforming+](#), [AP Mode](#), and [Anti-interference](#).

6.1 WiFi Name & Password

6.1.1 Overview

This router supports 2.4 GHz and 5 GHz WiFi signals. Features of these two signals are listed as follows:

- 2.4 GHz signal has longer wireless transmission distance than 5 GHz signal.
- 2.4 GHz signal has better wall penetration capacity than 5 GHz signal.
- 5 GHz signal has higher wireless transmission speed than 2.4 GHz signal.
- Comparing with 5 GHz, 2.4 GHz signal is more crowded, interrupted, but less stable.

You can set the WiFi names, encryption modes, and WiFi passwords for two WiFi networks on the **WiFi Name & Password** page. To access the configuration page, click **WiFi Settings > WiFi Name & Password**.

WiFi Name & Password

2.4 GHz Network

WiFi Name: Tenda_0A7E80 Hide

Encryption Mode: WPA/WPA2-PSK (recommend)

WiFi Password:

5 GHz Network

WiFi Name: Tenda_0A7E80_5G Hide

Encryption Mode: WPA/WPA2-PSK (recommend)

WiFi Password:

Save

Parameter description:

Parameter	Description
2.4 GHz/ 5 GHz Network	Used to enable/disable the 2.4 GHz/5 GHz WiFi network of your router.
WiFi Name	It specifies the name of 2.4 GHz/5 GHz WiFi network. You can change it if needed. After the router connects to the internet, wireless devices can surf the internet by connecting to the

	WiFi name.
Encryption Mode	<p>It specifies the encryption modes supported by the router, including:</p> <ul style="list-style-type: none"> - None: It indicates that the wireless network is not encrypted so that any wireless devices can connect to it. This option is not recommended as it leads to low network security. - WPA-PSK: It indicates that the WiFi network uses WPA-PSK/AES as its authentication method. - WPA2-PSK: It indicates that the WiFi network uses WPA2-PSK/AES as its authentication method. - WPA/WPA2-PSK (Recommended): It indicates that the WiFi network uses the mixed authentication method of WPA-PSK/AES and WPA2-PSK/AES as its authentication method.
WiFi Password	It specifies the WiFi password which is required when your wireless devices try connecting to the WiFi network.
Hide	<p>It specifies whether to prevent the WiFi name from being detected by wireless devices.</p> <p>If the box beside Hide is checked, the router does not broadcast the WiFi signal. The WiFi name does not appear in the devices' lists of available networks, either. When wireless devices connect to the WiFi network, users should manually enter the WiFi name for connection.</p>

6.1.2 Changing WiFi name & WiFi password

Assume to change the 2.4 GHz WiFi name to Tenda_2.4G, WiFi password to 12345678; 5 GHz WiFi name to Tenda_5G, WiFi password to 87654321.

Procedures:

Step 1 Click **WiFi Settings > WiFi Name & Password**.

Step 2 Change 2.4 GHz WiFi network information.

1. **WiFi Name:** Set **Tenda_2.4G** as the WiFi Name.
2. **Encryption Mode:** Keep the default setting, which is **WPA/WPA2-PSK** in this example. You can change it if needed.
3. **WiFi Password:** Set **12345678** as the WiFi password.

Step 3 Change 5 GHz WiFi network information.

1. **WiFi Name:** Set **Tenda_5G** as the WiFi Name.
2. **Encryption Mode:** Keep the default setting, which is **WPA/WPA2-PSK** in this example. You can change it if needed.
3. **WiFi Password:** Set **87654321** as the WiFi password.

Step 4 Click **Save**.

WiFi Name & Password

2.4 GHz Network

WiFi Name: Hide

Encryption Mode: ▾

WiFi Password:

5 GHz Network

WiFi Name: Hide

Encryption Mode: ▾

WiFi Password:

--End


Verification

Wait a moment for the modification to complete successfully. You can find the WiFi names have been changed on the **Internet Status** page.


Tenda

Internet Status English ▾ | Exit

Internet



Router



USB: 1

Online: 1

WiFi Extender

↑ 0.9KB/s | ↓ 1.3KB/s

Current Speed

192.168.20.187

WAN IP Address

V15.03.06.35_multi NEW

Firmware Version


2.4 GHz: Tenda_2.4G
5 GHz: Tenda_5G

6.2 WiFi Schedule


6.2.1 Overview

This WiFi Schedule function allows you to disable the WiFi network of the router at specified period. By default, this function is disabled.

To access the configuration page, click **WiFi Settings > WiFi Schedule**.



The following figure appears when the WiFi Schedule function is enabled:



Parameter description:

Parameter	Description
WiFi Schedule	Used to enable/disable the WiFi Schedule function.
Turn Off During	It specifies the period when the WiFi network is disabled. In that period, wireless devices cannot search the router's WiFi networks, but out of that period they can search and connect to the WiFi networks.
In	It allows you to customize your WiFi schedule. See the following:

- Every Day: The router disables its WiFi networks at the specified time you set every day.
- Specified Day: The router disables its WiFi networks at the specified time you set on specified days.


6.2.2 Example

Scenario

Michael bought an AC10/AC10U for network coverage. For a healthier sleeping environment, he wants to disable the WiFi networks every day during 23:00 to 7:00.

Procedures:

1. Click **WiFi Settings > WiFi Schedule**.
2. Set the WiFi schedule button to .
3. **Turn Off During:** Set the period as needed, which is **23:00~07:00** in this example.
4. **In:** Select the schedule type as needed, which is **Every Day** in this example.
5. Click **Save**.



The screenshot shows the 'WiFi Schedule' configuration window. At the top, there is a title bar with 'WiFi Schedule' and a close button. Below the title bar, the 'WiFi Schedule' toggle is turned on (green). The 'Turn Off During' field is set to '23:00 ~ 07:00'. Under the 'In:' section, 'Every Day' is selected with a radio button. Below this, all days of the week (Mon., Tue., Wed., Thur., Fri., Sat., Sun.) are checked with checkboxes. A green 'Save' button is located at the bottom center. At the very bottom, there is a small note: 'To restore WiFi connectivity when WiFi is disabled as scheduled, press the WiFi button on the router.'

--End

Verification

The WiFi networks are disabled from 23:00 to 07:00 every day.

6.3 Wireless Repeating


6.3.1 Overview

The Wireless Repeating function enables the router to expand WiFi coverage by connecting to the WiFi network of an upstream router. This router supports two wireless repeating modes: WISP and Client+AP.




If repeating the WiFi hotspot provided by ISP, you are recommended to select WISP. Otherwise, select WISP or Client+AP.

To access the configuration page, click **WiFi Settings** > **Wireless Repeating**. By default, the Wireless Repeating function is disabled.



Set the wireless repeating button to . Then the following figure appears:



If wireless repeating is enabled, the Sleeping Mode, IPTV Function, Guest Network, WPS, Tenda App, and WiFi Schedule functions become unavailable. You can find their icons disappear on the **WiFi Settings** page.

Parameter description:

Parameter	Description
Wireless Repeating	Used to enable/disable the Wireless Repeating function.

	It specifies how the router repeats the upstream WiFi network.
Repeating Mode	<ul style="list-style-type: none"> - WISP: The router repeats WiFi hotspot provided by ISP or ordinary WiFi network. - Client+AP: The router repeats ordinary WiFi network.
Upstream WiFi Name	It specifies the name of the WiFi network you decide to repeat. You can select it from the drop-down list box.
Upstream WiFi Password	It specifies the password of the WiFi network you decide to repeat. This parameter appears after you select the upstream WiFi name.

6.3.2 Example

Scenario



Michael bought a wireless router for network after having broadband service. The router is placed in the living room. WiFi signals are strong in the living room and master bedroom, but too poor in the other bedrooms and restrooms to access the internet. Now he wants to expand the WiFi coverage, ensuring devices to access the internet everywhere.


Solution

Michael can buy an AC10/AC10U, and set the wireless repeating function on it to expand the WiFi network coverage of the original router. Thus, devices in dead zones can access the internet through the WiFi signal of AC10/AC10U. See the following figure:




Procedures:

1. Click **WiFi Settings > Wireless Repeating**.
2. Set the wireless repeating button from  to .
3. Select **WISP** or **Client+AP**.
4. **Upstream WiFi Name:** Select the WiFi name of the original router from the drop-down list box, which is **majianwei** in this example.
5. **Upstream WiFi Password:** Enter the password of the WiFi network of the original router, which is **12345678** in this example. (If the wireless network of the upstream router is unencrypted, leave this box blank.)
6. Click **Save**.



The screenshot shows a window titled "Wireless Repeating" with a close button (X) in the top right corner. Inside the window, there are four main sections: 1. "Wireless Repeating:" with a green toggle switch that is currently turned on. 2. "Repeating Mode:" with two radio buttons: "WISP" (selected) and "Client+AP". 3. "Upstream WiFi Name:" with a dropdown menu showing "majianwei" and a refresh icon to its right. 4. "Upstream WiFi Password:" with a text input field containing seven asterisks. At the bottom center of the window is a green "Save" button with a mouse cursor pointing at it.

7. Click **OK**.



--End

Verification

After the message "Connected. You can access the internet now." appears on the **Internet Settings** page and the **Internet Status** page appears as the second figure, devices can access the internet through the WiFi network of AC10/AC10U.

WAN Port: Ethernet cable disconnected

Connection Type: Dynamic IP Address


DNS Settings: Automatic

Connection Status: Connected. You can access the internet now.

Connection Duration: 15s

Disconnect

2.4 GHz: Tenda_842E68
5 GHz: Tenda_842E68_5G



- USB: 0
- Online: 1
- WiFi Extender



- If the connection type provided by the upstream router is dynamic IP address, the new router obtains connection information from the upstream router automatically. If the connection type is static IP address, you need to set the connection information manually.
- In mode WISP, if the LAN IP address of the new router is in the same network segment as that of the upstream router, an IP conflict occurs. In this case, the new router replaces its LAN IP address with an IP address which belongs to another network segment. Then log in to the web UI of the new router using **tendawifi.com**.
- In Client+AP mode, the LAN IP address of A10/AC10U changes and you can view the new IP address from the DHCP client list of the upstream router.

6.4 Channel & Bandwidth

6.4.1 Overview

This module allows you to change network mode, WiFi channel, and WiFi bandwidth of either 2.4 GHz or 5 GHz WiFi network. Please retain the default channel and bandwidth settings if you set without professional guidance. To access the configuration page, click **WiFi Settings > Channel & Bandwidth**.

Channel & Bandwidth

2.4 GHz Network

Network Mode: 11b/g/n mixed

WiFi Channel: Auto

WiFi Bandwidth: 20/40

5 GHz Network

Network Mode: 11a/n/ac mixed

WiFi Channel: Auto

WiFi Bandwidth: 20/40/80

Save

Parameter description:

Parameter	Description
Network	It specifies various protocols adopted for wireless transmission. You are recommended to keep the default settings. For 2.4 GHz networks, 11b/g mixed, 11b/g/n mixed, and 11n protocols are

Parameter	Description
Mode	<p>available. For 5 GHz networks, the 11ac and 11a/n/ac protocols mixed are available.</p> <ul style="list-style-type: none"> - 11b/g mixed: It indicates that devices compliant with 802.11b or 802.11g protocol can connect to the router. - 11b/g/n mixed: It indicates that all devices working at 2.4 GHz and compliant with 802.11b, 802.11g, or 802.11n protocol can connect to the router. - 11n: It indicates that devices working at 2.4 GHz and compliant with 802.11n can connect to the router. - 11ac: It indicates that devices complaint with 802.11ac protocol can connect to the router. - 11a/n/ac mixed: It indicates that devices working at 5 GHz and compliant with 802.11a, 802.11n or 802.11ac protocol can connect to the router.
WiFi Channel	<p>It specifies the operating channel of a WiFi network.</p> <p>By default, the WiFi channel is Auto, which indicates that the router selects a proper channel based on the utilization rate it detected. But you can change it as required. A channel different from nearby channels and with less interference are recommended to use because of better wireless transmission efficiency. You can use a third-party tool to identify the channels different from nearby channels and with less interference.</p>
WiFi Bandwidth	<p>It specifies the bandwidth of the WiFi channel of a WiFi network. Change the default settings only when necessary.</p> <ul style="list-style-type: none"> - 20: It indicates that the channel bandwidth of a router is to 20 MHz. - 40: It indicates that the channel bandwidth of a router is 40 MHz. - 20/40: It specifies that a router can switch its channel bandwidth between 20 MHz and 40 MHz based on the ambient environment. This option is available only at 2.4 GHz. - 80: It indicates that the channel bandwidth of a router is 80 MHz. This option is available only at 5 GHz. - 20/40/80: It specifies that a router can switch its channel bandwidth among 20 MHz, 40 MHz, and 80 MHz based on the ambient environment. This option is available only at 5 GHz.

6.4.2 Changing WiFi channel

Assume that the channel at 2.4 GHz WiFi network is required to change to channel 11, and 5 GHz WiFi network to channel 157.

Procedures:

1. Click **WiFi Settings > Channel & Bandwidth**.
2. Change the channel of 2.4 GHz WiFi network to **Channel 11**.
3. Change the channel of 5 GHz WiFi network to **Channel 157**. (If there is no special requirement, retain the other default settings.)
4. Click **Save**.

Channel & Bandwidth ✕

2.4 GHz Network

Network Mode:

WiFi Channel:

WiFi Bandwidth:

5 GHz Network

Network Mode:

WiFi Channel:


WiFi Bandwidth:

--End

6.5 Transmit Power

This router supports three WiFi signal strength modes: Low, Medium, and High. By default, 2.4 GHz and 5 GHz WiFi signal is in the High mode. You can adjust the WiFi coverage and wall penetration capacity of the router's WiFi network through changing its WiFi signal strength mode.

To access the configuration page, click **WiFi Settings > Transmit Power**.




Descriptions about WiFi signal strength modes:

- **Low:** WiFi transmit power in this mode is relatively weak, suitable for small-area or barrier-free WiFi coverage environment.
- **Medium:** WiFi transmit power in this mode is relatively strong, suitable for medium-area WiFi coverage environment or environment with few barriers.
- **High:** WiFi transmit power in this mode is strong, suitable for large-area WiFi coverage environment or environment with many barriers.

If WiFi network experience is excellent in Low mode, you are recommended to set your router in this mode.

If you want to improve your network experience in some areas with poor WiFi signal, you are recommended to have a Tenda WiFi extender to get your WiFi coverage wider. Click **Details** to know more about the recommended Tenda WiFi extender. For instructions about how to extend WiFi coverage using WiFi extender, refer to the installation guide or user guide of your WiFi extender.




6.6 WPS

6.6.1 Overview

The WPS function enables wireless devices such as smart phones to connect to WiFi networks of the router easily.

To access the configuration page, click **WiFi Settings** > **WPS**. Then follow the onscreen instructions to set.




6.6.2 Connect devices to WiFi network using WPS



- Smart phones can connect to the WiFi network of the router through WPS only when they support WPS function.
- Desktops or laptops can connect to the WiFi network of the router through WPS only when they are installed with wireless adapters. For detailed information, please refer to the user guide of relevant wireless adapter.

Method 1: Setting through the web UI of the router

1. Click **WiFi Settings > WPS**.
2. Click **Click Here**. Then the router's WiFi LED indicator on the front panel is blinking slowly.
3. Set WPS on a smart phone or computer installed with wireless network adapter within 2 minutes.



--End

Smart phones or computers are connected to the WiFi network of the router successfully after a while.

Method 2: Setting via the WPS button on the router

1. Press the WPS button on the router.
2. Set WPS on a smart phone or computer installed with wireless adapter within two minutes.

--End



The smart phone or computer is connected to the WiFi network of the router successfully after a while.

Method 3: Setting through pin code of the router



WPS connection using pin code is generally applied on computer with wireless adapter. Please refer to relevant adapter's user guide for detailed instructions.

1. Record the router's pin code labeled on the bottom of the router.



2. Enter the pin code on the device for connection.

--End

The device is connected to the router's WiFi network successfully after a while.

6.6.3 Example

Scenario


Michael bought an AC10/AC10U for network and he has set the WiFi password. He hopes to connect devices to the router's WiFi network without entering WiFi password. Assume that the WiFi name of his router is Tenda_XXXXXX.

The WPS function can address this requirement.

Procedures:


Step 1 Set up the router.

1. Click **WiFi Settings** > **WPS** > **Click Here**.





Step 2 Set WPS on a smart phone. Smart phone Redmi Note 4X is used as an example here.


1. Click **Settings** on the phone's homepage.



2. Then click **WLAN > Advanced Settings > Connect WPS**.




3. The smart phone is performing WPS negotiation with the router.



--End

Wait a moment for the negotiation to complete. Then the smart phone connects to the router's WiFi network successfully.



Verification

The smart phone accesses the internet through the router's WiFi network successfully.

6.7 Beamforming+

6.7.1 Overview

- As a wireless signal optimization technology, the location-oriented Beamforming could transmit wireless signals to wireless devices precisely, offering users with better internet connection, such as higher download speed or playback of HD videos. Wireless routers broadcast signals to all directions in transmission if they do not support Beamforming+ function.
- Wireless routers supporting Beamforming+ could transmit wireless signals toward the location of connected devices, improving users' internet experiences.

The following figure shows the wireless transmission when Beamforming+ is disabled.




The following figure shows the wireless transmission when Beamforming+ is enabled.



6.7.2 Setting Beamforming+

To access the configuration page, click **WiFi Settings** > **Beamforming+**. By default, Beamforming+ function is enabled. You are recommended to retain the default settings.




6.8 AP Mode

6.8.1 Overview

In AP mode, the router implements the functions of wireless access point (AP), and WAN port of the router functions as a LAN port. Usually, in AP mode, when the router connects to the upstream router using an Ethernet cable, the router extends the wireless network coverage of the upstream router, or transforms the wired signal to wireless one.

To access the configuration page, click **WiFi Settings** > **AP Mode**. By default, AP mode is disabled.




6.8.2 Enabling AP mode

1. Click **WiFi Settings > AP Mode**.

2. Set the AP mode button  to .

3. Click **Save**.



--End



- If AP mode is enabled, Internet Settings, VPN, Parental Control, Bandwidth Control, and Virtual Server functions become unavailable.
- The LAN IP address of the router will be changed since AP mode is enabled. Please log in to the router's web UI by domain name **tendadwifi.com**, or look for the new LAN IP address from the client list of the upstream router, and log in to the router through the new IP address.

6.8.3 Example


Scenario

Michael could access the internet through his optical modem only in a wired manner. Now he wants to access the internet by WiFi network.

Solution

He is recommended to purchase an AC10 or AC10U and enable its AP mode. After setting up the router successfully, his wireless devices like smart phones could access the internet through WiFi network of the router.

Connect a LAN port of the optical modem to any port of the router using an Ethernet cable. Then connect your computer to the router using an Ethernet cable and your smart phones to the router's WiFi network. See the following figure:




Procedures:


1. Click **WiFi Settings > AP Mode**.

2. Set the AP mode button to .

3. Click **Save**.



4. Click **Ok** in the following window that appears:



--End


Verification

Wired devices like computers could access the internet successfully if they connect to the router using Ethernet cables, and wireless devices like smart phones are also available to the internet if they connect the router's WiFi network.

6.9 Anti-interference

This router supports the Anti-interference function. When having bad internet experience, you are allowed to modify the Anti-interference settings.

To access the configuration page, click **WiFi Settings** > **Anti-interference**. By default, this function is in **Auto** status.



- When you choose **Auto**, the router will adjust receiving sensitivity automatically based on the current interference. Please keep **Auto** if you do not have any special requirement.
- When you choose **Enable**, the router has better anti-interference ability but smaller WiFi coverage.
- When you choose **Disable**, the router has wider WiFi coverage. But if the interference is strong in your environment, you are recommended to choose **Auto** or **Enable**.

7

Guest Network

7.1 Overview

This module makes you able to enable/disable the Guest Network function and change guest network's WiFi name and password.

Devices connected to the guest network can access to the internet and communicate with each other, but cannot access the router's web UI or the master network. This function not only enables guests to access the internet but also ensures the security of the master network.

To access the configuration page, click **Guest Network**. By default, the Guest Network function is disabled.



The screenshot shows the 'Guest Network' configuration interface. At the top left is the title 'Guest Network' and at the top right are 'English' and 'Exit' options. The main configuration area includes: a 'Guest Network' toggle switch (currently off), a '2.4 GHz WiFi Name' text box containing 'Tenda_VIP', a '5 GHz WiFi Name' text box containing 'Tenda_VIP_5G', a 'Guest Network Password' text box containing 'Blank means no password.', a 'Validity' dropdown menu set to '8 hours', and a 'Shared Bandwidth for Guests' dropdown menu set to 'Unlimited' with 'Mbps' indicated to the right. A green 'Save' button is positioned at the bottom center of the configuration area.


Parameter description:

Parameter	Description
Guest Network	Used to enable the Guest Network function. By default, this function is disabled.
2.4 GHz/ 5 GHz WiFi Name	It specifies the WiFi name of the router's guest network. By default, Tenda_VIP is for 2.4 GHz WiFi network and Tenda_VIP_5G for 5 GHz WiFi network. You can change the SSIDs if required. To distinguish the guest network from the master network, you are recommended not to set the same name for these two networks.
Guest Network Password	It specifies the password for the router's two guest networks. Please set the password according to your requirements.

Parameter	Description
Validity	It specifies the validity of the guest networks. The Guest Network function will be disabled automatically out of the specified time so wireless devices will not search it. Please set the validity as needed.
Shared Bandwidth for Guests	It specifies the downloading speed of guest network devices, with a unit Mbps. By default, the speed is not limited. You can set it as needed.

7.2 Setting guest network

1. Click **Guest Network**.
2. Set the Guest Network button  to .
3. **2.4 GHz WiFi Name:** Change the WiFi name, such as to **Michael**.
4. **5 GHz WiFi Name:** Change the WiFi name, such as to **Michael_5G**.
5. **Guest Network Password:** Set the password for guest networks, such as to **987654321**.
6. **Validity:** Click the drop-down box, and choose **4 hours**.
7. **Shared Bandwidth for Guests:** Click the drop-down box, and choose **2**.
8. Click **Save**.



Guest Network

English | Exit

Guest Network:

2.4 GHz WiFi Name:

5 GHz WiFi Name:

Guest Network Password:

Validity:

Shared Bandwidth for Guests: Mbps

Save

--End

After configuration, wireless devices such as smart phones, connected to **Michael** or **Michael_5G** share a downloading speed up to 2 Mbps, and can access the internet consecutively for 4 hours.


8

Parental Control





8.1 Overview

This module enables you to set the internet accessibility of devices in the router's LAN network, including specified time for surfing the internet, websites allowed or banned to visit.

To access the configuration page, click **Parental Control**. The **Parental Control** page shows devices which are connected to the router currently.




The screenshot shows the 'Parental Control' interface. At the top, there is a header with a home icon, the text 'Parental Control', a language dropdown set to 'English', and an 'Exit' button. Below the header is a table with the following columns: 'Device Name', 'MAC Address', 'Uptime', and 'Operation'. There are two rows of data:

Device Name	MAC Address	Uptime	Operation
 RedmiNote4X-hongmish 192.168.0.189	c4:0b:cb:81:5d:11	29 s	
 liguilan-PC 192.168.0.129	4c:cc:6a:ad:14:53	1 hour(s) 28 min 59 s	


At the bottom right of the table area, there is a '+New' button.


Parameter description:

Parameter	Description
Device Name	It specifies names of the devices connected to the router.
MAC Address	It specifies MAC addresses of the devices connected to the router.
Uptime	It specifies the time that has elapsed since the device is connected to the router currently.
Operation	Click  to set limits for devices to access the internet through the router.
+New	Click +New to add devices and set limits for them.


8.2 Setting parental control rules

8.2.1 Scenario 1: The device has been connected to the router

1. Click **Parental Control**.
2. In device list, locate the device you want to set rules on and click .




3. Set valid time for internet connection, and websites banned or allowed to visit.
4. Click **Save**.




--End

8.2.2 Scenario 2: The device has not been connected to the router

1. Click **Parental Control**.
2. Click **+New**.



3. Set device name, MAC address, time limit to internet access and limit to website access as required.
4. Click **Save**.



--End

Parameter description:

Parameter	Description
Device Name	It specifies the name of the device you want to apply the rule to.
MAC Address	It specifies the MAC address of the device you want to apply the rule to.
Internet Accessible At	It specifies the specific time for the device to access the internet through the router.
In	It specifies dates for the device to access the internet through the router.
Website Access Limit	Used to enable/disable the website access limit function. By default, this function is enabled.
Access Control Mode	It specifies modes for website access limit in a parental control rule. <ul style="list-style-type: none">- Blacklist: The device under the rule is not allowed to visit the website(s) below.- Whitelist: The device under the rule is only allowed to visit the website(s) below.
Blocked/Unblocked Websites	It specifies the websites that the device under the rule is banned/allowed to visit during Internet Accessible At .

8.2.3 Example


Scenario





Michael bought an AC10/AC10U for network. His children always surf the internet on smart phones through the router. For the good of his children' learning, he intends to allow his children to access Google during 8:00 to 22:00 from Monday to Friday.

Solution

The Parental Control function of AC10/AC10U could fulfill his requirements.


Procedures:

1. Click **Parental Control**.
2. In device list, locate the device you want to set a rule on and click  .

Parental Control			
Device Name	MAC Address	Uptime	Operation
 RedmiNote4X-hongmish 192.168.1.189	c4:0b:cb:81:5d:11	12min 33s	
 liguilan-PC 192.168.1.129	4c:cc:6a:ad:14:53	3hour(s) 17min 42s	

3. **Internet Accessible At:** Set time limit for the device to access the internet, which is **08:00~20:00** in this example.
4. **In:** Select **Specified Day** and then **Monday to Friday**.
5. **Access Control Mode:** Click **Whitelist**.
6. **Unblocked Websites:** Enter the website accessible for the device, which is **google** in this example.
7. Click **Save**.

Parental Control
✕

Device Name: RedmiNote4X-hongmish 

Internet Accessible At: ~

In: Every Day Specified Day

Sun. Mon. Tue. Wed.
 Thur. Fri. Sat.

Website Access Limit:

Access Control Mode: Blacklist Whitelist

Unblocked Websites:

Enter website keywords separated by a comma. For example, eHow,google indicates that only the eHow and Google websites are accessible.

--End

Verification

Google is only accessible for the device under the rule during 8:00-20:00 on weekdays.

9

VPN

The VPN module includes the following functions: [PPIP Server](#), [Online PPTP Users](#), and [PPTP/L2TP Client](#).

VPN (Virtual Private Network) is a dedicated network across the shared or public network (usually the internet). However, since this dedicated network does not have physical lines but only exists logically, it is called the virtual private network. The VPN technology allows employees at a branch of an enterprise and employees at the headquarters to exchange resources conveniently without exposing these resources to other internet users.

9.1 PPTP Server

9.1.1 Overview

The **PPIP Server** page allows you to set the router as PPIP server.

PPTP server allows the specified VPN users to dial in. For example, you can allow staffs on business trip to access the headquarter's resources through VPN dialing up on a router whose PPTV server function is enabled.

To access the configuration page, click **VPN > PPTP Server**.

User Name	Password	Connection Status	Operation
<input type="text"/>	<input type="text"/>	--	<input type="button" value="+New"/>

After enabling the PPIP Server function, the figure below appears:

PPTP Server
✕

PPTP Server:

IP Address Pool: ~10.0.0.

MPPE Encryption:

User Name	Password	Connection Status	Operation
<input type="text"/>	<input type="text"/>	--	<input type="button" value="+New"/>

Parameter description:

Parameter	Description
PPTP Server	Used to enable/disable the PPTP server function. If the function is enabled, the router functions as a PPTP server.
IP Address Pool	It specifies the range of IP addresses that the PPTP server can assign to users.
MPPE Encryption	Used to enable/disable the MPPE encryption function.
User Name	Set user name and password that is allowed to dial in the PPTP server. This name and password are needed when a device connects to the PPTP server.
Password	
Connection Status	It specifies the status of a VPN connection.
	The following operations can be performed on the PPTP user rules:
	- +New : It is used to add PPTP users. Users can access the PPTP server successfully after you have added them.
Operation	- : It is used to disable PPTP users to access the PPTP server.
	- : It is used to enable PPTP users to access the PPTP server again if they were disabled before.
	- : It is used to delete PPTP users.

9.1.2 Example

Scenario

Michael bought an AC10/AC10U for network. And he needs to access the resources of his FTP server at home.

Solution

The PPTP server function of AC10/AC10U can address this requirement. Set PPTP Server function on the router. He can access the resources on the computer's FTP server by VPN dialing up on business trip.

Assume that the IP address of the FTP server is 192.168.0.104, and the WAN IP address of the router is 113.88.112.220. After the PPTP server function of the router is enabled, the WAN IP address becomes the address of the PPTP server.

Procedures:

1. To access the configuration page, choose **VPN > PPTP Server**.

2. **PPTP Server:** set to .

3. **IP Address Pool:** Set the range of IP addresses that the PPTP server assigns to devices. You are recommended to keep the default settings.

4. **MPPE Encryption:** Set to , and configure the number of MPPE encryption bits, which is **128** in this example.

5. **User Name, Password:** Set user names and passwords that devices use for VPN dialing up, which are **admin1** in this example.

6. Click **+New**.

7. Click **Save**.

PPTP Server:

IP Address Pool: ~

MPPE Encryption:

Number of MPPE Encryption Bits: 40 128


User Name	Password	Connection Status	Operation
<input type="text"/>	<input type="text"/>	--	<input type="button" value="+New"/>
admin1	admin1		

--End


Verification (Example: Windows 7)

On business trip, Michael succeeds in accessing resources on his computer's FTP server at home. The following describes the steps:


1. Click  at the lower-right corner of the desktop, and click **Open Network and Sharing Center**.




2. Click **Set up a new connection or network**.




3. Click **Connect to a workplace > Next**.




4. Click **Use my Internet connection (VPN)**. If a dialog box appears, you can follow the onscreen instructions to perform operations.




5. Enter the IP address of the PPTP server in the Internet address text box, which is **113.88.112.220** in this example. Then click **Next**.



6. Enter the user name and password for connecting to the PPTP server, which are **admin1** in this example. Click **Create**.




7. Click **Click Now** after a while.




8. Access the resources on the FTP Server at home by the server or **My Computer**.

Method: "ftp://Server IP address: Service port number", which is **ftp://192.168.0.104:21** in this example.




9. Access successfully. See the following figure:



9.2 Online PPTP Users

This page enables you to have detailed information about the VPN devices dialed up to the PPTP server.

To access the page, select **VPN > Online PPTP Users**.



Parameter description:

Parameter	Description
User Name	It specifies the user name for a user to dial in the PPTP server.
Dial-in IP Address	It specifies the IP address of a device. If the device is a router, IP address of the WAN port which enables VPN function will be displayed.
Assigned IP Address	It specifies the IP address that the PPTP server assigns to a device.
Uptime	It specifies the time that has elapsed since the PPTP device dials in the server successfully this time.

9.3 PPTP/L2TP Client


9.3.1 Overview

You are allowed to set router as a PPTP/L2TP client on the **PPTP/L2TP Client** page.

The router can connect to PPTP/L2TP server after the PPTP/L2TP Client function is enabled.


Example: If users subscribe to the VPN service provided by their ISP when having broadband, they can dial in their ISP's VPN network through the PPTP/L2TP Client function of the router.

To access the configuration page, click **VPN > PPTP/L2TP Client**.



The screenshot shows a window titled "PPTP/L2TP Client" with a close button (X) in the top right corner. Inside the window, the text "PPTP/L2TP Client:" is followed by a toggle switch that is currently turned off (grey). Below the toggle switch is a green "Save" button.

The following figure appears after enabling the PPTP/L2TP Client function:



The screenshot shows the "PPTP/L2TP Client" configuration page after the function has been enabled. The window title is "PPTP/L2TP Client" with a close button (X) in the top right corner. The "PPTP/L2TP Client:" toggle switch is now turned on (green). Below it, the "Client Type:" section has two radio buttons: "PPTP" (which is selected) and "L2TP". There are three input fields: "Server IP Address/Domain Name:", "User Name:", and "Password:". Below these fields, the "Status:" is displayed as "Disconnected". At the bottom of the window is a green "Connect" button.

Parameter description:

Parameter	Description
PPTP/L2TP Client	Used to enable/disable the PPTP/L2TP Client function. After the function is enabled, the router works as a VPN client.
Client Type	It specifies whether the router is a PPTP client or an L2TP client.
Server IP Address/Domain Name	It specifies the IP address or domain name of the PPTP/L2TP server to which the router is to be connected.
User Name Password	It specifies the user name and password assigned by the PPTP/L2TP server to the PPTP/L2TP client.
Status	It specifies the current connection status of a VPN client.

9.3.2 Example

Scenario

Michael subscribed to PPTP service provided by ISP when he had broadband. Assume that the VPN service information provided by his ISP is as follows:



- PPTP Server Address: 1.1.1.1
- User name/Password: 123

Michael bought an AC10/AC10U for network. Now he wants to access VPN resources provided by his ISP.

Solution

The PPTP Client function could address this requirement. Set the PPTP Client function on his router. Then clients in LAN network could access the VPN resources provided by the ISP.

Procedures:

1. Click **VPN > PPTP/L2TP Client**.
2. **PPTP/L2TP Client**: Switch the button  to .
3. **Client Type**: Select client type, which is **PPTP** in this example.
4. **Server IP/Domain Name**: Enter the PPTP server's IP address or domain name, which is **1.1.1.1** in this example.
5. **User Name, Password**: Set user name and password that client uses for VPN dialing up, which are **123** in this example.
6. Click **Connect**.

PPTP/L2TP Client:

Client Type: PPTP L2TP

Server IP Address/Domain Name:

User Name:

Password:

Status: Disconnected

--End

Verification


Clients in LAN network could access the VPN resources provided by the ISP.

10

USB App

10.1 Overview

The USB App function includes the Share File feature. This feature allows you to share the files of a connected USB device with LAN devices or internet devices. If you insert a portable USB device to the router, the USB app function is enabled automatically. Otherwise, this function is disabled. For the **USB App** page, see the following figure:



AC10U supports the USB App function, but AC10 does not own this function.

To access the **USB App** page, click **USB App > Share File**.

Share File

FTP Server

Encoding Type:

Allow Internet Access:



LAN Address: <ftp://192.168.0.1:21>

Samba Server

Address for Windows OS: \\192.168.0.1

Address for MAC OS: smb://192.168.0.1

Role	User Name	Password	Permission
Administrator	admin	<input type="password" value="....."/>	Read/Write
Guest	<input type="text" value="guest1"/>	<input type="password" value="....."/>	<input type="text" value="Read"/>

After you switch the **Allow Internet Access** button from  to , the following figure appears:

Share File

FTP Server

Encoding Type:

Allow Internet Access:

Access from Internet: <ftp://192.168.20.187>:

LAN Address: <ftp://192.168.0.121>

Samba Server


Address for Windows OS: \\192.168.0.1

Address for MAC OS: smb://192.168.0.1

Role	User Name	Password	Permission
Administrator	admin	<input type="password" value="....."/>	Read/Write
Guest	<input type="text" value="guest1"/>	<input type="password" value="....."/>	<input type="text" value="Read"/> ▼

Parameter description:

Parameter	Description
FTP Server	It specifies one of the built-in servers of your router which supports the File Transfer Protocol (FTP). You can access the USB resources of your router through this server.
Encoding Type	<p>It specifies the encoding type for every language in the world.</p> <ul style="list-style-type: none"> – Unicode (utf-8): It is an encoding type for all languages which is acceptable worldwide. – Simplified Chinese (GBK): It is an encoding type for simplified Chinese. – Traditional Chinese (Big5): It is an encoding type for traditional Chinese.
Allow Internet Access	<p>It specifies whether to allow internet devices to access the USB resources of your router through the FTP server.</p> <ul style="list-style-type: none"> – If you set the button to <input checked="" type="checkbox"/>, devices in the internet can access the USB resources of the router. – If not, devices in the internet cannot access the USB resources.

Access from Internet	It specifies the login address internet users need to enter in address bar when they try to access the USB resources through the FTP server. This address changes with the WAN IP address of your router. 21 in the box is the control port of the FTP protocol. If not necessary, you are recommended to keep the default settings.
LAN Address	It specifies the login address LAN users need to enter in address bar when they try to access the USB resources through the FTP server. This address changes with the LAN IP address of your router. LAN users can also visit FTP server using ftp://tendawifi.com which does not change with LAN IP address of your router.
Samba Server	It specifies one of the built-in servers of your router which supports the Server Messages Block (SMB) protocol. You can access the USB resources of your router through this server.
	 <p>Only LAN devices can access the USB resources through the samba server.</p>
Access from Windows OS	It specifies the login address LAN users need to enter in address bar when they try to access the USB resources through the samba server on a device with windows operating system. This address changes with the LAN IP address of your router. LAN users using devices with windows operating systems can visit samba server using \\tendawifi.com for all time.
Access from MAC OS	It specifies the login address LAN users need to enter in address bar when they try to access the USB resources through the samba server on a device with MAC operating system. This address changes with the LAN IP address of your router. LAN users using devices with MAC operating systems can visit samba server using smb://tendawifi.com for all time.
Role	<p>It specifies the account allowed to access the USB resources through FTP/samba server of your router. The servers only allow two accounts for visiting: one administrator and one guest.</p> <ul style="list-style-type: none"> – Administrator: After visiting the servers of the router through this account, the user not only can view the files in the USB device, but also edit, delete or move the files and so on. – Guest: Guest account is used for another user (except the administrator) to visit the servers of your router.
User Name	It specifies the user name of an account used to visit the FTP/samba server of your router. The user name of administrator account is admin for all time. The default user name of guest account is guest1 , but you can customize it yourself.
Password	It specifies the password of an account used to visit the FTP/samba server of your router. The default password of administrator account is admin, and guest account is guest1 . But you can customize these two parameters yourself.
Permission	<p>It specifies the operation allowed for an account to perform on the USB resources of your router, which includes Read and Read/Write.</p> <ul style="list-style-type: none"> – Read: It specifies the account is only allowed to view/download the files in the USB device, but not to edit, delete or move the files. – Read/Write: It specifies the account is allowed not only to view/download the files in the USB device, but also edit, delete or move the files and so on. Permission for administrator account is Read/Write all the time.

10.2 Modifying role information

In this module, both the default user name and password of administrator are admin, and you are only allowed to modify the password of administrator. Both the default user name and password of guest are **guest1**, and you can customize these two parameters yourself. The permission for administrator is **Read/Write** for all time, while the default permission for guest is **Read** but you can modify it as required.

10.2.1 Example

Procedure:

1. Access the web UI of your router, then click **USB App > Share File**.

Role	User Name	Password	Permission
Administrator	admin	Read/Write
Guest	guest1	Read

2. Clear the default user name for guest, default passwords for administrator or guest, and enter your desired user name and passwords.
3. To modify the permission for guest, select your desired permission from the drop-down-list box.
4. Click **Save**.

Share File

FTP Server

Encoding Type: Unicode (utf-8) ▼

Allow Internet Access:

LAN Address: <ftp://192.168.0.1:21>

Samba Server

Address for Windows OS: \\192.168.0.1

Address for MAC OS: smb://192.168.0.1

Role	User Name	Password	Permission
Administrator	admin	<input type="password" value="....."/>	Read/Write
Guest	<input type="text" value="1234567E"/>	<input type="password" value="....."/>	Read/W ▼

Save

--End

Verification

Modification succeeds. See the following figure:

Share File

FTP Server

Encoding Type: Unicode (utf-8) ▼

Allow Internet Access:

LAN Address: <ftp://192.168.0.1:21>

Samba Server

Address for Windows OS: \\192.168.0.1

Address for MAC OS: smb://192.168.0.1

Role	User Name	Password	Permission
Administrator	admin	Read/Write
Guest	1234567E	Read/W ▼

Save



If the user name or password of either account is modified, you need to enter the new user name or password to visit the FTP/samba server next time.

10.3 Accessing USB resources through FTP/Samba servers

10.3.1 Accessing the USB resources from a LAN device

Procedure: (FTP server is used as an example here)

1. Insert your USB (KINGSTON-b in this example) to the USB port of AC10U. You can check whether your USB is connected to the router properly on **Internet Status** page.
2. Log in to the web UI of your router, then click **USB App > Share File**.

Share File

FTP Server

Encoding Type:

Allow Internet Access:

LAN Address: <ftp://192.168.0.1:21>


Samba Server

Address for Windows OS: \\192.168.0.1


Address for MAC OS: smb://192.168.0.1

Role	User Name	Password	Permission
Administrator	admin	Read/Write
Guest	<input type="text" value="guest1"/>	<input type="text" value="Read"/>

- Record the LAN address used to visit the FTP server, which is **ftp://192.168.0.1:21** in this example.
- Click **My Computer** in a computer connected to your router. Enter **ftp://192.168.0.1:21** in the address bar, and press **Enter**.




- Enter your user name and password, which are both **admin** in this example, and click **log on**.



--End

Verification

Access the USB resources of your router successfully. See the following figure:



10.3.2 Accessing the USB resources from an internet device

Procedure: (FTP server is used as an example here)

1. Insert your USB (KINGSTON-b in this example) to the USB port of AC10U. You can check whether your USB is connected to the router properly on **Internet Status** page.
2. Log in to the web UI of your router, then click **USB App > Share File**.

Share File

FTP Server

Encoding Type:

Allow Internet Access:

LAN Address: <ftp://192.168.0.1:21>

Samba Server

Address for Windows OS: \\192.168.0.1

Address for MAC OS: smb://192.168.0.1

Role	User Name	Password	Permission
Administrator	admin	<input type="password" value="....."/>	Read/Write
Guest	<input type="text" value="guest1"/>	<input type="password" value="....."/>	<input type="text" value="Read"/>

3. Set the **Allow Internet Access** button to and click **Save** on the bottom of the page.

Share File

FTP Server

Encoding Type: Unicode (utf-8) ▼

Allow Internet Access:

Access from Internet: ftp://192.168.20.133: 21

LAN Address: ftp://192.168.0.1:21

Samba Server


Address for Windows OS: \\192.168.0.1

Address for MAC OS: smb://192.168.0.1


Role	User Name	Password	Permission
Administrator	admin	Read/Write
Guest	guest1	Read ▼

Save

4. Access the configuration page again, and record the address used to visit the FTP server for internet devices, which is **ftp://192.168.20.133:21** in this example.
5. Click **My Computer** in a computer not connected to your router. Enter **ftp://192.168.20.133:21** in the address bar, and press **Enter**.




6. Enter your user name and password, which are both **admin** in this example, and click **log on**.



--End

Verification

Access the USB resources of your router successfully. See the following figure:



11

Advanced Settings

This module includes: [Bandwidth Control](#), [Tenda App](#), [Sleeping Mode](#), [LED Control](#), [Filter MAC Address](#), [Firewall](#), [IPTV](#), [Static Route](#), [DDNS](#), [Virtual Server](#), [DMZ Host](#), [UPnP](#).

11.1 Bandwidth Control

11.1.1 Overview


This page allows you to view information about online devices, and set upload limits or download limits for devices if needed.

To access the configuration page, click **Advanced Settings > Bandwidth Control**.

Device Name	Upload Speed	Download Speed	Upload Limit	Download Limit
liguilan-PC 192.168.0.129	1.0KB/s	5.0KB/s	Unlimited	Unlimited
RedmiNote4X-hon... 192.168.0.189	0.0KB/s	0.0KB/s	Unlimited	Unlimited

Save

Parameter description:

Parameter	Description
Device Name	It presents information about a device that has connected to the router, including name, IP address. You can change the device name by clicking  .
Upload/Download Speed	It specifies the current upload and download speeds of a device.
Upload/Download Limit	It specifies the maximum upload/download speed of a device. You can select your preferred maximum upload/download from the drop-down box, or entering the speed manually.


11.1.2 Example

Scenario

Michael bought an AC10/AC10U for network after having broadband. He needs to set download limit for every device to ensure all family members can have good internet experience.

Procedures:

1. Click **Advanced Settings > Bandwidth Control**.
2. **Download Limit:** Set download limit to a value for the devices in the list, which is **2Mbps** in this example.
3. Click **Save**.



--End

Verification

The maximum download speed for each device in the list is 2 Mbps, which allows each device to see HD videos and surf the internet normally.

11.2 Tenda App

11.2.1 Overview

App management on this router allows you to manage it wherever and whenever you are. You can use **Tenda WiFi** app to:

- Manage your router in LAN.

- Manage your router remotely over the internet.

To access the Tenda App page, click **Advanced Settings** > **Tenda App**.

11.2.2 Example

The following figure may help you understand how to manage the router remotely using **Tenda WiFi**.




Procedures:


Step 1 Install **Tenda WiFi** app.


Download **Tenda WiFi** in app store of your smart phone.

Step 2 Register a Tenda account.


1. Open **Tenda WiFi** and enter the login password of your router (if any) in the password box. Click **Log**.



2. Click  for registration. (Example: Email address)



3. Choose your registration type, which is **Email address** in this example.



4. **Email address:** Enter the email address you want to set as an account name, which is **12345678901@163.com** in this example.
5. **Password:** Set a password for your Tenda account.
6. Click **Register**.
7. The activation email has sent to your email address. Please tap **click here to confirm** to activate in valid time.

To initiate the Account confirmation process for your [1 \[redacted\]@163.com](#), Tenda Account, [click here to confirm](#)

If clicking the link above doesn't work, please copy and paste the URL below in a new browser window instead. The link is valid in 24 hours.



<http://182.254.218.214:8081/mail/regist/v1?encry=20e7d54fc04c1f3fa19b4ba08aa96fc8&lang=en&path=account>


If you've received this mail in error, it's likely that another user entered your email address by mistake while trying to register an account. If you didn't initiate the request, you don't need to take any further action and can safely disregard this email.

Sincerely,
The Tenda Cloud Team

8. Your account is activated successfully.

Step 3 Log in to the web UI of the router, and enable the Tenda App function.


1. Log in to the web UI of the router. Then click **Advanced Settings > Tenda App**.
2. **Manage with Tenda App:** Switch the button  to .
3. **Account:** Enter the account registered in your **Tenda WiFi** app.
4. Click **Save**.



--End

Verification

When you are not at home, you can use **Tenda WiFi** app to manage the router by connecting your smart phone to WiFi network or traffic.




11.3 Sleeping Mode

This router supports Sleeping Mode function. When this function takes effect, LED indicators and WiFi network of this router will be disabled.



The Sleeping Mode function works based on time settings. If the system time of the router is not synchronized with the internet time, this function cannot work properly.

To access the configuration page, click **Advanced Settings > Sleeping Mode**. By default, the Sleeping Mode function is disabled.



The following figure appears after the Sleeping Mode function is enabled:

Sleeping Mode
✕

Sleeping Mode: The Sleeping mode takes effect only if the system time is synchronized with the internet time.

Sleeping Time: 00 : 00 : 07 : 00

Delay: Delay enabling the Sleep mode when there is an online user.

Save

How to use the WiFi network when the router is in Sleeping mode?
 Method 1: Press the WiFi button on the router.
 Method 2: Wake up the router using Tenda App. (To download Tenda App, choose Advanced Settings > Tenda App and scan the QR code.)


Parameter description:

Parameter	Description
	Used to enable/disable the Sleeping Mode function..
Sleeping Mode	When the router is in Sleeping mode, you can enable the WiFi network function by pressing the WiFi button on the rear panel of the router or using Tenda WiFi app. For details about how to enable this WiFi network function by Tenda WiFi app, refer to the usage of the app.
Sleeping Time	It specifies the time when the Sleeping Mode function is effective.
Delay	<ul style="list-style-type: none"> - When Delay enabling the Sleep mode when there is an online user option is selected, if device (s) exchange(s) data with the router in a WAN speed of no more than 3KB/s within 30 minutes, the router enters Sleeping mode; if no device exchanges data with the router, and the traffic is less than 3 KB/s within 3 minutes, the router enters Sleeping mode. - When the Sleeping Mode function is enabled and the Delay enabling the Sleep mode when there is an online user option is not selected, the router enters Sleeping mode during Sleeping Time automatically.

11.4 LED Control

This page allows you to set on/off status of the router's LED indicators.

To access the configuration page, click **Advanced Settings > LED Control**.



Parameter description:

Parameter	Description
Always on	It indicates that all the LED indicators work in ordinary states.
Always off	It indicates that all the indicators are off even the router is working.
Schedule	In specifies that all the LED indicators are turned off at the duration of Turn Off During , but return to their ordinary states when the periods expire.

11.5 Filter MAC Address

11.5.1 Overview

Usually computers and smart phones have their own MAC addresses.

The **Filter MAC Address** page allows you to add a filter rule and set internet limit for devices with specific MAC addresses, including **To disallow listed devices to access the internet** and **To allow only the listed devices to access the internet**.

To access the configuration page, click **Advanced Settings > Filter MAC Address**.


Filter MAC Address
✕

MAC Address Filter Mode: **Blacklist** (To disallow listed devices to access the internet)
 Whitelist (To allow only the listed devices to access the internet)

Blacklisted Device	MAC Address	Operation
<input type="text"/>	<input type="text"/>	<input type="button" value="+New"/>

The blacklist is empty.

Parameter description:

Parameter	Description
MAC Address Filter Mode	<p>It specifies whether the listed devices are allowed to access the internet through the router.</p> <ul style="list-style-type: none"> - Whitelist: It specifies that only the listed devices can access the internet through the router. - Blacklist: It specifies that the listed devices cannot access the internet through the router.
Blacklisted/Whitelisted Device	Enter names of devices that you want to add in blacklist or whitelist.
MAC Address	Enter MAC addresses of devices that you want to add in blacklist or whitelist.
Operation	Click +New to add the device to blacklist or whitelist.
<u>Add all online devices to the whitelist</u>	<p>Click this link to add all online devices to the whitelist. This link is only available for Whitelist.</p> <div style="text-align: center; margin-top: 10px;">  </div> <p style="text-align: center;">This link only appears when you set the whitelist for the first time.</p>

11.5.2 Adding a MAC address filter rule


1. To access the configuration page, click **Advanced Settings > Filter MAC Address**.
2. **MAC Address Filter Mode:** Select your MAC address filter mode, which is **Blacklist** in this example.

3. **Blacklisted Device:** Set the device that you disallow to access the internet through your router, which is **Michael's Phone** in this example.
4. **MAC Address:** Enter the MAC address of the blacklisted device, which is **C8:3A:35:13:05:18** in this example.
5. Click **+New**.
6. Click **Save**.

Blacklisted Device	MAC Address	Operation
Michael's phone	C8:3A:35:13:05:18	+New

--End

11.5.3 Deleting a MAC address filter rule

1. To access the configuration page, click **Advanced Settings > Filter MAC Address**.
2. Select the rule you want to delete, and click .
3. Click **Save** on the bottom of the page.

Filter MAC Address
✕

MAC Address Filter Mode: **Blacklist** (To disallow listed devices to access the internet)
 Whitelist (To allow only the listed devices to access the internet)

Blacklisted Device	MAC Address	Operation
<input type="text"/>	<input type="text"/>	<input type="button" value="+New"/>
Michael's phone	C8:3A:35:13:05:18	

--End

11.5.4 Example

Scenario

Michael bought an AC10/AC10U for network. He finds unknown devices in module **Attached Devices** of the router. But he hopes to allow only devices owned by his family members to access the internet through the router.

Solution

The Filter MAC Address function of the router can address this requirement.

Assume that the devices owned by his family members have following MAC addresses:

- 4C:CC:6A:AD:14:53
- 14:5F:94:BC:FC:81
- 1C:5C:F2:B4:40:01

Procedures:

1. To access the configuration page, click **Advanced Settings > Filter MAC Address**.
2. **MAC Address Filter Mode:** Select **Whitelist**.
3. **Whitelisted Device:** Enter name of the device allowed to connect to the router, which is **Phone-1** in this example.
4. **MAC Address:** Enter MAC address of the device allowed to connect to the router, which is **14:5F:94:BC:FC:81** in this example.
5. Click **+New**.

6. Refer to step 3-5 for adding MAC address 4C:CC:6A:AD:14:53.
7. Click **Save**.

Filter MAC Address ✕

MAC Address Filter Mode: Blacklist (To disallow listed devices to access the internet)
 Whitelist (To allow only the listed devices to access the internet)

Whitelisted Device	MAC Address	Operation
<input type="text"/>	<input type="text"/>	<input type="button" value="+New"/>
liquilan-PC	4C:CC:6A:AD:14:53	Local Host
phone-1	14:5F:94:BC:FC:81	<input type="button" value="🗑"/>
phone-2	1C:5C:F2:B4:40:01	<input type="button" value="🗑"/>

--End


Verification

Only devices with MAC address 4C:CC:6A:AD:14:53, 14:5F:94:BC:FC:81 or 1C:5C:F2:B4:40:01 can access the internet through the router.

11.6 Firewall

The firewall can protect the router against some common DoS attacks such as ICMP Flood Attack, TCP Flood Attack, and UCP Flood Attack. It also ignores Ping packets from the WAN port as well, helping ensure network security.

To access the configuration page, click **Advanced Settings > Firewall**. By default, the Firewall function is enabled. You are recommended to retain the default settings.



Parameter description:


Parameter	Description
ICMP Flood Attack Defense	<p>Used to enable/disable the ICMP flood attack defense.</p> <p>ICMP Flood Attack is an attack using ICMP packets.</p> <p>If an attacker sends many ICMP ECHO packets to destination host, which results in ICMP flood. Then destination host pays much time and resources on ICMP ECHO packets but nothing on normal requests or responses, which achieves attack against destination host.</p>
TCP Flood Attack Defense	<p>Used to enable/disable the TCP flood attack defense.</p> <p>In TCP protocol, when one device sends connection request and initialization to a server, protocol stack in the server will leave Backlog Quene for information exchange in connecting process.</p> <p>Attackers make use of Backlog Quene and send TCP connection requests only with SYN to the server many times by special program. Server will regard those requests as uncompleted and establish sessions for them in Backlog Queue.</p> <p>If those SYN requests are more than what server can hold, Backlog Queue will be full. Then server will not accept new request so that other legal connection will be refused.</p>
UCP Flood Attack Defense	<p>Used to enable/disable the UCP flood attack defense.</p> <p>UCP Flood Attack works on the similar principle as ICMP Flood Attack. If an attacker sends many UDP packets to destination host, the destination host pays much time and resources on UDP packets but nothing on normal packet requests or responses, which achieves attack against the destination host.</p>
Ignore Ping Packet Form WAN Port	<p>It specifies whether to ignore ping packets from WAN port.</p> <p>When host in the internet tries to ping WAN IP address of the router, the router will ignore that ping request automatically, protecting itself from exposure to the internet and external Ping attack.</p>

11.7 IPTV


11.7.1 Overview

IPTV is the abbreviation of Internet Protocol Television. It is new technology integrating with internet, multimedia, telecommunication and many other technologies, providing interactive services including digital TV to family users by internet broadband lines. IPTV is a service provided by ISP. Users can have multiple IPTV programs by IP set-top-box and television at home.

To access the configuration page, click **Advanced Settings > IPTV**.



The following figure appears after IPTV is enabled:



Parameter description:

Parameter	Description
IPTV	Used to enable/disable the IPTV function of the router. When this function is enabled, the third LAN port of this router can be used only as IPTV port and connect IPTV set-top-box, but cannot access other devices such as computer.
VLAN	It specifies the VLAN ID of your IPTV service. - If you do not have any information about VLAN provided by your ISP when having IPTV

Parameter	Description
	service, please keep Default .
	- If you have VLAN ID from your ISP when having IPTV service, please choose Custom VLAN and enter the VLAN value.
	- If you have IPTV service in Shanghai, please choose Shanghai VLAN and click VLAN value.

11.7.2 Example

Scenario

Michael subscribed to IPTV service when he had broadband. His ISP provided IPTV account and password but no information about VLAN. After buying an AC10/AC10U for network, he wants to have IPTV program.

Solution


The IPTV function of the router can address this requirement. Network topology is shown as follows:



Procedures:

Step 1 Set you router

1. To access the configuration page, click **Advanced Settings** > **IPTV**.
2. **IPTV**: Switch the button to .
3. Click **Save**.

A screenshot of a web-based configuration interface for IPTV. At the top, there is a label 'IPTV:' followed by a green toggle switch that is currently turned on. Below this is a text instruction: 'Connect the IPTV STB to the IPTV port of the router.' Underneath the instruction is a 'VLAN:' label followed by a dropdown menu showing 'Default' and a downward arrow. At the bottom of the interface is a large green button labeled 'Save' with a mouse cursor hovering over it.

Step 2 Set your set-top-box

Dial up on set-top-box with the account and password provided by ISP.

--End

Verification

Michael can have IPTV programs on television.

11.8 Static Route

11.8.1 Overview

Routing is performed to select the best route for delivering data from a source address to a destination address. A static route is a manually configured route which is simple, efficient, and reliable. Appropriate static routes help reduce route selection problems and data overload of route selection, improving the packet forwarding speed.

To access the configuration page, click **Advanced Settings > Static Route**.

Static Route				
Destination Network	Subnet Mask	Gateway	WAN	Operation
<input type="text"/>	<input type="text"/>	<input type="text"/>	WAN1	<input type="button" value="+New"/>
0.0.0.0	0.0.0.0	192.168.20.100	WAN1	System
192.168.0.0	255.255.255.0	0.0.0.0	br0	System
192.168.20.0	255.255.255.0	0.0.0.0	WAN1	System
224.0.0.0	240.0.0.0	0.0.0.0	br0	System

Parameter description:

Parameter	Description
Destination Network	It specifies the destination IP address of a packet.
Subnet mask	It specifies the subnet mask of a packet's destination IP address.
Gateway	It specifies the IP address of the next hop of packet transmitted from the router.
WAN	It specifies router's WAN port where packets leave the router.
Operation	It allows you to add/delete a static route rule.


11.8.2 Example

Scenario

Michael used wired router and switch for network in the past. Now he purchases an AC10/AC10U for wireless coverage and builds office intranet on that network, requiring devices connected to AC10/AC10U able to access both the internet and office intranet.

Solution

The following figure shows a network topology for reference:



Router 1 accesses the internet and Router 2 to the intranet. AC10/AC10U gets IP address to access the internet from Router 1 automatically. Set static route on AC10/AC10U, achieving LAN devices access both the internet and intranet.

Assume that the devices have following MAC addresses:

- AC10/AC10U LAN IP Address: 192.168.0.1
- Router 1 LAN IP Address: 192.168.1.10
- Router 2 LAN IP Address: 192.168.1.20

Assume that the intranet has following information:

- Address: 172.16.105.10
- Subnet Mask: 255.255.255.0

Procedures:

- Step 1** Set Router 1 to access the internet. Please refer to the installation guide/user guide of the router for detailed steps. Set Router 2 to access the intranet and disable the DHCP function of this router. Please refer to the installation guide / user guide of the router for detailed steps.
- Step 2** Set AC10/AC10U to access the internet by dynamic IP address. Please refer to [5.3 Setting up an internet connection with a dynamic IP address](#) in this user guide for detailed steps.

WAN Port: Ethernet cable connected

Connection Type:

DNS Settings:

Connection Status: Connected. You can access the internet now.

Connection Duration: 10s

Step 3 Set a static route rule on AC10/AC10U.

1. To access the configuration page, click **Advanced Settings > Static Route**.
2. **Destination Network:** Enter IP address of the destination network, which is **172.16.105.0** in this example.
3. **Subnet mask:** Enter subnet mask of the destination IP address, which is **255.255.255.0** in this example.
4. **Gateway:** Set Gateway to the LAN IP address of Router 2, which is **192.168.1.20** in this example.
5. Click **+New**.

Destination Network	Subnet Mask	Gateway	WAN	Operation
172.16.105.0	255.255.255.0	192.168.1.20	WAN1	+New
0.0.0.0	0.0.0.0	192.168.1.10	WAN1	System
192.168.0.0	255.255.255.0	0.0.0.0	br0	System
192.168.1.0	255.255.255.0	0.0.0.0	WAN1	System
224.0.0.0	240.0.0.0	0.0.0.0	br0	System

--End

Configuration succeeds.

Destination Network	Subnet Mask	Gateway	WAN	Operation
			WAN1	+New
0.0.0.0	0.0.0.0	192.168.1.10	WAN1	System
192.168.0.0	255.255.255.0	0.0.0.0	br0	System
192.168.1.0	255.255.255.0	0.0.0.0	WAN1	System
224.0.0.0	240.0.0.0	0.0.0.0	br0	System
172.16.105.0	255.255.255.0	192.168.1.20	WAN1	

Verification


Devices connected to the router can access both the internet and the intranet.

11.9 DDNS

11.9.1 Overview


WAN IP address is needed when Virtual Server, DMZ Host, and Tenda App function are enabled. If router's WAN IP address changes, these functions will not work properly. The DDNS function allows you to map a dynamic WAN IP address (public IP address) of the router to a static domain name, helping internet users (WAN side) access the router by static domain name.

If you dislike remembering complex IP addresses, you can enable the DDNS function. To access the configuration page, click **Advanced Settings > DDNS**.



The screenshot shows a window titled "DDNS" with a close button in the top right corner. In the center, there is a label "DDNS:" followed by a toggle switch that is currently turned off (white). Below the toggle switch is a green "Save" button.

The following figure appears after DDNS is enabled:



The screenshot shows the "DDNS" configuration window after enabling the function. The "DDNS:" toggle switch is now turned on (green). Below it, there are several input fields: "Service Provider:" is a dropdown menu showing "no-ip.com" with a "Register" link to its right; "User Name:" is an empty text box; "Password:" is an empty text box; and "Domain Name:" is an empty text box. At the bottom, the "Connection Status:" is displayed as "Disconnected" in red text. A green "Save" button is located at the bottom center.

Parameter description:

Parameter	Description
DDNS	Used to enable/disable the DDNS function. By default, this function is disabled.
Service Provider	It specifies a DDNS service provider. AC10/AC10U supports service provider no-ip.com, 3322.org, dyndns.org, 88ip.cn, and oray.com.
User Name	It specifies the user name registered on a DDNS service provider's website for logging into the DDNS service.
Password	It specifies the password registered on a DDNS service provider's website for logging into the DDNS service.
Domain Name	It specifies the DDNS domain name registered on a DDNS service provider's website. If this item does not appear after you select service provider, you do not need to enter a domain name manually.
Connection Status	It specifies whether the DDNS service is configured successfully.


11.9.2 Adding a DDNS rule

1. To access the configuration page, click **Advanced Settings** > **DDNS**.
2. **DDNS**: Switch to .
3. **Service Provider**: Choose your DDNS service provider.




If you do not have a DDNS account, please select a service provider and click **Register** to have one on the website of the service provider. After successful registration, log in to the DDNS configuration page to configure again.

4. Set User Name, Password, and Domain Name.
5. Click **Save**.



--End

When the Connection Status displays **Connected**, the configuration succeeds.




11.9.3 Example

Scenario

Michael bought an AC10/AC10U for network after having broadband. He wants to make a web server built on LAN accessible to the internet, and internet users can visit that server by static domain name.

The following figure shows the scenario:



Solution

This requirement can be addressed by Virtual Server function and DDNS function. Assume that the intranet web server has following information:

- Server IP Address: 192.168.0.110
- MAC Address of the Server Host: C8:3A:35:13:05:18
- User Name/Password: admin/admin
- Server Port: 80

Procedures:

Step 1 Register a domain name.

1. To access the configuration page, click **Advanced Settings > DDNS**.
2. **DDNS:** Switch to .
3. **Service Provider:** Select a DDNS service provider, which is **dyndns.org** in this example, and click **Register**.

DDNS configuration window showing the following fields and options:

- DDNS:
- Service Provider: [Register](#)
- User Name:
- Password:
- Domain Name:
- Connection Status: Disconnected
-


4. Register on the website of the selected DDNS service provider. Assume the registered information are listed as follows:
 - Service Provider: dyndns.org
 - User Name: Tenda
 - Password: 12345678
 - Domain Name: tenda.dyndns.org

Step 2 Set DDNS

1. To access the configuration page, click **Advanced Settings > DDNS**.
2. **DDNS:** Switch to .
3. **Service Provider:** Select dyndns.org from drop-down-box.
4. **User Name:** Enter the user name registered on DDNS service provider's website, which is **Tenda** in this example.
5. **Password:** Enter the password registered on DDNS service provider's website, which is **12345678** in this example.
6. **Domain Name:** Enter domain name registered on DDNS service provider's website, which is **tenda.dyndns.org** in this example.
7. Click **Save**.

The screenshot shows a configuration interface for DDNS. At the top, there is a toggle switch labeled 'DDNS:' which is currently turned on (green). Below this are four input fields: 'Service Provider' is a dropdown menu with 'dyndns.org' selected and a 'Register' link to its right; 'User Name' contains the text 'Tenda'; 'Password' is masked with ten black dots; and 'Domain Name' contains 'tenda.dyndns.org'. Below the input fields, the 'Connection Status' is displayed as 'Disconnected' in red text. At the bottom center, there is a large green button labeled 'Save' with a mouse cursor hovering over it.

Wait until the connection status changes to **Connected**.



DDNS:

Service Provider: [Register](#)

User Name:

Password:

Domain Name:


Connection Status: Connected

Step 3 Set Virtual Server function. For detailed steps, please refer to [11.10 Virtual Server](#) in this guide.

--End

Verification

The visit path for internet users to access intranet resources is: http://domain name: server port, which is http://**tenda.dyndns.org.net:80** in this example. Then perform according to onscreen instructions.



11.10 Virtual Server

Usually, internet users cannot access LAN through router, but internet users can visit LAN resources on router by enabling virtual server. After the Virtual Server function is configured, if one host in LAN has Web or FTP server, internet users can access that server successfully.

To access the configuration page, click **Advanced Settings > Virtual Server**.

The screenshot shows a 'Virtual Server' configuration window. It contains a table with the following columns: Internal IP Address, LAN Port, WAN Port, Protocol, and Operation. The LAN Port field is set to 21, and the Protocol field is set to TCP. There is a '+New' button in the Operation column.

Parameter description:

Parameter	Description
Internal IP Address	It specifies the IP address of an internal server.
LAN Port	<p>It specifies the service port number of a server that resides on the LAN of the router.</p> <p>Click drop-down list box, and select corresponding service port number; or enter service port number manually. See the following figure:</p>
WAN Port	It specifies a router port accessible to internet users. WAN port will be populated automatically after you select LAN port.
Protocol	It specifies the protocol of a service. If you are uncertain about which service protocol is used, TCP/UDP is recommended.
Operation	It allows you to add/delete a virtual server rule.


11.10.1 Adding a virtual server rule

1. To access the configuration page, click **Advanced Settings > Virtual Server**.
2. **Internal IP Address:** Enter IP address of the internal sever, which is **192.168.0.110** in this example.
3. **LAN Port:** Click drop-down list box and select internal service port number or enter the number manually, which is **21** in this example.
4. **Protocol:** Select protocol of a service from the drop-down list box, which is **TCP&UDP** in this example.
5. Click **+New**.


Internal IP Address	LAN Port	WAN Port	Protocol	Operation
192.168.0.110	21	21	TCP&UDP	+New


--End

The rule is added successfully. See the following figure:

Internal IP Address	LAN Port	WAN Port	Protocol	Operation
	21		TCP&UDP	+New
192.168.0.110	21	21	TCP&UDP	

11.10.2 Deleting a virtual server rule

1. To access the configuration page, click **Advanced Settings > Virtual Server**.
2. Select the rule you want to delete, and click .

Internal IP Address	LAN Port	WAN Port	Protocol	Operation
	21		TCP&UDP	+New
192.168.0.110	21	21	TCP&UDP	

--End

11.10.3 Example

Scenario

Michael bought an AC10/AC10U for network after having broadband. He wants to make the web server built on LAN accessible to internet users.

The following figure shows the scenario:



Solution

This requirement can be addressed by the Virtual Server function.

Assume that the internal web server information is listed as follows:

- Server IP Address: 192.168.0.110
- MAC Address of the Server Host: C8:3A:35:13:05:18
- User Name/Password: admin/admin
- Server Port: 80

Procedures:

Step 1 Configure the Virtual Server function

1. To access the configuration page, click **Advanced Settings > Virtual Server**.
2. **Internal IP Address:** Enter IP address of the internal web server, which is **192.168.0.110** in this example.
3. **LAN Port:** Click drop-down list box and select internal service port number, which is **80(HTTP)** in this example.
4. **Protocol:** Select protocol of a service from the drop-down list box, which is **TCP&UDP** in this example.
5. Click **+New**.

Internal IP Address	LAN Port	WAN Port	Protocol	Operation
192.168.0.110	80	80	TCP&UDP	+New

The rule is added successfully, see the following figure:

Internal IP Address	LAN Port	WAN Port	Protocol	Operation
	80		TCP&UDP	+New
192.168.0.110	80	80	TCP&UDP	

Step 2 Assign static IP address to the host on which the server is built.

1. Select **System Settings > DHCP Reservation**.
2. **Device Name:** Set a name for the host, which is **Web Server** in this example.
3. **MAC Address:** Enter the MAC address of the host, which is **C8:3A:35:13:05:18** in this example.
4. **IP Address:** Enter the static IP address assigned to the host, which is **192.168.0.110** in this example.
5. Click **+New**.

Device Name	MAC Address	IP Address	Status	Operation
Web Server	C8:3A:35:13:05:18	192.168.0.110	--	+New

--End

The DHCP reservation rule is added successfully. See the following figure:

Device Name	MAC Address	IP Address	Status	Operation
			--	+New
liquilan-PC	4c:cc:6a:ad:14:53	192.168.0.129		
Web Server	C8:3A:35:13:05:18	192.168.0.110		

Verification

Internet users visit this web server in the form of “Protocol: //WAN IP address: external port”, which is **http://102.33.66.88:80** in this example. Then perform according to onscreen instructions.




If you want to visit that server by domain name, you can try the “Virtual Server+DDNS” method.

11.11 DMZ Host

The DMZ Host function If you can set a computer in LAN as DMZ host, that computer will become available to the internet completely, which achieves unlimited bidirectional communication. When you play games or have video meeting on some computer, you can set it as DMZ host for better user experience.

To access the configuration page, click **Advanced Settings > DMZ Host**. By default, the DMZ Host function is disabled.




- A DMZ host is not protected by the firewall of the router because the host is exposed to the internet completely. A hacker may leverage the DMZ host to attack your LAN. Therefore, enable the DMZ function only when necessary.
- Manually set a static IP address for a DMZ host, to prevent changes of dynamic IP address which lead to DMZ function failures.
- Security software, antivirus software, and the built-in OS firewall of the computer may cause DMZ function failures. Disable them when using the DMZ function. If the DMZ function is not required, it is recommended that you disable it and enable your firewall, security, and antivirus software.

11.11.1 Setting a computer to DMZ host

1. To access the configuration page, click **Advanced Settings > DMZ Host**.

2. DMZ Host: Set to .
3. **DMZ Host IP Address:** Enter the last part of the IP address of the computer to be set to DMZ host, which is **110** in this example.
4. Click **Save**.




--End

11.12 UPnP

Universal Plug and Play (UPnP) is a set of networking protocols. This function enables the router to open ports for LAN apps supporting UPnP, which improves user experience.

To access the configuration page, click **Advanced Settings > UPnP**.



After UPnP is enabled, port transfer information displays on the configuration page when UPnP application, such as Thunder, is running in the LAN network. Port transfer information is provided when apps make requests. See the following figure:

UPnP ✕

UPnP:

Remote Host	Internet Port	Local Host	Internal Port	Protocol
anywhere	54321	192.168.0.23	12345	UDP
anywhere	54321	192.168.0.23	54321	TCP

12 System Settings

This module includes the following functions: [LAN Settings](#), [DHCP Reservation](#), [WAN Settings](#), [Time Settings](#), [Login Password](#), [Reboot and Reset](#), [Firmware Upgrade](#), [Backup/Restore](#), [Remote Management](#), [System Status](#), [System Log](#), and [Automatic Maintenance](#).

12.1 LAN Settings

12.1.1 Overview

This module enables you to do the followings:

- Modify the LAN IP address of the router.


The LAN IP address is the management IP address of the router, which is **192.168.0.1** by default but can be modified if necessary.

- Modify parameters of DHCP server.

If the DHCP Server function is enabled, the DHCP server can automatically assign IP addresses, subnet mask, gateway and other internet parameters to the devices connected to the router. If this function is disabled, you have to manually set the IP address settings on your devices to access the internet. You are recommended to retain the DHCP Server function enabled.

- Configure the DNS information assigned to devices.

To access the configuration page, click **System Settings > LAN Settings**.



LAN Settings

LAN IP Address:

Subnet Mask:


DHCP Server:

IP Address Range: 192.168.0. ~

Lease Time:

DNS Settings:

Parameter description:

Parameter	Description
LAN IP Address	<p>It specifies the LAN IP address of the router, which is the IP address used to log in to the web UI of the router.</p> <p>You can log in to the web UI of the router through either IP address (default: 192.168.0.1) or the domain name (tendawifi.com).</p>
Subnet Mask	It specifies the subnet mask of the IP address of the router.
DHCP Server	<p>IP Address Range It specifies the IP addresses assigned by the DHCP server to devices, which ranges from 192.168.0.100 to 192.168.0.200 by default.</p>
	<p>It specifies the validity period of an IP address assigned by the DHCP server to a device. When the lease time expires:</p> <ul style="list-style-type: none"> – If the device is still connected to the router, the device automatically extends the lease time and continues to use this IP address. – If the device has been disconnected (shutdown, or the Ethernet cable between the device and the router has been removed) from the router, the router recycles the IP address. The router assigns this IP address to other devices requested for IP addresses. <p>You are recommended to retain the default value.</p>
	<p>Lease Time</p>
DNS Settings	<p>It specifies the primary DNS server IP address assigned by the DHCP server to LAN devices.</p>
	<p>Primary DNS Server</p> <p> NOTE</p> <p>Generally, you are recommended to retain the default configuration. If it is necessary to change the default configuration, please set this parameter to a correct DNS server IP address or DNS proxy IP address, to enable devices to access the internet.</p>
	<p>Secondary DNS Server</p> <p>It specifies the secondary DNS server IP address assigned by the DHCP server to devices. This parameter is optional. If it is empty, the DHCP server does not assign it to devices.</p>

12.1.2 Changing the LAN IP address

1. To access the configuration page, click **System Settings** > **LAN Settings**.
2. **LAN IP Address**: Modify the **LAN IP Address**, which is **192.168.3.1** in this example.
3. Click **Save** in the bottom of the page.

LAN IP Address:

Subnet Mask:

DHCP Server:

IP Address Range: 192.168.3. ~

Lease Time:

DNS Settings:

--End

Wait till the modification completes successfully, you will be redirected to the login page. If you fail to log in to the web UI of the router, ensure that the local connection of your computer is set to **Obtain an IP address automatically**. Then release the current IP address of your computer and try to log in again after your computer get new IP address. If the problem still persists, please try logging in again using **tendawifi.com**. For details about how to set local area connection of your computer, please refer to **A1 Setting the IP address of your computer** in the appendixes. To release the current IP address of your computer, disconnect the Ethernet cable between your router and computer for a while, and reconnect it soon.




12.2 DHCP Reservation

This function allows the device to obtain the same IP address all the time, ensuring the Virtual Server and DMZ Host functions that requires fixed IP address take effect normally.

To access the configuration page, click **System Settings > DHCP Reservation**.


DHCP Reservation				
Device Name	MAC Address	IP Address	Status	Operation
<input type="text" value="Optional"/>	<input type="text"/>	<input type="text"/>	---	<input type="button" value="+New"/>

Parameter description:

Parameter	Description
Device Name	It specifies the name of the device to be bound with a fixed IP address.
MAC Address	It specifies the MAC address of a device.
IP Address	It specifies the IP address to be bound with the device indicated by the corresponding MAC address.
Status	It indicates whether a device is connected to the router or not.
Operation	<p>It is used to edit a DHCP Reservation rule, including four operations:</p> <ul style="list-style-type: none"> – +New : It is used to add a DHCP Reservation rule. –  : It is used to bind a device with a static IP. –  : It is used to unbind a device with a static IP. –  : It is used to delete a DHCP Reservation rule.


12.2.1 Adding a DHCP reservation rule

1. To access the configuration page, click **System Settings > DHCP Reservation**.
2. **Device Name**: Enter the device name used to assign static IP addresses, which is **Web Server** in this example.
3. **MAC Address**: Enter the MAC address of the device, which is **C8:3A:35:13:05:18** in this example.
4. **IP Address**: Enter the static IP address assigned to the device, which is **192.168.0.110** in this example.
5. Click **+New**.




--End


The DHCP reservation rule is added successfully. See the following figure:



12.2.2 Deleting a DHCP reservation rule

1. To access the configuration page, click **System Settings > DHCP Reservation**.

2. Locate the rule you want to delete, and click .




--End

12.3 WAN Settings

12.3.1 Overview

This module enables you to modify MTU, speed and MAC address of the WAN port. If you cannot access the internet after configuring the internet settings, try modifying the WAN parameters.

To access the configuration page, click **System Settings > WAN Settings**.



Parameter description:

Parameter	Description
MTU	Maximum transmission unit (MTU). It specifies the size of the largest data packet that can be transmitted across the network devices. You are recommended to retain the default value.
Speed	It specifies the speed of the WAN port of the router. If the LED indicator of the WAN port is off, or does not turn on until 5 seconds later under the circumstance that the quality Ethernet cable has been connected correctly, you can select 10 Mbps FDX or 10 Mbps HDX from the drop-down list box of Speed . Otherwise, you are recommended to retain the default configuration 1000 Mbps

Parameter	Description
	Auto-negotiation.
	It is used to clone the MAC address accessible to the internet to the WAN port of the router. If the router cannot access the internet after you configure the internet settings, it is perhaps that the ISP has bound the connection information with a MAC address. In this case, you can try to clone the MAC address, and try to access the internet again.
MAC Address	<ul style="list-style-type: none"> - Default: It is used to restore the MAC address of the WAN port of the router to factory settings. - Clone local MAC address: It is used to set the MAC address of the WAN port to the MAC address of the current device managing the router. - Set MAC address: It is used to set the MAC address of the WAN port manually.

12.3.2 Changing MTU value

You are recommended to retain the default value of MTU, unless the following cases happen:

- Websites are inaccessible, or you cannot log in to some secure websites (such as paypal login page).
- Email service fails, or FTP, POP and other servers are inaccessible.

In these cases, you can try to decrease the MTU value from the maximum one (recommended range: 1400-1500), till the problem is resolved.


MTU	Description
1500	It is commonly used for ADSL and non-VPN dial-up connections.
1492	It is used for PPPoE dial-up connections.
1472	It is the maximum value for the ping command. (A packet with a size larger than 1472 is splitted.)
1468	It is used for DHCP connections.
1436	It is used for VPN or PPTP connections.

12.3.3 Changing the MAC address of the WAN port



Ensure that the MAC address to be cloned is correct! Before you have AC10/AC10U, the MAC address of your computer that can access to the internet through the Ethernet jack, or the WAN MAC address of your original router that can access to the internet, is the correct MAC address you should clone.

1. To access the configuration page, click **System Settings > WAN Settings**.
2. **MAC Address:** Select **Clone local MAC address** or **Set MAC address** from the drop down list box. If you select **Set MAC address**, enter the MAC address that you want to clone. If you select **Clone local MAC address**, configure this function on the computer with a correct MAC address.
3. Click **Save**.



WAN Settings

MTU:

Speed:

MAC Address: Default: C8:3A:35:84:2E:71

--End

To verify if cloning MAC address is successful, choose **System Settings > System Status**, if the MAC address under the WAN Status is same as the MAC address you select to clone, MAC address cloning succeeds. If the internet is inaccessible after you clone the MAC address successfully, contact your ISP to resolve this issue.


12.4 Time Settings

12.4.1 Overview

This module enables you to set the system time of the router. Correct system time of the router makes time-based functions take effect successfully, such as the WiFi Schedule, Parental Control, LED Control, Sleeping Mode, and Automatic Maintenance functions. Please keep the system time of your router correct.

To access the configuration page, click **System Settings > Time Settings**.

The default time zone of the router is **(GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi, Taipei**. After connected, the router automatically synchronizes its system time with the time zone you select.



Time Settings

Select Time Zone:


Current Time: 2018-01-22 17:41:52 (synchronized with internet time)

12.5 Login Password

12.5.1 Overview

This module enables you to modify the login password of the router. The login password is used to log in to the web UI of the router. By default, the router has no login password. You are recommended to configure a login password when you set up the router for the first time.

To access the configuration page, click **System Settings > Login Password**.



Login Password


New Password:

Confirm Password:

Save

12.5.2 Changing the login password

1. To access the configuration page, click **System Settings > Login Password**.
2. **New Password:** Set a new login password.
3. **Confirm Password:** Enter the new login password again.
4. Click **Save**.



Login Password

New Password:


Confirm Password:

Save

--End

You will be redirected to the login page. Enter the new login password, and click **Login** to login to the web UI

of the router.




12.6 Reboot and Reset

12.6.1 Overview

This module enables you to reboot the router or restore the router to factory settings.


- If a setting does not take effect or the router does not work properly, you can try rebooting the router to resolve the problem.
- If the internet is inaccessible for unknown reasons, or you forget the login password, you are recommended to restore the router to factory settings and reconfigure it. The router can be reset through the web UI or holding down the **RST/WPS** button on the back panel of the router for 8 seconds. After resetting the router, refer to [Chapter 2 Set up to access the internet](#) to configure your router for internet connection.

To access the configuration page, click **System Settings > Reboot and Reset**.



12.6.2 Rebooting the router

1. To access the configuration page, click **System Settings > Reboot and Reset**.
2. Click **Reboot**.



--End


12.6.3 Resetting the router



Resetting the router deletes all your current configuration. You need to reconfigure the router to access the internet. Ensure that the power supply of the router is properly when the router is resetting.

Resetting the router via the web UI

1. To access the configuration page, click **System Settings > Reboot and Reset**.
2. Click **Reset**. Your router is reset successfully when all the indicators blink once. Then wait for the router to restart.



--End

Resetting the router via the RST/WPS button

Power on your router. When the SYS indicator blinks, hold the **RST/WPS** button down for about 8 seconds. Your router is reset successfully when all the indicators blink once.


12.7 Firmware Upgrade

12.7.1 Overview

This module enables you to upgrade the firmware of the router.

Firmware upgrade offers the router with more stable performance and new functions. The router supports **Online Upgrade** and **Local Upgrade**, and the default setting is **Online Upgrade**, which means the router automatically detects whether the new firmware is available or not and displays its information if any.

To access the configuration page, click **System Settings > Firmware Upgrade**.




12.7.2 Steps for local upgrade




- Before an upgrade, check if the firmware is accurate. Erroneous firmware will damage the router.
- Do not power off the router during an upgrade. Otherwise, the router may be damaged.
- After the firmware is upgraded, you are recommended to restore the factory settings of the router and configure the router again, so as to ensure stability of the new firmware and proper operation of its new functions.

1. Log in to the official website of Tenda <http://www.tendacn.com> and download the latest firmware to your computer.
2. Log in to the web UI of the router, and choose **System Settings > Firmware Upgrade**.
3. **Upgrade Type:** Click **Local Upgrade**.
4. **Select Upgrade File:** Click **Choose File**, and select the firmware that has been downloaded to your computer.



5. Click **Upgrade**.



--End

Wait a second for the upgrade to complete. You can go to the **Internet Status** page to see whether the upgrade succeeds. If it does, reset your router and configure it again to access the internet.


12.7.3 Checking your firmware version

1. Log in to the web UI of the router, restore the router to the factory settings, and reconfigure the router.
2. After login to the web UI, click **System Settings > Firmware Upgrade**.
3. Check whether the current firmware version of the router is the same as the one you used for upgrade just now.

12.7.4 Steps for online upgrade

After connecting to the internet, the router detects firmware version automatically. If new firmware is available, you can choose **Online Upgrade** to upgrade the router's firmware.

1. To access the configuration page, click **System Settings > Firmware Upgrade**.
2. Click **Upgrade**.



--End

Wait for the upgrade to complete. You will be redirected to the login page of the router after successful upgrade.


12.8 Backup/Restore

12.8.1 Overview

This module enables you to back up the current configuration of your router to your computer, or restore your router to a previous configuration by importing the configuration file on your computer to the router.

The module enables you to back up the router's configuration in case that you lost all the configuration after resetting the router. After you clicking **Backup**, the system generates a configuration file. If the router is restored to factory settings, importing the configuration file can restore the router to the previous settings.

To access the configuration page, click **System Settings > Backup/Restore**.



- **Backup:** It is used to back up the current configuration of the router.
- **Restore:** It is used to restore the router to previous settings by importing the backup configuration file.

12.8.2 Steps for backup

1. To access the configuration page, click **System Settings > Backup/Restore**.
2. Click **Backup**.
3. Follow the onscreen instructions to backup the configuration.

--End

12.8.3 Steps for restore

1. To access the configuration page, click **System Settings > Backup/Restore**.
2. Click **Restore**, and select the configuration file to be restored.
3. Wait for the router to reboot.

--End


12.9 Remote Management

12.9.1 Overview

This module enables you to login to the web UI of the router over the internet.

Generally, only devices connected to the router can log in to the web UI of the router. But if necessary, you can to log in to the web UI of the router remotely over the internet.

To access the configuration page, click **System Settings > Remote Management**.



The following figure appears after this function is enabled:

Remote Management
✕

Remote Management:

Remote IP Address:


Port:

Parameter description:

Parameter	Description
Remote Management	Used to enable/disable the remote management function. By default, this function is disabled.
Remote IP Address	It specifies the IP address that can access the router remotely.
Port	<p>It specifies the port number needed when you manage the router remotely. The default port number is 8080, which can be modified if necessary.</p> <div style="display: flex; align-items: center; margin-top: 10px;"> TIP </div> <p>Since ports 1 to 1024 are used by well-known service, you are strongly recommended to set the value in the range of 1025~65535 to prevent port confliction.</p>

12.9.2 Configuring remote management

1. To access the configuration page, click **System Settings > Remote Management**.
2. **Remote Management:** Set to .
3. **Remote IP Address:** Set the IP address allowed to access the router remotely.
4. **Port:** Set the port number used for remote access. You are recommended to keep the default value if you do not have special requirement.
5. Click **Save**.




--End

Scenario

Michael bought an AC10/AC10U for network after having broadband. The WAN IP address of the router is 202.105.106.55. Michael needs to log in to the web UI of the router on business trip.

Solution

The remote management function can address this requirement. The following figure shows a network topology for reference:



Procedures:

1. To access the configuration page, click **System Settings > Remote Management**.
2. **Remote Management:** Set to .
3. **Remote IP Address:** Enter remote IP address, which is 0.0.0.0 in this example.

4. **Port:** Keep the default settings.
5. Click **Save**.



Remote Management:

Remote IP Address:

Port:

--End

Verification

You can log into the web UI of the router to manage it by accessing <http://202.105.106.55:8080> on the remote computer with the IP address **0.0.0.0**.


12.10 System Status

This module enables you to view the basic information of the router, including the **Information**, **WAN Status**, **LAN Status**, and **WiFi Status** sections.

To access the configuration page, click **System Settings > System Status**.

12.10.1 Information

This module enables you to view system time, uptime, firmware version, and hardware version. See the following figure:




Parameter description:

Parameter	Description
System Time	It specifies the current system time of the router. Ensure that the router is connected to the internet properly.
Uptime	It specifies the time that has elapsed since the router was previously started.
Firmware Version	It specifies the current firmware version of the router. You can check whether the firmware upgrade configured in Firmware Upgrade succeeded or not here.
Hardware Version	It specifies the current hardware version of the router.

12.10.2 WAN Status

This module enables you to view the WAN status of the router. See the following figure:



The screenshot displays the WAN Status configuration page. At the top, it shows 'System Status' and 'WAN Status'. The connection type is 'Dynamic IP Address', and the status is 'Connected'. The connection duration is '1 hour(s) 49 min 49 s'. The IP address is '192.168.20.187', the subnet mask is '255.255.255.0', and the default gateway is '192.168.20.100'. The primary DNS is '192.168.20.100', and the secondary DNS is blank. The MAC address is 'C8:3A:35:84:2E:71'.


Parameter description:

Parameter	Description
Connection Type	It specifies the current connection type of the router.
Connection Status	It specifies the current connection status of the router.
Connection Duration	It specifies the time that has elapsed since the router was connected to the internet previously.

IP Address	It specifies the WAN IP address of the router. This parameter is needed for when you use functions like Virtual Server or Remote Management.
Subnet Mask	It specifies the subnet mask of the WAN IP address of the router.
Default Gateway	It specifies the gateway assigned to the router.
Primary DNS	It specifies the primary DNS assigned to the router.
Secondary DNS	It specifies the secondary DNS assigned to the router.
MAC Address	It specifies the MAC address of the WAN port of the router. You can check whether the MAC clone configured in WAN Settings succeeded here.

12.10.3 LAN Status

This module enables you view the LAN IP address (the login IP address) of the router.



Parameter description:

Parameter	Description
IP Address	It specifies the LAN IP address of the router, which is the IP address used to log in to the web UI of the router. You can log in to the web UI of the router through either IP address (default: 192.168.0.1) or the domain name (tendawifi.com).
Subnet Mask	It specifies the subnet mask of the LAN IP address of the router.
MAC Address	It specifies the MAC address of the LAN port of the router.

12.10.4 WiFi Status

This module allows you to view the WiFi status of the router, such as WiFi name, whether the WiFi network is enabled or not. See the following figure:

System Status

WiFi Status

2.4 GHz Network: Visible

Hotspot Name: Tenda_842E68

Encryption Mode: None

WiFi Channel: 4

WiFi Bandwidth: 20

MAC Address: C8:3A:35:84:2E:69

5 GHz Network: Visible

Hotspot Name: Tenda_842E68_5G

Encryption Mode: None

WiFi Channel: 157

WiFi Bandwidth: 80

MAC Address: C8:3A:35:84:2E:6D

Parameter description:


Parameter	Description
	It specifies the WiFi status over 2.4 GHz/5 GHz network of the router.
2.4 GHz/ 5 GHz Network	<ul style="list-style-type: none"> – Disable: It indicates that the WiFi network is disabled. – Visible: It indicates that the WiFi network is enabled and users can connect the Hotspot Name of the WiFi network to access the internet.
Hotspot Name	It specifies the current WiFi name of the router. After the 2.4 GHz/5 GHz WiFi network is enabled, smart devices can scan and connect to it to access the internet.
Encryption Mode	It specifies the encryption mode of the WiFi network of the router.
WiFi Channel	It specifies the current wireless data transmission channel of the router.
WiFi Bandwidth	It specifies the bandwidth of the operating channel of the router's WiFi network, with a unit MHz.
MAC Address	It specifies the MAC address of the WiFi network of the router.

12.11 System Log

This module enables you to view the system log information. The system logs can be used for troubleshooting

when the router is faulty.

To access the configuration page, click **System Settings > System Log**.



The screenshot shows a window titled "System Log" with a close button (X) in the top right corner. Below the title bar, there is a note: "Note: If the router is not connected to the internet, the default logging time is 2000-X-X XX:XX:XX." Below the note is a table with four columns: "Number", "Time", "Type", and "Log Content". The table contains seven rows of log entries.

Number	Time	Type	Log Content
1	2018-02-01 19:25:17	wan	DHCP_ack Received From (192.168.20.100)
2	2018-02-01 19:25:17	wan	Sending DHCP_renew for 192.168.20.187 to 192.168....
3	2018-02-01 19:11:37	wan	DHCP_ack Received From (192.168.20.100)
4	2018-02-01 19:11:37	wan	Sending DHCP_renew for 192.168.20.187 to 192.168....
5	2018-02-01 18:58:09	wan	DHCP_ack Received From (192.168.20.100)
6	2018-02-01 18:58:09	wan	Sending DHCP_renew for 192.168.20.187 to 192.168....
7	2018-02-01 18:49:08	system	LAN3 up

Clicking **Export** can export the system log to your local computer.

12.12 Automatic Maintenance

12.12.1 Overview

This module enables you to set the router to reboot at a specified time, improving the system stability and service life of the router.

To access the configuration page, click **System Settings > Automatic Maintenance**. By default, the Automatic Maintenance function is enabled.

Automatic Maintenance
✕

System Reboot Schedule:

Reboot At: :

Delay: Delay rebooting the router when it is exchanging data with a device at a speed higher than 3 KB/s.

Parameter description:

Parameter	Description
System Reboot Schedule	Used to enable or disable the system reboot schedule function.
Reboot At	It specifies the time for the router to reboot.
Delay	<p>It specifies the premise for the router to delay a reboot.</p> <ul style="list-style-type: none"> – Selected: The router reboots automatically when there are devices connected to the router, and the traffic over the WAN port is less than 3 KB/s for 30 minutes; or there are no device connected to the router, and the traffic over the WAN port is less than 3 KB/s for 3 minutes. – Unselected: The router reboots automatically when the time for the router to reboot is up.

12.12.2 Configuring system reboot schedule

1. To access the configuration page, click **System Settings > Automatic Maintenance**.
2. **Reboot At:** Select the time to reboot from the drop-down list box, which is **23:30** in this example.
3. Click **Save**.

Automatic Maintenance ✕

System Reboot Schedule:

Reboot At: :

Delay: Delay rebooting the router when it is exchanging data with a device at a speed higher than 3 KB/s.

--End

After the configuration above, the router reboots automatically at 23:30 every day if there are devices connected to the router, and the traffic over the WAN port is less than 3 KB/s for 30 minutes; or there are no devices connected to the router, and the traffic over the WAN port is less than 3 KB/s for 3 minutes.


Appendixes

A.1 Setting the IP address of your computer


The following describes the configuration steps for Win8 and Win7. Choose the proper instructions according to your computer system. A computer installed with a wired network adapter is used as an example here to describe the procedures. Steps for configuring a computer installed with a wireless adapter are similar.

A.1.1 Windows 8


1. Right-click  in the lower-right corner of the desktop and choose **Open Network and Sharing Center**.




2. Click **Ethernet** and **Properties**.



3. Double-click **Internet Protocol Version 4 (TCP/IPv4)**.




4. Select **Obtain an IP address automatically** and **Obtain DNS server address automatically**, and click **OK**.




5. You are redirected to the **Ethernet Properties** box, and click **OK**.

A.1.2 Windows 7


1. Right-click  in the lower-right corner of the desktop and choose **Open Network and Sharing Center**.




2. Click **Local Area Connection > Properties.**



3. Double-click **Internet Protocol Version 4 (TCP/IPv4).**



4. Select **Obtain an IP address automatically** and **Obtain DNS server address automatically**, and click **OK**.



5. You are redirected to the **Internet Properties** box, and click **OK**.

A.2 FAQ


Q1: I cannot access the web UI of the router after entering **tendawifi.com** or **192.168.0.1**. What should I do?

A1: Try the following solutions and log in again:

- Ensure that your Ethernet cable with internet connectivity is plugged into the WAN port of the router rather than a LAN port.
- Ensure that your wireless device is connected to the router's SSID.
- Ensure that your wired device is connected to port 1, 2 or 3 of the router properly by Ethernet cable. And the device is also set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.
- Ensure that **tendawifi.com** is entered correctly, or you can try logging by entering **192.168.0.1**.
- Clear the cache of your web browser or replace the web browser, and try logging in again.
- Disable the firewall of your computer or replace the computer, and try logging in again.
- If the problem persists, reset your router and try logging in again.

Q2: How to choose my connection type?

A2: You can choose your internet connection type based on the following table or by consulting your internet service provider (ISP).


Internet connection media	Internet connection type	Description
Telephone line/Ethernet cable	PPPoE	You need to double-click  and enter a PPPoE user name and password to set up a dial-up connection.
TV cable/Ethernet cable	Dynamic IP address	You can access the internet after connecting to an upstream router or a cable TV.
Ethernet cable/Optical fiber	Static IP address	You are assigned a static IP address, a subnet mask, a default gateway address, and DNS server address for accessing the internet.

Q3: I cannot access the internet after configuring internet settings. What should I do?

A3: Try the following solutions and log in again:

Log in to the web UI of the router, and check your router's connection status on the Internet Status page.

- If your router is connected to the internet successfully as the figure shown below, try the following solutions:



Connect your wireless devices to the WiFi network of the router using the new WiFi name and password you set.

- If **Connection failed** appears on the page:
 - Click **Internet Settings** on the web UI to check whether the connection type and parameters you entered are correct.

Connection type	Information provided by your ISP
PPPoE	ISP user name and ISP password
Dynamic IP address	None
Static IP address	IP address, subnet mask, gateway, DNS server and other parameters

- Connect the Ethernet cable with internet connectivity to your computer directly.
 - ◆ If your computer cannot access the internet, consult your ISP.
 - ◆ Otherwise, reconnect the Ethernet cable with internet connectivity to your router, reset your router and configure it again.

Q4: How to reset the router if I cannot access the web UI of the router?

A4: Power on your router. When the **SYS** indicator blinks, hold down the **RST/WPS** button for about 8 seconds. The router is reset successfully when all the LED indicators blink once.

Q5: An IP address conflict message appears after a computer which is connected to the router starts. What should I do?

A5: Try checking the following items:

- Ensure that there is no other DHCP server in your LAN or the other DHCP server is disabled.
- Verify that the IP address of your router is not used by another device in your LAN. The default IP address of the router is 192.168.0.1.
- Ensure that the static IP address assigned to the computer in your LAN is not used by other devices.

Q6: I forget the login password of the router. What should I do?

A6: Reset the router and log in the router's web UI.

Method to reset: Power on your router. When the **SYS** indicator blinks, hold down the **RST/WPS** button for about 8 seconds. The router is reset successfully when all the LED indicators blink once



CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Operations in the 5.15-5.25 GHz band are restricted to indoor use only.

This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

The mains plug is used as disconnect device, the disconnect device shall remain readily operable.

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

Declaration of Conformity

Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the radio equipment type AC10 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
<http://www.tendacn.com/en/service/download-cata-101.html>

Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the radio equipment type AC10U is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
<http://www.tendacn.com/en/service/download-cata-101.html>

Operate Frequency:

2.4 GHz: EU/2400-2483.5 MHz (CH1-CH13)

5 GHz: EU/5150-5250 MHz (CH36-CH48)

EIRP Power (Max.):

2.4 GHz: 19.95 dBm

5 GHz: 22.9 dBm

Software Version: V15.03.06




Caution : **(For AC10)**

Adapter Model: BN036-A12012E

Manufacture: SHENZHEN HEWEISHUN NETWORK TECHNOLOGY Co., LTD.

Input: 100 - 240 V AC 50/60 Hz 0.4 A

Output: 12 V dc 1 A

 : DC Voltage




Caution : **(For AC10U)**

Adapter Model: BN037-A18012E

Manufacture: SHENZHEN HEWEISHUN NETWORK TECHNOLOGY Co., LTD.

Input: 100 - 240 V AC 50/60 Hz 0.6 A

Output: 12 V dc 1.5 A

 : DC Voltage



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device is for indoor usage only.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Caution:


Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

Operating Temperature: 0 °C - 40 °C

Operating Humidity: (10 – 90)% RH, non-condensing




RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys new electrical or electronic equipment.

EAC

	BE	BG	CZ	DK	DE	EE	IE
	EL	ES	FR	HR	IT	CY	LV
	LT	LU	HU	MT	NL	AT	PL
	PT	RO	SI	SK	FI	SE	UK

Copyright © 2018 Shenzhen Tenda Technology Co., Ltd. All rights reserved.

Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.

Technical Support

USA hotline: 1-800-570-5892

Toll Free: Daily-9am to 6pm EST

Canada hotline: 1-888-998-8966

Toll Free: Mon - Fri 9 am - 6 pm PST

Website: <http://www.tendaus.com>

Email: support.usa@tenda.com.cn

Hong Kong Hotline: 00852-81931998

Website: <http://www.tendacn.com>

E-mail: support@tenda.com.cn