

# TRENDNET®

## User's Guide



## 4-Port Industrial Modbus Gateway Industrial Modbus Gateway

TI-M42 / TI-M12

# Contents

<b>1. REPRESENTATIVE APPLICATIONS .....</b>	<b>3</b>
1.1 Multiple Serial Slaves connected from Ethernet Masters .....	3
1.2 Serial Slaves with ASCII and RTU connected from Ethernet Masters.....	5
1.3 Serial Masters connect Multiple Ethernet Slaves.....	6
<b>2. FUNCTIONAL PROPERTIES .....</b>	<b>7</b>
2.1 Overview.....	7
2.2 Login .....	7
2.3 Basic.....	8
2.3.1 System.....	8
2.3.2 Port .....	8
2.3.3 Device .....	9
2.3.4 Time .....	9
2.3.5 Console .....	10
2.3.6 Email .....	10
2.3.7 Ping .....	11
2.4 Accessible IP .....	12
2.5 Network .....	13
2.6 Modbus Gateway.....	14
2.6.1 Serial Port .....	14
2.6.2 MB COM .....	15
2.6.3 Modbus Config.....	16
2.6.3.1 Router .....	16
2.6.3.2 ID Mapping .....	18
2.6.3.3 Parameters.....	21
2.6.4 Priority Control .....	22
2.6.4.1 Master.....	22
2.6.4.2 TCP .....	23
2.6.4.3 Request.....	23
2.7 SNMP .....	24
2.7.1 SNMP Settings .....	24
2.7.2 Event .....	25
2.8 Maintenance.....	26
2.8.1 Change Password.....	26
2.8.2 Load Default.....	26
2.8.3 Firmware Update.....	27
<b>3. Software MBcom administration utility .....</b>	<b>28</b>
3.1 Overview.....	28
3.2 Installation the MBCOM utility.....	28
3.3 Search device .....	31
3.4 COM Mapping.....	32

# 1. REPRESENTATIVE APPLICATIONS

## 1.1 Multiple Serial Slaves connected from Ethernet Masters

In order to get data collection and control from discrete Modbus serial devices. Most host computer over Ethernet can rely on the Modbus gateway. The products supports serial interface RS-232, RS-422 and RS-485 and supports Modbus TCP 32 connections.

### Master

Parameters (both of device 1 & 2):

### Parameters Setup

Initial Delay:	<input type="text" value="0"/>	(0-30000ms)
Listen Port:	<input type="text" value="502"/>	(1 - 65535)
TCP Exception:	<input type="text" value="Disable"/>	
TCP Timeout:	<input type="text" value="1000"/>	(10 - 120000ms)

### Device 1

Slave side

Serial:

### Serial 1 Setup

Mode:	<input type="text" value="RTU Slave"/>	Baud Rate:	<input type="text" value="921600"/>
Data Bits:	<input type="text" value="8"/>	Any Baud Rate:	<input type="text" value="50"/> (50 - 921600)
Stop Bits:	<input type="text" value="1"/>	Parity:	<input type="text" value="None"/>
Interface:	<input type="text" value="RS-232"/>	Flow Control:	<input type="text" value="None"/>
RTS ON delay:	<input type="text" value="0"/> (0-100ms)	RTS OFF delay:	<input type="text" value="0"/> (0-100ms)

ID Mapping:

### ID Mapping Setup

Auto Device Routing	<input type="text" value="Disable"/>	Page	<input type="text" value="1 ~ 20"/>	
Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
1	Manual	Serial	1-1<=>1-1	Serial 1

## Device 2

Serial:

### Serial 2 Setup

Mode:	RTU Slave	Baud Rate:	921600
Data Bits:	8	Any Baud Rate:	50 (50 - 921600)
Stop Bits:	1	Parity:	None
Interface:	RS-485 2-Wire	Flow Control:	None
RTS ON delay:	0 (0-100ms)	RTS OFF delay:	0 (0-100ms)

ID Mapping:

### ID Mapping Setup

Auto Device Routing

Page

	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input type="radio"/>	1	Manual	Serial	2-4<=>2-4	Serial 2

## 1.2 Serial Slaves with ASCII and RTU connected from Ethernet

### Masters

TCP master devices can get connection with Modbus slave devices of different parameters. For example, access data both ASCII and RTU at the same time.

You can configure Modbus series products each serial port to be an environment for particular Modbus serial slave parameters. After you configure the ID mapping setup, Modbus TCP master can access Modbus serial devices passed through Modbus series products.

#### Master side

Parameters :

### Parameters Setup

Initial Delay:	<input type="text" value="0"/>	(0-30000ms)
Listen Port:	<input type="text" value="502"/>	(1 - 65535)
TCP Exception:	<input type="text" value="Disable"/>	
TCP Timeout:	<input type="text" value="1000"/>	(10 - 120000ms)

#### Slave side

Serial : (RTU slave or ASCII slave)

### Serial 1 Setup

Mode:	<input type="text" value="RTU Slave"/>	Baud Rate:	<input type="text" value="1200"/>
Data Bits:	<input type="text" value="8"/>	Any Baud Rate:	<input type="text" value="50"/> (50 - 921600)
Stop Bits:	<input type="text" value="1"/>	Parity:	<input type="text" value="None"/>
Interface:	<input type="text" value="RS-232"/>	Flow Control:	<input type="text" value="None"/>
RTS ON delay:	<input type="text" value="0"/> (0-100ms)	RTS OFF delay:	<input type="text" value="0"/> (0-100ms)

ID Mapping :

### ID Mapping Setup

Auto Device Routing	<input type="text" value="Disable"/>	Page	<input type="text" value="1 ~ 20"/>		
	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input type="radio"/>	1	Manual	Serial	1-1<=>1-1	Serial 1
<input type="radio"/>	2	Manual	Serial	2-2<=>2-2	Serial 2
<input type="radio"/>	3	Manual	Serial	3-3<=>3-3	Serial 3

# 1.3 Serial Masters connect Multiple Ethernet Slaves

If you use a Modbus serial master with only serial interface and need to access Modbus TCP slave devices. The Modbus series product can set parameters for connection with serial-based PC and slave device over an Ethernet. It supports up to 32 Modbus TCP slave connection.

## Master side

Serial : (RTU master or ASCII master)

### Serial 1 Setup

Mode:	RTU Master	Baud Rate:	921600
Data Bits:	8	Any Baud Rate:	50 (50 - 921600)
Stop Bits:	1	Parity:	None
Interface:	RS-232	Flow Control:	None
RTS ON delay:	0 (0-100ms)	RTS OFF delay:	0 (0-100ms)

## Slave side

ID Mapping :

### ID Mapping Setup

Auto Device Routing	Disable	Page	1 ~ 20		
	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input checked="" type="radio"/>	1	Manual	TCP	1-1<=>1-1	192.168.2.10:502
<input type="radio"/>	2	Manual	TCP	2-2<=>2-2	192.168.2.20:502

# 2. FUNCTIONAL PROPERTIES

---

## 2.1 Overview


This section describes the functions of each item in main menu. Each item lists point out the details of the parameters and the defaults set by the Modbus series products device.

In addition, users can easily configure Modbus series devices through Web, Remote console.

## 2.2 Login

To open the web console, enter your device IP address in browser. Modbus device default IP is address, [192.168.2.1](http://192.168.2.1).

If you are configuring at first time, you will use default username and password to login, default username, password and language is “[admin](#) / [system](#) / [English](#)”. In addition, the switch of menu language is saved and takes effect after login.



Login	
User Name	admin
Password	.....
Menu Language	English ▼
<input type="button" value="Login"/>	

Suggested that uses IE7, 8, Firefox, Google the Chrome browser.

## 2.3 Basic

### 2.3.1 System

This page provides basic information for the current product the page provides basic information for the current device. Can helps an administrator to identify software version, system uptime and IP address.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
<h2>System Status</h2>							
<b>Device Information</b>							
Model:	4 ports	Firmware Version:	v.1.201111_1442				
Server name:	Modbus Gateway	System Up Time:	0 days 0h:0m:48s				
Current Time:	2000-01-01 00:00						
<b>IPv4 Configuration</b>							
IP Configuration:	Static						
IP Address:	192.168.2.1	Subnet Mask:	255.255.255.0				
Gateway:		Primary DNS:					
Second DNS:		MAC Address:	b8:c4:6f:00:00:1b				

### 2.3.2 Port

This page shows the status of each port, including operating mode and serial settings, the serial number (No.) can be directly linked to the corresponding page settings.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
System	Port Status	Device	Time	Console	Email	Ping	
<h2>Serial Port Status</h2>							
No.	Mode	Baud Rate	Stop Bits	Data Bits	Parity	Interface	Flow Control
<a href="#">1</a>	RTU Slave	921600	1	8	None	RS-485 2-Wire	None
<a href="#">2</a>	RTU Slave	921600	1	8	None	RS-485 2-Wire	None
<a href="#">3</a>	RTU Slave	921600	1	8	None	RS-485 2-Wire	None
<a href="#">4</a>	RTU Slave	9600	1	8	None	RS-485 2-Wire	None



### 2.3.3 Device

**Server name (default = Modbus Gateway)** : User can named for the server, which helps distinguish the names of multiple devices.

**Syslog server (default = empty)** : This option is for your syslog server's IP address.

**Menu Language (default = English)** : This option supports three languages: English, Traditional Chinese, and Simplified Chinese.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
System	Port Status	Device	Time	Console	Email	Ping	

## Device Setup

Server Name:

Syslog Server:

Menu Language:  ▼

### 2.3.4 Time

**Time server (default = time.stdtime.gov.tw)** : To configure time server for time sync.

**Time zone (default = UTC+08:00)** : Modbus series products devices uses the UTC. User can be selected as well from the drop-down list.

**Time Setup** : To set the Year / Month / Date / Hour / Minute / Second in this page, or you can get time from PC.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
System	Port Status	Device	Time	Console	Email	Ping	

## Time Setup

Time Server:

Time Zone:  ▼

Time Setup:  Year  Month  Date  Hour  Minute  second

## 2.3.5 Console

**Web console (default = Enable)** : This option enables or disables access to the web console.

**Remote console (default = Enable)** : This option enables or disables access to the remote console.

**Reset button protect (default =NO)** : This option can enable or disable to reboot the system.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
System	Port Status	Device	Time	Console	Email	Ping	

### Console Setup

Web Console:	Enable
Remote Console:	Enable
Reset Button protect:	No

[Apply](#)

## 2.3.6 Email

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
System	Port Status	Device	Time	Console	Email	Ping	

### Email Setup

Enable Mail Alert:	Disable
SMTP Server:	<input type="text"/>
	(Not support SSL/TLS/STARTTLS connections)
SMTP Server Port:	25 (25 ~ 1024)
Username:	<input type="text"/>
Password:	<input type="text"/>
From:	<input type="text"/>
To:	<input type="text"/>

### Alert Events:

Cold Start Alert:	<input type="checkbox"/>
Message:	Cold Start Alert
Warm Start Alert:	<input type="checkbox"/>
Message:	Warm Start Alert
WEB Login Failure Alert:	<input type="checkbox"/>
Message:	WEB Login Failure Alert

[Apply](#)

This page shows how to Setup SMTP mail parameters for further operation and alert operation.

**Enable Mail Alert (Default = Disable)** : To Enable SMTP function.

**SMTP Server:** Set the IP address of SMTP server address.

**SMTP Server Port (Default = number 25):** Set port number of SMTP service.

**Username** : Enter Your login name for the SMTP server.

**Password** : Enter Your login password of SMTP server.

**From** : Enter the sender's email address.

**TO** : Enter the receiver's email address.

**Cold start Alert / Warm start Alert (Default = Disable)** : To enable the cold alert / warm alert.

**Message** : Enter the message of the email. The default subject is cold start alert or warm alert.

**WEB Login Failure (Default = Disable)** : To enable the WEB login failure alert.

**Message** : Enter the message of the email. The default subject is WEB Login Failure Alert.

### 2.3.7 Ping

The ICMP request is sent to the target host to echo the packet and waits to receive a response packet. The device is sending five packets.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
System	Port Status	Device	Time	Console	Email	Ping	

## PING

Specifies the IP address :

## 2.4 Accessible IP

This list only provides the specified IP address to connect with the Modbus series products server. When the list of accessible IP is enabled, only IP address in the list can connect to Modbus series products. When the function is disable, there is no such restriction. List allows user to configure up to four IP groups.

**Active :** Configure the accessible IP list. Disable or Enable.

**Activate NO :** If you check NO.1, enable NO.1, and so on

**Start IP Address :** Enter the IP address of start.

**End IP Address N:** Enter the IP address of end.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
<h2>Accessible IP Setup</h2>							
Active:		Disable ▼					
Active No.1:		Disable ▼					
Start IP Address:		<input type="text"/>					
End IP Address N:		<input type="text"/>					
Active No.2:		Disable ▼					
Start IP Address:		<input type="text"/>					
End IP Address N:		<input type="text"/>					
Active No.3:		Disable ▼					
Start IP Address:		<input type="text"/>					
End IP Address N:		<input type="text"/>					
Active No.4:		Disable ▼					
Start IP Address:		<input type="text"/>					
End IP Address N:		<input type="text"/>					
<input type="button" value="Apply"/>							

As shown in the following table:

Allowed hosts	Start :IP Address setting	End :IP Address N
Any host	(disable)	(disable)
192.168.2.120	192.168.2.120	192.168.2.120
192.168.2.1 to 192.168.2.254	192.168.2.1	192.168.2.254

## 2.5 Network

**IP Configuration (default = Static) :** Configure Static or DHCP to get IPv4 address.

Option	Description
Static	Is an IP address that was manually configured for a device.
DHCP	Set IP address automatically assigned from DHCP server.

**IP Address (default = 192.168.2.1) :**

Is the current IP address of the device.

**Subnet mask (default = 255.255.255.0):**

Is the current IP Subnet mask of the device.

**Gateway (default = empty) :**

The gateway IP interface.

**Primary DNS (default = empty) :**

Configure the primary DNS server.

**Second DNS (default = empty) :**

Configure the second DNS server when Primary DNS is unavailable.

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
-------	------------------	---------	-------------------	------	-------------	------------------	--------

### IP Configuration

**IPv4 Configuration**

IP Configuration:

IP Address:

Subnet Mask:

Gateway:

Primary DNS:

Second DNS:

## 2.6 Modbus Gateway

The following figure as shown Serial Port Configure part of port settings and Modbus gateway feature.

### 2.6.1 Serial Port

The following table describes the table in this screen.

Property	Options	Default	Description
Mode	RTU Slave, RTU Master, ASCII Slave ASCII Master Disable	RTU Slave	Used to set Modbus/serial on serial port
Baud rate	50 bps to 921600 bps	921600	This is the communication speed of the link between the serial server and the device connected to its serial port.
Data bits	8	8	This parameter controls the number of bits of data in each character.
Any Baud rate	Specify any number	50	User can specify any integer baudrate, the range is 50-921600bps
Stop bits	1, 1.5/2	1	This parameter controls the number of bits to indicate the end of a character.
Parity	Even. Odd, None, Space, Mark	None	This parameter controls the error checking mode.
Interface	RS-232, RS-422, RS-485-2W	RS-232	Select the appropriate serial interface mode, used to connection between the serial port and device communication.
Flow control	None, RTS/CTS, DTR/DSR, RTS Toggle	None	This parameter controls the local handshaking method for stopping serial input or output.
RTS ON delay	0 ms to 100 ms	0	This parameter controls RTS turn on before data transmission.
RTS OFF delay	0 ms to 100 ms	0	This parameter controls RTS turn off after the transmission completes
Response Timeout	10 to 120000 ms	1000	This parameter is used to configure how long the gateway will wait for a response from a Modbus ASCII or RTU slave.

## Serial 1 Setup

Mode:	RTU Slave	Baud Rate:	921600
Data Bits:	8	Any Baud Rate:	50 (50 - 921600)
Stop Bits:	1	Parity:	None
Interface:	RS-232	Flow Control:	None
RTS ON delay:	0 (0-100ms)	RTS OFF delay:	0 (0-100ms)

Response Timeout:  (10 - 120000ms)

Apply to all serial ports:  (It would take a while.)

You can set up the all serial ports by choosing the " Apply to all serial ports".

### 2.6.2 MB COM

Using MB COM, you can communicate over the Ethernet with serial devices. It looks like they were connected to the PC's COM ports.

## MB COM Setup

Active:

MB COM 1:	RTU Slave
MB COM 2:	RTU Slave
MB COM 3:	RTU Slave
MB COM 4:	RTU Slave
MB COM 5:	RTU Slave
MB COM 6:	RTU Slave
MB COM 7:	RTU Slave
MB COM 8:	RTU Slave

## 2.6.3 Modbus Config

### 2.6.3.1 Router

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Serial Port	MB COM	Modbus Config	Priority Control				
Router	ID Mapping	Parameters					

## Router Setup

Page 1 ~ 20 ▼

Index	Local Interface	Local IP / TCP port	Destination
<input type="radio"/> 1			
<input type="radio"/> 2			
<input type="radio"/> 3			
<input type="radio"/> 4			
<input type="radio"/> 5			
<input type="radio"/> 6			
<input type="radio"/> 7			
<input type="radio"/> 8			
<input type="radio"/> 9			
<input type="radio"/> 10			
<input type="radio"/> 11			
<input type="radio"/> 12			
<input type="radio"/> 13			
<input type="radio"/> 14			
<input type="radio"/> 15			
<input type="radio"/> 16			
<input type="radio"/> 17			
<input type="radio"/> 18			
<input type="radio"/> 19			
<input type="radio"/> 20			

Apply

Local Interface: IP Address ▼

Local IP Address:

Destination: Select ▼

Add

Edit

Delete



The Modbus series products support four Modbus masters in each serial port can communicate with the Modbus slave devices. It can be connected to a serial port by IP address or TCP port.

Local Interface: IP Address ▾  
Local IP Address: IP Address TCP Port  
Destination: Serial 1 ▾  
Add Edit Delete

For example, if you want to set IP address 192.168.2.1 is assigned to serial port 4. As shown below, it will forward directly to serial port 4 when you get a Modbus request sent to 192.168.2.1.

## Router Setup

	Index	Local Interface	Local IP / TCP port	Destination
<input type="radio"/>	1	IP Address	192.168.2.1	Serial 4

Apply

## 2.6.3.2 ID Mapping

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Serial Port	MB COM	Modbus Config	Priority Control				
Router	ID Mapping	Parameters					

### ID Mapping Setup

Auto Device Routing:  Disable Page: 1 ~ 20

<input type="radio"/>	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input type="radio"/>	1	Manual	Serial	1-3<=>1-3	Serial 1
<input type="radio"/>	2				Block 1
<input type="radio"/>	3				
<input type="radio"/>	4				
<input type="radio"/>	5				
<input type="radio"/>	6				
<input type="radio"/>	7				
<input type="radio"/>	8				
<input type="radio"/>	9				
<input type="radio"/>	10				
<input type="radio"/>	11				
<input type="radio"/>	12				
<input type="radio"/>	13				
<input type="radio"/>	14				
<input type="radio"/>	15				
<input type="radio"/>	16				
<input type="radio"/>	17				
<input type="radio"/>	18				
<input type="radio"/>	19				
<input type="radio"/>	20				

Need Apply to keep changes.

Type:

Slave ID From:  To:

Slave ID Offset:

Destination:


The ID Mapping Setup is a routing mechanism for gateway. It can follow routing rule on this table to transfer Modbus request to the specific serial port or TCP server that connects the Modbus slave device.

In block 1, it's a setting value for slave ID 1~3 will forward to serial port1. When you get a Modbus requests with slave ID 1~3, it will follow this rule to be routed to the targeted Modbus slave device.

In block 2, you can select the one to add, edit or delete the rule on the table.

## Basic setting

If you want to set a rule that there are a Modbus devices with slave ID 1 is connected to serial port 1.



The screenshot shows a configuration form with the following fields and values:

- Type: Serial Port
- Slave ID From: 1 To 1
- Slave ID Offset: 0
- Destination: Serial 1

Below the form are three buttons: Add, Edit, and Delete.

It will show up as follows

### ID Mapping Setup

Auto Device Routing:  Page: 1 ~ 20

	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input checked="" type="radio"/>	1	Manual	Serial	1-1<=>1-1	Serial 1

So it will transfer a request with slave id 1 to serial 1 from the Modbus master.

### Auto Device Routing

It's a mechanism that will help you find where is it and be routed correctly on serial port. So users don't need to set the rule manually.

If the Auto Device Routing is enabled, it will clear Slave ID Mapping value of the rule with serial port automatically.

### ID Mapping Setup

Auto Device Routing:  Page: 1 ~ 20

	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input checked="" type="radio"/>	1	Manual	Serial	0-0<=>0-0	Serial 1
<input type="radio"/>	2				

When you get a request with slave id didn't exist on rule table. It will detect all serial port to find the target device and add on the rule table directly.

## ID Mapping Setup

Auto Device Routing  Page

	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input type="radio"/>	1	Manual	Serial	0-0<=>0-0	Serial 1
<input type="radio"/>	2	Auto	Serial	1-1<=>1-1	Serial 2
<input type="radio"/>	3				

If there are two target device with same ID in two serial port, it will show conflict. Check environment please.

## ID Mapping Setup

Auto Device Routing  Page

	Index	Router	Type	Slave ID Mapping (Virtual<=>Real)	Destination
<input type="radio"/>	1	Manual	Serial	0-0<=>0-0	Serial 1
<input type="radio"/>	2	Auto	Serial	2-2<=>2-2	Serial 1
<input type="radio"/>	3	Auto	Serial	2-2<=>2-2	Serial 2 , Conflict
<input type="radio"/>	4				

## 2.6.3.3 Parameters

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Serial Port	MB COM	Modbus Config	Priority Control				
Router	ID Mapping	Parameters					

### Parameters Setup

Initial Delay:	<input type="text" value="0"/>	(0-30000ms)
Listen Port:	<input type="text" value="502"/>	(1 - 65535)
TCP Exception:	<input type="text" value="Disable"/>	
TCP Timeout:	<input type="text" value="1000"/>	(10 - 120000ms)

#### Initial Delay

You can make the Modbus series products to wait for some Modbus slave device may take more time to boot up. It will force the Modbus series products to wait the initial delay setting before booting completed.

#### Listen Port

This parameter(default:502) is described the TCP port that communicates with the connected device.

#### TCP Exception

If this setting is enabled, Modbus series products will return an exception in response when there is no response from the slave. If it's disabled, it will do nothing when there is no response.

#### TCP Timeout

This parameter(default:1000) is used to configure how long Modbus series products will wait for a response from a Modbus TCP slave. If there is no response from the slave, the master will ignore and continue next step. This makes the Modbus system did work properly even if a Modbus slave device is faulty.

## 2.6.4 Priority Control

It's a mechanism that Modbus Messaging Priority Control can make a certain requests for more immediate response times. It will be arranged to the front of queue to be sent when Modbus gateway detect a priority request.

### 2.6.4.1 Master

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Serial Port	MB COM	Modbus Config	Priority Control				
Master	TCP	Request					

## Master Control

Specified Masters:   ▾

	Index	Type	Definition
<input type="radio"/>	1	Serial Port	Serial 1
<input type="radio"/>	2	IP Address	192.168.2.123
<input type="radio"/>	3		
<input type="radio"/>	4		
<input type="radio"/>	5		
<input type="radio"/>	6		
<input type="radio"/>	7		
<input type="radio"/>	8		
<input type="radio"/>	9		
<input type="radio"/>	10		
<input type="radio"/>	11		
<input type="radio"/>	12		
<input type="radio"/>	13		
<input type="radio"/>	14		
<input type="radio"/>	15		
<input type="radio"/>	16		

---

Type:   ▾

IP Address:

The priority rule can be assigned by master (serial port or IP address). As above, it means the request from serial port 1 or 192.168.2.123 will be considered a priority request.

## 2.6.4.2 TCP

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Serial Port	MB COM	Modbus Config	Priority Control				
Master	TCP	Request					

### TCP Control

Specified TCP Port:

TCP Port:  (1024-65535)

Same as priority master. As above, it means the request from port 1024 will be high priority.

## 2.6.4.3 Request

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Serial Port	MB COM	Modbus Config	Priority Control				
Master	TCP	Request					

### Request Control

Specified Request:

	Index	Slave ID	Function Code	Data
<input type="radio"/>	1	3	3	00-00-00-03
<input type="radio"/>	2			
<input type="radio"/>	3			
<input type="radio"/>	4			

Slave ID:

Function Code:

Data (Format in Hex):  (ex. 01-3a-b5)

Command type can also make to be a priority request. As above, it means that the request with slave id 3, function code 3 and data 00 00 00 03 will be high priority.

## 2.7 SNMP

This function is used to retrieve network status information and device monitoring and configure the network parameters to automatically warn the administrator.

### 2.7.1 SNMP Settings

**Community name (default = public):** It is the password for SNMP. The management station and the management agent must use the same community name, otherwise the frame will be discarded.

**Contact (default = empty):** Contact is the primary contact showing the device being queried.

**Location (default = empty):** Location is the physical location of the monitored device. Its definition is described in RFC1213.

**SNMP trap server (default = empty):** To configure the Modbus series products to distribute trap messages from any unexpected events, you can fill in the IP address of the SNMP Trap server or domain name.

#### **NOTICE**

*If the SNMP trap server IP settings are incorrect, the Modbus Gateway device's automatic warning function will not work properly and you will have to ask the Network Administrator to get the correct information.*



## 2.7.2 Event

**Cold start Trap** : This event is triggered when the power is interrupted and restarted.

**Warm start Trap** : This event occurs when the device is reset but does not turn off the power.

**Authentication failure Trap** : This event occurs when an incorrect or unauthorized password are entered.

Basic

Accessible  
IP

Network

Modbus  
Gateway

SNMP

Maintenance

Save &  
Reboot

Logout

## SNMP Setup

SNMP Active:	<input type="text" value="Disable"/>
Community:	<input type="text" value="public"/>
Contact:	<input type="text"/>
Location:	<input type="text"/>
Trap Server:	<input type="text"/> IP or domain name

### Events:

Cold Start Trap:	<input type="checkbox"/>
Warm Start Trap:	<input type="checkbox"/>
Authentication Failure Trap:	<input type="checkbox"/>

## 2.8 Maintenance

### 2.8.1 Change Password

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Change Password	Load Default	Firmware Update					

## Change Password

New Password:

Confirm Password:

(ex: A-Z, a-z, \_ ,0-9)

In order to ensure security of device system, each time you login to the Modbus series products device you must be key in a password. When you first receive an Modbus serial server device from the factory, the default password is "system". After logged into the Modbus series products Serial Server Manager, user can make changes from the "Change Password" page.

#### NOTICE

*Before setting up the password for the first time, we strongly recommend exporting the complete configuration of Modbus product to the file. If you forget the password, you can easily restore the configuration. Otherwise, use the reset button to return to factory default.*

### 2.8.2 Load Default

Basic	Accessible IP	Network	Modbus Gateway	SNMP	Maintenance	Save & Reboot	Logout
Change Password	Load Default	Firmware Update					

## Reset to Default

Be aware that previous settings will be lost.

Once the initialization action is performed, Modbus Gateway products's will reload all factory default configuration parameters, thus current configuration settings will be lost. It is strongly recommended that you first save your configuration to a file so that it can be restored if necessary.

## 2.8.3 Firmware Update

This allows you to upload new firmware to the target Modbus Gateway products's Click "Upgrade" to execute upgrade activity.



## Firmware Update



Select a image for new firmware file and click Upgrade button.



It will take 99 seconds for Modbus Gateway products's firmware to be updated. Do not disconnect Modbus series products network and power supply during update process to avoid updating fail. Please wait for the end of the countdown.

### Information Note

Please wait while .... System will reboot automatically after finished.

99 seconds

### 3. Software MCom administration utility

---


#### 3.1 Overview

The Modbus series products Administration Suite provides you search function to your Modbus Gateway products from a remote location. With Modbus series products MCOM Administration utility, you can easily install and search your Modbus series products device server over the network. You can also run Modbus series products MCOM Administration utility from one location to manage multiple device servers.


#### 3.2 Installation the MCOM utility

Modbus series products MCOM Administration utility can be installed from the Document and Software CD onto a Windows PC. To install Modbus series products Administration Suite, insert the Modbus series products Document & Software CD into your PC's CD-ROM drive. Locate and run the setup program and follow the on-screen instructions. The setup program will be named mbgsetup.exe.


1. When you run installer from documentation and software CD, it will show welcome window. Click Next to continue.




2. Click Next to accept suggested installation path or click browse to select a different location.




3. The setup wizard will show the progress of the installation and status.



- 4. Click Finish to successfully complete installation of Modbus Gateway product Management Suite.




- 5. Restart computer





### 3.3 Search device

First click "Add Device" and click "Search" if device has access to network, as shown below.



Click "Select/Clear All" and Click "ok", it will add device automatically on the main window.






### 3.4 COM Mapping

This function should be set as COM mode on the Modbus Gateway. The software will create the relevant virtual COM ports for COM mapping as shown below.


#### Add COM port

Click "COM Mapping" button and click "Add COM" it will show the window as below.






Click the "ok" button. You will see the virtual COM ports generated as shown as below.



#	Type	IP	Port	COM Port	Connection Status
1	4 ports	192.168.2.1	1	COM1	N/A
2	4 ports	192.168.2.1	2	COM2	N/A
3	4 ports	192.168.2.1	3	COM3	N/A
4	4 ports	192.168.2.1	4	COM4	N/A
5	4 ports	192.168.2.1	5	COM5	N/A
6	4 ports	192.168.2.1	6	COM6	N/A
7	4 ports	192.168.2.1	7	COM7	N/A
8	4 ports	192.168.2.1	8	COM8	N/A

## Delete COM Mapping Settings

In contrast, if want to remove a device server from COM Mapping list, click "**Remove COM**" button.



#	Type	IP	Port	COM Port	Connection Status
1	4 ports	192.168.2.1	1	COM1	N/A
2	4 ports	192.168.2.1	2	COM2	N/A
3	4 ports	192.168.2.1	3	COM3	N/A
4	4 ports	192.168.2.1	4	COM4	N/A
5	4 ports	192.168.2.1	5	COM5	N/A
6	4 ports	192.168.2.1	6	COM6	N/A
7	4 ports	192.168.2.1	7	COM7	N/A
8	4 ports	192.168.2.1	8	COM8	N/A

# TRENDnet<sup>®</sup>

## Product Warranty Registration

Please take a moment to register your product online.  
Go to TRENDnet's website at <http://www.trendnet.com/register>

TRENDnet  
20675 Manhattan Place  
Torrance, CA 90501. USA

---

Copyright ©2022. All Rights Reserved. TRENDnet.