

# LANTRONIX®



## G520 Series IoT Cellular Gateway User Guide

Part Number PMD-00123  
Revision B July 2022

---

## Intellectual Property

© 2022 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

*Lantronix* is a registered trademark of Lantronix, Inc. in the United States and other countries.

Patented: [www.lantronix.com/legal/patents/](http://www.lantronix.com/legal/patents/). Additional patents pending.

*Windows* and *Internet Explorer* are registered trademarks of Microsoft Corporation. *Firefox* is a registered trademark of the Mozilla Foundation. *Chrome* is a trademark of Google Inc. All other trademarks and trade names are the property of their respective holders.

## Warranty

For details on the Lantronix warranty policy, please go to our web site at [www.lantronix.com/support/warranty/](http://www.lantronix.com/support/warranty/)

## Contacts

### Lantronix, Inc.

48 Discovery, Suite 250  
Irvine, CA 92618, USA  
Toll Free: 800-526-8766  
Phone: 949-453-3990  
Fax: 949-453-3995

### Technical Support

Online: [www.lantronix.com/support/](http://www.lantronix.com/support/)

### Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at [www.lantronix.com/about-us/contact/](http://www.lantronix.com/about-us/contact/)

## Disclaimer

All information contained herein is provided “AS IS.” Lantronix undertakes no obligation to update the information in this publication. Lantronix does not make, and specifically disclaims, all warranties of any kind (express, implied or otherwise) regarding title, non-infringement, fitness, quality, accuracy, completeness, usefulness, suitability or performance of the information provided herein. Lantronix shall have no liability whatsoever to any user for any damages, losses and causes of action (whether in contract or in tort or otherwise) in connection with the user’s access or usage of any of the information or content contained herein. The information and specifications contained in this document are subject to change without notice.

---

## Revision History

Date	Rev.	Comments
December 2021	A	Initial document for G520 series cellular gateway
July 2022	B	Updated for firmware release 2.0.0.0. <ul style="list-style-type: none"><li>◆ Added rating, power, and battery information.</li><li>◆ Added PoE specification and statement.</li><li>◆ Updated last gasp service and Tunnel BT SPP configuration.</li><li>◆ Added network 5G cellular interface protocol settings.</li><li>◆ Added cable diagnostics.</li></ul>

For the latest revision of this product document, please check our online documentation at [www.lantronix.com/support/documentation](http://www.lantronix.com/support/documentation).

---

# Contents

<b>About this Guide</b>	<b>16</b>
Purpose	16
Summary of Chapters	16
Additional Documentation	18
<b>Introduction</b>	<b>19</b>
Key Features	19
Hardware Variants	19
InfiniShield™ Security	19
Software Features	19
Lantronix Software Services	20
Applications	20
SKU Information	21
Hardware Components	23
General Specification	23
Model-Dependent Features	24
Front Panel	26
Back Panel	27
LEDs	27
Top Panel LEDs	27
Cellular	28
SIM Slots	29
Antenna Connections	29
Certified Antennas	30
Antenna Selection	30
Ethernet Ports (LAN/WAN)	30
RS-232 Serial Port	32
RS-485 Serial Port	32
RS-485 Wiring diagram	33
Input / Output Connections	33
Power Input	34
Power Consumption	34
Reset Button	34
Power over Ethernet (PSE-PoE+)	35
Product Label	35
<b>Installation</b>	<b>36</b>
Package Contents	36
User Supplied Items	36
Statement	36

---

Accessories _____	37
Add-ons _____	38
Preparing to Install _____	38
Enabling DHCP Client on Your Computer _____	38
SIM Card Management _____	39
SIM Card Activation _____	39
SIM Management Portal _____	39
Second SIM Card _____	39
Lantronix Connectivity Services Links _____	39
Physical Installation _____	40
Insert the SIM Card _____	40
Connect the Antennas _____	41
Connect the AC Power _____	42
Connect the Gateway to a Computer _____	42
Connect using Wi-Fi _____	42
Connect using Ethernet _____	43
Default Configuration _____	43
Web Admin Page _____	43
Wireless Access Point SSID _____	43
Default Interface Configuration _____	43
<b>Web Administration Interface _____</b>	<b>45</b>
Logging In _____	46
Change Passwords After Initial Login _____	47
Logging Out _____	48
<b>Using Lantronix Provisioning Manager _____</b>	<b>49</b>
Installing Lantronix Provisioning Manager _____	49
Accessing the G520 Using Lantronix Provisioning Manager _____	49
<b>Quick Setup _____</b>	<b>50</b>
Quick Setup _____	50
<b>Status _____</b>	<b>53</b>
Overview _____	53
System Status _____	55
Cellular Status _____	56
Memory Status _____	57
Network Status _____	57
Active DHCP and DHCPv6 Leases Status _____	58
Wireless Status _____	58
Digital Input/Output Status _____	59

---

Dynamic DNS Status	59
MWAN Interfaces Status	59
Firewall Status	59
Routes	60
System Log	62
Kernel Log	62
Processes	62
Realtime Graphs	63
Load	63
Traffic	64
Wireless	64
Connection	65
Load Balancing	67
Interface	67
Detail	67
Diagnostics	67
Troubleshooting	67

## **System** **68**

System	68
General Settings	68
Logging	69
Time Synchronization	70
Language and Style	71
Administration	71
Router Password	71
SSH Access	71
SSH-Keys	72
Software	72
Configure OPKG	73
Startup	74
Initscripts	74
Local Startup	75
Scheduled Tasks	75
LED Configuration	76
Backup / Flash Firmware	78
Actions	78
Configuration	79
Custom Commands	79
Write Custom Shell Command	79
Run Custom Shell Command	80
Reboot	80
Schedule a Reboot	80

---

<b>VPN</b>	<b>81</b>
IPsec (Internet Protocol Security) _____	81
OpenVPN _____	85
OpenVPN Instances _____	85
Template-based Configuration _____	87
Predefined templates _____	87
Edit the template-based configuration _____	87
OpenVPN Configuration File _____	87
Edit the OVPN Configuration File _____	87
<b>Services</b>	<b>88</b>
Industrial Protocols _____	88
Protocol Conversion _____	88
Data Send Applications _____	88
Agents _____	89
DLMS Client _____	89
DOTA _____	91
Lantronix Server _____	91
Custom Server _____	91
Dynamic DNS _____	93
EtherCAT _____	95
Events _____	95
External Filesystems _____	97
GPS _____	98
Description of NMEA Messages _____	99
GPGGA Format _____	100
GPRMC Format _____	101
GPGSV Format _____	102
GPGSA Format _____	103
GPVTG Format _____	104
IEC 101 to 104 _____	105
Keepalived _____	107
Keepalived Configuration _____	107
Last Gasp _____	110
Logs Information _____	111
Modbus Master _____	111
Serial Transmission Mode _____	111
Ethernet Transmission Mode _____	111
Modbus Master Configuration _____	112
Data Window _____	113
Modbus Download _____	113
Modbus RTU to DNP3 _____	113

---

Configure DNP3 Outstation for Modbus RTU to DNP3 conversion _____	113
Modbus Master Configuration File for DNP3 Outstation _____	114
Sample CSV with DNP3 Parameters _____	114
Page Selector _____	115
Reporting Agent _____	115
Sending Data _____	117
Data Format _____	117
Service Actions _____	118
SMS _____	119
SMS Configuration _____	119
SMS AT Commands _____	119
Ethernet SMS _____	122
Live Message _____	123
SNMPD _____	124
SNMP Architecture _____	124
SNMP Versions _____	124
SNMP Configuration _____	125
Agent Behavior _____	125
View-based Access Control Model (VACM) _____	125
SNMPv3 with User-based Security Model (USM) _____	126
System Information and Monitoring _____	126
Active Monitoring _____	126
Configure SNMPv1 or SNMPv2 _____	127
Configure SNMPv3 with USM _____	127
SNMPTRAPD _____	134
SNMP-TRAP Configuration _____	134
uHTTPd _____	137
Web Server Configuration _____	137
Self-Signed SSL Certificate Parameters _____	139

## **Network 140**

Interfaces _____	140
Interfaces Overview _____	140
Interface Status _____	142
Interface Protocols _____	143
Protocol Descriptions _____	144
Static Address _____	144
DHCP Client _____	146
DHCPv6 Client _____	148
PPPoE _____	149
QMI Cellular _____	150
CELLULAR Interface _____	152
LAN Interface _____	153



---

DHCP Server	153
WAN and WAN6 Interface	155
WWAN and WWAN6 Interface	157
Add Virtual Interface	158
Relay Bridge	160
Wireless	161
Wireless Network Configuration	162
DHCP and DNS	165
General Settings	165
Resolv and Host Files	166
TFTP Settings	166
Advanced Settings	167
Static Leases	168
Hostnames	169
Static Routes	169
Static IPv4 Routes	169
Static IPv6 Routes	170
Diagnostics	172
Firewall	173
General Settings	173
Firewall Global Settings	173
Firewall Zones	174
Port Forwards	175
Add Port Forwarding Rule	176
Traffic Rules	177
Add Traffic Rule	178
Custom Rules	179
QoS	180
Load Balancing	182
How it works	182
Globals	182
Interfaces	183
Members	185
Policies	186
Rules	188
Notification	189

## **Bluetooth** **190**

Bluetooth Settings	190
Configure Bluetooth settings	190
Scan for and Pair a Device	190
Bluetooth SPP	191
Configure Bluetooth SPP Connection	192

---

Configure Tunnel SPP Slave _____	192
Configure Tunnel SPP Master _____	192
<b>ConsoleFlow</b>	<b>194</b>
Client _____	194
ConsoleFlow Line _____	195
<b>Discovery</b>	<b>197</b>
Query Port _____	197
<b>Serial</b>	<b>198</b>
Serial Line Statistics _____	198
Serial Line Configuration _____	198
<b>SSL</b>	<b>200</b>
Credentials _____	200
Trusted Authorities _____	201
<b>Tunnel</b>	<b>203</b>
Tunnel Statistics _____	203
Tunnel Modbus RTU to Modbus TCP _____	203
Tunnel Accept _____	204
Tunnel Connect _____	207
Hosts _____	208
Connecting Multiple Hosts _____	210
Tunnel Disconnect _____	210
<b>Compliance Information</b>	<b>211</b>
FCC Statement _____	212
Federal Communication Commission Interference Statement _____	212
ISED Statement _____	213
EU Declaration of Conformity _____	214
EU Statements _____	215
<b>Power Cable Schematic</b>	<b>221</b>
Power Cable Schematic _____	221
<b>List of Acronyms and Protocols</b>	<b>222</b>
<b>Lantronix Technical Support</b>	<b>225</b>

---

## List of Figures

Figure 2-1 G520 Series Front View	26
Figure 2-2 G520 Series Back View	27
Figure 2-3 Dual SIM Operation	29
Figure 2-4 Ethernet Port	31
Figure 2-5 RS-232 DB9F Interface	32
Figure 2-6 RS-485 and I/O Connections	32
Figure 2-7 RS-485 Wiring Diagram	33
Figure 2-8 DC Input Interface	34
Figure 2-9 Sample Product Label (G526 shown)	35
Figure 4-1 Web Admin Interface	45
Figure 4-2 Web Admin Login Page	47
Figure 4-3 Change Initial Password (admin user)	48
Figure 6-1 Quick Setup > Network Setup page	51
Figure 7-1 Status Overview System Details	54
Figure 7-2 IPv4 Firewall Status	60
Figure 7-3 Realtime CPU Load Graph	63
Figure 7-4 Realtime Network Traffic Graph (eth1)	64
Figure 7-5 Realtime Wireless Usage Graph (client)	65
Figure 7-6 Realtime Connection Traffic Graph	66
Figure 10-1 Reporting Agent Data Format (excerpt)	118
Figure 10-2 Service Actions	118
Figure 10-3 VACM Configuration Model	126
Figure 11-1 Interfaces Overview (partial view)	141
Figure 11-2 WAN Interface Status	142
Figure 11-3 LAN Interface (Static Address) Configuration	154
Figure 11-4 WAN Interface (Static Address) Configuration	156
Figure 11-5 WWAN Interface (DHCP client) Configuration	157
Figure 11-6 Network Add New Interface	158
Figure 11-7 Wireless Overview	161
Figure A-1 EU Declaration of Conformity	214
Figure B-1 3-pin Power Cable	221

---

## List of Tables

Table 2-1 G520 Series Models	21
Table 2-2 General Specification	23
Table 2-3 G520 Series Model-Dependent Features	24
Table 2-4 Top Panel LEDs	27
Table 2-5 G520 Series Cellular Data Rates	28
Table 2-6 G520 Series Cellular Bands	28
Table 2-7 Certified Antennas	30
Table 2-8 Ethernet RJ45 Connector Pin Assignment and LEDs	31
Table 2-9 RS-232 Pin Assignment	32
Table 2-10 RS-485 Pin Assignments	32
Table 2-11 RS-485 Options	33
Table 2-12 Pin Assignments	33
Table 2-13 Power Input and PoE Output	34
Table 2-14 G520 Series Power Consumption	34
Table 3-1 Lantronix Accessories	37
Table 3-2 Add-ons	38
Table 3-3 Default Web Admin Page Credentials	43
Table 3-4 Default Wireless Access Point SSID	43
Table 3-5 Default Network Interface Configuration	43
Table 6-1 Quick Setup Network Configuration	52
Table 7-1 System Status Overview	55
Table 7-2 Cellular Status Overview	56
Table 7-3 Memory Status Overview	57
Table 7-4 Network Status Overview	57
Table 7-5 Active DHCP Leases Status Overview	58
Table 7-6 Wireless Status Overview	58
Table 7-7 Firewall Status	60
Table 7-8 Routes Status	61
Table 7-9 Processes Status	62
Table 8-1 System General Settings	68
Table 8-2 Syslog Configuration	69
Table 8-3 System Time Synchronization Configuration	70
Table 8-4 Language and Style Configurations	71
Table 8-5 SSH Access Configuration	72
Table 8-6 Software Package Details	73
Table 8-7 OPKG Package Manager Configuration	74

---

Table 8-8 Initscripts Actions	74
Table 8-9 Cron Shortcuts	75
Table 8-10 Trigger Descriptions	76
Table 8-11 LED Configuration	77
Table 8-12 Backup, Restore, and Flash Operations	78
Table 8-13 Custom Commands Configuration	79
Table 8-14 Schedule Reboot Time Specification	80
Table 9-1 IPsec General Settings	81
Table 9-2 IPsec Advanced Settings	83
Table 10-1 Agent Configurations	89
Table 10-2 DLMS Client Configuration	90
Table 10-3 DLMS Data Send Configuration	90
Table 10-4 DOTA using Lantronix Server	91
Table 10-5 DOTA Custom Server Configuration	92
Table 10-6 Dynamic DNS Client Configuration	93
Table 10-7 Events Configuration	96
Table 10-8 External Filesystems Configuration	97
Table 10-9 GPS Service Configuration	98
Table 10-10 GGA Data Format	100
Table 10-11 RMC Data Format	101
Table 10-12 GPGSV Data Format	102
Table 10-13 GSA Data Format	103
Table 10-14 VTG Data Format	104
Table 10-15 IEC-101 Slave Configuration	105
Table 10-16 IEC-104 Master Configuration	106
Table 10-17 Keepalived Configuration	108
Table 10-18 Last Gasp Message Configuration	110
Table 10-19 Modbus RTU Packet Data Structure	111
Table 10-20 Modbus Application Protocol Byte Header	112
Table 10-21 Modbus Configuration	112
Table 10-22 DNP3 Outstation Configuration	113
Table 10-23 Reporting Agent Configuration	116
Table 10-24 Reporting Agent Data Send Configuration	117
Table 10-25 SMS Service Configuration	119
Table 10-26 SMS AT Command Syntax	119
Table 10-27 Ethernet SMS Configuration	122
Table 10-28 SNMP Security Models and Levels	125
Table 10-29 SNMP General Settings Configuration	128

---

Table 10-30 SNMP v1/v2/USM VACM Settings _____	130
Table 10-31 SNMP VACM Settings Engine ID Configuration _____	132
Table 10-32 SNMP VACM Settings SNMPv3-USM _____	133
Table 10-33 SNMP Trap Settings Configuration _____	133
Table 10-34 SNMP-Trap Receiver Configuration _____	134
Table 10-35 uHTTPd Server Configuration _____	137
Table 10-36 uHTTPd Self-signed Certificate Configuration _____	139
Table 11-1 Network Interfaces Overview _____	141
Table 11-2 Wireless Overview and Associated Stations _____	142
Table 11-3 Network Interface Protocols _____	143
Table 11-4 Static Address Protocol Settings _____	144
Table 11-5 DHCP Client Protocol Settings _____	146
Table 11-6 DHCPv6 Client Protocol Settings _____	148
Table 11-7 PPPoE Protocol Settings _____	149
Table 11-8 QMI Cellular Protocol Settings _____	150
Table 11-9 VPN Tunnel Protocols _____	159
Table 11-10 Wireless Overview and Associated Stations _____	161
Table 11-11 Wireless Device Configuration _____	162
Table 11-12 Wireless Interface Configuration _____	163
Table 11-13 General Configuration of DHCP Server and DNS-Forwarder _____	165
Table 11-14 Resolv and Host File Configuration for DHCP and DNS _____	166
Table 11-15 TFTP Configuration for DHCP and DNS _____	166
Table 11-16 Advanced Configuration for DHCP and DNS _____	167
Table 11-17 DHCP and DNS Static Leases _____	168
Table 11-18 Hostnames Configuration _____	169
Table 11-19 Static IPv4 Routes Configuration _____	169
Table 11-20 Static IPv6 Routes Configuration _____	170
Table 11-21 Diagnostics - Network Utilities _____	172
Table 11-22 Cable Diagnostics Status Messages _____	172
Table 11-23 Firewall Global Settings _____	173
Table 11-24 Firewall Zones Configuration (LAN) _____	174
Table 11-25 Firewall Port Forwards _____	176
Table 11-26 Port Forwarding Configuration for Firewall Zone _____	176
Table 11-27 Firewall Zone Traffic Rules _____	177
Table 11-28 Firewall Traffic Rule Configuration _____	178
Table 11-29 QoS Configure Classes _____	180
Table 11-30 MWAN Globals Configuration _____	183
Table 11-31 MWAN Interface _____	183

---

Table 11-32 MWAN Interface Configuration	184
Table 11-33 MWAN Members	185
Table 11-34 MWAN Members Configuration	186
Table 11-35 MWAN Policy	187
Table 11-36 MWAN Policy Configuration	187
Table 11-37 MWAN Rules	188
Table 11-38 MWAN Rules Configuration	188
Table 12-1 Bluetooth Settings Configuration	190
Table 12-2 Bluetooth Scan Results	191
Table 12-3 Bluetooth SPP Line Configuration	192
Table 13-1 ConsoleFlow Client Configuration	194
Table 13-2 ConsoleFlow Line	196
Table 15-1 Serial Line Configuration	198
Table 16-1 SSL Credentials - Upload Certificate	200
Table 16-2 SSL Credentials - Create Self-Signed Certificate	201
Table 16-3 SSL Trusted Authority	202
Table 17-1 Tunnel for Modbus RTU to Modbus TCP	203
Table 17-2 Tunnel Accept Mode Configuration	204
Table 17-3 Tunnel Connect Mode Configuration	207
Table 17-4 Host Configuration	209
Table 17-5 Tunnel Disconnect Configuration	210
Table A-1 Regional Certifications	211
Table A-2 Country Transmitter IDs	211
Table A-3 EU Statements	215

# 1: About this Guide

## Purpose

This guide provides the information needed to install, configure, and use the Lantronix G520 series IoT cellular gateways using the web interface. The G520 series gateways are designed for IoT professionals for M2M and enterprise IoT applications requiring faultless connectivity.

The information in this document assumes the reader has knowledge of networking fundamentals and routing concepts for data communication, control, and management functions.

For additional support and product resources, please visit the [Lantronix Technical Support](#) portal.

## Summary of Chapters

The remaining chapters in this guide include:

Chapter	Description
<a href="#">Chapter 2: Introduction</a>	Describes the main features of the product and the protocols it supports.
<a href="#">Chapter 3: Installation</a>	Instructions for installing the G520 series gateways. List of accessories for the gateway. Provides the default credentials for access to the web interface and wireless access point.
<a href="#">Chapter 4: Web Administration Interface</a>	Instructions for accessing the web administration interface and using it to configure settings for the G520 series gateways. The configuration chapters (6 -17) provide detailed instructions for using the web interface.
<a href="#">Chapter 5: Using Lantronix Provisioning Manager</a>	Instructions for using Lantronix Provisioning Manager to locate and configure the gateway.
<a href="#">Chapter 6: Quick Setup</a>	Instructions for configuring the Quick Setup.
<a href="#">Chapter 7: Status</a>	Overview of the gateway status pages.
<a href="#">Chapter 8: System</a>	Instructions for configuring the system features, including clock, syslog, SSH access and keys, password, enabling startup scripts, scheduling cron jobs, LED behavior, and executing custom shell commands. Instructions for operations and maintenance, installing software packages, firmware upgrades, configuration backup, restoring configuration, reboot and factory reset.
<a href="#">Chapter 9: VPN</a>	Instructions for configuring and enabling OpenVPN and IPsec tunneling.
<a href="#">Chapter 10: Services</a>	Instructions for configuring and enabling router and gateway services, and for starting and stopping services. Instructions for configuring industrial protocol services.



Chapter	Description
<a href="#">Chapter 11: Network</a>	<p>Instructions for configuring and enabling the wired, wireless, and cellular network interfaces.</p> <p>Instructions for configuring DHCP and DNS, static routes, firewall, QoS, and load balancing.</p> <p>Instructions for defining hostname and running network diagnostic commands.</p>
<a href="#">Chapter 12: Bluetooth</a>	Instructions for configuring and enabling Bluetooth SPP for serial data transmission.
<a href="#">Chapter 13: ConsoleFlow</a>	Instructions for configuring ConsoleFlow client settings.
<a href="#">Chapter 14: Discovery</a>	Instructions for enabling discovery on query port 0x77FE.
<a href="#">Chapter 15: Serial</a>	Instructions for configuring serial settings on the RS-232 and RS-485 lines.
<a href="#">Chapter 16: SSL</a>	Instructions for creating SSL credentials, uploading SSL certificates and private keys from a CA or self-signed, generating self-signed certificates, and uploading trusted authority certificates.
<a href="#">Chapter 17: Tunnel</a>	Instructions for configuring and enabling serial Tunnel connections.
<a href="#">Appendix A: Compliance Information</a>	Provides compliance information.
<a href="#">Appendix B: Power Cable Schematic</a>	Provides information about accessories, cabling, and connectors.
<a href="#">Appendix C: List of Acronyms and Protocols</a>	Provides a glossary of relevant acronyms and protocols.
<a href="#">Appendix D: Lantronix Technical Support</a>	Provides instructions for contacting Lantronix Technical Support.

## Additional Documentation

Visit the Lantronix web site at <https://www.lantronix.com/support/documentation> for the latest documentation for this product series.

<b>Document</b>	<b>Description</b>
<b><i>G520 Series Quick Start Guide</i></b>	Provides hardware installation instructions, directions to connect the G520 series gateway, and network IP configuration information.
<b><i>Using the G520 Series SDK Application Note</i></b>	Describes how to use the SDK to create custom packages and the Image Builder to build custom firmware images.
<b><i>G520 Series Product Brief</i></b>	Provides G520 series gateway product overview information and specifications.

## 2: Introduction

The G520 series offers LTE Cat 4 and 5G industrial-grade cellular gateways that address the demands of Industry 4.0, security, and transport applications.

With multiple variants providing vertical configuration and clear market differentiators, the G520 series cellular gateways make it possible to combine multiple application use cases in a compact, highly secure, industrial-grade platform.

### Key Features

#### Hardware Variants

- ◆ Industrial Gateway – Ethernet, serial, I/O, Fieldbus conversion, other industrial protocols
- ◆ Security Gateway – Built-in cryptographic secure element and PSE-PoE

**Note:** *The product is considered not likely to require connection to an Ethernet network with outside plant routing.*

#### InfiniShield™ Security

- ◆ Built-in security framework for mission-critical applications
- ◆ Secure boot, secure firmware updates, secure storage
- ◆ Secure communications, secure network attach

#### Software Features

- ◆ Administration and network protocols
  - ◆ Web user interface, setup wizard, console log viewer, save/load configuration
  - ◆ NTP, SMS/OTA remote configuration, TR-069 capable, Lantronix Provisioning Manager
- ◆ Redundancy
  - ◆ Ethernet, Cellular, Wi-Fi (configurable as failover or load balancing)
- ◆ Resilience
  - ◆ Network connectivity watchdog (configurable), internal application watchdog
- ◆ Wi-Fi
  - ◆ Client or Access point, multiple SSID
  - ◆ WPA, WPA-PSK/WPA2-PSK/WPA3-PSK
  - ◆ Enterprise Security (WPA2-Enterprise/WPA3-Enterprise)
  - ◆ EAP-TLS, EAP-TTLS (MS-CHAPv2), EAP-PEAPv0/EAP-MS-CHAPv2, EAP-PEAPv1, EAP-FAST
  - ◆ Bluetooth and Wi-Fi coexistence
- ◆ Routing features and protocols
  - ◆ DHCP, static routing, port forwarding, traffic routing, static/dynamic DNS, DNS proxy, NAT, STP

- ◆ VPN and tunneling protocols – PPTP client, L2TP, OpenVPN client/server/passthrough, GRE, IPsec up to 4 channels
- ◆ Security – zone-based firewall, VLAN, DMZ, HTTPS local & remote connection, SIM PIN
- ◆ Performance and Fault Management
  - ◆ Real time processor load and interface (WAN/LAN/Wi-Fi), traffic analysis, ICMP, traceroute, NS lookup
- ◆ Essential IoT Applications
  - ◆ Serial and Bluetooth SPP to Network tunnels
  - ◆ Python runtime and packages available as IPKs for installation
  - ◆ Add your own IoT edge applications with the SDK and Image Builder
- ◆ Industrial protocols and protocol conversion suite
  - ◆ Modbus master, DLMS client, DNP3 outstation (client), EtherCAT
  - ◆ Modbus RTU to TCP, Modbus RTU to DNP3, IEC 101 to IEC 104 conversion

### Lantronix Software Services

- ◆ Lantronix ConsoleFlow – secure cloud platform to manage remote IoT gateways through a single pane of glass
- ◆ Lantronix Connectivity Services – North American and global cellular data plans and VPN security to manage your SIMs and services

## Applications

The G520 series cellular gateway is suitable for these application scenarios:

- ◆ Industry 4.0
- ◆ Security camera monitoring
- ◆ Banking application

## SKU Information

Table 2-1 G520 Series Models

Lantronix Part Number	Description
<b>INDUSTRY GATEWAY</b>	
<b>G526GP12S</b>	INDUSTRY PACK LTE CAT 4 GATEWAY FOR EMEA, ASIA PACIFIC; <ul style="list-style-type: none"> <li>◆ LTE-3G-2G B28,20,8,3,1,7-B8,1-B8,3;</li> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK INDUSTRIAL SUITE</li> </ul>
<b>G526GP1AS</b>	INDUSTRY PACK LTE CAT 4 GATEWAY FOR CANADA, USA; <ul style="list-style-type: none"> <li>◆ LTE B71,12(17),13,14,26(5),66(10,4),25(2);</li> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK INDUSTRIAL SUITE</li> </ul>
<b>G526GP17S</b>	INDUSTRY PACK LTE CAT 4 GATEWAY FOR JAPAN, SOUTH KOREA; <ul style="list-style-type: none"> <li>◆ LTE B18,5(19),8,21,3(9),1,7;</li> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK INDUSTRIAL SUITE</li> </ul>
<b>G526GP1CS</b>	INDUSTRY PACK LTE CAT 4 GATEWAY FOR CHINA, THAILAND, INDONESIA, INDIA; <ul style="list-style-type: none"> <li>◆ LTE-3G-2G B5,8,3,1;40,41-B8,1-B8,3;</li> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK INDUSTRIAL SUITE</li> </ul>
<b>SECURITY GATEWAY</b>	

Lantronix Part Number	Description
<b>G527GP22S</b>	SECURITY PACK LTE CAT 7-13 GATEWAY FOR EMEA, ASIA PACIFIC; <ul style="list-style-type: none"> <li>◆ LTE-3G B28,20,8,32,3,1,7;40,41(38),42,43-B5,8,1;</li> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ SECURITY ELEMENT;</li> <li>◆ PSE-POE+ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK SECURITY SUITE</li> </ul>
<b>G527GP2AS</b>	SECURITY PACK LTE CAT 7-13 GATEWAY FOR AMERICA; <ul style="list-style-type: none"> <li>◆ LTE-3G B71,12(17),13,14,26(5),66(10,4),25(2),7;41,42,48,43-B5,4,2;</li> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ SECURITY ELEMENT;</li> <li>◆ PSE-POE+ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK SECURITY SUITE</li> </ul>
<b>G527GP27S</b>	SECURITY PACK LTE CAT 7-13 GATEWAY FOR JAPAN; <ul style="list-style-type: none"> <li>◆ LTE-3G B18,5(19),8,3(9),1,41,42,43/B5(19,6),1;</li> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ SECURITY ELEMENT;</li> <li>◆ PSE-POE+ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK SECURITY SUITE</li> </ul>
<b>G528GP2FS-P</b>	SECURITY PACK 5G Sub 6 GHZ LTE CAT13 FB IOT GATEWAY WORLD; <ul style="list-style-type: none"> <li>◆ 10.8 - 60 V DC; L. GASP; DI;</li> <li>◆ DI-O X2; VI-O X2;</li> <li>◆ RS-232; RS-485; USB;</li> <li>◆ WI-FI 5; BT 5;</li> <li>◆ SEC. ELEM.;</li> <li>◆ PSE-POE+ ETHERNET X2;</li> <li>◆ GNSS; DUAL SIM;</li> <li>◆ MICROSD</li> <li>◆ SW EPACK SECURITY SUITE</li> </ul>

## Hardware Components

### General Specification

Table 2-2 General Specification

Component	Specification
<b>Physical</b>	
Casing	Brushed aluminum alloy
Dimensions (W x D x H)	131.5 x 81.27 x 25 mm
Weight	334 grams
<b>Environmental</b>	
Operating temperature	-30 °C ~ +70 °C, up to 95% RH
Storage temperature	-40 °C ~ +85 °C, up to 95% RH
<b>Memory</b>	
SPI Flash memory	8MB
NAND Flash memory	256MB
RAM	DDR2 SDRAM 256MB
<b>Power</b>	
Power	Input voltage: 10.8 ~ 60 V DC 3-pin Nano-Fit™ header Power over ethernet (PSE-PoE+) is available on select models. See <a href="#">Model-Dependent Features</a> .
Last Gasp	100-second long, approximately Two (2) 96 mWh Li-ion batteries (not functional below -10 °C)
Digital Input (Ignition)	One (1) digital input, on the middle pin of the 3-pin header Input: 0 V DC ~ 2.5 V DC => ZERO; 3 V DC ~ 50 V DC => ONE
Power off Timekeeping	Dedicated RTC with 100-day data retention period, approximately 15 mWh lithium manganese battery (not functional below -20 °C)
<b>Interfaces</b>	
Ethernet	10/100 BASE-T Two (2) ports (1 LAN, 1 WAN, configurable as LAN) Two (2) LEDs per port (link, activity)
Wi-Fi	IEEE 802.11ac/a/b/g/n 2x2 MIMO 2T2R Wi-Fi 5, with 2 RP-SMA antenna connectors Bluetooth 5.1, via Wi-Fi's rightmost RP-SMA antenna connector For the number of Wi-Fi clients in AP mode, see <a href="#">Model-Dependent Features</a> .
Dual SIM operation	Dual SIM / Single standby Two (2) SIM slots (Mini - 2FF)
GNSS	Satellite systems support: BeiDou, Galileo, GLONASS, GPS One (1) SMA antenna connector

Component	Specification
User data storage	Internal: via the 256MB of parallel NAND Flash memory External: One (1) microSD card slot (microSD card not provided)
USB	One (1) USB 2.0 host port, Type A
RS-232	One (1) RS-232 serial port with DB9F connector Software configurable baud rate options from 2400 bps to 921600 bps For RS-485 serial operation, see <a href="#">Model-Dependent Features</a> .
Digital I/Os	Two (2) I/Os with common ground, with 3-pin COMBICON header and plug. <ul style="list-style-type: none"> <li>◆ Input: 0 V dc ~ 2.5 V dc =&gt; ZERO; 3 V dc ~ 50 V dc =&gt; ONE</li> <li>◆ Output: open collector, 200 mA maximum, 50 V dc maximum</li> </ul>
Versatile I/O	Two (2) I/Os with common ground, with 3-pin COMBICON header and plug. Each I/O is independently user-configurable as analog input, analog input suited to current loop (4 mA ~ 20 mA) sensors, or digital output. <ul style="list-style-type: none"> <li>◆ Analog input: 0 V dc ~ 48 V dc range; 12-bit resolution; capable of counting pulses at up to 10 Hz</li> <li>◆ Analog input: 4 mA ~ 20 mA range, 12-bit resolution</li> <li>◆ Output: open collector, 200 mA maximum, 50 V dc maximum</li> </ul>
Status LEDs	Nine (9) LEDs on top panel for network activity and status
Reset button	Soft Reset (reboot): Short press more than one (1) second and less than 5 seconds  Hard Reset (factory reset): Long press more than 5 seconds and less than 20 seconds

## Model-Dependent Features

**Table 2-3 G520 Series Model-Dependent Features**

Feature	Description	Industry Gateway (G526)	Security Gateway (G527 / G528)
RS-485 operation (serial)	6kV (contact) and 8kV (air) ESD-protected, 2.5kV isolated, via 5-pin COMBICON header Half-duplex (factory setting) or Full-duplex mode (software configurable)	Yes	Yes
PSE-PoE+ (power over ethernet)	IEEE 802.3at standard-compliant 30 W per LAN port; requires PoE+ power supply accessory	No	Yes
Wi-Fi Operation	Number of Wi-Fi Clients in AP mode	12	12



<b>Feature</b>	<b>Description</b>	<b>Industry Gateway (G526)</b>	<b>Security Gateway (G527 / G528)</b>
4G Cellular and GNSS Operations	LTE Cat 4 with 3G or 3G/2G fallback mode; 2 SMA antenna connectors or LTE Cat 13/7 with 3G fallback mode; 2 SMA antenna connectors	LTE Cat 4	LTE Cat 13/7
	Qualcomm® IZat™ location services or u-blox M8; 1 dedicated SMA antenna connector	Qualcomm IZat gen. 8c	Qualcomm IZat gen. 9c
5G Cellular and GNSS Operations	Sub-6 GHz 5G, with both LTE Cat 13 (uplink) / Cat 20 (downlink) and 3G fallback modes	No	Yes
	Dual band GPS and Galileo; Single band GLONASS and BeiDou; 4 SMA antenna connectors, 2 Rx / Tx dedicated to cellular and 2 Rx-only shared between cellular and GNSS	No	Yes
3-axis accelerometer	STMicroelectronics LIS331DLH	No	No
Secure element	NXP EdgeLock SE050	No	Yes
User data storage	Internal via the 256MB of parallel NAND Flash memory	Yes	Factory option

## Front Panel

Figure 2-1 G520 Series Front View



ID	Connection Name	ID	Connection Name
1	Wi-Fi antenna (left)	6	RS-485
	Wi-Fi / Bluetooth antenna (right)	7	Versatile I/O
2	RS-232	8	Power input
3	USB	9	Ethernet (LAN, WAN/LAN #2)
4	Reset button	10	LEDs
5	Digital I/O		

## Back Panel

Figure 2-2 G520 Series Back View




ID	Connection Name
1	Cellular diversity antenna (left) Cellular main antenna (right)
2	microSD card slot
3	Last Gasp switch (OFF by default)
4	GNSS antenna
5	SIM #1 / SIM # 2 Mini SIM slots

## LEDs

### Top Panel LEDs

Table 2-4 describes the top panel LEDs as shown from top to bottom in [Figure 2-1](#).

Table 2-4 Top Panel LEDs

Name	Color	Status	Description
<b>Alert</b> 	Red	OFF	No alert, device is running smoothly
		Flashing	Cellular module reboot, Linux kernel booting
		ON	Hardware fault
<b>User programmable #1</b>	Blue	OFF	User configurable via software
		Flashing	User configurable via software
		ON	User configurable via software
<b>User programmable #2</b>	Blue	OFF	User configurable via software
		Flashing	User configurable via software
		ON	User configurable via software

Name	Color	Status	Description
Activity	Amber	OFF	Cellular data service is not connected
		Flashing	Data sent and received over cellular connection
		ON	Cellular data service is connected
Network	Amber	OFF	Device is not registered on a cellular network
		Flashing	Registered on roaming cellular network
		ON	Registered on home cellular network
Signal	Amber	OFF	No signal (CSQ=0 to 5, 97, 98, 99)
		Flashing	Weak signal (CSQ > 6 to 12)
		ON	Strong signal (CSQ ≥ 6 to 12)
SIM	Blue	OFF	SIM not in use
		Flashing	SIM2 in use
		ON	SIM1 is in use
Wi-Fi	Blue	OFF	Wi-Fi network is inactive
		Flashing	Wi-Fi network connection traffic
		ON	Wi-Fi network link is up and active
Power	Green	OFF	Power off
		ON	Power on

## Cellular

Table 2-5 G520 Series Cellular Data Rates

Cellular Type	Uplink / Downlink Maximum Data Rate
2G	236.8 / 296 kbps
3G	5.76 / 42.2 Mbps
4G LTE Cat 4	FDD: 50 / 150 Mbps TDD: 35 / 130 Mbps
4G LTE Cat 13/7	FDD: 150 / 300 Mbps TDD: 35 / 130 Mbps

Table 2-6 G520 Series Cellular Bands

Model	Part Number	Cellular Type	Bands <sup>1</sup>	Fallback Mode	Bands <sup>1</sup>
<b>Industry Gateway</b>					
G526	G526GP12S	LTE Cat 4	28/20/8/3/1/7	3G, 2G	8/1; 8/3
	G526GP1AS	LTE Cat 4	71/12(17)/13/14/26(5)/ 66(10,4)/25(2)	–	–
	G526GP17S	LTE Cat 4	18/5(19)/8/21/3(9)/1/7	–	–
	G526GP1CS	LTE Cat 4	5/8/3/1; TDD 40/41 <sup>2</sup>	3G, 2G	8/1; 8/3
<b>Security Gateway</b>					

Model	Part Number	Cellular Type	Bands <sup>1</sup>	Fallback Mode	Bands <sup>1</sup>
G527	G527GP22S	LTE Cat 13 (up)/LTE Cat 7 (down)	28/20/8/32/3/1/7; TDD 40/41(38)/42/43	3G	5/8/1
	G527GP2AS	LTE Cat 13 (up)/LTE Cat 7 (down)	71/12(17)/13/14/26(5)/ 66(10,4)/25(2)/7; TDD 41/42/48/43	3G	5/4/2

1. Ranked by increasing frequency
2. More precisely, B41's 2535 MHz ~ 2655 MHz subset, suited to China well

## SIM Slots

The G520 series gateway provides two SIM slots to accommodate two mini SIM cards (2FF), as shown in [Figure 2-3](#). The SIM cards must be activated before use.

Figure 2-3 Dual SIM Operation



## Antenna Connections

Wi-Fi / Bluetooth Antenna connectors (see [Figure 2-1](#)):

- ◆ Two (2) Wi-Fi, RP-SMA connectors

**Note:** If you are using Bluetooth only (no Wi-Fi), one antenna may be attached to the connector on the right.

WWAN Antenna connectors (see [Figure 2-2](#)):

- ◆ 4G / GNSS (G526, G527 models) - Two (2) cellular, RP-SMA connectors and one (1) GNSS, RP-SMA connector

## Certified Antennas

Table 2-7 lists the antennas that have been certified for the G520 series gateways.

Table 2-7 Certified Antennas

Purpose	Antenna type	Description	Lantronix Part Number	Approved Region
Wi-Fi Antenna	Dipole, swivel type antenna, with RP-SMA(M) connector	Peak gain: 2 dBi, 2.4 Ghz to 2.5 Ghz, 2 dBi, 5.15 Ghz to 5.85 Ghz RoHS compliant	A21H0	FCC, IC, EU, AUS/NZS, JPN, China, Mexico
WWAN Antenna	Dipole, 4G, swivel type blade antenna, with SMA connector, adhesive mount	Performance across LTE frequency bands 698-960, 1710-2170, 2500-2700 MHz Gain: Up to 2 dBi RoHS compliant	A33M0	N/A

**Note:** Antenna gain listed above excludes cable loss.

### Antenna Selection

Use the following guidelines in Wi-Fi antenna selection:

- ◆ Dipole, peak gain less than 3.8 dBi @ 2.4 GHz ~ 2.5 GHz
- ◆ Use the same dipole antenna type as certified module and modem for FCC or external antenna with length greater than 20 cm.

### Ethernet Ports (LAN/WAN)

Figure 2-4 Ethernet Port




Table 2-8 Ethernet RJ45 Connector Pin Assignment and LEDs

Pin	Signal Name
1	ETX+
2	ETX-
3	ERX+
4	-
5	-
6	ERX-
7	-
8	-
Left LED (Green)	RX/TX Activity Flashing on: Activity Off: No activity
Right LED (Amber)	Link On: Link Off: No link

## RS-232 Serial Port

Figure 2-5 RS-232 DB9F Interface




Table 2-9 RS-232 Pin Assignment

Pin	Description	Pin	Description
1	DCD out	6	DSR out
2	RX out	7	RTS in
3	TX in	8	CTS out
4	DTR in	9	NC
5	GND	–	–

## RS-485 Serial Port

Figure 2-6 RS-485 and I/O Connections




Table 2-10 RS-485 Pin Assignments

### RS-485 Full-duplex

Pin	Description
B	B-
A	A+
G	Ground
Y	Y+
Z	Z-

### RS-485 Half-duplex

Pin	Description
A & Y	Data +
B & Z	Data -
G	Ground




Table 2-11 RS-485 Options

Interface	Description
RS-485 port	2.5 kV-isolated; half- or full-duplex RS-485 port on 5-pin COMBICON header and tool-less plug (supplied by user)
SNAP CAP™ RS-485 add-on connected to RS-232 serial port (not provided)	SNAPCAP RS-485 (SC485) converts G520 series RS-232 serial port into a 6 kV- (contact) or 8 kV- (air) ESD-protected, 2.5 kV-isolated, half- or full-duplex RS-485 port on a 5-pin 3.5 mm pitch, COMBICON header.

### RS-485 Wiring diagram

Figure 2-7 RS-485 Wiring Diagram



### Input / Output Connections

The G520 series gateway provides digital I/O and versatile I/O connections on 3-pin COMBICON headers and tool-less plugs (supplied by user). The connections are shown in [Figure 2-6](#).

Table 2-12 Pin Assignments

#### Digital I/O

Pin	Description
#1	Input
C	Common
#2	Output

#### Versatile I/O

Pin	Description
#1	Input
G	Ground
#2	Output

## Power Input


The power input interface is shown in [Figure 2-8](#).

For the power cable schematic, see [Power Cable Schematic on page 221](#).

**Table 2-13 Power Input and PoE Output**

Input Rated	PoE Output
46.75 - 60Vdc	Each PoE port loaded to 30W
10.8 - 46.74Vdc	No PoE output

**Figure 2-8 DC Input Interface**



## Power Consumption

**Table 2-14 G520 Series Power Consumption**

Device State	Input Voltage		
	10V	12V	48V
Idle state (WAN, LAN, Wi-Fi, RS485, GPS & Cellular off)	210 mA	176 mA	83 mA
WAN connected (LAN, Wi-Fi, RS485, GPS & Cellular off)	245 mA	204 mA	96 mA
LAN connected (WAN, Wi-Fi, RS485, GPS & Cellular off)	240 mA	190 mA	95 mA
Wi-Fi on (WAN, LAN, RS485, GPS & Cellular off)	245 mA	190 mA	95 mA
RS485 connected (WAN, LAN, Wi-Fi, GPS & Cellular off)	–	–	–
GPS on (WAN, LAN, Wi-Fi, RS485 & Cellular off)	–	–	–
WAN, LAN, RS485 connected & Wi-Fi, GPS on (Cellular standby)	290 mA	245 mA	108 mA
WAN, LAN, RS485 connected & Wi-Fi, GPS on & Cellular on	295 mA	250 mA	110 mA

## Reset Button

Using a paper clip or similar object to poke through the RESET hole, press the recessed Reset button as shown in [Figure 2-1](#).

- ◆ To reboot the unit, press and hold the reset button for more than 1 second and less than 5 seconds.
- ◆ To reset to factory settings, press and hold the reset button for more than 5 seconds and less than 20 seconds.


### Power over Ethernet (PSE-PoE+)

The G520 series gateway (Security gateway SKUs only) can be used as an IEEE 802.3at PoE+ compliant power source (PSE) to supply power to a device attached to the LAN port. Each LAN port supports a maximum output of 30 W. This requires the PoE+ power supply (ACC-U301 accessory, supplied by user).

Input Rated	PoE Output
46.75 - 60Vdc	Each PoE port loaded to 30W
10.8 - 46.74Vdc	No PoE output

### Product Label

Figure 2-9 Sample Product Label (G526 shown)



## 3: Installation

### Package Contents

- ◆ G520 series cellular gateway
- ◆ Power cord
- ◆ SIM card (2FF)
- ◆ Quick Start Guide
- ◆ SIM Insert (printed card with SIM APN and Lantronix Connectivity Services links)

The SIM card is pre-activated by Lantronix and preloaded with an initial amount of data. For more details, see [SIM Card Management on page 39](#).

Other accessories are not included and should be purchased separately.

### User Supplied Items

The following items are not included and should be supplied by the user, if needed. For details about purchasing Lantronix accessories, see [Accessories](#) below.

- ◆ Second SIM card (2FF), data plan activation required
- ◆ Power supply and adapters
- ◆ Wi-Fi / Bluetooth antennas
- ◆ Cellular / GNSS antenna
- ◆ MICRO COMBICON 3-pin and 5-pin pluggable terminal blocks
- ◆ Cat 5 Ethernet cable for wired LAN / WAN connection
- ◆ Serial cable (RS-232 DB9M connector)
- ◆ microSD card for user data storage

The Ethernet cable, serial cable, and microSD card can be acquired from various vendors.

#### **Statement**

- ◆ Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types);
- ◆ Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- ◆ Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- ◆ A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- ◆ GPS function is not intended to be used for location of persons.

## Accessories

Lantronix accessories are listed in [Table 3-1](#) according to part number and application.

To buy Lantronix accessories, go to <https://www.lantronix.com/about-us/contact/>.

**Table 3-1 Lantronix Accessories**

Part Number	Description
<b>Power Cords</b>	
ACC-500-0420-00	POWER CORD WITH 3-PIN NANO-FIT PLUG; 2.5 A FUSE; TWO 1-METRE-LONG AWG20 STRIPPED WIRES (RED, BLACK) FOR POWER
ACC-500-421-00	POWER CORD WITH 3-PIN NANO-FIT PLUG; 2.5 A FUSE; TWO 1-METRE-LONG AWG20 STRIPPED WIRES (RED, BLACK) FOR POWER; ONE 20-CENTIMETRE-LONG AWG20 WIRE (BLUE) FOR IGNITION
<b>Power Supply and Adapters</b>	
ACC-520-0165-00	WORLDWIDE. POWER SUPPLY, WALL CUBE, 12VDC 12W, 4 AC PLUGS, LEVEL 6, WITH PSE, 2X2 3.0MM LATCHED CONN OUTPUT
ACC-520-0166-00	US. POWER SUPPLY, WALL CUBE, 12VDC 12W, US, LEVEL 6, WITH PSE, 2X2 3.0MM LATCHED CONN OUTPUT
ACC-U301	PoE+ POWER SUPPLY, 75 W industrial power supply
<b>Wi-Fi Antenna</b>	
A21H0	2.4/5.8GHZ DIPOLE ANTENNA FOR ISM & WLAN, RP-SMA(M) HINGED
<b>4G / GNSS Antenna</b>	
A33M0	THREE IN ONE LTE, 2*LTE+GPS/GLONASS/BD ANTENNA, 3*3000MM RG174 CABLE WITH 3*SMA MALE, ADHESIVE MOUNT
A33H0	THREE IN ONE LTE, 2*LTE+GPS/GLONASS/BD/GALILEO ANTENNA, 3*3000MM RG174 CABLE WITH 3*SMA MALE, ADHESIVE MOUNT.
A32M0	TWO IN ONE LTE, 2*LTE ANTENNA, 2*3000MM RG174 CABLE, SMA MALE
A32H0	TWO IN ONE LTE, 2*LTE ANTENNA, 2*3000MM CABLE, SMA MALE, ADHESIVE MOUNT.
A22H0	ANTENNA, 4G, ULTRA WIDEBAND, LTE/GPS/WIFI, HINGED 90 DEGREE SMA MALE.
A22H1	4G LTE ANTENNA, LTE/GPS/WIFI, HIGHED 90 DEGREE SMA MALE. (INCLUDING 450 MHZ)
<b>5G / GNSS Antenna</b>	
A22H2	Set of four (4) L-shaped, hinged
<b>MICRO COMBICON Plugs</b>	
ACC-140-0985-00	3 PIN PLUGGABLE TERMINAL BLOCKS: FMC 0,5/3-ST2,54
ACC-140-0986-00	5 PIN PLUGGABLE TERMINAL BLOCKS FMC 0,5/5-ST2 54

**Note:** The product is intended to be supplied by a UL Listed Power Unit marked “L.P.S.” (or “Limited Power Source”) and is rated 10.8-60Vdc, 0.5A min., Tma = 70 degree C. For assistance with purchasing the power source, please contact Lantronix Sales.

**Caution:** **Caution: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.**

**Note:** If using a class I adapter, the power cord shall be connected to a socket outlet with earthing connection.

## Add-ons

Table 3-2 Add-ons

Item	Description
SNAPCAP™ Converter	31.5 mm-wide, 17 mm-high, 9-pin sub-D plugs that convert G520 series' RS-232 DB9F serial port
SC485	38.2 mm-deep, 6 kV- (contact) or 8 kV- (air) ESD-protected, 2.5 kV-isolated, half- (factory setting) or full-duplex (user-configurable via a slide switch) RS-485 port; via a 5-pin, 3.5 mm pitch COMBICON header

To order Lantronix add-on parts, go to <https://www.lantronix.com/about-us/contact/>.

## Preparing to Install

Before starting installation, gather the necessary hardware, accessories, and documentation. Review and follow the safety information as described in the documentation.

Ensure that the computer used to access the web admin interface for gateway configuration is equipped with the following:

- ◆ Ethernet port or Wi-Fi connectivity and Internet service
- ◆ Web browser with recently updated version (Chrome, Safari, Firefox, Edge, Internet Explorer)
- ◆ DHCP client is enabled on the computer

### Enabling DHCP Client on Your Computer

The DHCP client must be enabled on your computer to obtain a valid IP address from the gateway.

#### To enable DHCP on Windows 8 or 10:

1. Go to Start > Control Panel > Network and Internet > Network and Sharing Center.
2. Click the active network connection. The Network Connection Status box appears.
3. Click Properties and then select IPv4 (TCP/IPv4) and click Properties. The Internet Protocol Version 4 (TCP/IP) Properties will appear.
4. On the General tab, select the following options:
  - ◆ Obtain an IP address automatically
  - ◆ Obtain DNS server address automatically

5. Click OK to close the dialog.

**To enable DHCP on Mac OS:**

1. Launch System Preferences, and then choose Network.
2. Select Ethernet from the adapters list on the left.
3. Set the Configure IPv4 list to “Using DHCP.”

## SIM Card Management

One SIM card (2FF) is provided in the box with the G520 series gateway. The Lantronix Connectivity Services SIM card comes pre-activated by Lantronix and preloaded with an initial amount of data. A printed SIM Insert card with the SIM APN on one side and Lantronix Connectivity Services links on the other side is also provided. Keep this card for quick reference.

When the purchase order for the gateways is processed, Lantronix creates an account on the Connectivity Services SIM Management portal and enters the SIM cards into the account. A confirmation email with account login details is sent to the contact person on record.

### *SIM Card Activation*

The provided SIM card is pre-activated by Lantronix, but you may need to configure APN in the G520 series software’s cellular network interface SIM settings. To configure the APN, go to Quick Setup or Network > Interfaces and edit the cellular network interface’s SIM settings.

### *SIM Management Portal*

To manage your Lantronix SIM cards, visit the Connectivity Services SIM Management portal at: <https://connectivity.lantronix.com>

Sign in by entering the user name and password provided by Lantronix.

Here you can view SIM status and usage, manage SIM data limits, manage the SIMs, and access the API documentation.

Before use, the SIM card status will be Pre-active on the SIM Management portal. After it is installed and starts transferring data, the status will appear as Active.

### *Second SIM Card*

You may purchase a second SIM card (region specific) from Lantronix Connectivity Services or from a cellular operator for use in the second SIM slot of the G520 series gateway. Before using the SIM card, activate it according to the instructions provided by the vendor.

### *Lantronix Connectivity Services Links*

SIM Management Portal	<a href="https://connectivity.lantronix.com">https://connectivity.lantronix.com</a>
Account	<a href="https://shop.lantronix.com/account">https://shop.lantronix.com/account</a>
Email Support	<a href="mailto:simhelp@lantronix.com">simhelp@lantronix.com</a>

## Physical Installation

### Insert the SIM Card

Use the provided, pre-activated SIM card or purchase a SIM card separately and activate it according to vendor instructions before use. A second SIM card may be installed in the second slot.

To insert a SIM card:

1. Select SIM slot #1 or #2 and slide the latch to the left.



2. Gently insert the SIM card (contact side down) into the slot and push to lock it in place. Release the latch.





## Connect the Antennas

Ensure that the antenna used is suitable for the cellular frequencies in use, for both the main and auxiliary connectors.

To connect the antennas:

1. Attach the cellular antennas to the main and auxiliary connectors on the base unit and tighten them securely.
2. Attach and tighten the GNSS antenna to the GNSS connector.



3. Attach and tighten the Wi-Fi antennas to the Wi-Fi and Wi-Fi / Bluetooth connectors on the base unit. If you are using Bluetooth only but not Wi-Fi, then one antenna can be attached to the Wi-Fi / Bluetooth connector on the right.



### Connect the AC Power

To connect the AC power:

1. Connect the power cord to the power supply.
2. Attach the 3-pin connector end of the power cord to the DC input connector on the base unit.



DC input - 3-pin connector

3. Plug the AC plug on the power supply into a standard AC receptacle.

### Connect the Gateway to a Computer

To log into the web administration interface, first connect to the gateway's Wi-Fi access point or connect an Ethernet cable from the gateway's LAN Ethernet port to the computer's LAN Ethernet port.

#### Connect using Wi-Fi

To connect using Wi-Fi:

1. On your computer, open the Wireless settings and connect to the gateway's Wi-Fi access point. The default access point SSID is:

Parameter	Details
SSID	Lantronix-<model>-<serial-number>
WPA/WPA2 TKIP Key	W1rele\$\$

2. Open the web browser to 192.168.1.1. The login page appears.
3. Log into the web admin interface. The default username and password credentials are:

User	Default Password
admin	admin
root	L@ntr0n1x

4. You will be required to change the root and user passwords after the first login. After changing the initial passwords, log in again to configure the network settings.

### Connect using Ethernet

To connect using Ethernet:

1. Connect an RJ-45 terminated Ethernet cable between the LAN Ethernet port on the unit and the LAN Ethernet port on the computer.
2. Open the web browser to 192.168.1.1. The login page appears.
3. Log into the web admin interface. The default username and password credentials are:

User	Default Password
admin	admin
root	L@ntr0n1x

4. You will be required to change the root and admin user passwords after the first login. After changing the initial passwords, log in again to configure the network settings.

## Default Configuration

All usernames and passwords are case sensitive.

### Web Admin Page

Table 3-3 Default Web Admin Page Credentials

User	Default Password
admin	admin
root	L@ntr0n1x

**Note:** Upon first login, you are required to change the factory default passwords before any other gateway configuration can be done. Both the admin and root passwords must be changed.

### Wireless Access Point SSID

Table 3-4 Default Wireless Access Point SSID

Parameter	Details
SSID	Lantronix-<model>-<serial-number>
WPA/WPA2 TKIP Key	W1rele\$\$

### Default Interface Configuration

Table 3-5 Default Network Interface Configuration

Interface	Details
WAN (Ethernet)	Automatic (DHCP client) Priority source of Internet with cellular backup


<b>Interface</b>	<b>Details</b>
<b>LAN (Ethernet)</b>	Active DHCP with starting IP address 192.168.1.100 with pool of 100 clients.
<b>Cellular</b>	No PAP/CHAP authentication
<b>Wireless (LAN)</b>	Wi-Fi enabled as access point

## 4: Web Administration Interface

The web admin interface allows the administrator and other authorized users to configure and manage the G520 series gateways using most web browsers (Firefox, Internet Explorer or Safari web applications with the latest browser updates).




Figure 4-1 shows highlights key components on the web admin interface:

Figure 4-1 Web Admin Interface



How to interact with the web interface:

<p>1</p>	<p><b>Menu</b></p> <ul style="list-style-type: none"><li>Network</li><li>Interfaces</li><li>Wireless</li></ul>	<p>The menu displays a list of options to configure and operate the gateway.</p> <p>Select a menu option to display the related status and configuration settings in the content pane.</p>
----------	--	--

2	<p><b>Active content</b></p> 	<p>The content pane displays status, configuration settings, and options for interacting with the gateway.</p> <p>It lets you view status, and configure settings on the gateway, or perform maintenance or other operations.</p>
3	<p><b>Save Configuration</b></p> 	<p>These actions let you save configuration changes or reset unsaved changes on the active page</p> <ul style="list-style-type: none"> <li>◆ <b>Save &amp; Apply</b> - Applies and saves the changes on the web page to the gateway (in NVRAM) so that the settings will persist when the gateway is rebooted. After clicking this button, wait for the configuration to be applied before closing the browser, otherwise the old configuration will be restored.</li> <li>◆ <b>Apply Unchecked</b> - Click the arrow on the Save &amp; Apply button to reveal this option. Applies and saves the changes on the web page to the gateway (in NVRAM), but will not disrupt the active network interface. Use this if you are changing the interface parameters on which the session is active.</li> <li>◆ <b>Save</b> - Saves the changes on the web page (to RAM) without committing the changes. All saved configuration will be lost when the gateway is rebooted if they are not saved and applied.</li> <li>◆ <b>Reset</b> - Discards the unsaved changes on the page.</li> </ul>
4	<p><b>Helper actions</b></p> 	<p>These actions help you use the web interface.</p> <ul style="list-style-type: none"> <li>◆ <b>Help?</b> - opens embedded help information for the active page</li> <li>◆ <b>Auto Refresh on/off</b> - lets you enable or disable the UI auto refresh action</li> <li>◆ <b>Unsaved changes: &lt;#&gt;</b> - shows the number of unsaved changes and lets you save &amp; apply the changes to the gateway's configuration or revert the changes back to the saved configuration.</li> <li>◆ <b>Logout</b> - logs you out of the web administration interface.</li> </ul>

## Logging In

The admin user or root user can log into the web admin interface.


If your gateway is new, please inspect and set up the gateway as described in [Chapter 3: Installation](#).

### To log into the web interface:

1. Open a web browser on the computer.

2. Enter the default LAN IP address 192.168.1.1. The login screen is displayed.

Figure 4-2 Web Admin Login Page



LANTRONIX  
CONNECT SMART. DO MORE.

Lantronix-G526-0080A38BFDAE

Authorization Required

Please enter your username and password.

admin

Login Reset

3. Enter the admin username and password. If you are logging in for the first time after installation or after factory reset, use the default credentials (hint: admin/admin).


### Change Passwords After Initial Login

After first login with a new device or after resetting the device to factory defaults, you are required to change the factory default passwords before any other gateway configuration can be done. Both the admin and root passwords must be changed.

**Note:** To change both admin and root password at the same time, log in as root user.

*Figure 4-3* shows the page used to change the default admin password after initial login.

Figure 4-3 Change Initial Password (admin user)



The screenshot shows the Lantronix web administration interface. On the left is a sidebar with the Lantronix logo and two buttons: 'Change pass' and 'Passchange'. The main content area is titled 'Change Initial Password' and includes a 'Logout' button in the top right. Below the title is a message: 'You are logged in as admin. Change the Initial passwords for admin and root. (You need to be logged in as root to change roots password)'. The form contains three fields: 'User' with the value 'admin', 'Password', and 'Confirmation'. The 'Password' field has a note below it: 'Password between 5 to 80 characters allowed.' There are circular icons to the right of the Password and Confirmation fields. A 'Save & Apply' button is located at the bottom right of the form.

1. For root and admin user, enter the new password and then re-enter it to confirm it.
2. Click **Save & Apply**.

This will log you out and return to the login page automatically.

## Logging Out

### To log off the web admin interface:

1. Click the **Logout** button located in the upper right part of the web admin interface page. When logout is complete, the login screen is displayed.



## 5: Using Lantronix Provisioning Manager

This chapter covers the steps for locating a device and viewing its properties and details. Lantronix Provisioning Manager is a free utility program provided by Lantronix that discovers, configures, upgrades, and manages Lantronix devices.

It can be downloaded from the Lantronix website at <https://www.lantronix.com/products/lantronix-provisioning-manager/>. For instructions on using the application, see the [Lantronix Provisioning Manager online help](#).

### Installing Lantronix Provisioning Manager

1. Download the latest version of Lantronix Provisioning Manager from <https://www.lantronix.com/products/lantronix-provisioning-manager/>.
2. In most cases, you can simply extract Lantronix Provisioning Manager from the archive and run the executable. For detailed instructions, see the [Lantronix Provisioning Manager online help](#).

### Accessing the G520 Using Lantronix Provisioning Manager

To discover a device on the local network:

1. Launch Lantronix Provisioning Manager
2. If this is the first time you have launched Lantronix Provisioning Manager, you may need to proceed through an initial setup.
3. Locate the G520 series gateway in the device list. The device's firmware version, serial number, IP address, and MAC address will be shown. Additional information can be obtained by clicking the **three dot menu** and clicking **Get Device Info**.
4. In order to perform operations on the G520 series gateway such as upgrading the firmware, updating the configuration, or uploading to the file system, click the **checkbox** next to the device and select an operation at the top.

## 6: Quick Setup

Quick Setup lets you configure the IP network port so that you can configure other gateway settings. To bypass quick setup and directly configure the network interfaces using advanced settings, go to the Network page (see [Chapter 11: Network](#)).

### Quick Setup

#### **Quick Setup > Quick Setup**

To configure the network settings:

1. On the Quick Setup page, click **Quick Setup**. The Network Setup page displays the configurable network interfaces, LAN, WAN, Cellular, and wireless LAN (Access Point mode). See [Figure 6-1](#).
2. Enter the basic configuration settings for the network interface. See [Table 6-1](#).

Figure 6-1 Quick Setup &gt; Network Setup page

[Help ?](#) [Logout](#)

### Network Setup

Here you can configure the basic aspects of your device like Lan, Wan, Wwan, Cellular.

#### Local Area Network (LAN)

IPv4-Address

If this parameter is modified, use "Apply Unchecked" instead of "Save & Apply" to avoid roll back of the configuration

IPv4-Netmask

#### Wide Area Network (Wired WAN)

**Protocol**  ▼

Manual => Used if you have static IP allocated from ISP.  
Automatic => Used if you need to do dhcp with ISP.  
PPPoE => Used if you need to do dial-up over ethernet with ISP.

**IPv4 Address**

**IPv4 Netmask**

**IPv4 Gateway**

**DNS Server**

#### Cellular

**General Settings** SIM1 settings SIM2 settings

**Primary SIM**  ▼

#### Wireless Network (LAN)

**Disable**

**Mode**

**SSID**

**Encryption**

**Password**

Table 6-1 Quick Setup Network Configuration

Parameters	Description
<b>Local Area Network (LAN)</b>	
<b>IPv4-Address</b>	Enter an IPv4 address for the LAN interface. This is the IP Address that must be used to access the gateway. The default LAN IPv4 Address is 192.168.1.1.
<b>IPv4-Netmask</b>	Enter the IPv4 netmask of the LAN interface. The default netmask is 255.255.255.0
<b>Wide Area Network (Wired WAN)</b>	
<b>Protocol</b>	Select the protocol for the WAN interface: <ul style="list-style-type: none"> <li>◆ Manual – to set a static IPv4 address. If selected, enter the details for IPv4 address, IPv4 netmask, IPv4 gateway, and DNS server.</li> <li>◆ Automatic – to use DHCP server to acquire the IP address.</li> <li>◆ PPPoE (Point to Point Protocol over Ethernet) . If selected, enter the username and password.</li> </ul> The default WAN protocol is Automatic (DHCP).
<b>Cellular</b>	
<b>SIM 1 settings/SIM 2 settings</b>	Cellular SIM card settings for two SIM card slots.
<b>APN</b>	Access Point Name (APN) is the name of an access point for the cellular network data connection. Generally, the wireless cellular network operator will provide the APN to their end users. Enter the APN provided by the cellular network operator.
<b>PIN</b>	SIM card Personal Identification Number (PIN) is used to lock the card, preventing people from making unauthorized phone call or accessing cellular data services. Enter the PIN of the SIM card.
<b>Authentication Type</b>	The authentication method used for the cellular connection. If PAP, PAP/CHAP, or CHAP are selected, enter the username and password.
<b>Username</b>	Enter the PAP/CHAP username.
<b>Password</b>	Enter the PAP/CHAP password.
<b>Enable Roaming</b>	Select to enable data roaming on the cellular interface.
<b>Wireless Network (LAN)</b>	
<b>Disable</b>	Select the check box to disable the Wireless interface. By default, the Wireless interface is enabled. <b>Note:</b> Only the default access point configuration can be modified from the Quick Setup page. To modify encryption or Wi-Fi client configuration, use the Wireless Configuration page. (Network > Wireless).
<b>Mode</b>	Displays the Wireless network (LAN) mode. Mode can be ap (access point) or client.
<b>SSID</b>	Enter the Service Set Identifier (SSID) name. Leave the field blank to use the default SSID value. The default SSID is <b>Lantronix-&lt;model&gt;-&lt;serial-number&gt;</b>
<b>Encryption</b>	Displays the type of encryption.
<b>Password</b>	The default SSID password is <b>W1rele\$\$</b> .

## 7: Status

Status provides a summary view of the vital configurations of the gateway. It includes the following pages:

- ◆ [Overview](#)
- ◆ [Firewall Status](#)
- ◆ [Routes](#)
- ◆ [System Log](#)
- ◆ [Kernel Log](#)
- ◆ [Processes](#)
- ◆ [Realtime Graphs](#)
- ◆ [Load Balancing](#)

### Overview

#### **Status > Overview**

The Status Overview page provides a listing of important system and network parameters.

To view the Status Overview:

1. Go to Status > Overview. [Figure 7-1](#) shows the System portion of the Status Overview page.

Figure 7-1 Status Overview System Details

The screenshot shows the Lantronix G526-0080A38BFDAE Status Overview page. The left sidebar contains navigation links for various system functions. The main content area displays system information in a table format.

System	
Hostname	Lantronix-G526-0080A38BFDAE
Model	G526
Part Number	G526GP1AS
UbootVersion	Lantronix SAM9X60 Bootstrap 1.0.0.0R3
Architecture	ARM926EJ-S rev 5 (v5l)
Firmware Version	Lantronix G520 1.6.0.0R10
Module Firmware	SWI9X07H_00.03.03.00 2bb7a4 jenkins 2020/04/15 07:57:29
Kernel Version	5.4.41-linux4sam-2020.04
Router Time	2021-08-17 02:00:25
Uptime	7d 1h 1m 49s
Load Average	1.79, 1.12, 0.95
Reboot Cause	Reboot from webpage at Tue Aug 10 00:58:12 UTC 2021
IMEI	352138110136175
SnapCap	Absent

2. Scroll the page to view the Status Overview sections. Click the following links for details about each of the subsections.

- ◆ [System Status](#)
- ◆ [Cellular Status](#)
- ◆ [Memory Status](#)
- ◆ [Network Status](#)
- ◆ [Active DHCP and DHCPv6 Leases Status](#)
- ◆ [Wireless Status](#)
- ◆ [Digital Input/Output Status](#)
- ◆ [Dynamic DNS Status](#)
- ◆ [MWAN Interfaces Status](#)

## System Status

The System section provides the gateway's model and software related information.

**Table 7-1 System Status Overview**

Parameters	Description
<b>Hostname</b>	Name assigned to the gateway for addressing purposes
<b>Model</b>	Model number of the gateway
<b>Part Number</b>	Model part number Example: G526GP1AS
<b>UbootVersion</b>	U-Boot version number
<b>Architecture</b>	Architecture type
<b>Firmware Version</b>	Base firmware version number
<b>POE</b>	Power Over Ethernet (PoE) is available in G520 series (security SKUs only) where the gateway be used to power a device attached on the LAN port.
<b>Module Firmware</b>	Modem firmware version
<b>Kernel Version</b>	Linux Kernel version number
<b>Router Time</b>	Day of the week, month, date, time and year configured on the unit. The format is Day Month Date hh:mm:ss Year. The time is displayed in 24-hour clock format.
<b>Uptime</b>	Displays the elapsed time since the unit last rebooted. The format is dd hh mm ss.
<b>Load Average</b>	Average CPU load time over periods of 1, 5, and 15 minute averages
<b>Reboot Cause</b>	Displays the last reboot cause and time whenever possible.
<b>IMEI</b>	15 digit IMEI number An IMEI number (International Mobile Equipment Identity) is a 15 or 17 digit unique number to identify GSM or UMTS mobile devices. It is used to prevent call initiation from a misplaced or stolen GSM or UTMS device, even if someone swaps out the device's SIM card.  <i>Note: We recommend you record the IMEI number and secure it so that it can be quickly accessed in the event of theft or loss of the unit.</i>
<b>SnapCap</b>	Displays the installation status of the SnapCap accessory. ◆ Installed ◆ Absent

## Cellular Status

The Cellular section provides the status of the SIM cards inserted in the unit.

**Table 7-2 Cellular Status Overview**

Parameters	Description
<b>Cellular Data</b>	Displays the cellular data connection status. <ul style="list-style-type: none"> <li>◆ CONNECTED – Data communication is connected.</li> <li>◆ DISCONNECTED – Data communication is not connected.</li> </ul>
<b>Signal Strength</b>	Displays the current signal strength. The signal strength range is 0 to 32. <ul style="list-style-type: none"> <li>◆ 0: -113 dBm or less (none)</li> <li>◆ 1: -111 dBm (poor)</li> <li>◆ 2 to 30: -109 to -53 dBm (fair to good)</li> <li>◆ 31: -51dBm or greater (excellent)</li> </ul> <p><i>Note: Signal strength for a good cellular data connection must be 12 or above.</i></p>
<b>Network Status</b>	Displays the registration status of the unit on the current cellular network. <ul style="list-style-type: none"> <li>◆ Registered</li> <li>◆ Not Registered</li> </ul>
<b>Operator Name</b>	Name of the cellular operator in use
<b>Operator Number</b>	Number of the cellular operator in use
<b>Operator Type</b>	Operator type
<b>Roaming Status</b>	The roaming status of the unit: <ul style="list-style-type: none"> <li>◆ Home</li> <li>◆ Roaming</li> <li>◆ N/A</li> </ul>
<b>SIM 1/SIM 2 Status</b>	Displays the availability of SIM card in SIM card slot. <ul style="list-style-type: none"> <li>◆ Error – SIM card is not inserted.</li> <li>◆ READY – SIM card is inserted.</li> </ul>
<b>Active SIM</b>	Displays the active SIM, SIM 1 or SIM 2.
<b>IMSI</b>	Displays the International Subscriber Identity (IMSI) number. In case of UMTS, it is read from the SIM card.  The IMSI is a 15 digit unique mobile number associated with the cellular network and used to acquire the details of the mobile for identifying the user of a cellular network.
<b>Configured Band</b>	The configured radio frequency bands
<b>Registered Band</b>	The registered radio frequency band
<b>Temperature</b>	Internal temperature of the unit in degrees Celsius
<b>ICCID</b>	Integrated Circuit Card ID (ICCID) – unique serial number that identifies the SIM card.



## Memory Status

The Memory section provides information about the available memory in KB.

**Table 7-3 Memory Status Overview**

Parameters	Description
<b>Total Available</b>	Total available RAM memory. Total Memory is sum of used memory, free memory, buffered memory and cached memory.
<b>Free</b>	Free RAM memory. The bar graph shows the amount of free memory as a percentage of the total memory.
<b>Buffered</b>	Size of buffered memory. The bar graph shows the amount of buffered memory as a percentage of the total memory.
<b>Cached</b>	Size of cached memory. The bar graph shows the amount of cached memory as a percentage of the total memory.

## Network Status

The Network section provides the IPv4 and IPv6 WAN status and the number of active connections.

**Table 7-4 Network Status Overview**

Parameters	Description
<b>WAN</b>	Displays status of fixed-line WAN connection with following details: <ul style="list-style-type: none"> <li>◆ Protocol – Static (manually addressed) or DHCP client (dynamically addressed)</li> <li>◆ Address – IP address of the WAN interface.</li> <li>◆ Gateway – IP address of the WAN interface gateway.</li> <li>◆ DNS – Two DNS IP addresses; primary DNS server and secondary DNS server.</li> <li>◆ Connected: Duration of time since connection was established.</li> </ul>
<b>Cellular</b>	Displays status of cellular network data connection with following details: <ul style="list-style-type: none"> <li>◆ IP – IP Address of the cellular interface.</li> <li>◆ Gateway – IP Address of the cellular interface gateway.</li> <li>◆ DNS – Two DNS IP addresses; primary DNS server and secondary DNS server.</li> </ul>
<b>WWAN</b>	Displays status of Wi-Fi WWAN connection with following details: <ul style="list-style-type: none"> <li>◆ IP – IP Address of the WWAN interface.</li> <li>◆ Gateway – IP Address of the WWAN interface gateway.</li> <li>◆ DNS – Two DNS IP addresses; primary DNS server and secondary DNS server.</li> </ul> <p><b>Note:</b> In case of WWAN access, Wi-Fi must be configured in client mode and connected to an access point.</p>

## Active DHCP and DHCPv6 Leases Status

The Active DHCP Leases and DHCPv6 Leases shows information about the devices connected to the gateway using a DHCP lease. This includes IPv4 and IPv6 connections.

**Table 7-5 Active DHCP Leases Status Overview**

Parameters	Description
<b>Host Name</b>	Name of the device (laptop, mobile, etc.) that is connected to the gateway and has been leased an IPv4 address or an IPv6 address by the gateway's DHCP server.
<b>IPv4 Address/IPv6 Address</b>	IPv4 address or IPv6 address assigned to the device.
<b>MAC Address</b>	Applies to IPv4. MAC address of the device.
<b>DUID</b>	Applies to IPv6. DUID (Device Unique Identifier) of the device connected.
<b>Leasetime remaining</b>	The remaining time for which the device can use the DHCP server leased IPv4 address.

## Wireless Status

The Wireless section describes the status of the Wi-Fi network used by the gateway and the Wi-Fi associated stations.

**Table 7-6 Wireless Status Overview**

Parameters	Description
<b>Connection Name</b>	<p>Name of the connection and the details:</p> <ul style="list-style-type: none"> <li>◆ Type – The wireless radio chipset</li> <li>◆ Channel – Wi-Fi channel</li> <li>◆ Bitrate – Data transfer rate</li> <li>◆ SSID –Service Set Identifier (SSID) that uniquely names a wireless local area network (WLAN)</li> <li>◆ Mode – Displays whether the WLAN interface is currently configured as an access point (Master) or as a client of a higher order Wi-Fi network.</li> </ul> <p><b>Note:</b> For Wi-Fi WAN (WWAN) operation, the connection mode should be 'Client'.</p> <ul style="list-style-type: none"> <li>◆ BSSID – Displays Basic Service Set Identification (BSSID); 24 bit MAC address of wireless device.</li> <li>◆ Encryption – Displays the data encryption method.</li> <li>◆ Associations – Displays the number of associated stations.</li> </ul>
<b>Associated Stations</b>	
<b>Network</b>	Mode and name of the network to which the device is connected
<b>MAC Address</b>	MAC address of the computers and/or devices that are connected
<b>Host</b>	Host name of the associated station
<b>Signal/Noise</b>	Signal strength/noise in dBm

Parameters	Description
<b>RX Rate/Tx Rate</b>	The receive (RX) and transmission (TX) data rates of the associated client. Displays data transfer rate (Mbit/s), channel bandwidth (MHz), Modulation and Coding Scheme index (MCS), and GI time (Guard Interval, for TX rate).
<b>Disconnect</b>	Click to disconnect the associated station from the access point.

### Digital Input/Output Status

The Digital Input/Output section shows the state of the two digital input/digital output pins. The status is red when the pins are Low/Open, or green when the pins are High/Closed.

### Dynamic DNS Status

The Dynamic DNS section shows the Dynamic DNS IPv4 and IPv6 configuration.

### MWAN Interfaces Status

The MWAN Interface section shows the status of the available and connected WAN options. The interface is green when it is active (it can be online or offline), and red when it is disabled. Online interfaces show tracking status and uptime. Offline interfaces show the downtime.

## Firewall Status

### *Status > Firewall*

The Firewall Status page provides a listing of the IPv4 firewall or IPv6 firewall rule chains in the Filter, NAT, Mangle, and Raw firewall tables.

You can hide or show empty chains in the firewall list, reset the counters, and restart the firewall.

<b>Hide empty chains</b>	Click to hide the chains that have no rules.
<b>Show empty chains</b>	Click to show all chains.
<b>Reset Counters</b>	Click to reset counters for number of packets and traffic.
<b>Restart Firewall</b>	Click to reload the existing firewall configuration of every interface.

[Figure 7-2](#) shows a portion of the IPv4 Firewall status page, and [Table 7-7](#) describes the firewall details.

Figure 7-2 IPv4 Firewall Status

Firewall Status

IPv4 Firewall IPv6 Firewall

Hide empty chains Reset Counters Restart Firewall

Table: Filter

Chain *INPUT* (Policy: *ACCEPT*, 2 Packets, 72 B Traffic)

Pkts.	Traffic	Target	Prot.	In	Out	Source	Destination	Options	Comment
1	112 B	ACCEPT	all	lo	*	0.0.0.0/0	0.0.0.0/0	-	-
4.62 K	762.25 KB	<a href="#">input_rule</a>	all	*	*	0.0.0.0/0	0.0.0.0/0	-	Custom input rule chain
3.55 K	534.77 KB	ACCEPT	all	*	*	0.0.0.0/0	0.0.0.0/0	ctstate RELATED,ESTABLISHED	-
288	14.98 KB	<a href="#">syn_flood</a>	tcp	*	*	0.0.0.0/0	0.0.0.0/0	tcp flags:0x17/0x02	-
0	0 B	<a href="#">zone_lan_input</a>	all	br-lan	*	0.0.0.0/0	0.0.0.0/0	-	-
1.07 K	227.48 KB	<a href="#">zone_wan_input</a>	all	eth1	*	0.0.0.0/0	0.0.0.0/0	-	-
0	0 B	<a href="#">zone_wan_input</a>	all	tun0	*	0.0.0.0/0	0.0.0.0/0	-	-
0	0 B	<a href="#">zone_wan_input</a>	all	tun1	*	0.0.0.0/0	0.0.0.0/0	-	-

Table 7-7 Firewall Status

Parameters	Description
<b>Rule Chain name and details</b>	Displays the rule chain name, type, and policy details
<b>Pkts</b>	Displays the number of accepted packets.
<b>Traffic</b>	Displays the amount of traffic captured by the filter.
<b>Target</b>	Displays the target action for the traffic processed for a respective rule.
<b>Prot.</b>	Displays the protocols configured in the firewall rule.
<b>In</b>	Input interface.
<b>Out</b>	Output interface.
<b>Source</b>	Displays the source IPv4/IPv6 address.
<b>Destination</b>	Displays the destination IPv4/IPv6 Address.
<b>Options</b>	Displays option details
<b>Comment</b>	Displays comment details

## Routes

### Status > Routes

The Routes status page displays the ARP table and active IPv4 and IPv6 routes.

Table 7-8 Routes Status

Parameters	Description
<b>ARP</b>	
<b>IPv4 Address</b>	Displays the IPv4 address.
<b>MAC Address</b>	Displays MAC address of the peripheral device.
<b>Interface</b>	Displays the interface name connected to the peripheral device.
<b>Active IPv4 Routes</b>	
<b>Network</b>	Displays the network type used by the active IPv4 routes.
<b>Target</b>	Displays the destination IPv4 address.
<b>IPv4 gateway</b>	Displays the IPv4 address gateway used for traffic routing.
<b>Metric</b>	Displays the metric assigned to the interface.
<b>Active IPv6 Routes</b>	
<b>Network</b>	Displays the network type used by the active IPv4 routes.
<b>Target</b>	Displays the destination IPv6 address.
<b>Source</b>	Displays the IPv6 address gateway used for traffic routing.
<b>Metric</b>	Displays the metric assigned to interface.

## System Log

### [Status > System Log](#)

The System Log displays detailed system, traffic, and network activity log information.

Syslog events contain the date, severity, and event details. The format is shown in the following example:

```
Tue Sep 15 22:33:38 2020 user.info Eventsms: BAND : All supported bands
```

To configure the system logs, see [System > System > Logging](#).

## Kernel Log

### [Status > Kernel log](#)

The Kernel log displays the Linux kernel log events. It shows information about hardware drivers, kernel information and status during boot up and more. It gets reset on every boot.

## Processes

### [Status > Processes](#)

The Processes log displays a list of active Linux system processes and their resource usage.

**Table 7-9 Processes Status**

Parameters	Description
<b>PID</b>	Displays the Process identifier (PID) number associated with the process.
<b>Owner</b>	Displays the task owner
<b>Command</b>	Displays the command name
<b>CPU usage %</b>	The CPU usage of the process, displayed as a percentage of the total available CPU resources.
<b>Memory usage %</b>	The amount of the system's working physical memory that the process is currently using, displayed as a percentage.
<b>Hang up</b>	Sends a hang up signal to terminate the process.
<b>Terminate</b>	Sends a terminate signal to terminate the process.
<b>Kill</b>	Sends a kill signal to immediately terminate the process. The process will not perform any cleanup operations.

## Realtime Graphs

### Status > Realtime Graphs

The Realtime graphs display the gateway's activities over time for CPU load, WAN network traffic, wireless usage, and connections.


### Load

#### Status Realtime Graphs > Load

The Load graph shows the CPU load average and peak (y-axis, % utilization) over time (x-axis). Averages are shown for 1-minute (red), 5-minute (orange), and 15-minute (yellow) load.

[Figure 7-3](#) shows a CPU load graph.

**Figure 7-3 Realtime CPU Load Graph**



## Traffic

### Status > Realtime Graphs > Traffic


The Traffic graph indicates the WAN-side incoming and outgoing traffic rate (y-axis) on the different interfaces over time (x-axis). The graphs display the average and peak data transfer on the following interfaces (if configured for WAN traffic): eth0, eth1, tun0, tun1, wwan0, can0, erspan0, br-lan, and wlan1.

Average and peak rates are shown for inbound traffic (blue) and outbound traffic (green).

The WAN interface shows average and peak WAN and cellular traffic.

[Figure 7-4](#) shows an example of network traffic for the eth1 interface:

**Figure 7-4 Realtime Network Traffic Graph (eth1)**



## Wireless

### Status > Realtime Graphs > Wireless


The Wireless graph indicates Wi-Fi usage including signal and noise levels (y-axis, dBm) and physical data transfer rate (y-axis, Mbit/sec) over time (x-axis).

The top graph displays signal (blue) and noise (red) levels. The bottom graph displays the physical data transfer rate (green) irrespective of Wi-Fi being used as an access point or client.

[Figure 7-5](#) shows the wireless usage graph for a G520 series device configured as Wi-Fi client (STA) and connected to an external access point.



Figure 7-5 Realtime Wireless Usage Graph (client)



## Connection

### Status > Realtime Graphs > Connection


The Connection graph indicates the number of active network connections (x-axis) over time (y-axis). It includes connections originating from the gateway and also connections originating from the LAN or WAN.

The graph displays UDP (blue), TCP (green) and other (red) connections. The table below the graph displays connection details including IPv4/IPv6, protocol, source IP, destination IP, and amount of data transferred.

By default DNS lookup is disabled. You can enable it by clicking the link **Enable DNS lookups** below the graph.

Figure 7-6 shows a realtime connection graph for an idle gateway.

**Figure 7-6 Realtime Connection Traffic Graph**



---

## Load Balancing

*Status > Load Balancing*

### Interface

*Status > Load Balancing > Interface*

The Interface page shows the MWAN interfaces, with active interfaces shown in green and disabled interfaces shown in red. The uptime (hh:mm:ss) is displayed for active interfaces.

### Detail

*Status > Load Balancing > Detail*

The Detail page shows MWAN interface (IPv4 and IPv6) details including interface status, current policies, directly connected networks, and active user rules.

### Diagnostics

*Status > Load Balancing > Diagnostics*

The Diagnostics page shows all configured MWAN interfaces and provides diagnostic commands to check the health of the selected MWAN interface.

The following diagnostics commands are supported:

- ◆ Ping the default gateway
- ◆ Ping tracking IP
- ◆ Check IP rules
- ◆ Check routing tables
- ◆ Hotplug ifup
- ◆ Hotplug ifdown

To run a diagnostics command, select the interface and the task and click **Execute**.

### Troubleshooting

*Status > Load Balancing > Troubleshooting*

The Troubleshooting page displays the output of the following IP commands:

- ◆ ip a show
- ◆ ip route show
- ◆ ip route list table 1-250
- ◆ iptables -L -t mangle -v -n

## 8: System

The System pages provide configuration for secure local and remote management. The System menu contains the following sections:

- ◆ [System](#)
- ◆ [Administration](#)
- ◆ [Software](#)
- ◆ [Startup](#)
- ◆ [Scheduled Tasks](#)
- ◆ [LED Configuration](#)
- ◆ [Backup / Flash Firmware](#)
- ◆ [Custom Commands](#)
- ◆ [Reboot](#)

### System

#### [System](#) > [System](#)

This section contains settings that apply to the basic operation of the system, including the hostname, time zone, and system log configuration.

#### General Settings

##### [System](#) > [System](#) > [General Settings](#)

General settings let you configure local and router time, hostname, and time zone.

To configure general system settings:

1. Go to [System](#) > [System](#) > [General Settings](#).
2. Enter the configuration settings. See [Table 8-1](#).
3. Click **Save & Apply**.

**Table 8-1 System General Settings**

Parameters	Description
<b>Local Time</b>	<p>Displays the local time of the user's computer. Sync the local time with browser or with an NTP server.</p> <p>Click <b>Sync with browser</b> button to synchronize the gateway's clock with the local computer browser.</p> <p>Click <b>Sync with NTP-Server</b> to synchronize the gateway's clock with an NTP server.</p> <p><b>Note:</b> The displayed time is dependent on the configuration of your local computer that is being used as an NTP server.</p>
<b>Router Time</b>	<p>Displays the current router time according to the configured time zone.</p>

Parameters	Description
<b>Hostname</b>	Displays the hostname for this unit. Do not include the period character "." in the hostname as only the string before the period will be used as the hostname.
<b>Timezone</b>	Select time zone according to the geographical region in which the unit is deployed. The default time zone is UTC.
<b>Set Time Manually</b>	Set the year, month, date, hour, minute and seconds. Click <b>Apply the time</b> to save the information.

## Logging

### System > System > Logging

The system logger provides important debugging and monitoring capabilities. The system logs capture traffic, system, and network activity. The logs are stored in RAM and are reset when the gateway is rebooted.

The system logs can be stored locally or sent to an external UDP or TCP syslog server for storage and archival purposes.

To configure the system log settings:

1. Go to System > System > General Settings.
2. Enter the configuration settings (see [Table 8-2](#)).
3. Click **Save & Apply**.

**Table 8-2 Syslog Configuration**

Parameters	Description
<b>System log buffer size</b>	Enter the size of the buffer in Kilobytes (KB) to save logs and status information details. The default system log buffer size is 64 KB. When the buffer is full, records will be overwritten on a first in, first out (FIFO) basis.
<b>External system log server</b>	Enter the IP address of an external syslog server to be used to save the real time logs. By default the logs are written to the local system.
<b>External system log server port</b>	Enter the UDP port number of the external syslog server. The default port is 514.
<b>External system log server protocol</b>	Protocol of the external syslog server. UDP
<b>Write system log to file</b>	File path and file name to write the log messages to. If an external filesystem (SD card or USB flash drive) is mounted, add the mount path and file name here. The logs display application (see <a href="#">Services &gt; Logs Information</a> ) will download the files written to this file path. Example: /mnt/usbdevice/log.txt

Parameters	Description
Log output level	<p>Select the log severity output level. The level of severity progresses from Info to Emergency. Lower severity levels are more verbose and will include messages from all higher severity levels.</p> <p>Log levels are listed in order of increasing severity:</p> <ul style="list-style-type: none"> <li>◆ Debug – Provides debug messages used by the software developer for debugging the application. These logs are typically not useful during operations.</li> <li>◆ Info – Provides normal operational information messages that are used for general purposes like reporting.</li> <li>◆ Notice – Provides alerts for peculiar events that are not an error. These logs help to identify potential issues. Since these logs do not indicate errors, immediate action may/may not be necessary.</li> <li>◆ Warning – Displays warning messages for a potential issue, indicating to take an action. An error may occur if no action is taken against the warning issued.</li> <li>◆ Error – Displays the messages indicating an error condition.</li> <li>◆ Critical – Indicates failure in secondary system and must be corrected immediately.</li> <li>◆ Alert – Problems which should be corrected immediately.</li> <li>◆ Emergency – System is unusable.</li> </ul> <p><b>Note:</b> For help with log errors, contact <a href="#">Lantronix Technical Support</a>.</p>
Cron log level	<p>Select the minimum level for cron messages to be logged to syslog.</p> <ul style="list-style-type: none"> <li>◆ Debug – Helps to debug cron process which has failed during runtime.</li> <li>◆ Normal – Displays informational messages</li> <li>◆ Warning – Indicates some issues can happen or error could be generated in cron process.</li> </ul> <p><b>Note:</b> For help with Cron log warning messages, contact <a href="#">Lantronix Technical Support</a>.</p>

## Time Synchronization

### System > System > Time Synchronization

Select the method that the gateway uses to synchronize its internal clock.

**Note:** If all three methods are enabled, the order of precedence is GPS, then NTP, then GSM.

Table 8-3 System Time Synchronization Configuration

Time Synchronization	
GPS Time Synchronization	<p>For gateways that support GPS. If enabled, the gateway will synchronize its internal clock using GPS.</p> <p><b>Note:</b> GPS antenna will be needed for GPS time sync.</p>
Enable NTP client	<p>If enabled, the gateway will synchronize its internal clock every 60 minutes from an NTP server.</p> <p><b>Note:</b> Enabling NTP Client consumes data.</p>
GSM Time Synchronization	<p>If enabled, the gateway will synchronize using GSM functionality.</p>

## Language and Style

### System > System > Language and Style

The language and style settings are used to control the look and feel of the web interface.

Table 8-4 Language and Style Configurations

Parameters	Description
Language	Default value is auto.
Design	Default design of user interface is Rosy.
Auto refresh default pollinterval in seconds	Set the auto refresh polling interval between 5 and 50 seconds. Default is 5 seconds.  <i>Note: Auto refresh can be turned on or off using the Auto Refresh button on the UI.</i>

## Administration

### System > Administration

The Administration page allows you to configure the unit's password and SSH access to the device. You can configure various ports and login security.

### Router Password

#### System > Administration > Router Password

This page allows you to change the login password of the current user. If you are logged in as administrator, you can change the administrator password, and if you are logged in as root, you can change the root password and the administrator password.

To change the password:

1. Go to System > Administration.
2. Type the new password and retype it to confirm.
3. Click **Save**.

### SSH Access

#### System > Administration > SSH Access

Secure Shell (SSH) lets you securely and remotely access the gateway over the network from a terminal emulator to view and configure it. SSH provides strong password authentication and public key authentication, as well as encrypted data communication between your computer and the router. The router listens for SSH connections on TCP port 22 (default).

To set up SSH access, an SSH key is required. You can use the default SSH key or generate and upload your own SSH keys.

By default, remote SSH over WAN is disabled. It can be enabled from the web interface (you need to enable port 22 in Firewall settings) or by sending an SMS from a registered admin number. You should disable SSH access on interfaces when it's not needed.

To configure SSH access:

1. Go to System > Administration > SSH Access.
2. Enter the configuration settings (see [Table 8-5](#)).

Table 8-5 SSH Access Configuration

Parameters	Description
<b>Interface</b>	Select the interface. SSH listens only on the selected interface. <i>Note: Unspecified – If this option is selected, SSH listens on all interfaces.</i>
<b>Port</b>	Provide the listening port of the instance. Default port is 22.
<b>Password Authentication</b>	Select to allow authentication using SSH password.
<b>Allow root logins</b>	Select to allow root user logins to the router.
<b>Allow root logins with password</b>	Select to allow root logins and require a password.
<b>GatewayPorts</b>	Select to allow remote hosts to connect to local SSH forwarded ports.
<b>Add Instance</b>	Click to add another SSH instance.

## SSH-Keys

### System > Administration > SSH-Key

Public SSH keys are used to authenticate with SSH public key authentication. One or more keys are provided by default or you can upload your own keys.

To add a new public SSH key:

1. Go to System > Administration > SSH-Keys.
2. Copy the public key from the host system and paste it in the input field. Alternatively, drag and drop the SSH key file (.pub) into the input field.
3. Click **Add key**.

## Software

### System > Software

The software package manager lets you install, update, and remove software packages. Software packages can be stored on the Lantronix package server, you can use your own custom package feeds, or you can upload the package from your local machine.

The web interface also lets you view and modify the OPKG package manager configuration files. See [Configure OPKG](#).

To manage packages:

1. Go to System > Software.
2. Select the list view:
  - ◆ **Available** displays the packages that are stored on the Lantronix package server.
  - ◆ **Installed** displays the installed packages on the unit.
  - ◆ **Updates** displays the packages for which an update is available from the server.



**Note:** To refresh the list, click **Update lists...**

3. To install a package, do one of the following:
  - ◆ From the list of Available packages, select the package and click **Install**.
  - ◆ Under **Download and install package**, enter the package name (for a package on the download server) or enter the URL (for a package on a custom feed), and click **OK**.
  - ◆ Click **Upload Package** and browse to select the package from the local machine.
4. To remove a package, from the list of Installed packages, select the package and click **Remove**.

**Table 8-6 Software Package Details**

Parameters	Description
<b>Available Memory</b>	
<b>Free space</b>	Indicates the free and used space on the flash memory. The darker line represents the portion of free space.
<b>Available, Installed, or Update Package Details</b>	
<b>Package name</b>	Displays the name of package.
<b>Version</b>	Displays the version of package.
<b>Size (.ipk)</b>	Displays the size of the installed package.
<b>Description</b>	Displays the package description, if one has been provided.

## Configure OPKG

The OPKG configuration files define the configuration and feed locations used by the OPKG package manager. It includes the following configuration files:

- ◆ `opkg.conf` – This configuration file sets the default folders.
- ◆ `opkg/customfeeds.conf` – This file is used to add your custom package feeds (repositories).
- ◆ `opkg/distfeeds.conf` – This file is used to set the feeds. By default, it provides the path to the Lantronix package server.

To modify the OPKG configuration:

1. Go to System > Software.
2. Click the **Configure opkg** button.
3. Modify the OPKG configuration (see [Table 8-7](#)).
4. Click **Save**.

Table 8-7 OPKG Package Manager Configuration

Parameters	Description
<b>opkg.conf</b>	<p>The default configuration is shown:</p> <ul style="list-style-type: none"> <li>◆ dest root /</li> <li>◆ dest ram /tmp</li> <li>◆ lists_dir ext /var/opkg-lists</li> <li>◆ option overlay_root /overlay</li> <li>◆ option check_signature</li> </ul> <p>The options can be left at the default value.</p>
<b>customfeeds.conf</b>	<p>Enter each custom package feed on its own line.</p> <p>The feed can be on a remote server, in a version control system, on the local file system, or in any location addressable by a single name (path/URL) over a protocol with a supported feed method.</p> <p>An example format is provided:</p> <pre># src/gz example_feed_name http://www.example.com/path/to/files</pre> <p>Remove the “#” (hash symbol) at the start of the line.</p>
<b>distfeeds.conf</b>	<p>Displays the Lantronix package feeds repository.</p> <p>The feed can be on a remote server, in a version control system, on the local file system, or in any location addressable by a single name (path/URL) over a protocol with a supported feed method.</p>

## Startup

### System > Startup

### Initscripts

#### System > Startup > Initscripts

Init scripts are run to start required processes during the boot process. The web interface lets you view and enable or disable installed init scripts. Reboot the router for the changes to take effect.

**Note:** *Disabling an essential script such as a network script may cause your device to become inaccessible.*

- ◆ **Enable** and **Disable** actions enable or disable the initscript.
- ◆ **Start**, **Restart**, and **Stop** actions perform the specified action on the process immediately.

[Table 8-8](#) describes the initscripts.

Table 8-8 Initscripts Actions

Parameters	Description
<b>Start priority</b>	Displays the priority of when the initscript is run during startup. Order of priority is from 00 to 99.
<b>Initscript</b>	Displays the name of the initscript
<b>Enable/Disable</b>	Displays the current state as Enabled or Disabled. Click the button to disable or enable the initscript.
<b>Start</b>	Starts the initscript immediately

Parameters	Description
<b>Restart</b>	Restarts the initscript immediately
<b>Stop</b>	Stops the initscript immediately

## Local Startup

### System > Startup > Local Startup

The local startup file (/etc/rc.local) contains custom commands that are run at the end of the boot process, after the system is initialized. By default, it is empty.

To configure the local startup file:

1. Go to System > Startup > Local Startup.
2. In the editor, type custom commands on any line before the line "exit 0". Make sure that the file ends with the line "exit 0".
3. Click **Save**.

Changes will take effect on the next reboot.

## Scheduled Tasks

### System > Scheduled Tasks

This feature lets you schedule cron jobs to run at a fixed time, date, or interval.

Enter each task on a separate line in the crontab file. Tasks are specified using the following syntax:

```
* * * * * command to execute
- - - - -
| | | | •----day of the week (0-6) (Sunday=0)
| | | •-----month (1-12)
| | •-----day of month (1-31)
| •-----hour (0-23)
•-----min (0-59)
```

To configure scheduled tasks:

1. Go to System > Scheduled Tasks.
  - Note:** If the editor is empty, you must restart the cron service before creating a scheduled task. To restart the cron service, go to Services > Service Actions in the web interface.
2. Enter the cron task according to the syntax described above. [Table 8-9](#) lists available shortcuts.
3. Click **Save**.

Table 8-9 Cron Shortcuts

Shortcut	Equivalent	Description
@reboot	(none)	At system startup
@yearly	0 0 1 1 *	Every year

Shortcut	Equivalent	Description
@annually	0 0 1 1 *	Every year
@monthly	0 0 1 **	Every month
@weekly	0 0 * * 0	Every week
@daily	0 0 * * *	Every day
@midnight	0 0 * * *	Every day
@hourly	0 * * * *	Every hour

## LED Configuration

### System > LED Configuration

The G520 series router provides 9 LEDs to indicate status and activity. Among these, there are 2 user-programmable LEDs. The other LEDs are not recommended to be modified. For a description of the default LED behaviors, see [LEDs](#).

The LED can be controlled by various system events, which is selected by the trigger option. Depending on the trigger, additional options must be specified. See [Table 8-10](#) which lists some trigger descriptions. The UI displays some triggers not listed in the table, but these are not recommended to be used.

**Table 8-10 Trigger Descriptions**

Trigger	Description	Examples
none	The LED is always in the default state. This is useful to declare an LED to be always ON.	LED always on: <ul style="list-style-type: none"> <li>◆ LED name: any LED</li> <li>◆ Default: On</li> <li>◆ Trigger: none</li> </ul>
timer	The LED blinks with the configured On/Off frequency. Options: <ul style="list-style-type: none"> <li>◆ On-state delay: time in milliseconds that the LED is On.</li> <li>◆ Off-state delay: time in milliseconds that the LED is Off.</li> </ul>	LED is 100ms On / 200ms Off: <ul style="list-style-type: none"> <li>◆ LED name: any LED</li> <li>◆ Default: On</li> <li>◆ Trigger: timer</li> <li>◆ On-State Delay: 100</li> <li>◆ Off-State Delay: 200</li> </ul>
defaulton	This trigger option is deprecated. Use trigger = none and default = On instead.	
heartbeat	The LED flashes to simulate actual heartbeat thump-thump-pause. The frequency is in direct proportion to 1-minute average CPU load.	LED blinks in heartbeat pattern: <ul style="list-style-type: none"> <li>◆ LED name: any LED</li> <li>◆ Default: Off</li> <li>◆ Trigger: heartbeat</li> </ul>

Trigger	Description	Examples
netdev	<p>Network Activity</p> <p>The LED flashes with link status and/or send and receive activity on the configured interface.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>◆ Device: name of the network interface whose status will be indicated</li> <li>◆ Mode: link, transmit, receive. One or more can be selected</li> </ul>	<p>LED blinks when there is a link, transmit or receive activity on the configured network interface (WAN, WWAN, LAN, cellular).</p> <ul style="list-style-type: none"> <li>◆ LED name: G520-wwanactivity, G520-lanactivity, G520-wanactivity, or G520-network</li> <li>◆ Default: Off</li> <li>◆ Trigger: netdev</li> <li>◆ Device: select the configured interface (for example, "Ethernet adapter: eth1" for WAN)</li> <li>◆ Mode: Link, Transmit, Receive</li> </ul>
usbdev usbport	<p>The LED turns on if a USB device is connected. It is recommended to use usbport rather than usbdev.</p> <p>Options for usbport:</p> <ul style="list-style-type: none"> <li>◆ USB Port: select the configured USB port</li> </ul> <p>Options for usbdev:</p> <ul style="list-style-type: none"> <li>◆ USB device: select the configured USP device</li> </ul>	<p>LED turns on if USB device is connected.</p> <ul style="list-style-type: none"> <li>◆ LED name:</li> <li>◆ Default: Off</li> <li>◆ Trigger: usbport</li> <li>◆ USP Port: Portusb1-port2</li> </ul>

**Note:** LED configuration should be done by experienced personnel. Use care when modifying the LEDs as improper configuration may cause LED indicators to be misread or missed.

To configure the user-programmable LED:

1. Go to System > LED Configuration.
2. Click **Add LED action** or click **Edit** next to the existing LED action that you want to modify.
3. Enter or modify the configuration settings. See [Table 8-11](#).
4. Click **Save**.
5. Click **Save & Apply**.

**Table 8-11 LED Configuration**

Parameter	Description
<b>Name</b>	Displays the descriptive name of the LED.
<b>LED Name</b>	Displays the LED name by function.
<b>Default state</b>	Displays the default state of the LED before the trigger. Options are On or Off.
<b>Trigger</b>	Displays the trigger event that will toggle the LED state. For descriptions, see <a href="#">Table 8-10</a> .

## Backup / Flash Firmware

### System > Backup / Flash Firmware

This page allows you to do backup and maintenance operations to keep the device healthy. Operations include download and restore backup configuration file, reset the device to factory defaults, and flash the device firmware.

Run backups to keep the working configuration data. The backup consists of all policies and all other user related information.

Restore backups to restore configuration on the router or to configure a new router with the same settings.

### Actions

#### System > Backup / Flash Firmware > Actions

To perform backup/flash firmware operations:

1. Go to System > Backup/Flash Firmware > Actions.
2. Click the button corresponding to the operation that you want to perform. Follow the prompts for the selected operation. See [Table 8-12](#).

**Table 8-12 Backup, Restore, and Flash Operations**

Parameters	Description
<b>Backup/Restore</b>	
<b>Download Backup</b>	Click <b>Generate archive</b> button to download a .tar archive file of the current configuration files.
<b>Reset to defaults</b>	<p>Click <b>Perform Reset</b> button to reset the firmware to its default configurations.</p> <p>This is valid only with squashfs images.</p> <p><b>Note:</b> <i>The router can also be reset by pressing the reset button on the router. Reset button behavior is as follows:</i></p> <ul style="list-style-type: none"> <li>◆ <i>Press and hold for more than 5 seconds and less than 20 seconds to reset the router to factory settings.</i></li> <li>◆ <i>Press and hold for more than one second but less than 5 seconds to reboot the router.</i></li> </ul>
<b>Restore backup</b>	Click <b>Upload archive</b> button to upload a previously generated backup archive.
<b>Flash image</b>	
<b>Image</b>	<p>Click <b>Flash image</b> button to upload a sysupgrade compatible image for replacing the running firmware.</p> <p><b>Note:</b> <i>Do not power off the device during the update.</i></p> <p>When the image file is uploaded, a file integrity check is done through the use of md5 algorithm. You should verify the md5 value with the one given along with the binary file.</p> <p>When uploading the binary image, the UI will prompt to “Keep settings and retain the current configuration.” This is selected by default. If you deselect it, the device configuration will be reset to factory setting after updating to the new firmware.</p>

## Configuration

### *System > Backup / Flash Firmware > Configuration*

Add files and directories that should be preserved during a system upgrade to the backup file list. Modified files in `/etc/config/` directory and certain other configurations are automatically preserved.

To show the current backup file list, click **Open list...**

To modify the backup file list:

1. Go to System > Backup/Flash Firmware > Configuration.
2. In the editor, place the cursor below the last line.
3. Enter file path for each file or directory on a new line. The file path is relative to the top level directory.
4. Click **Save**.

## Custom Commands

### *System > Custom Commands*

Write and execute custom shell commands from the web interface.

### Write Custom Shell Command

This page lets you add or delete custom shell commands.

To write a custom shell command:

1. Go to System > Custom Commands > Configure.
2. Click **Add**.
3. Enter the command details. See [Table 8-13](#).
4. Click **Save** or **Save & Apply**.

The commands will be visible on the dashboard where you can run them.

**Table 8-13 Custom Commands Configuration**

Parameter	Description
<b>Description</b>	A short text description of the command.
<b>Command</b>	The command to execute on the shell terminal. To specify a file to be executed, the file must be copied to the <code>/usr/sbin</code> directory on the router. Files not in env PATH require the complete file path and should be executable.
<b>Custom arguments</b>	Check the box to allow user to provide additional command line arguments while running this command.
<b>Public access</b>	Check the box to allow the command to be executed and the output downloaded without prior authentication.

## Run Custom Shell Command

Run custom shell commands. You also have the option to download the results of the command.

To run a custom command:

1. Go to System > Custom Commands > Dashboard.
2. Select the command to be run and click **Run**.

The command, result, and return code are displayed in a box below the custom command.

## Reboot

### System > Reboot

Perform a reboot of the router. The router will restart and reload the configuration. Any unsaved configuration will be lost when the router is rebooted.

To reboot the router:

1. Go to System > Reboot.
2. Click **Perform Reboot**.

The router will restart and reload the configuration. After the router reboots, the login page will be displayed.

### Schedule a Reboot

Schedule times when the router will reboot itself. You can set the frequency by time of day (hour and minute), day of week, and day of month.

The scheduled item must be enabled in order for the router to reboot itself.

To configure the reboot schedule:

1. Go to System > Reboot > Schedule Reboot.
2. Click **Add**.
3. Enter the schedule details (see [Table 8-14](#)).
4. Click **Save**.

**Table 8-14 Schedule Reboot Time Specification**

Parameter	Description
Minute	Range: 0-59
Hour	Range: 0-23 0 = midnight
Day of week	Range: 0-6 0 = Sunday
Date	1-31
Month	Range: 1-12



## 9: VPN

A Virtual Private Network (VPN) tunnel carries traffic of a private network from one endpoint system to another over a public network such as the Internet. The traffic of a private network so carried over a public network does not know about the existence of the intermediate hops between the two endpoints. Similarly, the intermediate hops are also not aware that they are carrying the network packets that are traversing the tunnel. The tunnel may optionally compress and/or encrypt the data, providing enhanced performance and some measure of security.

**Note:** The G520 series gateways support additional tunneling protocols. For L2TP, PPTP, or GRE protocol configuration, see [Interface Protocols](#).

### IPsec (Internet Protocol Security)

#### VPN > IPsec

The IP Security (IPsec) suite of protocols are designed for cryptographically secure communication at the IP layer. The gateway uses standard IPsec protocol to protect traffic. The identity of communicating users is checked with the user authentication based on pre-shared keys (PSK) or X.509 certificates.

The IPsec VPN instance can be started or stopped from the Web UI or by sending an SMS AT+VPN command. See [Table 10-26 SMS AT Command Syntax](#).

You can configure a router-to-router VPN connection.

To configure an IPsec instance:

1. Go to VPN > IPsec, and click **Add**.
2. Under router to router, click **Add**.
3. Enter the VPN configuration details on the General Settings ([Table 9-1](#)) and Advanced Settings ([Table 9-2](#)) tabs.

**Table 9-1 IPsec General Settings**

Parameters	Description
<b>Profile Name</b>	Enter the Profile Name to identify the router-to-router IPsec VPN connection.
<b>Proto Type</b>	router to router is the only available option.
<b>Enable</b>	Check to enable the connection.
<b>Remote IPsec router</b>	Enter the remote WAN IP Address or domain name of the remote IPsec router server.
<b>Remote Address</b>	Enter the remote LAN IP Address and subnet of the remote IPSEC router server for use on the VPN connection.
<b>Remote ID</b>	Enter the ID of the remote network as configured on the remote IPsec router server.

Parameters	Description
<b>Method</b>	Select the interface used to establish the tunnel. <ul style="list-style-type: none"> <li>◆ Static – indicates that you will specify the interface to be used to establish the tunnel</li> <li>◆ Auto – uses the interface that is active from the Load Balancer (MWAN) policies</li> </ul>
<b>Route</b>	Available if Static is selected in Method field. Select the interface used to configure IPsec: <ul style="list-style-type: none"> <li>◆ Wan</li> <li>◆ Wifi</li> <li>◆ Cellular</li> </ul>
<b>Policy</b>	Available if Auto is selected in Method field. Select the MWAN policy to use.
<b>Interface</b>	Displays the IP address of the interface used for the VPN connection.
<b>Local Address</b>	Enter the local network IP Address and subnet mask of the router for use on the VPN connection.
<b>Local ID</b>	Enter the ID of the local router as configured on the remote IPSEC router server. Note: On the remote server, it may be displayed as "remote ID."
<b>Key Mode</b>	Select the type of Key mode in use for VPN connection: <ul style="list-style-type: none"> <li>◆ Pre shared Key</li> <li>◆ X.509 certificate</li> </ul>
<b>Preshared-Key</b>	This field is available if Pre shared Key is selected in the Key Mode field. Enter the key. The peer uses the key to authenticate each other from Internet Key Exchange.
<b>Cert.</b>	This field is available if X.509 Certificate is selected in the Key Mode field. The certificate file must be uploaded to the /etc/ipsec.d/certs directory. Click <b>Select file...</b> to browse the local drive and select the file. Click <b>Upload file...</b> to upload the file. After the file is uploaded, the Cert. field displays the file name and time stamp of the upload. To delete a file, click <b>Delete</b> .
<b>Key</b>	This field is available if X.509 Certificate is selected in the Key Mode field. The key file must be uploaded to the /etc/ipsec.d/private directory. Click <b>Select file...</b> to browse the local drive and select the file. Click <b>Upload file...</b> to upload the file. After the file is uploaded, the Key field displays the file name and time stamp of the upload. To delete a file, click <b>Delete</b> .

Parameters	Description
<b>CA Cert.</b>	<p>This field is available if X.509 Certificate is selected in the Key Mode field.</p> <p>The CA certificate file must be uploaded to the /etc/ipsec.d/cacerts directory.</p> <p>Click <b>Select file...</b> to browse the local drive and select the file.</p> <p>Click <b>Upload file...</b> to upload the file.</p> <p>After the file is uploaded, the CA Cert. field displays the file name and time stamp of the upload.</p> <p>To delete a file, click <b>Delete</b>.</p>
<b>Single hop IP for watchdog</b>	<p>Enter the IP address to be used for monitoring purposes. The application will ping the IP defined here. If the ping fails, it will restart the device. This could be the LAN IP address of the IPsec router server.</p>
<b>Monitor interface ping failure</b>	<p>Select Yes to ping the IP address defined in Single hop IP for watchdog.</p> <p>Select No if you don't want the monitor interface to ping the single hop IP address.</p> <p>The default is No.</p>

Table 9-2 IPsec Advanced Settings

Parameters	Description
<b>IKE Mode</b>	<p>Select the mode that Internet Key Exchange (IKE) protocol uses to authenticate and/or encrypt the peers.</p> <ul style="list-style-type: none"> <li>◆ Main</li> <li>◆ Aggressive</li> </ul>
<b>Key Exchange</b>	<p>Select the mode of encryption key exchange between two communicating peers:</p> <ul style="list-style-type: none"> <li>◆ IKEV1</li> <li>◆ IKEV2</li> <li>◆ The default mode is IKEV1.</li> </ul>
<b>IKE Encryption</b>	<p>Select the cipher type to use for the Internet Key Exchange (IKE):</p> <ul style="list-style-type: none"> <li>◆ Any</li> <li>◆ AES</li> <li>◆ AES-128</li> <li>◆ AES-192</li> <li>◆ AES-256</li> <li>◆ 3DES</li> <li>◆ DES</li> </ul> <p>The default cipher type is "Any".</p>

Parameters	Description
<b>IKE Hash</b>	<p>The IKE hash is used for authentication of packets for the key exchange.</p> <p>Select the IKE Hash type to use for VPN connection:</p> <ul style="list-style-type: none"> <li>◆ Any</li> <li>◆ MD5</li> <li>◆ SHA1</li> <li>◆ SHA2 256</li> <li>◆ SHA2 384</li> <li>◆ SHA2 512</li> </ul> <p>The default IKE hash type is "Any".</p>
<b>IKE DH Group</b>	<p>Select the desired Diffie-Hellman group to use:</p> <ul style="list-style-type: none"> <li>◆ Any</li> <li>◆ Group 1 (768)</li> <li>◆ Group 2 (1024)</li> <li>◆ Group 5 (1536)</li> <li>◆ Group 14 (2048)</li> <li>◆ Group 15 (3072)</li> <li>◆ Group 16 (4096)</li> <li>◆ Group 17 (6144)</li> <li>◆ Group 18 (8192)</li> </ul> <p>Higher-numbered groups are more secure but also require longer to generate the key.</p> <p>The default group is "Any".</p>
<b>IPsec Encryption</b>	<p>Select the type of IPsec encryption for VPN connection:</p> <ul style="list-style-type: none"> <li>◆ Any</li> <li>◆ AES</li> <li>◆ AES-128</li> <li>◆ AES-192</li> <li>◆ AES-256</li> <li>◆ 3DES</li> <li>◆ DES</li> </ul> <p>The default cipher type is "Any".</p>
<b>IPsec Hash</b>	<p>The IPsec hash is used for authentication of packets for the key exchange.</p> <p>Select the IPsec Hash type to use for VPN connection:</p> <ul style="list-style-type: none"> <li>◆ Any</li> <li>◆ MD5</li> <li>◆ SHA1</li> <li>◆ SHA2 256</li> <li>◆ SHA2-384</li> <li>◆ SHA2-512</li> </ul> <p>The default hash type is "Any".</p>

Parameters	Description
<b>DH Group</b>	Select the desired Diffie-Hellman group to use: <ul style="list-style-type: none"> <li>◆ Any</li> <li>◆ Group 1 (768)</li> <li>◆ Group 2 (1024)</li> <li>◆ Group 5 (1536)</li> <li>◆ Group 14 (2048)</li> <li>◆ Group 15 (3072)</li> <li>◆ Group 16 (4096)</li> <li>◆ Group 17 (6144)</li> <li>◆ Group 18 (8192)</li> </ul> <p>Higher-numbered groups are more secure but also require longer to generate the key.</p> <p>The default group is “Any”.</p>
<b>DPD Keep Alive Time</b>	Enter the time in seconds for interval between Dead Peer Detection keep alive messages.
<b>DPD Timeout</b>	Enter the time in seconds of no response from peer before Dead Peer Detection times out.
<b>IKE Re-key Time</b>	Enter the time in seconds between changes of the encryption key. To disable changing the key, set it to 0.
<b>SA Life Time</b>	Enter the time in seconds for the security association lifetime.
<b>DPD Action</b>	Select the desired Dead Peer Detection action. This action must be taken when a dead IKE peer is detected.

4. Click **Save**. The instance is saved and displayed on the IPsec page.
5. After configuring the profile, click **Connect** to start the IPsec connection for the first time.

## OpenVPN

### VPN > OpenVPN

OpenVPN is an open-source software application that implements virtual private network (VPN) techniques for creating secure point-to-point or site-to-site connections. It uses the OpenSSL library to provide encryption of both the data and control channels. OpenVPN can run over UDP or TCP transports, multiplexing created SSL tunnels on a single TCP/UDP port.

OpenVPN fully supports IPv6 as the protocol of the virtual network inside a tunnel and the OpenVPN applications can also establish connections via IPv6. It has the ability to work through most proxy servers (including HTTP) and is good at working through network address translation (NAT) and getting out through firewalls. The server configuration has the ability to push certain network configuration options to the clients, including IP addresses, routing commands, and a few connection options.

The G520 series gateways support OpenVPN client, server, and pass through.

### OpenVPN Instances

The OpenVPN client will attach itself to the configured OpenVPN server over any available WAN, LAN, or Cellular network interface. If the auto-connect function is enabled, OpenVPN will connect over available WAN, switch between WAN connections when one WAN fails-over to another, and also auto start on every reboot.

To create an OpenVPN instance:

1. Go to VPN > OpenVPN. The following page is displayed:

The screenshot displays the OpenVPN configuration interface. At the top, under 'OpenVPN', there are two profile cards. The first card, 'openvpn\_1', shows a status of 'RX: 0 B (0 Pkts.)' and 'TX: 0 B (0 Pkts.)' and is associated with tunnel '(tun0)'. The second card, 'openvpn\_2', also shows 'RX: 0 B (0 Pkts.)' and 'TX: 0 B (0 Pkts.)' and is associated with tunnel '(tun1)'. Below this, the 'OpenVPN instances' section provides a table of configured instances and their current state. The table has columns for Name, Enabled, Started, Start/Stop, Port, Protocol, and Tunnel. The instance 'openvpn\_1' is listed with 'Enabled' as an unchecked checkbox, 'Started' as 'no', a 'start' button, 'Port' as 1194, 'Protocol' as 'udp', and 'Tunnel' as 'tun0'. There are 'Edit' and 'Delete' buttons for this instance. Below the table, there are sections for 'Template based configuration' and 'OVPN configuration file upload'.

2. Under OpenVPN instances, select the method for the instance configuration:
  - ◆ **Template based configuration** – Select the instance name and the template (server or client templates are provided). Click **Add**.
  - ◆ **OVPN configuration file upload** – Select the instance name and then choose the OVPN configuration file. Click **Upload**.
3. The instance is added to the list under OpenVPN instances.
4. Choose from the following options:
  - ◆ To continue configuring the instance, click **Edit**. See [Template-based Configuration](#) or [OpenVPN Configuration File](#) for details respective to the configuration method.
  - ◆ To enable the instance, select **Enabled**.
5. Click **Save & Apply**.

**Note:** You must manually enter the DNS from [Network > DHCP and DNS](#).

---

## Template-based Configuration

### Predefined templates

Use the following predefined server and client templates to create the initial configuration of the OpenVPN instance:

- ◆ Client configuration for an ethernet bridge VPN
- ◆ Client configuration for a routed multi-client VPN
- ◆ Simple client configuration for a routed point-to-point VPN
- ◆ Server configuration for an ethernet bridge VPN
- ◆ Server configuration for a routed multi-client VPN
- ◆ Simple server configuration for a routed point-to-point VPN

**Note:** *This document does not cover OpenVPN client/server configuration. Please consult your administrator for configuration details of your VPN or refer to the [OpenVPN online documentation](#) for information on how to configure the VPN.*

### Edit the template-based configuration

After you add the template-based instance, you can edit the instance to configure the appropriate fields and values for the particular VPN connection.

Note the following about editing the template-based instances:

- ◆ Click the **Switch to advanced configuration** or **Switch to basic configuration** links at the top of the form to switch the view between basic and advanced configuration.
- ◆ Select **Additional Field** at the bottom of the form to select additional configuration fields to add to the form.
- ◆ Select **Client** to enable client mode, or leave it blank to enable server mode.
- ◆ You should add your CA, certificates, and keys for the instance.
- ◆ Click **Save & Apply** when you are finished.

## OpenVPN Configuration File

If you use an OVPN configuration file to configure the OpenVPN instance, the configuration file should contain settings for either a server configuration or a client configuration with **.ovpn** as the file extension.

**Note:** *This document does not cover how to create OpenVPN configuration files. Please refer to the [OpenVPN online documentation](#) for sample server and client configuration files and information on how to create configuration files.*

### Edit the OVPN Configuration File

After you upload the configuration file, you can use the OpenVPN configuration editor on the web interface to modify the configuration. The editor window contains two sections: one to modify the OVPN configuration file and one to add a user and password authentication file with your credentials.

Click **Save** to save changes to the configuration file and close the editor.

## 10: Services

The G520 series gateways are equipped with services that complement the routing features. These services include:

- ◆ *Agents*
- ◆ *DLMS Client*
- ◆ *DOTA*
- ◆ *Dynamic DNS*
- ◆ *EtherCAT*
- ◆ *Events*
- ◆ *External Filesystems*
- ◆ *GPS*
- ◆ *IEC 101 to 104*
- ◆ *Keepalived*
- ◆ *Last Gasp*
- ◆ *Logs Information*
- ◆ *Modbus Master*
- ◆ *Modbus RTU to DNP3*
- ◆ *Page Selector*
- ◆ *Reporting Agent*
- ◆ *Service Actions*
- ◆ *SMS*
- ◆ *SNMPD*
- ◆ *SNMPTRAPD*
- ◆ *uHTTPd*

### Industrial Protocols

The G520 series gateways support a number of industrial protocols used in process automation systems and other automation purposes.

The gateways support the following industrial protocols:

- ◆ DLMS client
- ◆ DNP3 Outstation (client)
- ◆ EtherCAT
- ◆ IEC-101 master and IEC-104 slave
- ◆ Modbus Master

Refer to the index at the start of this chapter for links to the industrial protocol services.

### Protocol Conversion

The gateways support the following protocol conversion:

- ◆ Modbus RTU to Modbus TCP
- ◆ Modbus RTU to DNP3
- ◆ IEC-101 to IEC-104

### Data Send Applications

The gateways support the following data send applications:

- ◆ Modbus Master to HTTP



- ◆ Modbus Master to FTP
- ◆ Modbus Master to Cumulocity
- ◆ Modbus Master to MQTT
- ◆ Modbus Master to Azure
- ◆ DLMS to FTP

Configure the Modbus data send applications at <https://modbus.d2sphere.com>.

## Agents

### Services > Agents

Agents are customized applications loaded on the gateway that communicate with a specific device or data management platform.

By default, the Lantronix Wireless Automation Server (MWAS) agent is loaded on the gateway, which facilitates bi-directional data communication between devices/PLCs (Programmable Logic Controllers) connected to the gateway and a centralized server through a Kalkitech-compatible server.

[Device/SCADA <=> Kalkitech(server)] <=> [MWAS(agent) <=> Device/PLC]

**Table 10-1 Agent Configurations**

Parameters	Description
<b>Agents</b>	Select the agent from the list: ◆ MWAS – Lantronix Wireless Acquisition System
<b>Enable</b>	Click to enable the selected agent.
<b>LAN IP/URL</b>	Enter the IP address of the field device (PLC).
<b>LAN PORT</b>	Enter the port number of the field device (PLC).
<b>WAN IP/URL</b>	Enter the IP address of the WAN server.
<b>WAN PORT</b>	Enter the port number of the WAN server.
<b>Enable WAN Backup IP</b>	Click to enable the backup server. If enabled, enter the following: ◆ Backup WAN IP/URL – Enter the IP address of backup WAN server. ◆ Backup WAN Port – Enter the port number of backup WAN server.

## DLMS Client

### Services > DLMS Client

The G520 series gateway acts as a DLMS client that communicates with the DLMS meter. The DLMS client is the master and the smart meter is the slave device. The DLMS client has the following functionality:

- ◆ DLMS client queries information from DLMS meter. The queried information includes instantaneous, load, billing, and event profile data. The data collected is based on the COSEM specification and the device capability of the meter.
- ◆ DLMS client stores queried information in a file in CSV format.

- ◆ DLMS client sends the CSV file to FTP.
- ◆ DLMS is available on both RS-232 and RS-485 serial interfaces.

To configure the DLMS client:

1. Go to Services > DLMS Client.
2. Click **Enable** to enable the DLMS client on the gateway.
3. Under DLMS Configuration, enter the configuration information. See [Table 10-2](#).

**Table 10-2 DLMS Client Configuration**

Parameters	Description
<b>Enable</b>	Click to enable the DLMS client.
<b>DLMS meter make</b>	Secure Meters option is selected. The Secure meter default password is used by the back end. The option Others may be available. If selected, enter the meter password.
<b>Client address</b>	Enter the DLMS client address. The length is 8 bits.
<b>Server address</b>	Enter the DLMS server address.
<b>Instantaneous profile read time</b>	Enter the time interval in minutes that the instantaneous profile data will be read
<b>Billing profile read time</b>	Enter the time interval in minutes that the billing profile data will be read.
<b>Load profile recording period 1 read time</b>	Enter the time interval in minutes that the load profile for recording period 1 will be read.
<b>Duration for load profile recording period 1</b>	Select the duration in months of the load profile recording period.
<b>Load profile recording period 2 read time</b>	Enter the time interval in minutes that the load profile for recording period 2 will be read.
<b>Event profile read time</b>	Enter the time interval in minutes that the event profile data will be read.

4. Under Data Send Configuration, enter the FTP server settings to where the client will send the information. See [Table 10-3](#).

**Table 10-3 DLMS Data Send Configuration**

Parameters	Description
<b>Protocol</b>	FTP
<b>IP/URL</b>	IP address or URL of the FTP server
<b>Port</b>	21
<b>Username</b>	Username of the FTP server
<b>Password</b>	Password of the FTP server
<b>Path</b>	File path of the FTP server where the CSV file will be saved
<b>File name</b>	File name of the CSV file

5. Click **Save & Apply**.
6. Configure the Serial 1 (RS-232) or Serial 2 (RS-485) line mode to DLMS client. Click **Save &**

Apply.

## DOTA

DOTA (download over the air) allows you to remotely update the gateway's firmware using the Lantronix server or your custom server.

### Lantronix Server

*Services > Dota > Lantronix Server*

This page allows you to update the gateway's firmware using the Lantronix DOTA server.

To upgrade the firmware:

1. Go to *Services > DOTA > Lantronix Server*.
2. Select the channel and click **Check for update** to find available updates. See [Table 10-4](#).

The results of the update check are displayed in the area below the action bar. If an update is available, the firmware file is displayed under Available Firmwares.

3. To update the device, select the firmware file under Available Firmwares and click **Update now**.

Do not power off the device during the update. After the firmware is updated, the device will reboot.

**Table 10-4 DOTA using Lantronix Server**

Parameters	Description
<b>Channel</b>	Select the channel on which to look for the firmware update files. The options are Development, Beta, and Released. The default channel option is Released.
<b>Check for update</b>	Click to check for available updates.
<b>Available Firmware</b>	Displays a list of firmware that is available on the server. Select the firmware from this list and click <b>Update now</b> to upgrade or downgrade the firmware.
<b>Force Upgrade</b>	Check this box for forceful upgrade or downgrade of the firmware version.
<b>Update now</b>	Click <b>Update now</b> to download the firmware selected in the Available Firmware list.

### Custom Server

*Services > Dota > Custom Server*

This page allows you to update the gateway's firmware using a custom DOTA server.

To update firmware using a custom server:

1. Go to *Services > DOTA > Custom Server*.
2. Enter the server details. See [Table 10-5](#).
3. Click **Update now**.

Table 10-5 DOTA Custom Server Configuration

Parameters	Description
<b>Update now</b>	After setting the Custom Server parameters, click <b>Update now</b> to download the firmware pointed to by the URL and the filename below.
<b>Custom Server Settings</b>	
<i>Note: If the custom server is not configured, DOTA service will configure the Lantronix server.</i>	
<b>Protocol</b>	Select HTTP or HTTPS as the protocol of the custom server. Enter the configuration depending on the protocol you selected.
<b>URL/IP</b>	Enter the URL or the IP address of the custom DOTA server. The URL, if provided, must include http or https.
<b>Filename</b>	Enter the firmware file name to be accessed for the update.
<b>Username</b>	This field is displayed if the selected protocol was HTTP. Enter the server login username.
<b>Password</b>	This field is displayed if the selected protocol was HTTP. Enter the server login password.
<b>Cert-type</b>	This field is displayed if the selected protocol was HTTPS. Choose the type of certificate file. The options are PEM, DER, or ENG.
<b>Cert</b>	This field is displayed if the selected protocol was HTTPS. Click the <b>Select file...</b> button to browse to the SSL certificate file to be uploaded.
<b>Key</b>	This field is displayed if the selected protocol was HTTPS. Click the <b>Select file...</b> button to browse to the key file to be uploaded.
<b>Timeout in Minutes</b>	Enter the period of time to wait for the download to complete. The download process will be aborted after the timeout period expires. The default value is 10 minutes.
<b>Retries</b>	Enter the number of retry attempts allowed to check and download the latest firmware file from the server. The default number of retries is 3.

**Note:** DOTA update can also be triggered using SMS by sending the SMS AT+DOTA command after setting the custom server configuration from the Web UI (shown above) or by sending the AT+DOTASETTINGS command using SMS from a registered mobile number. For command syntax, see [Table 10-26 SMS AT Command Syntax](#).

## Dynamic DNS

### Services > Dynamic DNS

Dynamic Domain Name System (Dynamic DNS or DDNS) offers a method of keeping a static domain/host name linked to a dynamically assigned public IP address allowing your server to be more easily accessible from various locations on the Internet.

The DDNS page lets you configure your DDNS service so that the gateway automatically updates its public IP to your DDNS provider. Before starting this configuration, you should already have registered a DNS name with a compatible DDNS service provider. For a list of compatible DDNS providers, visit: <https://openwrt.org/docs/guide-user/services/ddns/client>.

To add a DDNS configuration:

1. Go to Services > Dynamic DNS.
2. At the bottom of the Overview section, type the DDNS configuration name and click **Add**.

To edit a DDNS configuration:

1. Go to Services > Dynamic DNS.
2. In the Overview section, select the DDNS configuration that you want to edit and click **Edit**.
3. Edit the configuration settings. See [Table 10-6](#).
4. Click **Save & Apply**.

Table 10-6 Dynamic DNS Client Configuration

Parameters	Description
<b>Basic Settings</b>	
<b>Enabled</b>	Select to enable Dynamic DNS. Clear to disable Dynamic DNS. Dynamic DNS allows the gateway to be reached with a fixed hostname while having a dynamically changing IP Address.
<b>Lookup Hostname</b>	Name to identify the host that you want to use on DDNS server. This is the domain name that you registered with your DDNS service provider. The hostname is received from the dynamic DNS service provider.
<b>IP address version</b>	Select the IP address version – IPv4 or IPv6.
<b>DDNS Service Provider [IPv4/IPv6]</b>	Select the DDNS service provider from the drop down list.
<b>Domain</b>	The domain that you want to update. Usually the same as the lookup hostname.
<b>Username</b>	Username of DDNS account. The username is received from the DDNS service provider.
<b>Password</b>	Password of DDNS account. The password is received from DDNS service provider.
<b>Use HTTP Secure</b>	Select to use HTTPS with the DDNS provider. Otherwise, leave it unchecked.

Parameters	Description
<b>Path to CA-certificate</b>	This field is visible if HTTPS is selected. Enter the directory or file path of the ssl certs. To run HTTPS without verification of server certificates (insecure), enter IGNORE.
<b>Advanced Settings</b>	
<b>IP address source [IPv4/IPv6]</b>	Select the IP Address source: Network, Interface, URL, or Script and enter the appropriate configuration details.  Network <ul style="list-style-type: none"> <li>◆ Network (IPv4) – Select the software interface to read systems IPv4 address from.</li> </ul> Interface <ul style="list-style-type: none"> <li>◆ Interface – Select the physical network interface from the options</li> </ul> URL <ul style="list-style-type: none"> <li>◆ URL to detect – Enter the URL to read systems IP address from. The source IP Address by default is URL.</li> <li>◆ Event Network (IPv4) – network on which the ddns-updater scripts will be run</li> <li>◆ Bind Network – leave as “default” or select the network to use for communication. Note that casual users should not change this setting.</li> </ul> Script <ul style="list-style-type: none"> <li>◆ Script – Enter the script path and file name.</li> <li>◆ Event Network (IPv4) – network on which the ddns-updater scripts will be run</li> </ul>
<b>Force IP Version</b>	Select if you want to force the usage of either IPv4 or IPv6 only. This field is optional.
<b>DNS-Server</b>	Enter DNS server domain name or IP address if you want to override the default DNS server to detect the registered IP. Enter IP address or FQDN.
<b>PROXY-Server</b>	Enter the proxy server to use for detection and updates. Format: [user:password@]proxyhost:port IPv6 address must be given in square brackets: [2001:db8::1]:8080
<b>Log to syslog</b>	Select log level to write log messages to syslog. Critical errors are always logged to syslog. Available options include No logging, Info, Notice, Warning, Error. The default setting is Notice.
<b>Log to file</b>	Select to allow the detailed messages to be written to log files. Log files store up to 250 lines and then are automatically truncated.
<b>Timer Settings</b>	
<b>Check Interval</b>	Specify the time interval to check if the local IP has changed. Values less than 5 minutes (300 seconds) are not supported. Default is 10 minutes.

Parameters	Description
<b>Force Interval</b>	Specify the time interval after which the DDNS server should force update the IP address of your server even if no IP change was detected. The force interval should be greater than the check interval. Enter 0 to force the script to only run once. Default is 72 hours.
<b>Error Retry Counter</b>	The number of retries to attempt before the script stops execution. Default setting is 0 which indicates infinite retries.
<b>Error Retry Interval</b>	If an error occurs on detecting, sending or updating, the script will retry the relevant action according to the specified time interval. Default is 60 seconds.
<b>Log File Viewer</b>	
<b>Read/Reread log file</b>	Click to display the DDNS log file.

## EtherCAT

### Services > EtherCAT

The G520 series gateway can act as an EtherCAT master for bidirectional communication with an EtherCAT slave device.

The EtherCAT application is not included with the default firmware. To use it, it should be created as a custom package (.ipk) using the SDK. The package can be included in a custom firmware image build or installed as a software package. For details on how to create a custom package using the SDK, please refer to the [G520 Series SDK Application Note](#).

**Note:** *EtherCAT protocol and master application will run on the Ethernet WAN interface.*

On the EtherCAT page:

1. Under Status, view the status of the EtherCAT master application.
2. Under Configuration, select the checkbox next to Enable to enable EtherCAT master application, or clear it to disable EtherCAT.
3. Click **Save & Apply**.

## Events

### Services > Events

G520 series gateways are equipped with two digital inputs/outputs (I/O). Digital inputs range from 3V to 24V and the same input pins are also available to be used as open collector digital output with maximum 200mA @ 24V.

The Event Management page allows you to map actions to events respective to the digital I/Os.

To add an event:

1. Go to Services > Events.

2. Enter the event parameters (see [Table 10-7](#)).
3. Click **Add**.
4. Click **Save & Apply**.

**Table 10-7 Events Configuration**

Parameters	Description
<b>Enable</b>	Click to enable the events
<b>Event</b>	<p>Select the event from the options.</p> <p>DIO by default are pulled up to high voltage level.</p> <ul style="list-style-type: none"> <li>◆ Digital Input #1 is grounded</li> <li>◆ Digital Input #2 is grounded</li> <li>◆ Digital Input #1 has voltage</li> <li>◆ Digital Input #2 has voltage</li> </ul>
<b>Action</b>	<p>Select the action from the options.</p> <ul style="list-style-type: none"> <li>◆ Close digital Output # 1/2 – to close the digital pin</li> <li>◆ Open digital Output # 1/2 – to open the digital pin</li> <li>◆ Start VPN – to start VPN</li> <li>◆ Stop VPN – to stop VPN</li> <li>◆ SMS – to send the event details using the SMS</li> <li>◆ Switch Digital Output – to change the state of digital output</li> <li>◆ Reboot – to reboot the gateway. Use this option with caution. It may cause continuous reboot if the DI events are not properly configured.</li> </ul>
<b>Mobile Number / VPN Type</b>	<p>Enter the mobile number if the selected action was SMS.</p> <p>Enter the VPN type if the selected action was Start VPN or Stop VPN.</p> <ul style="list-style-type: none"> <li>◆ Mobile number – The mobile number format must be: &lt;countrycode&gt;&lt;phonenumber&gt;.</li> <li>◆ VPN type – enter the type of the VPN such as ipsec, pptp, l2tp, or openvpn.</li> </ul>
<b>Text / VPN Name</b>	<p>Enter the text message that will be sent to the configured mobile number in case the event occurs.</p> <p>Enter the VPN instance name to start or stop the VPN in case the event occurs.</p>



## External Filesystems

### Services > External Filesystems

The G520 series gateway supports an SD(HC)/MMC card or external USB flash drive for external file storage. This page configures the mount settings for the external filesystem.

To configure the external filesystem:

1. Insert the SD card in the SD card slot or the USB flash drive in the USB slot on the gateway.
2. Go to Services > External Filesystems.
3. Configure the external device settings. See [Table 10-8](#).
4. Click **Save & Apply**.

**Table 10-8 External Filesystems Configuration**

Parameters	Description
<b>External device</b>	Select the external device.
<b>Mount point</b>	Enter the mount point directory to the file system, relative to the top level directory. Example: /tmp/usbdevice
<b>Auto mount</b>	Select to mount the device automatically when the gateway boots. If unselected, the device must be mounted manually.
<b>Options</b>	Enter the Linux mount options to be run when the device is mounted. Separate each of the options with a comma. Default mount option: rw, sync

## GPS

### Services > GPS

The built-in GPS receiver receives GPS data from GPS satellites for synchronizing the GPS time and position data.

#### Enable GPS

To enable GPS receiver:

1. Go to Services > GPS.
2. Select GPS Enable.
3. Click **Save & Apply**.

The data will be displayed on the page (see [Table 10-9](#)). It may take some time (about a minute) to receive and display the data.

#### Send GPS Data to an External Server

The GPS data can be sent in NMEA data format to an external TCP server on a real-time basis. You can also configure the GPS data to be sent to a backup server.

To send the GPS data to an external server:

1. Go to Services > GPS.
2. Select **Enable Data Send** and enter the server settings (see [Table 10-9](#)).
3. Click **Save & Apply**.

**Table 10-9 GPS Service Configuration**

Parameters	Description
<b>GPS Parameters</b>	
<b>GPS Enable</b>	Select GPS Enable check box to display current GPS data.
<b>Time (GMT)</b>	Time in hh:mm:ss
<b>Latitude (degree.mmsss)</b>	Latitude in ddmm.mmmm
<b>N/S-Indicator</b>	N = North or S = South
<b>Longitude (degree.mmsss)</b>	Longitude in ddmm.mmmm
<b>E/W-Indicator</b>	E = East or W=West
<b>Position-Fix-Indicator</b>	Indicates the type of signal or technique used by the GPS receiver to determine its location. <ul style="list-style-type: none"> <li>◆ <b>0</b> – Fix not available or invalid</li> <li>◆ <b>1</b> – GPS SPS Mode, fix valid</li> <li>◆ <b>2</b> – Differential GPS, SPS Mode, fix valid</li> <li>◆ <b>3 to 5</b> – Not supported</li> <li>◆ <b>6</b> – Dead Reckoning Mode, fix valid</li> </ul>
<b>Number of Satellites Used</b>	Number of satellites used to receive GPS signals. The range for the number of satellite used is 0 to 12.
<b>HDOP</b>	Horizontal Dilution of Precision (HDOP) indicates the relative accuracy of the horizontal position
<b>Altitude (in meters)</b>	Altitude above mean sea level

Parameters	Description
<b>Status</b>	Displays the status. A = Data valid V = Data not valid
<b>Speed</b>	Speed over ground in knots
<b>Course of Ground</b>	Track, or intended direction of travel
<b>Protocol</b>	
<b>Enable Data Send</b>	Select <b>Enable Data Send</b> check box to send data to the selected server. It sends the GPS information in NMEA format.
<b>Protocol</b>	Select the TCP protocol only.
<b>IP1/URL1</b>	Enter the primary IP address.
<b>Port1</b>	Enter the port number.
<b>Backup</b>	Click to use a backup server, in case sending the data fails using primary IP address. ◆ IP2/URL2 – Enter the backup IP address. ◆ Port2 – Enter the backup port number.
<b>Polling Interval (in seconds)</b>	The period of time between the end of the timeout period or the completion of the network request and the next request for data on the network.
<b>Send Interval (in seconds)</b>	The period of time to wait between attempts to send GPS data using the primary IP address or backup IP.

## Description of NMEA Messages

The G520 series device receives NMEA sentences every second, depending on the configuration. The identifiers for the NMEA messages are listed below. All messages are based on the NMEA standard messages.

<b>GPGGA</b>	GPS Fix Data
<b>GPRMC</b>	Recommended Minimum Specific GPS Data
<b>GPGSV</b>	GPS Satellites in View
<b>GPGSA</b>	GPS DOP and Active Satellites
<b>GPVTG</b>	Course Over Ground and Ground Speed

A full description and definition of the listed messages above is provided in the next sections.

## GP GGA Format

The \$GP GGA message includes time, position, GPS quality and number of satellites in use.

Example: \$GP GGA,120133.0,1907.469671,N,07250.544473,E,1,05,1.0,43.1,M,-64.0,M,,\*42

**Table 10-10 GGA Data Format**

Parameters	Description
<b>MID GGA Parameters</b>	
<b>MID</b>	GGA Protocol Header Example – \$GP GGA
<b>UTC Time</b>	Time in hhmm.ss Example – 120133.0
<b>Latitude</b>	Latitude in ddmm.mmmm Example – 1907.469671
<b>N/S-Indicator</b>	N = North or S = South Example – N
<b>Longitude</b>	Longitude in ddmm.mmmm Example – 07250.544473
<b>E/W-Indicator</b>	E = East or W = West Example – E
<b>Position-Fix-Indicator</b>	Indicates <ul style="list-style-type: none"> <li>◆ 0 – Fix not available or invalid</li> <li>◆ 1 – GPS SPS Mode, fix valid</li> <li>◆ 2 – Differential GPS, SPS Mode, fix valid</li> <li>◆ 3 to 5 – Not supported</li> <li>◆ 6 – Dead Reckoning Mode, fix valid</li> </ul> Example – 1
<b>Satellite-Used</b>	Number of satellite used to receive GPS signals. The range for the number of satellite used is 0 to 12. Example – 05
<b>HDOP</b>	Horizontal Dilution of Precision Example – 1.0
<b>MSL Altitude</b>	Altitude in meters. Example – 43.1 meters
<b>Units</b>	Example – M meters
<b>Geoid Separation</b>	Geoid-to-ellipsoid separation. Ellipsoid altitude = MSL Altitude + Geoid Separation Example: -64.0 meters
<b>Units</b>	Example: M meters
<b>Age of Diff.Corr.</b>	Null fields when DGPS is not used. <sup>4</sup> The units is sec.
<b>Diff. Ref.Station ID</b>	–
<b>Checksum</b>	*42
<b>&lt;CR&gt;&lt;LF&gt;</b>	End of message termination

## GPRMC Format

The \$GPRMC message includes time, date, position, course, and speed data.

Example: \$GPRMC,120133.0,A,1907.469671,N,07250.544473,E,0.0,0.0,150915,0.3,W,A\*1E

**Table 10-11 RMC Data Format**

Parameters	Description
<b>MID RMC Parameters</b>	
<b>MID</b>	RMC Protocol Header Example – \$GPRMC
<b>UTC Time</b>	Time in hhmmss.sss Example – 120133.0
<b>Status<sup>(1)</sup></b>	A = Data valid V = Data not valid Example – A
<b>Latitude</b>	Time in ddm.mmmm Example – 1907.469671
<b>N/S-Indicator</b>	N = North or S = South Example – N
<b>Longitude</b>	Longitude in ddm.mmmm Example – 07250.544473
<b>E/W-Indicator</b>	E = East or W = West Example – E
<b>Speed Over Ground</b>	Measured in knots. Example – 0.0
<b>Course Over Ground</b>	True. Measured in degrees Example – 0.0
<b>Date</b>	Date in ddmmyy Example – 150915
<b>Magnetic Variation<sup>(2)</sup></b>	E = East or W = West Measured in degrees Example – 0.3
<b>East/West Indicator<sup>(2)</sup></b>	W = West Example – W
<b>Mode</b>	Indicates <ul style="list-style-type: none"> <li>◆ A – Autonomous</li> <li>◆ D – DGPS</li> <li>◆ E – DR</li> <li>◆ N – Output Data Not Valid</li> <li>◆ R – Course Position<sup>(3) (4) (5)</sup></li> <li>◆ S – Simulator</li> </ul> Example – A
<b>Checksum</b>	*1E

Parameters	Description
<CR><LF>	End of message termination

(1) A valid status is derived from all the parameters set in the software. This includes the minimum number of satellites required, any DOP mask setting, presence of DGPS corrections, etc. If the default or current software setting requires that a factor is met, and then if that factor is not met the solution will be marked as invalid.

(2) CSR Technology Inc. does not support magnetic declination. All courses over ground data are geodetic WGS84 directions relative to true North.

(3) Position was calculated based on one or more of the SVs having their states derived from almanac parameters, as opposed to ephemerides.

(4) This feature is supported in the GSD4e product only.

(5) This feature is supported in the GSD4e product, version 1.1.0 and later.

### GPGSV Format

The \$**GPGSV** includes the number of satellites in view, satellite ID numbers and their evaluation, azimuth and signal-to-noise ratio.

Example: \$GPGSV,4,1,16,21,50,358,38,22,28,272,37,29,53,164,36,18,51,319,31,\*71E

IMEI number is added at the start of every frame.

**Table 10-12 GPGSV Data Format**

Parameters	Description
<b>MID GSV Parameters</b>	
<b>MID</b>	GSV Protocol Header Example – \$GPGSV
<b>Number of Messages<sup>(1)</sup></b>	Total number of GSV messages to be sent in this group Example – 4
<b>Message Number<sup>(1)</sup></b>	Message number in this group of GSV messages Example – 1
<b>Satellites in View<sup>(1)</sup></b>	16
<b>Satellite ID</b>	Channel (Range 1 – 32) Example – 21
<b>Elevation</b>	Channel 1 (Maximum 90) Example – 50 degrees
<b>Azimuth</b>	Channel (True, Range 0 – 359) Example – 358 degrees
<b>SNR (C/N0)</b>	Range 0 – 99, null when not tracking Example – 38dBHz
....	(Satellite ID, elevation, azimuth, and SNR repeated for each satellite in view)
<b>Satellite ID</b>	Channel 4 (Range 1 – 32) Example – 18

Parameters	Description
<b>Elevation</b>	Channel 4 (Maximum 90) Example – 51 degrees
<b>Azimuth</b>	Channel 4 (True, Range 0 - 359) Example – 319 degrees
<b>SNR (C/N0)</b>	Range 0 – 99, null when not tracking Example – 31 dBHz
<b>Checksum</b>	*71
<b>&lt;CR&gt;&lt;LF&gt;</b>	End of message termination

<sup>(1)</sup>Depending on the number of satellites tracked, multiple messages of GSV data may be required. In some software versions, the maximum number of satellites reported as visible is limited to 12, even though more may be visible.

### GPGSA Format

The \$GPGSA message includes the list of satellites being used.

Example: \$GPGSA,A,3,18,20,21,22,29,,,,,,,,,2.4,1.0,2.2\*36

**Table 10-13 GSA Data Format**

Parameters	Description
<b>MID GSA Parameters</b>	
<b>MID</b>	GSA Protocol Header Example – \$GPGSA
<b>Mode1</b>	<b>M – Manual:</b> Forced to operate in 2D or 3D mode <b>A – 2D Automatic:</b> Allowed to automatically switch 2D/3D  Example – A
<b>Mode2</b>	1 – Fix not available 2 – 2D (<4 SVs used) 3 – 3D (>3 SVs used) Example – 3
<b>Satellite Used<sup>(1)</sup></b>	SV on Channel 1 Example – 18
<b>Satellite Used<sup>(1)</sup></b>	SV on Channel 2 Example – 20
....	....
<b>Satellite Used</b>	SV on Channel 12
<b>PDOP<sup>(2)</sup></b>	Position Dilution of Precision Example: 2.4
<b>HDOP<sup>(2)</sup></b>	Horizontal Dilution of Precision Example: 1.0
<b>VDOP<sup>(2)</sup></b>	Vertical Dilution of Precision Example: 2.2

Parameters	Description
Checksum	*33
<CR><LF>	End of message termination

(1) Satellite used in solution.

(2) Maximum DOP value reported is 50. When 50 is reported, the actual DOP may be much larger.

## GPVTG Format

The \$GPVTG message includes course over ground and ground speed.

Example: \$GPVTG,0.0,T,0.3,M,0.0,N,0.0,K,A\*20

Table 10-14 VTG Data Format

Parameters	Description
<b>MID VTG Parameters</b>	
<b>MID</b>	VTG Protocol Header Example – \$GPVTG
<b>Course</b>	Measured heading Example – 0.0 degrees
<b>Reference</b>	True Example – T
<b>Course</b>	Measured heading Example – 0.3 degrees
<b>Reference</b>	Magnetic <sup>(1)</sup> Example – M
<b>Speed</b>	Measured horizontal speed Example – 0.0 knots
<b>Units</b>	Knots Example – N
<b>Speed</b>	Measured horizontal speed Example – 0.0 km/hr
<b>Units</b>	Kilometers per hour Example – K
<b>Mode</b>	Indicates <ul style="list-style-type: none"> <li>◆ A – Autonomous</li> <li>◆ D – DGPS</li> <li>◆ E – DR</li> <li>◆ N – Output Data Not Valid</li> <li>◆ R – Course Position<sup>(2) (3) (4)</sup></li> <li>◆ S – Simulator</li> </ul> Example – A
<b>Checksum</b>	*20



Parameters	Description
<CR><LF>	End of message termination

(1) CSR does not support magnetic declination. All “course over ground” data are geodetic WGS84 directions.

(2) Position was calculated based on one or more of the SVs having their states derived from almanac parameters, as opposed to ephemerides.

(3) This feature is supported in the GSD4e product only.

(4) This feature is supported in the GSD4e product, version 1.1.0 and later.

## IEC 101 to 104

### Services > IEC 101 to 104

The G520 series gateway supports IEC 60870-5-101 (short IEC-101) and IEC 60870-5-104 (short IEC-104) protocols. It supports protocol conversion from IEC-101 to IEC-104. IEC-101 master is available on both the RS232 and RS485 interfaces.

To use this feature, configure the IEC 101 to 104 settings and also the serial interface (RS232 or RS485).

To configure IEC-101 to 104:

1. Go to Services > IEC 101 to 104.
2. Select **Enable** to enable the IEC 101 to 104 service.
3. Under IEC 101 Slave Configuration, enter the information for the IEC-101 slave device. See [Table 10-15](#).

**Table 10-15 IEC-101 Slave Configuration**

Parameters	Description
<b>ASDU Address</b>	Enter the ASDU address. The Application Service Data Unit (ASDU) is the data structure that holds application layer information to exchange between a control center and a remote terminal unit. If Unbalanced mode is selected, enter addresses separated by a comma.
<b>Link Address</b>	Enter the address of the end device. If Unbalanced mode (polling is used) is selected, enter addresses separated by a comma. All connected devices on the line receive the telegram and the addressed device responds using its own address as the link address.
<b>ASDU Address size</b>	Enter the address size as one or two octets (bytes)
<b>COT size</b>	Enter the Cause of Transmission (COT) size as one or two octets.
<b>IOA address size</b>	Enter the Information object address (IOA) size as one, two or three octets.
<b>Link Address size</b>	Enter the link address size as one or two octets or not present.

Parameters	Description
<b>Link Transmission Procedure</b>	Defines the control information for IEC-101. Select one of the following options: <ul style="list-style-type: none"> <li>◆ Balanced mode for point-to-point operation</li> <li>◆ Unbalanced mode for polling operations to multiple targets</li> </ul>

4. Under IEC 104 Master Configuration, enter the information for the IEC-104 master (control center). See [Table 10-16](#).

**Table 10-16 IEC-104 Master Configuration**

Parameters	Description
<b>ASDU Address</b>	Enter the ASDU address.
<b>COT size</b>	Enter the COT size as one or two octets.
<b>Time out T1</b>	Enter the timeout for T1 in milliseconds
<b>Time out T2</b>	Enter the timeout for T2 in milliseconds
<b>Time out T3</b>	Enter the timeout for T3 in milliseconds
<b>Type</b>	Select the interface that the IEC-104 master listens on. Internal – listens on LAN. Select IP and enter port. External – listens on WAN/WiFi/Cellular with automatic fallback
<b>IP</b>	IP address of the IEC-104 master (control center). Select the LAN IP address of the gateway or enter a custom IP address.
<b>Port</b>	Enter the TCP port number of the IEC-104 master device. The default IEC-104 TCP port is 2404.

5. Click **Save & Apply**.

To configure the serial interface:

1. Go to Serial > Serial 1 (RS232) or Serial 2 (RS485).
2. Configure the serial communication settings to match the serial configuration of the IEC-101 slave.
3. Select the mode as IEC 101 to 104.
4. Click **Save & Apply**.

---

## Keepalived

### Services > Keepalived

The Keepalived service provides frameworks for load balancing and high availability of the servers connected to the gateway. Keepalived uses Virtual Router Redundancy Protocol (VRRP) to check the health of load balanced routers and elect a router on the network that will serve a particular IP.

In a typical configuration, VRRP groups two or more routers into a virtual router, where one router is the master (active) server and the other is the backup node. The master server has a higher priority than the backup server. The master server transmits multicast VRRP advertisement packets at regular intervals, and the backup servers listen for these advertisement packets. If the backup servers fail to receive three consecutive VRRP advertisements, the backup router with the highest priority becomes the new master router so that the system remains functional.

The configuration for the backup server will be similar to that of the master server, with the exception of the values for priority, state, and interface, depending on the system hardware configuration.

### Keepalived Configuration

The Keepalived configuration on the web interface includes the following sections:

- ◆ **General** – Keepalived log settings
- ◆ **Global** – Keepalived global settings
- ◆ **Tracking Scripts** – create tracking script blocks that Keepalived will run to determine the health of the host and increase or decrease the priority of the router by the value of the weight.
- ◆ **Tracking Interfaces** – configure which interfaces Keepalived will monitor. If a monitored interface fails, Keepalived will adjust the priority of the host according to the configured weight of the tracking interface.
- ◆ **Tracking Processes** – create tracking process blocks that Keepalived can use to monitor the health of the router. If the monitored process stops running, Keepalived will adjust the priority of the host according to the weight of the tracking process. After adding a process, you must restart the Keepalived service.
- ◆ **Virtual IP** – configure the Virtual IP address for the VRRP instance.
- ◆ **VRRP Instances** – add VRRP instances to be run on interfaces that Keepalived is monitoring. The VRRP instance is defined in the General and Advanced settings. The User Notify settings allow Keepalived to run specified scripts when the router transitions between backup and master states.

To configure Keepalived settings:

1. Go to Services > Keepalived.
2. Edit the configuration settings. See [Table 10-17](#).
3. Click **Save & Apply** when you are finished.

Table 10-17 Keepalived Configuration

Parameters	Description
<b>General</b>	
<b>Detailed Log</b>	Select to enable detailed keepalived general/common logs.
<b>Syslog level</b>	Set the log level from 0-4, with 4 being the most detailed.
<b>Keepalived Global</b>	
<b>Vrrp startup delay</b>	Enter the time in seconds to delay before starting VRRP.
<b>Global Router Id/name</b>	Enter the global router ID/name. A default name is provided, but you can modify it if you want. It doesn't have to be the hostname, but it must be unique for each device in a pool.
<b>Keepalived config file</b>	Select the Keepalived configuration file. Settings in the configuration file will supersede settings configured on the Keepalived UI pages except for all scripts loaded in Tracking Scripts, and the User Notify settings in VRRP Instances. The name of the script should match the ones in the configuration file settings.
<b>Remove configuration for Keepalived</b>	Unlink the uploaded keepalived configuration so as to fill the configurations manually.
<b>User</b>	The user for script execution.
<b>Enable Script Security</b>	Select to prevent running any scripts that were configured to be run as root if any part of the path is writable by a non-root user.
<b>Enable dynamic interfaces</b>	Select to enable dynamic interfaces. Once enabled, next to Dynamic interfaces, select Allow or None
<b>Tracking Scripts</b>	
<b>Name of trackscript block</b>	Enter the tracking script block name.
<b>Script</b>	Select the tracking script file to upload it to the router. The file is uploaded to the /usr/sbin/ folder. The script name should start with "keepalived_" and end with ".sh".
<b>Remove script</b>	Click to remove the tracking script.
<b>TrackScript interval</b>	Enter the time interval between script invocations in seconds. Default is 1 second
<b>Weight</b>	Enter the weight to adjust the priority if the tracking script fails. Range is -253 to 253. Positive value will increase the priority. Negative value will decrease the priority. Setting it to zero (0) will ignore the weight, which means that any VRRP instance monitoring the script will transition to the fault state after the fail count number of consecutive failures of the script. A script returning 0 (zero) is success and everything else is fail.
<b>TrackScript pass count</b>	Enter the required number of successes for OK transition.
<b>TrackScript fail count</b>	Enter the required number of fails for NOK transition.
<b>Tracking Interfaces</b>	
<b>Name of interface block</b>	Enter the name of the tracking interface block
<b>Interfaces</b>	Select the interface to monitor for changing the state of the router or decreasing the weight.

Parameters	Description
<b>Weight</b>	Enter the weight to adjust the priority if the interface is present or absent.  Range is -253 to 253. Positive value will increase the priority. Negative value will decrease the priority. Default is 0 (zero), which means that the router will fail in case of the interface not running.
<b>Tracking Processes</b>	
<b>Name of process block</b>	Enter the name of the process block.
<b>Process</b>	Enter the name of the process to monitor for running state.
<b>Weight</b>	Enter the weight to adjust the priority if the process is not running.  Range is -253 to 253. Positive value will increase the priority. Negative value will decrease the priority. Default is 0 (zero), which means that the router will fail in case of the interface not running.
<b>Virtual IP</b>	
<b>Name of address block</b>	Enter the name of the address block.
<b>Virtual ipaddress</b>	Enter the Virtual IP address and netmask that will be used by the virtual router.
<b>Physical device</b>	Select the device used for the virtual IP.
<b>Scope of the virtual ip</b>	Select the scope. Options include: <b>global</b> , site, link, host, nowhere.
<b>VRRP Instances</b>	
<b>VRRP Instances &gt; General Settings</b>	
<b>Enable</b>	Click to enable the VRRP instance.  The VRRP instance defines and configures VRRP behavior to run on a specific interface.
<b>Name of Instance</b>	Enter a name for the VRRP instance.
<b>Virtual Router ID</b>	Enter the router ID. This number should be the same for all routers on the virtual router.  Unique number from 1 to 155.
<b>Interface to look for</b>	Select the interface that needs to be monitored for switching.
<b>Virtual Router Priority</b>	Enter the priority. The router with the highest priority will be the master.
<b>Delay</b>	Enter the interval in seconds that VRRP will wait between sending advertisement packets.  Default is 1 second.
<b>Debug</b>	Enter the debug level, from 1 to 4.  Note: Debug level is not implemented yet by Keepalived.
<b>Initial Virtual Router State</b>	Select the initial virtual router state as MASTER or BACKUP.  This is for initial state only. As soon as the other routers in the virtual router group come up, an election will be held and the router with the highest priority will become MASTER.
<b>Enable Authentication</b>	Select to enable authentication. Authentication type can be PASS (suggested) or AH – IPsec (not recommended).  PASS is a simple text password. This should be the same value on all machines in the virtual router. Only the first eight (8) characters are used.  Note: Authentication was removed from the VRRPv2 specification, and use of the option is non-compliant and can cause problems.

Parameters	Description
<b>VRRP Instances &gt; Advanced Settings</b>	
<b>Virtual IPs</b>	Enter the Virtual IP block. The router will assume this IP when it becomes Master and release it when it changes to Backup. Add blocks configured in Virtual IP.
<b>Track Process</b>	Enter the track process block that the VRRP instance will monitor. Add blocks configured in Tracking Process.
<b>Track interface</b>	Enter the track interface block that the VRRP instance will monitor. Add blocks configured in Tracking Interfaces.
<b>Track Script</b>	Enter the tracking script block that the VRRP instance will monitor. Add blocks configured in Tracking Scripts.
<b>VRRP Instances &gt; User Notify Settings</b>	
<b>Notify master Script</b>	Select the notify master script which will be run when the router becomes Master.
<b>Remove master script</b>	Remove the notify master script.
<b>Notify backup Script</b>	Select the notify backup script which will be run when the router becomes Backup.
<b>Remove backup script</b>	Remove the notify backup script.

## Last Gasp

### Services > Last Gasp

Last gasp transmits a text message to a specified mobile phone number when the gateway loses power. To use this function, the last gasp switch must be in the ON position. The battery is charged while the device is connected to an external power input.

To configure last gasp:

1. Go to Services > Last Gasp.
2. Select **Enable**.
3. Enter the configuration settings (see [Table 10-18](#)).
4. Click **Save & Apply**.

**Table 10-18 Last Gasp Message Configuration**

Field	Description
Enable	Select to enable or clear to disable the last gasp message. It is disabled by default.
Mobile Number	Enter the mobile number with country code
Power restore text	Enter the message to send to the mobile number in case the power to the gateway is restored.
Power failure text	Enter the message to send to the mobile number in case the power is lost.

## Logs Information

### *Services > Logs Information*

Logs Information page lets you view the system log file and download them to the local computer. The current log file and up to 3 historical log files may be saved.

The logs configuration is read from the system logging. In order to display and download the log file, the system logging must be configured to write system log to file (see [System > System > Logging](#)).

To display or download logs:

1. Go to Services > Logs Information. The Logs page appears.
2. Select the log file. The file is displayed on the page.
3. Click **Download**. The log file is downloaded to the local computer.

## Modbus Master

### *Services > Modbus Master*

Modbus Master configures the gateway as a master device that connects to slave devices. It supports Modbus RTU through a serial line or Modbus TCP through a TCP/IP network.

Modbus RTU based serial slave devices can also be connected via the Ethernet through an existing Modbus TCP/IP network. Any device having access to a given Modbus implementation will be able to perform the full range of operations that the implementation supports.

The gateway can be configured to communicate through a tunnel using Modbus RTU to Modbus TCP conversion mode. For details, please see [Tunnel Modbus RTU to Modbus TCP](#).

### Serial Transmission Mode

The G520 series gateway can be configured to communicate on Modbus networks using RTU. [Table 10-19](#) shows the standard Modbus RTU packet data structure. Modbus RTU can use either the RS232 or the RS485 interface.

To use Modbus on the serial line, configure the Modbus master settings, the Serial port communication parameters, and the mode for the desired serial interface.

**Table 10-19 Modbus RTU Packet Data Structure**

Section	Description
Slave Address	8 bits (0 to 247 decimal, 0 is used for broadcast)
Function Code	8 bits (1 to 255, 0 is not valid)
Data	N X 8 bits (N=0 to 252 bytes)
CRC Check	16 bits

### Ethernet Transmission Mode

The G520 series gateway can be set up to communicate on Modbus networks using TCP/IP. [Table 10-20](#) shows the structure of the Modbus application protocol header. This header is added to the start of each Modbus message and the slave address and CRC are removed. Modbus TCP

uses a TCP port of 502 and includes a single byte function code (1=255) preceded by a 6 byte header:

To use Modbus using TCP/IP, configure the Modbus master settings on the gateway. Separately, configure the Modbus slave settings on the Modbus TCP device.

**Table 10-20 Modbus Application Protocol Byte Header**

Section	Size	Description
Transaction ID	2 bytes	Identification of request/response transaction – copied by slave
Protocol ID	2 bytes	0 – Modbus protocol
Length	2 bytes	Number of following bytes includes the unit identifier
Address	1 byte	Identification of remote slave

## Modbus Master Configuration

This page lets you do the following: configure the Modbus master settings, enable or disable the Modbus master, and view the status of active Modbus connections. When a connection is active, the remote client information is displayed as well as the number of protocol data units (PDUs) that have been sent and received.

The Modbus configuration settings are contained in a Modbus configuration file, which is a CSV formatted file that you can generate using the Modbus Configuration Utility at: <https://modbus.d2sphere.com>. The following configuration sections can be configured: the target server where the data will be reported, up to six (6) polling groups, up to five (5) upload groups, and Modbus logger details.

To configure Modbus master:

1. Go to Services > Modbus Master.
2. Click the Configuration tab.
3. Enter the configuration settings. See [Table 10-21](#).
4. Click **Save & Apply**.

**Table 10-21 Modbus Configuration**

Field	Description
<b>Enable</b>	Click to enable Modbus Master on the selected interface.
<b>Interface</b>	Select the interface that Modbus will communicate over. Serial 1/TCP – Modbus RTU on RS232 interface Serial 2/TCP – Modbus RTU on RS485 interface TCP – Modbus TCP on TCP/IP interface. LAN recommended.
<b>Upload Configuration File</b>	This field lets you upload and select the Modbus configuration file (CSV formatted file). This file contains all the configuration for the Modbus server. Generate the Modbus configuration file using <a href="https://modbus.d2sphere.com/">https://modbus.d2sphere.com/</a> . Click <b>Select file...</b> and then click <b>Upload file</b> to upload the configuration file from the local drive to the /etc folder on the gateway.



## Data Window

This page shows data by polling group. The polling groups are defined in the configuration file.

1. Click **Enable Data Window** to allow data to be read from the data window. This enables data logging for 5 minutes.
2. Select the polling group number and click **Show Data** to display the data for the specified polling group.

## Modbus Download

This page allows you to download the Modbus configuration file in CSV format.

Click **Download** to download the Modbus configuration file. The file is downloaded, or a message is displayed if there is no Modbus configuration file found.

## Modbus RTU to DNP3

### Services > Modbus RTU to DNP3

The G520 series gateway acts as a DNP3 outstation. DNP3 is an open standard communication protocol used in many SCADA environments. On the G520 series gateway, DNP3 has the following functionality:

- ◆ DNP3 serial to DNP3 over TCP by tunneling. DNP3 master communicates with DNP3 outstation using tunnel over RS-232 or RS-485. For configuration, see [Serial Line Configuration on page 198](#).
- ◆ Modbus RTU to DNP3 conversion. The G520 series gateway facilitates the DNP3 master (DNP3 SCADA) to connect and monitor the Modbus RTU device connected over RS-232 or RS-485.

### Configure DNP3 Outstation for Modbus RTU to DNP3 conversion

To use this feature, configure the DNP3 outstation, then configure the serial interface (RS-232 or RS-485), and then generate the Modbus Master configuration file with the DNP3 parameters added.

To configure the DNP3 outstation:

1. Go to Services > DNP3.
2. Select **Enable** to enable DNP3.
3. Under Outstation, enter the DNP3 outstation server, link layer and database configuration settings. See [Table 10-22](#).
4. In the Outstation section under Modbus Configuration, select **Enable** and then upload the Modbus configuration file with DNP3 parameters to the /etc folder. For details on how to create the configuration file, see [Modbus Master Configuration File for DNP3 Outstation](#).
5. Click **Save & Apply**.

Table 10-22 DNP3 Outstation Configuration

Parameters	Description
DNP3 Server Configuration	

Parameters	Description
<b>Protocol</b>	TCP is the selected protocol
<b>Type</b>	Select the interface that the DNP3 server listens on. Internal – listens on LAN. Select IP and enter port. External – listens on WAN/WiFi/Cellular with automatic fallback.
<b>IP</b>	IP address of LAN interface (required if Internal type is selected)
<b>Port</b>	Server listen port
<b>DNP3 Link Layer Configuration</b>	
<b>Local Address</b>	DNP3 master address <i>Note: Ensure that the link-layer local/remote addresses are configured correctly to avoid communication problems. There is no standard default address.</i>
<b>Remote Address</b>	DNP3 remote outstation address
<b>DNP3 Database Configuration</b>	
<b>Database points</b>	Enter the number of database points
<b>Modbus Configuration</b>	
<b>Enable</b>	Select to enable Modbus configuration.
<b>Upload Configuration File</b>	Upload and then select the Modbus configuration file in CSV format.

To configure the serial interface:

1. Go to Serial > Serial 1 (RS-232) or Serial 2 (RS-485).
2. Configure the serial communication settings.
3. Select the mode as DNP3.
4. Click **Save & Apply**.

#### **Modbus Master Configuration File for DNP3 Outstation**

To configure the Modbus Master configuration file:

1. Go to Services > Modbus Master.
2. Generate the Modbus Master configuration file using the Modbus Configuration Utility at: <https://modbus.d2sphere.com>. The sections that can be configured by the tool are: the target server where the data will be reported, up to six (6) polling groups, up to five (5) upload groups, and Modbus logger details. The configuration file is generated as a CSV file.
3. Open the Modbus configuration file in a text editor, and add the DNP3 parameters to the configuration. For a sample, see the section below, [Sample CSV with DNP3 Parameters](#).
4. Save the configuration file in CSV format.

#### **Sample CSV with DNP3 Parameters**

DNP3 parameters are displayed in blue text.

```
ConfigurationStart,,,,,,,,,,,,,
ModbusExtraInfoStart,,,,,,,,,,,,,
NULL,1000,1000,1,12345,,,,,,,,,
```

```

ModbusExtraInfoEnd,,,,,,,,,,,,,
PollingGroupStart,,,,,,,,,,,,,
Group1Start,,,,,,,,,,,,,
Group1,10,1,1,0,0,0,0,,,,,,,,,
QueryStart,,,,,,,,,,,,,
Query1,1,3,100,2,NULL,NULL,,,,,,,,,
Tag1,0,8,7,1,0,4,NULL,NULL,NULL,0,0,0
Tag2,8,8,7,1,0,4,NULL,NULL,NULL,0,0,0
QueryEnd,,,,,,,,,,,,,
QueryStart,,,,,,,,,,,,,
Query2,2,1,100,1,NULL,NULL,,,,,,,,,
Tag1,0,1,1,1,0,4,NULL,NULL,NULL,0,0,0
QueryEnd,,,,,,,,,,,,,
QueryStart,,,,,,,,,,,,,
Query3,3,3,100,1,NULL,NULL,,,,,,,,,
Tag1,0,4,4,1,0,4,NULL,NULL,NULL,0,0,0
QueryEnd,,,,,,,,,,,,,
Group1End,,,,,,,,,,,,,
PollingGroupEnd,,,,,,,,,,,,,
DNP3_MappStart,,,,,,,,,,,,,
NodeStart,,,,,,,,,,,,,
5,3,1,12345,0,,,,,,,,,
Tag1,1,Query1,,,,,,,,,,,,,
Tag2,1,Query1,,,,,,,,,,,,,
NodeEnd,,,,,,,,,,,,,
NodeStart,,,,,,,,,,,,,
2,1,2,12345,0,,,,,,,,,
Tag1,1,Query2,,,,,,,,,,,,,
NodeEnd,,,,,,,,,,,,,
NodeStart,,,,,,,,,,,,,
4,1,3,12345,0,,,,,,,,,
Tag1,1,Query3,,,,,,,,,,,,,
NodeEnd,,,,,,,,,,,,,
DNP3_MappEnd,,,,,,,,,,,,,

```

## Page Selector

This page allows a root user to hide certain pages from the admin user view.

## Reporting Agent

### *Services > Reporting Agent*

The reporting agent captures current device and interface information from the gateway on a periodic basis and sends it to a generic device management server using TCP/UDP/HTTP/HTTPS protocol.

To configure the reporting agent:

1. Go to Services > Reporting Agent.
2. Select **Enable All** to enable collection data on all settings for all interfaces.
3. Select the settings to report for each of the network interfaces (LAN, WAN, Cellular, Wi-Fi, GPS). See [Table 10-23](#).
4. Configure and enable the device info, reporting agent, and data send settings. See [Table 10-24](#).
5. Click **Save & Apply**.

Table 10-23 Reporting Agent Configuration

Parameters	Description
<b>Enable All</b>	Select check box to enable all settings for all interfaces.
<b>Disable All</b>	Select check box to disable all settings for all interfaces.
<b>LAN Parameters</b>	
<b>LAN</b>	Select to enable reporting of individual LAN settings. <ul style="list-style-type: none"> <li>◆ Status</li> <li>◆ Uptime</li> <li>◆ IP</li> <li>◆ Data usage</li> </ul>
<b>WAN Parameters</b>	
	Select to enable individual WAN settings. <ul style="list-style-type: none"> <li>◆ Status</li> <li>◆ Uptime</li> <li>◆ IP</li> <li>◆ Gateway</li> <li>◆ DNS</li> <li>◆ Data usage</li> </ul>
<b>Cellular Parameters</b>	
	Select to enable individual Cellular settings. <ul style="list-style-type: none"> <li>◆ Status</li> <li>◆ Uptime</li> <li>◆ IP</li> <li>◆ Gateway</li> <li>◆ DNS</li> <li>◆ Data usage</li> <li>◆ RSSI</li> <li>◆ Roaming Status</li> <li>◆ Operator Name</li> <li>◆ Network Status</li> <li>◆ IMSI</li> </ul>
<b>Wi-Fi Parameters</b>	
	Select to enable individual Wi-Fi settings. <ul style="list-style-type: none"> <li>◆ Status</li> <li>◆ Uptime</li> <li>◆ IP</li> <li>◆ Gateway</li> <li>◆ DNS</li> <li>◆ Data usage</li> <li>◆ Wifi Client Info</li> </ul>

Parameters	Description
<b>GPS Parameters</b>	
	Select to enable individual GPS settings. <ul style="list-style-type: none"> <li>◆ Time</li> <li>◆ Latitude</li> <li>◆ Longitude</li> <li>◆ Altitude</li> </ul>

## Sending Data

**Table 10-24 Reporting Agent Data Send Configuration**

Parameters	Description
<b>Device Info</b>	Select to allow reporting agent to retrieve device IMEI information.
<b>Reporting Agents</b>	Select the reporting agent. Generic agent is the default selection.
<b>Enable Data Send</b>	Select to enable data send.
<b>Protocol</b>	Select the protocol used in the data transmission. Options are TCP, UDP, HTTP, or HTTPS. Depending on the protocol that you selected, the server fields will vary.
<b>Starting string of the frame</b>	When TCP is selected, a start of frame sequence can be used to indicate the first frame of the data sent by the reporting agent. This string must be less than 20 characters in length.
<b>Ending string of the frame</b>	When TCP is selected, a start of frame sequence can be used to indicate the first frame of the data sent by the reporting agent. This string must be less than 20 characters in length.
<b>IP1/URL1</b>	Enter the IP address or the URL of the destination server.
<b>Port1</b>	Enter the port number (for TCP and UDP).
<b>TCP Timeout</b>	Enter the timeout in seconds to switch between primary and backup IP in case of connectivity failure. TCP user timeout value should be between 10 and 900 seconds.
<b>Backup</b>	This option is available when TCP protocol is selected. Select Backup check box to configure the backup TCP server. <ul style="list-style-type: none"> <li>◆ IP2/URL2</li> <li>◆ Port2</li> </ul> <p>The backup IP will be used after 3 failed attempts to send data to primary server. Reporting agent will continue to send data to backup server until the backup server fails or the device reboots.</p>
<b>Send Interval in Second</b>	The period of time between two data transmissions.

## Data Format

*Figure 10-1* shows a portion of the reporting agent data format for a case where all settings were selected.

**Figure 10-1 Reporting Agent Data Format (excerpt)**

```
@IMEI=352948070039411,Lan Status=Connected,Lan
IP(IPv4)=192.168.1.1,Lan Uptime(Seconds)=329501,Lan TX
bytes=572260469,Lan RX bytes=117212098,Wan Status=Connected,Wan
IP(IPv4)=192.169.1.110,Wan Uptime(Seconds)=329389,Wan
gateway=192.169.1.1,Wan DNS=27.109.1.2 27.109.1.3,Wan TX
bytes=75455301,Wan RX bytes=344481735,Cellular
Status=Enabled,Cellular IP(IPv4)=,Cellular
uptime(Seconds)=,Cellular gateway=,Cellular DNS=,Cellular TX
bytes=208,Cellular RX bytes=0,RSSI(ASU)=99,Roaming Status=N/
A,Operator Name=N/A,Network Status=Not Registered,IMSI=ERROR,Wifi
Status=Enabled,Wifi IP(IPv4)=192.169.2.116,Wifi
Uptime(Seconds)=383,Wifi gateway=192.169.2.1,Wifi
DNS=192.169.2.1,Wifi TX bytes=14135074,Wifi RX bytes=34397774,Wifi
Client
```

## Service Actions

### Services > Service Actions

This page displays a list of the available services and allows you to manage the system resources. You can start, stop, reload, or restart the service; and enable or disable automatic startup of the service when the device is rebooted.

**Note:** Use caution when changing the state of services as it may cause loss of network connectivity and data. Some features may stop working and the device may become unstable.

**Figure 10-2 Service Actions**

Service	Actions					
agents	Start	Stop	Reload	Restart	Enable	Disable
boot	Start	Stop	Reload	Restart	Enable	Disable
bootcount	Start	Stop	Reload	Restart	Enable	Disable
cellular_monitor	Start	Stop	Reload	Restart	Enable	Disable
cron	Start	Stop	Reload	Restart	Enable	Disable

## SMS

### Services > SMS

The SMS feature lets you send SMS messages to the gateway to request diagnostics information, configure gateway settings, or initiate certain actions such as DOTA upgrade or starting and stopping the VPN.

### SMS Configuration

#### Services > SMS > SMS Configuration

You can configure up to four administrator mobile numbers to receive SMS messages containing gateway diagnostics information after a command is sent by SMS. The mobile number format is as follows: +<countrycode><phonenumber>

You should include the preceding special character “plus (+)”. Example: +9198xxxxxxx

**Table 10-25 SMS Service Configuration**

Parameters	Description
<b>SMS Configuration</b>	
<b>Enable</b>	Enable remote SMS configuration.
<b>AT Enable</b>	Enable remote AT commands using SMS
<b>SMS Administrator</b>	<p>Displays up to four Administrators configured to receive the diagnostics via SMS after an SMS command is sent.</p> <p><b>Note:</b> If no number is configured then the gateway will accept SMS from any number.</p> <p>For each administrator to be configured, enter the mobile number with country code.</p> <p>The format of mobile number must be: +&lt;countrycode&gt;&lt;phonenumber&gt; with a preceding special character “plus (+)”.</p> <p>Example: +9198xxxxxxx</p>

### SMS AT Commands

Table 10-26 describes the SMS AT commands in alphabetical order.

**Table 10-26 SMS AT Command Syntax**

Name	Command Syntax
<b>AT Command</b>	<p>AT#ATCMD='&lt;AT command string&gt;','&lt;Timeout&gt;</p> <p>Description: The command passed in the AT command string will be sent directly to the internal GSM module.</p> <p>Parameters:</p> <ul style="list-style-type: none"> <li>◆ AT command string – AT command such as AT+CSQ (signal quality) or AT+CREG? (to check the registration status of GSM module).</li> <li>◆ Timeout – The timeout value should be an integer in seconds. If the timeout value is set to 0, don't wait for a response. Issue the command and leave it.</li> </ul> <p>Example: AT#ATCMD=AT+CSQ,5 – check signal strength</p>

Name	Command Syntax
<b>Cell Diagnostics</b>	AT+CELLDIAG? Description: Get cellular diagnostics
<b>CELL Ping</b>	AT+CELLPING=<IPA> Description: Pings the cellular IP address Parameter: ◆ IPA – IP address of the WAN interface to ping.
<b>DOTA Action</b>	AT+DOTA=<C/M>,<update/check>[,<released/beta/development>,<filename>] Description: Update firmware on gateway or check for available firmware updates from configured server Parameters: ◆ C/M – C for custom server, M for Lantronix server ◆ update/check – whether to update the gateway with the specified filename or to check for available updates ◆ released/beta/development – the release channel on the Lantronix download server ◆ filename – filename of the package to use for the update
<b>DOTA Custom Settings</b>	AT+DOTASETTINGS=<HTTP/HTTPS>,<Server URL>,<File name>,<Username>,<Password>,<Timeout>,<Retry> Description: Update firmware on gateway from a custom server Parameters: ◆ HTTP/HTTPS – protocol of the custom server ◆ Server URL – server URL, must include http: or https: ◆ File name – the name of the file to be accessed for the update ◆ Username – server username ◆ Password – server password ◆ Timeout – period of time to wait for the download to complete (minutes) ◆ Retry Parameters – number of retry attempts for the download
<b>Hardware Information</b>	AT+HWI? Description: Get hardware information
<b>Cellular Settings</b>	AT+IPGPRS=<1/2>,<Apn>,<Username>,<Password>,<Auth-Type>,<Data-Roam> Description: Configure cellular SIM settings Parameters: ◆ 1/2 – SIM slot number ◆ Apn – access point name provided by the cellular network provider ◆ Username – username if auth type is pap, chap, or pap/chap ◆ Password – password if auth type is pap, chap, or pap/chap ◆ Auth-type – none, pap, pap/chap, or chap (auth-type parameter is case sensitive, must be all lowercase) ◆ Data-Roam – 0 for disabled or 1 for enabled



Name	Command Syntax
<b>Install / Update / Remove / Autoremove IPK</b>	<p>AT+IPKDOTA=&lt;Name of IPK file&gt;,&lt;install/upgrade/remove/autoremove&gt;,&lt;For install/upgrade: 0-both default URL and custom URL, 1-default URL, 2-custom URL&gt;</p> <p>Description: Install, update, remove or auto remove packages</p> <p>Parameters:</p> <ul style="list-style-type: none"> <li>◆ Name of IPK file – IPK file name that OPKG will install, upgrade, or remove.</li> <li>◆ install/upgrade/remove/autoremove – action that OPKG will run.</li> <li>◆ location to check for the package for install or upgrade. This argument is not required for remove or autoremove. <ul style="list-style-type: none"> <li>&gt; 0 – Both default server URL &amp; custom URL. Both servers should be running, otherwise it will return a failed response.</li> <li>&gt; 1 – default server URL</li> <li>&gt; 2 – custom server URL</li> </ul> </li> </ul>
<b>Lan Settings</b>	<p>AT+IPLAN=&lt;IPv4 address&gt;,&lt;SubnetMask&gt;</p> <p>Description: Configure LAN IPv4 settings</p> <p>Parameters:</p> <ul style="list-style-type: none"> <li>◆ IPv4 address – The IP address of the LAN interface</li> <li>◆ Subnet mask – Subnet mask of the LAN IP address</li> </ul>
<b>LAN Diagnostics</b>	<p>AT+LANDIAG?</p> <p>Description: Get LAN diagnostics</p>
<b>LAN Ping</b>	<p>AT+LANPING=&lt;IPA&gt;</p> <p>Description: Ping LAN IP address</p> <p>Parameter:</p> <ul style="list-style-type: none"> <li>◆ IPA – IP address of the LAN interface to ping</li> </ul>
<b>OPKG Configuration Settings</b>	<p>AT+OPKGSETTINGS=&lt;Server URL&gt;</p> <p>Description: Set OPKG server</p> <p>Parameter:</p> <ul style="list-style-type: none"> <li>◆ Server URL – URL of the package server</li> </ul>
<b>Manage Digital Output</b>	<p>AT#OUT=&lt;GPO1/GPO2&gt;,&lt;OPEN/CLOSE&gt;</p> <p>Description: Pull high or push low GPIO pins</p> <p>Parameters:</p> <ul style="list-style-type: none"> <li>◆ GPO1/GPO2 – the pin to be configured</li> <li>◆ OPEN/CLOSE – Set OPEN for low, or CLOSE for high.</li> </ul>
<b>Reboot</b>	<p>AT+REBOOT=1</p> <p>Description: Reboot the gateway</p>
<b>Enable Remote Access</b>	<p>AT+REMACC=&lt;1/0&gt;</p> <p>Description: remote access</p> <p>Parameter:</p> <ul style="list-style-type: none"> <li>◆ 1/0 – Set 1 to enable, set 0 to disable remote access</li> </ul>
<b>Software Information</b>	<p>AT+SWI?</p> <p>Description: Get software information</p>
<b>WAN Diagnostics</b>	<p>AT+WANDIAG?</p> <p>Description: Get WAN diagnostics</p>

Name	Command Syntax
<b>WAN Ping</b>	AT+WANPING=<IPA> Description: Ping WAN interface Parameter: ◆ IPA – IP address of the WAN interface to ping.
<b>WWAN Ping</b>	AT+WWANPING=<IPA> Description: Ping WWAN interface Parameter: ◆ IPA– IP address of the WAN interface to ping.
<b>Start/Stop VPN</b>	AT+VPN=<VPN Type>,<VPN Name>,<start/stop> Description: Start or stop the VPN instance Parameters: ◆ VPN type – pptp, l2tp, ipsec, openvpn ◆ VPN name – VPN instance name ◆ Start/stop – action to start or stop the VPN Examples: ◆ AT+VPN=ipsec,IPSEC1,start ◆ AT+VPN=ipsec,IPSEC1,stop

## Ethernet SMS

### Services > SMS > Ethernet SMS

This service enables the device connected on LAN to initiate an SMS using Ethernet port.

**Table 10-27 Ethernet SMS Configuration**

Parameters	Description
<b>Enable</b>	Check to enable the Ethernet SMS.
<b>Port</b>	Enter the port number. The port number range is from 0 to 65535.

To send an SMS you need to open a TCP client connection on the LAN IP and configured port. Once the connection is created, issue the following commands:

To send an SMS

```
AT#SENDSMS=+<Mobile Number with Country Code><Message end with CTRL+D>
```

To read an incoming SMS

```
AT#READSMS=<ALL/SMS ID><Enter>
```

To delete an SMS

```
AT#DELSMS=<ALL/SMS ID><Enter>
```

The internal SMS buffer is 10 messages – meaning, 11<sup>th</sup> incoming SMS will be over written on the 1<sup>st</sup> SMS.

## Live Message

### Services > SMS > Live Message

Sends SMS from the web interface.

#### Notes:

- ◆ To activate the Live Message feature, you must first enable the Ethernet SMS feature.
- ◆ To send SMS, add a # symbol preceding the phone number instead of the + symbol.

To send SMS from the web interface:

1. Go to Services > SMS > Live Message.
2. Under Send SMS:, type #<mobile number with country code>.
3. Under Message Area: type the message. It can be update 159 characters.
4. Click **SendSMS**.

To read SMS:

On the Live Message page, select the message number (from 1-10 or All) and click **ReadSms**.

To delete an SMS:

On the Live Message page, select the message number (from 1-10 or All) and click **DeleteSms**.

## SNMPD

### Services > SNMPD

The G520 series gateway uses Net-SNMP to implement SNMP v1, v2c, and v3 using both IPv4 and IPv6 to remotely manage and monitor network components and systems. The implementation includes an SNMP agent for responding to SNMP requests or actions from the SNMP manager, an SNMP-TRAP application for receiving and processing SNMP notifications (or traps), and support for a number of applications to retrieve information from an SNMP capable device (snmpget, snmpgetnext, snmpwalk), retrieve statistics (snmpstatus) or write configuration on the device (snmpset).

The configuration of the SNMP agent and SNMP-TRAP application configuration files (mainly snmpd.conf and snmptrapd.conf) are done using the web interface. Likewise, operations such as enabling or disabling the agent and trap receiver are done using the web interface. Most management operations and monitoring, however, will be done through the SNMP manager.

Prerequisites to use this feature include having knowledge of SNMP and having a network management system (NMS) with which to monitor the network.

For more information about Net-SNMP or SNMP in general, please refer to the [Net-SNMP web site](#).

For information about using SNMP management systems, see the appropriate documentation for your NMS application.

### SNMP Architecture

A typical SNMP implementation includes the following components:

- ◆ Network management system (NMS) – a combination of hardware devices and software (SNMP manager) used to monitor and administer a network. The manager polls the devices on the network for information about network connectivity, activity, and events.
- ◆ Managed device – any device on the network that is managed by the NMS.
- ◆ SNMP agent – the SNMP process that resides on the managed device and communicates with the SNMP manager. It responds to requests for information or actions from the manager and generates SNMP notifications (traps). The agent also controls access to the agent's MIB.
- ◆ Management Information Base (MIB) – collection of objects that specify the information that the agent provides to the SNMP manager.

### SNMP Versions

The G520 series software supports the following versions of SNMP: SNMPv1, SNMPv2c and SNMPv3/USM.

- ◆ SNMPv1 – Simple Network Management Protocol, defined in RFC 1157. Security is based on community strings.
- ◆ SNMPv2c – The community string-based Administrative Framework for SNMPv2. SNMPv2c is defined in RFCs 1901, 1905, and 1906. Security is based on community strings.
- ◆ SNMPv3/USM – SNMPv3 is defined in RFCs 3413-3415. It provides secure access to devices by authenticating and encrypting packets over the network. SNMPv3 provides message integrity, authentication, and encryption security features.

Table 10-28 SNMP Security Models and Levels

SNMP Model	Level	Authentication	Encryption
v1	noAuthNoPriv	Community String	No
v2c	noAuthNoPriv	Community String	No
v3	noAuthNoPriv	Username	No
v3	authNoPriv	MD5 or SHA	No
v3	authPriv	MD5 or SHA	DES or AES

## SNMP Configuration

The SNMP agent must be configured to use the version of SNMP that is supported by the management station. An agent can communicate with multiple managers. You can configure the SNMP agent to support communication with one management station using SNMPv1, one using SNMPv2c, and one using SNMPv3.

The web interface allows you to configure the SNMP settings. The configuration specifies directives in the following areas:

- ◆ agent behavior
- ◆ access control to the agent (VACM)
- ◆ system information and monitoring
- ◆ active monitoring of the local system

### Agent Behavior

The following directives control the behavior of SNMP network service.

- ◆ agent address – the listening address on which to receive incoming SNMP requests. The default behavior is to listen on UDP port 161 on all IPv4 interfaces
- ◆ EngineID – SNMPv3 only. SNMPv3 requires an SNMP agent to define a unique engine ID to respond to SNMP requests.

For configuration details, see [Table 10-29 on page 128](#).

### View-based Access Control Model (VACM)

SNMP v1/v2c/v3-USM follow the VACM model. VACM determines whether to allow access to a managed object in a local MIB by a remote principal. VACM makes use of a MIB that defines the access control policy for the agent and makes it possible to use remote configuration.

The SNMP service uses four keywords to set up VACM:


- ◆ **Com2sec** – maps a v1 and v2c community string and a source IP or network to a security name.
- ◆ **Group** – maps a security name/security model pair to a group name.
- ◆ **View** – maps an OID subtree family and bitstring value (mask-optional), or MIB view, to a view name.
- ◆ **Access** – maps a group name to a minimum access level (noauth, auth, or priv) and read/write/notify scope for a specified security model (v1, v2c, v3/usm, or any).

In summary:

- ◆ The Access and View keywords determine what access is being controlled.

- ◆ The Group and com2sec keywords determine who has this access.

Figure 10-3 shows how the fields map in the VACM configuration model.



For SNMP v1/v2c/USM VACM configuration details, see [Table 10-30 on page 130](#).

### SNMPv3 with User-based Security Model (USM)

SNMPv3 with USM contains a private list of users and keys specific to the SNMPv3 protocol. To use this model, the SNMPv3 USM users must be created and added to the VACM group table (as security name).

For SNMPv3 with USM user configuration details, see [Table 10-32 on page 133](#).

### System Information and Monitoring

System information includes system group information and monitoring information, which is described below. The system group information, such as name, location, contact, and description, are retrieved from the underlying network management system.

The agent is built with support for monitoring the local system. The following directives can be specified:

- ◆ Process monitoring – provides information about individual processes running on the local system
- ◆ Disk usage monitoring – provides information about disk usage for specified disks or all disks
- ◆ System load monitoring – provides information about system load average and swap space
- ◆ Log file monitoring – monitors the file size of specified log files

For system information and monitoring configuration details, see [Table 10-29 on page 128](#).

### Active Monitoring

The agent can be configured to generate trap notifications based on the following directives:

- ◆ Authentication failure trap – generate authentication failure traps

- ◆ Default monitors – configure the Event MIB tables to monitor various UCD-SNMP-MIB tables for problems
- ◆ Link up/link down notifications – monitor for network interfaces being taken up or down and triggering a linkUp or linkDown notification as appropriate
- ◆ Where to send the trap notifications – determine where to send the notifications such as to the localhost or to the SNMP manager.

For Trap sender configuration, see [Table 10-33 on page 133](#).

### Configure SNMPv1 or SNMPv2

To configure SNMPv1 or SNMPv2c:

1. Go to Services > SNMPD.
2. Enter the configuration settings as required according to the SNMP version (v1/v2c/v3-USM) you have chosen. Click **Save** before moving between tabs on the SNMP page.
3. To configure SNMP general settings including agent behavior and system information/monitoring, select the General Settings tab. See [Table 10-29](#).
4. To configure VACM access control settings, select the VACM tab. See [Table 10-30](#).

**Note:** You do not need to configure the EngineID or SNMPv3 with USM settings.

5. To configure SNMP agent trap sender, select the Trap Settings tab. See [Table 10-33](#).

**Note:** To configure SNMP-TRAP application, see [SNMPTRAPD on page 134](#).

6. On the General Settings tab, select **Enable** if it is not already selected.
7. Click **Save & Apply**.

### Configure SNMPv3 with USM

To configure SNMPv3 with USM:

1. Go to Services > SNMPD.
2. Enter the configuration settings as required according to the SNMP version (v1/v2c/v3-USM) you have chosen. Click **Save** before moving between tabs on the SNMP page.
3. To configure SNMP general settings including agent behavior and system information/monitoring, select the General Settings tab. See [Table 10-29](#).
4. To configure VACM access control settings, select the VACM tab. See [Table 10-30](#).
5. To configure Engine ID settings for SNMPv3, select the VACM tab. See [Table 10-31](#).
6. To create users for SNMPv3 with USM, select the VACM tab. See [Table 10-32](#).
7. To configure SNMP agent trap sender, select the Trap Settings tab. See [Table 10-33](#).

**Note:** To configure SNMP-TRAP application, see [SNMPTRAPD on page 134](#).

8. On the General Settings tab, select **Enable** if it is not already selected.
9. Click **Save & Apply**.

Table 10-29 SNMP General Settings Configuration

Parameters	Description
<b>Enable</b>	Select to enable the SNMPD application.
<b>EngineID</b>	Displays the SNMP engine ID, which is required to respond to SNMPv3 requests. This value is auto-generated when the agent is first started.
<b>agentaddress</b>	<p>Defines a list of listening addresses on which to receive incoming SNMP requests.</p> <p>The default agent behavior is listening on all interfaces on UDP port 161. This is equivalent to the following directive: agentaddress udp:161 or simply agentaddress 161</p> <p>To configure this field, specify one or more listening addresses using the format: [&lt;transport-specifier&gt;:]&lt;transport-address&gt;</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>◆ UDP:161, UDP6:161 – accept requests on all IPv4 and IPv6 interfaces on UDP port 161</li> <li>◆ localhost:161 – accept requests on the local loopback interface on UDP port 161</li> <li>◆ 127.0.0.1 – accept requests on the local loopback interface (UDP is implied)</li> <li>◆ UDP:161, UDP6:161, TCP:161, TCP6:161 – accept requests on all IPv4 and IPv6 interfaces on UDP port 161 and TCP port 161</li> </ul> <p>Other combinations are also valid.</p>
<b>System Information</b>	<p>Displays the system group information. System name, contact and location can be set through the SNMP Manager.</p> <ul style="list-style-type: none"> <li>◆ sysName – default is Lantronix</li> <li>◆ sysContact – default is root@localhost</li> <li>◆ sysLocation – default is Unknown</li> <li>◆ sysDescription – default 'uname -s -n -r -v -m' command output is not writable using a set request.</li> </ul>
<b>Process Monitoring</b>	
<b>Process Monitoring</b>	<p>Monitors the processes running on the local system and registers a command that can be run to fix errors.</p> <p>This table displays the processes that are being monitored and provides options to add, edit or delete items from the monitoring table.</p> <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the process monitoring table. Enter the process name and other details as shown below.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>Process Name</b>	Name of the process that is being counted.
<b>Max Process</b>	Maximum number of processes that should be running. Generates an error flag if the number of processes detected is greater than the maximum specified.
<b>Min Process</b>	Minimum number of processes that should be running. Generates an error flag if the number is less than the minimum.
<b>Enable Fix Action</b>	<p>Tells the agent to attempt to fix the problem by calling the operation specified in the fix action.</p> <p>The command will not be invoked automatically.</p>
<b>Program Name (Procfix action)</b>	The command that gets run when the error is detected and the fix action field is enabled.
<b>Arguments</b>	Arguments that support the command.



Parameters	Description
<b>Disk Usage Monitoring</b>	
<b>Disk Usage Monitoring</b>	<p>Monitors the minimum threshold specified in KB or as a percentage of the total disk space and registers an error if the available disk space is less than the minimum required space configured for it. Disk usage monitoring section also allows for monitoring of all disks found on the system according to a specified percentage threshold. (See Include all disks.)</p> <p>This table displays the disks being monitored for disk usage and provides options to add, edit, or delete items from the monitoring table.</p> <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the disk usage monitoring table. Enter the partition and space details as shown below.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>Partition</b>	Path where the disk is mounted.
<b>Minimum Space</b>	<p>Minimum space or minimum percentage must be configured.</p> <ul style="list-style-type: none"> <li>◆ Minimum space required on the disk in KB before the errors are triggered.</li> <li>◆ Minimum space required on the disk as a percentage of the total disk space before the errors are triggered.</li> </ul>
<b>Include All disks</b>	Enables monitoring of all disks found on the system.
<b>Minimum Percent</b>	<p>Minimum space required as a percentage of total disk space of all disks before the errors are triggered.</p> <p><i>Note: The threshold for individual disks can be configured using the partition directives above.</i></p>
<b>System Load Monitoring</b>	
<b>Load Monitoring</b>	<p>Displays the system load monitoring details if configured.</p> <p>Monitors the load average of the local system.</p>
<b>Enable Load Monitoring</b>	Enables monitoring of system load averages
<b>1 - Minute Max. Load</b>	The one-minute maximum load average before errors are triggered.
<b>5 - Minute Max. Load</b>	The five-minute maximum load average before errors are triggered.
<b>15 - Minute Max. Load</b>	The fifteen-minute maximum load average before errors are triggered.
<b>Swap Space Threshold (in KB)</b>	<p>Amount of swap space (in KB) available on the local system.</p> <p>The default threshold is 16 MB and it is enabled by default. If the available swap space is less than 16 KB if not user-configured, or less than the configured value, and if Default Monitoring is enabled, it will generate a notification to SNMP traps.</p>
<b>Log File Monitoring</b>	
<b>Log File Monitoring</b>	<p>Monitors the size of the log files and registers an error if the size exceeds the maximum size configured for it.</p> <p>Limit: Up to 20 files can be monitored.</p> <p>This table displays log files being monitored for file size limits and provides options to add, edit or delete items from the monitoring table.</p> <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the log file monitoring table. Enter the details as shown below.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>File Path</b>	File path and name of the file to be monitored.

Parameters	Description
Maximum Size	Maximum file size in KB before errors are triggered.

Table 10-30 SNMP v1/v2/USM VACM Settings

Parameters	Description
<b>Com2Sec Configuration</b>	
<b>Com2Sec Configuration</b>	<p>The com2sec directive maps a v1/v2c community string and a source IP or network address to a security name (username).</p> <p>This table displays com2Sec entries and provides options to add, edit, or delete items from the table.</p> <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the com2sec table. Enter the details as shown below.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>Security Name</b>	<p>Username specifies the security name to which this source and community string are to be mapped.</p> <p>Security name can contain alphanumeric characters, dash, underscore, or period. No spaces or other special characters allowed.</p>
<b>Source</b>	<p>Source can be one of the following:</p> <ul style="list-style-type: none"> <li>◆ restricted source – a specific hostname or address</li> <li>◆ subnet – represented as IP/Mask (10.10.10.10/255.255.255.0) or IP in CIDR notation (10.10.10.10/8) or the IPv6 equivalents</li> <li>◆ global – use “default”</li> <li>◆ localhost – use “localhost” or 127.0.0.1</li> </ul>
<b>Community</b>	<p>Specifies the community (user credential) to use for SNMP requests.</p> <p>The same community string can be specified in separate com2sec directives.</p>
<b>Group Configuration</b>	
<b>Group Configuration</b>	<p>The group directive maps a security name in the specified security model (see <a href="#">Table 10-28 on page 125</a>) into a named group.</p> <p>This table displays groups and provides options to add, edit, or delete items from the table.</p> <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the group table. Enter the details as shown below.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>➢ Several group directives can specify the same group name, allowing a single access setting to apply to several users and/or community strings.</li> <li>➢ All members of one group have the same access rights.</li> <li>➢ A user cannot belong to more than one group for each of the security models.</li> <li>➢ Groups must be set up for the community-based models separately. You would typically create two group directives for a single com2sec directive, one for v1 and one for v2c.</li> </ul>
<b>Group Name</b>	<p>Group name can contain alphanumeric characters, dash, underscore, or period. No spaces or other special characters allowed.</p>

Parameters	Description
<b>Version</b>	<ul style="list-style-type: none"> <li>◆ v1</li> <li>◆ v2c</li> <li>◆ usm</li> </ul>
<b>Security Name</b>	Security name should be one of the security names defined in the com2sec configuration.
<b>Access Configuration</b>	
<b>Access Configuration</b>	<p>The access directive maps a group name to an access level (noauth, auth, or priv) and read/write/notify scope for a specified security model (v1, v2c, v3/usm, or any).</p> <p>The table displays access entries and provides options to add, edit, or delete items from the table.</p> <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the access table. Enter the details as shown below.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>Group Name</b>	Group name should be one of the group names defined in Group configuration.
<b>Context</b>	Default context is the empty string "", which equates to "none". For v1 or v2c, context will be empty ("none").
<b>Version</b>	<ul style="list-style-type: none"> <li>◆ v1</li> <li>◆ v2c</li> <li>◆ usm</li> <li>◆ any</li> </ul> <p>This value should match the SNMP version of clients that will connect to this agent.</p>
<b>Level</b>	<ul style="list-style-type: none"> <li>◆ noauth</li> <li>◆ auth – (authNoPriv) use strong authentication</li> <li>◆ priv – (authPriv) use strong authentication and encryption</li> </ul> <p>For v1 or v2c, set the level to noauth.</p> <p>For usm, set the level to at least the minimum level required. The SNMPv3–USM security level must be configured to this level or higher.</p>
<b>Match</b>	<p>Specifies how the context should be matched against the context of the incoming request.</p> <ul style="list-style-type: none"> <li>◆ exact – context name must match exactly (default)</li> <li>◆ prefix – only the first part of the context name must match</li> </ul>
<b>Read</b>	<p>Specifies the view to be used for GET requests.</p> <ul style="list-style-type: none"> <li>◆ unspecified – if left unspecified, it will be treated as none - no access</li> <li>◆ none – no access</li> <li>◆ custom – name of the view from the view table</li> </ul>
<b>Write</b>	<p>Specifies the view to be used for SET requests.</p> <ul style="list-style-type: none"> <li>◆ unspecified – if left unspecified, it will be treated as none - no access</li> <li>◆ none – no access</li> <li>◆ custom – name of the view from the view table</li> </ul>
<b>Notify</b>	<p>Specifies the view to be used for TRAP/INFORM requests.</p> <ul style="list-style-type: none"> <li>◆ unspecified – if left unspecified, it will be treated as none - no access</li> <li>◆ none – no access</li> <li>◆ custom – name of the view from the view table</li> </ul>
<b>View</b>	

Parameters	Description
<b>View</b>	Creates a named view, which determines what part of the MIB the access control is applied to. The table displays view entries and provides options to add, edit, or delete items from the table. <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the view table. Enter the details as shown below.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>View Name</b>	View name can contain alphanumeric characters, dash, underscore, or period. No spaces or other special characters allowed.
<b>Type</b>	Specifies whether to include or exclude the elements of the subtree from the MIB view. <ul style="list-style-type: none"> <li>◆ included – the MIB view includes all the elements of the subtree</li> <li>◆ excluded – the MIB view excludes all the elements of the subtree</li> </ul>
<b>OID</b>	The OID defining the root of the subtree to include or exclude from the named view.
<b>Mask (optional)</b>	List of hex octets optionally separated by '.' or ':' with the set bits indicating which subidentifiers in the view OID to match against. Recommended to ignore this field.

Table 10-31 SNMP VACM Settings Engine ID Configuration

Parameters	Description
<b>Engine ID Configuration</b>	EngineID is required to respond to SNMPv3 requests. This ID is determined automatically, but can be configured manually. The string must be consistent through time and should not change or conflict with another agent's engineID. For this reason, it is recommended that you use the default values unless you know what you are doing.
<b>Enable</b>	Enables the engineID.
<b>engineID</b>	Specifies that the engineID should be built from the given text string. Default: lantronix
<b>engineIDType</b>	Specifies that the engineID should be built from given type. Type 1 – IPv4 address Type 2 – IPv6 address Type 3 – MAC address (default)
<b>engineIDNic</b>	Specifies that the engineID should use the following interface when determining the MAC address. Only required if engineIDType 3 is specified. Default: eth0

Table 10-32 SNMP VACM Settings SNMPv3-USM

Parameters	Description
<b>SNMPv3 with USM Configuration</b>	<p>Create one or more SNMPv3 users.</p> <p>The table displays SNMPv3 with USM users and provides options to add, edit, or delete items from the table.</p> <ul style="list-style-type: none"> <li>◆ Click <b>Add</b> to add an entry to the table. Enter the details as shown below.</li> <li>◆ Click <b>Edit</b> to modify an entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>User Name</b>	Map the security name from the VACM com2sec table here.
<b>Security Level</b>	<p>Security level can be:</p> <ul style="list-style-type: none"> <li>◆ NoAuth,NoPriv – no authentication or privacy protocol</li> <li>◆ Auth,NoPriv – has authentication (MD5 SHA), no privacy protocol</li> <li>◆ Auth,Priv – has authentication (MD5 SHA), and has privacy protocol (DES AES).</li> </ul>
<b>Auth Protocol</b>	<p>Select the authentication protocol.</p> <ul style="list-style-type: none"> <li>◆ MD5</li> <li>◆ SHA</li> </ul> <p>SHA authentication requires SSL.</p>
<b>Auth Password</b>	<p>Enter the MD5 or SHA passphrase to use for authentication.</p> <p>The passphrase must be at least 8 characters.</p>
<b>Priv Protocol</b>	<p>Select the privacy protocol.</p> <ul style="list-style-type: none"> <li>◆ DES</li> <li>◆ AES</li> </ul> <p>DES and AES require SSL.</p>
<b>Priv Password</b>	<p>Enter the privacy protocol passphrase.</p> <p>The passphrase must be at least 8 characters.</p>

Table 10-33 SNMP Trap Settings Configuration

Parameters	Description
<b>Enable</b>	
<b>Authentication Failure Trap Enable</b>	If enabled, generates authentication failure traps. This is disabled by default.
<b>Enable Default Monitors</b>	<p>Monitors the UCD-SNMP-MIB tables for problems. The monitored events (process, load, disk usage, log file) should first be configured on the General Settings page.</p> <p>By default, the agent will check the default monitors once on startup and then every 10 minutes.</p>
<b>Enable Link Up/Down Notification</b>	Monitors the ifTable for changes in network interfaces link status and generates linkUp or linkDown notifications as appropriate.
<b>Trap Configuration</b>	
<b>Version</b>	<p>Specifies the SNMP version. Can be v1, v2c, or v3.</p> <ul style="list-style-type: none"> <li>◆ For v1, community and host are required.</li> <li>◆ For v2c, type, community, and host are required.</li> <li>◆ For v3, type, username, security level, and host are required.</li> </ul>

Parameters	Description
<b>Type</b>	Select the type as trap or inform. For information about SNMPv3 notification behavior and the difference between traps and informs, see the following tutorial: <a href="http://www.net-snmp.org/tutorial/tutorial-5/commands/snmptrap-v3.html">http://www.net-snmp.org/tutorial/tutorial-5/commands/snmptrap-v3.html</a> To use type inform, the SNMP manager must also support inform messages.
<b>User Name</b>	Username is the SNMP v3 security name, as defined in VACM settings.
<b>Security Level</b>	Security level can be: <ul style="list-style-type: none"> <li>◆ NoAuth,NoPriv – no authentication or privacy protocol</li> <li>◆ Auth,NoPriv – has authentication (MD5 SHA), no privacy protocol</li> <li>◆ Auth,Priv – has authentication (MD5 SHA), and has privacy protocol (DES AES).</li> </ul> If Auth,NoPriv or Auth,Priv are selected, additional fields will be displayed. Enter the authentication and privacy protocol details as needed.
<b>Community</b>	Defines the v1 or v2c community string to be used when sending traps.
<b>Host</b>	Defines the IP address and port that the trap should be sent to. Typically, this could be localhost:162 or the IP and port of the SNMP manager. The well known SNMP Trap port is port 162.

## SNMPTRAPD

### Services > SNMPD TRAPD

The SNMP-TRAP application listens for incoming SNMP notifications. When it receives a notification, it can log the notification, pass the details to a handler program, or forward the trap to another notification receiver.

### SNMP-TRAP Configuration

To configure SNMP-TRAP settings:

1. Go to Services > SNMPTRAPD.
2. Enter the configuration settings. See [Table 10-34](#).
  - ◆ Logging – Notifications can be written to the syslog or to a file path on the gateway.
  - ◆ Notification processing – notifications can sent to a notification handler or to a notifications receiver.
3. Under General, select **Enable** if it is not already selected.
4. Click **Save & Apply**.

Table 10-34 SNMP-Trap Receiver Configuration

Parameters	Description
<b>General</b>	

Parameters	Description
<b>Enable</b>	Enables the SNMPTRAP application.
<b>Ignore Authorization Failure</b>	Select to ignore authentication failure traps.
<b>SNMP-TRAP daemon configuration</b>	
<b>Version</b>	Specifies the SNMP version. Can be v1, v2c, or v3. <ul style="list-style-type: none"> <li>◆ For v1, community and host are required.</li> <li>◆ For v2c, type, community, and host are required.</li> <li>◆ For v3, type, username, security level, and host are required.</li> </ul>
<b>Community</b>	Specifies the community used for v1 and v2c authorization. Notifications using the specified community will be allowed to be processed per the notification handling configuration.
<b>User Name</b>	Enter the SNMP v3 username, as defined in VACM settings.
<b>Type</b>	Select the type as trap or inform. For information about SNMPv3 notification behavior and the difference between traps (unacknowledged) and informs (acknowledged), see the following tutorial: <a href="http://www.net-snmp.org/tutorial/tutorial-5/commands/snmptrap-v3.html">http://www.net-snmp.org/tutorial/tutorial-5/commands/snmptrap-v3.html</a>
<b>EngineID</b>	Specifies the EngineID value. For use only with SNMPv3 traps.
<b>Security Level</b>	Security level can be: <ul style="list-style-type: none"> <li>◆ NoAuth,NoPriv – no authentication or privacy protocol</li> <li>◆ Auth,NoPriv – has authentication (MD5 SHA), no privacy protocol</li> <li>◆ Auth,Priv – has authentication (MD5 SHA), and has privacy protocol (DES AES).</li> </ul> Enter the authentication and privacy protocol type and passphrase as appropriate for the selection.
<b>Source</b>	Used for v1 and v2c authorization. The source field specifies that the configuration should only apply to notifications received from the listed sources.
<b>OID</b>	Specifies the OID defining the root of the subtree to add to or exclude from the named view.
<b>Logging Configuration</b>	
<b>Log</b>	Enables log.
<b>Logging Location</b>	Specifies where to log the notifications, either to a local file on the gateway or to the syslog. Select one: <ul style="list-style-type: none"> <li>◆ Specific file – enter the file path.</li> <li>◆ syslog</li> </ul>
<b>Format1</b>	Specify the format used to display SNMPv1 traps. If no format is defined, the default Net-SNMP format will be provided. For information about the format specification, see <a href="http://www.net-snmp.org/docs/man/snmptrapd.html">http://www.net-snmp.org/docs/man/snmptrapd.html</a> .
<b>Format2</b>	Specify the format used to display SNMPv2c and SNMPv3 traps. SNMP v2c and v3 use the same PDU format. If no format is defined, the default Net-SNMP format will be provided. For information about the format specification, see <a href="http://www.net-snmp.org/docs/man/snmptrapd.html">http://www.net-snmp.org/docs/man/snmptrapd.html</a> .
<b>Notifications Handling</b>	
<b>Execute</b>	Pass the details of the trap to a specified handler program.

Parameters	Description
<b>Execute OID</b>	<p>Invokes the specified program with the given arguments whenever a notification is received that matches the OID token.</p> <p>For SNMPv2c and SNMPv3 notifications, this token will be compared against the snmpTrapOID value taken from the notification.</p> <p>For SNMPv1 traps, the generic and specific trap values and the enterprise OID will be converted to the equivalent OID per RFC 2576.</p> <p>If the OID field is the token default then the program will be invoked for any notification not matching another OID-specific traphandle entry.</p>
<b>Program</b>	Program name with path specified followed by a space separated arguments if any. For example, /usr/bin/xyz 1 2 3
<b>Net</b>	<p>Forward the trap to another notification receiver</p> <p><b>Note:</b> Do not use this directive for SNMPv3.</p>
<b>Net OID</b>	See description for Execute OID above.
<b>Destination</b>	Forwards notifications that match the specified OID to another receiver.



## uHTTPd

### Services > uHTTPd

uHTTPd is the web server that runs the web interface. It supports multiple instances such as multiple listening ports each with its own document root directory, TLS (SSL), and other web server features.

### Web Server Configuration

The web server configuration has two sections, one for server settings and the other for default values for SSL certificates. The uHTTPd Main instance is provided by default and is used for configuring the gateway.

To configure the HTTP/S server:

1. Go to Services > uhttpd.
2. Edit the configuration settings for the gateway. See [Table 10-35](#).
3. If you upload a new X.509 certificate and private key in the general web server settings, you will need to configure the uHTTPd Self-signed Certificate Parameters section. See [Table 10-36](#).
4. Click **Save & Apply**.

**Note:** If you want to create a new server instance, go to the bottom of the Main instance (on the General Settings tab), enter a name and click **Add**. For configuration details, see [Table 10-35](#).

Table 10-35 uHTTPd Server Configuration

Parameters	Description
<b>General Settings</b>	
<b>HTTP listeners (address:port)</b>	Either HTTP listener or HTTPS listener is required. Enter the ports and addresses to listen on for HTTP access. Use 0.0.0.0/[::] to bind to all devices present. Enter a specific IP address to restrict binding to a specific interface.
<b>HTTPS listener (address: port)</b>	Either HTTP listener or HTTPS listener is required. Enter the ports and addresses to listen on for HTTPS access. Use 0.0.0.0/[::] to bind to all devices present. Enter a specific IP address to restrict binding to a specific interface.
<b>Redirect all HTTP to HTTPS</b>	Select this option to redirect all HTTP to HTTPS.
<b>Ignore private IPs on public interface</b>	Select to ignore requests from private IP addresses (RFC1918) directed to the server's public IPs. The default setting is to ignore the requests from private IPs.
<b>HTTPS Certificate (DER Encoded)</b>	Upload the HTTPS cert file. Click the icon to expand the directory structure (from root).
<b>HTTPS Private Key (DER Encoded)</b>	Upload the HTTPS private key file. Click the icon to expand the directory structure (from root).
<b>Remove old certificate and key</b>	Click to remove old certificate and key files
<b>Remove configuration for certificate and key</b>	Click to remove the cert, key, and configuration information.

Parameters	Description
<b>Full Web Server Settings</b>	
<b>Index page(s)</b>	Enter the index file to use for directories. Usually index.html or index.php.
<b>CGI filetype handler</b>	Enter the interpreter to associate with file endings in the cgi scripts directory.
<b>Do not follow symlinks outside document root</b>	If selected, the HTTP/HTTPS server will not follow symbolic links outside the document root.
<b>Do not generate directory listings</b>	If selected, the HTTP/HTTPS server will not generate directory listings.
<b>Aliases</b>	Maps URL to filesystem locations outside the document root. The format should be /old/path=/new/path
<b>Realm for Basic Auth</b>	Enter the realm for basic authentication when prompting the client for credentials. The default is "Lantronix", which is the local hostname.
<b>Config file (e.g. for credentials for Basic Auth)</b>	Enter the path of the configuration file for credentials for basic authentication and additional settings. The server will not use HTTP authentication if this field is blank.
<b>404 Error</b>	Enter the virtual URL of file or CGI script to handle 404 (file not found) request. It must begin with a forward slash '/.
<b>Advanced Settings</b>	
<b>Document root</b>	Enter the directory path to the server document root. By default the document root is /www.
<b>Path prefix for CGI scripts</b>	Enter the prefix for CGI scripts, relative to the document root. Leave it blank to disable CGI support.
<b>Virtual path prefix for Lua scripts</b>	Enter the prefix for sending requests to the embedded Lua interpreter, relative to the document root. Leave it blank to disable Lua support.
<b>Full real path to handler for Lua scripts</b>	Enter the full path to the Lua handler script to initialize Lua runtime on server start. This field is required if Lua prefix is given, otherwise it's optional.
<b>Virtual path prefix for ubus via JSON-RPC integration</b>	Enter the URL prefix for ubus via JSON-RPC handler, relative to the document root. Leave it blank to disable UBUS.
<b>Override path for ubus socket</b>	Enter the override ubus socket path
<b>Enable JSON-RPC Cross-Origin Resource Support</b>	Select to enable CORS HTTP headers on JSON-RPC API. By default, this setting is disabled.
<b>Disable JSON-RPC authorization via ubus session API</b>	If selected, do not authenticate JSON-RPC requests against the UBUS session API. By default the requests are authenticated.
<b>Maximum wait time for Lua, CGI, or ubus execution</b>	Enter the maximum wait time for CGI, Lua or ubus requests in seconds. If no output is generated within the timeout period, the requested executables are terminated. Default is 60 seconds.
<b>Maximum wait time for network activity</b>	Enter the maximum wait time for network activity. If no network activity occurs within the timeout period, the requested executables are terminated and the connection is shut down. Default is 30 seconds.
<b>Connection reuse</b>	Sets the time limit for connection reuse.

Parameters	Description
<b>TCP Keepalive</b>	Number of unanswered keep alive requests allowed. Default: 1
<b>Maximum number of connections</b>	Enter the maximum number of concurrent connections allowed. If the limit is reached, further TCP connection attempts are queued until the number of connections is below the limit. Default: 100
<b>Maximum number of script requests</b>	Enter the maximum number of concurrent requests. If the limit is reached, further requests are queued until the number of requests drops below the limit. Default: 6
<b>Maximum wait time for rpc timeout in seconds per requests</b>	Enter the maximum wait time for RPC timeout in seconds. Default: 55

### Self-Signed SSL Certificate Parameters

uHTTPd requires an X.509 certificate and private key. This has been configured for the Main instance. You only need to configure this section if you choose to upload a new certificate and private key.

**Table 10-36 uHTTPd Self-signed Certificate Configuration**

Parameters	Description
<b>uHTTPd Self-signed Certificate Parameters</b>	
<b>Valid for # of Days</b>	Enter the validity time (number of days) of the generated certificate. Default: 730 days
<b>Length of key in bits</b>	Enter the length of the generated RSA key in bits Default: 2048
<b>Server hostname</b>	Enter the server hostname covered by the certificate. Default: Lantronix
<b>Country</b>	Country of the certificate issuer
<b>State</b>	State of the certificate issuer
<b>Location</b>	Location/city of the certificate issuer

## 11: Network

The software provides the administrator several options to customize the Network configuration adhering to the organization's requirements. The following sections are available to configure the Network parameters:

- ◆ *Interfaces*
- ◆ *Wireless*
- ◆ *DHCP and DNS*
- ◆ *Hostnames*
- ◆ *Static Routes*
- ◆ *Diagnostics*
- ◆ *Firewall*
- ◆ *QoS*
- ◆ *Load Balancing*

### Interfaces

#### *Network > Interfaces*

The Interfaces section provides the overview and status of the network interfaces for LAN, WAN, Cellular, and WWAN. It also provides the configuration parameters for each of these interfaces, which allow you to configure or update the interface according to your requirements.

Additionally, you can add new virtual interfaces, such as GRE, L2TP, PPP, or PPTP VPN instances.

The Network Interfaces section contains the following pre-configured interfaces:

- ◆ *CELLULAR Interface*
- ◆ *LAN Interface*
- ◆ *WAN and WAN6 Interface*
- ◆ *WWAN and WWAN6 Interface*

#### **Interfaces Overview**

##### *Network > Interfaces*

*Figure 11-1* shows a summary view of the network interfaces and interface status.

Figure 11-1 Interfaces Overview (partial view)

Interfaces






<p>LAN</p>  <p>br-lan</p>	<p>Protocol: Static address            Uptime: 2d 15h 56m 21s            MAC: 00:80:A3:8B:AE            RX: 273.78 KB (1865 Pkts.)            TX: 1.27 MB (2321 Pkts.)            IPv4: 192.168.1.1/24            IPv6: fd6a:1ba5:8503::1/60</p>	<p>Restart Stop Edit Delete</p>
<p>WAN</p>  <p>eth1</p>	<p>Protocol: Static address            Uptime: 2d 15h 56m 20s            MAC: 00:80:A3:8B:FD:AE            RX: 183.65 MB (1853814 Pkts.)            TX: 29.10 MB (314482 Pkts.)            IPv4: 172.19.216.5/16</p>	<p>Restart Stop Edit Delete</p>
<p>WAN6</p>  <p>eth1</p>	<p>Protocol: DHCPv6 client            Uptime: 5h 5m 34s            MAC: 00:80:A3:8B:FD:AF            RX: 183.65 MB (1853814 Pkts.)            TX: 29.10 MB (314482 Pkts.)            IPv6: 2001:db80:ac13:d91e:280:a3ff:fe8b:fdaf/64</p>	<p>Restart Stop Edit Delete</p>
<p>WWAN</p>  <p>Not present</p>	<p>Protocol: DHCP client            Error: Network device is not present</p>	<p>Restart Stop Edit Delete</p>

Table 11-1 Network Interfaces Overview

Parameters	Description
<b>Interfaces Overview</b>	
<p><b>Network</b></p> 	<p>Displays the network name and image representing the interface.</p> <p><b>Note:</b> When Wi-Fi is configured as Client, the WWAN interface will become active.</p>
<b>Status</b>	Displays the status of the interface. See <a href="#">Interface Status</a> .
<b>Actions</b>	<p>Select the action to be taken for the interface.</p> <ul style="list-style-type: none"> <li>◆ <b>Restart</b> – Connects the interface or reconnects the already started interface.</li> <li>◆ <b>Stop</b> – Stops the interface.</li> <li>◆ <b>Edit</b> – Allows you to edit the interface settings.</li> <li>◆ <b>Delete</b> – Deletes the interface.</li> </ul> <p><b>Note:</b> Default interfaces have predefined configurations and should not be deleted.</p>
<b>Add new interface</b>	Click <b>Add new interface</b> to add a virtual interface. See <a href="#">Add Virtual Interface</a> .
<b>Global Network Options</b>	
<b>IPv6 ULA-Prefix</b>	Displays the IPv6 Unique Local Address (ULA)-Prefix

Parameters	Description
<b>Network Watchdog</b>	
<b>Enable</b>	Select this box to enable or clear the box to disable the network watchdog.  The network watchdog monitors the connectivity of all WAN (external network) interfaces. In the absence of connectivity resulting in Network down, the gateway resets itself.  By default, the network watchdog is in enabled mode.
<b>Time</b>	If the network watchdog is enabled, enter the watchdog timeout in minutes.
<b>Wan as Lan</b>	
<b>Enable</b>	Select the box to enable the WAN port to act as a LAN interface. This will provide two LAN interfaces on the gateway.

## Interface Status

Figure 11-2 WAN Interface Status




Table 11-2 Wireless Overview and Associated Stations

Parameters	Description
<b>Protocol</b>	Protocol assigned to the interface
<b>Uptime</b>	Amount of time that the interface has been active since the last reconnection.
<b>MAC Address</b>	MAC address of the physical interface.  <i>Note: MAC address is displayed for LAN, WAN, WWAN, and OpenVPN interfaces.</i>
<b>RX</b>	Number of received bytes over the interface for the current session.
<b>TX</b>	Number of transmitted bytes over the interface for the current session.
<b>IPv4</b>	IPv4 address
<b>IPv6</b>	IPv6 address

## Interface Protocols

The protocol assigned to each interface defines rules for exchanging information on the interface. [Table 11-3](#) shows the available protocol options for each of the interfaces. When configuring an interface, please make sure that the protocol selection is appropriate for the interface.

Legend: ✓ = protocol can be assigned ✗ = protocol should not be assigned

**Table 11-3 Network Interface Protocols**

Interface	LAN	WAN	WWAN	Cellular
Static Address	✓	✓	✓	✗
DHCP client	✗	✓	✓	✗
DHCPv6 client	✗	✓	✓	✗
GRE	✗	✗	✗	✗
L2TP	✗	✗	✗	✗
Unmanaged	✓	✓	✓	✗
PPP	✗	✗	✗	✗
PPPoE	✗	✓	✗	✗
PPTP	✗	✗	✗	✗
Cellular	✗	✗	✗	✓
QMI Cellular	✗	✗	✗	✓
Relay Bridge	✗	✗	✗	✗

The interface configuration involves selection or configuration of other settings such as default gateway, gateway metric, DHCP server, and firewall zone to name a few. These settings may or may not be used by the interface; the interface configuration depends on both the protocol selected as well as the network requirements. For descriptions of the protocols used with the LAN, WAN, WWAN, and Cellular interfaces, see the next section, [Protocol Descriptions](#).

Most of the other protocols listed in [Table 11-3](#) are used for VPN configuration. For example, use L2TP protocol to configure an L2TP VPN connection. For descriptions on these protocols, see [Add Virtual Interface](#).

The interfaces can be set to Unmanaged, if no protocol is desired. This setting may be used to enumerate an interface for firewall purposes.

## Protocol Descriptions

### Static Address

Table 11-4 describes the Static Address protocol settings.

**Table 11-4 Static Address Protocol Settings**

Parameters	Description
<b>General Settings</b>	
<b>Protocol</b>	Static Address – Static configuration with fixed address and netmask
<b>Bring up on boot</b>	Allows the interface to be live after every reboot. Bring up on boot is checked by default.
<b>IPv4 Address</b>	Enter the IPv4 Address. This IP Address must be used to access the gateway. The default LAN IP Address is 198.162.1.1.
<b>IPv4 Netmask</b>	Select the IPv4 Netmask.
<b>IPv4 Gateway</b>	Enter the IPv4 address for gateway.
<b>IPv4 broadcast</b>	Enter the IPv4 address for broadcast.
<b>Use Custom DNS servers</b>	Enter the IP address of the custom DNS server. Click the + button to add more DNS servers.
<b>IPv6 assignment length</b>	<p>Select the IPv6 assignment length.</p> <p>Available Options</p> <ul style="list-style-type: none"> <li>◆ 64 or 60 – Assign a part of the given length of public IPv6-prefix to this interface.</li> <li>◆ disabled – do not assign part of the prefix to this interface</li> <li>◆ --custom-- – Assign a part of the given length of public IPv6-prefix to this interface.</li> </ul> <p>IPv6 assignment length is disabled by default.</p> <p>If assignment length is disabled, enter the following:</p> <ul style="list-style-type: none"> <li>◆ IPv6 address – Enter the IPv6 Address.</li> <li>◆ IPv6 gateway – Enter the IPv6 Address for Gateway.</li> <li>◆ IPv6 routed prefix – Enter the public prefix to direct the client distribution to the gateway.</li> </ul> <p>If assignment length is 60, 64, or custom, enter the following:</p> <ul style="list-style-type: none"> <li>◆ IPv6 assignment hint – Enter hexacimal subprefix ID for this instance to assign prefix parts.</li> <li>◆ IPv6 suffix – Enter the IPv6 suffix.</li> </ul>
<b>Advanced Settings</b>	
<b>Use builtin IPv6 -management</b>	Allows to use the built in IPv6 management configuration.
<b>Force link</b>	<p>Select this option to assign interface properties regardless of the link being active or not.</p> <p>If not selected, items are assigned only after the link has become active.</p> <p>Default is not selected.</p>
<b>Override MAC address</b>	<p>Click to override the default MAC Address for the WAN Interface.</p> <p>On factory reset, it will be set to default MAC address.</p>



Parameters	Description
<b>Override MTU</b>	Enter the number of bytes indicating the largest physical packet size that the network can transmit. The default MTU size is 1500 bytes. Blank value represents auto MTU size
<b>Use gateway metric</b>	Enter the gateway metric. It ensures a separate routing entry for the respective interface in the main routing table. The default metric is 5.
<b>Physical Settings</b>	
<b>Bridge Interfaces</b>	Click to enable creating a bridge over multiple interfaces. <ul style="list-style-type: none"> <li>◆ Enable STP – Check to enable the Spanning Tree Protocol over the bridge.</li> <li>◆ Enable IGMP snooping – Check to enable IGMP snooping on the bridge.</li> </ul>
<b>Interface</b>	Select the interface to be configured. Select more than one interface, if parameter creating a bridge over multiple interfaces is enabled.
<b>Firewall Settings</b>	
<b>Create/Assign firewall -zone</b>	Select the firewall zone to be assigned to the interface. Select unspecified – or – create to remove the interface or assign a new zone to the interface respectively. Enter the name of the new zone in the text box and click Save & Apply button.
<b>DHCP &gt; General Setup</b> <b>DHCP Server - DHCP Server is used only for LAN interfaces</b>	
<b>Ignore Interface</b>	Check to disable the DHCP interface. <b>Note:</b> If DHCP server is disabled for the interface, all the LAN devices connected to the gateway should have a static LAN IP configured.
<b>Start</b>	Lowest leased address as offset from the network address. <b>Note:</b> If your LAN IP address is 192.168.1.1 and the parameter Start is configured as 100, then the starting IP Address of the leased IP Address range is 192.168.1.100
<b>Limit</b>	Maximum number of leased addresses that can be configured. Example <ul style="list-style-type: none"> <li>◆ If your LAN IP Address is 192.168.1.1, the parameter Start is configured as 100, and parameter Limit is configured as 150, then a total of 150 devices are configured. Thus the leased IP Address range is 192.168.1.100 to 192.168.1.249.</li> </ul>
<b>Lease time</b>	Remaining time until the device can use the DHCP server leased IP Address. <b>Note:</b> IP address allocated by the gateway will disappear from the Wi-Fi / Overview / Associated stations list only after individual lease time for each IP expires.
<b>DHCP &gt; Advanced Settings</b>	
<b>Dynamic DHCP</b>	Check to allocate DHCP IP addresses dynamically to the clients. When unchecked, service will be provided only to the clients having the static IP Address.

Parameters	Description
<b>Force</b>	Check to override the current configured Server and use DHCP server.
<b>IPv4-Netmask</b>	Enter the IPv4 netmask. This netmask will override the netmask used by the clients. In normal scenario netmask is calculated from the subnet.
<b>DHCP-Options</b>	Define additional DHCP options Example: ◆ "6,192.168.2.1, 192.168.2.2" which advertises different DNS servers to clients.
<b>DHCP &gt; IPv6 Settings</b>	
<b>Router Advertisement-Service</b>	Select the Router Advertisement-Service mode; disabled, server mode, relay mode, hybrid mode.
<b>DHCPv6-Service</b>	Select the DHCPv6-Service mode; disabled, server mode, relay mode, hybrid mode.
<b>NDP-Proxy</b>	Select the NDP mode; disabled, server mode, relay mode, hybrid mode.
<b>DHCPv6-Mode</b>	Select the DHCPv6-Service mode: ◆ Stateless ◆ Stateful ◆ Stateless + Stateful ◆ Stateful only
<b>Always announce default router</b>	Select to Announce as default router even if no public prefix is available.
<b>Announced DNS servers</b>	Add the DNS servers
<b>Announced DNS domains</b>	Add the DNS domains.

### DHCP Client

Table 11-5 describes the DHCP Client protocol settings.

**Table 11-5 DHCP Client Protocol Settings**

Parameters	Description
<b>General Settings</b>	
<b>Protocol</b>	DHCP client – Address and netmask are assigned by DHCP.
<b>Bring up on boot</b>	Allows the interface to be live after every reboot. Bring up on boot is checked by default.
<b>Hostname to send when requesting DHCP</b>	Hostname of the gateway
<b>Advanced Settings</b>	
<b>Use builtin IPv6 -management</b>	Allows to use the built in IPv6 management configuration.
<b>Force link</b>	Select this option to assign interface properties regardless of the link being active or not. If not selected, items are assigned only after the link has become active. Default is not selected.

Parameters	Description
<b>Use broadcast flag</b>	Check to use the broadcast flag. This flag is generally used by the ISP's.
<b>Use default gateway</b>	Click to configure a default gateway route. None of the gateway routes are configured by default.
<b>Use DNS server advertised by peer</b>	Allows advertising the DNS server address. Use DNS server advertised by peer for WAN interface is checked by default. If unchecked, the advertised DNS server addresses are ignored.
<b>Use gateway metric</b>	Enter the gateway metric. The Load Balancer uses these Metric values to determine priority of a WAN. The default metric is 4.
<b>Client ID to send when requesting DHCP</b>	Enter the Client ID that shall be sent when requesting DHCP.
<b>Vendor Class to send when requesting DHCP</b>	To allocate DHCP IP Addresses based on Vendor Class.
<b>Override MAC address</b>	Click to override the default MAC Address for the WAN Interface. On factory reset, it will be set to default MAC address.
<b>Override MTU</b>	Enter the number of bytes indicating the largest physical packet size that the network can transmit. The default MTU size is 1500 bytes. Blank value represents auto MTU size
<b>Physical Settings</b>	
<b>Bridge Interfaces</b>	Click to enable creating a bridge over multiple interfaces. Enable STP – Check to enable the Spanning Tree Protocol over the bridge. Enable IGMP snooping – Check to enable IGMP snooping on the bridge.
<b>Interface</b>	Select the interface to be configured. Select more than one interface if parameter creating a bridge over multiple interfaces is enabled.
<b>Firewall Settings</b>	
<b>Create/Assign firewall -zone</b>	Select the firewall zone to be assigned to the interface. Select unspecified – or – create to remove the interface or assign a new zone to the interface respectively. Enter the name of the new zone in the text box and click Save & Apply button.

**DHCPv6 Client**

Table 11-6 describes the DHCPv6 Client protocol settings.

**Table 11-6 DHCPv6 Client Protocol Settings**

Parameters	Description
<b>General Settings</b>	
<b>Protocol</b>	DHCPv6 Client – Address and netmask are assigned by DHCP
<b>Bring up on boot</b>	Allows the interface to be live after every reboot. Bring up on boot is checked by default.
<b>Request IPv6-address</b>	Enter the behavior for requesting addresses. Options are try (default), force, and disabled
<b>Request IPv6-prefix of length</b>	Enter the IPv6 address prefix length in bits. Options are: <ul style="list-style-type: none"> <li>◆ Unspecified</li> <li>◆ Automatic (default)</li> <li>◆ disabled – use if you want single IPv6 address for the AP without a subnet for routing</li> <li>◆ 48, 52, 56, 60, 64 –hinted prefix length</li> <li>◆ custom – enter custom prefix length</li> </ul>
<b>Advanced Settings</b>	
<b>Use builtin IPv6 -management</b>	Allows to use the built in IPv6 management configuration.
<b>Force link</b>	Select this option to assign interface properties regardless of the link being active or not. If not selected, items are assigned only after the link has become active. Default is not selected.
<b>Use default gateway</b>	Click to configure a default gateway route. None of the gateway routes are configured by default.
<b>Custom delegated IPv6 prefix</b>	Enter the custom IPv6 prefix to be used.
<b>Use DNS server advertised by peer</b>	Allows advertising the DNS server address. Use DNS server advertised by peer for WAN interface is checked by default. If unchecked, the advertised DNS server addresses are ignored.
<b>Client ID to send when requesting DHCP</b>	Enter the Client ID that shall be sent when requesting DHCP.
<b>Override MAC address</b>	Click to override the default MAC Address for the WAN Interface. On factory reset, it will be set to default MAC address.
<b>Override MTU</b>	Enter the number of bytes indicating the largest physical packet size that the network can transmit. The default MTU size is 1500 bytes. Blank value means auto MTU size
<b>Physical Settings</b>	
<b>Bridge Interfaces</b>	Click to enable creating a bridge over multiple interfaces. <ul style="list-style-type: none"> <li>◆ Enable STP – Check to enable the Spanning Tree Protocol over the bridge.</li> <li>◆ Enable IGMP snooping – Check to enable IGMP snooping on the bridge.</li> </ul>

Parameters	Description
<b>Interface</b>	Select the interface to be configured. Select more than one interface, if parameter creating a bridge over multiple interfaces is enabled.
<b>Firewall Settings</b>	
<b>Create/Assign firewall -zone</b>	Select the firewall zone to be assigned to the interface. Select unspecified – or – create to remove the interface or assign a new zone to the interface respectively. Enter the name of the new zone in the text box and click Save & Apply button.

### PPPoE

Table 11-7 describes the PPPoE protocol settings.

Table 11-7 PPPoE Protocol Settings

Parameters	
<b>General Settings</b>	
<b>Protocol</b>	PPPoE – Point to Point Protocol over Ethernet
<b>Bring up on boot</b>	Allows the interface to be live after every reboot. Bring up on boot is checked by default.
<b>PAP/CHAP username</b>	Enter the PAP/CHAP username. The default password is admin.
<b>PAP/CHAP password</b>	Enter the PAP/CHAP password.
<b>Access Concentrator</b>	Enter the access concentrator name.
<b>Service Name</b>	Enter the service name. <i>Note: Access Concentrator name and Service Name gets auto populated from the PPPoE Access Point router if they are not explicitly provided</i>
<b>Advanced Settings</b>	
<b>Use builtin IPv6 management</b>	Allows to use the built in IPv6 management configuration
<b>Force link</b>	Select this option to assign interface properties regardless of the link being active or not. If not selected, items are assigned only after the link has become active. This is the default.
<b>Obtain IPv6-Address</b>	Allow IPv6 negotiation on the PPP link
<b>Use default gateway</b>	Select to use the default gateway. If unselected, no default route will be configured.
<b>Use DNS servers advertised by peer</b>	Select to use DNS servers advertised by peer, otherwise ignore advertised DNS servers.
<b>Use gateway metric</b>	Enter gateway metric.
<b>LCP echo failure threshold</b>	Enter the number of LCP echo request failures allowed before considering the peer dead. Set to zero (0) to ignore failures.
<b>LCP echo interval</b>	The LCP echo interval in seconds. LCP echo failure threshold must be set, otherwise this value is ignored.
<b>Host-Uniq tag content</b>	Enter the custom Host-Uniq tag to be used.

Parameters	
<b>Inactivity timeout</b>	Enter the inactivity timeout in seconds, Close the connection if the timeout is reached or enter zero (0) to ignore inactivity timeout.
<b>Override MTU</b>	Enter MTU size in bytes. The default is 1500 bytes.
<b>Physical Settings</b>	
<b>Bridge Interfaces</b>	Click to enable creating a bridge over multiple interfaces. <ul style="list-style-type: none"> <li>◆ Enable STP – Check to enable the Spanning Tree Protocol over the bridge.</li> <li>◆ Enable IGMP snooping – Check to enable IGMP snooping on the bridge.</li> </ul>
<b>Interface</b>	Select the interface to be configured. Select more than one interface, if parameter creating a bridge over multiple interfaces is enabled.
<b>Firewall Settings</b>	
<b>Create/Assign firewall -zone</b>	Select the firewall zone to be assigned to the interface. Select unspecified – or – create to remove the interface or assign a new zone to the interface respectively. Enter the name of the new zone in the text box and click Save & Apply button.

### QMI Cellular

Table 11-8 describes the QMI Cellular protocol settings.

**Table 11-8 QMI Cellular Protocol Settings**

Parameters	Description
<b>General Settings</b>	
<b>Protocol</b>	QMI Cellular – USB modems using QMI protocol
<b>Bring up on boot</b>	Allows the interface to be live after every reboot. Bring up on boot is checked by default.
<b>Cellular Module</b>	Displays the cellular module name
<b>Modem device</b>	Displays the modem device
<b>PDP Type</b>	Enter the IP stack mode as IPv4, IPv6, or IPv4/IPv6 (dual stack)
<b>Primary SIM</b>	Indicates which SIM is the primary SIM. SIM1 or SIM2
<b>Retries</b>	Enter the number of retry attempts to make on the primary SIM before switching to the secondary SIM in case of data connection failures. Default: 5
<b>Period after which the router will try and return to primary SIM</b>	Enter the number of minutes after failover to the secondary SIM that the router should wait before attempting to switch back to the primary SIM. Default: 60
<b>Routine switch to secondary SIM</b>	Enter the number of minutes after which the interface should switch from primary to secondary SIM.
<b>Advanced Settings</b>	
<b>Use builtin IPv6 -management</b>	Allows to use the built in IPv6 management configuration.

Parameters	Description
<b>Force link</b>	Select this option to assign interface properties regardless of the link being active or not. If not selected, items are assigned only after the link has become active. Default is not selected.
<b>Enable IPv6 negotiation</b>	Click to enable IPv6 negotiation on PPP link.
<b>Modem init timeout</b>	Enter the maximum wait time in seconds for the modem to become ready. The default modem initiation timeout 20 seconds.
<b>Use default gateway</b>	Click to configure a default gateway route. If unchecked, no default route is configured.
<b>Use gateway metric</b>	Enter the gateway metric. Default is 5
<b>Override MTU</b>	Enter the number of bytes indicating the largest physical packet size that the network can transmit. The default MTU size is 1500 bytes, which is the maximum size. A blank value means use auto MTU size.
<b>Firewall Settings</b>	
<b>Create/Assign firewall -zone</b>	Select the firewall zone to be assigned to the interface. Select unspecified – or – custom to remove the interface or assign a new zone to the interface respectively. Enter the name of the new zone in the text box.
<b>SIM1/SIM2 Settings</b>	
<b>PDP Type</b>	IP stack mode <ul style="list-style-type: none"> <li>◆ IP (for IPv4)</li> <li>◆ IPv6 (for IPv6)</li> <li>◆ IPv4v6 (for dual-stack)</li> </ul>
<b>Service Type</b>	<ul style="list-style-type: none"> <li>◆ Automatic</li> <li>◆ NR5G-NSA</li> <li>◆ NR5G-SA</li> <li>◆ LTE Only</li> <li>◆ 3G only</li> </ul>
<b>APN</b>	Enter the Access Point Name provided by the cellular network operator.
<b>PIN</b>	Enter the PIN code to unlock the SIM card
<b>PUK</b>	Enter the PUK (personal unblocking key) used to unblock the SIM card if the PIN code has been repeatedly entered incorrectly
<b>Authentication Type</b>	Enter the authentication method used for the cellular connection. <ul style="list-style-type: none"> <li>◆ PAP (requires username and password)</li> <li>◆ CHAP (requires username and password)</li> <li>◆ None</li> </ul>
<b>Enable roaming</b>	Enable data roaming on the cellular interface
<b>Cid</b>	Enter Cid value. It is usually okay to leave as the default value.

## CELLULAR Interface

### Network > Interfaces > CELLULAR

This page allows you to configure the Cellular interface parameters. When the Cellular interface is first enabled or when the gateway is factory reset, the gateway detects the GSM module and assigns the appropriate protocol.

For descriptions of the protocol settings, see [QMI Cellular](#).

To edit the interface:

1. Go to Network > Interfaces, select CELLULAR and click **Edit**.

Interfaces » CELLULAR

General Settings | Advanced Settings | Firewall Settings | Sim1 Settings | Sim2 Settings

Status Device: wwan0  
Uptime: 2d 18h 7m 56s  
RX: 89.89 KB (861 Pkts.)  
TX: 90.35 KB (870 Pkts.)

Protocol QMI Cellular

Bring up on boot

Cellular Module RC7611

Modem device /dev/cdc-wdm0

Primary SIM SIM1

Retries 5  
Number of attempts to re-establish the data link after it has been lost

Period after which the router will try and return to the primary SIM 60  
Force switch back to primary SIM after the specified number of minutes

Routine switch to secondary SIM 0  
Switch to secondary SIM after the specified number of minutes

Dismiss Save

2. Configure the interface settings.

**Note:**

- ◆ *General Settings – Protocol should not be changed for the cellular interface.*
- ◆ *Firewall Settings – Firewall zone should be set as WAN zone.*
- ◆ *SIM1 / SIM2 Settings – Configure the SIM settings according to the SIM slot.*

3. Click **Save**.
4. Click **Save & Apply** to save the configuration on the gateway.



## LAN Interface

### *Network > Interface > LAN*

This page allows you to configure the LAN interface. The LAN interface should use Static Address. Gateway may be used but is not required. DHCP server may be used to dynamically assign an IP address to clients connecting to the LAN. If DHCP server is disabled for the interface, all the LAN devices connected to the gateway should have a static LAN IP configured.

### *DHCP Server*

The G520 series gateway can act as the DHCP server and assign IP addresses to devices connecting to the LAN network. The DHCP server maintains a database of available IP addresses and configuration information. When it receives a request from a client, the DHCP server determines the network to which the DHCP client is connected, allocates an IP address or prefix appropriate for the client, and sends configuration information appropriate for that client.

DHCP servers typically grant IP addresses to clients for a limited interval called a lease. DHCP clients are responsible for renewing their IP address before that interval has expired, and must stop using the address once the interval has expired, if they have not been able to renew it. DHCP is used for IPv4 and IPv6. While both versions serve the same purpose, the details of the protocol for IPv4 and IPv6 are sufficiently different that they should be considered separate protocols.

Interface configuration settings are determined mainly by the protocol selection. For a description of the protocol settings, see [Static Address](#).

To edit the interface:


1. Go to Network > Interfaces, select LAN and click **Edit**.

Figure 11-3 LAN Interface (Static Address) Configuration

Interfaces » LAN


General Settings | Advanced Settings | Physical Settings | Firewall Settings


DHCP Server

Status  Device: br-lan  
 Uptime: 2d 18h 52m 39s  
 MAC: 00:80:A3:8B:FD:AE  
 RX: 273.78 KB (1865 Pkts.)  
 TX: 1.28 MB (2348 Pkts.)  
 IPv4: 192.168.1.1/24  
 IPv6: fd6a:1ba5:8503::1/60

Protocol Static address ▾


Bring up on boot


IPv4 address 192.168.1.1 

IPv4 netmask 255.255.255.0 

IPv4 gateway

IPv4 broadcast 192.168.1.255

Use custom DNS servers  

IPv6 assignment length 60 



Assign a part of given length of every public IPv6-prefix to this interface

IPv6 assignment hint 0

Assign prefix parts using this hexadecimal subprefix ID for this interface.

IPv6 suffix ::1

Optional. Allowed values: 'eui64', 'random', fixed value like '::1' or '::1:2'.  
 When IPv6 prefix (like 'a:b:c:d::') is received from a delegating server,  
 use the suffix (like '::1') to form the IPv6 address (a:b:c:d::1) for the  
 interface.

2. Configure the interface settings respective to the gateway model number.

- ◆ For protocol settings, see [Static Address](#).

**Note:**

- ◆ *General Settings* – Protocol should be Static Address for the LAN interface. Gateway is not required.
  - ◆ *Physical Settings* – By default, the LAN interface bridges the eth0.1 and wlan0 physical interfaces.
  - ◆ *Firewall Settings* – Firewall zone should be set as LAN zone.
  - ◆ *DHCP Server* – DHCP server can be used to assign IP address to clients connecting to the LAN. To enable the DHCP server, make sure that the check box "Ignore Interface" is not selected, and configure the other DHCP settings.
3. Click **Save**.
  4. Click **Save & Apply** to save the configuration.

## WAN and WAN6 Interface

### **Network > Interface > WAN or WAN6**

The WAN and WAN6 pages allow you to configure the WAN and WAN6 interfaces, respectively. The WAN interface supports IPv4 or dual mode IPv4/IPv6 and the WAN6 interface supports IPv6 mode. Otherwise, the WAN and WAN6 interfaces are similar and are configured in a similar manner.

The WAN or WAN6 interface should use Static Address, DHCP client, DHCPv6 client, or PPPoE protocol. If you assign Static Address as the protocol, the IPv4 gateway is required for the external interface, but should not be used for internal use. DHCP server should be disabled.

The interface configuration parameters will depend on the assigned protocol. For descriptions of the protocol settings, see [Static Address](#), [DHCP Client](#), [DHCPv6 Client](#), or [PPPoE](#).


To edit the interface:

1. Go to Network > Interfaces, select WAN and click **Edit**.

Figure 11-4 WAN Interface (Static Address) Configuration


Interfaces » WAN


General Settings | Advanced Settings | Physical Settings | Firewall Settings | DHCP Server

Status  Device: eth1  
 Uptime: 2d 19h 11m 53s  
 MAC: 00:80:A3:8B:FD:AF  
 RX: 197.76 MB (1987248 Pkts.)  
 TX: 55.03 MB (372273 Pkts.)  
 IPv4: 172.19.216.5/16

Protocol Static address ▼


Bring up on boot


IPv4 address 172.19.216.5 


IPv4 netmask 255.255.0.0 

IPv4 gateway 172.19.0.1

IPv4 broadcast 172.19.255.255

Use custom DNS servers 



IPv6 assignment length disabled   
 Assign a part of given length of every public IPv6-prefix to this interface

IPv6 address Add IPv6 address... 

IPv6 gateway \_\_\_\_\_

IPv6 routed prefix \_\_\_\_\_  
 Public prefix routed to this device for distribution to clients.

IPv6 suffix ::1  
 Optional. Allowed values: 'eui64', 'random', fixed value like '::1' or '::1:2'. When IPv6 prefix (like 'a:b:c:d:') is received from a delegating server, use the suffix (like '::1') to form the IPv6 address ('a:b:c:d::1') for the interface.

2. Configure the interface settings respective to the gateway.
  - ◆ For protocol settings, see [Static Address](#), [DHCP Client](#), or [PPPoE](#).
  - ◆ General Settings – To change the WAN protocol, select the protocol and click the **Switch Protocol** button.
  - ◆ Firewall Settings – Firewall zone should be set as WAN zone.
  - ◆ DHCP Server – DHCP server should be disabled. Make sure to select "Ignore Interface."
3. Click **Save**.
4. Click **Save & Apply** to save the configuration.

## WWAN and WWAN6 Interface

### Network > Interface > WWAN or WWAN6

This page allows you to configure the WWAN and WWAN6 interface parameters. The WWAN interface becomes active when the wireless interface is configured as client. The wireless interface is configured on the Network > Wireless page.

The WWAN interface supports IPv4 or dual mode IPv4/IPv6. WWAN6 interface supports IPv6 mode. Otherwise, the WWAN and WWAN6 interfaces provide similar functionality and are configured in a similar manner.


The WWAN or WWAN6 interface will use either Static Address, DHCP client, or DHCPv6 client protocol. On the WWAN interface, if you assign Static Address as the protocol, IPv4 gateway is required for external interface, but should not be used for internal use. DHCP server should be disabled.

Interface configuration settings will vary depending on the assigned protocol. For descriptions of the protocol settings, see [Static Address](#), [DHCP Client](#), or [DHCPv6 Client](#).

To edit the interface:

1. Go to Network > Interfaces, select WWAN and click **Edit**.

Figure 11-5 WWAN Interface (DHCP client) Configuration



2. Configure the interface settings respective to the gateway.
  - ◆ For protocol settings, see [Static Address](#) or [DHCP Client](#).
  - ◆ General Settings – To change the WWAN protocol, select the protocol and click the **Switch Protocol** button. If Static IP address protocol is selected, IPv4 gateway is required for external interface, but should not be used for internal use.

- ◆ Advanced Settings – Similar to WAN DHCP settings, except the metric is fixed by default for other features to work as per requirement.
  - ◆ Firewall Settings – Firewall zone should be set as WAN zone.
  - ◆ DHCP Server – DHCP server should be disabled.
3. Click **Save**.
  4. Click **Save & Apply** to save the configuration.

### Add Virtual Interface

The virtual network interface allows you to configure a new interface such as a VPN tunnel that encapsulates data inside a transport protocol. The supported tunneling protocols include GRE, L2TP, PPP, and PPTP.

The virtual interface can be created for other reasons, such as to configure a relay bridge to extend the wireless network.

**Note:** Adding a virtual interface may require modifications to the load balancer configuration. For load balancer configuration, see [Load Balancing](#). For additional support and knowledge base articles, please visit [Lantronix Support](#).

To add a new interface:

1. Go to Network > Interfaces, scroll to the bottom of the list of interfaces and click **Add new interface**.

**Figure 11-6 Network Add New Interface**

2. Enter the interface name. The name must include only alpha numeric characters and special character underscore ( \_ ).
3. Select the protocol to assign to the interface.
4. Click **Create interface**.
5. Configure the interface settings relative to the selected protocol.
  - ◆ The first field below the protocol selection is Bring up on boot. This is enabled by default and will start the interface when the gateway is booted.
  - ◆ For the remaining configuration details, see [Table 11-9](#).
6. Click **Save** to save the new interface.
7. Click **Save & Apply** to apply the configuration to the gateway.

Table 11-9 VPN Tunnel Protocols

Protocol	Description
<b>GRE</b>	
<b>GRE General Settings</b>	<ul style="list-style-type: none"> <li>◆ Bring up on boot – Start the interface when the device is booted. Selected by default.</li> <li>◆ Enable GRE tunnel – Enable the interface.</li> <li>◆ GRE Server Address – Enter the WAN IP address or domain name of the remote GRE server.</li> <li>◆ Local Address – Enter the WAN IP address of the gateway</li> <li>◆ Local Tunnel Address – Enter the local IP address of the gateway on the GRE tunnel</li> <li>◆ Remote Tunnel Address – Enter the remote IP address on the GRE tunnel</li> <li>◆ Keepalive Interval (in minutes) – The amount of time before sending a keepalive probe packet to check the connection</li> <li>◆ Keepalive Retries – The number of unanswered echo requests before considering the peer dead</li> <li>◆ Interface – Enter the interface to bind to GRE. GRE cannot move from one interface to another. It must be bound to a particular interface.</li> </ul>
<b>GRE Advanced Settings</b>	<ul style="list-style-type: none"> <li>◆ Use builtin IPv6 management – Allows to use the built in IPv6 management configuration</li> <li>◆ Force link – Select this option to assign interface properties regardless of the link being active or not.</li> </ul> <p>If not selected, items are assigned only after the link has become active. This is the default.</p>
<b>GRE Firewall Settings</b>	Select the WAN zone as the firewall zone.
<b>L2TP</b>	
<b>L2TP General Settings</b>	<ul style="list-style-type: none"> <li>◆ Bring up on boot – Start the interface when the device is booted. Selected by default.</li> <li>◆ L2TP Server – Enter the public IP address of the VPN server for L2TP connection</li> <li>◆ PAP/CHAP username – Enter the PAP/CHAP username. The default password is admin.</li> <li>◆ PAP/CHAP password – Enter the PAP/CHAP password.</li> </ul>
<b>L2TP Advanced Settings</b>	<p>Advanced settings are similar to those of PPPoE with a few exceptions as noted below. For configuration details, see <a href="#">QMI Cellular</a>.</p> <ul style="list-style-type: none"> <li>◆ Keepalive Requests is similar to LCP echo failure threshold.</li> <li>◆ Checkup Interval is similar to Inactivity timeout.</li> <li>◆ L2TP does not include fields for LCP echo interval or Host-Uniq tag content.</li> </ul>
<b>L2TP Firewall Settings</b>	Select the WAN zone as the firewall zone.
<b>PPP</b>	
<b>PPP General Settings</b>	<ul style="list-style-type: none"> <li>◆ Modem device – Select the modem device from the list.</li> <li>◆ PAP/CHAP username – Enter the PAP/CHAP username. The default password is admin.</li> <li>◆ PAP/CHAP password – Enter the PAP/CHAP password.</li> </ul>
<b>PPP Advanced Settings</b>	Advanced settings are similar to those of PPPoE. For configuration details, see <a href="#">QMI Cellular</a> .
<b>PPP Firewall Settings</b>	Select the WAN zone as the firewall zone.
<b>PPtP</b>	

Protocol	Description
<b>PPtP General Settings</b>	<p><b>Note:</b> Enabling PPTP will also enable a 20 mins PPTP watchdog which will reboot the gateway in absence of an active PPTP connection for a period of 20 mins.</p> <ul style="list-style-type: none"> <li>◆ VPN Server – Enter the public IP Address or DNS name of the remote VPN Server for the PPTP connection.</li> <li>◆ PAP/CHAP username – Enter the PAP/CHAP username.</li> <li>◆ PAP/CHAP password – Enter the PAP/CHAP password. The default password is admin.</li> <li>◆ Interface – Select the interface that the device will use to initiate the PPTP connection.</li> <li>◆ Unspecified – use the active interface to make the connection.</li> </ul>
<b>PPtP Advanced Settings</b>	<p>Advanced settings are similar to those of PPPoE. For configuration details, see <a href="#">QMI Cellular</a>.</p> <p>One additional setting is described below:</p> <ul style="list-style-type: none"> <li>◆ Use mppe – Select to enable encryption if this setting is enabled on the remote server.</li> </ul>
<b>PPtP Firewall Settings</b>	<ul style="list-style-type: none"> <li>◆ Select the WAN zone as the firewall zone.</li> </ul>

### Relay Bridge

The Relay Bridge protocol provides an option to implement bridge behavior (on IPv4 only) to extend the wireless network. The virtual interface must have a local IPv4 address to access the bridge connection and relay between two networks.



## Wireless

### Network > Wireless

The Wireless interface on the gateway can operate in two modes:

- ◆ Client mode – The gateway will act as a Wi-Fi client to existing wireless networks. The gateway will accept Internet access through wireless access provided by another service provider and then distribute the access to the machines connected to the gateway on its LAN interface.
- ◆ Access point (Master) mode – The gateway will act as a wireless access point to provide a wireless LAN network that wireless clients may join.

The gateway can act as Wi-Fi master and client at the same time provided that the gateway's Wi-Fi client is connected to any AP.

Figure 11-7 and Table 11-10 describe the Wireless Overview and Associated Stations.

Figure 11-7 Wireless Overview




Table 11-10 Wireless Overview and Associated Stations

Parameters	Description
<b>Wireless Overview</b>	<p>Displays status and details about the wireless radio and wireless instances.</p> <p>The gateway provides the following interaction with the wireless radio:</p> <ul style="list-style-type: none"> <li>◆ <b>Restart</b> – restart the radio</li> <li>◆ <b>Scan</b> – scan for available wireless connections and join a network. This also adds a new client instance.</li> <li>◆ <b>Add</b> – add a new instance</li> </ul> <p>The gateway provides the following interaction on the wireless interface instances:</p> <ul style="list-style-type: none"> <li>◆ <b>Disable/Enable</b> – disable or enable the instance</li> <li>◆ <b>Edit</b> – edit the instance configuration settings</li> <li>◆ <b>Remove</b> – delete the instance</li> </ul>
<b>Associated Stations</b>	<p>Displays details about associated wireless stations such as network, MAC address, host, signal and Rx/Tx (rate).</p>

## Wireless Network Configuration

**Note:** When Wi-Fi is configured as Client, the WWAN interface will become active.

### Wi-Fi Client

To join a wireless network in client mode:

1. Go to Network > Wireless.
2. Click **Scan** to find available wireless networks. The scan results will display a list of networks.
3. Select the network that you want to connect to and click **Join Network**.
4. On the wireless configuration window, enter the settings to join the network based on the network's encryption method (WPA, WPA2, WPA3 SAE, mixed WPA/WPA2). The assigned firewall zone should be WAN. If you select Replace wireless configuration, all existing networks will be deleted from the radio. Click **Submit**.
5. Configure the wireless network client. For details, see [Table 11-11](#) and [Table 11-12](#).
6. Click **Save**.

The client instance is created and the access point to which it is associated appears under Associated Stations.

7. Click **Save & Apply**.

### Wireless Access Point

To configure the wireless instance as an access point:

1. Go to Network > Wireless.
2. If an access point exists and you want to edit it, click **Edit**.
3. If no access point exists, click **Add** to create an instance.
4. Configure the device and interface settings, selecting Access point as the Wi-Fi interface mode. For configuration details, see [Table 11-11](#) and [Table 11-12](#).
5. Click **Save**.
6. The access point instance is created or modified.
7. Click **Save & Apply**.

Table 11-11 Wireless Device Configuration

Parameters	Description
<b>General Setup</b>	
<b>Status</b>	Displays the following details: <ul style="list-style-type: none"> <li>◆ Mode – Master (access point) or Client</li> <li>◆ SSID – Service Set Identifier (SSID) is a public identifier up to 32 characters that uniquely names a Wi-Fi connection.</li> <li>◆ BSSID – Basic Service Set Identification (BSSID); 24 bit MAC Address of Wireless Access Point</li> <li>◆ Encryption – data encryption method</li> <li>◆ Channel – wireless channel and frequency band</li> <li>◆ Tx-Power – transmit power in dBm</li> <li>◆ Signal/Bitrate – signal strength in dBm and bitrate in Mbit/sec</li> <li>◆ Country – country code</li> </ul>

Parameters	Description
<b>Wireless network is enabled/disabled</b>	The field label displays the state of the wireless network as either enabled or disabled. Click <b>Enable</b> or <b>Disable</b> to update the network operation state.
<b>Operating Band</b>	By default, 'auto' lets the wireless device select the operating band to use. Alternatively, choose the band and channel. Channels are defined in 5 MHz increments and are 20 MHz wide. It's recommended to select 'auto' or to select channels that don't overlap with channels used by other access points in the immediate area of the access point that you are configuring.
<b>Roaming</b>	
<b>Roaming State</b>	Enable or disable the roaming state, which allows the wireless client to make roaming choices of which AP to associate to.
<b>Level</b>	Select preconfigured roaming settings or select Custom to configure custom settings for the client.
<b>Time interval for consecutive scans</b>	The interval in seconds between scans.
<b>RSSI Delta for 2.4G</b>	The RSSI delta for 2.4G represents the roaming threshold at which the client will roam to the target AP.
<b>RSSI Delta for 5G</b>	The RSSI delta for 5G represents the roaming threshold at which the client will roam to the target AP.
<b>Scan Threshold for 2.4G</b>	The 2.4G scanning threshold in dbm, after which the client will scan for potential target APs.
<b>Scan Threshold for 5G</b>	The 5G scanning threshold in dbm, after which the client will scan for potential target APs.

Table 11-12 Wireless Interface Configuration

Parameters	Description
<b>General Setup</b>	
<b>Mode</b>	Select the Wi-Fi Interface mode. Available Options <ul style="list-style-type: none"> <li>◆ Access Point – gateway will act as an access point (master mode)</li> <li>◆ Client – gateway will act as a wireless client</li> </ul> The default mode is Access Point.
<b>ESSID</b>	Displays the device name assigned to the gateway. The default name is Lantronix G52X
<b>Priority</b>	The order of preference in which the gateway will attempt to join the configured wireless networks. The range is from 1 to 8 with 1 being the highest priority and 8 being the lowest priority.
<b>BSSID</b>	This field is displayed for Client only. Basic Service Set Identifier (BSSID) – 48-bit MAC address for the access point of the BSS. This can be left blank.
<b>Network</b>	Select LAN for the Access Point or WWAN for Client Mode to configure the gateway as LAN or WWAN respectively.
<b>Hide ESSID</b>	Select Hide ESSID, to hide ESSID when client machines scan for available Wi-Fi networks.

Parameters	Description
<b>Wireless Security</b>	
<b>Encryption</b>	<p>Select the Encryption mode for Wi-Fi network.</p> <p>Available Options:</p> <ul style="list-style-type: none"> <li>◆ No Encryption</li> <li>◆ WPA3 SAE</li> <li>◆ WPA-PSK/WPA2-PSK Mixed mode</li> <li>◆ WPA2-PSK</li> <li>◆ WPA-PSK</li> <li>◆ WPA3 Transition Mode</li> <li>◆ WPA2-EAP</li> <li>◆ WPA-EAP</li> </ul> <p>The default encryption mode for access point configuration is WPA-PSK/WPA2-PSK Mixed mode.</p> <p>WPA3 only applies to the STA (client) interface</p>
<b>Cipher</b>	<p>For all encryption modes except No Encryption.</p> <p>Select the cipher suitable to the gateway.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>◆ Auto</li> <li>◆ Force CCMP (AES)</li> <li>◆ Force TKIP</li> <li>◆ Force TKIP and CCMP (AES)</li> </ul> <p>The default cipher is auto mode.</p>
<b>Key</b>	Enter the key respective to cipher type
<b>Enable key reinstallation (KRACK) countermeasures</b>	<p>This setting is displayed only if the interface is an Access Point.</p> <p>Select to enable KRACK countermeasures.</p> <p>This setting is disabled by default.</p>
<b>MAC-Address Filter</b>	
<b>MAC-Address Filter</b>	<p>Allows or blocks certain client MAC Addresses. Default is disabled.</p> <p>This setting applies only to Access point mode.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>◆ Disable</li> <li>◆ Allow listed only – If this option is selected, choose the client MAC Addresses to allow.</li> <li>◆ Allow all except listed – If this option is selected, choose the client MAC Addresses to block.</li> </ul>

## DHCP and DNS

### Network > DHCP and DNS

Dynamic Host Configuration Protocol (DHCP) is a network protocol that is used to configure network devices to communicate on an IP network. A DHCP client uses the DHCP protocol to acquire configuration information, such as an IP address, a default route, and one or more DNS server addresses from a DHCP server. The DHCP client then uses this information to configure its host. Once the configuration process is complete, the host is able to communicate on the network.

For details about basic setup of DHCP server on the LAN side see [DHCP Server](#).

The DHCP and DNS page allows you to configure advanced options such as custom DNS servers, custom lease files, advanced TFTP settings and MAC Address-based IP Address allocation.

To configure:

1. Go to Network > DHCP and DNS.
2. Enter the configuration settings. See [Table 11-13](#) to [Table 11-17](#).
3. Click **Save & Apply**.

### General Settings

#### Network > DHCP and DNS > General Settings

Table 11-13 General Configuration of DHCP Server and DNS-Forwarder

Parameters	Description
<b>Server Settings</b>	
<b>Domain required</b>	Check to allow forwarding of DNS request only if they have domain name.
<b>Authoritative</b>	Check to authorize the DHCP in the local network.
<b>Local server</b>	Enter the local server domain specification. These domain names are only resolved using DHCP or host files.
<b>Local domain</b>	Enter the local domain suffix appended to DHCP names and host file entries.
<b>Log queries</b>	Log the DNS request received in the syslog server.
<b>DNS forwardings</b>	Enter the DNS Server names to forward the received DNS requests.
<b>Rebind protection</b>	Check to discard upstream RFC1918 responses
<b>Allow localhost</b>	Check to allow upstream responses in the 127.0.0.0/8 range, e.g. for RBL services
<b>Domain whitelist</b>	Enter the list of domain name to allow RFC1918 responses.
<b>Local Service Only</b>	Select to accept DNS queries only from hosts whose address is on a local subnet.
<b>Non-wildcard</b>	Select to bind only configured interface addresses, instead of the wildcard address.
<b>Listen Interfaces</b>	Restrict listening to the specified interfaces.
<b>Exclude Interfaces</b>	Prevent listening on the specified interfaces.
<b>Active DHCP Leases</b>	

Parameters	Description
<b>Hostname</b>	Name of the device that is connected to the gateway and has been leased an IP Address by DHCP server.
<b>IPv4-Address</b>	IPv4 Address assigned to the device connected to the gateway.
<b>MAC-Address</b>	MAC address of the device connected to the gateway.
<b>Leasetime remaining</b>	Remaining time until which the device can use the DHCP server leased IP Address.
<b>Active DHCPv6 Leases</b>	
<b>Hostname</b>	Name of the device that is connected to the gateway and has been leased an IPv6 Address by DHCPv6 server.
<b>IPv6-Address</b>	IPv6 Address assigned to the device connected to the gateway.
<b>DUID</b>	DUID (Device Unique Identifier) of the device connected to the gateway
<b>Leasetime remaining</b>	Remaining time until which the device can use the DHCPv6 sever leased IPv6 Address.
<b>Static Leases</b>	
<b>Hostname</b>	Name of the device that is connected to the gateway and has been assigned a static IP Address.
<b>MAC-Address</b>	MAC address of the device connected to the gateway.
<b>IPv4-Address</b>	IPv4 Address to be assigned to the device connected to the gateway.
<b>IPv6-Suffix (hex)</b>	IPv6 Address to be assigned to the device connected to the gateway.

## Resolv and Host Files

[Network > DHCP and DNS > Resolv and Host File](#)

Table 11-14 Resolv and Host File Configuration for DHCP and DNS

Parameters	Description
<b>Use /etc/ethers</b>	Check to use /etc/ethers for configuring the DHCP-Server.
<b>Leasefile</b>	Enter the directory path name where given DHCP-leases will be stored.
<b>Ignore resolve file</b>	Check to ignore the resolved file.
<b>Resolve file</b>	Enter the local DNS file.
<b>Ignore /etc/hosts</b>	Check to ignore the hosts file.
<b>Additional Hosts file</b>	Enter the additional host files.

## TFTP Settings

[Network > DHCP and DNS > TFTP Settings](#)

This page provides settings to configure the gateway as a Trivial File Transfer Protocol (TFTP) server, which can be used to serve files for download to a remote TFTP client.

Table 11-15 TFTP Configuration for DHCP and DNS

Parameters	Description
<b>Server Settings</b>	

Parameters	Description
<b>Enable TFTP server</b>	<p>Check to enable TFTP server.</p> <p>By default, the TFTP server is in disabled.</p> <ul style="list-style-type: none"> <li>◆ TFTP server root – Enter the Root directory for the files served using TFTP.</li> <li>◆ Network boot image – Enter the Filename of the boot image which is advertised to the clients.</li> </ul>

## Advanced Settings

*Network > DHCP and DNS > Advanced Settings*

**Table 11-16 Advanced Configuration for DHCP and DNS**

Parameters	Description
<b>Server Settings</b>	
<b>Suppress logging</b>	Suppress logging of the routine operation of DHCP. Errors and problems will still be logged.
<b>Allocate IP Sequentially</b>	Force DHCP server to allocate IP addresses sequentially, starting from the lowest available address.  In this mode, clients that allow a lease to expire are more likely to move IP address.
<b>Filter private</b>	Check to deny the reverse lookups for local networks.
<b>Filter useless</b>	Check to deny the requests that cannot be answered by public name servers.  By default the request are forwarded.
<b>Localize queries</b>	Check to localize hostname depending on the requesting subnet if multiple IP Addresses are available.
<b>Expand hosts</b>	Check to add local domain suffix to names served from hosts files.
<b>No negative cache</b>	Check to deny caching the negative replies, e.g. for non-existing domains.
<b>Additional Servers file</b>	List of DNS servers to forward requests to.
<b>Strict order</b>	DNS servers will be queried in the order of the resolve file.
<b>All Servers</b>	Select to query all upstream DNS servers.
<b>Bogus NX Domain Override</b>	Enter the hostname that supply bogus NX domain results.
<b>DNS server port</b>	Enter the listening port for inbound DNS queries. The default DNS server port is 53.
<b>DNS query port</b>	Enter the fixed source port number for outbound DNS queries. The default DNS query port is “any”
<b>Max. DHCP leases</b>	Enter the maximum number of allowed DHCP leases that are active. By default unlimited DHCP leases are allowed.
<b>Max. EDNS0 packet size</b>	Enter the maximum allowed size of EDNS.0 UDP packets. The default EDNS.0 UDP packet size is 1280.
<b>Max. concurrent queries</b>	Enter the maximum number of concurrent DNS queries allowed. By default 150 concurrent DNS queries are allowed.

Parameters	Description
Size of DNS query cache	Enter the maximum number of cached DNS entries. By default, 150 DNS entries are cached. Maximum is 10000. A value of zero (0) means no caching.

## Static Leases

[Network](#) > [DHCP and DNS](#) > [Static leases](#)

Table 11-17 DHCP and DNS Static Leases

Parameters	Description
Add	Click to add a static lease.
<b>Active DHCP Leases</b>	
Hostname	Name of the device that is connected to the gateway and has been leased an IP Address by DHCP server.
IPv4-Address	IPv4 Address assigned to the device connected to the gateway.
MAC-Address	MAC address of the device connected to the gateway.
Leasetime remaining	Remaining time until which the device can use the DHCP server leased IP Address.
<b>Active DHCP6 Leases</b>	
Hostname	Name of the device that is connected to the gateway and has been leased an IPv6 Address by DHCPv6 server.
IPv6-Address	IPv6 Address assigned to the device connected to the gateway.
DUID	DUID (Device Unique Identifier) of the device connected to the gateway
Leasetime remaining	Remaining time until which the device can use the DHCPv6 sever leased IPv6 Address.
<b>Static Leases</b>	
Hostname	Name of the device that is connected to the gateway and has been assigned a static IP Address.
MAC-Address	MAC address of the device connected to the gateway.
IPv4-Address	IPv4 Address to be assigned to the device connected to the gateway.
IPv6-Suffix (hex)	IPv6 Address to be assigned to the device connected to the gateway.



## Hostnames

### *Network > Hostnames*

Allows you to enter host names for the devices on the LAN.

To add a host name:

1. Go to Networks > Hostnames.
2. Click **Add**.
3. Enter the hostname and the IP address of the host. See [Table 11-18](#).
4. Click **Save**.
5. Click **Save & Apply**.

**Table 11-18 Hostnames Configuration**

Parameters	Description
<b>Hostname</b>	Enter the Hostname. The hostname can contain any combination of alphabetic characters, numbers, dashes, and underscores. No other special characters are allowed.
<b>IP address</b>	Enter the IP Address of the host.

## Static Routes

### *Network > Static Routes*

Configure static routes to define the explicit path between two different networks located in two different domains. Static routes must be manually reconfigured when network changes occur.

To configure static routes:

1. Go to Networks > Static Routes.
2. Select IPv4 or IPv6 tab.
3. Click **Add**.
4. Enter the configuration settings. For IPv4 static routes, see [Table 11-19](#) and for IPv6 static routes, see [Table 11-20](#).
5. Click **Save**.
6. Click **Save & Apply**.

### Static IPv4 Routes

**Table 11-19 Static IPv4 Routes Configuration**

Parameters	Description
<b>General Settings</b>	
<b>Interface</b>	Select the interface name of the parent interface this route belongs to.
<b>Target</b>	Enter the target host IPv4 Address or Network address if the target is a network.

Parameters	Description
<b>IPv4-Netmask</b>	Enter the IPv4 Netmask of the static route.
<b>IPv4-Gateway</b>	Enter the IPv4 gateway. If gateway is not entered, the gateway from the parent interface is used.
<b>Advanced Settings</b>	
<b>Metric</b>	Enter the metric of the static route.
<b>MTU</b>	Enter the number of bytes indicating the largest physical packet size that the network can transmit. The default MTU size is 1500 bytes. A blank value represents auto MTU size.
<b>Route type</b>	Select the route type. Available options: <ul style="list-style-type: none"> <li>◆ unicast – route entry describes real paths to the destinations covered by the route prefix.</li> <li>◆ local – destinations are assigned by this host. Packets are looped back and delivered locally.</li> <li>◆ broadcast – destinations are broadcast addresses. Packets are sent as link broadcasts.</li> <li>◆ multicast – special type used for multicast routing.</li> <li>◆ unreachable – these destinations are unreachable</li> <li>◆ prohibit – these destinations are unreachable.</li> <li>◆ blackhole – these destinations are unreachable. Packets are discarded silently. Local senders get an ENVAL error.</li> <li>◆ anycast – these destinations are anycast addresses assigned to this host.</li> </ul>
<b>Route table</b>	Define the table ID to use for the route. The table ID can be either a numeric table index ranging from 0 to 65535 or a symbolic alias declared in /etc/iproute2/rt_tables. The following special aliases are also recognized: local (255), main (254), default (253).
<b>Source Address</b>	Specify the preferred source address when sending to destinations covered by the target.
<b>On-Link route</b>	If enabled, the gateway is on link even if the gateway doesn't match any interface prefix.

## Static IPv6 Routes

Table 11-20 Static IPv6 Routes Configuration

Parameters	Description
<b>General Settings</b>	
<b>Interface</b>	Select the interface name of the parent interface this route belongs to.
<b>Target</b>	Enter the target host IPv6 Address or Network CIDR if the target is a network.
<b>IPv6-Gateway</b>	Enter the IPv6 gateway for the static route. If gateway is not entered, the gateway from the parent interface is used.
<b>Advanced Settings</b>	
<b>Metric</b>	Enter the metric of the static route.

Parameters	Description
<b>MTU</b>	<p>Enter the number of bytes indicating the largest physical packet size that the network can transmit.</p> <p>The default MTU size is 1500 bytes. Blank value represents auto MTU size</p>
<b>Route type</b>	<p>Select the route type.</p> <p>Available options:</p> <ul style="list-style-type: none"> <li>◆ unicast – route entry describes real paths to the destinations covered by the route prefix.</li> <li>◆ local – destinations are assigned by this host. Packets are looped back and delivered locally.</li> <li>◆ broadcast – destinations are broadcast addresses. Packets are sent as link broadcasts.</li> <li>◆ multicast – special type used for multicast routing.</li> <li>◆ unreachable – these destinations are unreachable</li> <li>◆ prohibit – these destinations are unreachable.</li> <li>◆ blackhole – these destinations are unreachable. Packets are discarded silently. Local senders get an ENVAL error.</li> <li>◆ anycast – these destinations are anycast addresses assigned to this host.</li> </ul>
<b>Route table</b>	Define the table ID to use for the route.
<b>Source Address</b>	Specify the preferred source address when sending to destinations covered by the target.
<b>On-Link route</b>	If enabled, the gateway is on link even if the gateway doesn't match any interface prefix.

## Diagnostics

### Network > Diagnostics

The diagnostics feature allows you to run network utilities and cable diagnostics commands from the web interface.

[Table 11-21](#) describes each of the network utilities.

[Table 11-22](#) describes the cable diagnostics status messages.

**Note:** The cable diagnostics command will bring down the Ethernet port link, which will take more time to complete the test. Cable diagnostics is only accurate for cable lengths of 7 - 120 meters.

**Table 11-21 Diagnostics - Network Utilities**

Network Utility	Description
<b>Ping</b>	IP Address or fully qualified domain name to be pinged. Ping determines network connection between gateway and host on the network. The output shows if the response was received, packets transmitted and received, and packet loss if any.
<b>Traceroute</b>	IP Address or fully qualified domain name Traceroute displays all the routers present between the destination IP address and the gateway. The output shows all the gateways through which data packets pass on way to the destination system from the source system, maximum hops and total time taken by the packet to return measured in milliseconds.
<b>Nslookup</b>	IP Address or fully qualified domain name that needs to be resolved. Name lookup is used to query the Domain Name Service for information about domain names and IP addresses. It sends a domain name query packet to a configured domain name system (DNS) server. If you enter a domain name, you get back the IP address to which it corresponds. If you enter an IP address, you get back the domain name to which it corresponds. A message stating "Unknown Host" indicates that the Internet Name does not exist.

**Table 11-22 Cable Diagnostics Status Messages**

Status message	Description
<interface name:> No cable faults detected	The cable link is good.
<interface name:> Open circuit detected in cable	There is no cable.
<interface name:> Open circuit detected in cable Distance to cable fault is ~<disance> meter(s).	Open ended cable.
<interface name:> Short circuit detected in cable. Distance to cable fault is ~<distance> meter(s).	There is an issue with the cable.

Status message	Description
<interface name:> Short cable (less than 10 meters) detected.	Short cable detected.
<interface name:> Cable diagnostic test failed	The cable has failed the diagnostic test. Possible failure reasons include: interface is busy, link partner is not configured for auto-negotiation, or link partner is busy establishing the link.

## Firewall

### Network > Firewall

The firewall policy helps secure the network. The G520 series gateways follow a zone based firewall concept. Every interface of the gateway, whether physical or virtual, needs to be assigned to a firewall zone, and all traffic routed through that interface is bound by the assigned policy. At a minimum, there are two firewall zones, the LAN zone and WAN zone, with one or more interfaces assigned to each zone.

By default, there is a minimal firewall configuration predefined in the gateway. The minimal configuration consists of global firewall settings, and two zones, the LAN zone and WAN zone which serve as a source or destination for port forwarding, rules, and redirects. This configuration may be sufficient for your needs with little modification. Otherwise, you can use the web interface to modify the firewall configuration.

This section assumes that the reader has knowledge of implementing firewall policies or will consult their network administrator to set up the firewall policies.

**Note:** Create a backup of the firewall configuration before making any changes.

### General Settings

The General settings page consists of the global settings and zones. The global firewall settings are default firewall settings that do not belong to any zone.

#### Firewall Global Settings

To configure firewall global settings:

1. Go to Network > Firewall.
2. In the top section of the General Settings page, if desired, modify global firewall settings. See [Table 11-23](#).
3. Click **Save & Apply** to save the changes and reload the firewall.

Table 11-23 Firewall Global Settings

Parameters	Description
<b>General Settings</b>	
<b>Enable SYN-flood protection</b>	Check to enable SYN-flood protection. SYN-flood protection will enable spamming detection and block whenever there is a spam attack.
<b>Drop invalid packet</b>	Check to drop the invalid packets that are not matching any active connection.

Parameters	Description
<b>Input</b>	Select to accept or reject the inbound traffic to all the interfaces.
<b>Output</b>	Select to accept or reject the outbound traffic from all the interfaces.
<b>Forward</b>	Select to accept or reject the forwarded traffic from all the interfaces.

### Firewall Zones

Two firewall zones, the LAN zone and WAN zone, are predefined in the gateway. All traffic from LAN to WAN has no restrictions but all incoming traffic from WAN source is blocked unless a port forwarding rule is set or unless a particular port is opened.

A zone section groups one or more interfaces and serves as source or destination for forwarding, rules, and redirects. A zone is defined by the following rules:

- ◆ Masquerade (NAT) of outgoing traffic (WAN) is controlled on a per zone basis on the outgoing interface.
- ◆ INPUT rules describe what happens to traffic trying to reach the gateway through an interface in that zone.
- ◆ OUTPUT rules zone describe what happens to traffic originating from the gateway going through an interface in that zone.
- ◆ FORWARD rules describe what happens to traffic passing between different interfaces in that zone.

### Packet filtering actions

- ◆ ACCEPT – traffic is allowed to pass as if there is no firewall in place. If the port at the destination is closed, a response will be returned as if a Reject rule is in place.
- ◆ DROP – the firewall discards the packet and sends no response back to the source host that sent the packet. The source host will wait for a response until a timeout occurs and may attempt to retry the connection after timeout occurs.
- ◆ REJECT – the firewall discards the packet and sends a response back to the source host that the port is closed. Doing so can hint to the source that packet filtering firewall is in place.

In general, use REJECT to deny traffic from trusted hosts by gracefully informing them that traffic is not allowed to pass. Use DROP to deny traffic from untrusted hosts or when you don't want expose information about the destination host.

To configure firewall zones:

1. Go to Network > Firewall.
2. To add and configure a new firewall zone, click **Add**.
3. To modify settings for an existing firewall zone, click **Edit**.
4. Enter or modify the firewall zone settings. See [Table 11-24](#).
5. Click **Save**.

**Table 11-24 Firewall Zones Configuration (LAN)**

Parameters	Description
<b>General Settings</b>	
<b>Name</b>	Enter the name of the zone.

Parameters	Description
<b>Input</b>	Select to accept, reject or drop the inbound traffic to all the configured zones.
<b>Output</b>	Select to accept, reject or drop the outbound traffic from all the configured zones.
<b>Forward</b>	Select to accept, reject or drop the forwarded traffic from all the configured zones.
<b>Masquerading</b>	Check to allow IP Masquerading (NAT).
<b>MSS clamping</b>	Check to allow MSS clamping.
<b>Covered networks</b>	Select the network interfaces that must be included in the zone configuration.
<b>General Settings / Inter-Zone Forwarding</b>	
<b>Allow forward to destination zones</b>	Select to allow or deny forwarding traffic to the configured destination zone.
<b>Allowed forward from source zones</b>	Select to allow or deny forwarding traffic from the configured source zone.
<b>Advanced Settings</b>	
Covered devices	List of raw network device names attached to this zone
Covered subnets	List of IP subnets attached to this zone.
Restrict to address family	Select IP Address family for configuring firewall for LAN zone from available options. Available Options <ul style="list-style-type: none"> <li>◆ IPv4</li> <li>◆ IPv6</li> <li>◆ IPv4 and IPv6</li> </ul>
Restrict Masquerading to given source subnets	Enter the source subnet to which the masquerading must be restricted.
Restricts Masquerading to given destination subnets	Enter the destination subnet to which the masquerading must be restricted.
Enable logging on this zone	Check to enable logging of all the activities on the Zone.
<b>Contrack Settings</b>	
Allow "invalid" traffic	Select to allow invalid traffic. More specifically, when selected, no rules can be installed that reject forwarded traffic with contrack state equal to invalid. Disabled by default.
Automatic helper assignment	Automatically assign contrack helpers for the zone.
<b>Contrack Settings</b>	
<b>Extra source arguments</b>	Extra arguments passed directly to iptables for source classification rules.
<b>Extra destination arguments</b>	Extra arguments passed directly to iptables for destination classification rules

## Port Forwards

[Network](#) > [Firewall](#) > [Port Forwards](#)

Port forwarding allows remote computers to connect to a specific host within the LAN by opening the WAN port and redirecting the connection (and data) on that port to an internal LAN IP and port. By default, all WAN side ports are closed.

To view port forwarding entries, go to Firewall > Port Forwards. See [Table 11-25](#) for a description. You can also edit, reorder or delete the entries from this view.

**Table 11-25 Firewall Port Forwards**

Parameters	Description
<b>Match</b>	Displays the WAN TCP/UDP ports for matching the conditions before forwarding it to LAN device.
<b>Forward to</b>	Displays the destination IP Address to which the traffic must be forwarded.
<b>Enable</b>	Check to enable the Port Forwarding rule.

### Add Port Forwarding Rule

To add a port forwarding rule:

1. Go to Network > Firewall > Port Forwards.
2. At the bottom of the Port Forwards table, click **Add**.
3. Enter the configuration settings. See [Table 11-26](#).
4. Click **Save**.

**Table 11-26 Port Forwarding Configuration for Firewall Zone**

Parameters	Description
<b>Port Forwards General Settings</b>	
<b>Name</b>	Enter the name of the Port Forwarding rule.
<b>Protocol</b>	Select the protocol. Available options: <ul style="list-style-type: none"> <li>◆ TCP</li> <li>◆ TCP + UDP</li> <li>◆ UDP</li> <li>◆ ICMP</li> <li>◆ unspecified</li> <li>◆ custom</li> </ul>
<b>Source Zone</b>	Specify the traffic source zone. This must refer to one of the firewall zones, usually WAN.
<b>External Port</b>	Enter the WAN port of the external network.
<b>Destination zone</b>	Specify the traffic destination zone. This must refer to one of the firewall zones, usually LAN.
<b>Internal IP address</b>	Enter the LAN IP address of the internal network.
<b>Internal port</b>	Enter the LAN port number of the internal network.
<b>Port Forwards Advanced Settings</b>	
<b>Source MAC Address</b>	The rule will match incoming traffic from the specified source mac address.



Parameters	Description
Source IP Address	The rule will match incoming traffic from the specified source IP address.
Source port	The rule will match incoming traffic from the specified source port number.
External IP Address	Enter the external IP address of the gateway.
Enable NAT Loopback	Enable NAT loopback to allow one machine on the LAN network to access another machine on the LAN through the external IP address of the gateway
Extra arguments	Passes additional arguments to iptables. Should be used with care.

## Traffic Rules

### Network > Firewall > Traffic Rules

Traffic rules are security policies that allow or restrict access to specific ports or hosts. Rule actions can be configured to accept, drop, or reject traffic.

The following describes good practices for configuring traffic rules.

- ◆ Block all traffic by default and explicitly enable specific traffic to known services.
- ◆ Allow specific traffic, using the principle of least privilege.
- ◆ Specify source IP address. It's okay to specify "any" if the service should be accessible to everyone on the Internet, otherwise, specify the source address.
- ◆ Specify the destination IP address.
- ◆ Specify the destination port. The value of the destination port should never be "any".

### Rule and zone matching

The source and destination zones are tied to the target action.

- ◆ If source and destination are given, the rule matches forwarded traffic.
- ◆ If only source is given, the rule matches incoming traffic.
- ◆ If only destination is given, the rule matches outgoing traffic.
- ◆ If neither source nor destination are given, the rule defaults to an outgoing traffic rule.

To view traffic rules, go to Network > Firewall > Traffic Rules. See [Table 11-27](#) for a description. You can also enable or disable the traffic rule from this page view.

**Table 11-27 Firewall Zone Traffic Rules**

Parameters	Description
Name	Displays the name of the traffic rule.
Match	Displays the details of the traffic rule configuration and the conditions in which the rule is applicable.
Action	Action to be taken on the traffic when the rule conditions are satisfied. Indicates whether the rule is for incoming, forwarded, or outgoing traffic.

Parameters	Description
<b>Enable</b>	Select the box to enable the traffic rule. If the rule is enabled, clear the box to disable the rule.
<b>Edit</b>	Click to edit the traffic rule settings.
<b>Delete</b>	Click to delete the traffic rule.
<b>Add</b>	Click to add a new traffic rule. This button appears at the bottom of the Traffic Rules page.

### Add Traffic Rule

To add a traffic rule:

1. Go to Network > Firewall > Traffic Rules.
2. At the bottom of the Traffic Rules table, click **Add**.
3. Enter the configuration settings. See [Table 11-28](#).
4. Click **Save**.

**Table 11-28 Firewall Traffic Rule Configuration**

Parameters	Description
<b>General Settings</b>	
<b>Name</b>	Enter the name of the traffic rule.
<b>Protocol</b>	Select the protocol from the available options. Available options <ul style="list-style-type: none"> <li>◆ TCP – Allows only TCP traffic to the open port</li> <li>◆ UDP – Allows only UDP traffic to the open port</li> <li>◆ TCP+UDP – Allows both TCP and UDP traffic to the open port</li> </ul>
<b>Source zone</b>	Select the traffic source zone. This is usually WAN zone.
<b>Source address</b>	Match incoming traffic from the specified source IP address
<b>Source port</b>	Match incoming traffic from the specified source port
<b>Destination zones</b>	Select the destination firewall zone. If specified the rule applies to forwarded traffic, otherwise it is treated as an input rule.
<b>Destination address</b>	Match incoming traffic directed to the specified destination IP address. If no destination zone is specified, the rule is treated as an input rule.
<b>Destination port</b>	Match incoming traffic directed to the specified destination port.
<b>Action</b>	Sets the target parameter to indicate the firewall action. Options include: <ul style="list-style-type: none"> <li>◆ Accept</li> <li>◆ Reject</li> <li>◆ Drop</li> <li>◆ Mark</li> <li>◆ Notrack.</li> </ul>
<b>Advanced Settings</b>	
<b>Restrict to address family</b>	Enter the protocol family to generate iptables rules for. Options include: ipv4, ipv6, or any.
<b>Source MAC address</b>	Match incoming traffic from the specified MAC address.

Parameters	Description
<b>Extra arguments</b>	Enter extra arguments to pass to iptables. This can be used to specify additional match options.
<b>Time Restrictions</b>	
<b>Week Days</b>	If specified, only match traffic during the given days of the week.
<b>Month Days</b>	If specified, only match traffic during the given days of the month.
<b>Start Time (hh.mm.ss)</b>	Specify a time to start matching traffic.
<b>Stop Time (hh.mm.ss)</b>	Specify a time to stop matching traffic.
<b>Start Date (yyyy-mm-dd)</b>	Specify a date to start matching traffic.
<b>Stop Date (yyyy-mm-dd)</b>	Specify a date to stop matching traffic.
<b>Time in UTC</b>	Select to interpret all time values as UTC time instead of local time.

## Custom Rules

### *Network > Firewall > Custom Rules*

The shell script allows you to add custom iptable commands that will be executed after the firewall is restarted, immediately after the default ruleset has been loaded.

To configure custom rules:

1. Go to *Network > Firewall > Custom Rules*.
2. Enter the custom iptable rule command after the commented lines. Each rule should be on a separate line.
3. Click **Save**.

## QoS

### Network > QoS

QoS allows you to prioritize specific flows in network traffic to manage handling and allocation of network capacity. Assign traffic to target classes and allocate the amount of bandwidth that is given to those classes. QoS service provides the following functionality:

- ◆ Configure two to four predefined **classes** with rate, priority, and packet latency (delay) settings
- ◆ Configure one or more **interfaces** (WAN, WWAN, LAN, cellular, VPN) with global connection characteristics such as upload and download speed limits. Each interface can have its own buffer.
- ◆ Configure **classification rules** to allocate packets to the configured classes (targets). Traffic is differentiated by source and destination IP addresses, protocols, and ports.

You can configure up to four QoS classes, although you can achieve results by configuring as few as two classes. The predefined classes to limit traffic are Priority, Normal, Express, and Bulk, as well as classes to limit ingress traffic, which are appended with the `_down` suffix. If the classes to limit ingress traffic are configured, then the original classes will limit egress traffic only. Otherwise, if they are not configured, then Priority, Normal, Express, and Bulk will limit both ingress and egress traffic.

To enable QoS:

Enable QoS by interface. Go to Network > QoS > Interfaces.

To configure QoS:

1. Go to Network > QoS.
2. Enter the QoS configuration settings. See [Table 11-29](#).
3. To enable QoS, go to the Interfaces tab and select **Enable** to apply QoS to the interface.
4. Click **Save & Apply**.

**Table 11-29 QoS Configure Classes**

Parameters	Description
<b>Configure Classes</b>	
<b>Name</b>	Class name. <ul style="list-style-type: none"> <li>◆ Priority</li> <li>◆ Express</li> <li>◆ Normal</li> <li>◆ Bulk</li> </ul> When configured, these classes will limit both egress (outgoing from the host) and ingress (incoming to the host) traffic. Classes to limit ingress traffic: <ul style="list-style-type: none"> <li>◆ Priority_down</li> <li>◆ Normal_down</li> <li>◆ Express_down</li> <li>◆ Bulk_down</li> </ul> If Priority_down or Normal_down are configured, then Priority or Normal will limit egress traffic only.
<b>Packet Size</b>	Maximum packet size in bytes, up to 1500 bytes.

Parameters	Description
<b>Average Minimum Rate</b>	Average rate for this class, expressed as the percentage of bandwidth
<b>Priority</b>	Priority of the class, expressed as percentage. The sum priority of all classes should not exceed 100.
<b>Packet Delay in ms</b>	The amount of time, in milliseconds, that the packet will wait in queue before it is transmitted.
<b>Max Rate in percentage</b>	Maximum rate, expressed as percentage of total bandwidth
<b>Interfaces</b>	
<b>Name</b>	Displays the name of the interface that QoS will be configured on. Click <b>Add</b> to add an interface to the list.
<b>Enable</b>	Select to enable or clear to disable QoS on the interface.
<b>Classification Group</b>	One classification group "Default" is defined.
<b>Calculate Overhead</b>	Select to enable or clear to disable. Decreases upload and download ratio to prevent link saturation.
<b>Half-duplex</b>	Limit the interface to half-duplex mode.
<b>Download Speed (kbit/sec)</b>	Enter the download limit for the interface.
<b>Upload Speed (kbit/sec)</b>	Enter the upload limit for the interface.
<b>Classification Rules</b>	
<b>Target</b>	Select the target class. There can be one rule set for each class. If a target is deleted and you want to configure it, click <b>Add</b> .
<b>Source Host</b>	Enter the source IP address or IP and mask (CIDR notation). All packets that match this source host value will be included in the QoS target class.
<b>Destination Host</b>	Enter the destination IP address or IP and mask (CIDR notation). All packets that match this destination host value will be included in the QoS target class.
<b>Protocol</b>	Packets matching this protocol will be included in the target class
<b>Ports</b>	Packets matching this port or range of ports will be included in the target class.
<b>Number of bytes</b>	Packets matching this will be included in the target class.
<b>Comment</b>	Description field.

---

## Load Balancing

### **Network > Load Balancing**

Load balancing is a mechanism that enables balancing traffic between various links. It distributes traffic among various links, optimizing utilization of all the links to accelerate performance and reduce operating costs. Interfaces are assigned a priority by means of a metric.

### **How it works**

Load balancing is determined by the load metric, in other words, the weight. Each link is assigned a relative weight and the gateway distributes traffic across links in proportion to the ratio of weights assigned to each individual link. This weight determines how much traffic will pass through a particular link relative to the other links.

Weights can be selected based on:

- ◆ Link capacity (for links with different bandwidth)
- ◆ Link/Bandwidth cost (for links with varying cost)

**Note:** *The default configuration of the load balancer is in Failover Mode with the highest priority given to WAN, then WWAN and then Cellular.*

### **MWAN Concept**

On G520 series gateways, one or more sources of Internet can be used at the same time. In failover mode, the gateway uses one source of Internet and fails over to another according to defined priorities. Once the source with a higher priority is online, the same will be used as a primary source of Internet.

Priority can be defined by setting the metric. The lower the metric, the higher the priority.

The decision of when to failover or rollback is dependent on which interfaces are online and which ones are offline. Online and offline interface status is based on the PING responses to a particular server at a particular time interval. You can speed up the failover by sending PING packets in a shorter interval and you can add reliability by adding multiple server candidates.

Load balancing is where two or more sources of Internet are used at the same time and the load is split between the multiple interfaces in the ratio of their assigned weights.

The gateway supports a feature called WAN affinity whereby a particular source IP, Destination IP or a data type can be bound to a particular interface. To accomplish this, you need to create members which correspond to physical interfaces, assign the members in a particular policy, create rules and assign a policy to the rules.

In summary:

- ◆ Members correspond to physical interfaces with an assigned metric and weight
- ◆ Policy consists of a member or group of members
- ◆ Rules specify which traffic will use a particular policy

### **Globals**

#### **Network > Load Balancing > Globals**

To configure MWAN global settings:

1. Go to Network > Load Balancing > Globals.

2. Enter or modify the settings. See [Table 11-30](#).
3. Click **Save & Apply**.

Table 11-30 MWAN Globals Configuration

Parameters	Description
Firewall mask	Enter the firewall mask value in hexadecimal, starting with 0x.
Logging	Select to enable global firewall logging and select the log level.
Update Interval	Enter the update interval for the interface routing table. Default is 5 seconds.
Routing table lookup	Enter an additional routing table to be scanned for connected networks

## Interfaces

### Network > Load Balancing > Interfaces

To view and add MWAN interfaces:

1. Go to Network > Load Balancing.
2. The MWAN Interfaces table is displayed. See [Table 11-31](#).
3. Go to the bottom of the table, enter the interface name and click **Add**.
4. Enter the interface settings. See [Table 11-32](#).
5. Click **Save & Apply**.

**Note:** *Configuring a large number of tracking IP addresses, a high ping count, or a low ping interval time will result in faster switchover but will consume more data.*

Table 11-31 MWAN Interface

Parameters	Description
MWAN Interfaces	Displays the interfaces and provides options to add, edit, or delete items from the table. <ul style="list-style-type: none"> <li>◆ Enter the interface name (must match an existing interface name) and click <b>Add</b> to add member.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
Name	Name of the available Interface.
Enabled	Displays the Interface status. Yes for enabled No for disabled
Tracking method	Displays the method used to track the interface.
Tracking source	Displays the tracking source as address or interface.
Tracking reliability	Displays the number of tracking IP addresses. The acknowledgment/responses from these tracking IP addresses are considered to determine the interface as up or down.
Ping interval	Displays the time in seconds between sending two successive ping packets.

Parameters	Description
<b>Interface down</b>	Displays the number of consecutive failed attempts after which the interface is declared offline.
<b>Interface up</b>	Displays the number of consecutive successful pings after which the interface is declared online.
<b>Metric</b>	Metric assigned to the interface.

### Edit MWAN Interface

To edit MWAN interface settings:

1. Go to Network > Load Balancing > Interfaces.
2. To modify an interface, select the interface and click **Edit**.
3. Modify the settings. see [Table 11-32](#).
4. Click **Save & Apply**.

**Table 11-32 MWAN Interface Configuration**

Parameters	Description
<b>Enabled</b>	Enable the Interface. <ul style="list-style-type: none"> <li>◆ No – Interface do not participate in Load Balancing.</li> <li>◆ Yes – Interface is enabled and can connect to Internet. Once enabled it can be tracked using ping configuration.</li> </ul>
<b>Initial State</b>	Offline – traffic goes via this interface only if the load balancer has checked the connection first. Online – the interface is marked as online immediately. Default is Online
<b>Internet Protocol</b>	Displays the internet protocol of the interface as IPv4 or IPv6.
<b>Tracking hostname or IP address</b>	IP Address to which the ping requests are sent from the interface to determine if the interface is up or down. Leave the field blank to assume the interface is always online.
<b>Tracking method</b>	Select the tracking method in use. Default is ping.
<b>Tracking source</b>	Select the tracking source to use. Options are Interface or Address
<b>Tracking reliability</b>	Enter the number of responses that must be received from tracking IP Addresses to consider the Interface as up.
<b>Ping count</b>	Enter the number of ping packets that will be sent. The default ping count is 5.
<b>Ping size</b>	Size of the ping request in bytes. Default value is 56.
<b>Max TTL</b>	Displays the Max Time to Live (Max TTL) timer value to be included in the packets that tells the recipient how long to hold or use the packet before expiring or discarding the packet or data.
<b>Check link quality</b>	Select to check link quality otherwise leave box unselected.



Parameters	Description
<b>Ping timeout</b>	Enter the time to wait for a response to ping request sent before declaring the interface unreachable. The wait time is in seconds. The default value depends on the interface used. Cellular will have different values to reduce data consumption.
<b>Ping interval</b>	Specifies the time in seconds between sending ping packets. The default ping interval is 5 seconds.
<b>Interface down</b>	The number of consecutive failed attempts after which the interface is declared down. The default value depends on the interface used. Cellular will have different values to reduce data consumption.
<b>Interface up</b>	The number of consecutive successful attempts to determine the reliability of the network connection through the interface. The default value depends on the interface used. Cellular will have different values to reduce data consumption.
<b>Metric</b>	Displays the Interface Metric. The route with least metric is considered as best route. The default metric assigned to the interface is 1. For load balancing between two interfaces, both the interfaces must have the same metric value on the Member configuration page.

## Members

### [Network](#) > [Load Balancing](#) > [Members](#)

MWAN Members are profiles corresponding to individual interfaces where you can set metric and weight.

To view and add MWAN members:

1. Go to [Network](#) > [Load Balancing](#) > [Members](#).
2. The MWAN Members table is displayed. See [Table 11-33](#).
3. To add a member profile, at the bottom of the table enter the name and click **Add**.
4. Enter the settings. See [Table 11-34](#).
5. Click **Save & Apply**.

**Table 11-33 MWAN Members**

Parameters	Description
<b>MWAN Members</b>	Displays the members and provides options to add, edit, or delete items from the table. <ul style="list-style-type: none"> <li>◆ Enter a name and click <b>Add</b> to add member.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> <li>◆ The buttons to the left of the Edit button can be used to reorder the items in the list. This does not change the configuration.</li> </ul>
<b>Name</b>	Displays the interface member notation number.
<b>Interface</b>	Displays the name of the interface associated with the member.

Parameters	Description
<b>Metric</b>	<p>Displays the metric assigned to the interface.</p> <p>The interface with the lowest metric has the highest priority and all data is always routed through it.</p> <p><b>Note:</b> <i>If two or more interfaces have same metric configured and that metric is lowest compared to other interfaces, then the data/load is balanced and data/load is distributed among the two interfaces in the ratio of the respective weight.</i></p>
<b>Weight</b>	Displays the weight assigned to the interface. Members with the same metric will distribute load based on the weight value.
<b>Add</b>	Enter the name of the new interface to be added.

### Edit MWAN Member

To edit an MWAN member:

1. Go to Network > Load Balancing > Members.
2. Select the member and click **Edit**.
3. Modify the configuration settings. See [Table 11-34](#).
4. Click **Save & Apply**.

**Table 11-34 MWAN Members Configuration**

Parameters	Description
<b>Interface</b>	Select the name of the interface.
<b>Metric</b>	<p>Enter the interface metric.</p> <p>The route with lowest metric is considered as best route.</p> <p>For load balancing between two interfaces, both the interfaces must have the same metric value.</p>
<b>Weight</b>	<p>Enter the interface weight.</p> <p>The default weight assigned to the interface is 2.</p> <p>For load balancing between two interfaces, both the interfaces must have the same metric value. The route with higher weight carries more traffic. Also the connections will be distributed amongst the interfaces with the same weight and not the actual data traffic.</p>

## Policies

### [Network](#) > [Load Balancing](#) > [Policies](#)

Policies define how traffic is routed through the different WAN interfaces. Policy consists of a member or group of members. If a policy has one member, traffic will only go out through that member. If a policy has more than one member, members within the policy with a lower metric have precedence and are used first. Members with the same metric will be load balanced based on the assigned weight values.

Policy can also be configured to use one member and then fail over to another.

To view and add MWAN policies:

1. Go to Network > Load Balancing > Policies.

2. The MWAN Policies table is displayed. See [Table 11-35](#).
3. To add a policy, at the bottom of the table enter the name and click **Add**.
4. Enter the settings. See [Table 11-36](#).
5. Click **Save & Apply**.

Table 11-35 MWAN Policy

Parameters	Description
<b>MWAN Policies</b>	Displays the policies and provides options to add, edit, or delete items from the table. <ul style="list-style-type: none"> <li>◆ Enter a name and click <b>Add</b> to add policy.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>Name</b>	Name of the policy. The name must be 15 characters or less, and may contain characters A-Z, a-z, 0-9, _ and no spaces. Policies must not share the same name as configured interfaces, members or rules.
<b>Members assigned</b>	Interface members to which the policy is applied.
<b>Last resort</b>	Displays the failover routing behavior when all WAN policy members are offline.
<b>Errors</b>	Displays if an error has occurred during the Policy configuration. Error messages are displayed as warnings.

### Edit MWAN Policy

To edit MWAN policy:

1. Go to Network > Load Balancing > Policies.
2. Select the policy and click **Edit**.
3. Modify the configuration settings. See [Table 11-36](#).
4. Click **Save & Apply**.

Table 11-36 MWAN Policy Configuration

Parameters	Description
<b>Member used</b>	Select the interface to apply the policy on for traffic passing through the interface.
<b>Last Resort</b>	Select the failover routing behavior when all WAN policy members are offline. Available options: <ul style="list-style-type: none"> <li>◆ unreachable (reject)</li> <li>◆ blackhole (drop)</li> <li>◆ default (use main routing table)</li> </ul>

## Rules

### Network > Load Balancing > Rules

A rule specifies what traffic to match and what policy to assign for that traffic.

The MWAN Rules page displays the rules and provides options to add, edit, or delete items from the table. The Rules page also lists key points to consider when configuring rules.

To add MWAN rules:

1. Go to Network > Load Balancing > Rules.
2. The MWAN Policies table is displayed. See [Table 11-37](#).
3. At the bottom of the Rules table, add a rule name and click **Add**.
4. Modify the configuration settings. See [Table 11-38](#).
5. Click **Save & Apply**.

**Table 11-37 MWAN Rules**

Parameters	Description
<b>MWAN Rules</b>	Displays the rules and provides options to add, edit, or delete items from the table. <ul style="list-style-type: none"> <li>◆ Enter a name and click <b>Add</b> to add rule.</li> <li>◆ Click <b>Edit</b> to modify a table entry.</li> <li>◆ Click <b>Delete</b> to delete an entry from the table.</li> </ul>
<b>Name</b>	Displays the rule name.
<b>Source address</b>	Displays the Source IP address.
<b>Source port</b>	Displays the Source port number.
<b>Destination address</b>	Displays the Destination IP address.
<b>Destination port</b>	Displays the Destination port number.
<b>Protocol</b>	Displays the protocols on which the rule is applicable.
<b>Policy assigned</b>	Policy to be applied to the rule.
<b>Errors</b>	Displays if an error has occurred during the rule configuration. Error messages are displayed as warnings.

### Edit MWAN Rule

To edit MWAN rules:

1. Go to Network > Load Balancing > Rules.
2. Select the rule name and click **Edit**.
3. Modify the configuration settings. See [Table 11-38](#).
4. Click **Save & Apply**.

**Table 11-38 MWAN Rules Configuration**

Parameters	Description
<b>Source address</b>	Enter the Source IP Address.

Parameters	Description
<b>Source Port</b>	Enter the Source Port number.
<b>Destination address</b>	Enter the Destination IP Address.
<b>Destination port</b>	Enter the Destination Port number.
<b>Protocol</b>	Select the protocols on which the rule is applicable.
<b>Sticky</b>	Select Yes to allow traffic from the same source IP address within the timeout limit to use the same WAN interface as the previous session. Otherwise, select No.
<b>Sticky timeout</b>	Enter the stickiness timeout value in seconds. If no value is entered, this defaults to 600.
<b>IPset</b>	Enter the name of the IPset rule. IPset lets you route traffic over WAN interfaces based on a set of IP addresses. When the ipset option is configured, the rule will match traffic directed at the given destination IP address to the ipset set.
<b>Logging</b>	Select Yes to enable firewall logging. The global load balancing logging setting must also be enabled. Otherwise, select No.
<b>Policy assigned</b>	Policy to be applied to the rule.

## Notification

### *Network > Load Balancing > Notification*

MWAN Notification lets you write custom MWAN actions, to be executed with each netifd hotplug interface event on interfaces for which MWAN is enabled. The file is interpreted as a shell script, and is preserved during sysupgrade.

The script must start with the line “#!/bin/sh” (without quotation marks).

Commented lines (lines starting with #) will not be executed.

Three main environment variables are passed to the script. They are described below:

```
# $ACTION
#     <ifup>           Is called by netifd and mwan3track
#     <ifdown>        Is called by netifd and mwan3track
#     <connected>     Is only called by mwan3track if tracking was
#                   successful
#     <disconnected> Is only called by mwan3track if tracking has failed

# $INTERFACE          Name of the interface which went up or down
#                   (e.g. "wan" or "wwan")

# $DEVICE             Physical device name which interface went up or down
#                   (e.g. "eth0" or "wwan0")
```

## 12: Bluetooth

The G520 series gateways support dual-mode Bluetooth BR/EDR (Classic Bluetooth) and BLE wireless connectivity. The Serial Port Profile (SPP) is included for Bluetooth BR/EDR. Bluetooth SPP allows two Bluetooth devices to connect and exchange serial data using the Bluetooth SPP profile for tunneling.

### Bluetooth Settings

The Bluetooth Settings page lets you configure Bluetooth settings and scan for and pair to Bluetooth devices.

#### Configure Bluetooth settings

To configure Bluetooth settings:

1. Go to Bluetooth > Settings.
2. Next to Bluetooth State, select or clear the box to enable or disable Bluetooth.
3. Enter the configuration settings. See [Table 12-1](#).

Table 12-1 Bluetooth Settings Configuration

Parameters	Description
<b>Bluetooth State</b>	Select to enable or clear to disable Bluetooth.
<b>Device name</b>	Displays the Bluetooth device name. The name can be edited. <i>Note: Changing the device name will disconnect any existing Bluetooth SPP master or slave connections.</i>
<b>Device Address</b>	Displays the Bluetooth device address.
<b>Paired devices</b>	Displays the paired devices. Click <b>Unpair</b> to unpair the device.
<b>Allow Discovery</b>	Select to allow the gateway to be visible to other Bluetooth devices during a scan. Clear the box if you do not want the gateway to be visible to other Bluetooth devices during a scan.
<b>Scan</b>	Click <b>Scan</b> to scan for nearby discoverable Bluetooth devices. A device must be discoverable in order to pair to it.

4. Click **Save & Apply**.

#### Scan for and Pair a Device

To scan for and pair to nearby devices:

1. On the Bluetooth Settings page under Scan, click **Scan**. The scan will take a few seconds to complete.
2. The Bluetooth Scan Result page shows the discovered devices and contains the following details:

Table 12-2 Bluetooth Scan Results

Parameters	Description
<b>Device Address</b>	Displays the Bluetooth device address.
<b>Device Name</b>	Displays the Bluetooth device name.
<b>Type</b>	Displays the Bluetooth service type that the device advertises. BR/EDR – the device advertises Bluetooth BR/EDR service type and supports SPP. BLE (Public or Random) – the device advertises BLE service type.
<b>RSSI</b>	Displays the signal strength of the Bluetooth device.
<b>Pair</b>	Click <b>Pair</b> to pair the device. The device that initiates the pairing, in this case the G520 series gateway, acts as the master device, and the paired device acts as the slave device.
<b>Refresh</b>	Click <b>Refresh</b> to run the scan again.
<b>Dismiss</b>	Click <b>Dismiss</b> to close this page.

3. Click **Pair**.

The paired device appears under Paired devices.

To unpair a device:

1. On the Bluetooth Settings page under Paired Devices, view the paired devices.
2. In the row containing the device to be unpaired, click **Unpair**.

## Bluetooth SPP

Bluetooth SPP page allows you to configure the Bluetooth SPP connection.

To use Bluetooth SPP, the Bluetooth device and the gateway must first be paired. The master device makes the RFCOMM connection. Once the Bluetooth connection is established, configure a tunnel on the Bluetooth SPP line to enable serial data transmission.

Either device in the Bluetooth connection can be the master or the slave, and either can be the tunnel server or client.

The following describes the Bluetooth SPP roles:

- ◆ Master – The master is the device that initiates the pairing with the other Bluetooth device. The master device can:
  - ◆ establish the RFCOMM connection with the paired device
  - ◆ disconnect the RFCOMM connection
  - ◆ be configured in tunnel accept (server) or tunnel connect (client) mode
- ◆ Slave – The slave is the device that is paired. The slave device can:
  - ◆ disconnect the RFCOMM connection
  - ◆ be configured in tunnel accept (server) or tunnel connect (client) mode

## Configure Bluetooth SPP Connection

To configure the Bluetooth SPP connection:

1. Select the Master 1 tab to configure the gateway as the Bluetooth master device, or select the Slave tab to configure the gateway as the Bluetooth slave device.
2. Enter the line configuration settings. See [Table 12-3](#).
3. To establish the connection, click the **Connect** button. To end a connection, click the **Disconnect** button.

**Table 12-3 Bluetooth SPP Line Configuration**

Parameters	Description
<b>Name</b>	Displays the line name. The name can be edited.
<b>State</b>	Select to enable or clear to disable the line.
<b>Protocol</b>	Select the protocol. <ul style="list-style-type: none"> <li>◆ <b>Tunnel</b> – the line will use tunnel over Bluetooth SPP connection. Tunnel will use the settings configured under the Server or Client tab to select tunnel accept or tunnel connect mode.</li> <li>◆ <b>None</b> – no protocol will be used.</li> </ul>
<b>Gap Timer</b>	Set the number of milliseconds to delay from the last character received before the driver forwards the received serial bytes. By default, the delay is four character periods at the current baud rate (minimum 1 msec). Gap timer range is 1 to 5000 milliseconds (default value is 4000 msec).
<b>Threshold</b>	Enter the number of threshold bytes which need to be received in order for the driver to forward received characters. Default value is 56 bytes.
<b>RFCOMM</b>	If Master 1 tab was selected, click <b>Connect</b> to establish the connection or <b>Disconnect</b> to end the connection. If Slave tab was selected, click <b>Disconnect</b> to end the connection.

## Configure Tunnel SPP Slave

To configure the Tunnel SPP Slave:

1. Go to Tunnel > Tunnel SPP Slave.
2. Enter the Accept configuration if the connection attempt originates from the network (see [Table 17-2, “Tunnel Accept Mode Configuration,” on page 204](#)), or enter the Connect configuration if the connection attempt originates from the gateway ([Table 17-3, “Tunnel Connect Mode Configuration,” on page 207](#))
3. Click **Save & Apply**.
4. On the remote device, configure the tunnel server or client settings appropriate for the connection.

## Configure Tunnel SPP Master

To configure the Tunnel SPP Master:

1. Go to Tunnel > Tunnel SPP Master.
2. Enter the Accept configuration if the connection attempt originates from the network (see



[Table 17-2, “Tunnel Accept Mode Configuration,” on page 204](#)), or enter the Connect configuration if the connection attempt originates from the gateway ([Table 17-3, “Tunnel Connect Mode Configuration,” on page 207](#))

3. Click **Save & Apply**.
4. On the remote device, configure the tunnel server or client settings appropriate for the connection.

## 13: ConsoleFlow

The G520 series gateways come integrated with ConsoleFlow® cloud platform to allow for the remote management of devices. To set up the ConsoleFlow client, you need to configure the following settings:

- ◆ ConsoleFlow Client – to connect to the ConsoleFlow cloud platform.
- ◆ Line 1 and Line 2 – to enable remote management and data access to your application or device attached on the serial line.

### Client

To configure the ConsoleFlow client:

1. Go to ConsoleFlow > Line 1 (or Line 2).  
This page displays the configuration and status for the ConsoleFlow client.
2. Enter the client and connection configuration information. See [Table 13-1](#).
3. Click **Save & Apply**.

**Table 13-1 ConsoleFlow Client Configuration**

ConsoleFlow Client	Description
<b>Enable</b>	Select to enable or clear to disable the ConsoleFlow client.
<b>Device ID</b>	Read only. Displays the gateway's Device ID. Device ID may be provisioned through Lantronix Provisioning Manager. <i>Note: Device ID can only be provisioned once. It will persist across resets.</i>
<b>Serial Number</b>	Read only. Displays the serial number of the device.
<b>Device Name</b>	Enter the ConsoleFlow Device Name.
<b>Device Description</b>	Enter the ConsoleFlow Device Description.
<b>Status Update Interval (in minutes)</b>	Enter the frequency that the gateway updates the device status to ConsoleFlow. The valid range is between 1 minute and 1440 minutes (1 day).
<b>Content Check Interval (in hours)</b>	Enter the frequency that the gateway checks ConsoleFlow for updates to configuration or firmware. The valid range is between 1 hour and 2160 hours (90 days).
<b>Apply Firmware Updates</b>	Select to allow firmware updates to be applied via ConsoleFlow. Enabled by default.
<b>Apply Configuration Updates</b>	Select the option to indicate when to apply configuration updates. ◆ <b>Always:</b> always apply configuration updates. ◆ <b>Never:</b> never apply configuration updates.
<b>Reboot After Update</b>	Automatically reboot device after configuration update.
<b>Active Connection</b>	Select the connection instance to use when connecting to ConsoleFlow. You can configure two connections. The configuration options for Connection 1 and Connection 2 are listed below.
<b>Connection 1/Connection 2</b>	

ConsoleFlow Client	Description
<b>Host</b>	Enter the host name or IP address of the ConsoleFlow server, used to register the device.
<b>Port</b>	Enter the ConsoleFlow port. Default: 443
<b>Secure Port</b>	Select to enable or clear to disable the ConsoleFlow client secure port 443.
<b>Validate Certificates</b>	Select to enable or clear to disable the validation of the ConsoleFlow server certificates. To validate certificates, both MQTT Security and Secure Port must be enabled.
<b>Local Port</b>	Local port for Consoleflow MQTT client. When configured, a total of 32 consecutive ports will be reserved.
<b>Enable MQTT</b>	Select to enable or clear to disable MQTT.
<b>MQTT Host</b>	Hostname or IP address of MQTT server.
<b>MQTT Port</b>	Enter the port number of the ConsoleFlow MQTT server. When configured, a total of 32 consecutive ports will be reserved.
<b>MQTT Security</b>	Select to enable SSL for MQTT.
<b>MQTT Local Port</b>	Local port for ConsoleFlow MQTT client. When configured, a total of 32 consecutive ports will be reserved.
<b>Use Proxy</b>	Select to enable the use of a proxy for this connection. If enabled, complete the proxy fields displayed under the Use Proxy field. Disabled by default.
<b>Proxy Type</b>	Proxy server type. The supported type is SOCKS5.
<b>Proxy Host</b>	Hostname or IP address of the proxy server to be used.
<b>Proxy Port</b>	Port of the proxy server to be used. Default port is <b>80</b> .
<b>User Name</b>	Username for the proxy server.
<b>Password</b>	Password for the proxy server.

## ConsoleFlow Line

Configure ConsoleFlow Line settings to enable remote management and data access to your application or device attached on the serial line. The gateway offers 2 lines for configuration.

To configure ConsoleFlow Line settings:

1. Go to ConsoleFlow > Line 1 (or Line 2).  
This page displays the configuration and status for ConsoleFlow Line.
2. Enter the following information. See [Table 13-2](#).
3. Click **Save & Apply**.

**Note:** The Serial line mode should be configured as None or Tunnel.

Table 13-2 ConsoleFlow Line

ConsoleFlow Line	Description
<b>Enable</b>	Select to enable or clear to disable the ConsoleFlow line client.
<b>Project Tag</b>	Enter the ConsoleFlow project tag string, as provided by the ConsoleFlow project administrator.
<b>Status Update Interval</b>	Enter the frequency in minutes that the gateway updates the device status to ConsoleFlow. The valid range is between 1 minute and 1440 minutes (1 day).
<b>Content Check Interval</b>	Enter the frequency in hours that the gateway checks ConsoleFlow for updates to configuration or firmware. The valid range is between 1 hour and 2160 hours (90 days).
<b>Command Delimiter</b>	Enter the command delimiter for attached serial devices. <i>Note: Send delimiter before command and after response is received.</i>

## 14: Discovery

Network discovery allows your computer to locate other computers and devices on the network. This setting also allows other computers to see your computer. If enabled, the device responds to auto-discovery messages on port 0x77FE.

### Query Port

This page displays the current query port statistics and the configuration option to enable or disable discovery.

Query port is enabled by default.

To enable or disable query port discovery:

1. Go to Discovery > Query Port.
2. Under Configuration, select or clear **Enable**.
3. Click **Save & Apply**.

## 15: Serial

The G520 series gateways offer two serial ports. Serial port 1 uses a standard RS-232 interface and Serial port 2 uses the RS-485 interface. All serial settings such as baud rate, parity, data bits, stop bits, and flow control apply to these lines.

For wiring configuration details for the RS-485 port in half-duplex mode, see [B: Power Cable Schematic](#).

The default serial settings:

- ◆ Baud rate: 115200
- ◆ Parity: None
- ◆ Data bits: 8
- ◆ Stop bits: 1
- ◆ Flow control: None

### Serial Line Statistics

Serial line statistics contain information on bytes, queued bytes, breaks, flow control, parity errors, framing errors, overrun errors, no Rx buffer errors, CTS input, RTS output, and DTR output.

To view line statistics, go to Serial and select Serial 1 or Serial 2.

### Serial Line Configuration

**Note:** Serial port 1 uses standard RS-232 interface and Serial port 2 uses RS-485 interface.

To configure Serial line settings:

1. Go to Serial > Serial 1 or Serial 2.
2. Enter the line configuration settings. See [Table 15-1](#).
3. Click **Save & Apply**.

Table 15-1 Serial Line Configuration

Parameters	Description
Name	Descriptive name.
Enabled	Select to enable the line on the serial port.
Interface	The interface of the Serial Port. <ul style="list-style-type: none"><li>◆ If Serial 1 is selected, the interface is RS232.</li><li>◆ If Serial 2 is selected, the interface options are RS485 Full-Duplex (default) or RS485 Half-Duplex.</li></ul>
Termination	Termination of the RS485 bus, if available.

Parameters	Description
<b>Is baudrate custom</b>	If using a custom baud rate, select the box and add a value between 2400 bps and 921600 bps.
<b>Baud Rate</b>	Select the desired baud rate from the drop-down list. Baud rate options: 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, 921600
<b>Parity</b>	Select parity from the drop-down list: <ul style="list-style-type: none"> <li>◆ None</li> <li>◆ Even</li> <li>◆ Odd</li> </ul>
<b>Data Bits</b>	Select data bits from the drop-down list: <ul style="list-style-type: none"> <li>◆ 7</li> <li>◆ 8</li> </ul>
<b>Stop Bits</b>	Select the stop bits from the drop-down list: <ul style="list-style-type: none"> <li>◆ 1</li> <li>◆ 2</li> </ul>
<b>Flow Control</b>	Select the flow control from the drop-down list: <ul style="list-style-type: none"> <li>◆ None</li> <li>◆ Hardware</li> <li>◆ Software</li> </ul>
<b>Gap Timer</b>	Set the number of milliseconds to delay from the last character received before the driver forwards the received serial bytes. By default, the delay is four character periods at the current baud rate (minimum 1 msec). Gap timer range is 1 to 5000 milliseconds (default value is 4000 msec).
<b>Threshold</b>	Set the number of threshold bytes which need to be received in order for the driver to forward received characters. Default value is 56 bytes.
<b>Mode</b>	Select the mode of serial communication as determined by the modes available on the gateway model. <ul style="list-style-type: none"> <li>◆ None – can be used if ConsoleFlow line is configured</li> <li>◆ Tunnel – (see <a href="#">Chapter 17: Tunnel</a> )</li> <li>◆ Tunnel/Modbus RTU to Modbus TCP – (see <a href="#">Tunnel Modbus RTU to Modbus TCP</a>)</li> <li>◆ Managed Device</li> <li>◆ DLMS Client – (see <a href="#">GPS</a>)</li> <li>◆ DNP3 – (see <a href="#">Modbus RTU to DNP3</a>)</li> <li>◆ Modbus Master – (see <a href="#">Modbus Master</a>)</li> <li>◆ IEC 101 to 104 – (see <a href="#">IEC 101 to 104</a>)</li> </ul>

## 16: SSL

Secure Sockets Layer (SSL) is a protocol that creates an encrypted connection between devices. It also provides authentication and message integrity services. SSL is used widely for secure communication to a Web server, and for wireless authentication.

SSL certificates identify the G520 series gateway to peers and are used with some methods of wireless authentication. Provide a name at upload time to identify certificates on the G520 series gateway.

You can upload Certificate and Private key combinations, obtained from an external Certificate Authority (CA), to the G520 series gateway. The G520 series gateway can also generate self-signed certificates with associated private keys.

### Credentials

The G520 series gateway can generate self-signed certificates and their associated keys for both RSA and DSA certificate formats. When you generate certificates, assign them a credential name to help identify them on the G520 series gateway. Once you create your credentials, then configure them with the desired certificates.

To configure a new credential:

1. Go to SSL > Credentials.
2. Type the name for your credential in the Credential Name field.
3. Enter the fields under Upload Certificate (see [Table 16-1](#)) or Create New Self-Signed Certificate (see [Table 16-2](#)).
4. Click **Save & Apply**. The process to create a self-signed certificate can take up to 30 seconds, depending on the length of the key.

The newly created credential is displayed at the top of the SSL Credentials page.

To view a credential:

1. Go to SSL > Credentials.
2. Under Current Credentials, click the name of the credential to view its details.

To delete a credential:

1. Go to SSL > Credentials.
2. Under Current Credentials, click the **Delete** button next to the name of the credential.

**Table 16-1 SSL Credentials - Upload Certificate**

Field	Description
SSL Certificate	Click the <b>Select file...</b> button to browse to the SSL certificate to be uploaded. RSA or DSA certificates are allowed.



Field	Description
<b>Certificate Type</b>	Select the certificate type to upload: <ul style="list-style-type: none"> <li>◆ PEM</li> <li>◆ PKCS7</li> <li>◆ PKCS12</li> </ul> For PKCS certificates, enter a password. Ensure that the certificate is formatted properly with a valid open and close tag.
<b>SSL Private Key</b>	Click the <b>Select file...</b> button to browse to the SSL private key to be uploaded. The key must belong to the entered certificate. Ensure that the private key associated to the selected certificate and that it is formatted properly with a valid open and close tag.
<b>Key Type</b>	Select the key type being uploaded: <ul style="list-style-type: none"> <li>◆ PEM</li> <li>◆ Encrypted PEM</li> <li>◆ PKCS12</li> </ul> For encrypted PEM or PKCS12 key types, enter a password.

Table 16-2 SSL Credentials - Create Self-Signed Certificate

Field	Description
<b>Country (2 Letter code)</b>	Enter the 2 letter code for the country where the organization is located. This is a two-letter ISO code (e.g., "US" for the United States).
<b>State/Province</b>	Enter the state or province where the organization is located.
<b>Locality (City)</b>	Enter the city where the organization is located.
<b>Organization</b>	Enter the organization name to which the G520 series gateway belongs.
<b>Organization Unit</b>	Enter the organization unit which specifies the department or organization to which the G520 series gateway belongs.
<b>Common Name</b>	Enter a network name for the gateway when installed in the user's network (usually the fully qualified domain name). It is identical to the name that is used to access the gateway with a web browser without the prefix <code>http://</code> . In case the name given here and the actual network name differ, the browser will pop up a security warning when the gateway is accessed using HTTPS.
<b>Expires</b>	Type the date that the self-signed certificate expires in <b>mm/dd/yyyy</b> format.
<b>Type</b>	Select <b>RSA</b> , <b>DSA</b> , or <b>ECDSA</b> .
<b>Key length</b>	Select the key length in bits.

## Trusted Authorities

One or more authority certificates are used to verify the identity of a peer. Authority certificates are used with some wireless authentication methods. These certificates do not require a private key.

To upload an authority certificate:

1. Go to SSL > Trusted Authorities.

2. Enter the Upload Certificate fields. See [Table 16-3](#).
3. Click **Save & Apply**.

Table 16-3 SSL Trusted Authority

Field	Description
<b>SSL Certificate</b>	Click the <b>Select file...</b> button to browse to an existing SSL authority certificate. RSA or DSA certificates are allowed. The format of the authority certificate can be PEM or PKCS7. PEM files must start with “-----BEGIN CERTIFICATE-----” and end with “-----END CERTIFICATE-----”. Some certificate authorities add comments before and/or after these lines. Those comments must be deleted before upload.
<b>Certificate Type</b>	Select the certificate type through the drop-down list. This field may automatically update, depending upon extension of the certificate entered.
<b>Clear</b>	Click to clear the fields.

To delete an existing certificate authority:

1. Go to SSL > Trusted Authorities.
2. Under Current Certificate Authorities, click the **Delete** button next to the name of the authority.

## 17: Tunnel

Tunneling allows serial devices to communicate over a network without being aware of the devices that establish the network connection between them. The Tunnel settings allow you to configure how the serial network tunneling operates. Tunneling is available on serial lines. The connections on one serial line are separate from those on another serial port.

### Tunnel Statistics

Tunnel statistics contains data counters, error counters, connection time and connection information. Aggregate and individual connection statistics are displayed.

To view tunnel statistics, go to Tunnel and select Tunnel 1, Tunnel 2, Tunnel SPP Slave, or Tunnel SPP Master.

### Tunnel Modbus RTU to Modbus TCP

The G520 series gateway acts as a converter between a Modbus RTU and a Modbus TCP device. Modbus RTU polls the data from the Modbus slave and sends it to the Modbus master using Modbus TCP.

To use this feature, configure the serial interface and TCP interface. You can use either the RS-232 or RS-485 interface.

To configure the serial interface:

1. Go to Serial and select Serial 1 (RS232) or Serial 2 (RS485).
2. Configure the serial port settings.
3. Select Mode as Tunnel/Modbus RTU to Modbus TCP.
4. Click **Save & Apply**.

To configure the TCP interface:

1. Go to Tunnel and select Tunnel 1 or Tunnel 2.
2. Under Modbus RTU to Modbus TCP, select **Enable** and then enter the configuration settings. See [Table 17-1](#)
3. Click **Save & Apply**.

Table 17-1 Tunnel for Modbus RTU to Modbus TCP

Field	Description
Enable	Select to enable and configure the Modbus RTU to Modbus TCP settings.
Protocol	TCP option is selected.

Field	Description
<b>Mode</b>	<ul style="list-style-type: none"> <li>◆ <b>Server</b> - the gateway acts as a server and listens for the TCP connection from external Modbus master. TCP Port is required.</li> <li>◆ <b>Client</b> - the gateway acts as a TCP client and sends the TCP connection request to the external Modbus master. IP address and TCP port of the Modbus master is required</li> </ul>
<b>IP</b>	IP address of the external Modbus master on the LAN or WAN interface.
<b>Port</b>	Modbus TCP port number that the server is listening on. The default Modbus TCP port number is 502.
<b>Backup Server Enable</b>	Select to configure a backup Modbus master. Enter the IP address and port number.
<b>Socket Timeout Enable</b>	Select to configure socket timeout. Enter the Inactivity Timeout in seconds.

## Tunnel Accept

In Tunnel Accept mode, the G520 series gateway listens (waits) for incoming connections from the network. Accept mode can be configured on Tunnel 1, Tunnel 2, Tunnel SPP Slave, or Tunnel SPP Master.

A remote node on the network initiates the connection. The configurable local port is the port the remote device connects to for this connection. There is no remote port or address. Supported serial lines and associated local port numbers progress sequentially in matching value. For instance, the default local ports are 10001 for serial line 1, 1002 for serial line 2, 10003 for Bluetooth SPP Slave, and 10004 for Bluetooth SPP Master. Serial data can still be received while waiting for a network connection, keeping in mind serial data buffer limitations.

To configure Accept mode:

1. Go to Tunnel > Tunnel 1, Tunnel 2, Tunnel SPP Slave, or Tunnel SPP Master.
2. Under Accept, enter the accept mode configuration settings. See [Table 17-2](#).
3. Click **Save & Apply**.

**Table 17-2 Tunnel Accept Mode Configuration**

Field	Description
<b>Mode</b>	Set the method used to start the tunnel in Accept mode. Choices are: <ul style="list-style-type: none"> <li>◆ <b>Disable</b> - do not accept an incoming connection.</li> <li>◆ <b>Always</b> - accept an incoming connection (<i>default</i>).</li> <li>◆ <b>Any Character</b> - start waiting for an incoming connection when any character is read on the serial line.</li> <li>◆ <b>Start Character</b> - start waiting for an incoming connection when the start character for the selected tunnel is read on the serial line.</li> </ul>

Field	Description
<b>Local Port</b>	Set the port number for use as the network local port. The default local port number correlates with the tunnel instance: <ul style="list-style-type: none"> <li>◆ Tunnel 1: 10001</li> <li>◆ Tunnel 2: 10002</li> <li>◆ Tunnel SPP Slave: 10003</li> <li>◆ Tunnel SPP Master: 10004</li> </ul>
<b>Protocol</b>	Select the desired security protocol: <ul style="list-style-type: none"> <li>◆ SSL</li> <li>◆ TCP (<i>default protocol</i>)</li> <li>◆ TCP AES</li> <li>◆ Telnet</li> </ul> Configure the protocol fields as determined by the protocol selection.
<b>Secure Protocols</b>	When using SSL, select the secure protocols and the SSL credential. Protocol options are: <ul style="list-style-type: none"> <li>◆ SSL3</li> <li>◆ TLS1.0</li> <li>◆ TLS1.1 (default selected)</li> <li>◆ TLS1.2 (default selected)</li> <li>◆ TLS1.3 (default selected)</li> </ul>
<b>TCP Keep Alive</b>	The TCP keep alive time is the time in which probes are periodically sent to the other end of the connection to ensure the other side is still connected. Enter the TCP Keep Alive time in milliseconds. Set to 0 to disable TCP Keep Alive, and blank the field to restore the default.
<b>TCP Keep Alive Interval</b>	Enter the time, in milliseconds, to wait between Keep Alive probes in order to keep the TCP connection up during idle transfer periods. Blank the field to restore the default.
<b>TCP Keep Alive Probes</b>	Enter the number of TCP Keep Alive probes to send before closing the connection if no response is received. The probes are sent after the initial TCP Keep Alive probe is sent. Valid values are between 1 and 16. Blank the field to restore the default.
<b>AES Encrypt Key</b>	Enter the AES Encrypt Key. This configuration field becomes available when the TCP AES protocol is selected.
<b>AES Encrypt Key Type</b>	Select <b>Text</b> or <b>Hexadecimal</b> to indicate format. This configuration field becomes available when the TCP AES protocol is selected.
<b>AES Decrypt Key</b>	Enter the AES Decrypt Key. This configuration field becomes available when the TCP AES protocol is selected.
<b>AES Decrypt Key Type</b>	Select <b>Text</b> or <b>Hexadecimal</b> to indicate format. This configuration field becomes available when the TCP AES protocol is selected.

Field	Description
<b>Initial Send</b>	<p>Enter the <b>Initial Send</b> data to be sent out the network upon connection establishment before any data from the Line. It may contain one or more <b>Directives</b> of the form <code>%&lt;char&gt;</code>.</p> <p>The Initial Send string can be entered in <b>Text</b> or <b>Binary</b> form.</p> <p>The Binary form allows square braces <code>[]</code> to enclose one or more character designations separated by commas. Use straight decimal numbers up to 255 or hexadecimal numbers prefixed with <code>0x</code> up to <code>0xFF</code> within the square braces. To specify an open brace in binary mode, use two in a row.</p> <p>Example The selection (in binary mode): <code>AB [255 , 0xFF] C [ [D]</code> results in a string containing binary values where the dots appear: <code>AB . . . C [D]</code></p> <p><b>Directives</b></p> <ul style="list-style-type: none"> <li>◆ <code>%i</code> local IP address</li> <li>◆ <code>%m</code> MAC address</li> <li>◆ <code>%n</code> network interface name</li> <li>◆ <code>%p</code> local port</li> <li>◆ <code>%s</code> serial number</li> <li>◆ <code>%%</code> %</li> </ul>
<b>Initial Send Type</b>	<p>The format of the initial send data.</p> <ul style="list-style-type: none"> <li>◆ <b>Text</b></li> <li>◆ <b>Binary</b></li> </ul>
<b>Flush Serial</b>	<p>Set whether the serial line data buffer is flushed upon a new network connection. Choices are:</p> <ul style="list-style-type: none"> <li>◆ <b>Enabled</b> – serial data buffer is flushed on network connection</li> <li>◆ <b>Disabled</b> – serial data buffer is not flushed on network connection (<i>default</i>)</li> </ul>
<b>Block Serial</b>	<p>Set whether Block Serial is enabled for debugging purposes. Choices are:</p> <ul style="list-style-type: none"> <li>◆ <b>Enabled</b> – incoming characters from the serial line will not be forwarded to the network. Instead, they will be buffered and will eventually flow off the serial line if hardware or software flow control is configured.</li> <li>◆ <b>Disabled</b> – this is the default setting; incoming characters from the serial line are sent to the network. Any buffered characters are sent first.</li> </ul>
<b>Block Network</b>	<p>Set whether Block Network is enabled for debugging purposes. Choices are:</p> <ul style="list-style-type: none"> <li>◆ <b>Enabled</b> – incoming characters from the network will not be forwarded to the serial line. Instead, they will be buffered and will eventually flow off the network side.</li> <li>◆ <b>Disabled</b> – this is the default setting; incoming characters from the network are sent to the serial line. Any buffered characters are sent first.</li> </ul>
<b>Password</b>	<p>The password can be up to 31 characters in length. Valid characters are alphanumeric characters and punctuation. When set, clients must send the correct password string to the device within 30 seconds from opening network connection in order to enable data transmission.</p> <p>The password sent to the device must be terminated with one of the following:</p> <ul style="list-style-type: none"> <li>◆ <code>0A</code> (Line Feed)</li> <li>◆ <code>00</code> (Null)</li> <li>◆ <code>0D 0A</code> (Carriage Return/Line Feed)</li> <li>◆ <code>0D 00</code> (Carriage Return/Null)</li> </ul> <p>If <b>Prompt for Password</b> is selected and a password is configured, the user will be prompted for the password upon connection.</p>

## Tunnel Connect

In Connect mode, the G520 series gateway continues to attempt an outgoing connection on the network until established. If the connection attempt fails or the connection drops, then it retries after a timeout. The remote node on the network must listen for the Connect mode's connection.

For Connect mode to function, it must be enabled, have a remote station (node) configured, and a remote port configured (TCP or UDP). When established, Connect mode is always on. Enter the remote station as an IPv4 or IPv6 address or DNS name. The gateway will not make a connection unless it can resolve the address. For Connect mode using UDP, the gateway accepts packets from any device on the network. It will send packets to the last device that sent it packets.

**Note:** *The port in Connect mode is not the same port as the one configured in Accept mode. The TCP keep alive time is the time in which probes are periodically sent to the other end of the connection. This ensures the other side is still connected.*

To configure Tunnel Connect mode:

1. Go to Tunnel > Tunnel 1, Tunnel 2, Tunnel SPP Slave, or Tunnel SPP Master.
2. Under Connect, enter the connect mode configuration settings. See [Table 17-3](#).
3. Under Connect Host, configure 1 to 4 hosts. See [Table 17-4](#).
4. Click **Save & Apply**.

**Table 17-3 Tunnel Connect Mode Configuration**

Field	Description
<b>Connect Mode</b>	Set the method to be used to attempt a connection to a remote host or device. Choices are: <ul style="list-style-type: none"> <li>◆ <b>Disable</b> – an outgoing connection is never attempted. (<i>default</i>)</li> <li>◆ <b>Always</b> – a connection is attempted until one is made. If the connection gets disconnected, the gateway retries until it makes a connection.</li> <li>◆ <b>Any Character</b> – a connection is attempted when any character is read on the serial line.</li> <li>◆ <b>Start Character</b> – a connection is attempted when the start character for the selected tunnel is read on the serial line.</li> </ul>
<b>Host Mode</b>	If more than one host is configured, set the method to be used to access multiple hosts. <p><b>Sequential</b> – A tunnel will connect to hosts in sequential order. Host 1 will be attempted first. If that fails, it will proceed in order to Host 2, 3, and then 4. When a connection drops, the cycle starts again with Host 1 and proceeds in order. (<i>default setting</i>)</p> <p><b>Simultaneous</b> – A tunnel will connect to all hosts accepting a connection. Simultaneous connections occur at the same time to all listed hosts. The gateway supports a maximum of 4 host connections.</p>
<b>Local Port</b>	Enter an alternative local port. The local port is set to <Random> by default but can be overridden. Blank the field to restore the default.
<b>Reconnect Timer</b>	Set the value of the reconnect timeout (in milliseconds) for outgoing connections established by the gateway. Valid range is 1 to 65535 milliseconds. Default is 15000.

Field (continued)	Description
<b>Flush Serial</b>	Set whether the serial line data buffer is flushed upon a new network connection. Choices are: <ul style="list-style-type: none"> <li>◆ <b>Enabled</b> – serial data buffer is flushed on network connection</li> <li>◆ <b>Disabled</b> – serial data buffer is not flushed on network connection (<i>default</i>)</li> </ul>
<b>Block Serial</b>	Set whether Block Serial is enabled for debugging purposes. Choices are: <ul style="list-style-type: none"> <li>◆ <b>Enabled</b> – If Enabled, incoming characters from the Serial Line will not be forwarded to the network. Instead, they will be buffered and will eventually flow off the serial line if hardware or software flow control is configured.</li> <li>◆ <b>Disabled</b> – this is the default setting; incoming characters from the serial line are sent on into the network. Any buffered characters are sent first.</li> </ul>
<b>Block Network</b>	Set whether Block Network is enabled for debugging purposes. Choices are: <ul style="list-style-type: none"> <li>◆ <b>Enabled</b> – If Enabled, incoming characters from the network will not be forwarded to the serial line. Instead, they will be buffered and will eventually flow off the network side.</li> <li>◆ <b>Disabled</b> – this is the default setting; incoming characters from the network are sent on into the serial line. Any buffered characters are sent first.</li> </ul>

## Hosts

The Connect mode supports up to 4 hosts. Hosts may be accessed sequentially or simultaneously.

### Notes:

*Configure the keep alive timeout to be larger than the user timeout.*

- ◆ *If the keep alive time expires, the user timeout is expired, and there are probes in flight, the connection will be reset. For this reason, it is recommended that if keep alive is used in conjunction with the user timeout, the keep alive timeouts be larger than the user timeout.*
- ◆ *If it is smaller, what will typically be seen is that the initial probe will be sent, then at the interval where the next probe would normally be sent, the connection will be reset, with no additional probes sent. Also note that in these cases: if the keep alive timer is significantly smaller than the user timeout, probes will continue to be sent for an unreachable host until the user timeout expires.*

*The user timeout will not be an exact limit; in practice, it will always take somewhat longer for the connection to be closed.*

- ◆ *If there is data in flight when the TCP retransmission timeout kicks in, the user timeout is checked as a limiting condition only when the timer expirations would normally be checked during RTO handling. The longer the user timeout is, the more likely it will expire between exponentially slower retransmissions, and the connection will not experience an error until the next retransmission timeout is checked.*
- ◆ *The user timeout expiration during retransmission returns an error to the application; it does not automatically reset the connection as happens with the keep alive timeout. It is up to the application (e.g., tunneling) to close the connection (this happens almost immediately with tunneling).*



Table 17-4 Host Configuration

Host Field	Description
<b>Address</b>	Enter the destination IP address or DNS address for the connection.
<b>Port</b>	Enter the TCP or UDP port number on the target host for the connection.
<b>Protocol</b>	Select the desired security protocol. <ul style="list-style-type: none"> <li>◆ SSL</li> <li>◆ TCP</li> <li>◆ TCP AES</li> <li>◆ Telnet</li> <li>◆ UDP</li> <li>◆ UDP AES</li> </ul> Configure the remaining protocol fields as determined by the protocol selection.
<b>Secure Protocols</b>	When using SSL, select the secure protocols and the SSL credential. Protocol options are: <ul style="list-style-type: none"> <li>◆ SSL3</li> <li>◆ TLS1.0</li> <li>◆ TLS1.1 (default selected)</li> <li>◆ TLS1.2 (default selected)</li> <li>◆ TLS1.3 (default selected)</li> </ul>
<b>TCP Keep Alive</b>	Enter the time, in milliseconds, the gateway waits during a silent TCP connection before the first Keep Alive probe is sent to the remote host in order to keep the TCP connection up during idle transfer periods. Set to 0 to disable TCP Keep Alive, and blank the field to restore the default.
<b>TCP Keep Alive Interval</b>	Enter the time, in milliseconds, to wait between Keep Alive probes in order to keep the TCP connection up during idle transfer periods. Blank the display field to restore the default.
<b>TCP Keep Alive Probes</b>	Enter the number of TCP Keep Alive probes to send before closing the connection if no response is received. The probes are sent after the initial TCP Keep Alive probe is sent. Valid values are between 1 and 16. Blank the field to restore the default.
<b>TCP User Timeout</b>	Specify the amount of time the TCP segments will be retransmitted before the connection is closed.
<b>AES Encrypt Key</b>	Enter the AES Encrypt Key. This configuration field becomes available when the TCP AES or UDP AES protocol is selected.
<b>AES Encrypt Key Type</b>	Select <b>Text</b> or <b>Hexadecimal</b> to indicate format
<b>AES Decrypt Key</b>	Enter the AES Decrypt Key. This configuration field becomes available when the TCP AES or UDP AES protocol is selected.
<b>AES Decrypt Key Type</b>	Select <b>Text</b> or <b>Hexadecimal</b> to indicate format
<b>Initial Send</b>	Enter the Initial Send character to be sent out the network upon connection establishment before any data from the line. It may contain one or more <b>Directives</b> of the form %<char>. This configuration field becomes available when the TCP, UDP, or UDP AES protocol is selected.
<b>Initial Send Type</b>	Select <b>Text</b> or <b>Hexadecimal</b> to indicate format.
<b>Credentials</b>	If SSL is the selected protocol, select an existing credential from the drop-down list. Go to SSL > Credentials to create, view, or edit SSL credentials.
<b>Validate Certificate</b>	Select to enable validation of the SSL certificate on the server. This configuration field becomes available when the SSL protocol is selected.

## Connecting Multiple Hosts

The Connect mode supports up to 4 hosts. Hosts may be accessed sequentially or simultaneously.

- ◆ **Sequential** – A tunnel will connect to hosts in sequential order. The host specified as Host 1 will be attempted first. If that fails, it will proceed to Host 2, 3, and 4. When a connection drops, the cycle starts again with Host 1 and proceeds in order. Sequential is the default Host mode.
- ◆ **Simultaneous** – A tunnel will connect to all hosts accepting a connection. Simultaneous connections occur at the same time to all listed hosts. The gateway can support a maximum of 4 connections.

## Tunnel Disconnect

Disconnect specifies the optional conditions for disconnecting any tunnel connection that may be established. If any of these conditions are selected but do not occur and the network disconnects the tunnel, a Connect mode connection will attempt to reconnect. However, if none of these conditions are selected, a closure from the network is taken as a disconnected host.

To configure Disconnect settings:

1. Go to Tunnel > Tunnel 1, Tunnel 2, Tunnel SPP Slave, or Tunnel SPP Master.
2. Under Disconnect, enter the configuration settings.
3. Click **Save & Apply**.

**Table 17-5 Tunnel Disconnect Configuration**

Field	Description
<b>Stop Character</b>	Enter the Stop Character which, when received on the serial line, disconnects the tunnel. The Stop Character may be designated as a single printable character or as a control character. Control characters may be input in any of the following forms: <control>J or 0xA(hexadecimal) or \10 (decimal). To disable the Stop Character, blank the field, which sets it to <None>.
<b>Flush Stop Character</b>	Set whether to flush the stop character when the tunnel is disconnected. Options: ◆ <b>Enabled</b> ◆ <b>Disabled</b> (default)
<b>Timeout</b>	Enter the number of milliseconds a tunnel may be idle before disconnection. To disable the timeout, set the field to zero (0).
<b>Flush Serial Data</b>	Set whether to flush the serial line when the tunnel is disconnected. Choices are: ◆ <b>Enabled</b> ◆ <b>Disabled</b> (default)

## A: Compliance Information

(According to ISO/IEC Guide and EN 45014)

### Manufacturer's Name & Address:

Lantronix, Inc. 48 Discovery, Suite 250, Irvine, CA 92618 USA

### Product Family:

G520 Series

Conforms to the following standards or other normative documents:

**Table A-1 Regional Certifications**

Country /	Specification
USA	FCC 47 CFR part 15 Subpart B FCC 47 CFR part 15 Subpart 22H, 22E, 27 & 90S FCC 47 CFR Part 15 Subpart E
Canada	ISED RSS-130 Issue 2 RSS-132 Issue 3 RSS-133 Issue 6 RSS 139 Issue 3 RSS195 Issue 2 RSS-199 RSS-247 Issue 2 RSS-GEN Issue 5
EU	EU Declaration of Conformity See <a href="#">Figure A-1</a> .
Australia, New Zealand	AS/NZS CISPR 32:2015
Safety	UL/EN 60950-1 UL/EN 62368-1 CAN/CSA C22.2 62368-1-14 CAN/CSA C22.2 60950-1-07
Cellular Certification	PTCRB, AT&T

**Table A-2 Country Transmitter IDs**

Country	Specification
USA FCC ID	Cellular Module: N7NEM7455 Wi-Fi Module (pending): SQG-60SIPT
Canada IC ID	Cellular Module: 2417C-EM7455 Wi-Fi Module (pending): 3147A-602230C

---

## FCC Statement

### Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**Operations are restricted to indoor usage only.**

### Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### Antenna Installation

- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

---

## ISED Statement

This device complies with RSS-247 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-247 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

### **Radiation Exposure Statement:**

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### **Déclaration d'exposition aux radiations:**

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

### **This device is intended only for use under the following conditions:**



- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

### **Cet appareil est conçu uniquement pour les intégrateurs OEM dans les conditions suivantes: (Pour utilisation de dispositif module)**

- 1) L'antenne doit être installée de telle sorte qu'une distance de 20 cm est respectée entre l'antenne et les utilisateurs, et
- 2) Le module émetteur peut ne pas être coïmplanté avec un autre émetteur ou antenne.

## EU Declaration of Conformity

Figure A-1 EU Declaration of Conformity


  


**EU DECLARATION OF CONFORMITY**

**Manufacturer's Name:** LANTRONIX, INC.  
**Manufacturer's Address:** 7535 Irvine Center Drive, Suite 100, Irvine, CA. 92618. USA

**Product Type:** Gateway  
**Product Family:** G520 Series  
**Model name:** G526GP12S  
**Rated:** 10.8-60 VDC  
**Intended use:** Commercial installations, indoor use

**Manufacturer's Quality System:**



ISO 9001:2015 Certificate No. 74 300 4282 TÜV Rheinland

**Applicable EU Directives:**

**Low Voltage Directive (2014/35/EU)**

- EN 62368-1:2020+A11:2020

**EMC Directive (2014/30/EU)**

- EN 301 489-1 V2.2.3 (2019-11)
- EN 301 489-17 V3.2.4 (2020-09)
- EN 301 489-19 V2.1.1 (2019-04)
- Draft EN 301 489-52 V1.1.2 (2020-12)
- EN 55032:2015+A11: 2020, Class B
- EN 61000-3-2:2019
- EN 61000-3-3:2013+A1:2019
- EN 55035:2017+A11:2020

**RF Radio Directive (2014 / 53 / EU)**

- EN 301 908-1 V13.1.1 (2019-11)
- EN 301 908-2 V13.0.1
- EN 301 908-13 V13.1.1
- EN 301 511 V12.5.1 (2017-03)
- EN 300 328 V2.2.2 (2019-07)
- EN 301 893 V2.1.1 (2017-05)
- EN 303 413 V1.2.1 (2021-04)

**Healthy Directive (2014 / 53 / EU)**

- EN 62311:2020

**RoHS**

- 1) 2011/65/EU Restriction of the use of Hazardous Substances in EEE (RoHS)
- 2) 2015/863/EU Change of Annex II from 2011/65/EU
- 3) Directive 2018/736/EU and 2018/741/EU

- EN 63000-2018

**Statement of Conformity:** The product specified above complies with applicable EU directive referenced, including the application of sound engineering practice.

Signature: \_\_\_\_\_ Date: April 6, 2022

Name: Fathi Hakam Title: VP of Engineering

CERT-00241 rev A

## EU Statements

Table A-3 EU Statements

Code	Language	Statement
bg	Bulgarian	<p>Lantronix, Inc., декларира, че този G520 Series отговаря на основните изисквания и други приложими разпоредби на Директива 2014/53 / ЕС.</p> <p>Пълният текст на декларацията на ЕС за съответствие е достъпен на следния интернет адрес: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Известие на ЕС за ограничения при употреба: Това устройство е ограничено само за вътрешна употреба. Може да не се работи на открито.</p>
cs	Česky [Czech]	<p>Lantronix, Inc. tímto prohlašuje, že tento G520 Series je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 2014/53/EU.</p> <p>Úplné znění ES prohlášení o shodě je k dispozici na této internetové adrese: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Oznámení EU o omezení používání: Toto zařízení je omezeno pouze na použití uvnitř. Nesmí být provozován venku.</p>
da	Dansk [Danish]	<p>Undertegnede Lantronix, Inc. erklærer herved, at følgende udstyr G520 Series overholder de væsentlige krav og øvrige relevante krav i direktiv 2014/53/EU.</p> <p>Den fulde tekst til EU-overensstemmelseserklæringen er tilgængelig på følgende internetadresse: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EU-meddelelse om begrænsninger i brug: Denne enhed er kun begrænset til indendørs brug. Det betjenes måske ikke udendørs.</p>
de	Deutsch [German]	<p>Hiermit erklärt Lantronix, Inc., dass sich das Gerät G520 Series in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2014/53/EU befindet.</p> <p>Der vollständige Text der EU-Konformitätserklärung ist unter folgender Internetadresse abrufbar: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EU-Hinweis zu Nutzungsbeschränkungen: Dieses Gerät darf nur in Innenräumen verwendet werden. Es darf nicht im Freien betrieben werden.</p>

Code	Language	Statement
et	Eesti [Estonian]	<p>Käesolevaga kinnitab Lantronix, Inc. seadme G520 Series vastavust direktiivi 2014/53/EU põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.</p> <p>EL-i vastavusdeklaratsiooni täielik tekst on saadaval järgmisel Interneti-aadressil: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EL-i teade kasutuspiirangute kohta: seda seadet saab kasutada ainult siseruumides. Seda ei tohi õues kasutada.</p>
en	English	<p>Hereby, Lantronix, Inc., declares that this G520 Series is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.</p> <p>The full text of the EU declaration of conformity is available at the following internet address: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EU Notice of Restrictions on Use: This device is limited to indoor use only. It may not be operated outdoors.</p>
es	Español [Spanish]	<p>Por medio de la presente Lantronix, Inc. declara que el G520 Series module cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 2014/53/EU.</p> <p>El texto completo de la declaración de conformidad de la UE está disponible en la siguiente dirección de Internet: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Aviso de restricciones de uso de la UE: este dispositivo está limitado solo para uso en interiores. No puede ser operado al aire libre.</p>
el	Ελληνική [Greek]	<p>ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Lantronix, Inc. ΔΗΛΩΝΕΙ ΟΤΙ G520 Series ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 2014/53/EU.</p> <p>Το πλήρες κείμενο της δήλωσης συμμόρφωσης της ΕΕ διατίθεται στην ακόλουθη διεύθυνση διαδικτύου: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Ειδοποίηση της ΕΕ για περιορισμούς χρήσης: Η συσκευή αυτή περιορίζεται μόνο σε εσωτερικούς χώρους χρήσης. Μπορεί να μην λειτουργεί σε εξωτερικούς χώρους.</p>



Code	Language	Statement
fr	Français [French]	<p>Par la présente Lantronix, Inc. déclare que l'appareil G520 Series est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 2014/53/EU.</p> <p>Le texte complet de la déclaration de conformité UE est disponible à l'adresse Internet suivante : <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Avis de restrictions d'utilisation de l'UE: Cet appareil est limité à une utilisation en intérieur uniquement. Il ne doit pas être utilisé à l'extérieur.</p>
is	Icelandic	<p>Hér með lýsir Lantronix, Inc. því yfir að G520 Series sé í samræmi við grunnkröfur og önnur viðeigandi ákvæði tilskipunar 2014/53 / ESB.</p> <p>Í heildartexta ESB-samræmisýfirlýsingarinnar er að finna á eftirfarandi internetfangi: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Tilkynning ESB um takmarkanir á notkun: Þetta tæki er eingöngu takmarkað við notkun innanhúss. Það má ekki nota það úti.</p>
it	Italiano [Italian]	<p>Con la presente Lantronix, Inc. dichiara che questo G520 Series è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 2014/53/EU.</p> <p>Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Avviso di restrizioni d'uso dell'UE: questo dispositivo è limitato esclusivamente all'uso in interni. Potrebbe non essere utilizzato all'aperto.</p>
lv	Latviski [Latvian]	<p>Ar šo Lantronix, Inc. deklarē, ka G520 Series atbilst Direktīvas 2014/53/EU būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.</p> <p>Pilns ES atbilstības deklarācijas teksts ir pieejams šādā tīmekļa vietnē: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>ES paziņojums par lietošanas ierobežojumiem: šo ierīci var izmantot tikai iekšējās telpās. To nedrīkst darbināt ārpus telpām.</p>
lt	Lietuvių [Lithuanian]	<p>Šiuo Lantronix, Inc. deklaruoja, kad šis G520 Series atitinka esminius reikalavimus ir kitas 2014/53/EU Direktyvos nuostatas.</p> <p>Visą ES atitikties deklaracijos tekstą galite rasti šiuo interneto adresu: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>ES pranešimas apie naudojimo apribojimus: Šis prietaisas skirtas naudoti tik patalpose. Jo negalima naudoti lauke.</p>

Code	Language	Statement
nl	Nederlands [Dutch]	<p>Hierbij verklaart Lantronix, Inc. dat het toestel G520 Series overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 2014/53/EU.</p> <p>De volledige tekst van de EU-conformiteitsverklaring is beschikbaar op het volgende internetadres: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EU kennisgeving van gebruiksbeperkingen: dit apparaat is beperkt tot gebruik binnenshuis. Het mag niet buitenshuis worden gebruikt.</p>
mt	Malti [Maltese]	<p>Hawnhekk, Lantronix, Inc., jiddikjara li dan G520 Series jikkonforma malħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 2014/53/EU.</p> <p>It-test sħiħ tad-dikjarazzjoni ta 'konformità tal-UE huwa disponibbli fl-indirizz tal-internet li ġej: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Avviż tal-UE dwar Restrizzjonijiet fuq l-Użu: Dan l-apparat huwa limitat għal użu ġewwa biss. Ma jistax jiġihaddem barra.</p>
hu	Magyar [Hungarian]	<p>Alulírott, Lantronix, Inc. nyilatkozom, hogy a G520 Series megfelel a vonatkozó alapvető követelményeknek és az 2014/53/EU irányelv egyéb előírásainak.</p> <p>Az EU-megfelelőségi nyilatkozat teljes szövege a következő internetes címen érhető el: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EU értesítés a korlátozásokról: Ez az eszköz csak beltéri használatra korlátozódik. Lehet, hogy szabadban nem üzemeltethető.</p>
no	Norwegian	<p>Lantronix, Inc. erklærer herved at denne G520 Series er i samsvar med de grunnleggende kravene og andre relevante bestemmelser i direktiv 2014/53 / EU.</p> <p>Den fullstendige teksten til EU-samsvarserklæringen er tilgjengelig på følgende internetadresse: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EUs merknad om bruksbegrensninger: Denne enheten er bare begrenset til innendørs bruk. Det kan hende at den ikke brukes utendørs.</p>

Code	Language	Statement
pl	Polski [Polish]	<p>Niniejszym Lantronix, Inc. oświadcza, że EMG 8500 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 2014/53/EU.</p> <p>Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Zawiadomienie UE o ograniczeniach użytkowania: To urządzenie jest przeznaczone wyłącznie do użytku w pomieszczeniach. Nie można go obsługiwać na zewnątrz.</p>
pt	Português [Portuguese]	<p>Lantronix, Inc. declara que este G520 Series está conforme com os requisitos essenciais e outras disposições da Directiva 2014/53/EU.</p> <p>O texto completo da declaração UE de conformidade está disponível no seguinte endereço na Internet: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Aviso da UE de restrições de uso: Este dispositivo está limitado apenas ao uso interno. Não pode ser operado ao ar livre.</p>
ro	Romanian	<p>Prin prezenta, Lantronix, Inc., declară că acest G520 Series respectă cerințele esențiale și alte dispoziții relevante din Directiva 2014/53 / UE.</p> <p>Textul complet al declarației de conformitate a UE este disponibil la următoarea adresă de internet: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Notificarea UE privind restricțiile de utilizare: Acest dispozitiv este limitat numai la uz interior. Este posibil să nu funcționeze în aer liber.</p>
sr	Serbian	<p>Овиме, Лантроник, Инц., изјављује да је овај G520 Series у складу са суштинским захтевима и осталим релевантним одредбама Директиве 2014/53 / ЕУ.</p> <p>Комплетан текст ЕУ изјаве о усаглашености доступан је на следећој Интернет адреси: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Обавештење ЕУ о ограничењима употребе: Овај уређај је ограничен само на унутрашњу употребу. Можда се не користи на отвореном.</p>
sl	Slovensko [Slovenian]	<p>Lantronix, Inc. izjavlja, da je ta G520 Series v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 2014/53/EU.</p> <p>Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Obvestilo EU o omejitvah uporabe: Ta naprava je omejena samo na notranjo uporabo. Morda ga ne uporabljate na prostem.</p>


Code	Language	Statement
sk	Slovensky [Slovak]	<p>Lantronix, Inc. týmto vyhlasuje, že G520 Series enterprise Wi-Fi IoT module spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 2014/53/EU.</p> <p>Úplné znenie EÚ vyhlásenia o zhode je k dispozícii na tejto internetovej adrese: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>Oznámenie EÚ o obmedzeniach pri používaní: Toto zariadenie je obmedzené iba na použitie v interiéri. Nesmie sa používať vonku.</p>
fi	Suomi [Finnish]	<p>Lantronix, Inc. vakuuttaa täten että G520 Series tyyppinen laite on direktiivin 2014/53/EU oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.</p> <p>EU-vaatimustenmukaisuusvakuutuksen koko teksti on saatavana seuraavassa Internet-osoitteessa: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EU: n ilmoitus käyttörajoituksista: Tämä laite on rajoitettu vain sisäkäyttöön. Sitä ei saa käyttää ulkona.</p>
sv	Svenska [Swedish]	<p>Härmed intygar Lantronix, Inc. att denna G520 Series står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 2014/53/EU.</p> <p>Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande internetadress: <a href="https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads">https://www.lantronix.com/products/lantronix-emg/#tab-docs-downloads</a></p> <p>EU-meddelande om begränsningar för användning: Den här enheten är endast begränsad till inomhusbruk. Det får inte användas utomhus.</p>

## B: Power Cable Schematic

### Power Cable Schematic

3-pin power cable schematic

Figure B-1 3-pin Power Cable



## C: List of Acronyms and Protocols

Acronym	Description
2G	2nd Generation
3G	3rd Generation
AES	Advanced Encryption Standard
AP	Access Point (or wireless access point) is a device that provides wireless service for clients within its coverage area.
APN	Access Point Name is the name of an access point for the cellular network data connection.
ASDU	Application Service Data Unit is the IEC-101/IEC-104 data structure that holds application layer information to exchange between a control center and a remote terminal unit.
CHAP	Challenge handshake protocol is used by PPP to authenticate users and can be used with many VPNs.
CSQ	Cellular Signal Strength (CSQ). It ranges from 0 to 32.
DHCP	Dynamic Host Configuration Protocol is a standardized networking protocol used by hosts to dynamically discover and lease an IP address, and learn the correct subnet mask, default gateway, and DNS server IP address.
DIO	Digital Input/Output
DLMS	Device Language Message Specification is a set of standards for electricity meter data exchange.
DMZ	Demilitarized Zone is a physical or logical sub network that contains and exposes an organization's external-facing services to a larger and un-trusted network, usually the Internet.
DNP3	Distributed Network Protocol version 3 is a protocol used for automation and remote control communication with serial and TCP/IP capabilities used in SCADA environments.
DNS	Domain Name System is an application layer protocol used throughout the Internet for translating hostnames into their associated IP addresses.
DynDNS, DDNS	Dynamic DNS is a method of automatically updating a name server in the Domain Name System (DNS), often in real time, with the active DNS configuration of its configured hostnames, addresses or other information.
EDGE	Enhanced Data rates for GSM Evolution (EDGE) is a backwards-compatible extension of GSM that provides higher data transmission rates than GSM
GPRS	General packet radio service is a packet oriented mobile data standard on the 2G and 3G cellular communication network's GSM
GPS	Global Positioning Satellite
GSM	Global system for mobile communications
HT Physical mode	High Throughput Physical Mode
IEC-101/IEC-104	IEC-101 (serial) and IEC-104 (TCP) are part of the IEC 60870-5 set of standards that define systems or methods used for telecontrol in electrical engineering and power system automation applications.

Acronym	Description
ICMP	Internet Control Message Protocol (ICMP) is a TCP/IP network layer protocol that reports errors and provides other information relevant to IP packet processing.
IGMP	Internet Group Management Protocol is a communications protocol used by hosts and adjacent gateways on IP networks to establish multicast group memberships
IKEv1 and IKEv2	Internet Key Exchange (version 1 or version 2) is an encryption key exchange mode used between two peers.
IPsec	Internet Protocol Security is a protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a communication session.
ISP	Internet service provider
L2TP	Layer Two Transport Protocol
LAN	Local Area Network
LED	Light emitting diode
M2M	Machine to machine
MAC address	Media Access Control address is a unique identifier (6 bytes) assigned to a network interface for use as a network address.
MD5	MD5 is a message digest algorithm used as a checksum to verify data integrity
Modbus	Modbus is a data communication protocol used for connecting industrial electronic devices.
MTU	Maximum transmission unit of a communications protocol of a layer is the size (in bytes) of the largest protocol data unit that the layer can pass onwards
MWAN	multiple WAN interface
NAT	Network Address Translation is a method of translating IP addresses that are not globally unique into public addresses in the globally routable address space.
NMS	Network Management System. Component in SNMP architecture that includes SNMP manager.
NTP	Network Time Protocol is a networking protocol for clock synchronization between computer systems over packet-switched, variable-latency data networks
PAP	Password Authentication Protocol is a password based protocol used by PPP (point to point protocol) to authenticate users and can be used with many VPNs. PAP is considered less secure than CHAP or some other authentication protocols.
PDU	Protocol Data Unit
PoE	Power over Ethernet describes standards for passing electric power and data over Ethernet cabling between the Power Sourcing Equipment (PSE) and the Powered Device (PD).
PLC	Programmable Logic Controller
PPP	Point to Point Protocol
PPPoE	Point-to-Point Protocol over Ethernet
PPTP	Point-to-Point Tunneling Protocol

---

<b>Acronym</b>	<b>Description</b>
PSK	Pre-shared key
QoS	Quality of Service
RF	Radio Frequency
RTU	Remote terminal unit
Rx	Reception
SCP	Secure Copy Protocol
SHA1/SHA2	Secure Hash Algorithm is an encryption cipher type
SIM	Subscriber identity module
SMS	Short Message Service
SNMP	Simple Network Management Protocol
SPI	Serial Peripheral Interface
SSH	Secure Shell
SSID	Service Set Identifier
SSL/TLS	Secure Sockets Layer/Transport Layer Security are encryption-based security protocols designed to provide data security for Internet communications.
STP	Spanning Tree Protocol is a network protocol that prevents loops when switches or bridges are interconnected through multiple paths.
TCP	Transmission Control Protocol
TKIP	Temporal Key Integrity Protocol
Tx	Transmission
UDP	User Datagram Protocol
VPN	Virtual private network
VRRP	Virtual Router Redundancy Protocol
WAN	Wide Area network
WPA/WPA2/WPA3	Wi-Fi Protected Access® (WPA) family of technologies are security protocols for wireless networks.



## ***D: Lantronix Technical Support***

Lantronix offers many resources to support our customers and products at <http://www.lantronix.com/support>.

For example, you can browse the knowledge base, open a support issue, find firmware downloads, view tutorials, and more. At this site you can also find FAQs, product bulletins, warranty information, extended support services, and product documentation.

To submit a support request, please use the Lantronix Technical Support portal at <https://ltxdev.atlassian.net/wiki/spaces/LTRXTS/overview> (registration required).

To contact Lantronix Sales, look up your local office at <https://www.lantronix.com/about-us/contact/>.