



ES1686dc R2

User Guide

Contents

1. Important Information

Safety information.....	3
-------------------------	---

2. Product Overview

About the ES1686dc R2.....	6
Hardware Specifications.....	6
Package Contents.....	11
Components.....	11
Front Panel.....	11
Front Panel Buttons.....	12
Front Panel LEDs.....	13
Front Panel OLED Display.....	14
Rear Panel.....	17
Rear Panel LEDs.....	19
Storage Controller Power Button.....	22
Reset Button.....	22
Battery Backup Unit.....	23
System Board.....	23
Drive Numbering.....	24
Installation Requirements.....	24
Setting Up the NAS.....	25

3. Installation and Configuration

Hardware Installation.....	27
Removing a Storage Controller.....	27
Installing a Storage Controller.....	28
Drive Installation.....	29
Installing Expansion Cards.....	36
Replacing Memory Modules.....	39
Replacing the Fan Module.....	41
Hot-swapping Redundant Power Supply Units.....	43
Replacing the Battery Backup Unit.....	44
Expansion Unit Installation.....	45
QES Installation.....	51
Installing QES Using a Static IP Address.....	51
Installing QES Using a Dynamic IP Address.....	53
Installing QES Using Manual Setup.....	54
Service Port Configuration.....	56
Storage Controller Service Port.....	56
Expansion Unit Service Port.....	57
Management Port Configuration.....	59
Multipath I/O Network Configuration.....	60

4. Troubleshooting

Forcing Qfinder Pro to Locate the NAS.....	62
Hot-swapping Failed Drives.....	62
Support and other resources.....	63

5. Glossary

QES.....	64
Qfinder Pro.....	64

6. Notices

Limited warranty.....	65
Disclaimer.....	65
Copyright and trademarks.....	65
GNU General Public License.....	66
CE notice.....	75
UKCA notice.....	75
FCC notice.....	75
VCCI notice.....	76
BSMI notice.....	76
SJ/T 11364-2006.....	76

1. Important Information

Original Packaging

Please keep the original packaging and packaging materials. If you want to return the product or send it for repairs, please use the original packaging to avoid damage.

QNAP reserves the right not to provide a refund or warranty service for products that are damaged due to improper packaging.

Hardware Defects

If your QNAP product has hardware defects, return the product to QNAP or a QNAP-authorized service center for maintenance or replacement. Any attempt to repair or perform maintenance procedures on the product by you or an unauthorized third party invalidates the warranty.

QNAP is not responsible for any damage or data loss caused by unauthorized modifications and installation of unsupported third-party applications.

For details, see the [QNAP Warranty Terms and Conditions](#).

Safety information

The following instructions help ensure personal safety and environmental safety. Read these instructions carefully before performing any operation.

General Instructions

- The device should be stored in a secure location with restricted access, controlled through the use of a tool, lock and key, or any means of security.
- Only qualified, skilled, and authorized persons with knowledge of all restrictions, safety precautions, and installation and maintenance procedures should have physical access to the device.

WARNING



To avoid potential injury or damage to components, ensure that the drives and other internal system components have cooled before touching them.



Observe electrostatic discharge (ESD) procedures to avoid potential injury or damage to components.

Power

WARNING



To reduce the risk of fire or electric shock, ensure that you only connect the power cord to a properly grounded electrical outlet.



Devices with redundant power supply may have one or more power supply unit (PSU) cords. To avoid serious injuries, a trained service technician must disconnect all PSU cords from the device before installing or replacing system components.

Moving Parts

WARNING



Moving fan blades: Keep your body parts away from any moving fan blades while the device is connected to a power source.



Moving components: Keep your body parts away from any other moving components.

The device is not suitable for use in locations where children are likely to be present.

System Battery

WARNING



INGESTION HAZARD

- This product may contain a button battery.
- Keep batteries out of reach of children.
- If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours.
- If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

- To avoid potential battery explosion, causing injury or damage to components, ensure that you replace the existing battery with a battery of the same type.

- Dispose of used batteries properly according to local regulations or the instructions of the battery manufacturer.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- For information on the type and voltage of the button battery in your device, please see the hardware specification table.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat, or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, or different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Rail Kits

Rackmount models may require rail kits for installation onto a server rack or cabinet.

To ensure equipment and personal safety, please carefully read the installation instructions for your rail kit before you install the rail kit and mount your device.

To check if your device is a rackmount unit, see the hardware specification table.

WARNING

- When the rail kit is installed on the server rack, do not fully extend and unlatch the rails except when mounting or unmounting a device.
- Leaving the rails fully extended out and unlatched may cause heavy equipment to fall. This can cause equipment damage and severe or even fatal injuries.
- Before you prepare the rails for device mounting or unmounting, please carefully read and ensure you understand the installation instructions.
- Do not place any objects or add any extra load onto the device or rails when mounting or unmounting a device.
- When mounting a device, slide the device all the way into the server rack to fully latch the rails and secure the device to the server rack.

2. Product Overview

This chapter provides basic information about the QNAP ES1686dc R2 NAS.

About the ES1686dc R2

The ES1686dc R2 is designed to deliver a scalable platform for enterprise-level solutions. It is equipped with a powerful multi-core processor, AES-NI hardware encryption engine, and both USB 3.2 and 10GbE ports, allowing it to deliver optimal performance for enterprise users. The ES1686dc R2 supports up to 16 storage drives. This number can be increased by attaching multiple expansion units. It has redundant storage controllers and power supplies to provide the necessary reliability, serviceability, and read/write speeds.

Hardware Specifications

Warning

- If your QNAP product has hardware defects, return the product to QNAP or a QNAP-authorized service center for maintenance or replacement. Any attempt to repair or perform maintenance procedures on the product by you or an unauthorized third party invalidates the warranty.
- QNAP is not responsible for any damage or data loss caused by unauthorized modifications and installation of unsupported third-party applications. For details, see the [QNAP Warranty Terms and Conditions](#).


Ordering P/N	CPU	Memory	Power supply
ES1686dc-R2-2123IT-64G	Intel® Xeon™ D-2123IT	64 GB (32 GB per controller)	Redundant
ES1686dc-R2-2142IT-96G	Intel® Xeon® D-2142IT	96 GB (48 GB per controller)	Redundant
ES1686dc-R2-2142IT-128G	Intel® Xeon® D-2142IT	128 GB (64 GB per controller)	Redundant

Component	ES1686dc-R2-2123IT-64G	ES1686dc-R2-2142IT-96G ES1686dc-R2-2142IT-128G
Processor		
CPU	Intel® Xeon™ D-2123IT	Intel® Xeon® D-2142IT
Frequency	4-core/8-thread 2.2 GHz base/3.0 GHz turbo	8-core/16-thread 1.9 GHz/3.0 GHz turbo

Component	ES1686dc-R2-2123IT-64G	ES1686dc-R2-2142IT-96G ES1686dc-R2-2142IT-128G
Architecture	x86 64-bit	
Encryption engine	AES-NI	
Memory		
Memory slots	<div>8 x DDR4 RDIMM or LRDIMM slots per controller</div> <div>Important<ul style="list-style-type: none">• Use only QNAP memory modules to maintain system performance and stability. For NAS devices with more than one memory slot, use QNAP modules with identical specifications.• Using unsupported modules may degrade performance, cause errors, or prevent the operating system from starting.• You can only use one type of dual in-line memory module (DIMM) at a time. Do not use registered DIMM (RDIMM) with load-reduction DIMM (LRDIMM) memory.</div>	
Maximum memory	512 GB RAM: 8 x 64 GB	
Flash memory	4 GB (dual-boot OS protection)	
Cache for Copy-to-Flash	64 GB per controller	
Storage		
Drive bays	<div>16 x 3.5-inch SAS 12 Gbps</div> <div>Note<p>The interface is backward compatible to SAS 6 Gbps.</p></div>	

Component	ES1686dc-R2-2123IT-64G	ES1686dc-R2-2142IT-96G ES1686dc-R2-2142IT-128G
Drive compatibility	<div>3.5-inch bays:</div> <ul style="list-style-type: none">• 2.5-inch SAS hard disk drives• 3.5-inch SAS hard disk drives• 2.5-inch SAS solid-state drives <div><div>Tip</div><div>For the list of compatible drive models, go to https://www.qnap.com/compatibility. A QDA-SA or QDA-SA2 drive adapter is required for installing SATA HDD/SSD. For more details, see the drive adapter Quick Installation Guide.</div></div>	
SSD cache acceleration support	3.5-inch drive bays: 1 to 16	
Hot-swapping	This device supports hot-swapping for all drives.	
Network		
10 Gigabit network interface	4 x 10GbE SFP+ ports per controller	
Gigabit network interface	3 x GbE RJ45 ports per controller	
External I/O Ports & Expansion Slots		
PCIe slots	<div>2 x PCIe 3.0 x8 slots per controller</div> <div><div>Tip</div><div>For the list of compatible drive models and expansion cards, go to https://www.qnap.com/compatibility.</div></div>	
USB ports	<div>2 x USB 3.2 Gen 1 Type-A ports per controller</div> <div><div>Note</div><div>For engineering purposes only.</div></div>	

Component	ES1686dc-R2-2123IT-64G	ES1686dc-R2-2142IT-96G ES1686dc-R2-2142IT-128G
Interface		
Buttons	<div>NAS<ul style="list-style-type: none">• Power• OLED panel power button</div> <div>Storage Controllers<ul style="list-style-type: none">• Power• Reset</div>	
Dimensions		
Form factor	3U Rackmount	
Dimensions (H x W x D)	132 x 446.2 x 587.75 mm (5.20 x 17.57 x 23.14 in)	
Net weight	30.22 kg (66.62 lbs)	
Others		
Rail compatibility	<div>RAIL-E02</div> <div><div>Note</div>Information on rail kit installation can be found in the installation guide included in the rail kit package.</div>	
Power supply unit	<div>2 x 700W, 90-264V AC, 50/60 Hz</div> <div><div>Warning</div>To reduce the risk of fire or electric shock, ensure that you only connect the power cord to a properly grounded electrical outlet.</div>	

Component	ES1686dc-R2-2123IT-64G	ES1686dc-R2-2142IT-96G ES1686dc-R2-2142IT-128G
System battery	CR2032 lithium battery (3V, 225 mAh) <div> <p>Warning</p> <p>To avoid potential battery explosion, causing injury or damage to components, ensure that you replace the existing battery with a battery of the same type.</p> </div> <div> <p>Important</p> <p>Dispose of used batteries according to local regulations or the instructions of the battery manufacturer.</p> </div>	
Hot-swappable battery backup unit	2 x 10.8V, 2200 mAh	
Hot-swappable fan module	System: 60 x 60 x 38 mm, 12V DC fan <div> <p>Warning</p> <ul style="list-style-type: none">  <p>To avoid potential injury or damage to components, do not touch the fans while the device is connected to a power source.</p> To ensure proper cooling, replacement of the fan should be completed within 10 seconds. </div>	
Operating temperature	0°C to 40°C (32°F to 104°F)	
Relative humidity	<ul style="list-style-type: none"> Non-condensing relative humidity: 5% to 95% Wet-bulb temperature: 27°C (80.6°F) 	

Tip


Model specifications are subject to change without prior notice. To see the latest specifications, go to <https://www.qnap.com>.

Package Contents

Item	Quantity
ES1686dc R2 NAS	1
Power cord	2
Ethernet cable	2
Screws for 2.5-inch drives	64
Screws for 3.5-inch drives	64
RAIL-E02 rail kit	1
Quick Installation Guide (QIG)	1

Components


Front Panel



No.	Component	No.	Component
1	OLED panel	4	Drive status LED
2	System power LED	5	Drive activity LED

No.	Component	No.	Component
3	Status LED	-	-

Front Panel Buttons



Note
Pull the panel cover to access the front panel buttons.

No.	Component	No.	Component
1	OLED panel power button	2	Power button

Operation	User Action	Result
Power on NAS	Press the power button.	<ul style="list-style-type: none"> Both storage controllers power on. All storage and management services are disabled. <div> Tip <ul style="list-style-type: none"> System startup takes 10 to 15 minutes, depending on the number of installed drives and connected devices. Check the rear panel LEDs to determine the startup status. For details, see Rear Panel LEDs. This button can only be used to power on the two storage controllers. Use the respective rear panel storage controller power button to power off the storage controllers. For details, see Storage Controller Power Button. </div>
Power on OLED display	Press the OLED button.	The OLED display powers on.
Power off OLED display	Press the OLED button.	The OLED display powers off.

Front Panel LEDs

The front panel LEDs indicate system status and related information when the NAS is powered on. The following LED information applies only when the drive is correctly installed and when the NAS is connected to the network.

For details on the location of the LEDs, see [Front Panel](#).


LED	Status	Description
System power	Blue	System powered on
System status	Green	System operating normally







LED	Status	Description
System status	Red	<ul style="list-style-type: none"> System errors or warnings (e.g. degraded RAID mode, memory failure, fan/power supply failure, system/disk temperature too high, storage pool reaching threshold value) were detected. Refer to the QES User Guide for details. The system is performing takeover. The dual active-active controller system enables a single controller to take over the pool disk resources owned by the other controller in the event of a controller failure. Takeovers can be initiated manually or be set up with the automatic system failover protection. For more information, refer to the QES user guide. Power supply unit unplugged
Drive status	Green	Drive can be accessed
	Flashing green slowly	The QES Storage Manager Locate command is enabled and is identifying the drive
	Red	Drive read/write error
	Off	Drive not installed
Drive activity	Flashing green continuously or slowly	No drive activity
	Flashing green	High activity on drive or drive being configured as part of an array






Front Panel OLED Display

The OLED display displays the status of the storage controllers and main components.

For details on the location of the OLED display, see [Front Panel](#).

Icon name	Icon	Description
Controller power status		<ul style="list-style-type: none"> On: Both controllers are powered on Flashing: Both controllers are booting

Icon name	Icon	Description
Controller power status		<ul style="list-style-type: none"> On: Only controller A is powered on Flashing: Controller A is booting
		<ul style="list-style-type: none"> On: Only controller B is powered on Flashing: Controller B is booting
Controller fan status		<ul style="list-style-type: none"> On: The fan modules of both controllers are operating normally Flashing: The fan modules of both controllers are operating incorrectly or are not installed
		<p>If both controllers are installed:</p> <ul style="list-style-type: none"> Flashing: The fan module in controller A is operating incorrectly or is not installed <p>If only controller A is installed:</p> <ul style="list-style-type: none"> On: The fan module in controller A is operating normally Flashing: The fan module in controller A is operating incorrectly or is not installed
		<p>If both controllers are installed:</p> <ul style="list-style-type: none"> Flashing: The fan module in controller B is operating incorrectly or is not installed <p>If only controller B is installed:</p> <ul style="list-style-type: none"> On: The fan module in controller B is operating normally Flashing: The fan module in controller B is operating incorrectly or is not installed
Controller battery backup unit		<ul style="list-style-type: none"> On: The BBUs of both controllers are operating normally Flashing: The BBUs of both controllers are operating incorrectly Highlighted: The BBUs of both controllers are charging Off: The BBUs of both controllers are not detected


Icon name	Icon	Description
Controller battery backup unit		<p>If both controllers are powered on:</p> <ul style="list-style-type: none"> Flashing: The BBU in controller A is operating incorrectly or is not detected Highlighted: The BBU in controller A is charging <p>If only controller A is powered on:</p> <ul style="list-style-type: none"> On: The BBU in controller A is operating normally Flashing: The BBU in controller A is operating incorrectly or is not detected Highlighted: The BBU in controller A is charging
		<p>If both controllers are powered on:</p> <ul style="list-style-type: none"> Flashing: The BBU in controller B is operating incorrectly or is not detected Highlighted: The BBU in controller B is charging <p>If only controller B powered on:</p> <ul style="list-style-type: none"> On: The BBU in controller B is operating normally Flashing: The BBU in controller B is operating incorrectly or is not detected Highlighted: The BBU in controller B is charging
High availability status		<ul style="list-style-type: none"> On: In active state Flashing: Performing takeover or undergoing giveback
		Highlighted: Controller A is in takeover state
		Highlighted: Controller B is in takeover state


Icon name	Icon	Description
Two-digit display	05	<p>The two-digit display shows the booting status of each storage controller. The left digit is controller A, and right is controller B.</p> <ul style="list-style-type: none"> • No Display: BIOS booting • 1: Detecting device • 2: Applying network settings • 3: Applying system settings • 4: Service starting • 5: System self-testing • 0: System ready

Tip

To view the full list of system components and their status, open **High Availability** in QES.

Rear Panel






No.	Component	No.	Component
1	PCIe 3.0 x8 slot 2	9	Power supply unit 1
2	PCIe 3.0 x8 slot 1	10	Reset button
3	Ethernet port 6 (10GbE SFP+)	11	USB 3.2 Gen 1 Type-A port 2 Note This port is only for engineering purposes.
4	Ethernet port 4 (10GbE SFP+)	12	USB 3.2 Gen 1 Type-A port 1 Note This port is only for engineering purposes.
5	Service port Note This port is only for engineering purposes.	13	Ethernet port 3 (GbE RJ45)
6	Battery backup unit	14	Power button

No.	Component	No.	Component
7	Ethernet port 2 (GbE RJ45)	15	Ethernet port 5 (10GbE SFP+)
8	Ethernet port 1 (GbE RJ45, management port)	16	Ethernet port 7 (10GbE SFP+)

Rear Panel LEDs



No.	Component	No.	Component
1	10 Gigabit Ethernet speed LED	7	Gigabit Ethernet activity LED
2	Battery backup unit LED	8	High availability LED
3	Gigabit Ethernet speed LED	9	Battery backup unit status LED
4	Power supply LED	10	Fan status LED
5	Gigabit Ethernet speed LED	11	Status LED
6	Gigabit Ethernet activity LED	12	10 Gigabit Ethernet activity LED

The following LED information applies only when the drive is correctly installed and when the NAS is connected to the network.

LED	Status	Description
Power supply unit	Green	<ul style="list-style-type: none"> Powered on Power supply functioning normally
	Flashing green	System powering off
	Orange	AC power cord unplugged or malfunctioning
	Off	One or more of the following conditions exist: <ul style="list-style-type: none"> AC power unavailable Power supply failed
Battery backup unit	Green	Functioning normally
	Red	Malfunctioning
	Orange	Charging or learning
	Off	Not correctly attached to the ES1686dc R2
Status	Green	System operating normally
	Flashing green	System booting
	Off	System powered off
Fan	Green	Functioning normally
	Orange	Malfunctioning
	Off	Fans not detected
Battery backup unit status	Green	Functioning normally
	Orange	Writing buffer for Copy-to-Flash For details, see Battery Backup Unit .
	Off	One or more of the following conditions exist: <ul style="list-style-type: none"> Storage controller is powered off System cannot detect battery backup unit

LED	Status	Description
High availability	Green	Active State
	Flashing orange	<p>One of the following:</p> <ul style="list-style-type: none"> Performing takeover: The dual active-active controller system enables a controller to take over the pool disk resources and access the data upon the failure of the other controller. Takeovers can be initiated manually or be set up with the automatic system failover protection. For more details, refer to the QES user guide. Undergoing giveback: One of the storage controllers has taken over the system. The other storage controller has resumed operations and is ready to resume data service. Giveback can be initiated manually or be set up with automatic failback after system recovers. For more details, refer to the QES user guide.
	Orange	Storage controller has taken over from the other storage controller
	Off	<p>One or more of the following conditions exist:</p> <ul style="list-style-type: none"> Storage controller failed Storage controller is powered off
10 Gigabit Ethernet port speed	Green	10GbE connection
	Orange	1GbE connection
	Off	100 Mbps connection
10 Gigabit Ethernet port activity	Orange	Network link active
	Flashing orange	Network link active
	Off	No network link
1 Gigabit Ethernet port activity	Orange	Network link established
	Flashing orange	Network link active

LED	Status	Description
1 Gigabit Ethernet port activity	Off	No network link
1 Gigabit Ethernet port speed	Green	1GbE connection
	Orange	100 Mbps connection

Storage Controller Power Button

Operation	User Action	Result
Power on	Press the button once.	The storage controller powers on.
Power off	Press and hold the button for 5 seconds.	The storage controller powers off.

Reset Button

Operation	User Action	Result
Basic system reset	Press and hold the button for 3 seconds.	<p>The following settings are set to default values.</p> <ul style="list-style-type: none"> • System administrator password: For details on the default password, see this FAQ. • TCP/IP configuration: <ul style="list-style-type: none"> • IP address settings: Automatically obtained via DHCP • Jumbo frames: Disabled • Port trunking mode: Failover (multi-LAN models only) • Security level: Low (Allow all connections) • LCD panel password: (blank) • VLAN: Disabled • Service binding: NAS services can run on any available network interface

Operation	User Action	Result
Advanced system reset	Press and hold the button for 10 seconds.	<p>The device performs a basic system reset. All default system settings are also restored, deleting all previously created users, user groups, and shared folders. The user data stored on the disks is retained.</p> <p>To retrieve data after an advanced system reset, recreate the previous folder structure on the NAS.</p>


Battery Backup Unit

The battery backup unit (BBU) protects the data integrity of each storage controller. If both power supply units fail during a power outage, the system uses the BBUs for power and activates the asynchronous DRAM refresh (ADR) feature of the processors. While the BBUs supply power, cached data stored in the DRAM are written to the M.2 SSDs. This process is called Copy-to-Flash. Once power is restored and the system restarts, any logs, archives, or other important data are reconstructed from the data stored on the M.2 SSDs.

Warning


During a power outage, do not remove storage controllers while their BBU status LEDs are orange. Removing a storage controller during this period interrupts the Copy-to-Flash process and may result in data loss.

System Board



No.	Component	No.	Component
1	Memory slot 1	6	Memory slot 6
2	Memory slot 2	7	Memory slot 7
3	Memory slot 3	8	Memory slot 8
4	Memory slot 4	9	PCIe 3.0 x8 slot 1
5	Memory slot 5	10	PCIe 3.0 x8 slot 2

Drive Numbering



Installation Requirements

Category	Item
Environment	<ul style="list-style-type: none"> • Room temperature: 0°C to 40°C (32°F to 104°F) • Non-condensing relative humidity: 5% to 95% • Wet-bulb temperature: 27°C (80.6°F) • Flat, anti-static surface without exposure to direct sunlight, liquids, or chemicals • Free from objects that may obstruct device ventilation or apply pressure to the device or power cord • Restricted access <ul style="list-style-type: none"> • The device should be stored in a secure location with restricted access, controlled through the use of a tool, lock and key, or any means of security. • Only qualified, trained, and authorized device administrators with knowledge of all restrictions, safety precautions, and installation and maintenance procedures should have physical access to the device.

Category	Item
Hardware and peripherals	<ul style="list-style-type: none"> Storage drives For the list of compatible drive models, go to https://www.qnap.com/compatibility. Network cable
Tools	<ul style="list-style-type: none"> Phillips #1 or #2 screwdriver Anti-static wrist strap

Setting Up the NAS

Important

Read all safety requirements and information carefully before setting up the NAS or installing NAS components.

1. Place your NAS device in an environment that meets the requirements.

For details, see [Installation Requirements](#).

2. Install drives.

For details, see the following topics:

- [Drive Configuration](#)
- [Installing 3.5-inch Hard Drives on 3.5-inch Trays](#)
- [Installing 2.5-inch Hard Drives or Solid State Drives on 3.5-inch Trays](#)

For a list of compatible drives and expansion cards, go to <http://www.qnap.com/compatibility>.

3. Optional: Install expansion cards.

For details, see [Installing Expansion Cards](#).

4. Connect the NAS to the network.

For details, see the following topics:

- [Management Port Configuration](#)
- [Multipath I/O Network Configuration](#)

5. Optional: Connect the SAS Expansion Units.

For details, see [Connecting SAS Expansion Units](#).

6. Connect the power cord and all applicable cables.

7. Power on the NAS.

For details, see [Front Panel Buttons](#).

8. Install QES.

For details, see [QES Installation](#).

9. Log on to QES.

If QES finds unused disks in your NAS, it will ask you to initialize these disks. Click **Initialize** to start the process.

10. Open **High Availability** and check the system status.

If any of the components are experiencing issues, check if they are properly installed.

3. Installation and Configuration


This chapter provides specific hardware and firmware installation and configuration steps.

Hardware Installation


This section provides information on removing or installing the storage controller, drives, expansion cards, power supply units, fan modules, memory modules, and battery backup units.

Removing a Storage Controller

1. Power off the device.
2. Disconnect the power cord from the electrical outlet.
3. Disconnect all cables and external attachments.
4. Remove the storage controller.
 - a. Loosen the screw.




- b.** Pull the handle to pull out the storage controller.




Installing a Storage Controller

- 1.** Load the controller into the NAS.
 - a.** Insert the controller into the chassis.
 - b.** Push the handle up.



2. Tighten the screw.



3. Connect all cables and external attachments.
4. Connect the power cord to the electrical outlet.
5. Power on the device.

Drive Installation

The ES1686dc R2 is compatible with 3.5-inch hard drives and 2.5-inch hard drives.

Drive Configuration

The ES1686dc R2 supports the following drive configurations.

Configu-ration	Description
All SSDs	Use all solid-state drives (SSDs) for I/O intensive workloads and business-critical storage.
All HDDs	Use all hard disk drives (HDDs) for the best value for capacity. This configuration is suitable for storing cold data and running applications that require sequential data access, such as video editing and surveillance software.
Hybrid	Use a combination of SSDs and HDDs to balance cost and performance. In addition to high input/output operations per second (IOPS), the ES1686dc R2 also supports creating an SSD read cache to further increase storage performance. This configuration is especially suitable for virtual desktop infrastructure (VDI) and web servers. When using a hybrid configuration, QNAP recommends installing SSDs in drive bays 1 to 4.

Drive bays 1 to 4 are reserved for system configurations. QNAP recommends using drive bays 5 to 16 for data storage. This setup prevents data storage operations from interfering with the basic operation of the NAS system. This also allows easier migration of drives used for data storage.

For details on drive numbering, see [Drive Numbering](#).

Installing 3.5-inch Hard Drives on 3.5-inch Trays

For the list of compatible drive models, go to <https://www.qnap.com/compatibility>.

Warning

- Installing a drive deletes all data on the drive.
- Observe electrostatic discharge (ESD) procedures to avoid damage to components.
- Do not replace a drive without first bringing the storage pool offline in QES. You may replace a drive online only when it is part of an array that has been configured for fault tolerance and a predictive failure alert is received from QES. For more information, refer to the QES user guide.



Moving fan blades: Keep your hands and other body parts away from moving fan blades.



Other moving components: Keep your hands and other body parts away from other moving components.


Note

The QDA-SA or QDA-SA2 drive adapter allows SATA 6 Gbps drives to be installed into 3.5-inch SAS drive bays.

1. Power off the NAS.


2. Remove the drive tray.

- a.** Slide the lock to the left.




- b.** Push the button to release the tray handle.

- c.** Pull the tray out.

**3. Install a drive on the tray.**


- a.** Place the drive on the tray so that the holes on the sides of the drive are aligned with the holes on the sides of the tray.

- b.** Attach the screws to lock the drive to the tray.



- 4.** Load the tray into the bay.

- a.** Insert the tray into the bay.
b. Push the handle.



- c.** Slide the lock to the right.

- 5.** Power on the NAS.

Installing 2.5-inch Hard Drives or Solid State Drives on 3.5-inch Trays

For the list of compatible drive models, go to <https://www.qnap.com/compatibility>.

Warning

- Installing a drive deletes all data on the drive.
- Observe electrostatic discharge (ESD) procedures to avoid damage to components.
- Do not replace a drive without first bringing the storage pool offline in QES. You may replace a drive online only when it is part of an array that has been configured for fault tolerance and a predictive failure alert is received from QES. For more information, refer to the QES user guide.



- **Moving fan blades:** Keep your hands and other body parts away from moving fan blades.



- **Other moving components:** Keep your hands and other body parts away from other moving components.


Note

The QDA-SA or QDA-SA2 drive adapter allows SATA 6 Gbps drives to be installed into 3.5-inch SAS drive bays.

1. Power off the NAS.


2. Remove the drive tray.

- a.** Slide the lock to the left.




- b.** Push the button to release the tray handle.

- c.** Pull the tray out.

**3. Install a drive on the tray.**


- a.** Place the drive on the tray so that the holes on the bottom of the drive are aligned with the holes on the bottom of the tray.

- b.** Attach the screws to lock the drive to the tray.



- 4.** Load the tray into the bay.

- a.** Insert the tray into the bay.
b. Push the handle.



- c.** Slide the lock to the right.

- 5.** Power on the NAS.

Installing Expansion Cards

The ES1686dc R2 supports selected expansion cards, some of which require QNAP PCIe brackets. QNAP-branded expansion cards purchased from the company website are shipped with the brackets necessary to fit the ES1686dc R2.

Warning

- Only qualified personnel should perform the following steps. Failure to follow instructions can result in serious injury or death.
- Observe electrostatic discharge (ESD) procedures to avoid damage to components.




Moving fan blades: Keep your hands and other body parts away from moving fan blades.



Other moving components: Keep your hands and other body parts away from other moving components.


1. Check the expansion cards and brackets supported by your model on the QNAP website.
 - a. Go to www.qnap.com/compatibility.
 - b. Click **Search by NAS**.
 - c. Specify the number of bays and the specific model of your NAS.
 - d. Under **Category**, select the component or device type.
 - e. Locate a specific component or device model in the list.
 - f. Optional: Click the corresponding **Note** icon to view more information.
2. Remove the storage controller.
For details, see [Removing a Storage Controller](#).
3. Remove the PCIe cover.
 - a. Remove the screw that secures the cover to the bracket.

- b.** Pull the cover away from the slot.




- 4.** Optional: Attach the QNAP bracket to the expansion card.

- a.** Remove all screws of the existing bracket.



- b.** Carefully pull the bracket away from the card.


- c. Attach the QNAP bracket to the card using the same screws.



- d. Verify that the bracket is secured to the card.

5. Install the expansion card.

- a. Hold the card by the edges.
- b. Insert the card into the slot.
- c. Attach the screw.



6. Install the storage controller.

For details, see [Installing a Storage Controller](#).

Replacing Memory Modules

Each storage controller has eight memory slots. You can increase the memory capacity of the NAS by upgrading the memory module.

Use only QNAP memory modules to maintain system performance and stability. You can purchase QNAP memory modules from authorized resellers.

Important

QNAP recommends installing modules in pairs to run dual-channel mode.

- Ensure that each pair uses identical modules.
- Install the pairs in sequence and follow the assigned slots for each pair.
- The ES1686dc R2 has eight memory slots. For optimal quad-channel performance, install memory modules on either four or eight of the slots. When installing four memory modules, install the memory in slots 1, 3, 6, and 8.

For details on slot numbering, see [System Board](#).

Module Pair	Slot Number
First pair	Slots 1 and 8
Second pair	Slots 3 and 6
Third pair	Slots 2 and 7
Fourth pair	Slots 4 and 5

Warning

- Only qualified personnel should perform the following steps. Failure to follow instructions can result in serious injury or death.
- Observe electrostatic discharge (ESD) procedures to avoid damage to components.



Moving fan blades: Keep your hands and other body parts away from moving fan blades.



Other moving components: Keep your hands and other body parts away from other moving components.

1. Remove the storage controller.

For details, see [Removing a Storage Controller](#).


2. Remove an existing module.

- a.** Push the retention clips outward simultaneously to release the module.


Warning

Attempting to remove a module that is not completely released may damage the module and the system board.

- b.** Hold the module by the edges.

**3. Install a new module.**

- a.** Align the notch with the ridge in the slot.
- b.** Insert the module into the slot.
- c.** Verify that the metal connectors are completely inserted into the slot.
- d.** Carefully press down on the module until the retention clips lock the module into place.



4. Install the storage controller.
For details, see [Installing a Storage Controller](#).
5. Verify that the module is recognized by the device.
 - a. Log on to QES as administrator.
 - b. Go to **Control Panel > System > System Status > Hardware Information**.
 - c. Check the values for each memory slot.

Replacing the Fan Module

The fan module of the ES1686dc R2 contains three fans to ensure adequate cooling.

Warning



- To avoid potential injury or damage to components, do not touch the fans while the device is connected to a power source.
- Only qualified personnel should perform the following steps. Failure to follow instructions can result in serious injury or death.
- Observe electrostatic discharge (ESD) procedures to avoid damage to components.




Moving fan blades: Keep your hands and other body parts away from moving fan blades.




Other moving components: Keep your hands and other body parts away from other moving components.

1. Remove the storage controller.
For details, see [Removing a Storage Controller](#).

2. Remove the fan module.
 - a. Pull the handle to release the fan module.
 - b. Pull the module out.



3. Install a new fan module.
 - a. Insert the module into the chassis.
 - b. Push the handle down to lock the module in place.



4. Install the storage controller.
For details, see [Installing a Storage Controller](#).

Hot-swapping Redundant Power Supply Units


1. Disconnect the power cord from the electrical outlet and the PSU that you are replacing.

Warning




The NAS may have one or more power supply unit (PSU) cords. To avoid serious injuries, a trained service technician must disconnect all PSU cords before installing or replacing system components.

2. Firmly press the latch toward the handle and then pull the PSU out.



3. Insert the new PSU.




4. Connect the power cord to the PSU and the electrical outlet.


Replacing the Battery Backup Unit

If the power supply unit of the storage controller fails, the system will switch to the battery backup unit (BBU) for power.

1. Press the button and pull the BBU out.



2. Insert the new BBU into the slot until it locks in place.



Expansion Unit Installation

The ES1686dc R2 supports SAS expansion units and is compatible with the EJ1600 v2. When connecting to the EJ1600 v2, some storage expansion accessories are required. Refer to the following table for details.

Expansion Unit Type	Description	Required Accessories	Maximum Expansion Units Supported
EJ1600 v2	<ul style="list-style-type: none"> • Uses a SAS 12 Gbps interface • Supports SAS HDD/SSD 	<ul style="list-style-type: none"> • SAS-12G2E storage expansion card • Mini-SAS SFF-8644 cable • RAIL-E02 rail kit 	7

You can purchase storage expansion accessories from QNAP or an authorized reseller.

For details, go to <https://shop.qnap.com/>.


Connecting SAS Expansion Units

1. Install a storage expansion card on the PCIe slot.
For details, see [Installing Expansion Cards](#).


2. Connect the expansion units to the NAS using one of the following topologies.

Important

QNAP recommend always using dual-path configuration, to prevent storage downtime due to expansion unit failure or cable disconnection. Single-path configuration should be used only in a situation where it is not possible to use dual-path configuration.



Dual-path configuration




Single-path configuration

3. Power on the expansion units.
4. Verify that the expansion units are recognized by the NAS.
 - a. Log on to QES as administrator.
 - b. Go to **Main Menu > Storage Manager > Overview > System**.
 - c. Verify that the expansion units are listed.


Adding an SAS Expansion Unit

Important

- When adding an expansion unit to an existing NAS topology, the new expansion must be added last. For example, if there are 2 existing expansion units, then you must add the new unit in sequence as expansion unit 3.
- If you are using a dual-path configuration, you must prepare 2 new SAS cables.



Dual-path configuration



Single-path configuration

1. Mount the new expansion unit on the rack.
2. Install the drives in the new expansion unit.
3. If you are using a dual-path configuration, disconnect the loop cables from the SAS ports on the last expansion unit.
Loop cables are the SAS cables that you use to connect the last expansion unit back to the NAS.
4. Using the two new SAS cables, connect the last expansion unit to the new expansion unit.
5. If you are using a dual-path configuration, connect the loop cables to the new expansion unit.
6. Connect the power cables to the new expansion unit.
7. Power on the new expansion unit.
8. Log on to QES as administrator.
9. Go to **Main Menu > Storage Manager > Storage > Disks**.
10. Click **Recover**, and then select **Reinitialize enclosure ID**.

QES scans for and detects the new expansion unit and installed disks.

Replacing an SAS Expansion Unit

1. Take all storage pools on the old expansion unit offline.

Warning


Disconnecting an expansion unit containing online storage pools may result in data loss.

Configuration	Description
Single-path configuration	If you disconnect a SAS expansion unit, all succeeding units in the connection will also be disconnected. For example, if you are replacing expansion unit 2, then you must take the storage pools on expansion units 3 and 4 offline.
Dual-path configuration	If you disconnect an old expansion unit, only its storage pools will be taken offline.


For more information, refer to the QES User Guide.

2. Press and hold the power button on the old expansion unit for 5 seconds.
The old expansion unit powers off.
3. Disconnect all SAS cables from the old expansion unit.
4. Disconnect all power cables from the old expansion unit.
5. Unmount and remove the old expansion unit from the rack.
6. Remove the drives from the old expansion unit.
7. Mount the new expansion unit on the rack.
8. Install the drives in the new expansion unit.

9. Connect the SAS cables to the new expansion unit.
Use one of the following cabling topologies, depending on your current cabling layout. For more information, see [Connecting SAS Expansion Units](#).



Dual-path configuration



Single-path configuration

10. Connect the power cables to the new expansion unit.

11. Power on the new expansion unit.
12. Log on to QES as administrator.
13. Go to **Main Menu > Storage Manager > Storage > Disks**.
14. Click **Recover**, and then select **Reinitialize enclosure ID**.
QES scans for and detects the new expansion unit and installed disks.
15. Bring all offline storage pools back online.

QES Installation

The ES1686dc R2 uses the QNAP QES operating system. If the NAS is connected to your local area network, you can install QES using Qfinder Pro.

Mode	Description
Quick setup	Install QES and configure basic settings. For details, see the following topics: <ul style="list-style-type: none"> • Installing QES Using a Static IP Address • Installing QES Using a Dynamic IP Address
Manual setup	Install QES and configure advanced settings such as device type access and the QES system file storage pool. For details, see Installing QES Using Manual Setup .

Installing QES Using a Static IP Address

Warning

Installing QES deletes all data on the drives. Back up your data before proceeding.

1. Power on the NAS.
2. Connect the NAS to your local area network.
3. Run Qfinder Pro on a computer that is connected to the same local area network.

Tip

To download Qfinder Pro, go to <https://www.qnap.com/utilities>.

4. Locate the IP address of the storage controller from the device list.
If the computer is connected to the NAS through the management port, Qfinder Pro will also display the IP address of the second controller.

Controller Number	IP Address
1	169.254.100.100
2	169.254.100.101

5. Configure the network settings.

- a. On your Windows device, go to **Control Panel > Network and Internet > Network and Sharing Center**.
- b. Identify and click the network interface connected to the management port.
The connection status window opens.
- c. Click **Properties**.
The connection properties window opens.
- d. From the list of connections, select **Internet Protocol Version 4 (TCP/IPv4)**.
- e. Click **Properties**.
The **Internet Protocol Version 4 (TCP/IPv4) Properties** window opens.
- f. Select **Use the following IP address**.
- g. Specify an IP address and subnet mask.
Example:
 - IP address: 169.254.1.10
 - Subnet mask: 255.255.0.0
- h. Click **OK**.

Tip

You can change the settings back to their original configuration after installing QES.

6. In Qfinder Pro, double-click an uninitialized controller.
The setup wizard opens.
7. Click **Quick Setup**.
The **Quick Setup** window opens.

8. Specify a NAS name and password.

Field	Requirements
NAS name	<ul style="list-style-type: none"> Length: 1-14 characters Valid characters: A-Z, a-z, 0-9 Valid special characters: Hyphen (-) Not allowed: The last character is a hyphen (-)
Password	<ul style="list-style-type: none"> Length: 5-64 characters Valid characters: All ASCII characters

9. Specify the static IP address of the management port of each controller.

Example:

- LAN IP block: 10.8.13.xx
- Controller 1 IP address: 10.8.13.62
- Controller 2 IP address: 10.8.13.78

10. Click **Proceed**.

A confirmation message appears.

Warning

Clicking **Confirm** deletes all data on the drive before installing QES.

11. Click **Confirm**.

The wizard installs QES and restarts the NAS.

You must initialize any unused disks upon your next login.

Installing QES Using a Dynamic IP Address

Warning

Installing QES deletes all data on the drives. Back up your data before proceeding.

1. Power on the NAS.
2. Connect the NAS to your local area network.
3. Run Qfinder Pro on a computer that is connected to the same local area network.

Tip

To download Qfinder Pro, go to <https://www.qnap.com/utilities>.

4. Locate the NAS in the device list.

Tip

Refer to the device type and MAC address to identify the NAS. Its status is a question mark (?).

If the computer is connected to the NAS through the management port, Qfinder Pro will also display the details of the second controller.

5. Double-click an uninitialized controller.
The setup wizard opens.
6. Click **Quick Setup**.
The **Quick Setup** window opens.
7. Specify a NAS name and password.

Field	Requirements
NAS name	<ul style="list-style-type: none"> Length: 1-14 characters Valid characters: A-Z, a-z, 0-9 Valid special characters: Hyphen (-) Not allowed: The last character is a hyphen (-)
Password	<ul style="list-style-type: none"> Length: 5-64 characters Valid characters: All ASCII characters

8. Specify DHCP as the IP address.
9. Click **Proceed**.
A confirmation message appears.

Warning

Clicking **Confirm** deletes all data on the drive before installing QES.

10. Click **Confirm**.
The wizard installs QES and restarts the NAS.
You must initialize any unused disks upon your next login.

Installing QES Using Manual Setup

Warning

Installing QES deletes all data on the drives. Back up your data before proceeding.

1. Power on the NAS.

2. Connect the NAS to your local area network.
3. Run Qfinder Pro on a computer that is connected to the same local area network.

Tip

To download Qfinder Pro, go to <https://www.qnap.com/utilities>.

4. Locate the NAS in the device list, and then double-click the name or IP address.
The setup wizard opens.
5. Click **Manual Setup**.
The **Enter the NAS name and administrator's password** screen appears.
6. Specify a NAS name and password.

Field	Requirements
NAS name	<ul style="list-style-type: none"> Length: 1-14 characters Valid characters: A-Z, a-z, 0-9 Valid special characters: Hyphen (-) Not allowed: The last character is a hyphen (-)
Password	<ul style="list-style-type: none"> Length: 5-64 characters Valid characters: All ASCII characters

7. Click **Next**.
The **Set the date and time** screen appears.
8. Specify the time zone, date, and time.

Tip

QNAP recommends connecting to an NTP server to ensure that the NAS follows the Coordinated Universal Time (UTC) standard.

9. Click **Next**.
The **Configure the network settings** screen appears.
10. Select **Obtain an IP address automatically (DHCP)**.
11. Click **Next**.
The **Cross-platform file transfer service** screen appears.
12. Select the types of devices that you will use to access shared folders on the NAS.
13. Click **Next**.
The **Check system disk status** screen appears.

14. Select a storage pool to install QES on.

Important

Once the installation process starts, the selected storage pool cannot be modified. Reinitialize the NAS before selecting a different disk group.

15. Click **Next**.
The **Summary** screen appears.
16. Review the settings.
17. Click **Apply**.
A confirmation message appears.

Warning

Clicking **Confirm** deletes all data on the drive before installing QES.

18. Click **Confirm**.
The wizard installs QES and restarts the NAS.

Note

You must initialize any unused disks upon your next login.

Service Port Configuration


The service port is the main point for hardware installation, configuration, and maintenance activities.

Important

Only use the service port when directed by QNAP technical support personnel.

Storage Controller Service Port

The storage controller service port is a RS-232 port with an RJ-11 connector. Use the appropriate cable/adaptor (i.e. RJ-11 to DB9/DB9 to USB or RJ-11 to USB) to connect this port with your computer. The pin-outs are defined as follows:




Pin Number	Signal	Description
1	Rx1	Receive Data of UART1
2	Tx1	Transmit Data of UART1
3	GND	Ground
4	Rx2	Receive Data of UART2
5	Tx2	Transmit Data of UART2
6	GND	Ground

Configure the baud rate and character format of the PC or terminal to match these console port default characteristics:

- 115200 baud rate
- 8 data bits
- 1 stop bit
- No parity
- Flow control: XON/XOFF
- Default username/password: `admin/admin`

Expansion Unit Service Port

The expansion unit service port is a RS-232 port with an DB-9 (or DE-9) connector. The pin-outs are defined as the following:



Pin Number	Signal	Description
1	NC	No Connection
2	Rx	Receive Data
3	Tx	Transmit Data
4	NC	No Connection
5	GND	Ground
6	NC	No Connection
7	NC	No Connection
8	NC	No Connection
9	NC	No Connection

Configure the baud rate and character format of the PC or terminal to match these console port default characteristics:

- 115200 baud rate
- 8 data bits
- 1 stop bit
- No parity


- Flow control: XON/XOFF
- Default username/password: admin/admin

Management Port Configuration


Management is provided by the Intel® i210 Gigabit Ethernet controller. The management port allows you to connect to the QES desktop of the ES1686dc R2. The default ES1686dc R2 management website is 169.254.100.100:8080. If the NAS has been configured to use DHCP, you can use the QNAP Qfinder Pro to check the IP address of the NAS. Make sure the NAS and the computer that runs the QNAP Qfinder Pro are connected to the same subnet.

The system requires that the management IP addresses are configured on both controllers and that the controllers' management ports are connected to the management network. This should be a separate LAN or a VLAN because you should not use the production LAN or VLAN for management network traffic. To configure the management port IP address, refer to the QES User Guide. If one storage controller fails, you can enable takeover function from the High Availability app in QES to manage the system through the management port of the other storage controller with the same IP address. For more information, see the QES User Guide.

The following diagrams illustrate management port connections.



Connected to a QES endpoint using DHCP




Directly connected to a QES endpoint

Multipath I/O Network Configuration

Multipath I/O (MPIO) is a fault-tolerance technique where more than one physical network path is created between a server and a storage device such as a NAS. If any one network path goes down due to the failure of a switch, cable, or network card, the server can route I/O through the remaining network paths with no storage downtime. The ES1686dc R2 supports MPIO on iSCSI connections using standard Ethernet infrastructure.

The following diagram is an example of how the multipath I/O should be implemented:



Important**Requirements:**

- Each QES data port must use a static IP address.
- Each server and storage controller must be connected to at least two different physical switches on different subnets.

Recommendations:

- Use dedicated network switches or VLANs to separate iSCSI traffic from other network traffic.

Platform	QNAP Application Note Name
Windows	Configuring Microsoft iSCSI Storage with QNAP Enterprise-Class ES NAS
Linux	Configuring Linux iSCSI Storage with QNAP ES NAS

For further information, see the following user guide: <https://download.qnap.com/Storage/TechnicalDocument/ES1640dc-v2/ESNAS-UG1102-20180103-en.pdf>

4. Troubleshooting

This chapter describes basic troubleshooting information.

Forcing Qfinder Pro to Locate the NAS

If Qfinder Pro is unable to locate the NAS during QES installation, the drives or data may be faulty.

1. Power off the NAS.
2. Remove all drives.
3. Power on the NAS.
4. Locate the NAS using Qfinder Pro.
5. Reinsert the drives.
6. Continue with the QES installation.

Hot-swapping Failed Drives

The NAS supports hot-swapping of drives in the following situations.

RAID Type	Situation
RAID 1	One member drive fails
RAID 5	One member drive fails
RAID 6	One or two member drives fail
RAID 10	One or two member drives in two different pairs fail.
RAID 50	One disk per subgroup fails.
RAID 60	Two disks per subgroup fail.
Triple Mirror	One or two member drives fail.
RAID-TP	One, two, or three member drives fail.

1. Log on to QES as administrator.
2. Go to **Main Menu > Storage Manager > Storage > Disks**.
3. Locate the failed drive.
4. Prepare a new hard drive with a capacity that is the same as or larger than the failed hard drive.
5. Remove the failed drive from the NAS.

6. Wait for 20 seconds or until the NAS beeps twice.
7. Remove the failed drive from the drive tray.
8. Insert the new drive into the drive tray.
9. Install the new drive.
The NAS beeps twice.
10. Go to **Main Menu > Storage Manager > Storage Space**.
11. Locate the volume that contains the new drive and then verify that the status is **Rebuilding**.

Support and other resources

QNAP provides the following resources:

Resource	URL
Documentation	https://download.qnap.com
Compatibility List	https://www.qnap.com/compatibility
NAS Migration Compatibility	https://www.qnap.com/go/nas-migration
Expansion Unit Compatibility	https://www.qnap.com/go/compatibility-expansion
Service Portal	https://service.qnap.com
Product Support Status	https://www.qnap.com/go/product/eol.php
Downloads	https://download.qnap.com
QNAP Community	https://community.qnap.com
QNAP Accessories Store	https://shop.qnap.com

5. Glossary

QES

QNAP NAS operating system

Qfinder Pro

QNAP utility that lets you locate and access QNAP devices in your local area network

6. Notices

This chapter provides information about warranty, disclaimers, licensing, and federal regulations.

Limited warranty

QNAP offers limited warranty service on our products. Your QNAP-branded hardware product is warranted against defects in materials and workmanship for a period of one (1) year or more from the date printed on the invoice. ("Warranty Period"). Please review your statutory rights at www.qnap.com/warranty, which may be amended from time to time by QNAP in its discretion.

Disclaimer

Information in this document is provided in connection with products of QNAP Systems, Inc. (the "QNAP"). No license, express or implied, by estoppels or otherwise, to any intellectual property rights is granted by this document. Except as provided in QNAP's terms and conditions of sale for such products, QNAP assumes no liability whatsoever, and QNAP disclaims any express or implied warranty, relating to sale and/or use of QNAP products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right.

In no event shall QNAP's liability exceed the price paid for the product from direct, indirect, special, incidental, or consequential damages resulting from the use of the product, its accompanying software, or its documentation. QNAP makes no warranty or representation, expressed, implied, or statutory, with respect to its products or the contents or use of this documentation and all accompanying software, and specifically disclaims its quality, performance, merchantability, or fitness for any particular purpose. QNAP reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity.

Back up the system periodically to avoid any potential data loss is recommended. QNAP disclaims any responsibility of all sorts of data loss or recovery.

Should you return any components of the package of QNAP products such as NAS (Network Attached Storage) for refund or maintenance, make sure they are carefully packed for shipping. Any form of damages due to improper packaging will not be compensated.

All the features, functionality, and other product specifications are subject to change without prior notice or obligation. Information contained herein is subject to change without notice.

Further, the ® or ™ symbols are not used in the text.

Copyright and trademarks

Copyright © 2025 QNAP Systems, Inc. All rights reserved.

QNAP and other QNAP product names and logos are proprietary marks, trademarks, or registered trademarks of QNAP Systems, Inc.



The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Other company names and products mentioned herein are trademarks or registered trademarks of their respective holders.

GNU General Public License

Version 3, 29 June 2007

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The GNU General Public License is a free, copy left license for software and other kinds of works.

The licenses for most software and other practical works are designed to take away your freedom to share and change the works. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change all versions of a program--to make sure it remains free software for all its users. We, the Free Software Foundation, use the GNU General Public License for most of our software; it applies also to any other work released this way by its authors. You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for them if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs, and that you know you can do these things.

To protect your rights, we need to prevent others from denying you these rights or asking you to surrender the rights. Therefore, you have certain responsibilities if you distribute copies of the software, or if you modify it: responsibilities to respect the freedom of others.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must pass on to the recipients the same freedoms that you received. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

Developers that use the GNU GPL protect your rights with two steps: (1) assert copyright on the software, and (2) offer you this License giving you legal permission to copy, distribute and/or modify it.

For the developers' and authors' protection, the GPL clearly explains that there is no warranty for this free software. For both users' and authors' sake, the GPL requires that modified versions be marked as changed, so that their problems will not be attributed erroneously to authors of previous versions.

Some devices are designed to deny users access to install or run modified versions of the software inside them, although the manufacturer can do so. This is fundamentally incompatible with the aim of protecting users' freedom to change the software. The systematic pattern of such abuse occurs in the area of products for individuals to use, which is precisely where it is most unacceptable. Therefore, we have designed this version of the GPL to prohibit the practice for those products. If such problems arise substantially in other domains, we stand ready to extend this provision to those domains in future versions of the GPL, as needed to protect the freedom of users.

Finally, every program is threatened constantly by software patents. States should not allow patents to restrict development and use of software on general-purpose computers, but in those that do, we wish to avoid the special danger that patents applied to a free program could make it effectively proprietary. To prevent this, the GPL assures that patents cannot be used to render the program non-free.

The precise terms and conditions for copying, distribution and modification follow.

Terms and Conditions

1. Definitions.

"This License" refers to version 3 of the GNU General Public License.

"Copyright" also means copyright-like laws that apply to other kinds of works, such as semiconductor masks.

"The Program" refers to any copyrightable work licensed under this License. Each licensee is addressed as "you". "Licensees" and "recipients" may be individuals or organizations.

To "modify" a work means to copy from or adapt all or part of the work in a fashion requiring copyright permission, other than the making of an exact copy. The resulting work is called a "modified version" of the earlier work or a work "based on" the earlier work.

A "covered work" means either the unmodified Program or a work based on the Program.

To "propagate" a work means to do anything with it that, without permission, would make you directly or secondarily liable for infringement under applicable copyright law, except executing it on a computer or modifying a private copy. Propagation includes copying, distribution (with or without modification), making available to the public, and in some countries other activities as well.

To "convey" a work means any kind of propagation that enables other parties to make or receive copies. Mere interaction with a user through a computer network, with no transfer of a copy, is not conveying.

An interactive user interface displays "Appropriate Legal Notices" to the extent that it includes a convenient and prominently visible feature that (1) displays an appropriate copyright notice, and (2) tells the user that there is no warranty for the work (except to the extent that warranties are provided), that licensees may convey the work under this License, and how to view a copy of this License. If the interface presents a list of user commands or options, such as a menu, a prominent item in the list meets this criterion.

2. Source Code.

The "source code" for a work means the preferred form of the work for making modifications to it. "Object code" means any non-source form of a work.

A "Standard Interface" means an interface that either is an official standard defined by a recognized standards body, or, in the case of interfaces specified for a particular programming language, one that is widely used among developers working in that language.

The "System Libraries" of an executable work include anything, other than the work as a whole, that (a) is included in the normal form of packaging a Major Component, but which is not

part of that Major Component, and (b) serves only to enable use of the work with that Major Component, or to implement a Standard Interface for which an implementation is available to the public in source code form. A "Major Component", in this context, means a major essential component (kernel, window system, and so on) of the specific operating system (if any) on which the executable work runs, or a compiler used to produce the work, or an object code interpreter used to run it.

The "Corresponding Source" for a work in object code form means all the source code needed to generate, install, and (for an executable work) run the object code and to modify the work, including scripts to control those activities. However, it does not include the work's System Libraries, or general-purpose tools or generally available free programs which are used unmodified in performing those activities but which are not part of the work. For example, Corresponding Source includes interface definition files associated with source files for the work, and the source code for shared libraries and dynamically linked subprograms that the work is specifically designed to require, such as by intimate data communication or control flow between those subprograms and other parts of the work.

The Corresponding Source need not include anything that users can regenerate automatically from other parts of the Corresponding Source.

The Corresponding Source for a work in source code form is that same work.

3. Basic Permissions.

All rights granted under this License are granted for the term of copyright on the Program, and are irrevocable provided the stated conditions are met. This License explicitly affirms your unlimited permission to run the unmodified Program. The output from running a covered work is covered by this License only if the output, given its content, constitutes a covered work. This License acknowledges your rights of fair use or other equivalent, as provided by copyright law. You may make, run and propagate covered works that you do not convey, without conditions so long as your license otherwise remains in force. You may convey covered works to others for the sole purpose of having them make modifications exclusively for you, or provide you with facilities for running those works, provided that you comply with the terms of this License in conveying all material for which you do not control copyright. Those thus making or running the covered works for you must do so exclusively on your behalf, under your direction and control, on terms that prohibit them from making any copies of your copyrighted material outside their relationship with you.

Conveying under any other circumstances is permitted solely under the conditions stated below. Sublicensing is not allowed; section 10 makes it unnecessary.

4. Protecting Users' Legal Rights From Anti-Circumvention Law.

No covered work shall be deemed part of an effective technological measure under any applicable law fulfilling obligations under article 11 of the WIPO copyright treaty adopted on 20 December 1996, or similar laws prohibiting or restricting circumvention of such measures. When you convey a covered work, you waive any legal power to forbid circumvention of technological measures to the extent such circumvention is effected by exercising rights under this License with respect to the covered work, and you disclaim any intention to limit operation or modification of the work as a means of enforcing, against the work's users, your or third parties' legal rights to forbid circumvention of technological measures.

5. Conveying Verbatim Copies.

You may convey verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice; keep intact all notices stating that this License and any non-permissive terms

added in accord with section 7 apply to the code; keep intact all notices of the absence of any warranty; and give all recipients a copy of this License along with the Program.
You may charge any price or no price for each copy that you convey, and you may offer support or warranty protection for a fee.

6. Conveying Modified Source Versions.

You may convey a work based on the Program, or the modifications to produce it from the Program, in the form of source code under the terms of section 4, provided that you also meet all of these conditions:

- a.** The work must carry prominent notices stating that you modified it, and giving a relevant date.
- b.** The work must carry prominent notices stating that it is released under this License and any conditions added under section 7. This requirement modifies the requirement in section 4 to “keep intact all notices”.
- c.** You must license the entire work, as a whole, under this License to anyone who comes into possession of a copy. This License will therefore apply, along with any applicable section 7 additional terms, to the whole of the work, and all its parts, regardless of how they are packaged. This License gives no permission to license the work in any other way, but it does not invalidate such permission if you have separately received it.
- d.** If the work has interactive user interfaces, each must display Appropriate Legal Notices; however, if the Program has interactive interfaces that do not display Appropriate Legal Notices, your work need not make them do so.
A compilation of a covered work with other separate and independent works, which are not by their nature extensions of the covered work, and which are not combined with it such as to form a larger program, in or on a volume of a storage or distribution medium, is called an “aggregate” if the compilation and its resulting copyright are not used to limit the access or legal rights of the compilation's users beyond what the individual works permit. Inclusion of a covered work in an aggregate does not cause this License to apply to the other parts of the aggregate.

7. Conveying Non-Source Forms.

You may convey a covered work in object code form under the terms of sections 4 and 5, provided that you also convey the machine-readable Corresponding Source under the terms of this License, in one of these ways:

- a.** Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by the Corresponding Source fixed on a durable physical medium customarily used for software interchange.
- b.** Convey the object code in, or embodied in, a physical product (including a physical distribution medium), accompanied by a written offer, valid for at least three years and valid for as long as you offer spare parts or customer support for that product model, to give anyone who possesses the object code either (1) a copy of the Corresponding Source for all the software in the product that is covered by this License, on a durable physical medium customarily used for software interchange, for a price no more than your reasonable cost of physically performing this conveying of source, or (2) access to copy the Corresponding Source from a network server at no charge.

- c. Convey individual copies of the object code with a copy of the written offer to provide the Corresponding Source. This alternative is allowed only occasionally and noncommercially, and only if you received the object code with such an offer, in accord with subsection 6b.
- d. Convey the object code by offering access from a designated place (gratis or for a charge), and offer equivalent access to the Corresponding Source in the same way through the same place at no further charge. You need not require recipients to copy the Corresponding Source along with the object code. If the place to copy the object code is a network server, the Corresponding Source may be on a different server (operated by you or a third party) that supports equivalent copying facilities, provided you maintain clear directions next to the object code saying where to find the Corresponding Source. Regardless of what server hosts the Corresponding Source, you remain obligated to ensure that it is available for as long as needed to satisfy these requirements.
- e. Convey the object code using peer-to-peer transmission, provided you inform other peers where the object code and Corresponding Source of the work are being offered to the general public at no charge under subsection 6d.

A separable portion of the object code, whose source code is excluded from the Corresponding Source as a System Library, need not be included in conveying the object code work.

A “User Product” is either (1) a “consumer product”, which means any tangible personal property which is normally used for personal, family, or household purposes, or (2) anything designed or sold for incorporation into a dwelling. In determining whether a product is a consumer product, doubtful cases shall be resolved in favor of coverage. For a particular product received by a particular user, “normally used” refers to a typical or common use of that class of product, regardless of the status of the particular user or of the way in which the particular user actually uses, or expects or is expected to use, the product. A product is a consumer product regardless of whether the product has substantial commercial, industrial or non-consumer uses, unless such uses represent the only significant mode of use of the product.

“Installation Information” for a User Product means any methods, procedures, authorization keys, or other information required to install and execute modified versions of a covered work in that User Product from a modified version of its Corresponding Source. The information must suffice to ensure that the continued functioning of the modified object code is in no case prevented or interfered with solely because modification has been made.

If you convey an object code work under this section in, or with, or specifically for use in, a User Product, and the conveying occurs as part of a transaction in which the right of possession and use of the User Product is transferred to the recipient in perpetuity or for a fixed term (regardless of how the transaction is characterized), the Corresponding Source conveyed under this section must be accompanied by the Installation Information. But this requirement does not apply if neither you nor any third party retains the ability to install modified object code on the User Product (for example, the work has been installed in ROM).

The requirement to provide Installation Information does not include a requirement to continue to provide support service, warranty, or updates for a work that has been modified or installed by the recipient, or for the User Product in which it has been modified or installed. Access to a network may be denied when the modification itself materially and adversely affects the operation of the network or violates the rules and protocols for communication across the network.

Corresponding Source conveyed, and Installation Information provided, in accord with this section must be in a format that is publicly documented (and with an implementation available to the public in source code form), and must require no special password or key for unpacking, reading or copying.

8. Additional Terms.

“Additional permissions” are terms that supplement the terms of this License by making exceptions from one or more of its conditions. Additional permissions that are applicable to the entire Program shall be treated as though they were included in this License, to the extent that they are valid under applicable law. If additional permissions apply only to part of the Program, that part may be used separately under those permissions, but the entire Program remains governed by this License without regard to the additional permissions.

When you convey a copy of a covered work, you may at your option remove any additional permissions from that copy, or from any part of it. (Additional permissions may be written to require their own removal in certain cases when you modify the work.) You may place additional permissions on material, added by you to a covered work, for which you have or can give appropriate copyright permission.

Notwithstanding any other provision of this License, for material you add to a covered work, you may (if authorized by the copyright holders of that material) supplement the terms of this License with terms:

- a. Disclaiming warranty or limiting liability differently from the terms of sections 15 and 16 of this License; or
- b. Requiring preservation of specified reasonable legal notices or author attributions in that material or in the Appropriate Legal Notices displayed by works containing it; or
- c. Prohibiting misrepresentation of the origin of that material, or requiring that modified versions of such material be marked in reasonable ways as different from the original version; or
- d. Limiting the use for publicity purposes of names of licensors or authors of the material; or
- e. Declining to grant rights under trademark law for use of some trade names, trademarks, or service marks; or
- f. Requiring indemnification of licensors and authors of that material by anyone who conveys the material (or modified versions of it) with contractual assumptions of liability to the recipient, for any liability that these contractual assumptions directly impose on those licensors and authors.

All other non-permissive additional terms are considered “further restrictions” within the meaning of section 10. If the Program as you received it, or any part of it, contains a notice stating that it is governed by this License along with a term that is a further restriction, you may remove that term. If a license document contains a further restriction but permits relicensing or conveying under this License, you may add to a covered work material governed by the terms of that license document, provided that the further restriction does not survive such relicensing or conveying.

If you add terms to a covered work in accord with this section, you must place, in the relevant source files, a statement of the additional terms that apply to those files, or a notice indicating where to find the applicable terms.

Additional terms, permissive or non-permissive, may be stated in the form of a separately written license, or stated as exceptions; the above requirements apply either way.

9. Termination.

You may not propagate or modify a covered work except as expressly provided under this License. Any attempt otherwise to propagate or modify it is void, and will automatically terminate your rights under this License (including any patent licenses granted under the third paragraph of section 11).

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, you do not qualify to receive new licenses for the same material under section 10.

10. Acceptance Not Required for Having Copies.

You are not required to accept this License in order to receive or run a copy of the Program.

Ancillary propagation of a covered work occurring solely as a consequence of using peer-to-peer transmission to receive a copy likewise does not require acceptance. However, nothing other than this License grants you permission to propagate or modify any covered work. These actions infringe copyright if you do not accept this License. Therefore, by modifying or propagating a covered work, you indicate your acceptance of this License to do so.

11. Automatic Licensing of Downstream Recipients.

Each time you convey a covered work, the recipient automatically receives a license from the original licensors, to run, modify and propagate that work, subject to this License. You are not responsible for enforcing compliance by third parties with this License.

An “entity transaction” is a transaction transferring control of an organization, or substantially all assets of one, or subdividing an organization, or merging organizations. If propagation of a covered work results from an entity transaction, each party to that transaction who receives a copy of the work also receives whatever licenses to the work the party's predecessor in interest had or could give under the previous paragraph, plus a right to possession of the Corresponding Source of the work from the predecessor in interest, if the predecessor has it or can get it with reasonable efforts.

You may not impose any further restrictions on the exercise of the rights granted or affirmed under this License. For example, you may not impose a license fee, royalty, or other charge for exercise of rights granted under this License, and you may not initiate litigation (including a cross-claim or counterclaim in a lawsuit) alleging that any patent claim is infringed by making, using, selling, offering for sale, or importing the Program or any portion of it.

12. Patents.

A “contributor” is a copyright holder who authorizes use under this License of the Program or a work on which the Program is based. The work thus licensed is called the contributor's “contributor version”.

A contributor's “essential patent claims” are all patent claims owned or controlled by the contributor, whether already acquired or hereafter acquired, that would be infringed by some manner, permitted by this License, of making, using, or selling its contributor version, but do not include claims that would be infringed only as a consequence of further modification of the

contributor version. For purposes of this definition, “control” includes the right to grant patent sublicenses in a manner consistent with the requirements of this License.

Each contributor grants you a non-exclusive, worldwide, royalty-free patent license under the contributor's essential patent claims, to make, use, sell, offer for sale, import and otherwise run, modify and propagate the contents of its contributor version.

In the following three paragraphs, a “patent license” is any express agreement or commitment, however denominated, not to enforce a patent (such as an express permission to practice a patent or covenant not to sue for patent infringement). To “grant” such a patent license to a party means to make such an agreement or commitment not to enforce a patent against the party.

If you convey a covered work, knowingly relying on a patent license, and the Corresponding Source of the work is not available for anyone to copy, free of charge and under the terms of this License, through a publicly available network server or other readily accessible means, then you must either (1) cause the Corresponding Source to be so available, or (2) arrange to deprive yourself of the benefit of the patent license for this particular work, or (3) arrange, in a manner consistent with the requirements of this License, to extend the patent license to downstream recipients. “Knowingly relying” means you have actual knowledge that, but for the patent license, your conveying the covered work in a country, or your recipient's use of the covered work in a country, would infringe one or more identifiable patents in that country that you have reason to believe are valid.

If, pursuant to or in connection with a single transaction or arrangement, you convey, or propagate by procuring conveyance of, a covered work, and grant a patent license to some of the parties receiving the covered work authorizing them to use, propagate, modify or convey a specific copy of the covered work, then the patent license you grant is automatically extended to all recipients of the covered work and works based on it.

A patent license is “discriminatory” if it does not include within the scope of its coverage, prohibits the exercise of, or is conditioned on the non-exercise of one or more of the rights that are specifically granted under this License. You may not convey a covered work if you are a party to an arrangement with a third party that is in the business of distributing software, under which you make payment to the third party based on the extent of your activity of conveying the work, and under which the third party grants, to any of the parties who would receive the covered work from you, a discriminatory patent license (a) in connection with copies of the covered work conveyed by you (or copies made from those copies), or (b) primarily for and in connection with specific products or compilations that contain the covered work, unless you entered into that arrangement, or that patent license was granted, prior to 28 March 2007.

Nothing in this License shall be construed as excluding or limiting any implied license or other defenses to infringement that may otherwise be available to you under applicable patent law.

13. No Surrender of Others' Freedom.

If conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot convey a covered work so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not convey it at all. For example, if you agree to terms that obligate you to collect a royalty for further conveying from those to whom you convey the Program, the only way you could satisfy both those terms and this License would be to refrain entirely from conveying the Program.

14. Use with the GNU Affero General Public License.

Notwithstanding any other provision of this License, you have permission to link or combine any covered work with a work licensed under version 3 of the GNU Affero General Public License

into a single combined work, and to convey the resulting work. The terms of this License will continue to apply to the part which is the covered work, but the special requirements of the GNU Affero General Public License, section 13, concerning interaction through a network will apply to the combination as such.

15. Revised Versions of this License.

The Free Software Foundation may publish revised and/or new versions of the GNU General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies that a certain numbered version of the GNU General Public License “or any later version” applies to it, you have the option of following the terms and conditions either of that numbered version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of the GNU General Public License, you may choose any version ever published by the Free Software Foundation.

If the Program specifies that a proxy can decide which future versions of the GNU General Public License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Program.

Later license versions may give you additional or different permissions. However, no additional obligations are imposed on any author or copyright holder as a result of your choosing to follow a later version.

16. Disclaimer of Warranty.

THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

17. Limitation of Liability.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MODIFIES AND/OR CONVEYS THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

18. Interpretation of Sections 16 and 17.

If the disclaimer of warranty and limitation of liability provided above cannot be given local legal effect according to their terms, reviewing courts shall apply local law that most closely approximates an absolute waiver of all civil liability in connection with the Program, unless a warranty or assumption of liability accompanies a copy of the Program in return for a fee.

END OF TERMS AND CONDITIONS

CE notice



This device complies with CE Compliance Class A.

UKCA notice



This device complies with the UKCA requirements for products sold in Great Britain.

FCC notice

FCC Class A Notice



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Important

Any modifications made to this device that are not approved by QNAP Systems, Inc. may void the authority granted to the user by the FCC to operate this equipment.

VCCI notice

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用する
と電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求される
ことがあります。

VCCI-A

BSMI notice

警告：為避免電磁干擾，本產品不應安裝或使用於住宅環境。

SJ/T 11364-2006

本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
壳体	0	0	0	0	0	0
显示	0	0	0	0	0	0
印刷电路板	0	0	0	0	0	0
金属螺帽	0	0	0	0	0	0
电缆组装	0	0	0	0	0	0
风扇组装	0	0	0	0	0	0
电力供应组 装	0	0	0	0	0	0
电池	0	0	0	0	0	0
O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。						
X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。						