



# ThinkSystem ST45 V3 User Guide



**Machine Type:** 7DH4, 7DH5

## Note

Before using this information and the product it supports, be sure to read and understand the safety information and the safety instructions, which are available at:

[https://pubs.lenovo.com/safety\\_documentation/](https://pubs.lenovo.com/safety_documentation/)

In addition, be sure that you are familiar with the terms and conditions of the Lenovo warranty for your server, which can be found at:

<http://datacentersupport.lenovo.com/warrantylookup>

**Sixth Edition (November 2025)**

**© Copyright Lenovo 2024, 2025.**

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration (GSA) contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

---

# Contents

## Contents . . . . . i

## Safety . . . . . iii

Safety inspection checklist . . . . . iv

## Chapter 1. Introduction . . . . . 1

Features. . . . . 1

Tech Tips . . . . . 2

Security advisories . . . . . 2

Specifications . . . . . 3

    Technical specifications. . . . . 3

    Mechanical specifications . . . . . 6

    Environmental specifications . . . . . 6

Management options. . . . . 8

## Chapter 2. Server components . . . . . 11

Front view . . . . . 11

Rear view . . . . . 12

Side view . . . . . 15

Server locks . . . . . 16

System-board connectors. . . . . 17

## Chapter 3. Parts list . . . . . 19

Power cords . . . . . 21

## Chapter 4. Unboxing and setup . . . . . 23

Server package contents . . . . . 23

Identify the server . . . . . 23

Server setup checklist . . . . . 26

## Chapter 5. Hardware replacement procedures. . . . . 29

Installation Guidelines . . . . . 29

    Safety inspection checklist. . . . . 30

    System reliability guidelines . . . . . 31

    Handling static-sensitive devices . . . . . 31

Memory module installation rules and order . . . . . 33

Power on and power off the server . . . . . 34

    Power on the server . . . . . 34

    Power off the server . . . . . 34

Server replacement . . . . . 34

    Remove the server from rack . . . . . 34

    Install the server to rack . . . . . 36

CMOS battery (CR2032) replacement . . . . . 40

    Remove the CMOS battery (CR2032) . . . . . 40

    Install the CMOS battery (CR2032) . . . . . 42

Drive and drive cage replacement. . . . . 44

Simple-swap drive and drive cage replacement (bay 0-1). . . . . 44

Simple-swap drive and drive cage replacement (bay 2) . . . . . 58

Simple-swap drive and drive cage replacement (bay 3) . . . . . 68

Optical drive and drive cage replacement . . . . . 79

Fan replacement . . . . . 90

    Remove the fan (front and rear) . . . . . 90

    Install the fan (front and rear) . . . . . 93

Front bezel replacement . . . . . 95

    Remove the front bezel . . . . . 95

    Install the front bezel . . . . . 96

Heat sink and fan module replacement (trained technician only) . . . . . 97

    Remove the heat sink and fan module (trained technician only) . . . . . 97

    Install the heat sink and fan module (trained technician only) . . . . . 99

M.2 drive replacement . . . . . 101

    Remove an M.2 drive . . . . . 101

    Install an M.2 drive . . . . . 103

    Remove the M.2 drive retainer . . . . . 105

    Install the M.2 drive retainer . . . . . 107

Memory module replacement . . . . . 108

    Remove a memory module . . . . . 108

    Install a memory module . . . . . 111

Mono amplifier (speaker) replacement . . . . . 114

    Remove the mono amplifier (speaker) . . . . . 114

    Install the mono amplifier (speaker) . . . . . 115

PCIe adapter replacement. . . . . 116

    Remove a PCIe adapter . . . . . 116

    Install a PCIe adapter . . . . . 119

Power button with LED replacement. . . . . 121

    Remove the power button with LED . . . . . 121

    Install the power button with LED . . . . . 125

Power supply unit replacement. . . . . 127

    Remove the power supply unit . . . . . 127

    Install the power supply unit . . . . . 130

Processor replacement (trained technician only) . . . . . 133

    Remove the processor (trained technician only) . . . . . 133

    Install the processor (trained technician only) . . . . . 135

System board replacement (trained technician only) . . . . . 137

    Remove the system board . . . . . 138

|                                          |     |
|------------------------------------------|-----|
| Install the system board . . . . .       | 142 |
| Server cover replacement . . . . .       | 146 |
| Remove the server cover . . . . .        | 146 |
| Install the server cover . . . . .       | 148 |
| Thermal sensor replacement . . . . .     | 151 |
| Remove the thermal sensor . . . . .      | 151 |
| Install the thermal sensor . . . . .     | 153 |
| Complete the parts replacement . . . . . | 154 |

## **Chapter 6. Internal cable routing . . .157**

|                                                         |     |
|---------------------------------------------------------|-----|
| Cable routing for bay 0 drive . . . . .                 | 158 |
| Cable routing for bay 1 drive . . . . .                 | 159 |
| Cable routing for bay 2 drive . . . . .                 | 161 |
| Cable routing for bay 3 drive . . . . .                 | 163 |
| Cable routing for optical disk drive . . . . .          | 164 |
| Cable routing for the RAID adapter and drives . . . . . | 166 |
| Cable routing for the power supply unit . . . . .       | 169 |
| Cable routing for the front fan and rear fan . . . . .  | 170 |
| Cable routing for the heat sink and fan module. . . . . | 171 |
| Cable routing for the thermal sensor . . . . .          | 172 |
| Cable routing for the mono amplifier . . . . .          | 173 |
| Cable routing for the power button with LED . . . . .   | 174 |

## **Chapter 7. System configuration . . .175**

|                                                        |     |
|--------------------------------------------------------|-----|
| Update the firmware . . . . .                          | 175 |
| Configure the firmware . . . . .                       | 175 |
| Starting the Setup Utility program . . . . .           | 175 |
| Enabling or disabling a device . . . . .               | 175 |
| Enabling or disabling the automatic power-on . . . . . | 176 |
| Using passwords . . . . .                              | 176 |
| Selecting a startup device . . . . .                   | 177 |
| Exiting the Setup Utility program . . . . .            | 178 |
| Memory configuration . . . . .                         | 178 |
| RAID configuration . . . . .                           | 179 |
| Enabling AMD RAIDXpert2. . . . .                       | 179 |
| AMD RAIDXpert2 configurations . . . . .                | 179 |
| Monitor RAID status . . . . .                          | 180 |
| Restore (Rebuild) arrays. . . . .                      | 180 |
| Deploy the operating system. . . . .                   | 181 |
| Back up the server configuration . . . . .             | 181 |

## **Chapter 8. Problem determination . . .183**

|                                   |     |
|-----------------------------------|-----|
| Event logs . . . . .              | 183 |
| Troubleshooting by LEDs . . . . . | 183 |
| System-board LED. . . . .         | 183 |

|                                                              |     |
|--------------------------------------------------------------|-----|
| Ethernet port (10/100/1000 Mbps RJ-45) LEDs . . . . .        | 184 |
| General problem determination procedures . . . . .           | 185 |
| Resolving suspected power problems . . . . .                 | 185 |
| Resolving suspected Ethernet controller problems . . . . .   | 186 |
| Troubleshooting by symptom . . . . .                         | 186 |
| Audio problems . . . . .                                     | 187 |
| Intermittent problems. . . . .                               | 187 |
| Keyboard, mouse, KVM switch or USB-device problems . . . . . | 187 |
| Memory problems . . . . .                                    | 188 |
| Microsoft Server 2022 activation problem . . . . .           | 189 |
| Microsoft Server 2025 activation problem . . . . .           | 190 |
| Monitor and video problems . . . . .                         | 192 |
| Network problems . . . . .                                   | 194 |
| Observable problems. . . . .                                 | 194 |
| Optional-device problems . . . . .                           | 195 |
| Performance problems . . . . .                               | 197 |
| Power on and power off problems. . . . .                     | 197 |
| Software problems. . . . .                                   | 198 |
| Storage drive problems . . . . .                             | 198 |
| UEFI upgrade problem . . . . .                               | 199 |

## **Appendix A. Hardware disassembling for recycle . . . . .201**

|                                                    |     |
|----------------------------------------------------|-----|
| Disassemble the system board for recycle . . . . . | 201 |
|----------------------------------------------------|-----|

## **Appendix B. Getting help and technical assistance . . . . .205**

|                              |     |
|------------------------------|-----|
| Before you call . . . . .    | 205 |
| Contacting Support . . . . . | 206 |

## **Appendix C. Documents and supports . . . . .207**

|                              |     |
|------------------------------|-----|
| Documents download . . . . . | 207 |
| Support websites . . . . .   | 207 |

## **Appendix D. Notices. . . . .209**

|                                                               |     |
|---------------------------------------------------------------|-----|
| Trademarks . . . . .                                          | 210 |
| Important notes. . . . .                                      | 210 |
| Electronic emission notices . . . . .                         | 210 |
| Taiwan Region BSMI RoHS declaration . . . . .                 | 211 |
| Taiwan Region import and export contact information . . . . . | 211 |
| China Energy Label (CEL) . . . . .                            | 211 |

---

## Safety

Before installing this product, read the Safety Information.

قبل تركيب هذا المنتج، يجب قراءة الملاحظات الأمنية

Antes de instalar este produto, leia as Informações de Segurança.

在安装本产品之前，请仔细阅读 Safety Information（安全信息）。

安裝本產品之前，請先閱讀「安全資訊」。

Prije instalacije ovog produkta obavezno pročitajte Sigurnosne Upute.

Před instalací tohoto produktu si přečtěte příručku bezpečnostních instrukcí.

Læs sikkerhedsforskrifterne, før du installerer dette produkt.

Lees voordat u dit product installeert eerst de veiligheidsvoorschriften.

Ennen kuin asennat tämän tuotteen, lue turvaohjeet kohdasta Safety Information.

Avant d'installer ce produit, lisez les consignes de sécurité.

Vor der Installation dieses Produkts die Sicherheitshinweise lesen.

Πριν εγκαταστήσετε το προϊόν αυτό, διαβάστε τις πληροφορίες ασφάλειας (safety information).

לפני שתתקינו מוצר זה, קראו את הוראות הבטיחות.


A termék telepítése előtt olvassa el a Biztonsági előírásokat!

Prima di installare questo prodotto, leggere le Informazioni sulla Sicurezza.

製品の設置の前に、安全情報をお読みください。

본 제품을 설치하기 전에 안전 정보를 읽으십시오.

Пред да се инсталира овој продукт, прочитајте информацијата за безбедност.



Les sikkerhetsinformasjonen (Safety Information) før du installerer dette produktet.

Przed zainstalowaniem tego produktu, należy zapoznać się z książką "Informacje dotyczące bezpieczeństwa" (Safety Information).

Antes de instalar este produto, leia as Informações sobre Segurança.

Перед установкой продукта прочтите инструкции по технике безопасности.

Pred inštaláciou tohto zariadenia si pečítajte Bezpečnostné predpisy.

Pred namestitvijo tega proizvoda preberite Varnostne informacije.

Antes de instalar este producto, lea la información de seguridad.

Läs säkerhetsinformationen innan du installerar den här produkten.

ཐོན་ཐབས་འདི་བདེ་སྤྱད་མ་བྱས་གོང་། སྐྱོར་གྱི་ཡིད་གཟབ་  
བྱ་འདྲ་མིན་ཡིད་པའི་འོད་མེར་བལྟ་དགོས།

Bu ürünü kurmadan önce güvenlik bilgilerini okuyun.

مەزكۇر مەھسۇلاتنى ئورنىتىشتىن بۇرۇن بىخەتەرلىك ئۇچۇرلىرىنى ئوقۇپ چىقىڭ.

Youq mwngz yungh canjbinj neix gaxgonq, itdingh aeu doeg aen  
canjbinj soengq cungj vahgangj ancien siusik.

---

## Safety inspection checklist

Use the information in this section to identify potentially unsafe conditions with your server. As each machine was designed and built, required safety items were installed to protect users and service technicians from injury.

**Note:** The product is not suitable for use at visual display workplaces according to §2 of the Workplace Regulations.

**Attention:** This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

### CAUTION:

**This equipment must be installed or serviced by trained personnel, as defined by the IEC 62368-1, the standard for Safety of Electronic Equipment within the Field of Audio/Video, Information Technology and Communication Technology. Lenovo assumes you are qualified in the servicing of equipment and trained in recognizing hazards energy levels in products. Access to the equipment is by the use of a tool, lock and key, or other means of security, and is controlled by the authority responsible for the location.**

**Important:** Electrical grounding of the server is required for operator safety and correct system function. Proper grounding of the electrical outlet can be verified by a certified electrician.

Use the following checklist to verify that there are no potentially unsafe conditions:

1. Make sure that the power is off and the power cord is disconnected.
2. Check the power cord.
  - Make sure that the third-wire ground connector is in good condition. Use a meter to measure third-wire ground continuity for 0.1 ohm or less between the external ground pin and the frame ground.
  - Make sure that the power cord is the correct type.

To view the power cords that are available for the server:

- a. Go to:

<http://dcsc.lenovo.com/#/>

- b. Click **Preconfigured Model** or **Configure to order**.
  - c. Enter the machine type and model for your server to display the configurator page.
  - d. Click **Power → Power Cables** to see all line cords.
- Make sure that the insulation is not frayed or worn.
3. Check for any obvious non-Lenovo alterations. Use good judgment as to the safety of any non-Lenovo alterations.
4. Check inside the server for any obvious unsafe conditions, such as metal filings, contamination, water or other liquid, or signs of fire or smoke damage.
5. Check for worn, frayed, or pinched cables.
6. Make sure that the power-supply cover fasteners (screws or rivets) have not been removed or tampered with.




---

## Chapter 1. Introduction

The ThinkSystem ST45 V3 server (Types 7DH4 and 7DH5) is an entry 1 socket tower server ideal for small businesses, home offices, retail, educational institutions and branch offices. The server supports one AMD® EPYC™ 4004 series processor and up to 64 GB of 5200 MHz ECC DDR5 memory. With the modular design, the server is flexible to be customized for maximum storage capacity or high storage density with selectable input/output options and tiered system management.

*Figure 1. ThinkSystem ST45 V3*



---

## Features

Performance, ease of use, reliability, and expansion capabilities were key considerations in the design of your server. These design features make it possible for you to customize the system hardware to meet your needs today and provide flexible expansion capabilities for the future.

Your server implements the following features and technologies:

- **UEFI-compliant server firmware**

Lenovo ThinkSystem firmware is Unified Extensible Firmware Interface (UEFI) compliant. UEFI replaces BIOS and defines a standard interface between the operating system, platform firmware, and external devices.

Lenovo ThinkSystem servers are capable of booting UEFI-compliant operating systems, BIOS-based operating systems, and BIOS-based adapters as well as UEFI-compliant adapters.

**Note:** The server does not support Disk Operating System (DOS).

- **Large system-memory capacity**

The server supports error-correcting code unbuffered DIMM (ECC UDIMM). For more information about the specific types and maximum amount of memory, see [“Technical specifications” on page 3](#).

- **Large data-storage capacity**

The server supports a maximum of four drives or three drives and one slim SATA optical disk drive.

- **Mobile access to Lenovo Service Information website**

The server provides a QR code on the inside of the server cover, that you can scan the QR code with a mobile device and a QR code reader application to get quick access to the Lenovo Service web site for this server. The Lenovo Service Information website provides additional information for parts installation, replacement videos, and error codes for server support.

- **Lenovo XClarity Provisioning Manager Lite**

Lenovo XClarity Provisioning Manager Lite allows you to configure Redundant Array of Independent Disks (RAID), install compatible operating systems as well as associated device drivers, and run diagnostics. For more details, see <https://pubs.lenovo.com/lxpm-lite/>.

- **Reliability/Availability/Serviceability (RAS)**

EPYC 4004 RAS features include on-chip ECC/parity, on-package link CRC, PCIe LCRC, PCIe ECRC, and PCIe uncorrected error detection. Correction of single-bit memory errors and PCIe correctable errors support is limited to the hardware layer and offers no support for Windows Hardware Error Architecture (WHEA) or Error Detection and Correction (EDAC).

- **Tremendous durability**

The system has been verified to run even enterprise workload, 24/7.

---

## Tech Tips

Lenovo continually updates the support website with the latest tips and techniques that you can use to solve issues that your server might encounter. These Tech Tips (also called retain tips or service bulletins) provide procedures to work around issues or solve problems related to the operation of your server.

To find the Tech Tips available for your server:

1. Go to <http://datacentersupport.lenovo.com> and navigate to the support page for your server.
2. Click on **How To's** from the navigation pane.
3. Click **Article Type** → **Solution** from the drop-down menu.

Follow the on-screen instructions to choose the category for the problem that you are having.

---

## Security advisories

Lenovo is committed to developing products and services that adhere to the highest security standards in order to protect our customers and their data. When potential vulnerabilities are reported, it is the responsibility of the Lenovo Product Security Incident Response Team (PSIRT) to investigate and provide information to our customers so they may put mitigation plans in place as we work toward providing solutions.

The list of current advisories is available at the following site:

## Specifications

Summary of the features and specifications of the server. Depending on the model, some features might not be available, or some specifications might not apply.

Refer to the below table for specifications categories and the content of each category.

| Specification category | Technical specifications                                                                                                                                                                                                                                                                                                                                                        | Mechanical specifications                                                    | Environmental specifications                                                                       |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| Content                | <ul style="list-style-type: none"><li>• Processor</li><li>• Memory</li><li>• M.2 drive</li><li>• Storage expansion</li><li>• Expansion slots</li><li>• Integrated functions and I/O connectors</li><li>• Network</li><li>• RAID/HBA adapter</li><li>• System fan</li><li>• Electrical input</li><li>• Minimal configuration for debugging</li><li>• Operating systems</li></ul> | <ul style="list-style-type: none"><li>• Dimension</li><li>• Weight</li></ul> | <ul style="list-style-type: none"><li>• Acoustical noise emissions</li><li>• Environment</li></ul> |

## Technical specifications

Summary of the technical specifications of server. Depending on the model, some features might not be available, or some specifications might not apply.

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Processor</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <p>The server supports AMD® EPYC™ 4004 and 4005 series processors.</p> <ul style="list-style-type: none"><li>• Up to 12 cores for 4004 series processors and 16 cores for 4005 series processors</li><li>• Thermal Design Power (TDP): up to 65 W</li></ul> <p>For a list of supported processors, see <a href="https://serverproven.lenovo.com">https://serverproven.lenovo.com</a>.</p>                                                                                                                                                                                                                                              |
| <b>Memory</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <p>See “<a href="#">Memory module installation rules and order</a>” on page 33 for detailed information about memory configuration and setup.</p> <ul style="list-style-type: none"><li>• Minimum capacity: 16 GB</li><li>• Maximum capacity: 64 GB</li><li>• Slots: two DIMM slots (1 DIMM per channel)</li><li>• Memory module type:<ul style="list-style-type: none"><li>– ThinkSystem 16GB TruDDR5 5600MHz (1Rx8) ECC UDIMM-A</li><li>– ThinkSystem 32GB TruDDR5 5600MHz (2Rx8) ECC UDIMM-A</li></ul></li></ul> <p><b>Note:</b> ThinkSystem 32GB TruDDR5 5600MHz (2Rx8) ECC UDIMM-A is compatible with 4004 series processors.</p> |

## M.2 drive

The server supports up to two NVMe M.2 drives of the following drive form factor: 80 mm (2280). Supports the following M.2 drive capacity:

- 480 GB
- 960 GB

For a list of supported M.2 drives, see <https://serverproven.lenovo.com>.

## Storage expansion

The server supports three 3.5-inch drive bays (optional), one 2.5-inch drive bay (optional), and one ODD bay (optional).

- Drive bay 0 (optional)
  - 3.5-inch hard-disk drive or solid-state drive
- Drive bay 1 (optional)
  - 2.5-inch hard-disk drive or solid-state drive
- Drive bay 2 (optional)
  - 3.5-inch hard-disk drive or solid-state drive
- Drive bay 3 (optional)
  - 3.5-inch hard-disk drive or solid-state drive
- ODD bay (optional)
  - One 9mm slim SATA optical disk drive

For a list of supported drives, see <https://serverproven.lenovo.com>.

## Expansion slots

Two PCIe expansion slots are available:

- PCIe slot 1: PCIe Gen3 x16, FH/HL, 75W
- PCIe slot 3: PCIe Gen3 x1, FH/HL, 25W

## Integrated functions and I/O connectors

- Front connectors:
  - One Mic-in connector (supported by Windows Client OS only)
  - One headset connector (supported by Windows Client OS only)
  - One USB Type-C 3.2 Gen 1 (5 Gbps) connector
  - Four USB Type-A 3.2 Gen 1 (5 Gbps) connectors
- Rear connectors:
  - One audio line-out connector (supported by Windows Client OS only)
  - Two DisplayPort (DP) connectors
  - One High-Definition Multimedia Interface (HDMI) connector
  - One Ethernet port (10/100/1000 Mbps RJ-45)
  - Four USB Type-A 2.0 connectors

**Note:** The maximum video resolution is 3840 x 2160 at 60 Hz.

## Network

- One Ethernet port (10/100/1000 Mbps RJ-45)
- One of the following network adapters:
  - ThinkSystem Broadcom 5719 1GbE RJ45 4-Port PCIe Ethernet Adapter
  - ThinkSystem Broadcom 57416 10GBASE-T 2-Port PCIe Ethernet Adapter

### RAID adapter

The following options are available for this server.

- Hardware RAID (RAID levels 0, 1, and 5)
  - ThinkSystem RAID 5350-8i PCIe 12Gb Adapter
  - ThinkSystem RAID 545-8i PCIe Gen4 12Gb Adapter
- Software RAID (RAID levels 0 and 1)
  - AMD RAIDXpert2

#### Notes:

- AMD RAIDXpert2 is supported only in Windows Server operating systems.
- LXPm Lite does not support the AMD RAIDXpert2 function.
- Users need to build RAID by themselves because ST45 V3 does not support pre-configuring AMD RAIDXpert2 on manufacturing.
- UEFI version 1.20 (build ID QIE104D) or later is required for the AMD RAIDXpert2 function.

For more information about the RAID/HBA adapters, see [Lenovo ThinkSystem RAID Adapter and HBA Reference](#).

### Host bus adapter

- ThinkSystem 4350-8i SAS/SATA 12Gb HBA

For more information about the RAID/HBA adapters, see [Lenovo ThinkSystem RAID Adapter and HBA Reference](#).

### System fan

The server supports up to three fans:

- One front fan
- One rear fan
- One processor heat sink fan

### Electrical input

The server supports one of the following non-hot-swap, non-redundant power supplies:

- Fixed ATX 300-watt Single-Output Gold
  - Input power 115 Vac or 230 Vac
- Fixed ATX 500-watt Multi-Output Platinum
  - Input power 115 Vac or 230 Vac

### Minimal configuration for debugging

- One processor and one processor cooling heat sink
- One 16 GB ECC UDIMM in DIMM slot 1
- One power supply
- One power cord
- One 3.5-inch SATA drive in drive bay 0
- One system front fan (if debugging is out of chassis)

## Operating systems

Supported and certified operating systems:

- Microsoft Windows Server
- Red Hat Enterprise Linux
- SUSE Linux Enterprise Server
- Canonical Ubuntu

References:

- Complete list of available operating systems: <https://lenovopress.lenovo.com/osig>.
- OS deployment instructions: “Deploy the operating system” on page 181.

## Mechanical specifications

Summary of the mechanical specifications of server. Depending on the model, some features might not be available, or some specifications might not apply.

### Dimension

- Width: 170 mm (6.7 inches)
- Height:
  - With stands: 376 mm (14.8 inches)
  - Without stands: 370 mm (14.6 inches)
- Depth: 315.4 mm (12.4 inches)

### Weight

Net weight: up to 8.56 kg (18.87 lb) depending upon configuration

## Environmental specifications

Summary of the environmental specifications of server. Depending on the model, some features might not be available, or some specifications might not apply.

### Acoustical noise emissions

The server has the following acoustic noise emissions declaration:

| Configuration         |           | Typical |
|-----------------------|-----------|---------|
| LWA <sub>m</sub> (B)  | Idle      | 3.5     |
|                       | Operating | 4.5     |
| K <sub>v</sub> (B)    | Idle      | 0.4     |
|                       | Operating | 0.4     |
| LpA <sub>m</sub> (dB) | Idle      | 24.6    |

## Acoustical noise emissions

|  |           |      |
|--|-----------|------|
|  | Operating | 34.2 |
|--|-----------|------|

### Notes:

- These sound levels were measured in controlled acoustical environments according to procedures specified by ISO 7779 and are reported in accordance with ISO 9296. Testing was conducted at 23°C ± 2°C to align with ISO7779 procedures.
- Idling mode is the steady state in which the server is powered on but not operating any intended function. Operating mode 1 is 100% CPU TDP.
- The declared acoustic sound levels are based on the following configuration, which may change depending on configuration/conditions:
  - Typical: 1x 65 W CPU, 2x 32 GB DIMM, 3x 3.5" HDD, 1x 2.5" SSD, 2x 960 GB M.2, 1x 5350-8i RAID, 1x 500 W fixed PSU

## Environment

ThinkSystem ST45 V3 complies with ASHRAE Class A2 specifications. System performance may be impacted when the operating temperature is outside AHSARE A2 specification.

- Air temperature:
  - Operating
    - ASHRAE Class A2: 10°C to 35°C (50°F to 95°F); the maximum ambient temperature decreases by 1°C for every 300 m (984 ft) increase in altitude above 900 m (2,953 ft).
  - Server off: 5°C to 45°C (41°F to 113°F)
  - Shipment/storage: -20°C to 60°C (-4°F to 140°F)
- Maximum altitude: 3,050 m (10,000 ft)
- Relative Humidity (non-condensing):
  - Operating: 8% to 80%; maximum dew point: 21°C (70°F)
  - Shipment/storage: 8% to 90%
- Particulate contamination

**Attention:** Airborne particulates and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the server. For information about the limits for particulates and gases, see [“Particulate contamination” on page 7](#).

**Note:** The server is designed for standard data center environment and recommended to be placed in industrial data center.

## Particulate contamination

**Attention:** Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the device that is described in this document.

Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the device to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If Lenovo determines that the levels of particulates or gases in your environment have caused damage to the device, Lenovo may condition provision of repair or replacement of devices or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Table 1. Limits for particulates and gases

| Contaminant                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Limits                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Reactive gases                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <p>Severity level G1 as per ANSI/ISA 71.04-1985<sup>1</sup>:</p> <ul style="list-style-type: none"> <li>The copper reactivity level shall be less than 200 Angstroms per month (<math>\text{\AA}/\text{month} \approx 0.0035 \mu\text{g}/\text{cm}^2\text{-hour weight gain}</math>).<sup>2</sup></li> <li>The silver reactivity level shall be less than 200 Angstroms per month (<math>\text{\AA}/\text{month} \approx 0.0035 \mu\text{g}/\text{cm}^2\text{-hour weight gain}</math>).<sup>3</sup></li> <li>The reactive monitoring of gaseous corrosivity must be conducted approximately 5 cm (2 in.) in front of the rack on the air inlet side at one-quarter and three-quarter frame height off the floor or where the air velocity is much higher.</li> </ul>                                                                                                |
| Airborne particulates                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <p>Data centers must meet the cleanliness level of ISO 14644-1 class 8.</p> <p>For data centers without airside economizer, the ISO 14644-1 class 8 cleanliness might be met by choosing one of the following filtration methods:</p> <ul style="list-style-type: none"> <li>The room air might be continuously filtered with MERV 8 filters.</li> <li>Air entering a data center might be filtered with MERV 11 or preferably MERV 13 filters.</li> </ul> <p>For data centers with airside economizers, the choice of filters to achieve ISO class 8 cleanliness depends on the specific conditions present at that data center.</p> <ul style="list-style-type: none"> <li>The deliquescent relative humidity of the particulate contamination should be more than 60% RH.<sup>4</sup></li> <li>Data centers must be free of zinc whiskers.<sup>5</sup></li> </ul> |
| <p><sup>1</sup> ANSI/ISA-71.04-1985. <i>Environmental conditions for process measurement and control systems: Airborne contaminants</i>. Instrument Society of America, Research Triangle Park, North Carolina, U.S.A.</p> <p><sup>2</sup> The derivation of the equivalence between the rate of copper corrosion growth in the thickness of the corrosion product in <math>\text{\AA}/\text{month}</math> and the rate of weight gain assumes that <math>\text{Cu}_2\text{S}</math> and <math>\text{Cu}_2\text{O}</math> grow in equal proportions.</p> <p><sup>3</sup> The derivation of the equivalence between the rate of silver corrosion growth in the thickness of the corrosion product in <math>\text{\AA}/\text{month}</math> and the rate of weight gain assumes that <math>\text{Ag}_2\text{S}</math> is the only corrosion product.</p> <p><sup>4</sup> The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote ionic conduction.</p> <p><sup>5</sup> Surface debris is randomly collected from 10 areas of the data center on a 1.5 cm diameter disk of sticky electrically conductive tape on a metal stub. If examination of the sticky tape in a scanning electron microscope reveals no zinc whiskers, the data center is considered free of zinc whiskers.</p> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

## Management options

The system management options described in this section are available to help you manage the servers more conveniently and efficiently.

## Overview

| Offerings                                 | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Lenovo XClarity Essentials toolset        | <p>Portable and light toolset for data collection and firmware updates. Suitable both for single-server or multi-server management contexts.</p> <p><b>Interface</b></p> <ul style="list-style-type: none"> <li>• <b>OneCLI</b>: CLI application</li> <li>• <b>Bootable Media Creator</b>: CLI application, GUI application</li> </ul> <p><b>Usage and downloads</b></p> <p><a href="https://pubs.lenovo.com/lxce-overview/">https://pubs.lenovo.com/lxce-overview/</a></p> |
| Lenovo XClarity Provisioning Manager Lite | <p>UEFI-based embedded GUI tool on a single server that can simplify management tasks.</p> <p><b>Interface</b></p> <ul style="list-style-type: none"> <li>• GUI application</li> </ul> <p><b>Usage and downloads</b></p> <p><a href="https://pubs.lenovo.com/lxpm-lite/">https://pubs.lenovo.com/lxpm-lite/</a></p>                                                                                                                                                         |
| Lenovo Capacity Planner                   | <p>Application that supports power consumption planning for a server or rack.</p> <p><b>Interface</b></p> <ul style="list-style-type: none"> <li>• Web GUI Interface</li> </ul> <p><b>Usage and downloads</b></p> <p><a href="https://datacentersupport.lenovo.com/solutions/Invo-lcp">https://datacentersupport.lenovo.com/solutions/Invo-lcp</a></p>                                                                                                                      |

## Functions

| Options                                   |                        | Functions     |                      |                               |                 |                |
|-------------------------------------------|------------------------|---------------|----------------------|-------------------------------|-----------------|----------------|
|                                           |                        | OS deployment | System configuration | Firmware updates <sup>1</sup> | Inventory/ logs | Power planning |
| Lenovo XClarity Essentials toolset        | OneCLI                 |               |                      |                               | √ <sup>3</sup>  |                |
|                                           | Bootable Media Creator |               |                      | √ <sup>5</sup>                |                 |                |
| Lenovo XClarity Provisioning Manager Lite |                        | √             | √                    | √ <sup>2</sup>                | √ <sup>3</sup>  |                |
| Lenovo Capacity Planner                   |                        |               |                      |                               |                 | √ <sup>4</sup> |

### Notes:

1. Most options can be updated through the Lenovo tools. Some options such as Client HDD firmware require the use of supplier tools.
2. Firmware updates are limited to Lenovo XClarity Provisioning Manager Lite and UEFI updates only. Firmware updates for optional devices, such as adapters, are not supported.
3. Limited inventory.
4. It's highly recommended that you check the power summary data for your server using Lenovo Capacity Planner before purchasing any new parts.

5. Security Boot needs to be disabled for UEFI update on Bootable media Creator (BoMC).

# Chapter 2. Server components

This chapter contains information about each of the components associated with the server.

## Front view

This section contains information about the controls, LEDs, and connectors on the front of the server.




Figure 2. Front view

Table 2. Components on the front view

|                                                    |                                                        |
|----------------------------------------------------|--------------------------------------------------------|
| <b>1</b> Power button/LED (white)                  | <b>2</b> Drive activity LED (white)                    |
| <b>3</b> Mic-in connector (Windows Client OS only) | <b>4</b> Headset connector (Windows Client OS only)    |
| <b>5</b> USB Type-C 3.2 Gen 1 (5 Gbps) connector   | <b>6</b> USB Type-A 3.2 Gen 1 (5 Gbps) connectors (x4) |
| <b>7</b> Front thermal sensor                      | <b>8</b> Optical-drive bay (optional)                  |

### 1 Power button/LED (white)

Press this button to turn the server on and off manually. The states of the power LED are as follows:

| Status   | Color | Description        |
|----------|-------|--------------------|
| Solid on | white | The server is on.  |
| Off      | None  | The server is off. |

### 2 Drive activity LED (white)

This LED indicates the activity of the drives.

**Note:** The drive activity LED only indicates the activities of drives that are connected to the SATA ports on the system board.

| Status   | Color | Description                |
|----------|-------|----------------------------|
| Blinking | White | The drives are active.     |
| Off      | None  | The drives are not active. |

### 3 Mic-in connector

Plug in a microphone to this connector.

**Note:** This connector is only supported by Windows Client OS.

### 4 Headset connector

Plug in a headset with microphone to this connector. A standard headphone or microphone can also be plugged into the connector.

**Note:** This connector is only supported by Windows Client OS.

### 5 USB Type-C 3.2 Gen 1 (5 Gbps) connector

The connector is available for a Type-C compatible device that requires USB 2.0 or 3.0 connection, such as a keyboard, a mouse, or a USB flash drive.

### 6 USB Type-A 3.2 Gen 1 (5 Gbps) connectors (x4)

These connectors are available for Type-A compatible devices that require USB 2.0 or 3.0 connection, such as a keyboard, a mouse, or a USB flash drive.

### 7 Front thermal sensor

The thermal sensor works by converting temperature variations into electrical signals. It can measure the temperature of a system or space.

### 8 Optical drive bay

Depending on the model, the server might come with an optical drive installed in this drive bay. See [“Optical drive and drive cage replacement” on page 79](#).

---

## Rear view

This section contains information about the important components on the rear of this server.




Figure 3. Rear view

Table 3. Components on the rear view

|                                         |                                                 |
|-----------------------------------------|-------------------------------------------------|
| <b>1</b> Rear fan                       | <b>2</b> Padlock loop                           |
| <b>3</b> Kensington lock slot           | <b>4</b> Power cord connector                   |
| <b>5</b> PCIe slot 3                    | <b>6</b> PCIe slot 1                            |
| <b>7</b> USB Type-A 2.0 connectors (x4) | <b>8</b> Ethernet port (10/100/1000 Mbps RJ-45) |
| <b>9</b> HDMI connector                 | <b>10</b> DisplayPort connectors (x2)           |
| <b>11</b> Audio line-out connector      |                                                 |

#### **1** Rear fan

The rear fan is installed in this space. See [“Install the fan \(front and rear\)” on page 93](#).

#### **2** Padlock loop

This loop is available for installing a padlock. See [“Server locks” on page 16](#) for more information.

#### **3** Kensington lock slot

This slot is available for installing a Kensington lock. See [“Server locks” on page 16](#) for more information.

#### 4 Power cord connector

Connect the power cord to this connector.

#### 5/6 PCIe slots

There are two PCIe slots on the system board for installing appropriate PCIe adapters. For information about the PCIe slots, see “Expansion slots” in [“Technical specifications” on page 3](#).

#### 7 USB Type-A 2.0 connectors (x4)

These connectors are available for a Type-A compatible device that require USB 2.0 connection, such as a keyboard, a mouse, or a USB flash drive.

#### 8 Ethernet port (10/100/1000 Mbps RJ-45)

Connect an Ethernet cable to this connector for a LAN. This connector comes with LEDs for status indication.




Figure 4. Ethernet port (10/100/1000 Mbps RJ-45) LEDs

| LED                   | Description                                                                                                                                                                                                                                                                                                                                                               |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Link LED     | Use this LED to distinguish the network connectivity status: <ul style="list-style-type: none"><li>• Off: The network link is disconnected, or the network link is established at the speed of 10 Mbps.</li><li>• Green: The network link is established at the speed of 100 Mbps.</li><li>• Orange: The network link is established at the speed of 1000 Mbps.</li></ul> |
| <b>2</b> Activity LED | Use this LED to distinguish the network activity status: <ul style="list-style-type: none"><li>• Off: No data is being transmitted.</li><li>• Blinking: Data is being transmitted.</li></ul>                                                                                                                                                                              |

#### 9 HDMI connector

Connect a HDMI-compatible video device, such as a monitor, to this connector.

#### 10 DisplayPort connectors (x2)

Connect a DisplayPort-compatible video device, such as a monitor, to this connector.

#### 11 Audio line-out connector

Connect an audio device, such as a speaker or an earphone, to this connector.

#### Notes:

- This connector is only supported by Windows Client OS.
- Users may be aware of the low frequency noise via audio port in particular environments.
- Excessive sound pressure from earphone/headphone can cause hearing damage.

## Side view

Follow the instructions in this section to locate the components from the side of the server.




Figure 5. Side view

Table 4. Components on the side view

|                                                 |                                                                                                         |
|-------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| <b>1</b> Drive bay 2 (One 3.5-inch SATA drive)* | <b>2</b> ODD drive bay (One 9mm slim SATA optical disk drive) or Drive bay 3 (One 3.5-inch SATA drive)* |
| <b>3</b> Front bezel                            | <b>4</b> System board                                                                                   |
| <b>5</b> Front fan                              | <b>6</b> Mono amplifier (speaker)***                                                                    |
| <b>7</b> M.2 drive 2*                           | <b>8</b> Drive bay 1 (One 2.5-inch SATA drive)*                                                         |
| <b>9</b> Drive bay 0 (One 3.5-inch SATA drive)* | <b>10</b> Power supply unit                                                                             |
| <b>11</b> PCIe slot 3**                         | <b>12</b> PCIe adapter retainer                                                                         |
| <b>13</b> CMOS battery                          | <b>14</b> PCIe slot 1                                                                                   |
| <b>15</b> M.2 drive 1*                          | <b>16</b> Cage bar*                                                                                     |
| <b>17</b> Heat sink and fan module              | <b>18</b> Rear fan                                                                                      |

\* Optional components.

\*\* Currently, there is no PCIe adapter supported in this PCIe x1 slot. Go through the sales channel for additional requests.

\*\*\* Depending on chassis, the mono amplifier may not be supported.

---

## Server locks

Locking the server cover prevents unauthorized access to the inside of the server.

### Padlock

The server comes with a padlock loop. When a padlock is installed, the server cover cannot be removed.

**Note:** It is recommended to purchase a padlock from a local store.




Figure 6. Padlock

### Kensington-style cable lock

Use a Kensington-style cable lock to secure the server to a desk, table, or other non-permanent fixture. The cable lock attaches to the security-lock slot at the rear of the server and is operated with a key or combination depending on the type selected. The cable lock also locks the server cover. This is the same type of lock used with many notebook computers. You can order such a cable lock directly from Lenovo by searching for **Kensington** at <http://www.lenovo.com/support>.




Figure 7. Kensington-style cable lock

## System-board connectors

The following illustration shows the internal connectors on the system board.




Figure 8. System-board connectors

Table 5. System-board connectors

|                                              |                                             |
|----------------------------------------------|---------------------------------------------|
| <b>1</b> Connector for power button with LED | <b>2</b> Mono amplifier (speaker) connector |
| <b>3</b> System power connector              | <b>4</b> SATA power 1 connector             |
| <b>5</b> SATA power 2 connector              | <b>6</b> SATA 3 connector *                 |
| <b>7</b> SATA 2 connector                    | <b>8</b> M.2 drive 2 connector              |
| <b>9</b> SATA 1 connector                    | <b>10</b> Thermal sensor connector          |
| <b>11</b> PCIe slot 3**                      | <b>12</b> CMOS battery (CR2032)             |
| <b>13</b> PCIe slot 1                        | <b>14</b> M.2 drive 1 connector             |
| <b>15</b> Rear fan connector                 | <b>16</b> Processor power connector         |
| <b>17</b> Processor socket                   | <b>18</b> Processor fan connector           |
| <b>19</b> DIMM slot 1                        | <b>20</b> DIMM slot 2                       |
| <b>21</b> Front fan connector                |                                             |

\* Depending on the model, SATA 3 connector may not be supported.

\*\* Currently, there is no PCIe adapter supported in this PCIe x1 slot. Go through the sales channel for additional requests.

---

## Chapter 3. Parts list

Identify each of the components that is available for your server with the parts list.

For more information about ordering parts:

1. Go to <http://datacentersupport.lenovo.com> and navigate to the support page for your server.
2. Click **Parts**.
3. Enter the serial number to view a listing of parts for your server.

It is highly recommended that you check the power summary data for your server using Lenovo Capacity Planner before purchasing any new parts.

**Note:** Depending on the model, your server might look slightly different from the illustration.




Figure 9. Server components

The parts listed in the following table are identified as one of the following:

- **T1:** Tier 1 customer replaceable unit (CRU). Replacement of Tier 1 CRUs is your responsibility. If Lenovo installs a Tier 1 CRU at your request with no service agreement, you will be charged for the installation.
- **T2:** Tier 2 customer replaceable unit (CRU). You may install a Tier 2 CRU yourself or request Lenovo to install it, at no additional charge, under the type of warranty service that is designated for your server.
- **F:** Field replaceable unit (FRU). FRUs must be installed only by trained service technicians.
- **C:** Consumable and Structural parts. Purchase and replacement of consumable and structural parts (components, such as a filler or bezel) is your responsibility. If Lenovo acquires or installs a structural component at your request, you will be charged for the service.

| Description                                             | Type | Description                                                                               | Type |
|---------------------------------------------------------|------|-------------------------------------------------------------------------------------------|------|
| <b>1</b> Optical disk drive                             | T2   | <b>2</b> Bezel kit (including the optical disk drive bezel and latch)                     | F    |
| <b>3</b> Fan kit (including the front fan and rear fan) | T1   | <b>4</b> Cable kit (including the mono amplifier, thermal sensor, and power button cable) | T1   |
| <b>5</b> Chassis (with front bezel and server cover)    | F    | <b>6</b> 3.5-inch drive cage at bay 3                                                     | T1   |
| <b>7</b> 3.5-inch hard-disk drive assembly              | T1   | <b>8</b> 2.5-inch solid-state drive assembly                                              | T1   |
| <b>9</b> 3.5-inch solid-state drive assembly            | T1   | <b>10</b> Power supply unit                                                               | T1   |
| <b>11</b> Cable                                         | T1   | <b>12</b> Screw kit                                                                       | T1   |
| <b>13</b> PCIe adapter                                  | T1   | <b>14</b> M.2 drive retainer                                                              | T1   |
| <b>15</b> M.2 drive                                     | T1   | <b>16</b> Memory module                                                                   | F    |
| <b>17</b> System board                                  | F    | <b>18</b> Processor                                                                       | F    |
| <b>19</b> Heat sink and fan module                      | F    | <b>20</b> 3V CMOS battery (CR2032)                                                        | C    |

## Power cords

Several power cords are available, depending on the country and region where the server is installed.

To view the power cords that are available for the server:

1. Go to:  
<http://dcsc.lenovo.com/#/>
2. Click **Preconfigured Model** or **Configure to order**.
3. Enter the machine type and model for your server to display the configurator page.
4. Click **Power** → **Power Cables** to see all line cords.

### Notes:

- For your safety, a power cord with a grounded attachment plug is provided to use with this product. To avoid electrical shock, always use the power cord and plug with a properly grounded outlet.
- Power cords for this product that are used in the United States and Canada are listed by Underwriter's Laboratories (UL) and certified by the Canadian Standards Association (CSA).
- For units intended to be operated at 115 volts: Use a UL-listed and CSA-certified cord set consisting of a minimum 18 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a parallel blade, grounding-type attachment plug rated 15 amperes, 125 volts.
- For units intended to be operated at 230 volts (U.S. use): Use a UL-listed and CSA-certified cord set consisting of a minimum 18 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a tandem blade, grounding-type attachment plug rated 15 amperes, 250 volts.
- For units intended to be operated at 230 volts (outside the U.S.): Use a cord set with a grounding-type attachment plug. The cord set should have the appropriate safety approvals for the country in which the equipment will be installed.
- Power cords for a specific country or region are usually available only in that country or region.



---

## Chapter 4. Unboxing and setup

Information in this chapter assists you on unboxing and setting up the server. When unboxing the server, check if the items in the package are correct, and learn where to find information of server serial number. Make sure to follow the instructions in [“Server setup checklist” on page 26](#) when setting up the server.

---

### Server package contents

When you receive your server, verify that the shipment contains everything that you expected to receive.

The server package includes the following items:

- Server
- Keyboard\*
- Material box, including items such as power cords\*, accessory kit, and documentation.

**Note:** Items marked with asterisk (\*) are available on some models only.

If any item is missing or damaged, contact your place of purchase. Ensure that you retain your proof of purchase and packing material. They might be required to receive warranty service.

---


### Identify the server

This section contains instruction on how to identify the server.

#### Identifying your server

When you contact Lenovo for help, the machine type, model, and serial number information help support technicians to identify your server and provide faster service.


The illustration below shows the location of the ID label which contains the model number, machine type, and serial number of the server.



*Figure 10. Location of the ID label*

### **Service information QR code**

On the inside surface of the tray cover, there is a quick response (QR) code that provides mobile access to service information. You can scan the QR code using a QR code reader application on a mobile device to get quick access to the Service Information web page. The Service Information web page provides additional information for parts installation and replacement videos, and error codes for solution support.



*Figure 11. Service information QR code*

### **COA label**

The Certificate of Authenticity (COA) label, which is located on the top surface of the server, provides the name of the product it certifies and a certificate number, product key or serial number for the product.




Figure 12. COA label

---

## Server setup checklist

Use the server setup checklist to ensure that you have performed all tasks that are required to set up your server.

The server setup procedure varies depending on the configuration of the server when it was delivered. In some cases, the server is fully configured and you just need to connect the server to the network and an AC power source, and then you can power on the server. In other cases, the server needs to have hardware options installed, requires hardware and firmware configuration, and requires an operating system to be installed.

The following steps describe the general procedure for setting up a server.

### Setup the server hardware

Complete the following procedures to setup the server hardware.

1. Unpack the server package. See [“Server package contents” on page 23](#).
2. Install any required hardware or server options. See the related topics in [Chapter 5 “Hardware replacement procedures” on page 29](#).
3. If necessary, install the server into a standard rack cabinet by using the tower-to-rack conversion kit. See the documentation that comes with the optional conversion kit.
4. Connect all external cables to the server. See [Chapter 2 “Server components” on page 11](#) for connectors locations.

Typically, you will need to connect the following cables:

- Connect the server to the power source.
- Connect the server to the network.
- Connect the server to the storage device.

5. Power on the server.

Power button location and power LED are specified in [“Front view” on page 11](#).

The server can be turned on (power LED on) in any of the following ways:

- Press the power button.
- The server can restart automatically after a power interruption.

6. Validate the server. Make sure that the power LED, drive activity LED, and Ethernet connector LED are lit properly.

See [“Front view” on page 11](#) and [“Rear view” on page 12](#) for more information on the LED indications.

### **Configure the system**

Complete the following procedures to configure the system. For detailed instructions, see [Chapter 7 “System configuration” on page 175](#).

1. Update the firmware for the server if necessary.
2. Configure the firmware for the server.

The following information is available for RAID configuration:

- <https://lenovopress.lenovo.com/lp0578-lenovo-raid-introduction>
- <https://lenovopress.lenovo.com/lp0579-lenovo-raid-management-tools-and-resources>

3. Install the operating system.
4. Install the applications and programs for which the server is intended to be used.



---

## Chapter 5. Hardware replacement procedures

This chapter provides installation and removal procedures for all serviceable system components. Each component replacement procedure references any tasks that need to be performed to gain access to the component being replaced.

---

### Installation Guidelines

Before installing components in your server, read the installation guidelines.

Before installing optional devices, read the following notices carefully:

**Attention:** Prevent exposure to static electricity, which might lead to system halt and loss of data, by keeping static-sensitive components in their static-protective packages until installation, and handling these devices with an electrostatic-discharge wrist strap or other grounding system.

- Read the safety information and guidelines to ensure your safety at work:
  - A complete list of safety information for all products is available at:  
[https://pubs.lenovo.com/safety\\_documentation/](https://pubs.lenovo.com/safety_documentation/)
  - “Handling static-sensitive devices” on page 31.
- Make sure the components you are installing are supported by the server.
  - For a list of supported optional components for the server, see <https://serverproven.lenovo.com>.
  - For the option package contents, see <https://serveroption.lenovo.com/>.
- For more information about ordering parts:
  1. Go to <http://datacentersupport.lenovo.com> and navigate to the support page for your server.
  2. Click **Parts**.
  3. Enter the serial number to view a listing of parts for your server.
- When you install a new server, download and apply the latest firmware. This will help ensure that any known issues are addressed, and that your server is ready to work with optimal performance. Go to <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3/downloads/driver-list/> to download firmware updates for your server.

**Important:** Some cluster solutions require specific code levels or coordinated code updates. If the component is part of a cluster solution, verify the latest Best Recipe code level menu for cluster supported firmware and driver before you update the code.

- If you replace a part, such as an adapter, that contains firmware, you might also need to update the firmware for that part. For more information about updating firmware, see “Update the firmware” on page 175.
- It is good practice to make sure that the server is working correctly before you install an optional component.
- Keep the working area clean, and place removed components on a flat and smooth surface that does not shake or tilt.
- Do not attempt to lift an object that might be too heavy for you. If you have to lift a heavy object, read the following precautions carefully:
  - Make sure that you can stand steadily without slipping.
  - Distribute the weight of the object equally between your feet.

- Use a slow lifting force. Never move suddenly or twist when you lift a heavy object.
- To avoid straining the muscles in your back, lift by standing or by pushing up with your leg muscles.
- Back up all important data before you make changes related to the disk drives.
- Have a small flat-blade screwdriver and a small Phillips screwdriver available.
- You do not have to turn off the server to remove or install hot-plug USB devices. However, you must turn off the server before you perform any steps that involve removing or installing adapter cables, and you must disconnect the power source from the server before you perform any steps that involve removing or installing a processor, DIMM, HDD, M.2, ODD, or fan.
- Blue on a component indicates touch points, where you can grip to remove a component from or install it in the server, open or close a latch, and so on.
- Orange on a component or an orange label on or near a component indicates that the component can be hot-swapped if the server and operating system support hot-swap capability, which means that you can remove or install the component while the server is still running. (Orange can also indicate touch points on hot-swap components.) See the instructions for removing or installing a specific hot-swap component for any additional procedures that you might have to perform before you remove or install the component.
- The red strip on the drives, adjacent to the release latch, indicates that the drive can be hot-swapped if the server and operating system support hot-swap capability. This means that you can remove or install the drive while the server is still running.

**Note:** See the system specific instructions for removing or installing a hot-swap drive for any additional procedures that you might need to perform before you remove or install the drive.

- After finishing working on the server, make sure you reinstall all safety shields, guards, labels, and ground wires.

## Safety inspection checklist

Use the information in this section to identify potentially unsafe conditions with your server. As each machine was designed and built, required safety items were installed to protect users and service technicians from injury.

**Note:** The product is not suitable for use at visual display workplaces according to §2 of the Workplace Regulations.

**Attention:** This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

### CAUTION:

**This equipment must be installed or serviced by trained personnel, as defined by the IEC 62368-1, the standard for Safety of Electronic Equipment within the Field of Audio/Video, Information Technology and Communication Technology. Lenovo assumes you are qualified in the servicing of equipment and trained in recognizing hazards energy levels in products. Access to the equipment is by the use of a tool, lock and key, or other means of security, and is controlled by the authority responsible for the location.**

**Important:** Electrical grounding of the server is required for operator safety and correct system function. Proper grounding of the electrical outlet can be verified by a certified electrician.

Use the following checklist to verify that there are no potentially unsafe conditions:

1. Make sure that the power is off and the power cord is disconnected.
2. Check the power cord.
  - Make sure that the third-wire ground connector is in good condition. Use a meter to measure third-wire ground continuity for 0.1 ohm or less between the external ground pin and the frame ground.

- Make sure that the power cord is the correct type.

To view the power cords that are available for the server:

- a. Go to:

<http://dcsc.lenovo.com/#/>

- b. Click **Preconfigured Model** or **Configure to order**.
- c. Enter the machine type and model for your server to display the configurator page.
- d. Click **Power → Power Cables** to see all line cords.

- Make sure that the insulation is not frayed or worn.

3. Check for any obvious non-Lenovo alterations. Use good judgment as to the safety of any non-Lenovo alterations.
4. Check inside the server for any obvious unsafe conditions, such as metal filings, contamination, water or other liquid, or signs of fire or smoke damage.
5. Check for worn, frayed, or pinched cables.
6. Make sure that the power-supply cover fasteners (screws or rivets) have not been removed or tampered with.

## System reliability guidelines

Review the system reliability guidelines to ensure proper system cooling and reliability.

Make sure the following requirements are met:

- Adequate space around the server must be spared to allow server cooling system to work properly. Leave approximately 50 mm (2.0 in.) of open space around the front and rear of the server. Do not place any object in front of the fans.
- For proper cooling and airflow, refit the server cover before you turn the power on. Do not operate the server for more than 30 minutes with the server cover removed, for it might damage server components.
- Cabling instructions that come with optional components must be followed.
- A failed fan must be replaced within 48 hours after malfunction.
- The processor socket must contain either a socket cover or a processor with heat sink.

## Handling static-sensitive devices

Review these guidelines before you handle static-sensitive devices to reduce the possibility of damage from electrostatic discharge.

**Attention:** Prevent exposure to static electricity, which might lead to system halt and loss of data, by keeping static-sensitive components in their static-protective packages until installation, and handling these devices with an electrostatic-discharge wrist strap or other grounding system.

- Limit your movement to prevent building up static electricity around you.
- Take additional care when handling devices during cold weather, for heating would reduce indoor humidity and increase static electricity.
- Always use an electrostatic-discharge wrist strap or other grounding system, particularly when working inside the server with the power on.
- While the device is still in its static-protective package, touch it to an unpainted metal surface on the outside of the server for at least two seconds. This drains static electricity from the package and from your body.

- Remove the device from the package and install it directly into the server without putting it down. If it is necessary to put the device down, put it back into the static-protective package. Never place the device on the server or on any metal surface.
- When handling a device, carefully hold it by the edges or the frame.
- Do not touch solder joints, pins, or exposed circuitry.
- Keep the device from others' reach to prevent possible damages.

---

## Memory module installation rules and order

Memory modules must be installed in a specific order based on the memory configuration that you implement and the number of processors and memory modules installed in the server.

### Supported memory types

For information on the types of memory module supported by this server, see [“Technical specifications” on page 3](#).

Information about optimizing memory performance and configuring memory is available at the Lenovo Press website:

<https://lenovopress.lenovo.com/servers/options/memory>

In addition, you can take advantage of a memory configurator, which is available at the following site:

[https://dcsc.lenovo.com/#/memory\\_configuration](https://dcsc.lenovo.com/#/memory_configuration)

### Memory modules and processors layout




Figure 13. Memory modules and processor layout

Table 6. Memory slot and channel identification

| Channel     | Channel A | Channel B |
|-------------|-----------|-----------|
| Slot number | DIMM 1    | DIMM 2    |

### Memory mode and installation order

This server supports independent mode only.

Independent mode provides high performance memory capability. You can populate all channels with no matching requirements. Individual channels can run at different memory module timings, but all channels must run at the same interface frequency.

**Note:** Memory modules of different capacity cannot be mixed on the same server.

The following table shows the memory module installation order:

Table 7. Memory module installation order

| Total memory module installed | Memory module slot number |   | Memory speed                                                                                                                        |
|-------------------------------|---------------------------|---|-------------------------------------------------------------------------------------------------------------------------------------|
|                               | 1                         | 2 |                                                                                                                                     |
| One                           | ✓                         |   | <ul style="list-style-type: none"><li>• 5200 MHz for 4004 series processors</li><li>• 5600 MHz for 4005 series processors</li></ul> |
| One                           |                           | ✓ |                                                                                                                                     |
| Two                           | ✓                         | ✓ |                                                                                                                                     |

---

## Power on and power off the server

Follow the instructions in this section to power on and power off the server.

### Power on the server

Power button location and power LED are specified in [“Front view” on page 11](#).

The server can be turned on (power LED on) in any of the following ways:

- Press the power button.
- The server can restart automatically after a power interruption.

### Power off the server

The server remains in a standby state when it is connected to a power source. To remove all power from the server (power LED off), you must disconnect all power cables.

Power button location and power LED are specified in [“Front view” on page 11](#).

To place the server in a standby state:

- Start an orderly shutdown using the operating system (if supported by your operating system).
- Press the power button to start an orderly shutdown (if supported by your operating system).
- Press and hold the power button for more than 4 seconds to force a shutdown.

---

## Server replacement

Follow instructions in this section to remove and install the server.

### Remove the server from rack

Follow instructions in this section to remove the server from the rack.

#### S002



**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**S014****CAUTION:**

Hazardous voltage, current, and energy levels might be present. Only a qualified service technician is authorized to remove the covers where the label is attached.

**S033****CAUTION:**

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

**About this task****Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).

**Procedure**

**Note:** Your system might look slightly different from the illustration below.

Step 1. Remove the two M6 x 16 screws on the front of the rack cabinet.




Figure 14. Removing the screws on the front of the rack cabinet

Step 2. Remove the server from the rails.

- a. ❶ Slide and pull the rack server tray out of the rack cabinet.
- b. ❷ Lift the server out of the tray.




Figure 15. Removing the server from the rails


### After you finish

1. Place the server on its side with the cover up.
2. To install the server to the rails, see [“Install the server to rack” on page 36](#).

### Install the server to rack

Follow instructions in this section to install the server to the rack.

#### S002



**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**S014**



**CAUTION:**

Hazardous voltage, current, and energy levels might be present. Only a qualified service technician is authorized to remove the covers where the label is attached.

**S033**



**CAUTION:**

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

## About this task

**Attention:**

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See “[Power off the server](#)” on page 34.

**Note:** To install rails to rack, see the *Rail Installation Guide* at [https://serveroption.lenovo.com/rail\\_options/rail\\_options\\_tower\\_servers](https://serveroption.lenovo.com/rail_options/rail_options_tower_servers).

**Firmware and driver download:** You might need to update the firmware or driver after replacing a component.

- Go to <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3/downloads/driver-list/> to see the latest firmware and driver updates for your server.
- Go to “[Update the firmware](#)” on page 175 for more information on firmware updating tools.

## Procedure

Step 1. Install the four brackets to the tray as illustrated.




Figure 16. Installing the brackets to the tray

Step 2. Install the four rubber safety pads to the tray as illustrated.




Figure 17. Installing the rubber safety pads to the tray

Step 3. Orient the server to have the server cover facing up and the front bezel facing the front of the rails; then, align the server with the brackets and the tab on the front of the tray, and gently place the server on the tray.




Figure 18. Installing the server to the tray

- |                             |
|-----------------------------|
| <b>1</b> Server cover       |
| <b>2</b> Server front bezel |

Step 4. Install the server into the rack cabinet.

- a. **1** Lift the rail latches on both sides.
- b. **2** Gently slide and push the tray into the rack cabinet.




Figure 19. Installing the server into the rack cabinet

Step 5. Secure the tray with two M6 x 16 screws to the front of the rack cabinet.




Figure 20. Securing the tray with screws

### After you finish

Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

---

## CMOS battery (CR2032) replacement

Follow instructions in this section to remove and install the CMOS battery (CR2032).

### Remove the CMOS battery (CR2032)

Follow instructions in this section to remove the CMOS battery (CR2032).

#### About this task

##### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

##### S004



**CAUTION:**

When replacing the lithium battery, use only Lenovo specified part number or an equivalent type of battery recommended by the manufacturer. If your system has a module containing a lithium battery, replace it only with the same module type made by the same manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

*Do not:*

- Throw or immerse into water
- Heat to more than 100°C (212°F)
- Repair or disassemble

Dispose of the battery as required by local ordinances or regulations.

**S005****CAUTION:**

The battery is a lithium ion battery. To avoid possible explosion, do not burn the battery. Exchange it only with the approved part. Recycle or discard the battery as instructed by local regulations.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

Step 2. Locate the CMOS battery on the system board. See [“System-board connectors” on page 17](#).

Step 3. Remove the CMOS battery.

- a. ① Press the battery clip in the direction as shown.
- b. ② Carefully tilt and lift the CMOS battery out of the socket.

**Note:** Do not lift the battery with excessive force, as it may cause damages to the socket on the system board. Any damage to the socket may require replacing the system board.




Figure 21. CMOS battery removal

## After you finish

1. Install a replacement unit. See “Install the CMOS battery (CR2032)” on page 42.

**Note:** Make sure to install the CMOS battery before powering on the server. Otherwise, it might cause system abnormality.

2. Dispose the component with compliance to local regulations.

## Demo video

<https://www.youtube.com/watch?v=neJ1StAcu08>

## Install the CMOS battery (CR2032)

Follow instructions in this section to install the CMOS battery (CR2032).

## About this task

### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

### S004



#### CAUTION:

When replacing the lithium battery, use only Lenovo specified part number or an equivalent type of battery recommended by the manufacturer. If your system has a module containing a lithium battery, replace it only with the same module type made by the same manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

*Do not:*

- Throw or immerse into water
- Heat to more than 100°C (212°F)
- Repair or disassemble

Dispose of the battery as required by local ordinances or regulations.

#### S005



#### **CAUTION:**

The battery is a lithium ion battery. To avoid possible explosion, do not burn the battery. Exchange it only with the approved part. Recycle or discard the battery as instructed by local regulations.

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

The following notes describe information that you must consider when replacing the battery.

- When replacing the CMOS battery, you must replace it with another CMOS battery of the same type from the same manufacturer.
- After replacing the CMOS battery, make sure to reconfigure the server and reset system date and time.
- To avoid possible danger, make sure to read and follow the safety statements.
- Lenovo has designed this product with your safety in mind. The CMOS battery must be handled correctly to avoid possible danger. If you install the CMOS battery, do adhere to the following instructions.

**Note:** In the U. S., call 1-800-IBM-4333 for information about battery disposal.

- If you replace the original CMOS battery with a heavy-metal battery or a battery with heavy-metal components, be aware of the following environmental consideration. Batteries and accumulators that contain heavy metals must not be disposed of along with normal domestic waste. They should be taken back free of charge by for recycle or proper disposal by the manufacturer, distributor, or representatives.

#### **Procedure**

- Step 1. Follow any special handling and installation instructions that come with the CMOS battery.
- Step 2. Locate the CMOS battery socket on the system board. See [“System-board connectors” on page 17](#).
- Step 3. Locate the CMOS battery on the system board. See [“System-board connectors” on page 17](#).
- Step 4. Install the CMOS battery.
  - a. ① Insert the CMOS battery into the socket, with positive (+) side facing up.
  - b. ② Press the battery straight down until it clicks in place.




Figure 22. CMOS battery installation

## After you finish

1. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).
2. Reconfigure the server and reset the system date and time.

## Demo video

<https://www.youtube.com/watch?v=xx7kzwokN6o>

---

## Drive and drive cage replacement

Follow instructions in this section to remove and install a drive or a drive cage.

**Note:** For drive bay locations, see [“Side view” on page 15](#).

### Simple-swap drive and drive cage replacement (bay 0-1)

Follow instructions in this section to remove and install a simple-swap drive and drive cage from and into bay 0 or bay 1.

#### Remove a simple-swap drive (bay 0-1)

Follow instructions in this section to remove a simple-swap drive from bay 0 or bay 1.

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

## About this task

### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).

- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- Disconnect the cables from the drive assembly.

Step 2. Remove the drive assembly.

### Remove the 3.5-inch drive assembly from drive bay 0

Hold the retainer handle, and lift the drive assembly out of the drive bay.





Figure 23. Removing drive assembly from drive bay 0

### Remove the 2.5-inch drive assembly from drive bay 1


- ① Pinch the retainer handles.
- ② Lift the drive assembly out from the drive bay.



*Figure 24. Removing drive assembly from drive bay 1*


Step 3. If necessary, remove the drive from the retainer. Tear both sides of the retainer apart, and remove the drive.

**Remove a 3.5-inch drive from the retainer**



*Figure 25. Removing a 3.5-inch drive from the retainer*

**Note:** Depending on the configuration, the 3.5-inch drive may be the model in the illustration below.



**Remove a 2.5-inch drive from the retainer**




Figure 26. Removing a 2.5-inch drive from the retainer

### After you finish

1. Install a replacement unit. See “Install a simple-swap drive (bay 0-1)” on page 48.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

<https://www.youtube.com/watch?v=cjdW8yncXu8>

### Install a simple-swap drive (bay 0-1)

Follow instructions in this section to install a simple-swap drive to bay 0 or bay 1.

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

### About this task

#### Attention:

- Read “Installation Guidelines” on page 29 and “Safety inspection checklist” on page 30 to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.
- Make sure the type of drives to be installed is supported. Following are the types supported:
  - 3.5-inch simple-swap hard-disk drive or solid-state drive in drive bay 0, drive bay 2 and drive bay 3.
  - 2.5-inch simple-swap solid-state drive in drive bay 1.

For a complete list of supported optional devices for the server, see <https://serverproven.lenovo.com>.

- If there are more than one drives to be installed, determine installation order based on the following rules:
  - Start with solid-state drives, and proceed with hard-disk drives.
  - When installing one 3.5-inch solid-state drive and one 3.5-inch hard-disk drive, install the solid-state drive in bay 0 and the hard-disk drive in bay 2.
  - Start with the drive with the lowest capacity.
  - Start with bay 0, proceed to bay 1, and bay 2, and then bay 3.

**Note:** Drives of different types and different capacities are allowed to be installed in one server, but not in the same RAID array. The drives in a single RAID array must be the same type and the same capacity.

## Procedure

Step 1. Install a 3.5-inch or 2.5-inch drive to the retainer.

**Note:** To prevent from damaging the drive with static discharge, do not touch the circuit board on the bottom of the drive.




Figure 27. Circuit board on the drive

- 1 Slightly tear both sides of the retainer apart.
- 2 Align the four holes on the drive with the corresponding pins on the retainer; then, fit the drive into the retainer.

**Note:** The drive connectors should face the retainer handles.






Figure 28. Installing a 3.5-inch drive into the retainer




*Figure 29. Installing a 2.5-inch drive into the retainer*

Step 2. Face the retainer handles upward and push the drive assembly into the drive bay. Press the drive assembly firmly to ensure it is seated correctly.



*Figure 30. Installing the 3.5-inch drive assembly into drive bay 0*



*Figure 31. Installing the 2.5-inch drive assembly into drive bay 1*

Step 3. Connect the signal and power cables to the drive assembly. See [Chapter 6 “Internal cable routing” on page 157](#).

## After you finish

1. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).
2. Check the drive activity LED on the front of the server to verify if the drives are operating correctly. See [“Front view” on page 11](#).
3. Use the Lenovo XClarity Provisioning Manager Lite to configure the RAID if necessary. For more information, see [https://pubs.lenovo.com/lxpm-lite/RAID\\_setup](https://pubs.lenovo.com/lxpm-lite/RAID_setup).


## Demo video

<https://www.youtube.com/watch?v=kjNsDKpZd6g>

## Remove the drive cage (bay 0-1)

Follow instructions in this section to remove the bay 0 drive cage or bay 1 drive cage.

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

## About this task

### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. Remove the simple-swap drive from drive bay 0 or drive bay 1. See [“Remove a simple-swap drive \(bay 0-1\)” on page 44](#).

Step 2. Remove the bay 1 drive cage.

**Note:** Remove the bay 1 drive cage first; then, proceed to remove the bay 0 drive cage.

- a. ① Slightly pull out the latch on the bay 1 drive cage to release it from the bay 0 drive cage.
- b. ② Pull the bay 1 drive cage out from the chassis.




Figure 32. Removing the bay 1 drive cage

Step 3. Remove the front bezel.

- a. ① Release the three plastic tabs on the front bezel.
- b. ② Rotate the front bezel to remove it from the chassis.




Figure 33. Removing the front bezel

Step 4. Remove the bay 0 drive cage.

- a. ① From the outside of the chassis, remove the screw that secures the bay 0 drive cage to the chassis.
- b. ② From the inside of the chassis, remove the screw that secures the bay 0 drive cage to the chassis.

- c. 3 Pull the bay 0 drive cage out from the chassis.




Figure 34. Removing the bay 0 drive cage

### After you finish

1. Install a replacement unit. See “Install the drive cage (bay 0-1)” on page 55.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

<https://www.youtube.com/watch?v=cjdW8yncXu8>

### Install the drive cage (bay 0-1)

Follow instructions in this section to install the bay 0 drive cage or bay 1 drive cage.

### About this task

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

- Read “Installation Guidelines” on page 29 and “Safety inspection checklist” on page 30 to ensure that you work safely.

- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

## Procedure

**Note:** Install the bay 0 drive cage first; then, proceed to install the bay 1 drive cage.

Step 1. Install the bay 0 drive cage.

- 1 Align the bay 0 drive cage to the slots on chassis; then, install it into the chassis. Make sure the drive cage is seated correctly in the chassis.
- 2 From the inside of the chassis, fasten the screw that secures the bay 0 drive cage to the chassis.
- 3 From the outside of the chassis, fasten the screw that secures the bay 0 drive cage to the chassis.




Figure 35. Installing the bay 0 drive cage

Step 2. Install the front bezel.

- 1 Insert the three plastic tabs on the bottom of the front bezel with the corresponding slots on the front of the chassis.
- 2 Pivot the front bezel towards the chassis until it snaps into place.




Figure 36. Installing the front bezel

Step 3. Install the bay 1 drive cage.

Align the four hooks on both drive cages, and attach bay 1 drive cage to bay 0 drive cage; then, slide the bay 1 drive cage downward until the four hooks on both drive cages are fully engaged. Make sure the latch on the bay 1 drive cage is also engaged with the hook on the bay 0 drive cage.




Figure 37. Installing the bay 1 drive cage

**After you finish**

1. Install simple-swap drives if necessary. See [“Install a simple-swap drive \(bay 0-1\)” on page 48.](#)
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154.](#)

### Demo video

<https://www.youtube.com/watch?v=kjNsDKpZd6g>

## Simple-swap drive and drive cage replacement (bay 2)

Follow instructions in this section to remove and install a simple-swap drive or drive cage from and into bay 2.

**Note:** This topic uses the ODD+bay 2 drive cage assembly as an example for illustration. The procedure for bay 2+bay 3 drive cage assembly is similar. For details, see [“Simple-swap drive and drive cage replacement \(bay 3\)” on page 68.](#)

### Remove a simple-swap drive (bay 2)

Follow instructions in this section to remove a simple-swap drive from bay 2.

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

### About this task

#### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34.](#)
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34.](#)
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

### Procedure

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146.](#)

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. If applicable, remove the optical drive. See [“Remove an optical drive” on page 79.](#)
- c. If applicable, disconnect all the cables from the 3.5-inch drive assembly.

Step 2. Remove the ODD+bay 2 drive cage assembly from the chassis.

- a. ① Rotate the handle on the optical drive cage.
- b. ② Lift the drive cage assembly out from the chassis.




Figure 38. Removing the ODD+bay 2 drive cage assembly

Step 3. Remove the 3.5-inch drive.

- a. ① Slide the drive retainer out from the drive cage.
- b. ② Tear both sides of the retainer apart and remove the drive from the retainer.





Figure 39. Removing the 3.5-inch drive

**Note:** Depending on the configuration, the 3.5-inch drive may be the model in the illustration below.



## After you finish

1. Install a replacement unit. See “[Install a simple-swap drive \(bay 2\)](#)” on page 60.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=EACGnzKtNwh8>

## Install a simple-swap drive (bay 2)

Follow instructions in this section to install a simple-swap drive to bay 2.

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

## About this task

### Attention:

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.
- Make sure the type of drives to be installed is supported. Following are the types supported:
  - 3.5-inch simple-swap hard-disk drive or solid-state drive in drive bay 0, drive bay 2 and drive bay 3.
  - 2.5-inch simple-swap solid-state drive in drive bay 1.

For a complete list of supported optional devices for the server, see <https://serverproven.lenovo.com>.

- If there are more than one drives to be installed, determine installation order based on the following rules:
  - Start with solid-state drives, and proceed with hard-disk drives.

- When installing one 3.5-inch solid-state drive and one 3.5-inch hard-disk drive, install the solid-state drive in bay 0 and the hard-disk drive in bay 2.
- Start with the drive with the lowest capacity.
- Start with bay 0, proceed to bay 1, and bay 2, and then bay 3.

**Note:** Drives of different types and different capacities are allowed to be installed in one server, but not in the same RAID array. The drives in a single RAID array must be the same type and the same capacity.

## Procedure

Step 1. Install a 3.5-inch drive to the drive cage.

**Note:** To prevent from damaging the drive with static discharge, do not touch the circuit board on the bottom of the drive.




Figure 40. Circuit board on the drive

- 1 Slightly tear both sides of the retainer apart.

**Attention:** Position the drive connectors on the opposite side of the retainer handles.

- 2 Align the four holes on the drive with the corresponding pins on the retainer; then, fit the drive into the retainer.
- 3 Slide the drive into the drive cage.





Figure 41. Installing a 3.5-inch drive to the drive cage

**Attention:** If you are installing a 3.5-inch drive as the model in the illustration below:



Make sure the screw holes that are nearest to the drive connector are **outside** of the drive retainer.




Figure 42. Drive screw hole placement on retainer

### 1 Screw holes nearest to the drive connector

Step 2. Install the ODD+bay 2 drive cage assembly.

- a. 1 Align the four pins on the sides of the optical drive cage with the four slots on the chassis and cage bar; then, lower the drive cage assembly into the chassis.
- b. 2 Ensure that the drive cage assembly is seated correctly; then, rotate the handle on the optical drive cage toward the front of the chassis to secure the drive cage assembly into place.




Figure 43. Installing the ODD+bay 2 drive cage assembly

### After you finish

1. If applicable, install the optical drive. See [“Install an optical drive” on page 82](#).
2. Connect the signal and power cables to the drive assembly. See [Chapter 6 “Internal cable routing” on page 157](#).
3. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).
4. Check the drive activity LED on the front of the server to verify if the drives are operating correctly. See [“Front view” on page 11](#).
5. Use the Lenovo XClarity Provisioning Manager Lite to configure the RAID if necessary. For more information, see [https://pubs.lenovo.com/lxpm-lite/RAID\\_setup](https://pubs.lenovo.com/lxpm-lite/RAID_setup).


### Demo video

<https://www.youtube.com/watch?v=IEUcD2qyAgo>

### Remove the drive cage (bay 2)

Follow instructions in this section to remove the bay 2 drive cage.

### About this task



**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. If applicable, remove the optical drive. See [“Remove an optical drive” on page 79](#).
- c. If applicable, disconnect all the cables from the 3.5-inch drive assembly.

Step 2. Remove the ODD+bay 2 drive cage assembly from the chassis.

- a. ① Rotate the handle on the optical drive cage.
- b. ② Lift the drive cage assembly out from the chassis.




Figure 44. Removing the ODD+bay 2 drive cage assembly

- Step 3. If applicable, remove the 3.5-inch drive from the bay 2 drive cage. See [“Remove a simple-swap drive \(bay 2\)” on page 58](#).
- Step 4. Remove the optical drive cage from the bay 2 drive cage.
- 1 Remove the screw that secures the optical drive cage to the bay 2 drive cage. Reserve the screw to be used for reinstalling the optical drive cage.
  - 2 Slide the optical drive cage to separate it from the bay 2 drive cage.




Figure 45. Removing the optical drive cage from the bay 2 drive cage

## After you finish

1. Install a replacement unit. See [“Install the drive cage \(bay 2\)” on page 66](#).
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=EACGnzKNwh8>

## Install the drive cage (bay 2)

Follow instructions in this section to install the bay 2 drive cage.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

### Procedure

- Step 1. Make sure the cage bar is installed in the chassis. To install the cage bar, see [“Install the server cover” on page 148](#).
- Step 2. **(Optional)** Install the EMI shield included in the component packaging to the chassis.

**Note:** Installing the EMI shield is required when the original shield slot on the chassis is vacant.

- a. ❶ Insert the tabs on the left end of the EMI shield into the shield slot on the chassis.
- b. ❷ Push the EMI shield into the chassis until it snaps into place.




Figure 46. Installing the EMI shield

Step 3. Make sure there is no optical drive installed on the optical drive cage. Then, Install the optical drive cage to the bay 2 drive cage.

- a. ① Align the four hooks on the optical drive cage with the corresponding hooks on the bay 2 drive cage; then, lower the optical drive cage onto the bay 2 drive cage, and slide the optical drive cage forward until it secures into place.

**Note:** Make sure the four hooks on both drive cages are fully engaged.

- b. ② Fasten the screw to secure the two drive cages together.




Figure 47. Installing the optical drive cage to the bay 2 drive cage

Step 4. If applicable, install the 3.5-inch drive to the bay 2 drive cage. See [“Install a simple-swap drive \(bay 2\)”](#) on page 60.

Step 5. Install the ODD+bay 2 drive cage assembly.

- a. ① Align the four pins on the sides of the optical drive cage with the four slots on the chassis and cage bar; then, lower the drive cage assembly into the chassis.
- b. ② Ensure that the drive cage assembly is seated correctly; then, rotate the handle on the optical drive cage toward the front of the chassis to secure the drive cage assembly into place.




Figure 48. Installing the ODD+bay 2 drive cage assembly

### After you finish

1. If applicable, install the optical drive. See [“Install an optical drive” on page 82](#).
2. Connect the signal and power cables to the drive assembly. See [Chapter 6 “Internal cable routing” on page 157](#).
3. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

### Demo video


<https://www.youtube.com/watch?v=IEUcD2qyAgo>

## Simple-swap drive and drive cage replacement (bay 3)

Follow instructions in this section to remove and install a simple-swap drive or drive cage from and into bay 3.

### Remove a simple-swap drive (bay 3)

Follow instructions in this section to remove a simple-swap drive from bay 3.

**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**About this task****Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. Disconnect the cables from the drive assembly.

Step 2. Remove the bay 2+bay 3 drive cage assembly from the chassis.

- a. ① Rotate the handle on the bay 3 drive cage.
- b. ② Lift the bay 2+bay 3 drive cage assembly out from the chassis.




Figure 49. Removing the bay 2+bay 3 drive cage assembly

Step 3. Remove the 3.5-inch drive.

- a. ① Slide the drive retainer out from the drive cage.
- b. ② Tear both sides of the retainer apart and remove the drive from the retainer.





Figure 50. Removing the 3.5-inch drive

**Note:** Depending on the configuration, the 3.5-inch drive may be the model in the illustration below.



## After you finish

1. Install a replacement unit. See [“Install a simple-swap drive \(bay 3\)” on page 71](#).
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=EACGnzKtNwh8>

## Install a simple-swap drive (bay 3)

Follow instructions in this section to install a simple-swap drive to bay 3.

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

## About this task

### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.
- Make sure the type of drives to be installed is supported. Following are the types supported:
  - 3.5-inch simple-swap hard-disk drive or solid-state drive in drive bay 0, drive bay 2 and drive bay 3.
  - 2.5-inch simple-swap solid-state drive in drive bay 1.

For a complete list of supported optional devices for the server, see <https://serverproven.lenovo.com>.

- If there are more than one drives to be installed, determine installation order based on the following rules:
  - Start with solid-state drives, and proceed with hard-disk drives.

- When installing one 3.5-inch solid-state drive and one 3.5-inch hard-disk drive, install the solid-state drive in bay 0 and the hard-disk drive in bay 2.
- Start with the drive with the lowest capacity.
- Start with bay 0, proceed to bay 1, and bay 2, and then bay 3.

**Note:** Drives of different types and different capacities are allowed to be installed in one server, but not in the same RAID array. The drives in a single RAID array must be the same type and the same capacity.

Step 1. Install a 3.5-inch drive to the bay 3 drive cage.

**Note:** To prevent from damaging the drive with static discharge, do not touch the circuit board on the bottom of the drive.




Figure 51. Circuit board on the drive

- 1 Slightly tear both sides of the retainer apart.

**Attention:** Position the drive connectors on the opposite side of the retainer handles.

- 2 Align the four holes on the drive with the corresponding pins on the retainer; then, fit the drive into the retainer.
- 3 Slide the drive into the drive cage.






Figure 52. Installing a 3.5-inch drive to the bay 3 drive cage

**Attention:** If you are installing a 3.5-inch drive as the model in the illustration below:



Make sure the screw holes that are nearest to the drive connector are **outside** of the drive retainer.



*Figure 53. Drive screw hole placement on retainer*

|                                                     |
|-----------------------------------------------------|
| <b>1 Screw holes nearest to the drive connector</b> |
|-----------------------------------------------------|

Step 2. Install the bay 2+bay 3 drive cage assembly into the chassis.

- a. ① Align the four pins on the sides of the bay 3 drive cage with the four slots on the chassis and cage bar; then, lower the drive cage assembly into the chassis.
- b. ② Ensure that the drive cage assembly is seated correctly; then, rotate the handle on the bay 3 drive cage toward the front of the chassis to secure the drive cage assembly into place.




Figure 54. Installing the bay 2+bay 3 drive cage assembly

## After you finish

1. Connect the signal and power cables to the drive assembly. See [Chapter 6 “Internal cable routing” on page 157](#).
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).
3. Check the drive activity LED on the front of the server to verify if the drives are operating correctly. See [“Front view” on page 11](#).
4. Use the Lenovo XClarity Provisioning Manager Lite to configure the RAID if necessary. For more information, see [https://pubs.lenovo.com/lxpm-lite/RAID\\_setup](https://pubs.lenovo.com/lxpm-lite/RAID_setup).

## Demo video

<https://www.youtube.com/watch?v=IEUcD2qyAgo>

## Remove the drive cage (bay 3)

Follow instructions in this section to remove the bay 3 drive cage.

## About this task

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To

remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. Disconnect the cables from the drive assembly.

Step 2. Remove the bay 2+bay 3 drive cage assembly from the chassis.

- a. ① Rotate the handle on the bay 3 drive cage.
- b. ② Lift the bay 2+bay 3 drive cage assembly out from the chassis.




Figure 55. Removing the bay 2+bay 3 drive cage assembly

Step 3. Remove the 3.5-inch drive from the bay 3 drive cage. See [“Remove a simple-swap drive \(bay 3\)” on page 68](#).

Step 4. Remove the bay 3 drive cage from the bay 2 drive cage.

- a. ① Remove the screw that secures the bay 3 drive cage to the bay 2 drive cage. Reserve the screw to be used for reinstalling the bay 3 drive cage.
- b. ② Slide the bay 3 drive cage to separate it from the bay 2 drive cage.




Figure 56. Removing the bay 3 drive cage

### After you finish

1. Install a replacement unit. See “Install the drive cage (bay 3)” on page 76.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

<https://www.youtube.com/watch?v=EACGnzKtNwh8>

### Install the drive cage (bay 3)

Follow instructions in this section to install the bay 3 drive cage.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read “Installation Guidelines” on page 29 and “Safety inspection checklist” on page 30 to ensure that you work safely.

- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

## Procedure

Step 1. Make sure the cage bar is installed in the chassis. To install the cage bar, see [“Install the server cover” on page 148](#).

Step 2. **(Optional)** Install the EMI shield included in the component packaging to the chassis.

**Note:** Installing the EMI shield is required when the original shield slot on the chassis is vacant.

- 1 Insert the tabs on the left end of the EMI shield into the shield slot on the chassis.
- 2 Push the EMI shield into the chassis until it snaps into place.




Figure 57. Installing the EMI shield

Step 3. Install the bay 3 drive cage to the bay 2 drive cage.

- 1 Align the four hooks on the bay 3 drive cage with the corresponding hooks on the bay 2 drive cage; then, lower the bay 3 drive cage onto the bay 2 drive cage, and slide the bay 3 drive cage forward until it secures into place.

**Note:** Make sure the four hooks on both drive cages are fully engaged.

- 2 Fasten the screw to secure the two drive cages together.




Figure 58. Installing the bay 3 drive cage to the bay 2 drive cage

- Step 4. If applicable, install the 3.5-inch drive to the bay 3 drive cage. See [“Install a simple-swap drive \(bay 3\)” on page 71](#).
- Step 5. Install the bay 2+bay 3 drive cage assembly into the chassis.
- 1 Align the four pins on the sides of the bay 3 drive cage with the four slots on the chassis and cage bar; then, lower the drive cage assembly into the chassis.
  - 2 Ensure that the drive cage assembly is seated correctly; then, rotate the handle on the bay 3 drive cage toward the front of the chassis to secure the drive cage assembly into place.




Figure 59. Installing the bay 2+bay 3 drive cage assembly

## After you finish

1. Connect the signal and power cables to the drive assembly. See [Chapter 6 “Internal cable routing” on page 157](#).
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

## Demo video

<https://www.youtube.com/watch?v=IEUcD2qyAgo>

## Optical drive and drive cage replacement

Follow instructions in this section to remove and install an optical drive and optical drive cage.

### Remove an optical drive

Follow instructions in this section to remove an optical drive.

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

## About this task

### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. Disconnect the cables from the optical drive.

Step 2. Remove the optical drive from the optical drive cage.

- a. ① Press the latch on the optical drive to release it from the optical drive cage.
- b. ② Slide out the optical drive from the chassis.




Figure 60. Removing the optical drive

Step 3. **(Optional)** Remove the optical drive retainer.

- a. ① Pull out the retainer to disengage it from the optical drive.

- b. 2 Slide the retainer downward, and remove it from the optical drive.




Figure 61. Removing the optical drive retainer

- Step 4. **(Optional)** Pull the optical drive bezel away to remove it from the optical drive.




Figure 62. Removing the optical drive bezel

## After you finish

1. Install a replacement unit. See [“Install an optical drive” on page 82](#).
2. If no optical drive is to be installed, install the optical drive bay shield back to the front bezel.
  - a. 1 Engage the bottom of the shield to the opening on the front bezel.
  - b. 2 Pivot the shield towards the front bezel until it snaps into place.




Figure 63. Installing the optical drive bay shield

3. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

#### Demo video

<https://www.youtube.com/watch?v=0JlsxyH7u1Q>

### Install an optical drive

Follow instructions in this section to install an optical drive.

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**CAUTION:**

When laser products (such as CD-ROMs, DVD drives, fiber optic devices, or transmitters) are installed, note the following:

- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.

**About this task****Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

**Procedure**

Step 1. If the optical drive bay shield is installed on the front bezel, remove it from the front bezel. To remove the front bezel, see [“Remove the front bezel” on page 95](#).

- 1 Press the release tab on top of the drive bay shield.
- 1 Rotate the drive bay shield and remove it from the front bezel.




Figure 64. Removing the optical drive bay shield

Step 2. **(Optional)** Install the optical drive retainer.

- a. ① Align the pin on the bottom of the retainer and the corresponding slot on the optical drive; then, insert the pin into the slot.
- b. ② Insert the rest two pins on the retainer to the corresponding slots on the optical drive.




Figure 65. Installing the retainer to the optical drive

- Step 3. **(Optional)** Align the optical drive bezel with the slots on the optical drive; then, insert the bezel into the optical drive.




Figure 66. Installing the optical drive bezel

- Step 4. Install the optical drive.
- a. ① From the outside of the chassis, insert the optical drive into the chassis.
  - b. ② Slide the optical drive inward until the latch snaps into place.




Figure 67. Installing the optical drive

## After you finish

1. Connect the signal and power cables to the optical drive. See [Chapter 6 “Internal cable routing” on page 157](#).
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

## Demo video

<https://www.youtube.com/watch?v=Ce8VkGaSFYA>

## Remove an optical drive cage

Follow instructions in this section to remove the optical drive cage.

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

## About this task

### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- If applicable, remove the optical drive. See [“Remove an optical drive” on page 79](#).

Step 2. If applicable, disconnect all the cables from the 3.5-inch drive assembly.

Step 3. Remove the ODD+bay 2 drive cage assembly from the chassis.

- 1 Rotate the handle on the optical drive cage.
- 2 Lift the drive cage assembly out from the chassis.




Figure 68. Removing the ODD+bay 2 drive cage assembly

Step 4. Remove the optical drive cage from the bay 2 drive cage.

- 1 Remove the screw that secures the optical drive cage to the bay 2 drive cage. Reserve the screw to be used for reinstalling the optical drive cage.
- 2 Slide the optical drive cage to separate it from the bay 2 drive cage.




Figure 69. Removing the optical drive cage from the bay 2 drive cage

## After you finish

1. Install a replacement unit. See “Install the optical drive cage” on page 87.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=0JlsxyH7u1Q>

## Install the optical drive cage

Follow instructions in this section to install the optical drive cage.

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**CAUTION:**

When laser products (such as CD-ROMs, DVD drives, fiber optic devices, or transmitters) are installed, note the following:

- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.

**About this task****Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

**Procedure**

- Step 1. Make sure the cage bar is installed in the chassis. To install the cage bar, see [“Install the server cover” on page 148](#).
- Step 2. **(Optional)** Install the EMI shield included in the component packaging to the chassis.

**Note:** Installing the EMI shield is required when the original shield slot on the chassis is vacant.

- 1 Insert the tabs on the left end of the EMI shield into the shield slot on the chassis.
- 2 Push the EMI shield into the chassis until it snaps into place.




Figure 70. Installing the EMI shield

Step 3. Make sure there is no optical drive installed on the optical drive cage. Then, Install the optical drive cage to the bay 2 drive cage.

- a. ① Align the four hooks on the optical drive cage with the corresponding hooks on the bay 2 drive cage; then, lower the optical drive cage onto the bay 2 drive cage, and slide the optical drive cage forward until it secures into place.

**Note:** Make sure the four hooks on both drive cages are fully engaged.

- b. ② Fasten the screw to secure the two drive cages together.




Figure 71. Installing the optical drive cage to the bay 2 drive cage

Step 4. If applicable, install the 3.5-inch drive to the bay 2 drive cage. See [“Install a simple-swap drive \(bay 2\)” on page 60](#).

Step 5. Install the ODD+bay 2 drive cage assembly.

- a. ① Align the four pins on the sides of the optical drive cage with the four slots on the chassis and cage bar; then, lower the drive cage assembly into the chassis.
- b. ② Ensure that the drive cage assembly is seated correctly; then, rotate the handle on the optical drive cage toward the front of the chassis to secure the drive cage assembly into place.




Figure 72. Installing the ODD+bay 2 drive cage assembly

## Procedure

1. If applicable, install the optical drive. See [“Install an optical drive” on page 82](#).
2. Connect the signal and power cables to the 3.5-inch drive and optical drive. See [Chapter 6 “Internal cable routing” on page 157](#).
3. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

## Demo video

<https://www.youtube.com/watch?v=Ce8VkGaSFYA>

---

## Fan replacement

Follow instructions in this section to remove and install the front fan or rear fan.

**Note:** For heat sink and fan module replacement, see [“Heat sink and fan module replacement \(trained technician only\)” on page 97](#).

## Remove the fan (front and rear)

Follow instructions in this section to remove the front fan and rear fan.

## About this task

### S002



**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. **(For removing the front fan only)** Remove the front bezel. See [“Remove the front bezel” on page 95](#).

Step 2. Disconnect the fan cable from the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6 “Internal cable routing” on page 157](#) when disconnecting cables from the system board.

Step 3. If you are removing the rear fan for replacing or recycling the system board or removing the front fan for replacing the thermal sensor, perform the following steps.

- a. ① Carefully squeeze the four rubber mounts with a pair of pliers and push the rubber mounts inward.
- b. ② Slide the fan away from the chassis; then, lift it out of the chassis.




Figure 73. Removing the fan by squeezing rubber mounts

Step 4. If you are replacing the front or rear fan, perform the following steps.

- a. ① From the outside of the chassis, cut off the four rubber mounts that secure the fan to the chassis.
- b. ② Slide the fan away from the chassis; then, lift it out of the chassis.




Figure 74. Removing the fan by cutting off rubber mounts

## After you finish

1. Install a replacement unit. See [“Install the fan \(front and rear\)” on page 93](#).
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

[https://www.youtube.com/watch?v=rv\\_a-bKvuoc](https://www.youtube.com/watch?v=rv_a-bKvuoc)

## Install the fan (front and rear)

Follow instructions in this section to install the front fan or rear fan.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

### Procedure

Step 1. Install the front fan or rear fan.

- a. ① Align the four rubber mounts on the fan with the corresponding holes on the chassis.
- b. ② With a pair of pliers, gently pull the tips of the four rubber mounts through the holes until the fan is secured to the chassis.




Figure 75. Installing the front fan or the rear fan

**Note:** Make sure the rubber mounts are fully pulled out of the holes to secure the fans steadily to the chassis.




Figure 76. Front fan and rear fan rubber mounts installation

Step 2. Connect the fan cable to the system board. See [Chapter 6 “Internal cable routing” on page 157](#).

## After you finish

1. **(For installing the front fan only)** Install the front bezel. See [“Install the front bezel” on page 96](#).
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

## Demo video

---

## Front bezel replacement

Follow instructions in this section to remove and install the front bezel.

### Remove the front bezel

Follow instructions in this section to remove the front bezel.

#### About this task

##### S002



##### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

##### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

### Procedure

Step 1. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

Step 2. Remove the front bezel.

- a. ① Release the three plastic tabs on the front bezel.
- b. ② Rotate the front bezel to remove it from the chassis.




Figure 77. Removing the front bezel

## After you finish

1. Install a replacement unit. See [“Install the front bezel” on page 96](#).
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=jckqWu9svCw>

## Install the front bezel

Follow instructions in this section to install the front bezel.

## About this task

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**Attention:** Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.

## Procedure

Step 1. Install the front bezel.

- a. ① Insert the three plastic tabs on the bottom of the front bezel with the corresponding slots on the front of the chassis.
- b. ② Pivot the front bezel towards the chassis until it snaps into place.




Figure 78. Installing the front bezel

Step 2. Install the server cover. See [“Install the server cover” on page 148](#).

### After you finish

Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

### Demo video

<https://www.youtube.com/watch?v=a1o-ilwvK7M>

---

## Heat sink and fan module replacement (trained technician only)

Follow instructions in this section to remove and install the heat sink and fan module.

**Important:** This task must be operated by trained technicians that are certified by Lenovo Service. Do not attempt to remove or install the part without proper training and qualification.

### Remove the heat sink and fan module (trained technician only)

Follow instructions in this section to remove the heat sink and fan module. The procedure must be executed by a trained technician.

### About this task

**S002**

**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. If applicable, remove the ODD+bay 2 drive cage assembly (see [“Remove an optical drive cage” on page 85](#)) or remove the bay 2+bay 3 drive cage assembly (see [“Remove the drive cage \(bay 3\)” on page 74](#)).

Step 2. Disconnect the heat sink and fan module cable from the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6 “Internal cable routing” on page 157](#) when disconnecting cables from the system board.

Step 3. Remove the heat sink and fan module.

- a. ❶ & ❷ Loosen screw 1 and 2: First, partially loosen screw 1; then, fully loosen screw 2. Finally, fully loosen screw 1.
- b. ❸ & ❹ Loosen screw 3 and 4: First, partially loosen screw 3; then, fully loosen screw 4. Finally, fully loosen screw 3.
- c. ❺ Lift evenly and remove the heat sink and fan module from the server.

**Notes:**

1. Gently remove the four screws to avoid any possible damage to the system board.
2. Always keep the four screws attached to the heat sink and fan module.
3. Do not touch the thermal grease while handling the heat sink and fan module.




Figure 79. Removing the heat sink and fan module

## After you finish

1. Install a replacement unit. See “Install the heat sink and fan module (trained technician only)” on page 99.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=yPVzSTWPgrk>

## Install the heat sink and fan module (trained technician only)

Follow instructions in this section to install the heat sink and fan module. The procedure must be executed by a trained technician.

## About this task

**S002**



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To

remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

**Procedure**

- Step 1. Install the processor if one is not yet installed. See [“Install the processor \(trained technician only\)” on page 135](#).
- Step 2. Align the four screws on the heat sink and fan module with the corresponding screw holes in the chassis. Make sure the fan cable is close to the heat sink fan connector. See [“System-board connectors” on page 17](#).
- Step 3. Install the heat sink and fan module.
- a. ① & ② Tighten screw 1 and 2: First, partially tighten screw 1; then, fully tighten screw 2. Finally, fully tighten screw 1.
  - b. ③ & ④ Tighten screw 3 and 4: First, partially tighten screw 3; then, fully tighten screw 4. Finally, fully tighten screw 3.

**Note:** Do not touch the thermal grease while handling the heat sink and fan module.




Figure 80. Installing the heat sink and fan module

- Step 4. Connect the heat sink fan cable to the system board. See [Chapter 6 “Internal cable routing” on page 157](#).

## After you finish

1. If applicable, install the ODD+bay 2 drive cage assembly (see [“Install the optical drive cage” on page 87](#)) or install the bay 2+bay 3 drive cage assembly (see [“Install the drive cage \(bay 3\)” on page 76](#)).
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

### Demo video

<https://www.youtube.com/watch?v=9k154qBwPhQ>

---

## M.2 drive replacement

Follow instructions in this section to remove and install the M.2 drive.

### Notes:

- If two M.2 drives are to be installed, install M.2 drive 1 first.
- For M.2 drive locations, see [“Side view” on page 15](#).

## Remove an M.2 drive

Follow instructions in this section to remove an M.2 drive.

### About this task

#### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. If needed, remove the 2.5-inch drive from bay 1. See [“Remove a simple-swap drive \(bay 0-1\)” on page 44.](#)
- c. Locate the M.2 drive to be removed. See [“Side view” on page 15.](#)

Step 2. Remove M.2 drive 1.

- a. ❶ Remove the screw that secures the M.2 drive.
- b. ❷ Rotate the rear end of the M.2 drive to an angle.
- c. ❸ Remove the M.2 drive from the system board.




Figure 81. Removing M.2 drive 1

Step 3. Remove M.2 drive 2.

- a. ❶ Lift the retainer post away from the M.2 drive retainer.
- b. ❷ Rotate the rear end of the M.2 drive to an angle.
- c. ❸ Remove the M.2 drive from the system board.




Figure 82. Removing M.2 drive 2

### After you finish

1. Install a replacement unit. See “Install an M.2 drive” on page 103.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

<https://www.youtube.com/watch?v=BrB4-4CFPMQ>

## Install an M.2 drive

Follow instructions in this section to install an M.2 drive.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

## Procedure

Step 1. Locate the M.2 drive slot on the system board. See [“Side view” on page 15](#).

Step 2. Install M.2 drive 1.

- 1 Insert the M.2 drive at an angle into the connector.
- 2 Place down the M.2 drive onto the screw hole.
- 3 Install the screw to secure the M.2 drive in place.




Figure 83. Installing M.2 drive 1

Step 3. Install M.2 drive 2.

- 1 Insert the M.2 drive at an angle into the connector.
- 2 Place down the M.2 drive onto the M.2 drive retainer.
- 3 Insert the retainer post into the retainer to secure the M.2 drive in place.




Figure 84. Installing M.2 drive 2

### After you finish

1. If applicable, reinstall the 2.5-inch drive to bay 1. See “[Install a simple-swap drive \(bay 0-1\)](#)” on page 48.
2. Complete the parts replacement. See “[Complete the parts replacement](#)” on page 154.

### Demo video

<https://www.youtube.com/watch?v=rjBVwEaFcdc>

## Remove the M.2 drive retainer

Follow instructions in this section to remove the retainer for M.2 drive 2.

### About this task

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See “[Power off the server](#)” on page 34.
- If the server is in a rack, remove it from the rack. See “[Remove the server from rack](#)” on page 34.
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- Remove the server cover. See “[Remove the server cover](#)” on page 146.

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- If applicable, remove the 2.5-inch drive from bay 1. See “[Remove a simple-swap drive \(bay 0-1\)](#)” on page 44.
- Remove M.2 drive 2. See “[Remove an M.2 drive](#)” on page 101.

Step 2. Remove the M.2 drive retainer.

- ① Press the tab on the retainer and slightly push the nub upward.
- ② Slide the retainer forward and lift it out of the chassis.




Figure 85. Removing the M.2 drive retainer

## After you finish

1. Install a replacement unit. See “[Install the M.2 drive retainer](#)” on page 107.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=BrB4-4CFPMQ>

## Install the M.2 drive retainer

Follow instructions in this section to install the retainer for M.2 drive 2.

### About this task

S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

### Procedure

- Step 1. Align the M.2 drive retainer with the three slots on the chassis, and lower the retainer into the chassis; then, slide the retainer toward the 2.5-inch drive cage to secure it in place.




Figure 86. Installing the M.2 drive retainer

- Step 2. Install an M.2 drive. See [“Install an M.2 drive” on page 103](#).

### After you finish

1. If applicable, reinstall the 2.5-inch drive to bay 1. See [“Install a simple-swap drive \(bay 0-1\)” on page 48](#).

2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

### Demo video

<https://www.youtube.com/watch?v=rjBVwEaFcdc>

---

## Memory module replacement

Follow instructions in this section to remove and install a memory module.

### Remove a memory module

Follow instructions in this section to remove a memory module.

### About this task

#### S002



#### **CAUTION:**

**The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.**

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.
- Make sure to remove or install memory module 20 seconds after disconnecting power cords from the system. It allows the system to be completely discharged of electricity and safe for handling memory module.
- If you are not installing a replacement memory module to the same slot, make sure you have memory module filler available.
- Memory modules are sensitive to static discharge and require special handling. Refer to the standard guidelines for [“Handling static-sensitive devices” on page 31](#).
  - Always wear an electrostatic-discharge strap when removing or installing memory modules. Electrostatic-discharge gloves can also be used.
  - Never hold two or more memory modules together so that they do not touch each other. Do not stack memory modules directly on top of each other during storage.
  - Never touch the gold memory module connector contacts or allow these contacts to touch the outside of the memory module connector housing.

- Handle memory modules with care: never bend, twist, or drop a memory module.
- Do not use any metal tools (such as jigs or clamps) to handle the memory modules, because the rigid metals may damage the memory modules.
- Do not insert memory modules while holding packages or passive components, which can cause package cracks or detachment of passive components by the high insertion force.

## Procedure

Step 1. Make preparation for this task.

- Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- If applicable, remove the ODD+bay 2 drive cage assembly (see [“Remove an optical drive cage” on page 85](#)) or remove the bay 2+bay 3 drive cage assembly (see [“Remove the drive cage \(bay 3\)” on page 74](#)).
- Locate the memory module slots and determine the memory module to be removed.





Figure 87. Memory modules and processor layout

Step 2. Open the retaining clips on each end of the memory module slot. If necessary, you can use a pointed tool to open the retaining clips due to space constraints. Pencils are not recommended as a tool as they may not be strong enough.

- ① Place the tip of the tool in the recess on the top of the retaining clip.
- ② Carefully rotate the retaining clip away from the memory module slot.

**Attention:** To avoid breaking the retaining clips or damaging the memory module slots, handle the clips gently.

Figure 88. Opening retaining clips



Step 3. Remove the memory module from the slot.

- a. 1 Make sure the retaining clips are in the fully open position.
- b. 2 Hold the memory module at both ends and carefully lift it out of the slot.




Figure 89. Memory module removal

## After you finish

1. Install a replacement unit. See [“Install a memory module” on page 111](#).
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video


<https://www.youtube.com/watch?v=tiS551OwN84>

## Install a memory module

Follow instructions in this section to install a memory module.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

See “[Memory module installation rules and order](#)” on page 33 for detailed information about memory configuration and setup.

#### **Attention:**

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Make sure to remove or install memory module 20 seconds after disconnecting power cords from the system. It allows the system to be completely discharged of electricity and safe for handling memory module.
- Make sure to adopt one of the supported configurations listed in “[Memory module installation rules and order](#)” on page 33.
- Memory modules are sensitive to static discharge and require special handling. Refer to the standard guidelines at “[Handling static-sensitive devices](#)” on page 31:
  - Always wear an electrostatic-discharge strap when removing or installing memory modules. Electrostatic-discharge gloves can also be used.
  - Never hold two or more memory modules together so that they do not touch each other. Do not stack memory modules directly on top of each other during storage.
  - Never touch the gold memory module connector contacts or allow these contacts to touch the outside of the memory module connector housing.
  - Handle memory modules with care: never bend, twist, or drop a memory module.
  - Do not use any metal tools (such as jigs or clamps) to handle the memory modules, because the rigid metals may damage the memory modules.
  - Do not insert memory modules while holding packages or passive components, which can cause package cracks or detachment of passive components by the high insertion force.

**Firmware and driver download:** You might need to update the firmware or driver after replacing a component.

- Go to <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3/downloads/driver-list/> to see the latest firmware and driver updates for your server.

- Go to [“Update the firmware” on page 175](#) for more information on firmware updating tools.

## Procedure

**Attention:** Make sure to remove or install memory module 20 seconds after disconnecting power cords from the system. It allows the system to be completely discharged of electricity and safe for handling memory module.

Step 1. Locate the memory module slots and determine the memory module installation order based on [“Memory module installation rules and order” on page 33](#).





Figure 90. Memory modules and processor layout

- Step 2. Open the retaining clips on each end of the memory module slot. If necessary, you can use a pointed tool to open the retaining clips due to space constraints. Pencils are not recommended as a tool as they may not be strong enough.
- ① Place the tip of the tool in the recess on the top of the retaining clip.
  - ② Carefully rotate the retaining clip away from the memory module slot.

**Attention:** To avoid breaking the retaining clips or damaging the memory module slots, handle the clips gently.

Figure 91. Opening retaining clips



Step 3. Install the memory module into the slot.

- a. 1 Make sure the retaining clips are in the fully open position.
- b. 2 Align the memory module with the slot, and gently place the memory module on the slot with both hands.
- c. 3 Firmly press both ends of the memory module straight down into the slot until the retaining clips snap into the locked position.

**Attention:** If there is a gap between the memory module and the retaining clips, the memory module has not been correctly inserted. In this case, open the retaining clips, remove the memory module, and then reinsert it.




Figure 92. Memory module installation

## After you finish

1. If applicable, install the ODD+bay 2 drive cage assembly (see [“Install the optical drive cage” on page 87](#)) or install the bay 2+bay 3 drive cage assembly (see [“Install the drive cage \(bay 3\)” on page 76](#)).
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

## Demo video

<https://www.youtube.com/watch?v=mrtFc4BZvXY>

---

## Mono amplifier (speaker) replacement

If the chassis supports the mono amplifier, follow instructions in this section to remove and install the mono amplifier (speaker).

### Remove the mono amplifier (speaker)

Follow instructions in this section to remove the mono amplifier (speaker).

## About this task

### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

Step 2. Disconnect the mono amplifier cable from the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6 “Internal cable routing” on page 157](#) when disconnecting cables from the system board.

Step 3. Remove the mono amplifier.

- a. ① Remove the screw that secures the mono amplifier to the chassis.
- b. ② Slide out the mono amplifier from the bracket, and remove it from the chassis.




Figure 93. Removing the mono amplifier

### After you finish

1. Install a replacement unit. See “[Install the mono amplifier \(speaker\)](#)” on page 115.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

[https://www.youtube.com/watch?v=X\\_bxfl409aE](https://www.youtube.com/watch?v=X_bxfl409aE)

## Install the mono amplifier (speaker)

Follow instructions in this section to install the mono amplifier (speaker).

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.

- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

## Procedure

Step 1. Install the mono amplifier.

- a. ① Insert the mono amplifier into the bracket on the inside of the chassis.
- b. ② Fasten the screw to secure the mono amplifier to the chassis.




Figure 94. Installing the mono amplifier

Step 2. Connect the mono amplifier cable to the system board. See [Chapter 6 “Internal cable routing” on page 157](#).

## After you finish

Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

## Demo video

[https://www.youtube.com/watch?v=tMiKM\\_f-zpo](https://www.youtube.com/watch?v=tMiKM_f-zpo)

---

## PCIe adapter replacement

Follow instructions in this section to remove and install a PCIe adapter.

### Remove a PCIe adapter

Follow instructions in this section to remove a PCIe adapter.

### About this task

#### S002



**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**Attention:**

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See “[Power off the server](#)” on page 34.
- If the server is in a rack, remove it from the rack. See “[Remove the server from rack](#)” on page 34.
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Notes:**

- For a list of the supported PCIe adapters, see <https://serverproven.lenovo.com>.
- The PCIe adapter might look different from the illustration.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See “[Remove the server cover](#)” on page 146.

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. Disconnect all PCIe adapter cables. See [Chapter 6 “Internal cable routing”](#) on page 157.

Step 2. Remove the PCIe adapter.


- a. ❶ Rotate the PCIe adapter retainer clip to the open position.
- b. ❷ Press the retaining clip to release the PCIe adapter.

**Note:** This step is applicable only to the PCIe adapter installed in PCIe slot 1.

- c. ❸ Hold the PCIe adapter by both edges, and gently lift it out from the PCIe slot.

**Note:** The PCIe adapter might be clamped by the slot tightly. In this case, gently and evenly shake the PCIe adapter until the clamping force from the connector is significantly reduced and the adapter becomes easily removable.

Figure 95. Removing a PCIe adapter



### After you finish

1. Install a replacement unit. See [“Install a PCIe adapter” on page 119](#). Otherwise, install a bracket to cover the vacancy on the chassis, and close the retainer clip.




Figure 96. Installing a PCIe adapter bracket

2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

#### Demo video

<https://www.youtube.com/watch?v=oFJWURkNF3I>

## Install a PCIe adapter

Follow instructions in this section to install a PCIe adapter.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

#### Notes:

- For a list of the supported PCIe adapters, see <https://serverproven.lenovo.com>.
- The PCIe adapter might look different from the illustration.

## Procedure

Step 1. Make preparation for this task.

- If a bracket is installed in the chassis, open the PCIe adapter retainer clip and remove the bracket from the chassis. Keep the bracket for future use.




Figure 97. Removing a PCIe adapter bracket

- Locate the applicable PCIe slot. For more information about the PCIe slots, see “[Technical specifications](#)” on page 3.

Step 2. Install the PCIe adapter.

- ① Align the PCIe adapter to the slot; then, gently press both ends of the PCIe adapter until it is securely seated in the slot with ② the retaining clip clicks into the locked position.
- ③ Rotate the PCIe adapter retainer clip towards the chassis until it snaps into locked position.




Figure 98. Installing a PCIe adapter

Step 3. Connect the PCIe adapter cables. See [Chapter 6 “Internal cable routing” on page 157](#).

### After you finish

Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

### Demo video

<https://www.youtube.com/watch?v=p8rQ1ajTu8Y>


---

## Power button with LED replacement

Follow instructions in this section to remove and install the power button with LED.

### Remove the power button with LED

Follow instructions in this section to remove the power button with LED.



**CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

**About this task**

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).


**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. Remove the front bezel. See [“Remove the front bezel” on page 95](#).

Step 2. Remove the power button cable from the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6 “Internal cable routing” on page 157](#) when disconnecting cables from the system board.

Step 3. Remove the screw that secures the front I/O bracket to the chassis.



*Figure 99. Removing the screw that secures the front I/O bracket*

Step 4. Remove the front I/O bracket.

- a. ① Rotate the left end of the front I/O bracket away from the chassis.
- b. ② Remove the front I/O bracket from the chassis.




Figure 100. Removing the front I/O bracket from the chassis

Step 5. Remove the power button with LED from the front I/O bracket.

- a. ① Press the release tab on the power button to release it from the front I/O bracket.
- b. ② Remove the power button from the front I/O bracket.




Figure 101. Removing the power button with LED

## After you finish

1. Install a replacement unit. See [“Install the power button with LED” on page 125.](#)
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video


<https://www.youtube.com/watch?v=hbr608Jg8VI>

## Install the power button with LED

Follow instructions in this section to install the power button with LED.

### About this task

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

### Procedure

Step 1. Install the power button with LED.

- a. ① Tilt the power button, and insert the tab on the bottom of the power button cable into the slot.
- b. ② Push the power button into the slot until it snaps into place.




Figure 102. Installing the power button with LED

Step 2. Install the front I/O bracket.

- a. ① There is a small tab on the right side of the front I/O bracket. Place the tab behind the front I/O bracket slot on the chassis.

- b. ② Align the guide hole and screw hole on the front I/O bracket with the guide pin and screw slot on the chassis; then, install the front I/O bracket to the chassis. Make sure the small tab on the right side of the front I/O bracket is placed behind the chassis.




Figure 103. Installing the front I/O bracket to the chassis

- c. Fasten the screw to secure the front I/O bracket to the chassis.




Figure 104. Securing the front I/O bracket to the chassis

Step 3. Connect the power button cable to the system board. See [Chapter 6 “Internal cable routing” on page 157](#).

### After you finish

1. Reinstall the front bezel. See [“Install the front bezel” on page 96](#).
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

### Demo video

<https://www.youtube.com/watch?v=h68rtGFRHIU>

---

## Power supply unit replacement

Follow instructions in this section to remove and install the power supply unit.

### Remove the power supply unit

Follow instructions in this section to remove the power supply unit.

### About this task

**S001**



## DANGER

Electrical current from power, telephone, and communication cables is hazardous.  
To avoid a shock hazard:

- Connect all power cords to a properly wired and grounded electrical outlet/source.
- Connect any equipment that will be attached to this product to properly wired outlets/sources.
- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- The device might have more than one power cord, to remove all electrical current from the device, ensure that all power cords are disconnected from the power source.


### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

### S035



#### CAUTION:

Never remove the cover on a power supply or any part that has this label attached. Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

#### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- b. If applicable, remove the simple-swap drive (bay 0-1). See [“Remove a simple-swap drive \(bay 0-1\)” on page 44](#).
- c. If applicable, remove the simple-swap drive cage (bay 0-1). See [“Remove the drive cage \(bay 0-1\)” on page 53](#).

Step 2. Disconnect the processor power cable and system power cable from the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6 “Internal cable routing” on page 157](#) when disconnecting cables from the system board.

Step 3. From the outside of the chassis, remove the four screws that secure the power supply unit to the chassis.




Figure 105. Removing the screws securing the power supply unit

Step 4. Remove the power supply unit from the chassis.

- a. ① Press the release tab to disengage the power supply unit from the chassis.
- b. ① Slide out the power supply unit; then, lift it out of the chassis.




Figure 106. Removing the power supply unit

### After you finish

1. Install a replacement unit. See “[Install the power supply unit](#)” on page 130.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

[https://www.youtube.com/watch?v=\\_FTWRagoNmQ](https://www.youtube.com/watch?v=_FTWRagoNmQ)

## Install the power supply unit

Follow instructions in this section to install the power supply unit.

### About this task

#### S001





**DANGER**

Electrical current from power, telephone, and communication cables is hazardous.  
To avoid a shock hazard:

- Connect all power cords to a properly wired and grounded electrical outlet/source.
- Connect any equipment that will be attached to this product to properly wired outlets/sources.
- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- The device might have more than one power cord, to remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### S035



#### **CAUTION:**

Never remove the cover on a power supply or any part that has this label attached. Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.
- Make sure the type of power supply is applicable to server drive configuration. See [“Technical specifications” on page 3](#) for more information.

## **Procedure**

- Step 1. Lower the power supply unit into the chassis, and slide it toward the opening on the rear side of chassis until the release tab snaps into place.




Figure 107. Installing the power supply unit to the chassis

- Step 2. From the outside of the chassis, fasten the four screws to secure the power supply unit to the chassis.




Figure 108. Securing the power supply unit to the chassis

- Step 3. Connect the processor power cable and system power cable to the system board. See [Chapter 6](#) “Internal cable routing” on page 157.

## After you finish

1. Install the drive cage and drive. See [“Simple-swap drive and drive cage replacement \(bay 0-1\)” on page 44.](#)
2. Complete the parts replacement. See [“Complete the parts replacement” on page 154.](#)

### Demo video

<https://www.youtube.com/watch?v=fgtcBsGoEZk>

---

## Processor replacement (trained technician only)

Follow instructions in this section to remove and install the processor.

**Important:** This task must be operated by trained technicians that are certified by Lenovo Service. Do not attempt to remove or install the part without proper training and qualification.

**Attention:** Before reusing a processor or heat sink, make sure you use Lenovo proven alcohol cleaning pad and thermal grease.

### Remove the processor (trained technician only)

Follow instructions in this section to remove the processor. The procedure must be executed by a trained technician.

### About this task

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34.](#)
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34.](#)
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.
- Make sure to manually record the UEFI settings before processor removal because the system will load default UEFI settings when the processor is removed.

### Procedure

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146.](#)

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.


- b. If applicable, remove the ODD+bay 2 drive cage assembly (see [“Remove an optical drive cage” on page 85](#)) or remove the bay 2+bay 3 drive cage assembly (see [“Remove the drive cage \(bay 3\)” on page 74](#)).
- c. Remove the heat sink and fan module. See [“Remove the heat sink and fan module \(trained technician only\)” on page 97](#).

**Step 2. Remove the processor.**

- a. ① Gently pull the handle away from the processor retainer.
- b. ② Lift the handle.
- c. ③ Lift the socket retainer to the fully open position as illustrated.
- d. ④ Hold the processor by both sides and gently lift it away from the processor socket.

**Notes:**

1. Do not touch the gold contacts on the bottom of the processor.
2. Keep the processor socket clean from any object to prevent possible damages.



*Figure 109. Removing the processor*

## After you finish

After removing the processor, perform one of the following tasks immediately:

- Install the replacement processor.
  1. Install the replacement processor to the system board. See [“Install the processor \(trained technician only\)” on page 135](#).
  2. Package the defective processor that was removed, and return it to Lenovo. To prevent any shipping damage, reuse the packaging of the new processor, and follow all available packaging instructions.
- Install the processor that you removed to the replacement system board.
  1. Install the removed processor to the replacement system board. See [“Install the processor \(trained technician only\)” on page 135](#).

2. Package the defective system board, and return it to Lenovo. To prevent any shipping damage, reuse the packaging of the new system board, and follow all available packaging instructions.

### Demo video

<https://www.youtube.com/watch?v=yPVzSTWPgrk>

## Install the processor (trained technician only)

Follow instructions in this section to install the processor. The procedure must be executed by a trained technician.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
- Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.
- Before reusing a processor that was removed from another system board, wipe the thermal grease from the processor with an alcohol cleaning pad, and dispose of the cleaning pad after all of the thermal grease is removed.

**Note:** If you are applying new thermal grease on the top of the processor, make sure to do it after the alcohol has fully evaporated.

- Apply the thermal grease on the top of the processor with syringe by forming four uniformly spaced dots, while each dot consists of about 0.1 ml of thermal grease.




Figure 110. Proper shape of the thermal grease

## Procedure

Step 1. Hold the processor by both sides, and align the following:

1. Align **1** the small notches on the processor with **2** the tabs on the socket.
2. Align **3** the small triangle of the processor with **4** the triangular mark on the socket.

Then, gently lower the processor evenly into the socket.




Figure 111. Installing the processor

Step 2. Close the processor retainer, and push the handle to the locked position.




Figure 112. Closing the processor retainer

## After you finish

1. Install the heat sink and the fan module. See “Install the heat sink and fan module (trained technician only)” on page 99.
2. If applicable, install the ODD+bay 2 drive cage assembly (see “Install the optical drive cage” on page 87) or install the bay 2+bay 3 drive cage assembly (see “Install the drive cage (bay 3)” on page 76).
3. Complete the parts replacement. See “Complete the parts replacement” on page 154.
4. (For China only) If the message “The system detects a new processor installed or fTPM NVRAM data mismatched.” is displayed after the server is turned on, complete the following steps to clear fTPM:
  - a. Back up the security data or recovery key before clearing fTPM.
  - b. Press **F1** to start the Setup Utility program.
  - c. Select **Security**.
  - d. Set **Reset fTPM** to **Enabled**.
  - e. Restart the server.
5. After replacing the processor, make sure to reconfigure the server and reset system date and time.

## Demo video

<https://www.youtube.com/watch?v=9k154qBwPhQ>

---

## System board replacement (trained technician only)

Follow instructions in this section to remove and install the system board.

**Important:** This task must be operated by trained technicians that are certified by Lenovo Service. Do not attempt to remove or install the part without proper training and qualification.

### CAUTION:

**Hazardous moving parts. Keep fingers and other body parts away.**



### CAUTION:



The heat sinks and processors might be very hot. Turn off the server and wait several minutes to let the server cool before removing the server cover.

## Remove the system board

Follow instructions in this section to remove the system board. The procedure must be executed by a trained technician.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Important:**

- This task must be operated by trained technicians that are certified by Lenovo Service. Do not attempt to remove or install the part without proper training and qualification.
- When removing the memory modules, label the slot number on each memory module, remove all the memory modules from the system board, and set them aside on a static-protective surface for reinstallation.
- **When disconnecting cables, make a list of each cable and record the connectors the cable is connected to, and use the record as a cabling checklist after installing the new system board.**

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.


## Procedure

Step 1. Make preparation for this task.

- a. Remove the server cover. See [“Remove the server cover” on page 146](#).
- b. Remove the front bezel. See [“Remove the front bezel” on page 95](#).
- c. If applicable, remove the ODD+bay 2 drive cage assembly (see [“Remove an optical drive cage” on page 85](#)) or remove the bay 2+bay 3 drive cage assembly (see [“Remove the drive cage \(bay 3\)” on page 74](#)).

- d. Remove the cage bar. See step 3 in [“Remove the server cover”](#) on page 146.
- e. If applicable, remove the rear fan. See [“Remove the fan \(front and rear\)”](#) on page 90.
- f. If applicable, remove the M.2 drive. See [“Remove an M.2 drive”](#) on page 101.
- g. If applicable, remove the PCIe adapters. See [“Remove a PCIe adapter”](#) on page 116.
- h. Remove the memory modules. See [“Remove a memory module”](#) on page 108.
- i. Remove the heat sink and fan module. See [“Remove the heat sink and fan module \(trained technician only\)”](#) on page 97.
- j. Remove the processor. See [“Remove the processor \(trained technician only\)”](#) on page 133.


Step 2. Remove the screw that secures the front I/O bracket to the chassis.



*Figure 113. Removing the screw that secures the front I/O bracket*

Step 3. Remove the front I/O bracket.

- a. ① Rotate the left end of the front I/O bracket away from the chassis.
- b. ② Remove the front I/O bracket from the chassis.



*Figure 114. Removing the front I/O bracket from the chassis*

Step 4. Disconnect all the cables connected to the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6](#) “Internal cable routing” on page 157 when disconnecting cables from the system board.

Step 5. Remove the nine screws that secure the system board in the sequence shown in the illustration below. Keep the screws for future use.




Figure 115. System-board screws removal sequence

Step 6. Remove the system board from the chassis.

- a. ① Slide the system board toward the front of the server to release the serial port connector from the chassis.
- b. ② Gently grasp the system board by the edges; then, tilt the system board, and remove it from the chassis.




Figure 116. Removing the system board from the chassis

## After you finish

- If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

**Important:** Before you return the system board, make sure that you install the processor socket covers from the new system board. To replace a processor socket cover:

1. Take a socket cover from the processor socket assembly on the new system board, and orient it correctly above the processor socket assembly on the removed system board.
2. Gently press down the socket cover legs to the processor socket assembly. You might hear a click when the socket cover is securely attached.

**Note:** Press on the edges to avoid damage to the socket pins.

3. **Make sure** that the socket cover is securely attached to the processor socket assembly.

- If you plan to recycle the component, see [“Disassemble the system board for recycle” on page 201](#).

#### Demo video

<https://www.youtube.com/watch?v=lurLII4N9gE>

## Install the system board

Follow instructions in this section to install the system board. The procedure must be executed by a trained technician.

### About this task

#### S002



#### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### **Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Touch the static-protective package that contains the drive to any unpainted metal surface on the server; then, remove the drive from the package and place it on a static-protective surface.

**Firmware and driver download:** You might need to update the firmware or driver after replacing a component.

- Go to <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3/downloads/driver-list/> to see the latest firmware and driver updates for your server.
- Go to [“Update the firmware” on page 175](#) for more information on firmware updating tools.

## Procedure

Step 1. Install the system board.

- a. ① Tilt the system board, and align the connectors with the corresponding opening on the front of the chassis. Then, gently lower the system board into the chassis, and insert the connectors into the slot on the front of the chassis.

- b. 2 Slide the system board toward the rear of the chassis until the system board is secured in place.




Figure 117. Installing the system board into the chassis

- Step 2. Secure the system board to the chassis with nine screws in the sequence shown in the illustration below.




Figure 118. System-board screws installation sequence

## After you finish

**Note:** Make sure the CMOS battery is installed on the system board. See [“Install the CMOS battery \(CR2032\)” on page 42.](#)

1. Install the front I/O bracket.
  - a. 1 There is a small tab on the right side of the front I/O bracket. Place the tab behind the front I/O bracket slot on the chassis.

- b. ② Align the guide hole and screw hole on the front I/O bracket with the guide pin and screw slot on the chassis; then, install the front I/O bracket to the chassis.

**Note:** Make sure the small tab on the right side of the front I/O bracket is placed behind the chassis.




Figure 119. Installing the front I/O bracket to the chassis

- c. Fasten the screw to secure the front I/O bracket to the chassis.




Figure 120. Securing the front I/O bracket to the chassis

2. Install the processor. See [“Install the processor \(trained technician only\)”](#) on page 135.
3. Install the heat sink and fan module. See [“Install the heat sink and fan module \(trained technician only\)”](#) on page 99.
4. Install the memory module. See [“Install a memory module”](#) on page 111.
5. If applicable, install the PCIe adapter. See [“Install a PCIe adapter”](#) on page 119.
6. If applicable, install the M.2 drive. See [“Install an M.2 drive”](#) on page 103.
7. If applicable, install the rear fan. See [“Install the fan \(front and rear\)”](#) on page 93.
8. Install the cage bar. See step 3 in [“Install the server cover”](#) on page 148.
9. If applicable, install the ODD+bay 2 drive cage assembly (see [“Install the optical drive cage”](#) on page 87) or install the bay 2+bay 3 drive cage assembly (see [“Install the drive cage \(bay 3\)”](#) on page 76).
10. Install the front bezel. See [“Install the front bezel”](#) on page 96.
11. Reconnect all the cables that were disconnected.
12. Complete the parts replacement. See [“Complete the parts replacement”](#) on page 154.
13. Update the vital product data (VPD). See [ST45 V3 Tip TT2403](#). Machine type number and serial number can be found on the ID label. See [“Identify the server”](#) on page 23.
14. Optionally, enable UEFI Secure Boot. See [“Enable UEFI Secure Boot”](#) on page 146.
15. After replacing the system board, make sure to reconfigure the server and reset system date and time.

#### Demo video

[https://www.youtube.com/watch?v=MZ\\_z7Osz95M](https://www.youtube.com/watch?v=MZ_z7Osz95M)

## Enable UEFI Secure Boot

Optionally, you can enable UEFI Secure Boot.

To enable UEFI Secure Boot, do as follows:

1. Start the server and press **F1** to access Setup Utility.
2. Select **Security** → **Secure Boot** → **Secure Boot**.
3. Set **Secure Boot** to **Enabled** and save the setting.

**Note:** If disabling UEFI Secure Boot is needed, set **Secure Boot** to **Disabled** in step 3.

---

## Server cover replacement

Follow instructions in this section to remove and install the server cover.

### Remove the server cover

Follow instructions in this section to remove the server cover.

#### About this task

##### S002



##### **CAUTION:**

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

##### S014



##### **CAUTION:**

Hazardous voltage, current, and energy levels might be present. Only a qualified service technician is authorized to remove the covers where the label is attached.

##### S033



##### **CAUTION:**

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

**Procedure**

Step 1. Remove the server cover.

- a. ① Use a screwdriver to remove the two screws that secure the server cover to the chassis.
- b. ② Slide the server cover away from the front bezel, and lift it up from the chassis. Reserve the screws to be used for reinstalling the server cover.

**Attention:**

- The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.
- For proper cooling, always install the server cover before powering on the server. Operating the server without the cover properly installed might result in server component damage.




Figure 121. Removing the server cover

- Step 2. If applicable, remove the ODD+bay 2 drive cage assembly (see [“Remove an optical drive cage” on page 85](#)) or remove the bay 2+bay 3 drive cage assembly (see [“Remove the drive cage \(bay 3\)” on page 74](#)). Then, remove the cage bar.
- a. ① Push the latch on the cage bar until the cage bar is disengaged from the chassis.
  - b. ② Rotate the cage bar and remove it from the chassis.




Figure 122. Removing the cage bar

## After you finish

1. Install a replacement unit. See “Install the server cover” on page 148.
2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

## Demo video

<https://www.youtube.com/watch?v=KUWXGt1rD6c>

## Install the server cover

Follow instructions in this section to install the server cover.

## About this task

### S002



### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

### S014



**CAUTION:**

Hazardous voltage, current, and energy levels might be present. Only a qualified service technician is authorized to remove the covers where the label is attached.

**S033**



**CAUTION:**

Hazardous energy present. Voltages with hazardous energy might cause heating when shorted with metal, which might result in spattered metal, burns, or both.

**Attention:**

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Ensure that all adapters and other components are installed and seated correctly, and that you have not left loose tools or parts inside the server.
- Ensure that all internal cables are correctly routed. See [Chapter 6 “Internal cable routing” on page 157](#) for more information.
- If you are installing a new server cover, attach the service label to the inside of the new server cover if necessary.

**Note:** A new server cover comes without a service label attached. If you need a service label, order it together with the new server cover. The service label is free of charge.

**Procedure**

Step 1. (Optional) Install the cage bar.

- a. ① Insert the tabs on cage bar to the slots on the rear side of the chassis.
- b. ② Align the tabs on the other end of the cage bar to the slots on the front side of the chassis, and rotate the cage bar toward the front of the chassis until the cage bar is secured in place.




Figure 123. Installing the cage bar

Step 2. Install the server cover.

- a. ❶ Align the server cover to the slots on the side of the chassis. Ensure that all the tabs on the cover are engaged with the chassis properly; then, slide the cover towards the front bezel until it snaps in place.
- b. ❷ Use a screwdriver to fasten the two screws to secure the cover to the chassis.




Figure 124. Installing the server cover

#### Demo video

<https://www.youtube.com/watch?v=IZJc7x-gKO8>

---

## Thermal sensor replacement

Follow instructions in this section to remove and install the thermal sensor.

### Remove the thermal sensor

Follow instructions in this section to remove the thermal sensor.

#### About this task

##### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

- Read “Installation Guidelines” on page 29 and “Safety inspection checklist” on page 30 to ensure that you work safely.

- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

## Procedure

Step 1. Make preparation for this task.

- Remove the server cover. See [“Remove the server cover” on page 146](#).

**Attention:** The heat sink and processor could be very hot. To avoid burning yourself, wait for a few minutes after turning off the server before you remove the server cover.

- Remove the front bezel. See [“Remove the front bezel” on page 95](#).
- Remove the front fan. See [“Remove the fan \(front and rear\)” on page 90](#).
- If applicable, remove the M.2 drive. See [“Remove an M.2 drive” on page 101](#).

Step 2. Disconnect the thermal sensor cable from the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6 “Internal cable routing” on page 157](#) when disconnecting cables from the system board.

Step 3. Remove the thermal sensor.

- 1 Press the release tab on the thermal sensor to release it from the chassis.
- 2 Remove the thermal sensor from the chassis.




Figure 125. Removing the thermal sensor

## After you finish

1. Install a replacement unit. See [“Install the thermal sensor” on page 153](#).

2. If you are instructed to return the component or optional device, follow all packaging instructions, and use any packaging materials for shipping that are supplied to you.

### Demo video

<https://www.youtube.com/watch?v=pUPfSDYDLyc>

## Install the thermal sensor

Follow instructions in this section to install the thermal sensor.

### About this task

#### S002



#### CAUTION:

The power-control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.

#### Attention:

1. Read “[Installation Guidelines](#)” on page 29 and “[Safety inspection checklist](#)” on page 30 to ensure that you work safely.
2. Touch the static-protective package that contains the component to any unpainted metal surface on the server; then, remove it from the package and place it on a static-protective surface.

## Procedure

Step 1. Install the thermal sensor.

- a. ① From the inside of the chassis, attach the end of the thermal sensor to the corresponding slot on the front of the chassis.
- b. ② From the inside of the chassis, push the thermal sensor into the slot.
- c. ③ Make sure the thermal sensor is secured in place.




Figure 126. Installing the thermal sensor

Step 2. Connect the thermal sensor cable to the system board. See [Chapter 6 “Internal cable routing” on page 157](#).

### After you finish

1. If an M.2 drive was removed, reinstall the M.2 drive. See [“Install an M.2 drive” on page 103](#).

**Note:** The thermal sensor cable should be placed under the M.2 drive.

2. Reinstall the front fan. See [“Install the fan \(front and rear\)” on page 93](#).
3. Reinstall the front bezel. See [“Install the front bezel” on page 96](#).
4. Complete the parts replacement. See [“Complete the parts replacement” on page 154](#).

### Demo video

<https://www.youtube.com/watch?v=0VwAVkVgAqE>

---

## Complete the parts replacement

Go through the checklist to complete parts replacement

To complete the parts replacement, do the following:

1. Ensure that all components have been reassembled correctly and that no tools or loose screws are left inside your server.
2. Ensure that the CMOS battery is installed on the system board. See [“Install the CMOS battery \(CR2032\)” on page 42](#).
3. Properly route and secure the cables in the server. Refer to the cable connecting and routing information for each component.
4. Reinstall the server cover. See [“Install the server cover” on page 148](#).

5. Reconnect the power cords and any cables that you removed.

**Note:** To avoid component damage, connect all the other cables before connecting the power cords.

6. Power on the server and any peripheral devices. See “Power on the server” on page 34.

7. Update the server configuration.

- Download and install the latest device drivers: <http://datacentersupport.lenovo.com>.
- Update the system firmware. See “Update the firmware” on page 175.
- Reconfigure the disk arrays if you have installed or removed a storage drive or a RAID adapter. See <https://pubs.lenovo.com/lxpm-overview/> for the LXPM documentation compatible with your server.



## Chapter 6. Internal cable routing

Some of the components in the server come with internal cables meant for specific connectors.

### Cable routing guidelines


Before connecting the cables, read the following guidelines carefully:

- Turn off the server before you connect or disconnect any internal cables.
- Refer to the documentation that comes with any external devices for additional cabling instructions.
- Make use of the identifiers printed on the cables to locate the proper connectors.
- Ensure that the cable is not pinched and does not cover any connectors or obstruct any components on the system board.

**Attention:** Strictly observe the following instructions to avoid damaging cable sockets on the system board. Any damage to the cable sockets might require replacing the system board.

- Connect cable connectors vertically or horizontally in alignment with the orientations of the corresponding cable sockets, avoiding any tilt.
- To disconnect cables from the system board, do as follows:
  1. Press and hold all latches, release tabs, or locks on cable connectors to release the cable connectors.
  2. Remove the cable connectors vertically or horizontally in alignment with the orientations of the corresponding cable sockets, avoiding any tilt.

**Note:** The cable connectors might look different from those in the illustration, but the removal procedure is the same.



## Cable routing for bay 0 drive

Follow the instructions in this section to learn how to do cable routing for the drive in bay 0.

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 127. Cable routing for bay 0 drive

Table 8. Cable routing for bay 0 drive

| From (bay 0 drive)        | To (system board)               | Cable                                   |
|---------------------------|---------------------------------|-----------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 1 connector       | 7pin SATA to 7pin RA SATA cable, 185 mm |
| <b>2</b> Power connector  | <b>2</b> SATA power 2 connector | 4pin power cable, 300 mm/80 mm          |

---


## Cable routing for bay 1 drive

Follow the instructions in this section to learn how to do cable routing for the drive in bay 1.

- [“Cable routing for bay 1 drive when SATA 1 connector is occupied by bay 0 drive” on page 159](#)
- [“Cable routing for bay 1 drive when SATA 1 connector is not occupied” on page 160](#)


For the system-board connector locations, see [“System-board connectors” on page 17](#).

### Cable routing for bay 1 drive when SATA 1 connector is occupied by bay 0 drive



| From (bay 1 drive)        | To (system board)               | Cable                                   |
|---------------------------|---------------------------------|-----------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 2 connector       | 7pin SATA to 7pin RA SATA cable, 185 mm |
| <b>2</b> Power connector  | <b>2</b> SATA power 2 connector | 4pin power cable, 300 mm/80 mm          |

## Cable routing for bay 1 drive when SATA 1 connector is not occupied



| From (bay 1 drive)        | To (system board)               | Cable                                   |
|---------------------------|---------------------------------|-----------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 1 connector       | 7pin SATA to 7pin RA SATA cable, 185 mm |
| <b>2</b> Power connector  | <b>2</b> SATA power 2 connector | 4pin power cable, 300 mm/80 mm          |


## Cable routing for bay 2 drive

Follow the instructions in this section to learn how to do cable routing for the drive in bay 2.

- “Cable routing for bay 2 drive when SATA 2 connector is occupied by bay 1 drive” on page 161
- “Cable routing for bay 2 drive when SATA 2 connector is not occupied” on page 162


For the system-board connector locations, see “System-board connectors” on page 17.

### Cable routing for bay 2 drive when SATA 2 connector is occupied by bay 1 drive



| From (bay 2 drive)        | To (system board)               | Cable                                            |
|---------------------------|---------------------------------|--------------------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 3 connector       | 7pin SATA to 7pin Slim ODD SATA, 520 mm          |
| <b>2</b> Power connector  | <b>2</b> SATA power 1 connector | 4pin power to HDD&Slim ODD, 300 mm/210 mm/120 mm |

## Cable routing for bay 2 drive when SATA 2 connector is not occupied



| From (bay 2 drive)        | To (system board)               | Cable                                            |
|---------------------------|---------------------------------|--------------------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 2 connector       | 7pin SATA to 7pin Slim ODD SATA, 520 mm          |
| <b>2</b> Power connector  | <b>2</b> SATA power 1 connector | 4pin power to HDD&Slim ODD, 300 mm/210 mm/120 mm |

## Cable routing for bay 3 drive

Follow the instructions in this section to learn how to do cable routing for the drive in bay 3.

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 128. Cable routing for bay 3 drive

| From (bay 3 drive)        | To (system board)               | Cable                                   |
|---------------------------|---------------------------------|-----------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 3 connector       | 7pin SATA to 7pin RA SATA cable, 185 mm |
| <b>2</b> Power connector  | <b>2</b> SATA power 1 connector | 4pin power cable, 300 mm/80 mm          |

## Cable routing for optical disk drive

Follow the instructions in this section to learn how to do cable routing for the optical disk drive (ODD).

- “Cable routing for ODD when SATA 2 connector is occupied by bay 2 drive” on page 164
- “Cable routing for ODD when SATA 2 connector is not occupied” on page 165

For the system-board connector locations, see “System-board connectors” on page 17.

### Cable routing for ODD when SATA 2 connector is occupied by bay 2 drive




Figure 129. Cable routing for ODD

Table 9. Cable routing for ODD

| From (ODD)                | To (system board)               | Cable                                            |
|---------------------------|---------------------------------|--------------------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 3 connector       | 7pin SATA to 7pin Slim ODD SATA, 520 mm          |
| <b>2</b> Power connector  | <b>2</b> SATA power 1 connector | 4pin power to HDD&Slim ODD, 300 mm/210 mm/120 mm |

## Cable routing for ODD when SATA 2 connector is not occupied




Figure 130. Cable routing for ODD

Table 10. Cable routing for ODD

| From (ODD)                | To (system board)               | Cable                                            |
|---------------------------|---------------------------------|--------------------------------------------------|
| <b>1</b> Signal connector | <b>1</b> SATA 2 connector       | 7pin SATA to 7pin Slim ODD SATA, 520 mm          |
| <b>2</b> Power connector  | <b>2</b> SATA power 1 connector | 4pin power to HDD&Slim ODD, 300 mm/210 mm/120 mm |

---

## Cable routing for the RAID adapter and drives

Follow the instructions in this section to learn how to do cable routing for the RAID adapter and drives.

- [“Cable routing for two drives with the RAID adapter” on page 167](#)
- [“Cable routing for three drives with the RAID adapter” on page 168](#)

For the system-board connector locations, see [“System-board connectors” on page 17](#).

### RAID adapter cable

**Note:**  The break lines indicate that part of the cable is hidden in the illustration.




Figure 131. Cable for 5350-8i or 4350-8i





Figure 132. Cable for 545-8i


|                                                        |                                    |
|--------------------------------------------------------|------------------------------------|
| <b>1</b> Connector for the RAID adapter (connector C0) | <b>2</b> Connectors for the drives |
|--------------------------------------------------------|------------------------------------|

## Cable routing for two drives with the RAID adapter



| From                                            | To                                                                               | Cable                                                                                                                                                                                                                                                   |
|-------------------------------------------------|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> C0 connector on the RAID adapter       | <b>1a</b> Bay 2 drive signal connector<br><b>1b</b> Bay 0 drive signal connector | <ul style="list-style-type: none"> <li>For 5350-8i or 4350-8i: Mini SAS HD X4 Vertical to VT SATA7P x2 + RA SATA 7P x2, 460 mm/420 mm/440 mm/440 mm</li> <li>For 545-8i: SlimSASX8 to SATA7P ST*2 + SATA7P RA*2, 460 mm/420 mm/440 mm/440 mm</li> </ul> |
| <b>2</b> Bay 0 and bay 1 drive power connectors | <b>2</b> SATA power 2 connector                                                  | 4pin power cable, 300 mm/80 mm                                                                                                                                                                                                                          |
| <b>3</b> Bay 1 drive signal connector           | <b>3</b> SATA 1 connector                                                        | 7pin SATA to 7pin RA SATA cable, 185 mm                                                                                                                                                                                                                 |
| <b>4</b> Bay 2 drive power connector            | <b>4</b> SATA power 1 connector                                                  | 4pin power to HDD&Slim ODD, 300 mm/210 mm/120 mm                                                                                                                                                                                                        |

## Cable routing for three drives with the RAID adapter



| From                                                                           | To                                                                                                                         | Cable                                                                                                                                                                                                                                        |
|--------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> C0 connector on the RAID adapter                                      | <b>1a</b> Bay 0 drive signal connector<br><b>1b</b> Bay 3 drive signal connector<br><b>1c</b> Bay 2 drive signal connector | <ul style="list-style-type: none"> <li>For 5350-8i: Mini SAS HD X4 Vertical to VT SATA7P x2 + RA SATA 7P x2, 460 mm/420 mm/440 mm/440 mm</li> <li>For 545-8i: SlimSASX8 to SATA7P ST*2 + SATA7P RA*2, 460 mm/420 mm/440 mm/440 mm</li> </ul> |
| <b>2</b> Bay 0 and bay 1 drive power connectors                                | <b>2</b> SATA power 2 connector                                                                                            | 4pin power cable, 300 mm/80 mm                                                                                                                                                                                                               |
| <b>3</b> Bay 1 drive signal connector                                          | <b>3</b> SATA 1 connector                                                                                                  | 7pin SATA to 7pin RA SATA cable, 185 mm                                                                                                                                                                                                      |
| <b>4a</b> Bay 3 drive power connector<br><b>4b</b> Bay 2 drive power connector | <b>4</b> SATA power 1 connector                                                                                            | 4pin power to HDD&Slim ODD, 300 mm/210 mm/120 mm                                                                                                                                                                                             |

## Cable routing for the power supply unit

Follow the instructions in this section to learn how to do cable routing for the power supply unit (PSU).

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 133. Cable routing for PSU

Table 11. Cable routing for PSU

| From (PSU)                                                                                                                                                                                                                                                                                           | To (system board)                  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------|
| <b>1</b> Micro-fit to 1X15P and 1X4P Y-splitter power cable (4-pin or 8-pin SATA connector for processor power)<br><b>Note:</b> An ATX 300 W PSU uses the 4-pin connector, while an ATX 500 W PSU uses the 8-pin connector. The figure above shows the 4-pin connector, which is used as an example. | <b>1</b> Processor power connector |
| <b>2</b> Micro-fit to 1X15P and 1X4P Y-splitter power cable (15-pin connector for system power)                                                                                                                                                                                                      | <b>2</b> System power connector    |

# Cable routing for the front fan and rear fan

Follow the instructions in this section to learn how to do cable routing for the front fan and rear fan.

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 134. Cable routing for the front fan and rear fan

Table 12. Cable routing for the front fan and rear fan

| From (fan)               | To (system board)            |
|--------------------------|------------------------------|
| <b>1</b> Front fan cable | <b>1</b> Front fan connector |
| <b>2</b> Rear fan cable  | <b>2</b> Rear fan connector  |

## Cable routing for the heat sink and fan module

Follow the instructions in this section to learn how to do cable routing for the heat sink and fan module.

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 135. Cable routing for the heat sink and fan module

Table 13. Cable routing for the heat sink and fan module

| From                             | To                                          |
|----------------------------------|---------------------------------------------|
| 1 Heat sink and fan module cable | Processor fan connector on the system board |

# Cable routing for the thermal sensor

Follow the instructions in this section to learn how to do cable routing for the thermal sensor.

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 136. Cable routing for the thermal sensor

Table 14. Cable routing for the thermal sensor

| From                          | To                                           |
|-------------------------------|----------------------------------------------|
| <b>1</b> Thermal sensor cable | Thermal sensor connector on the system board |

**Note:** If applicable, place the thermal sensor cable under the M.2 drive.

## Cable routing for the mono amplifier

If the chassis supports the mono amplifier, follow the instructions in this section to learn how to do cable routing for the mono amplifier.

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 137. Cable routing for the mono amplifier

Table 15. Cable routing for the mono amplifier

| From                          | To                                                    |
|-------------------------------|-------------------------------------------------------|
| <b>1</b> Mono amplifier cable | <b>1</b> Mono amplifier connector on the system board |

# Cable routing for the power button with LED

Follow the instructions in this section to learn how to do cable routing for the power button with LED.

For the system-board connector locations, see [“System-board connectors” on page 17](#).




Figure 138. Cable routing for the power button with LED

Table 16. Cable routing for the power button with LED

| From                        | To                                                      |
|-----------------------------|---------------------------------------------------------|
| <b>1</b> Power button cable | Connector for power button with LED on the system board |

---

## Chapter 7. System configuration

Complete these procedures to configure your system.

**Note:** Some Lenovo system management applications, including Lenovo XClarity Controller, Lenovo XCC Logger Utility, Lenovo XClarity Administrator, Lenovo XClarity Integrator, and Lenovo XClarity Energy Manager, are not supported by ST45 V3.

---

### Update the firmware

Go to Lenovo Datacenter Support site for the latest firmware update package.

To update the firmware from a flash device, complete the following steps:

1. Go to <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3/downloads/driver-list/>. All the downloadable firmware packages for ST45 V3 are available on this site.
2. Download the latest version of firmware update packages.
3. Follow Lenovo XClarity Essentials Bootable Media Creator (BoMC) and Lenovo XClarity Provisioning Manager Lite (LXPM Lite) instructions to update the firmware.

**Notes:**

- BoMC can support all system firmware except HDD. For details, see <https://pubs.lenovo.com/lxce-bomc/>.
- LXPM Lite only supports UEFI firmware update. For details, see <https://pubs.lenovo.com/lxpm-lite/>.

---

### Configure the firmware

Read this section to learn about how to set up the firmware for the server.

### Starting the Setup Utility program

Follow this procedure to start the Setup Utility program.

To start the Setup Utility program, complete the following steps:

- Step 1. Power on or restart the server.
- Step 2. Before the operating system starts up, repeatedly press and release **F1**. It will lead to the text-based BIOS interface.

**Note:** If a BIOS password has been set, the Setup Utility program will not open until you enter the correct password.

### Enabling or disabling a device

This section provides information about how to enable or disable hardware devices, such as USB connectors or storage drives.

To enable or disable a device, complete the following steps:

- Step 1. Start the Setup Utility program. See [“Starting the Setup Utility program” on page 175](#).
- Step 2. Select **Devices**.
- Step 3. Select the device to enable or disable, and press **Enter**.

- Step 4. Select the desired setting, and press **Enter**.
- Step 5. To save settings and exit the Setup Utility program, press **F10**; then, select **Yes** in the displayed window, and press **Enter**.

## Enabling or disabling the automatic power-on

Automatic Power On in Setup Utility program provides various power-on options.

To enable or disable Automatic Power On, complete the following steps:

- Step 1. Start the Setup Utility program. See [“Starting the Setup Utility program” on page 175](#).
- Step 2. Select **Power**.
- Step 3. Select **After Power Loss**.
- Step 4. Select the desired option from **Power On**, **Power Off**, and **Last State**; then press **Enter**.
- Step 5. To save settings and exit the Setup Utility program, press **F10**; then, select **Yes** in the displayed window, and press **Enter**.

## Using passwords

Passwords can be set to prevent unauthorized access to the server.

Despite passwords enhance data security, they are not required. Read the following topics if you decide to set any passwords.

To start the Setup Utility program, complete the following steps:

### Password Types

The following types of passwords are available in the Setup Utility program:

- Power-on password

When a power-on password is set, you are prompted to enter a valid password each time the server is turned on. The server cannot be used until the valid password is entered.

- Administrator password

Setting an administrator password deters unauthorized users from changing configuration settings. If you are responsible for maintaining the configuration settings of several servers, you might want to set an administrator password.

When an administrator password is set, you are prompted to enter a valid password each time you try to access the Setup Utility program. The Setup Utility program cannot be accessed until a valid password is entered.

If both the power-on password and administrator password are set, you can enter either password. However, you must use your administrator password to change any configuration settings.

### Password considerations

A password can be any combination of up to 20 alphabetic and numeric characters. For security reasons, it is recommended to use a strong password that cannot be easily compromised.

**Note:** The Setup Utility program passwords are case-sensitive.

To set a strong password, consider the following guidelines:

- Have at least eight characters in length
- Contain at least one alphabetic character and one numeric character
- Not be your name or your user name
- Not be a common word or a common name
- Be significantly different from your previous passwords

## Setting, changing, or deleting a password

To set, change, or delete a password, complete the following steps:

- Step 1. Start the Setup Utility program. See [“Starting the Setup Utility program” on page 175](#).
- Step 2. Select **Security**.
- Step 3. Depending on the password type, select **Set Supervisor Password** and press **Enter**.
- Step 4. Follow the instructions on the right side of the screen to set, change, or delete a password.

**Note:** A password can be any combination of up to 20 alphabetic and numeric characters. For more information, see [Password considerations](#).

- Step 5. To save settings and exit the Setup Utility program, press **F10**; then, select **Yes** in the displayed window, and press **Enter**.

**Note:** When **Flash Authority** is set to **Disable**, the system will not validate the administrator password during a reboot initiated by a UEFI update.

## Erasing lost or forgotten passwords (clearing CMOS)

To erase a lost or forgotten password, complete the following steps:

- Step 1. Remove any media from the drives and turn off all connected devices and the server; then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the server.
- Step 2. Remove the server cover. See [“Remove the server cover” on page 146](#).
- Step 3. Remove the CMOS battery (CR2032). See [“Remove the CMOS battery \(CR2032\)” on page 40](#).
- Step 4. Wait for 10 to 15 seconds; then, reinstall the CMOS battery (CR2032). See [“Install the CMOS battery \(CR2032\)” on page 42](#).
- Step 5. Reinstall the server cover and reconnect the power cord. See [“Install the server cover” on page 148](#).
- Step 6. Turn on the server. Before the operating system starts up, press **F1** to enter the Setup Utility.
- Step 7. In Setup Utility, make sure the date, time, and other settings are correct.
- Step 8. To save settings and exit the Setup Utility program, press **F10**; then, select **Yes** in the displayed window, and press **Enter**.

## Selecting a startup device

If the server does not start up from the expected device, you can either change the startup device sequence or select a temporary startup device.

### Changing the startup device sequence permanently

To change the startup device sequence permanently, complete the following steps:

- Step 1. Depending on the type of the storage device, do one of the following:
  - If the storage device is internal, skip to [Step 2 on page 178](#).

- If the storage device is a disc, ensure that your server is turned on. Then, insert the disc into the optical drive.
- If the storage device is an external device other than a disc, connect the storage device to the server.

Step 2. Start the Setup Utility program. See [“Starting the Setup Utility program” on page 175](#).

Step 3. Select **Startup → FIXED BOOT ORDER Priorities**.

Step 4. Follow the instructions on the right side of the screen to change the startup device sequence.

Step 5. To save settings and exit the Setup Utility program, press **F10**; then, select **Yes** in the displayed window, and press **Enter**.

## Selecting a temporary startup device

**Note:** Not all discs and storage drives are applicable as startup device.

To select a temporary startup device, complete the following steps:

Step 1. Depending on the type of the storage device, do one of the following:

- If the storage device is internal, skip to [Step 2 on page 178](#).
- If the storage device is a disc, ensure that your server is turned on. Then, insert the disc into the optical drive.
- If the storage device is an external device other than a disc, connect the storage device to the server.

Step 2. Turn on or restart the server. Before the operating system starts up, repeatedly press and release **F12** until Startup Device Menu is displayed.

Step 3. Select the desired storage device and press **Enter**. The server will start up from the selected device.

## Exiting the Setup Utility program

Follow this procedure to exit the Setup Utility program.

To exit the Setup Utility program, do one the following steps:

- To save the new settings, press **F10**; then, select **Yes** in the displayed window, and press **Enter**.
- If you do not want to save the new settings, select **Exit → Discard Changes and Reset** and press **Enter**; then, select **Yes** in the displayed window, and press **Enter**.

---

## Memory configuration

Memory performance depends on several variables, such as memory mode, memory speed, memory ranks, memory population and processor.

More information about optimizing memory performance and configuring memory is available at the Lenovo Press website:

<https://lenovopress.lenovo.com/servers/options/memory>

In addition, you can take advantage of a memory configurator, which is available at the following site:

[https://dcsc.lenovo.com/#/memory\\_configuration](https://dcsc.lenovo.com/#/memory_configuration)

For specific information about the required installation order of memory modules in your server based on the system configuration and memory mode that you are implementing, see [“Memory module installation rules and order” on page 33](#).

---

## RAID configuration

Using a Redundant Array of Independent Disks (RAID) to store data remains one of the most common and cost-efficient methods to increase server's storage performance, availability, and capacity.

RAID increases performance by allowing multiple drives to process I/O requests simultaneously. RAID can also prevent data loss in case of a drive failure by reconstructing (or rebuilding) the missing data from the failed drive using the data from the remaining drives.

RAID array (also known as RAID drive group) is a group of multiple physical drives that uses a certain common method to distribute data across the drives. A virtual drive (also known as virtual disk or logical drive) is a partition in the drive group that is made up of contiguous data segments on the drives. Virtual drive is presented up to the host operating system as a physical disk that can be partitioned to create OS logical drives or volumes.

An introduction to RAID is available at the following Lenovo Press website:

<https://lenovopress.lenovo.com/lp0578-lenovo-raid-introduction>

Detailed information about RAID management tools and resources is available at the following Lenovo Press website:

<https://lenovopress.lenovo.com/lp0579-lenovo-raid-management-tools-and-resources>

AMD SW RAID driver installation guidelines are available at the following website:

[https://download.lenovo.com/servers\\_pdf/amd\\_sw\\_raid\\_driver\\_installation.pdf](https://download.lenovo.com/servers_pdf/amd_sw_raid_driver_installation.pdf)

## Enabling AMD RAIDXpert2

Before setting up RAID for SATA drives, follow the below steps to enable AMD RAIDXpert2:

1. Restart the system. Before the operating system starts up, press **F1** to enter the Setup Utility.
2. Go to **Devices → ATA Drive setup → SATA Mode**, and select **RAID**.
3. Save the changes and reboot the system.

## AMD RAIDXpert2 configurations

AMD offers various RAIDXpert2 configurations with different RAID levels and SSD support. See the following for more details.

**Note:** Supported RAID levels vary by model. For the RAID levels supported by ST45 V3, see [“Technical specifications” on page 3](#).

| AMD RAIDXpert2 configurations for SATA | Requirements                                                                    |
|----------------------------------------|---------------------------------------------------------------------------------|
| AMD RAIDXpert2                         | <ul style="list-style-type: none"><li>• Supports RAID levels 0 and 1.</li></ul> |

## Monitor RAID status

Users can monitor the RAID status in the following ways:

- Use the RAIDxpert2 GUI utility provided by AMD software raid (SWR) to monitor and manage the RAID volumes.
- Use AMD SWR HII (RAIDxpert2 in UEFI HII) to monitor and manage the RAID volumes.
- Use the `rcadm --manage --query-all` or `rcadm -M -qa` command to monitor the physical disk status and virtual disk (VD) status.
- When the RAID is in **Critical** state, the dmesg log records an event such as "**Array X has gone critical**".

## Restore (Rebuild) arrays

With the Restore task, a redundant-type array whose state has changed to **Critical** can be restored (rebuilt) in one of the following two ways:

- by assigning a dedicated spare to the array
- by creating a global spare or using an existing global spare (An existing global spare automatically starts restoring a redundant-type array after the state of the array changes to **Critical**.)

When a single disk in a non-redundant array fails, the array state changes to **Offline**. An array in an **Offline** state cannot be restored. This means that non-redundant arrays (Volume, RAID0) cannot be restored.

**Note:** If a **Critical** redundant array that is being restored loses a second disk (RAID1), or loses a second disk in the same mirror set (RAID10), the Restore task fails. The array must be re-created from backup storage data.

Users can assign a hot spare using RAIDxpert2 GUI utility, AMD SWR HII (RAIDxpert2 in UEFI HII), or the `rcadm` command.

### Assigning a hot spare using RAIDxpert2 GUI utility

1. In the **Array View** section, select the **Critical** array.
2. At the **Disk List** section, double-click on a disk.
3. At the **Disk** menu, select **Options**. Options for **Disk Device** displays in the **Disk List** panel.
4. Perform one of the following actions:
  - To use the disk as a dedicated spare, select **Assign as Dedicated Spare**.
  - To use the disk as a global spare, select **Assign as Global Spare**.
5. Click **Confirm**.

### Adding a hot spare using AMD SWR HII (RAIDxpert2 in UEFI HII)

To assign global spares, do as follows:

1. From the main menu of RaidXpert2 Configuration Utility, use the arrow keys to select **Physical Disk Management**, and then press **Enter**.
2. Select **Physical Disk Operations** using the arrow keys, and then press **Enter**.
3. Select **Select Physical Disk** using the arrow keys, and then press **Enter**.
4. Select **Assign Global Hot Spare** using the arrow keys, and then press **Enter**.
5. Review the warning message. If you want to proceed, use the arrow keys to select **Yes**, or press **ESC** or **No**, to exit.

To assign dedicated spares, do as follows:

**Note:** Dedicated spares can only be assigned to redundant arrays and must be the same size or larger than the other members of the redundant array.

1. From the main menu of RaidXpert2 Configuration Utility, use the arrow keys to select **Array Management**, and then press **Enter**.
2. Select **Manage Array Properties** using the arrow keys, and then press **Enter**.
3. Select **Select Array** using the arrow keys, select the desired array (must be a redundant array) from the drop-down menu, and then press **Enter**.
4. Select **Manage Dedicated Hot Spares** using the arrow keys, and then press **Enter**.
5. Select the disks to assign as dedicated spares.
  - a. Select the disk using the arrow keys to highlight the disk and press the space bar or **Enter** to select it.
  - b. Select **Add Hot Spare Physical Disk** using the arrow keys, and then press **Enter**.
  - c. At the warning message, press the space bar or **Enter** to confirm.
  - d. Select **Yes** using the arrow keys, and then press **Enter** or **ESC** to exit adding the dedicated spare.

### Using the `rcadm` command to assign a hot spare

For example, use the following command to add disk 1 as a global hot spare:

```
rcadm --manage --add-global-spare --disk 1
```

**Note:** Use the `rcadm -?` or `rcadm --help` command to find more usage about the `rcadm` command line tool.

---

## Deploy the operating system

### Tool-based deployment

- **Single-server**

- Lenovo XClarity Provisioning Manager Lite

[https://pubs.lenovo.com/lxpm-lite/os\\_installation](https://pubs.lenovo.com/lxpm-lite/os_installation)

**Note:** LXPM Lite does not support OS installation when the onboard RAID mode is enabled for the system.

### Manual deployment

If you cannot access the above tools, follow the instructions below, download the corresponding OS *Installation Guide*, and deploy the operating system manually by referring to the guide.

1. Go to <https://datacentersupport.lenovo.com/solutions/server-os>.
2. Select an operating system from the navigation pane and click **Resources**.
3. Locate the “OS Install Guides” area and click the installation instructions. Then, follow the instructions to complete the operation system deployment task.

---

## Back up the server configuration

After setting up the server or making changes to the configuration, it is a good practice to make a complete backup of the server configuration.

Use your backup methods to back up the operating system and user data for the server.



---

## Chapter 8. Problem determination

Use the information in this chapter to isolate and resolve issues that you might encounter while using your server.

---

### Event logs

Logs of system events are available in Setup Utility.

Setup Utility provides the list of system event logs that are available in the **Event Logs** tab. Start the server and press **F1** to access Setup Utility, and go to **Event Logs → View Smbios Event Log** to access the list of events.

Following is the list of events that might appear in the system event log.

Table 17. List of events in Setup Utility

| Error code | Event                | Description                                                                                                                                                                                                                                                                                                                                                                          |
|------------|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 03008000   | Memory size changed  | This event is reported when the system detects that the current memory capacity is different from the memory capacity at the previous startup. <ul style="list-style-type: none"><li>This event is for information only if the user has changed memory capacity support.</li><li>In other cases, follow <a href="#">“Memory problems” on page 188</a> for troubleshooting.</li></ul> |
| 03008001   | Password retry count | This event is for information only.                                                                                                                                                                                                                                                                                                                                                  |
| 03008002   | CPU Fan fail         | Complete the following steps for troubleshooting: <ol style="list-style-type: none"><li>Make sure the fan cable is connected to the correct connector, and the connector is plugged in firmly.</li><li>If the problem persists, replace the fan. See <a href="#">“Fan replacement” on page 90</a>.</li></ol>                                                                         |
| 03008003   | Rear Fan fail        |                                                                                                                                                                                                                                                                                                                                                                                      |
| 03008004   | Front Fan fail       |                                                                                                                                                                                                                                                                                                                                                                                      |
| 0005100B   | Unqualified DIMM 1   | Change the unqualified DIMM to a Lenovo qualified one.                                                                                                                                                                                                                                                                                                                               |
| 0005100C   | Unqualified DIMM 2   |                                                                                                                                                                                                                                                                                                                                                                                      |

---

### Troubleshooting by LEDs

See the following sections for information on available LEDs.

#### System-board LED

The following illustration shows the LED on the system board.




Figure 139. System-board LED

Table 18. System-board-LED

| LED                                 | Description                                                                                                                                                                    |
|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Drive activity LED (white) | This LED indicates the activity of the drives. <ul style="list-style-type: none"> <li>• Blinking: The drives are active.</li> <li>• Off: The drives are not active.</li> </ul> |

## Ethernet port (10/100/1000 Mbps RJ-45) LEDs

This topic provides information on LEDs of Ethernet port (10/100/1000 Mbps RJ-45).




Figure 140. Ethernet port (10/100/1000 Mbps RJ-45) LEDs

| LED                   | Description                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Link LED     | Use this LED to distinguish the network connectivity status: <ul style="list-style-type: none"> <li>• Off: The network link is disconnected, or the network link is established at the speed of 10 Mbps.</li> <li>• Green: The network link is established at the speed of 100 Mbps.</li> <li>• Orange: The network link is established at the speed of 1000 Mbps.</li> </ul> |
| <b>2</b> Activity LED | Use this LED to distinguish the network activity status: <ul style="list-style-type: none"> <li>• Off: No data is being transmitted.</li> <li>• Blinking: Data is being transmitted.</li> </ul>                                                                                                                                                                               |

---

## General problem determination procedures

Use the information in this section to resolve problems if the event log does not contain specific errors or the server is inoperative.

If you are not sure about the cause of a problem and the power supply is working correctly, complete the following steps to try to resolve the problem:

1. Check in Setup Utility and make sure all the installed components are enabled.
2. Make sure the firmware of the installed components is the latest version.
3. Turn off the server.
4. Ensure that the server is cabled correctly.
5. Remove or disconnect the following devices if applicable, one at a time, until you find the failure. Turn on and configure the server each time you remove or disconnect a device.
  - Any external devices
  - Surge-suppressor device (on the server)
  - Printer, mouse, and non-Lenovo devices
  - Each adapter
  - Storage drives
  - One memory module at a time until you reach the minimum configuration that is supported for the server

**Notes:** The minimum configuration required for the server is as the following:

- One processor and one processor cooling heat sink
  - One 16 GB ECC UDIMM in DIMM slot 1
  - One power supply
  - One power cord
  - One 3.5-inch SATA drive in drive bay 0
  - One system front fan (if debugging is out of chassis)
6. Turn on the server.

If the problem is solved after an adapter is removed from the server, but recurs after it is reinstalled, suspect the adapter. If the problem recurs when the adapter is replaced with a different one, try the original adapter in a different PCIe slot.

If the problem appears to be a networking one while the server passes all system diagnostics, suspect a network cabling problem that is external to the server.

## Resolving suspected power problems

Power problems can be difficult to solve. For example, a short circuit can exist anywhere on any of the power distribution buses. Usually, a short circuit will cause the power subsystem to shut down because of an overcurrent condition.

Complete the following steps to diagnose and resolve a suspected power problem.

Step 1. Check for short circuits, for example, if a loose screw causes short circuit on a circuit board.

Step 2. Remove the adapters and disconnect the cables and power cords to all internal and external devices until the server is at the minimum configuration that is required for the server to start. The minimum configuration required for the server is as the following:

- One processor and one processor cooling heat sink

- One 16 GB ECC UDIMM in DIMM slot 1
- One power supply
- One power cord
- One 3.5-inch SATA drive in drive bay 0
- One system front fan (if debugging is out of chassis)

Step 3. Reconnect all AC power cords and turn on the server. If the server starts successfully, reseal the adapters and devices one at a time until the problem is isolated.

If the server does not start from the minimum configuration, replace the components in the minimum configuration one at a time until the problem is isolated.

## Resolving suspected Ethernet controller problems

The method that you use to test the Ethernet controller depends on which operating system you are using. See the operating-system documentation for information about Ethernet controllers, and see the Ethernet controller device-driver readme file.

Complete the following steps to try to resolve suspected problems with the Ethernet controller.

Step 1. Make sure that the correct device drivers, which come with the server, are installed, and that they are at the latest level.

Step 2. Make sure that the Ethernet cable is installed correctly.

- The cable must be securely attached at all connections. If the cable is attached but the problem remains, try a different cable.
- If you set the Ethernet controller to operate at 100 Mbps or 1000 Mbps, you must use Category 5 cabling.

Step 3. Determine whether the hub supports auto-negotiation. If it does not, try configuring the integrated Ethernet controller manually to match the speed and duplex mode of the hub.

Step 4. Check the Ethernet port LEDs on the rear panel of the server. These LEDs indicate whether there is a problem with the connector, cable, or hub.

- The link LED is lit when the Ethernet controller receives a link pulse from the hub. If the LED is off, there might be a defective connector or cable or a problem with the hub.
- The activity LED is lit when the Ethernet controller sends or receives data over the Ethernet network. If the activity LED is off, make sure that the hub and network are operating and that the correct device drivers are installed.

Step 5. Check for operating-system-specific causes of the problem, and also make sure that the operating system drivers are installed correctly.

Step 6. Make sure that the device drivers on the client and server are using the same protocol.

If the Ethernet controller still cannot connect to the network but the hardware appears to be working, the network administrator must investigate other possible causes of the error.

---

## Troubleshooting by symptom

Use this information to find solutions to problems that have identifiable symptoms.

To use the symptom-based troubleshooting information in this section, complete the following steps:

1. Review this section to find the symptoms that you are experiencing, and follow the suggested actions to resolve the issue.
2. If the problem persists, contact support (see [“Contacting Support” on page 206](#)).

## Audio problems

The audio function is only supported on Windows Client OSs. Follow this procedure to disable the audio function on Server OSs.

1. Turn on the server.
2. Before the operating system starts up, press **F1** to enter the Setup Utility.
3. Select **Devices → Audio Setup → Onboard Audio Controller → Disabled**.

## Intermittent problems

Follow this procedure to solve intermittent problems.

- [“Intermittent external device problems” on page 187](#)
- [“Intermittent unexpected reboots” on page 187](#)

### Intermittent external device problems

Complete the following steps until the problem is solved.

1. Update the UEFI firmware to the latest versions.
2. Check the system event log and resolve any related problems. To view the system event log, go to **Setup Utility** and select **Event Logs → View Smbios Event Log**.
3. Make sure that:
  - The latest version of corresponding driver is installed.
  - The device is seated correctly without physical damage on the device or connector.
  - Device firmware has been updated to the latest version.
  - You followed the installation instructions that came with the device, and the device is installed properly.
  - You have not loosened any other installed devices or cables.
4. For a USB device:
  - a. Make sure that the device is properly configured and enabled in Setup Utility.
  - b. Connect the device to another USB port.
  - c. If the device is connected to a USB hub, remove the device from the hub, and connect it directly to the server.

### Intermittent unexpected reboots

Complete the following steps until the problem is solved.

1. Check the system event log and resolve any related problems. To view the system event log, go to **Setup Utility** and select **Event Logs → View Smbios Event Log**.
2. If the reboot occurs after the operating system starts, disable any automatic server restart (ASR) utilities or any ASR devices that are installed.
3. Look into the event logs for an event code that indicates a reboot. See [“Event logs” on page 183](#) for information about viewing the event log.

## Keyboard, mouse, KVM switch or USB-device problems

Use this information to solve problems related to a keyboard, mouse, KVM switch or USB device.

- [“All or some keys on the keyboard do not work” on page 188](#)
- [“Mouse does not work” on page 188](#)

- [“KVM switch problems” on page 188](#)
- [“USB device does not work” on page 188](#)

### **All or some keys on the keyboard do not work**

1. Make sure that:
  - The keyboard cable is securely connected.
  - The server and the monitor are turned on.
2. If you are using a USB keyboard and it is connected to a USB hub, disconnect the keyboard from the hub and connect it directly to the server.
3. Replace the keyboard.

### **Mouse does not work**

1. Make sure that:
  - The mouse cable is securely connected to the server.
  - The mouse device drivers are installed correctly.
  - The server and the monitor are turned on.
2. If you are using a USB mouse and it is connected to a USB hub, disconnect the mouse from the hub and connect it directly to the server.
3. Replace the mouse.

### **KVM switch problems**

1. Make sure that the KVM switch is supported by your server.
2. Make sure that the KVM switch is powered on correctly.
3. If the keyboard, mouse or monitor can be operated normally with direct connection to the server, then replace the KVM switch.

### **USB device does not work**

1. Make sure that:
  - The correct USB device driver is installed.
  - The operating system supports USB devices.
2. Make sure that the USB setup options are set correctly in system setup.

Restart the server and press the key according to the on-screen instructions to go to Setup Utility. Then, click **Devices → USB Setup**.

3. If you are using a USB hub, disconnect the USB device from the hub and connect it directly to the server.
4. Replace the USB device.

## **Memory problems**

Follow this procedure to resolve issues related to memory.

- [“Displayed system memory less than installed physical memory” on page 188](#)

### **Displayed system memory less than installed physical memory**

**Note:** Each time you install or remove a DIMM, you must disconnect the server from the power source; then, wait 10 seconds before restarting the server.

Complete the following steps until the problem is solved.


1. Check the system event log and resolve any related problems. To view the system event log, go to **Setup Utility** and select **Event Logs → View Smbios Event Log**.
2. Make sure that:
  - The DIMMs are supported by the server (see <https://serverproven.lenovo.com>).
  - The DIMMs are properly installed. Examine if there is any gap between the connector and the DIMM. Remove and install the DIMM if there is any.
3. If the server comes with Lenovo XClarity Provisioning Manager Lite, go to **Diagnostics → Memory test** to perform diagnostics on the DIMMs. Replace the DIMM that is displayed as faulty. Otherwise, skip to the next step.
4. Remove the DIMMs until the system reaches minimal memory requirement; then, add one DIMM and reboot the server, and repeat the step if the problem does not recur. If the problem occurs after addition of a DIMM, replace it.

See “[Technical specifications](#)” on [page 3](#) for the minimal configuration for debugging.


## Microsoft Server 2022 activation problem

Use this information to activate Windows Server 2022.


1. Power on the system to enter Windows Server 2022. Then, right-click on the **Start** button and select **Settings** from the menu.
2. Select **Update & Security → Activation → Change product key**.



3. Enter the product key and click **Next**.




**Note:** The product key is available on the Certificate of Authenticity (COA) label **1**.




## Microsoft Server 2025 activation problem

Use this information to activate Windows Server 2025.


1. Power on the system to enter Windows Server 2025. Then, right-click on the **Start** button and select **Settings** from the menu.
2. Select **System** → **Activation**, and click the **Change** button next to **Change product key**.



3. Enter the product key and click **Next**.



**Note:** The product key is available on the Certificate of Authenticity (COA) label **1**.



## Monitor and video problems

Use this information to solve problems related to a monitor or video.

- [“Incorrect characters are displayed” on page 192](#)
- [“Screen is blank” on page 192](#)
- [“Screen goes blank when you start some application programs” on page 193](#)
- [“The monitor has screen jitter, or the screen image is wavy, unreadable, rolling, or distorted” on page 193](#)
- [“The wrong characters appear on the screen” on page 193](#)

### Incorrect characters are displayed

Complete the following steps until the problem is solved.

1. Verify that the language and locality settings are correct for the keyboard and operating system.
2. If the wrong language is displayed, update the server firmware to the latest level. See [“Update the firmware” on page 175](#).

### Screen is blank

Complete the following steps until the problem is solved.

1. If you have installed new DIMMs recently, make sure the capacity of the new DIMMs is the same as the previously installed ones. If not, remove the newly installed DIMMs, and power on the server again.
2. If there are other monitors that are connected to the server, remove them.
3. If the server is attached to a KVM switch, bypass the KVM switch to eliminate it as a possible cause of the problem: connect the monitor cable directly to the correct connector on the rear of the server.

4. Make sure that:
  - The server is turned on and there is power supplied to the server.
  - The monitor cables are securely connected.
  - The monitor is turned on with brightness and contrast controls adjusted correctly.
5. Disconnect the cable and select another video connector for connection.
6. Replace the following components one at a time, in the order shown, restarting the server each time:
  - a. Monitor cable
  - b. Monitor
  - c. (Trained technician only) System board
7. If the problem remains, contact Lenovo Support.

### **Screen goes blank when you start some application programs**

1. Make sure that:
  - The application program is not setting a display mode with resolution that is higher than the capability of the monitor.
  - The necessary device drivers for the application are all installed.

### **The monitor has screen jitter, or the screen image is wavy, unreadable, rolling, or distorted**

Complete the following steps until the problem is solved.

1. If the monitor self-tests show that the monitor is working correctly, examine the location of the monitor. Magnetic fields around other devices (such as transformers, appliances, fluorescents, and other monitors) can cause screen jitter or wavy, unreadable, rolling, or distorted screen images. If this happens, turn off the monitor.

**Attention:** Moving a color monitor while it is turned on might cause screen discoloration.

Move the device and the monitor at least 305 mm (12 inches) apart, and turn on the monitor.

#### **Notes:**

- a. To prevent diskette drive read/write errors, make sure that the distance between the monitor and any external diskette drive is at least 76 mm (3 inches).
  - b. Non-Lenovo monitor cables might cause unpredictable problems.
2. Reseat the monitor cable.
  3. Replace the following components one at a time, in the order shown, restarting the server each time:
    - a. Monitor cable
    - b. Monitor
    - c. Video adapter (if one is installed)
    - d. (Trained technician only) System board

### **The wrong characters appear on the screen**

Complete the following steps until the problem is solved.

1. Verify that the language and locality settings are correct for the keyboard and operating system.
2. If the wrong language is displayed, update the server firmware to the latest level. See [“Update the firmware” on page 175](#).

## Network problems

Use this information to resolve issues related to networking.

- [“Cannot wake server using Wake on LAN” on page 194](#)
- [“Could not log in using LDAP account with SSL enabled” on page 194](#)

### Cannot wake server using Wake on LAN

Complete the following steps until the problem is resolved:

1. Go to **Setup Utility** and select **Power → Automatic Power On → Wake on LAN**. Make sure **Wake on LAN** is set to **Enabled**.
2. Remove and reinstall the network adapter.
3. Turn off the server and disconnect it from the power source; then, wait 10 seconds before restarting the server.
4. If the problem recurs, replace the network adapter.

### Could not log in using LDAP account with SSL enabled

Complete the following steps until the problem is resolved:

1. Make sure that the license key is valid.
2. Generate a new license key and log in again.

## Observable problems

Follow this procedure to solve observable problems.

- [“Server is unresponsive \(POST is complete and operating system is running\)” on page 194](#)
- [“Server is unresponsive \(cannot press F1 to start Setup Utility\)” on page 195](#)
- [“Unusual smell” on page 195](#)
- [“Server seems to be running hot” on page 195](#)
- [“Cracked parts or cracked chassis” on page 195](#)

### Server is unresponsive (POST is complete and operating system is running)

Complete the following steps until the problem is solved.

- If you have direct access to the server, complete the following steps:
  1. If possible, log in to the system and verify that all applications are running without hanging.
  2. Restart the server.
  3. If the problem recurs, make sure that every newly installed software is configured correctly.
  4. Contact the vendor or provider of the software for technical support.
- If you have remote access to the server, complete the following steps:
  1. If possible, log in to the system and verify that all applications are running without hanging.
  2. Log out of the system and log back in.
  3. Validate the network access by pinging or running traceroute to the server with a command line.
    - a. If you are unable to get a response during a ping test, try to ping another server in the same server room to determine whether the problem is caused by failed connection of the server.
    - b. Run traceroute to determine where the connection breaks down, and try to resolve the connection issue with VPN or avoiding where the connection breaks down.

4. Restart the server remotely.
5. If the problem recurs, make sure that every installed software is configured correctly.
6. Contact the vendor or provider of the software for technical support.

### **Server is unresponsive (cannot press F1 to start Setup Utility)**

Complete the following steps until the problem is solved.

**Note:** Any configuration changes, such as system firmware update, device and corresponding driver installation, could cause failed POST.

If this occurs, the server responds in either of the following ways:

- The system restarts automatically and produces POST again.
- The server hangs, and you must manually reboot the system so that the system produces POST again.

### **Unusual smell**

Complete the following steps until the problem is solved.

1. Any unusual smell might come from newly installed devices. Examine the devices to identify the source of the smell, and remove the one that produces it.
2. If the problem recurs, contact Lenovo Support.

### **Server seems to be running hot**

Complete the following steps until the problem is solved.

1. Make sure that the room temperature is within the specified range (see [“Environmental specifications” on page 6](#)).
2. Check the system event log and resolve any related problems. To view the system event log, go to **Setup Utility** and select **Event Logs → View Smbios Event Log**.
3. If there are no related events in the log, contact Lenovo Support.

### **Cracked parts or cracked chassis**

Contact Lenovo Support.

## **Optional-device problems**

Use this information to solve problems related to optional devices.

- [“PCIe adapter is not recognized or is not functioning” on page 196](#)
- [“A Lenovo optional device that worked previously does not work now” on page 196](#)
- [“A Lenovo optional device that was just installed does not work” on page 196](#)
- [“A Lenovo optional device that worked previously does not work now” on page 196](#)

### **External USB device is not recognized**

Complete the following steps until the problem is solved.

1. Update the UEFI firmware to the latest version.
2. Make sure that the proper drivers are installed on the server. See the product documentation for the USB device for information about device drivers.
3. Use Setup Utility to make sure that the device is configured correctly.
4. If the USB device is plugged into a hub or the console breakout cable, unplug the device and plug it directly into the USB port on the front of the server.

### **PCIe adapter is not recognized or is not functioning**

Complete the following steps until the problem is solved.

1. Make sure that:
  - The device is supported by the server (see <https://serverproven.lenovo.com>).
  - The latest version of corresponding driver is installed.
  - The device is seated correctly without physical damage on the device or connector.
  - System firmware has been updated to the latest version.
2. Remove the device and install it to another PCIe slot if possible.
3. Check <http://datacentersupport.lenovo.com> for any tech tips (also known as retain tips or service bulletins) that might be related to the adapter.

### **Insufficient PCIe resources are detected**

Complete the following steps until the problem is solved.

1. Remove any devices that were installed recently, and restart the server. If none was recently installed, remove one of the PCIe adapters.
2. Go to **Setup Utility** and select **Devices → PCI Express Configuration**; then, modify the setting to a lower speed. For example, modify the speed of PCIe x16 slot from Auto or Gen4 to Gen3, Gen2, or Gen1.
3. Save the settings and restart the server.
4. Depending on whether or not the restart is successful:
  - If it is successful, shut down the server and reinstall the removed PCIe adapters one at a time, and restart the server again after each addition.
  - If it fails, remove another PCIe adapter and restart the server again.

### **A Lenovo optional device that was just installed does not work**

Complete the following steps until the problem is solved.

1. Check the system event log and resolve any related problems. To view the system event log, go to **Setup Utility** and select **Event Logs → View Smbios Event Log**.
2. Make sure that:
  - The device is supported by the server (see <https://serverproven.lenovo.com>).
  - The latest version of corresponding driver is installed.
  - The device is seated correctly without physical damage on the device or connector.
  - System firmware has been updated to the latest version.
  - You followed the installation instructions that came with the device, and the device is installed properly.
  - You have not loosened any other installed devices or cables.
3. Reseat the device.
4. Replace the device.

### **A Lenovo optional device that worked previously does not work now**

Complete the following steps until the problem is solved.

1. Check the system event log and resolve any related problems. To view the system event log, go to **Setup Utility** and select **Event Logs → View Smbios Event Log**.
2. Make sure that all of the cables are securely connected.
3. If the device comes with test instructions, use those instructions to test the device.
4. Reseat the failing device.
5. Replace the failing device.

## Performance problems

Use this information to solve performance problems.

- [“Network performance” on page 197](#)
- [“Operating system performance” on page 197](#)

### Network performance

Complete the following steps until the problem is solved:

1. Isolate which network is operating slowly (such as storage, data, and management). You might find it helpful to use ping tools or operating-system tools such as task manager or resource manager.
2. Check for traffic congestion on the network.
3. Update the NIC device driver, or the storage device controller device driver.
4. Use the traffic-diagnostic tools that are provided by the IO-module manufacturer.

### Operating system performance

Complete the following steps until the problem is solved:

1. If you have recently made changes to the server (for example, updated device drivers or installed software applications), remove the changes.
2. Check for any networking issues.
3. Check the operating system logs for performance related errors.
4. Check for events related to high temperatures and power issues as the server might be throttled to help with cooling. If it is throttled, reduce the workload on the server to help improve performance.
5. Check for events related to disabled DIMMs. If you do not have enough memory for the application workload, your operating system will have poor performance.
6. Ensure that the workload is not too high for the configuration.

## Power on and power off problems

Use this information to resolve issues when powering on or powering off the server.

- [“Server does not power on” on page 197](#)
- [“Server powers off unexpectedly” on page 198](#)
- [“Server does not power off” on page 198](#)

### Server does not power on

Complete the following steps until the problem is solved.

**Note:** The power button will not function until approximately one to three minutes after the server is connected to ac power.

1. Remove any optional devices that were installed recently. System power problems caused by addition of a device indicates this device is either incompatible or too much for the power supply to support.
2. Make sure the power cord is securely connected to the server and to a working electrical outlet. Disconnect and reconnect or replace the server power cord.
3. Reseat the power supply. If the problem persists, replace the power supply.
4. Disconnect and reconnect the front panel cable (see [“System-board connectors” on page 17](#) for the location of the connector on the system board). If the problem persists, replace the front panel.

### Server powers off unexpectedly

Complete the following steps until the problem is solved.

1. Make sure the room temperature does not cause overheating, and no object is blocking the airflow in front and back of the server.
2. Remove any optional devices that were installed recently. System power problems caused by addition of a device indicates this device is either incompatible or too much for the power supply to support.
3. Make sure the power cord is securely connected to the server and to a working electrical outlet. Disconnect and reconnect or replace the server power cord.
4. Reseat the power supply. If the problem persists, replace the power supply.

### Server does not power off

Complete the following steps until the problem is solved.

1. Press **Ctrl+Alt+Delete**.
2. Turn off the server by pressing and holding the power button for five seconds.
3. Power on the server.
4. If the server fails POST and the power button does not work, disconnect the power cord for 20 seconds; then, reconnect the power cord and power on the server.
5. If the problem persists, contact Lenovo support.

## Software problems

Use this information to solve software problems.

1. To determine whether the problem is caused by the software, make sure that:
  - The server has the minimum memory that is needed to use the software. For memory requirements, see the information that comes with the software.

**Note:** If you have just installed an adapter or memory, the server might have a memory-address conflict.

- The software is designed to operate on the server.
  - Other software works on the server.
  - The software works on another server.
2. If you receive any error messages while you use the software, see the information that comes with the software for a description of the messages and suggested solutions to the problem.
  3. Contact your place of purchase of the software.

## Storage drive problems

Use this information to resolve issues related to the storage drives.

- [“Server cannot recognize a drive” on page 198](#)
- [“Multiple drives fail” on page 199](#)
- [“A replacement drive does not rebuild” on page 199](#)
- [“Suspected RAID volume failure” on page 199](#)

### Server cannot recognize a drive

Complete the following steps until the problem is solved.

1. Make sure that:

- The drive is supported by the server (see <https://serverproven.lenovo.com>).
  - The drive is properly installed with signal and power cables properly connected.
2. Make sure the drive is enabled. Go to **Setup Utility** and select **Devices → ATA Drive Setup** to see if the drive in question is enabled. If not, enable it.
  3. If the server comes with Lenovo XClarity Provisioning Manager Lite, go to **Diagnostics → HDD test** to perform diagnostics on the drives. Replace the drive that is displayed as faulty. Otherwise, skip to the next step.
  4. Remove the drives until the system reaches minimal drive requirement; then, add one drive and restart the server, and repeat the step if the problem does not recur. If the problem occurs after addition of a drive, replace it.

See “[Technical specifications](#)” on page 3 for the minimal configuration for debugging.

### Multiple drives fail

Complete the following steps until the problem is solved:

1. If the server comes with Lenovo XClarity Provisioning Manager Lite, go to **Diagnostics → HDD test** to perform diagnostics on the drives. Replace the drive that is displayed as faulty. Otherwise, skip to the next step.
2. Remove the drives until the system reaches minimal drive requirement; then, add one drive and reboot the server, and repeat the step if the problem does not recur. If the problem occurs after addition of a drive, replace it.

See “[Technical specifications](#)” on page 3 for the minimal configuration for debugging.

### A replacement drive does not rebuild

Complete the following steps until the problem is solved:

1. If the server comes with Lenovo XClarity Provisioning Manager Lite, go to **Diagnostics → RAID Log**. Look for related errors and solve them. Otherwise, skip to the next step.
2. Review the document that came with the RAID adapter to make sure RAID is set properly.

### Suspected RAID volume failure

Reboot the system, press **F1** to go to **Setup Utility**, and select **Advanced → x350-8i → Array Configuration → Manage Arrays → Array X → List Logical Drives → Logical Drive X (Logical Drive X) → Logical Drive Details** to check failure symptoms.

### UEFI upgrade problem

In Linux operating systems, if the message "0x10 Error: Unable to load driver" is displayed during UEFI upgrade and **Secure Boot** is enabled, complete the following steps to upgrade UEFI.

1. Go to <https://www.ami.com/bios-uefi-utilities/#aptiov>.
2. Download “APTIO V AMI FIRMWARE UPDATE UTILITY” and unzip the file.
3. Refer to “Chapter 6 Signing Driver and Enrolling Public Key to the System” in *AMI\_Aptio\_5.x\_AFU\_User\_Guide\_NDA.pdf* for details.

**Note:** The PDF file is included in “APTIO V AMI FIRMWARE UPDATE UTILITY”.



---

## Appendix A. Hardware disassembling for recycle

Follow the instructions in this section to recycle components with compliance with local laws or regulations.

---

### Disassemble the system board for recycle

Follow the instructions in this section to disassemble the system board before recycling.


#### About this task

##### Attention:

- Read [“Installation Guidelines” on page 29](#) and [“Safety inspection checklist” on page 30](#) to ensure that you work safely.
- Power off the server and peripheral devices and disconnect the power cords and all external cables. See [“Power off the server” on page 34](#).
- If the server is in a rack, remove it from the rack. See [“Remove the server from rack” on page 34](#).
- Remove any locking device that secures the server, such as a Kensington lock or a padlock.
- Place the server on its side with the cover up.

#### Procedure

- Step 1. Remove the server cover. See [“Remove the server cover” on page 146](#).
- Step 2. Remove the front bezel. See [“Remove the front bezel” on page 95](#).
- Step 3. If applicable, remove the ODD+bay 2 drive cage assembly (see [“Remove an optical drive cage” on page 85](#)) or remove the bay 2+bay 3 drive cage assembly (see [“Remove the drive cage \(bay 3\)” on page 74](#)).
- Step 4. Remove the cage bar. See step 3 in [“Remove the server cover” on page 146](#).
- Step 5. Remove all the system fans. See [“Remove the fan \(front and rear\)” on page 90](#).
- Step 6. If applicable, remove the M.2 drive. See [“Remove an M.2 drive” on page 101](#).
- Step 7. If applicable, remove the PCIe adapters. See [“Remove a PCIe adapter” on page 116](#).
- Step 8. Remove the memory modules. See [“Remove a memory module” on page 108](#).
- Step 9. Remove the heat sink and fan module. See [“Remove the heat sink and fan module \(trained technician only\)” on page 97](#).
- Step 10. Remove the processor. See [“Remove the processor \(trained technician only\)” on page 133](#).
- Step 11. Remove the screw that secures the front I/O bracket to the chassis.



*Figure 141. Removing the screw that secures the front I/O bracket*

Step 12. Remove the front I/O bracket.

- a. ① Rotate the left end of the front I/O bracket away from the chassis.
- b. ② Remove the front I/O bracket from the chassis.




Figure 142. Removing the front I/O bracket from the chassis

Step 13. Disconnect all the cables connected to the system board.

**Attention:** To avoid damaging the system board, make sure to follow the instructions in [Chapter 6](#) “Internal cable routing” on page 157 when disconnecting cables from the system board.

Step 14. Remove the nine screws that secure the system board in the sequence shown in the illustration below. Keep the screws for future use.




Figure 143. System-board screws removal sequence

Step 15. Remove the system board from the chassis.

- a. ① Slide the system board toward the front of the server to release the serial port connector from the chassis.
- b. ② Gently grasp the system board by the edges; then, tilt the system board, and remove it from the chassis.




Figure 144. Removing the system board from the chassis

## After you finish

After disassembling the server, recycle the unit in compliance with local regulations.

---

## Appendix B. Getting help and technical assistance

If you need help, service, or technical assistance or just want more information about Lenovo products, you will find a wide variety of sources available from Lenovo to assist you.

On the World Wide Web, up-to-date information about Lenovo systems, optional devices, services, and support are available at:

<http://datacentersupport.lenovo.com>

**Note:** IBM is Lenovo's preferred service provider for ThinkSystem.

---

### Before you call

Before you call, there are several steps that you can take to try and solve the problem yourself. If you decide that you do need to call for assistance, gather the information that will be needed by the service technician to more quickly resolve your problem.

#### Attempt to resolve the problem yourself

You can solve many problems without outside assistance by following the troubleshooting procedures that Lenovo provides in the online help or in the Lenovo product documentation. The online help also describes the diagnostic tests that you can perform. The documentation for most systems, operating systems, and programs contains troubleshooting procedures and explanations of error messages and error codes. If you suspect a software problem, see the documentation for the operating system or program.

You can find the product documentation for your ThinkSystem products at the following location:

<https://pubs.lenovo.com/>

You can take these steps to try to solve the problem yourself:

- Check all cables to make sure that they are connected.
- Check the power switches to make sure that the system and any optional devices are turned on.
- Check for updated software, firmware, and operating-system device drivers for your Lenovo product. (See the following links) The Lenovo Warranty terms and conditions state that you, the owner of the Lenovo product, are responsible for maintaining and updating all software and firmware for the product (unless it is covered by an additional maintenance contract). Your service technician will request that you upgrade your software and firmware if the problem has a documented solution within a software upgrade.
  - Drivers and software downloads
    - <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3/downloads/driver-list/>
  - Operating system support center
    - <https://datacentersupport.lenovo.com/solutions/server-os>
  - Operating system installing instructions
    - <https://pubs.lenovo.com/thinksystem#os-installation>
- If you have installed new hardware or software in your environment, check <https://serverproven.lenovo.com> to make sure that the hardware and software are supported by your product.
- Refer to [Chapter 8 “Problem determination” on page 183](#) for instructions on isolating and solving issues.
- Go to <http://datacentersupport.lenovo.com> and check for information to help you solve the problem.

To find the Tech Tips available for your server:

1. Go to <http://datacentersupport.lenovo.com> and navigate to the support page for your server.
2. Click on **How To's** from the navigation pane.
3. Click **Article Type → Solution** from the drop-down menu.

Follow the on-screen instructions to choose the category for the problem that you are having.

- Check Lenovo Data Center Forum at [https://forums.lenovo.com/t5/Datacenter-Systems/ct-p/sv\\_eg](https://forums.lenovo.com/t5/Datacenter-Systems/ct-p/sv_eg) to see if someone else has encountered a similar problem.

### Gathering information needed to call Support

If you require warranty service for your Lenovo product, the service technicians will be able to assist you more efficiently if you prepare the appropriate information before you call. You can also go to <http://datacentersupport.lenovo.com/warrantylookup> for more information about your product warranty.

Gather the following information to provide to the service technician. This data will help the service technician quickly provide a solution to your problem and ensure that you receive the level of service for which you might have contracted.

- Hardware and Software Maintenance agreement contract numbers, if applicable
- Machine type number (Lenovo 4-digit machine identifier). Machine type number can be found on the ID label, see “Identify the server” on page 23.
- Model number
- Serial number
- Current system UEFI and firmware levels
- Other pertinent information such as error messages and logs

As an alternative to calling Lenovo Support, you can go to <https://support.lenovo.com/servicerequest> to submit an Electronic Service Request. Submitting an Electronic Service Request will start the process of determining a solution to your problem by making the pertinent information available to the service technicians. The Lenovo service technicians can start working on your solution as soon as you have completed and submitted an Electronic Service Request.

---

## Contacting Support

You can contact Support to obtain help for your issue.

You can receive hardware service through a Lenovo Authorized Service Provider. To locate a service provider authorized by Lenovo to provide warranty service, go to <https://datacentersupport.lenovo.com/serviceprovider> and use filter searching for different countries. For Lenovo support telephone numbers, see <https://datacentersupport.lenovo.com/supportphonenumberlist> for your region support details.

---

## Appendix C. Documents and supports

This section provides handy documents, driver and firmware downloads, and support resources.

---

### Documents download

This section provides introduction and download link for handy documents.

#### Documents

Download the following product documentations at:

[https://pubs.lenovo.com/st45-v3/pdf\\_files.html](https://pubs.lenovo.com/st45-v3/pdf_files.html)

- **User Guide**
    - **Rail Installation Guides**
      - Rail installation in a rack
    - Complete overview, system configuration, hardware components replacing, and troubleshooting.
- Selected chapters from *User Guide*:
- **System Configuration Guide** : Server overview, components identification, system LEDs and diagnostics display, product unboxing, setting up and configuring the server.
  - **Hardware Maintenance Guide** : Installing hardware components, cable routing, and troubleshooting.

---

### Support websites

This section provides driver and firmware downloads and support resources.

#### Support and downloads

- Drivers and Software download website for ThinkSystem ST45 V3
  - <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3/downloads/driver-list/>
- Lenovo Data Center Forum
  - [https://forums.lenovo.com/t5/Datacenter-Systems/ct-p/sv\\_eg](https://forums.lenovo.com/t5/Datacenter-Systems/ct-p/sv_eg)
- Lenovo Data Center Support for ThinkSystem ST45 V3
  - <https://datacentersupport.lenovo.com/products/servers/thinksystem/st45v3>
- Lenovo License Information Documents
  - <https://datacentersupport.lenovo.com/documents/Invo-eula>
- Lenovo Press website (Product Guides/Datasheets/White papers)
  - <https://lenovopress.lenovo.com/>
- Lenovo Privacy Statement
  - <https://www.lenovo.com/privacy>
- Lenovo Product Security Advisories
  - [https://datacentersupport.lenovo.com/product\\_security/home](https://datacentersupport.lenovo.com/product_security/home)
- Lenovo Product Warranty Plans

- <http://datacentersupport.lenovo.com/warrantylookup>
- Lenovo Server Operating Systems Support Center website
  - <https://datacentersupport.lenovo.com/solutions/server-os>
- Lenovo ServerProven website (Options compatibility lookup)
  - <https://serverproven.lenovo.com>
- Operating System Installation Instructions
  - <https://pubs.lenovo.com/thinksystem#os-installation>
- Submit an eTicket (service request)
  - <https://support.lenovo.com/servicerequest>
- Subscribe to Lenovo Data Center Group product notifications (Stay up to date on firmware updates)
  - <https://datacentersupport.lenovo.com/solutions/ht509500>

---

## Appendix D. Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area.

Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service.

Lenovo may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document is not an offer and does not provide a license under any patents or patent applications. You can send inquiries in writing to the following:

*Lenovo (United States), Inc.  
8001 Development Drive  
Morrisville, NC 27560  
U.S.A.  
Attention: Lenovo Director of Licensing*

LENOVO PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Lenovo may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary.

Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk.

Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

---

## Trademarks

LENOVO, THINKSYSTEM, Flex System, System x, NeXtScale System, xArchitecture, ThinkEdge, and Neptune are trademarks of Lenovo.

Intel and Intel Xeon are trademarks of Intel Corporation in the United States, other countries, or both.

Internet Explorer, Microsoft, and Windows are trademarks of the Microsoft group of companies.

Linux is a registered trademark of Linus Torvalds.

All other trademarks are the property of their respective owners. © 2018 Lenovo.

---

## Important notes

Processor speed indicates the internal clock speed of the processor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1 024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard-disk-drive bays with the largest currently supported drives that are available from Lenovo.

Maximum memory might require replacement of the standard memory with an optional memory module.

Each solid-state memory cell has an intrinsic, finite number of write cycles that the cell can incur. Therefore, a solid-state device has a maximum number of write cycles that it can be subjected to, expressed as total bytes written (TBW). A device that has exceeded this limit might fail to respond to system-generated commands or might be incapable of being written to. Lenovo is not responsible for replacement of a device that has exceeded its maximum guaranteed number of program/erase cycles, as documented in the Official Published Specifications for the device.

Lenovo makes no representations or warranties with respect to non-Lenovo products. Support (if any) for the non-Lenovo products is provided by the third party, not Lenovo.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

---

## Electronic emission notices

When you attach a monitor to the equipment, you must use the designated monitor cable and any interference suppression devices that are supplied with the monitor.

Additional electronic emissions notices are available at:

## Taiwan Region BSMI RoHS declaration

| 單元 Unit                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | 限用物質及其化學符號<br>Restricted substances and its chemical symbols |                  |                  |                                                      |                                              |                                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|------------------|------------------|------------------------------------------------------|----------------------------------------------|------------------------------------------------------|
|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 鉛Lead<br>(PB)                                                | 汞Mercury<br>(Hg) | 鎘Cadmium<br>(Cd) | 六價鉻<br>Hexavalent<br>chromium<br>(Cr <sup>6+</sup> ) | 多溴聯苯<br>Polybrominated<br>biphenyls<br>(PBB) | 多溴二苯醚<br>Polybrominated<br>diphenyl ethers<br>(PBDE) |
| 機架                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | ○                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 外部蓋板                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | ○                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 機械組零件                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 空氣傳動設備                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 冷卻組零件                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 內存模組                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 處理器模組                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 電纜組零件                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 電源供應器                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 儲備設備                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| 印刷電路板                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | —                                                            | ○                | ○                | ○                                                    | ○                                            | ○                                                    |
| <p>備考1. “超出0.1 wt %” 及 “超出0.01 wt %” 係指限用物質之百分比含量超出百分比含量基準值。</p> <p>Note1 : “exceeding 0.1wt%” and “exceeding 0.01 wt%” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.</p> <p>備考2. “○” 係指該項限用物質之百分比含量未超出百分比含量基準值。</p> <p>Note2 : “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.</p> <p>備考3. “—” 係指該項限用物質為排除項目。</p> <p>Note3 : The “—” indicates that the restricted substance corresponds to the exemption.</p> |                                                              |                  |                  |                                                      |                                              |                                                      |

## Taiwan Region import and export contact information

Contacts are available for Taiwan Region import and export information.

委製商/進口商名稱: 台灣聯想環球科技股份有限公司  
進口商地址: 台北市南港區三重路 66 號 8 樓  
進口商電話: 0800-000-702

## China Energy Label (CEL)

本产品的中国能效标识施加在服务器产品本体上。

中国能效标识中的配置类型Type 1、Type 2、Type 3分别对应能效等级1、2、3级的产品配置。同一规格型号下产品配置会有所不同。（此描述仅适用于中国能效范围内的产品）





