BT50 Bluetooth Dongle

You can connect the WH66/WH67 base to the PC via Bluetooth.

Procedure

1. Connect the BT50 to a USB port on your PC.
2. The WH66/WH67 and the BT50 are pre-paired and ready to use out of the box. You can also pair the base and the BT50 via Yealink USB Connect.

Related Topic

- Yealink USB Connect
- Connect WH6X to PC
- Connect WH6X to Desk Phone