


HP LaserJet Enterprise MFP 8601
HP LaserJet Enterprise Flow MFP 8601

Repair Manual

www.hp.com/support/lj8601MFP

HP LaserJet Enterprise MFP 8601 Series, HP LaserJet Enterprise Flow MFP 8601 Series - Repair Manual

SUMMARY

This guide provides troubleshooting and repair information.

Legal information

Copyright and License

© Copyright 2025 HP Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Edition 1, 5/2025

Conventions used in this guide

Learn about the conventions used in this publication.

TIP: Tips provide helpful hints or shortcuts.

NOTE: Notes provide important information to explain a concept or to complete a task.

CAUTION: Cautions indicate procedures that you should follow to avoid losing data or damaging the product.

WARNING! Warnings alert you to specific procedures that you should follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

Safety precautions

Follow these safety protocols when handling or repairing the printer.

Product safety classification: This is a Safety Class I product, which means it has a protective earth terminal. This terminal must be connected to earth ground.

IMPORTANT: Before operation or repair, check the product and review this manual for safety warnings and instructions. Safety warnings for specific procedures are located at appropriate places in the manual.

WARNING: Hazardous voltages exist within the product.

NOTE: HP recommends that only qualified personnel trained in working with high voltage power equipment should service this unit.

Follow these precautions always:

NOTE: If you do not want to disassemble and repair the printer yourself, contact your local HP Service Representative for service, see Contact HP Support on page viii section.

Warnings and Cautions

To ensure the proper use of the printer and to prevent the printer from being damaged, follow the warning and caution symbols marked in this guide. See Conventions used in this guide on page iii.

Electrical precautions

- **Power cord instructions**
  - Make sure your power source is adequate for the product voltage rating. The voltage rating is on the product label.

    Typically, the product uses either 110-127 Vac or 220-240 Vac and 50/60 Hz. Depending on a product, the voltage usage might change (100-127 Vac, for example). It is recommended to refer your product manual for the specified voltage.
  - Connect the power cord between the product and a grounded AC outlet.

    CAUTION: To prevent damage to the product, use only the power cord that is provided with the product.

    Do not damage, cut, or repair the power cord. A damaged power cord can cause fire or electric shock. Replace a damaged power cord with an HP-approved power cord.
  - Unplug the power cord when disassembling or assembling the printer.

The printer utilizes a power switch (button) that is turned "ON" or "OFF". Be aware that electricity may flow on the primary side of the printer even when the printer is "OFF".

- Power off the printer and unplug the power cord and fax cord (if available) from the electrical outlet in any of the following cases:
  - When removing product enclosure or covers from the printer or when accessing internal parts of a printer.
  - If there is smoke or an unusual smell coming from the printer.
  - A piece of metal or a liquid (not part of cleaning and maintenance routines) touches internal parts of the printer.
  - During an electrical storm (with thunder and/or lightning).
  - During an electrical power failure.

Electrostatic Discharge (ESD) precautions

Electrostatic discharge (ESD) can damage electronic components inside your printer.

Use these guidelines to protect sensitive parts against damage from electrostatic discharge.

- Touch a metal object that is not painted and is grounded.
- Leave electronic parts such as a memory chip in the bag it was shipped in until you are ready to perform the installation.
- ESD wrist straps can also be used to help release excess electrostatic charge.

- **CAUTION:** 

  Some parts are sensitive to electrostatic discharge (ESD). Look for the ESD reminder when removing printer parts.

  Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly.

- Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

Handling toner

HP recommends that you wear gloves when handling toner cartridges and toner system components.

Do not expose toner or toner cartridge to fire or any heat source.

Keep imaging unit and/or toner cartridge away from children. The toner powder contained in the imaging unit and toner cartridge may be harmful, and if swallowed, you should contact a doctor.

Lifting equipment

Follow the recommendations for lifting or moving your printer.

The printed inbox guides and support documentation available on support.hp.com for your printer model will provide the lifting requirements to avoid injury and to safely move the printer.

NOTE: Do not attempt to lift heavy equipment without assistance.

Safety measures during disassembling or reassembling

IMPORTANT: Before disassembling or reassembling a printer, be sure to unplug its power cord from the electrical outlet.

NOTE: Assembly is the reverse of disassembly unless otherwise specified.

- During disassembly, reassembly, or transportation of a printer, remove the toner cartridge as necessary.
- Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used.

  Do not use repaired fuses or short-circuited fuse holders. Doing so, could cause a shock or fire hazard.
- Capacitors inside this product may hold a hazardous charge even if the product has been disconnected from its power source.
- Do not disable safety functions (Interlocks or safety circuits). Safety will not be assured leading to a safety hazard and potential injury.
- Note the length, diameters, and locations of screws as you remove them. When reassembling the printer, be sure to use them in their original locations.
- As a best practice safety rule, do not run the printer with any parts removed.

Ingestion hazards

This product may contain a button cell or coin battery that is not intended to be replaced.

- A swallowed button cell or coin battery can cause internal chemical burns in as little as two (2) hours.

  Death or serious injury can occur if ingested.
- Keep new and used batteries out of reach of children. Used batteries may cause severe injury or death.

  Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body. Call a local poison control center for treatment information.
- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do not dispose of batteries in household trash or incinerate.

Laser radiation hazards

The printer is certified as a Class 1 laser product.

WARNING: Using controls, adjusting or performing procedures other than those specified in the user guide could result in exposure to hazardous radiation. Do not disassemble the laser/scanner unit as the laser beam can injure your eyes. An invisible laser beam is emitted within the laser/scanner unit.

Mechanical hazards

The printer has moving parts that could cause injury. To avoid personal injury, take the following precautions when working close to the printer.

- Keep your clothes and body away from the printer's moving parts.
  - Avoid wearing dangling jewelry or other hanging objects around the printer as it might be caught by moving parts and lead to injury.
  - Keep long hair tied up and away from the paper feed mechanism.
  - Ensure the sleeves or gloves do not get caught in the printer's moving parts.
- Avoid standing close to the fans as it could cause injury and could also affect print quality (by obstructing the air flow).
- Do not touch gears or moving rolls during printing.
- Do not operate the printer when having enclosure covers removed or interlock switches bypassed.
- The product may have internal sharp edges.

  Make sure the wiring does not come into contact with sharp edges, burrs, or other pointed parts. Current can leak, leading to a risk of electrical shock or fire hazard.
- During and after repair, check internal electrical wiring for squeezing, sheaths and any damage.
- – Make sure that all screws, components, wiring, connectors and so forth that were removed, have been reinstalled in the original location.
  - Do not allow any metal parts such as clips, staples and screws to fall into the printer. This could potentially short internal circuits and cause an electrical shock hazard.
  - Do not allow liquids (except those used in HP cleaning kits) to touch the internal parts of the printer. Doing so may cause fire, electric shock, or other serious hazards.

Thermal hazards

Caution: Inspection before repair for fuser

The area around the fuser unit may be hot. Wait for a few minutes until the fuser assembly cools down.

Contact HP Support

HP offers phone support to assist you for printer issues. Ensure to read the following information before contacting HP Support.

Before contacting HP Support

Before contacting support, consider checking the resources available on HP Customer Support.

1. Go to HP Customer Support (https://support.hp.com) to locate your product support page.
2. Review the documents for troubleshooting before contacting HP.

Information required when contacting HP Support

If you call an HP support representative for assistance, ensure you have the following information for HP support to answer your questions quickly:

- **Product model**: Note the printer model, product number, and serial number you are using. The product number and the serial number are typically found on the label at the back of the product.
- **Error code**: If there is an error code or message displaying on the printer control panel, note the error code and message.
- **Computer (operating system)**: Provide the name of the computer/computer operating system you are using.
- Any **special equipment or software** you are using (for example, spoolers, networks, switch-boxes, modems or special software drivers).
  - The type of interface used on your product (USB or network).
  - The software and driver name and firmware version number that you are currently using.
- **Printer service information**: You can obtain the printer service information from the Embedded Web Server (EWS). If you need to send this information by email, download it as a file from your browser, and send the file.

NOTE: Depending on your printer firmware version, the menu items in the EWS might vary.

1. Open a Web browser on your computer, and then enter the IP address of your printer to access the Embedded Web Server.
2. Click **Support** > **Service support** > **Service information** > **Display**.

Phone support

HP phone support is available on the HP support website. For assistance, go to one of the following websites:

- https://support.hp.com/contact or
- https://support.hp.com/contact/help/printer or
- https://www.hp.com/us-en/contact-hp/contact.html.

Table of contents

1 Product information, configurations, and specifications 1

Printer views 2
Printer front view 2
Printer back view 3
Interface ports view 5
Control-panel view 5
How to use the touchscreen control panel 7

Specifications 9
Basic specifications 9
Supported operating systems 9
Mobile printing solutions 10
Printer dimensions 10
Operating-environment range 12
General specifications 12
Print specifications 13
Scan specifications 13
Copy specifications 14
Paper handling specifications 14
Supplies 17
Maintenance parts (Long Life Consumables (LLC)) 17
Network and software specifications 18
Network interface 18
Options 20
Option specifications 20

2 Product installation and maintenance 23

Product installation 23

Maintenance 24
PM table (Preventive Maintenance) 24
Cleaning 25
Cleaning the paper dust holder 25
Cleaning the CTD sensor 27
Cleaning the scanner glass 28
Cleaning the ADF CIS (Contact Image Sensor) 28
Cleaning the deve plate guide 29
Inspection procedures 30
Maintenance (remove and replace) 32

Counter reset after LLC replacement 33

3 Problem solving 34

General troubleshooting guide 35
Troubleshooting process 35
Determine the problem source 35
Power subsystem 35
Control panel checks 38
Individual component diagnostics 42
Tools for troubleshooting 45
Problem-solving checklist 45
Step 1: Check that the printer power is on 45
Step 2: Check the control panel for error messages 45
Step 3: Test print functionality 45
Step 4: Test copy functionality 46
Step 5: Test the fax sending functionality 46
Step 6: Test the fax receiving functionality 46
Step 7: Try sending a print job from a computer 46
Step 8: Test the Plug and Print USB Drive printing functionality 46
Factors that affect printer performance 47
Print menu map 47
Print current settings pages 47
Additional tools for troubleshooting 48
Remote Admin 48
Required software and network connection 48
Connect a remote connection 50
Disconnect a remote connection 55
Clear paper jams 56
Paper jam locations 56
Auto-navigation for clearing paper jams 57
Experiencing frequent or recurring paper jams? 58
31.13.yz jam error in the document feeder 58
13.B2.A1, 13.B2.D2 jam error in tray 1 (multipurpose tray) 60
13.A2, 13.A3, 13.A4 jam errors in tray 2, tray 3, or the optional 2 x 520-sheet trays 61
13.E1 jam error in the output bin 62
13.B9, 13.B2, 13.FF jam errors in the right door and fuser area 63

Control panel messages document (CPMD) 65
Error codes (types and structure) 65
Print the supplies status page 67
Print the event log 67
Pre-boot menu options 67
Open the Pre-boot menu from a touchscreen control panel 67
Cold reset using the Pre-boot menu from a touchscreen control panel 69
Remote Admin 69
Required software and network connection 70
Connect a remote connection 71
Disconnect a remote connection 75
Print the event log 77

4 Control panel menus 78
Pre-boot menu options 79
Open the Pre-boot menu from a touchscreen control panel 79
Cold reset using the Pre-boot menu from a touchscreen control panel 80
Remote Admin 88
Required software and network connection 88
Telnet client 89
Network connection 90
Connect a remote connection 90
Start the telnet server function at the printer 90
Start the telnet client function at the remote computer 92
Disconnect a remote connection 95
Reports menu 96
Settings menu 98
Copy menu 134
Scan menu 143
Fax menu (when a fax option is installed) 171
Print menu 175
Supplies menu 175
Trays menu 176
Support Tools menu 177
Service menu 177
Event Log 178
Counts 179
Coverage Report 179
Scanner Settings 179
Serial Number 181
Service ID 181
Cold Reset Paper 181
Low Alerts 181
Reset Supplies Level 182
Consumables Access Control 182
Software Version 183
Service Reports 183
Print Adjustment 183
Buckle Adjustment 185
Finisher Adjustment 185
Reset Engine NVM 194
Engine NVM Read/Write 194
Sensors 195
Component tests 203
TR Control Mode 209
Low-temperature Idling Mode 210
Altitude Adjustment 211
Humidity 212
Vapor Mode 212

Footer 213
PTT Test Mode 213
Test Support 213
Part Replacement Count 213
Reset Supplies 214
Fax V.29 Speed 214
Maintenance menu 214
Backup/Restore 215
Import/Export 215
Custom Color 215
Auto Tone Adjustment 215
CTD Sensor Cleaning 216
Manual Tone Adjustment 216
Toner Density Calibration 216
Calibrate Scanner 216
USB Firmware Upgrade 216
License Management 216
Troubleshooting menu 219
Configuration/Status Pages 219
Fax Reports 220
Other Pages 220
Fax T.30 Trace Report 220
Fax V.34 221
JBIG Compression 221
Fax Speaker Mode 221
Fax Service Log 221
PQ Troubleshooting Pages 221
Advanced Print Quality Pages 224
Event Log 224
Paper Path Page 224
Run Fax Test 224
Retrieve Diagnostic Data 225
Retrieve Fax Diagnostic Data 225

5 Remove and replace 226

Safety precautions 226

Contact HP Support 229

Base printer 231
Covers 231
Base covers 231
Removal and replacement: Rear upper cover 231
Removal and replacement: Rear lower cover 234
Removal and replacement: Controller cover 237
Removal and replacement: Exit rear cover 239
Removal and replacement: Left top cover 242
Removal and replacement: Left upper cover 244
Removal and replacement: Left cover 248
Removal and replacement: Middle upper cover 252

Removal and replacement: Right door sHCI dummy cover 254
Removal and replacement: Right upper cover 256
Removal and replacement: Right rear cover 266
Removal and replacement: Right front cover 268
Removal and replacement: Right middle cover assembly 271
Removal and replacement: Right middle cover 275
Removal and replacement: Power key 284
Removal and replacement: Hardware integration pocket (HIP) cover 294
Removal and replacement: Middle left cover 296
Removal and replacement: Exit cover stacker 299
Removal and replacement: Inner cover 302
Removal and replacement: Tie stoppers 310
Removal and replacement: Front lower cover 312
Removal and replacement: Front cover assembly 315
Feeding system 317
Right door assembly 317
Removal and replacement: Right door assembly 317
Removal and replacement: Right door front link 322
Removal and replacement: Right door front damper 327
Removal and replacement: Right door front damper bracket 332
Tray 1 unit 337
Removal and replacement: Tray 1 unit 337
Removal and replacement: Tray 1 empty sensor 355
Removal and replacement: Tray 1 clutch 374
Removal and replacement: Tray 1 roller kit (pickup/forward/reverse) 384
Tray 2-3 units 387
Removal and replacement: Tray 2 or Tray 3 387
Removal and replacement: Tray 2 pickup assembly 389
Removal and replacement: Tray 2, 3 roller kit (pickup/forward/reverse) 399
Removal and replacement: Tray 2 empty and stack height sensors 403
Removal and replacement: Tray 2 prefeed sensor 415
Removal and replacement: Tray 2 open and paper size sensor 427
Removal and replacement: Tray 2 pickup drive assembly 431
Removal and replacement: Tray 2 pickup motor 436
Removal and replacement: Tray 3 pickup drive assembly 439
Removal and replacement: Tray 3 pickup motor 442
Removal and replacement: Tray 3 pickup assembly 445
Removal and replacement: Tray 2, 3 roller kit (pickup/forward/reverse) 453
Removal and replacement: Tray 3 empty and stack height sensors 457
Removal and replacement: Tray 3 prefeed sensor 467
Removal and replacement: Tray 3 open and paper size sensor 477
Removal and replacement: Tray heater (accessory) 482
Removal and replacement: Feed drive assembly 485
Removal and replacement: Feed motor 493
Removal and replacement: Feed 2 sensor 504
Registration unit and loop sensing unit 514
Removal and replacement: Registration unit 514
Removal and replacement: Registration sensor 521
Removal and replacement: Registration drive assembly 529

Removal and replacement: Registration motor 536
Removal and replacement: Paper transfer belt (PBT) 543
Removal and replacement: Loop sensor 1 549
Removal and replacement: Loop sensor 2 558
Removal and replacement: Loop actuator 566
Removal and replacement: Right door exit assembly 573
Removal and replacement: Fuser out sensor 576
Removal and replacement: Fuser out sensor harness 579
Removal and replacement: Paper dust holder assembly 583
Exit unit 585
Removal and replacement: Exit unit 586
Removal and replacement: Output bin 1 sensor 600
Removal and replacement: Return gate solenoid 617
Removal and replacement: Exit 2 motor 633
Removal and replacement: Exit 2 sensor 649
Removal and replacement: Duplex jam 1 sensor 664
Removal and replacement: Duplex 1 motor 681
Removal and replacement: Exit stack guide 696
Duplex unit 698
Removal and replacement: Duplex assembly 698
Removal and replacement: Duplex jam 2 sensor 707
Removal and replacement: Duplex 2 motor 718
Toner flow 724
Toner cartridge 724
Removal and replacement: Toner dispense motor assembly 724
Removal and replacement: Toner dispense motor 734
Removal and replacement: Toner dispense motor sensor 743
Removal and replacement: Toner cartridge (control panel method) 755
Removal and replacement: Toner cartridge (disassemble method) 756
Removal and replacement: Toner CRUM module assembly 765
Removal and replacement: Guide toner cartridge and toner residual amount sensor 774
Reservoir unit 786
Removal and replacement: Reservoir unit 786
Removal and replacement: Reservoir drive assembly 801
Toner collection unit 816
Removal and replacement: Toner collection unit (TCU) 816
Removal and replacement: Toner collection unit (TCU) detection sensor 818
Removal and replacement: Toner collection unit (TCU) full sensor 826
Image creation 834
Laser scanner unit (LSU) 834
Removal and replacement: Laser scanner unit (LSU) 834
Developer and drum 840
Removal and replacement: Drum unit 840
Removal and replacement: Black developer unit 843
Removal and replacement: Developer powder 848
Removal and replacement: Developer, drum, and PTB drive assembly 857
Removal and replacement: Drum and PTB motor 864
Removal and replacement: Developer motor 867
Removal and replacement: Cable guide 870

Removal and replacement: CTD sensor assembly 873
Fuser unit 880
Removal and replacement: Fuser unit 880
Removal and replacement: Fuser and exit drive assembly 883
Removal and replacement: Fuser and exit motor 888
Removal and replacement: Fuser gap motor 893
Removal and replacement: Fuser gap sensor 897
Environmental sensor, switch, and fan 907
Base sensor, switch, and fan 907
Removal and replacement: Outer temperature humidity sensor assembly 907
Removal and replacement: LVPS fan 915
Removal and replacement: FDB fan 918
Removal and replacement: LVPS FDB fan assembly 922
Removal and replacement: Developer fan assembly 926
Removal and replacement: Developer suction duct 937
Removal and replacement: Fuser ventilation duct 940
Removal and replacement: LSU fan 944
Removal and replacement: Front door switch assembly 948
Removal and replacement: Right door switch assembly 956
Control panel 960
Base control panel 960
Removal and replacement: Control panel 960
PCAs 963
Main PCA 963
Removal and replacement: Formatter 963
Removal and replacement: Riser card and cradle 970
Removal and replacement: Rivet-SSD 975
Removal and replacement: Cradle-SSD 977
Removal and replacement: SSD 256GB 983
Sub PCAs 987
Removal and replacement: Accelerator card (optional) 987
Removal and replacement: USB hub PCA 991
Removal and replacement: Island of data (IOD) 999
Removal and replacement: Power key PCA 1003
Removal and replacement: Keyboard (Flow models) 1012
Removal and replacement: Fax card (optional) 1018
Power supply PCAs 1021
Removal and replacement: High-voltage power supply (HVPS) 1021
Removal and replacement: Low-voltage power supply (LVPS) 1024
Removal and replacement: Fuser-drive board (FDB) 1028
Integrated scanner asset (ISA) 1034
Whole unit 1034
300-Sheet ISA for z, z+ bundle 1034
Removal and replacement: Integrated scanner for Flow bundle (z, z+) 1034
200-Sheet ISA for dn bundle 1044
Removal and replacement: Integrated scanner for dn bundle (5QK35A for Flex-build) 1044
ADF (Automatic document feeder) 1049
300-Sheet ADF for z, z+ bundles 1049

Removal and replacement: ADF (300sh) 1049
Removal and replacement: ADF front cover (300sh) 1059
Removal and replacement: ADF CMF panel 1065
Removal and replacement: ADF rear cover (300sh) 1067
Removal and replacement: ADF top cover (300sh) 1073
Removal and replacement: ADF white backing kit (300sh) 1075
Removal and replacement: ADF pickup roller kit (300sh) 1080
Removal and replacement: ADF PCA (300sh) 1084
Removal and replacement: ADF flat-flexible cable (300sh) 1090
Removal and replacement: ADF power cable (300sh) 1096
Removal and replacement: ADF hinge kit (300sh) 1102
Removal and replacement: ADF hinge damper module 300sh) 1110
200-Sheet ADF for dn bundle 1117
Removal and replacement: ADF (200sh) 1117
Removal and replacement: ADF CMF panel 1124
Removal and replacement: ADF white backing kit (200sh) 1127
Removal and replacement: ADF pickup roller kit (200sh) 1132
Removal and replacement: ADF PCA (200sh) 1137
Removal and replacement: ADF flat-flexible cable (200sh) 1143
Removal and replacement: ADF power cable (200sh) 1149
Removal and replacement: ADF hinge kit (200sh) 1155
Removal and replacement: ADF hinge damper module (200sh) 1162
Flatbed Scanner (Tarot) 1169
Whole unit 1169
Removal and replacement: Flatbed scanner whole unit 1169
Covers 1177
Removal and replacement: Flatbed scanner rear cover 1177
PCA, harness, and sensor 1180
Removal and replacement: Flatbed scanner PCA assembly 1180
Removal and replacement: Flatbed scanner FFC 50 pin 1184
Removal and replacement: Flatbed scanner FFC 68 pin 1189
Removal and replacement: Flatbed scanner discrete power cable 1194
Removal and replacement: Flatbed scanner flatbed open sensor 1199
Input device (department) 1203
DCF (department) 1203
Covers 1203
Removal and replacement: DCF (Tray 4, 5) right cover 1203
Removal and replacement: DCF (Tray 4, 5) rear cover 1205
Removal and replacement: DCF (Tray 4, 5) left cover 1207
Removal and replacement: DCF (Tray 4, 5) right door 1209
Removal and replacement: Tray 4, 5 CMF panels 1211
Removal and replacement: Caster wheel 1214
Removal and replacement: Holder wheel kit - guide adjust 1216
Unit 1219
Removal and replacement: Tray 4, 5 cassettes 1219
Roller 1221
Removal and replacement: DCF roller kit 1221
Motor 1224

Removal and replacement: DCF pickup drive assembly....1224
Removal and replacement: Tray 4 pickup motor....1227
Removal and replacement: Tray 5 pickup motor....1230
Removal and replacement: DCF feed drive assembly....1232
Removal and replacement: DCF (Tray 4, 5) feed motor....1235
Sensor....1238
Removal and replacement: Tray 4, 5 paper size sensors....1238
Removal and replacement: Tray 4 pickup assembly....1241
Removal and replacement: Tray 4 paper empty and stack height sensors....1245
Removal and replacement: Tray 4 prefeed sensor....1249
Removal and replacement: Tray 5 pickup assembly....1254
Removal and replacement: Tray 5 paper empty and stack height sensors....1259
Removal and replacement: Tray 5 prefeed sensor....1263
Removal and replacement: DCF feed sensor....1269
PCA and harness....1275
Removal and replacement: Tray heater....1275
Removal and replacement: DCF (Tray 4, 5) PCA....1278
Removal and replacement: DCF (Tray 4, 5) right door open switch holder assembly....1281
Removal and replacement: DCF IF harness....1284
Removal and replacement: DCF door open switch sensor and harness....1287
Removal and replacement: DCF motor harness 2nd....1291
Removal and replacement: DCF sensor harness 1st....1294
Removal and replacement: DCF sensor harness 2nd....1298
Removal and replacement: DCF size harness....1302
Output device....1306
Stapler/stacker and (or) Booklet finisher....1306
Cover....1306
Removal and replacement: Front door....1306
Removal and replacement: Caster cover....1308
Removal and replacement: Left lower cover....1310
Removal and replacement: Left lower cover....1318
Removal and replacement: Left upper cover....1319
Removal and replacement: Booklet output tray....1329
Removal and replacement: Top output tray....1332
Removal and replacement: Main output tray....1334
Removal and replacement: Rear cover....1336
Removal and replacement: Front cover....1339
Removal and replacement: Punch cover....1343
Removal and replacement: Top cover....1345
Removal and replacement: Top door....1348
Removal and replacement: Right upper cover....1351
Removal and replacement: Front lower left cover....1354
Removal and replacement: Front lower right cover....1359
Removal and replacement: Shaft hinge - door....1361
Removal and replacement: Caster....1364
Removal and replacement: Caster fix nut....1367
Removal and replacement: Booklet front cover....1370
Bridge unit (or) Bridge unit with PQ Diagnostics....1372

Removal and replacement: Bridge unit (or) Bridge unit with PQ Diagnostics....1372
Removal and replacement: Bridge door sensor....1377
Removal and replacement: Bridge entrance sensor....1382
Removal and replacement: Bridge exit sensor....1387
Removal and replacement: Bridge motor....1394
Entrance unit....1400
Removal and replacement: Entrance sensor....1400
Removal and replacement: Entrance motor assembly....1414
Removal and replacement: Entrance motor....1417
Punch unit....1421
Removal and replacement: Punch unit....1421
Tray diverter unit....1423
Removal and replacement: Top jam cover assembly....1423
Removal and replacement: Tray diverter....1427
Removal and replacement: Top door open switch....1432
Removal and replacement: Tray diverter cam....1435
Removal and replacement: Tray diverter home sensor....1444
Top exit unit....1451
Removal and replacement: Top exit sensor....1451
Removal and replacement: Exit motor assembly....1461
Removal and replacement: Exit motor....1464
Top output tray unit....1467
Removal and replacement: Top lower feed assembly....1467
Removal and replacement: Tray extension....1476
Removal and replacement: Top output tray paper full sensor....1479
Main exit unit....1486
Removal and replacement: Main exit sensor....1486
Removal and replacement: Main exit cam motor assembly....1493
Removal and replacement: Main exit cam home sensor....1498
Removal and replacement: Main exit cam motor....1503
Removal and replacement: Front door switch....1508
Paddle unit....1514
Removal and replacement: Paddle....1514
Removal and replacement: Paddle motor assembly....1524
Removal and replacement: Paddle home sensor....1529
Removal and replacement: Paddle motor....1535
End fence unit....1540
Removal and replacement: End fence home sensor....1540
Removal and replacement: End fence motor assembly....1554
Removal and replacement: End fence motor....1559
Removal and replacement: Main output tray top of stack switch guide....1564
Removal and replacement: Main output tray top of stack switch lower guide....1573
Tamper unit....1582
Removal and replacement: Front tamper....1582
Removal and replacement: Front tamper home sensor....1594
Removal and replacement: Front tamper motor....1605
Removal and replacement: Rear tamper....1616
Removal and replacement: Rear tamper home sensor....1626
Removal and replacement: Rear tamper motor....1637

Stapler unit 1649
Removal and replacement: Stapler unit 1649
Removal and replacement: Staple cartridge 1655
Removal and replacement: Stapler front sensor 1657
Removal and replacement: Stapler mid-front and mid-rear sensors 1665
Removal and replacement: Manual staple sensor 1672
Removal and replacement: Stapler position motor 1678
Ejector unit 1685
Removal and replacement: Ejector unit 1685
Removal and replacement: Ejector sensor 1699
Removal and replacement: Ejector 1 home sensor 1715
Removal and replacement: Ejector 1 motor sensor 1729
Removal and replacement: Ejector 2 motor sensor 1744
Main output tray unit 1758
Removal and replacement: Main output tray 1758
Removal and replacement: Main output tray top of stack sensor 1760
Removal and replacement: Main output tray lower limit sensor 1772
Removal and replacement: Main output tray motor sensor 1783
Removal and replacement: Main output tray motor drive assembly 1786
Removal and replacement: Main output tray top of stack switch 1789
Paper holding unit 1799
Removal and replacement: Front and rear paper holding sensor 1799
Removal and replacement: Paper holding home sensor 1811
Removal and replacement: Paper holding motor drive assembly 1823
Buffer unit 1835
Removal and replacement: Buffer solenoid assembly 1835
Removal and replacement: Buffer motor 1841
Booklet finisher (only) 1846
Booklet maker 1846
Removal and replacement: Booklet maker 1846
Removal and replacement: Harness guide 1855
Booklet entrance unit 1867
Removal and replacement: Booklet entrance unit 1867
Removal and replacement: Booklet entrance sensor 1879
Removal and replacement: Booklet entrance-presser motor assembly 1893
Removal and replacement: Booklet entrance motor 1897
Booklet paddle unit 1907
Removal and replacement: Booklet paddle home sensor 1908
Removal and replacement: Booklet paddle motor assembly 1911
Removal and replacement: Booklet paddle motor 1915
Booklet end fence unit 1919
Removal and replacement: Booklet end fence home sensor 1919
Removal and replacement: Booklet end fence motor 1931
Booklet presser unit 1943
Removal and replacement: Booklet presser home sensor 1943
Removal and replacement: Booklet tamper 1948
Removal and replacement: Booklet tamper home sensor 1965
Removal and replacement: Booklet tamper motor 1983
Removal and replacement: Booklet tamper sensor 2001

Booklet stapler unit 2019
Removal and replacement: Booklet stapler 2020
Removal and replacement: Booklet staple cartridge 2036
Booklet fold unit 2039
Removal and replacement: Booklet c-fold blade assembly 2039
Removal and replacement: Booklet c-fold blade home sensor 2050
Removal and replacement: Booklet c-fold blade motor assembly 2056
Removal and replacement: Booklet c-fold blade motor 2062
Removal and replacement: Booklet blade home sensor 2067
Removal and replacement: Booklet blade motor 2084
Removal and replacement: Booklet fold motor assembly 2089
Removal and replacement: Booklet fold motor 2093
Booklet diverter unit 2097
Removal and replacement: Booklet diverter 2097
Removal and replacement: Booklet diverter home sensor 2113
Removal and replacement: Booklet diverter motor assembly 2120
Removal and replacement: Booklet diverter motor 2125
Booklet output tray unit 2131
Removal and replacement: Booklet output tray 2131
Removal and replacement: Booklet output tray sensor 2133
PCA 2141
Removal and replacement: Main PCA 2141
Removal and replacement: PCA 2146
Miscellaneous parts 2156
Removal and replacement: Finisher mounting brackets 2156

6 Parts and diagrams 2160

Base printer 2161
Covers 2161
Parts and diagrams: Covers 2161
Feeding system 2163
Tray 1 2164
Parts and diagrams: Tray 1 2164
Tray 2, 3 2165
Parts and diagrams: Tray 2, 3 2165
Registration and loop sensors 2166
Parts and diagrams: Registration and loop sensors 2166
Exit unit 2168
Parts and diagrams: Exit unit 2168
Duplex 2169
Parts and diagrams: Duplex 2169
Toner flow 2170
Toner cartridge 2170
Parts and diagrams: Toner 2170
Reservoir 2171
Parts and diagrams: Reservoir 2171
Toner collection unit (TCU) 2172
Parts and diagrams: Toner collection unit 2172
Image creation 2173

Laser scanner unit (LSU) 2173
Parts and diagrams: Laser scanner unit 2173
Developer 2173
Parts and diagrams: Developer 2174
Drum 2174
Parts and diagrams: Drum 2174
CTD 2175
Parts and diagrams: CTD 2175
PTB 2176
Parts and diagrams: PTB 2176
Fuser 2177
Parts and diagrams: PCA 2177
Sensor and fan 2179
Parts and diagrams: Sensor and fan 2179
PCA 2180
Parts and diagrams: PCA 2181
ADF / Image scanner assembly 2183
Image scanner assembly (ISA) 2183
Parts and diagrams: ISA 2183
300sh flow ADF 2185
Parts and diagrams: 300sh flow ADF (1 of 2) 2185
Parts and diagrams: 300sh flow ADF (2 of 2) 2186
200sh ADF 2188
Parts and diagrams: 200sh ADF (1 of 2) 2188
Parts and diagrams: 200sh ADF (2 of 2) 2189
Tarot platen 2189
Parts and diagrams: Tarot platen 2190
Input devices 2191
Department Dual cassette feeder (DCF, Tray 4, 5) 2192
Parts and diagrams: DCF (1 of 2) 2192
Parts and diagrams: DCF (2 of 2) 2194
Output device 2196
Stapler/Stacker finisher 2197
Parts and diagrams: Stapler/Stacker finisher (1 of 4) 2197
Parts and diagrams: Stapler/Stacker finisher (2 of 4) 2199
Parts and diagrams: Stapler/Stacker finisher (3 of 4) 2201
Parts and diagrams: Stapler/Stacker finisher (4 of 4) 2202
Booklet finisher 2204
Parts and diagrams: Booklet finisher (1 of 5) 2204
Parts and diagrams: Booklet finisher (2 of 5) 2206
Parts and diagrams: Booklet finisher (3 of 5) 2208
Parts and diagrams: Booklet finisher (4 of 5) 2210
Parts and diagrams: Booklet finisher (5 of 5) 2211
Alphabetical parts list 2213
Base printer 2161
Covers 2161
Parts and diagrams: Covers 2161

Feeding system 2163
Tray 1 2164
Parts and diagrams: Tray 1 2164
Tray 2, 3 2165
Parts and diagrams: Tray 2, 3 2165
Registration and loop sensors 2166
Parts and diagrams: Registration and loop sensors 2166
Exit unit 2168
Parts and diagrams: Exit unit 2168
Duplex 2169
Parts and diagrams: Duplex 2169
Toner flow 2170
Toner cartridge 2170
Parts and diagrams: Toner 2170
Reservoir 2171
Parts and diagrams: Reservoir 2171
Toner collection unit (TCU) 2172
Parts and diagrams: Toner collection unit 2172
Image creation 2173
Laser scanner unit (LSU) 2173
Parts and diagrams: Laser scanner unit 2173
Developer 2173
Parts and diagrams: Developer 2174
Drum 2174
Parts and diagrams: Drum 2174
CTD 2175
Parts and diagrams: CTD 2175
PTB 2176
Parts and diagrams: PTB 2176
Fuser 2177
Parts and diagrams: PCA 2177
Sensor and fan 2179
Parts and diagrams: Sensor and fan 2179
PCA 2180
Parts and diagrams: PCA 2181
ADF / Image scanner assembly 2183
Image scanner assembly (ISA) 2183
Parts and diagrams: ISA 2183
300sh flow ADF 2185
Parts and diagrams: 300sh flow ADF (1 of 2) 2185
Parts and diagrams: 300sh flow ADF (2 of 2) 2186
200sh ADF 2188
Parts and diagrams: 200sh ADF (1 of 2) 2188
Parts and diagrams: 200sh ADF (2 of 2) 2189
Tarot platen 2189
Parts and diagrams: Tarot platen 2190
Input devices 2191
Department Dual cassette feeder (DCF, Tray 4, 5) 2192

Parts and diagrams: DCF (1 of 2) 2192
Parts and diagrams: DCF (2 of 2) 2194
Output device 2196
Stapler/Stacker finisher 2197
Parts and diagrams: Stapler/Stacker finisher (1 of 4) 2197
Parts and diagrams: Stapler/Stacker finisher (2 of 4) 2199
Parts and diagrams: Stapler/Stacker finisher (3 of 4) 2201
Parts and diagrams: Stapler/Stacker finisher (4 of 4) 2202
Booklet finisher 2204
Parts and diagrams: Booklet finisher (1 of 5) 2204
Parts and diagrams: Booklet finisher (2 of 5) 2206
Parts and diagrams: Booklet finisher (3 of 5) 2208
Parts and diagrams: Booklet finisher (4 of 5) 2210
Parts and diagrams: Booklet finisher (5 of 5) 2211
Numerical parts list 2229
Base printer 2161
Covers 2161
Parts and diagrams: Covers 2161
Feeding system 2163
Tray 1 2164
Parts and diagrams: Tray 1 2164
Tray 2, 3 2165
Parts and diagrams: Tray 2, 3 2165
Registration and loop sensors 2166
Parts and diagrams: Registration and loop sensors 2166
Exit unit 2168
Parts and diagrams: Exit unit 2168
Duplex 2169
Parts and diagrams: Duplex 2169
Toner flow 2170
Toner cartridge 2170
Parts and diagrams: Toner 2170
Reservoir 2171
Parts and diagrams: Reservoir 2171
Toner collection unit (TCU) 2172
Parts and diagrams: Toner collection unit 2172
Image creation 2173
Laser scanner unit (LSU) 2173
Parts and diagrams: Laser scanner unit 2173
Developer 2173
Parts and diagrams: Developer 2174
Drum 2174
Parts and diagrams: Drum 2174
CTD 2175
Parts and diagrams: CTD 2175
PTB 2176
Parts and diagrams: PTB 2176
Fuser 2177

Parts and diagrams: PCA 2177
Sensor and fan 2179
Parts and diagrams: Sensor and fan 2179
PCA 2180
Parts and diagrams: PCA 2181
ADF / Image scanner assembly 2183
Image scanner assembly (ISA) 2183
Parts and diagrams: ISA 2183
300sh flow ADF 2185
Parts and diagrams: 300sh flow ADF (1 of 2) 2185
Parts and diagrams: 300sh flow ADF (2 of 2) 2186
200sh ADF 2188
Parts and diagrams: 200sh ADF (1 of 2) 2188
Parts and diagrams: 200sh ADF (2 of 2) 2189
Tarot platen 2189
Parts and diagrams: Tarot platen 2190
Input devices 2191
Department Dual cassette feeder (DCF, Tray 4, 5) 2192
Parts and diagrams: DCF (1 of 2) 2192
Parts and diagrams: DCF (2 of 2) 2194
Output device 2196
Stapler/Stacker finisher 2197
Parts and diagrams: Stapler/Stacker finisher (1 of 4) 2197
Parts and diagrams: Stapler/Stacker finisher (2 of 4) 2199
Parts and diagrams: Stapler/Stacker finisher (3 of 4) 2201
Parts and diagrams: Stapler/Stacker finisher (4 of 4) 2202
Booklet finisher 2204
Parts and diagrams: Booklet finisher (1 of 5) 2204
Parts and diagrams: Booklet finisher (2 of 5) 2206
Parts and diagrams: Booklet finisher (3 of 5) 2208
Parts and diagrams: Booklet finisher (4 of 5) 2210
Parts and diagrams: Booklet finisher (5 of 5) 2211
Glossary of terms 2245
Index 2255

1 Product information, configurations, and specifications

You will learn more about the product information, configurations, and specifications.

Printer views

Learn more specifically about the different views of the printer.

Printer front view

Locate features on the front of the printer.

Figure 1-1 **Printer front view**




Table 1-1 **Printer front view**

Item	Description
1	Automatic document feeder cover, for access for clearing jams
2	Automatic document feeder input tray
3	Automatic document feeder output tray
4	Control panel with color touchscreen display (tilts up for easier viewing)
5	On/off button
6	Right door, for access for clearing jams
7	Tray 1 (multipurpose tray)
8	Front door, for access to the toner cartridges
9	Power connection
10	Tary 4 and 5 jam access door
11	Hardware integration pocket (HIP), for connecting accessory and third-party devices
12	Output bin
13	Tray 2
14	Tray 3
15	Tray 4
16	Tray 5

Printer back view

Locate features on the back of the printer.

Figure 1-2 Printer back view





Table 1-2 Printer back view

Item	Description
1	Formatter cover CAUTION: There is a risk of electric shock. This cover should only be opened by a qualified service technician.
2	Interface ports
3	Thumbscrew CAUTION: The thumbscrew should be tightened with a tool after both initial installation and subsequent access to the formatter cover.
4	Serial number and product number label

Interface ports view

Locate the interface ports on the printer formatter.

Figure 1-3 Interface ports view



Item	Description
1	Fax port 1 NOTE: Fax port 2 is not used. (These ports might be covered)
2	Hi-speed USB 2.0 host port for connecting external USB devices (this port might be covered) NOTE: For easy-access USB printing, use the USB port near the control panel.
3	SuperSpeed USB 3.0 host port for connecting external USB devices (this port might be covered)
4	Local area network (LAN) Ethernet (RJ-45) network port
5	Slot for a cable-type security lock
6	SuperSpeed USB 3.0 printing port

Control-panel view

The control panel provides access to the printer features and indicates the current status of the printer.

NOTE: Tilt the control panel for easier viewing.

The Home screen provides access to the printer features and indicates the current status of the printer.

NOTE: The features that appear on the Home screen can vary, depending on the printer configuration.

Figure 1-4 Control-panel view




Table 1-3 Control-panel view

Item	Control	Description
1	Reset button	The Reset button returns the printer to default settings and is always present if users are not logged in. The Reset button is not present when the Sign Out button is present. Touch the Reset button to resume and release jobs from the previous pause state and interrupt mode, reset the quick copy count in the copy count field, exit special modes, reset the display language and the keyboard layout.
2	Sign In or Sign Out button	Touch the Sign In button to access secured features. Touch the Sign Out button to sign out of the printer. The printer restores all options to the default settings. **NOTE:** This button displays only if the administrator has configured the printer to require permission for access to features.




Table 1-3 Control-panel view (continued)

Item	Control	Description
3	Information button	Touch the information button to access a screen that provides access to several types of printer information. Touch the buttons at the bottom of the screen for the following information: • Display Language: Change the language setting for the current user session. • Sleep Mode: Place the printer into sleep mode. • Wi-Fi Direct: View information for how to connect directly to the printer using a phone, tablet, or other device with Wi-Fi (only available when the optional wireless accessory is installed). • Wireless: View or change wireless connection settings (only available when the optional wireless accessory is installed). • Ethernet: View or change Ethernet connection settings. • HP Web Services: View information to connect and print to the printer using HP Web Services (ePrint).
4	Help button	Touch the Help button to open the embedded help system. The status line provides information about the overall printer status.
5	Applications area	Touch any of the icons to open the application. Swipe the screen sideways to access more applications. NOTE: The available applications vary by printer. The administrator can configure which applications appear and the order in which they appear. On Flow printers the Scan button is replaced by the Scan+ button. Touch the Scan+ button to send a scan job to multiple destinations at once, including email, SharePoint, network folder, USB drive, fax, or printed hard copy. It also includes a preview mode that supports simple editing.
6	Copy button	Touch the Copy button to start a copy job.
7	Home-screen page indicator	Indicates the number of pages on the Home screen or in an application. The current page is highlighted. Swipe the screen sideways to scroll between pages.

How to use the touchscreen control panel

Perform the following actions to use the printer touchscreen control panel.

Table 1-4 Touchscreen control panel actions

Action	Description	Example
Touch 	Touch an item on the screen to select that item or open that menu. Also, when scrolling through menus, briefly touch the screen to stop the scrolling.	Touch the Settings icon to open the Settings app.
Swipe 	Touch the screen and then move your finger horizontally to scroll the screen sideways.	Swipe until the Settings app displays.
Scroll 	Touch the screen and then move your finger vertically to scroll the screen up and down. When scrolling through menus, briefly touch the screen to stop the scrolling.	Scroll through the Settings app.

Specifications

Learn about the specifications.

Basic specifications

Learn about the basic specifications of the printer.

Supported operating systems

Learn about supported operating systems.

The following information applies to the Printer-Specific Windows PCL 6 and HP print drivers for macOS and to the software installer.

Windows: The HP Software Installer can be downloaded from the printer support website for this printer which installs the correct print driver, depending on the Windows operating system, along with optional software when using the software installer.

The print driver only package is also made available in the printer support website. Download the applicable package from the printer-support website for this printer: www.hp.com/support.

Table 1-5 Supported operating systems and print drivers

Operating system	Print driver installed (from the software on the web)
Windows 11, 64-bit Windows 10, 32-bit and 64-bit	The PCL 6/PSA printer-specific print driver is available for download from the printer-support website. Download the driver, and then use the Microsoft Add Printer tool to install it.
Windows Server 2022, 64-bit	The PCL 6 printer-specific print driver is available for download from the printer-support website. Download the driver, and then use the Microsoft Add Printer tool to install it.
Windows Server 2019, 64-bit	The PCL 6 printer-specific print driver is available for download from the printer-support website. Download the driver, and then use the Microsoft Add Printer tool to install it.
Windows Server 2016, 64-bit	The PCL 6 printer-specific print driver is available for download from the printer-support website. Download the driver, and then use the Microsoft Add Printer tool to install it.
Windows Server 2012, 64-bit	The PCL 6 printer-specific print driver is available for download from the printer-support website. Download the driver, and then use the Microsoft Add Printer tool to install it.
Windows Server 2012 R2, 64-bit	The PCL 6 printer-specific print driver is available for download from the printer-support website. Download the driver, and then use the Microsoft Add Printer tool to install it.

Table 1-5 Supported operating systems and print drivers (continued)

Operating system	Print driver installed (from the software on the web)
macOS Sequoia (version 15) macOS Sonoma (version 14) macOS Ventura (version 13) macOS Monterey (version 12) macOS Big Sur (version 11) macOS Catalina (version 10.15) macOS Mojave (version 10.14)	To install the print driver, download HP Easy Start from 123.hp.com/LaserJet. Follow the steps provided to install the printer software and print driver.

NOTE: Microsoft retired mainstream support for Windows Server 2003 in July 2010. There is no more support for Windows 7, Windows Server 2003, and Windows Server 2008.

Table 1-6 Minimum system requirements

Windows	macOS
• Internet connection • Dedicated USB 1.1 or 2.0 connection or a network connection • 2 GB of available hard-disk space	• Internet connection • 2 GB of available hard-disk space

Mobile printing solutions

Learn what HP offers for mobile printing solutions.

HP offers multiple mobile solutions to enable easy printing to an HP printer from a laptop, tablet, smartphone, or other mobile device. To see the full list and to determine the best choice, go to HP Customer Support - Knowledge Base.

- Apple AirPrint
- Mopria Certified
- WiFi Direct Printing
- NFC Touch to Print
- ePrintIT PrinterOn

Printer dimensions

Learn about the printer dimensions.

Figure 1-5 **Printer dimensions (fully open)**





Figure 1-6 Printer with finisher (fully open)



Operating-environment range

In order to operate properly, the printer must be in an environment that meets certain specifications.

Table 1-7 Operating-environment specifications

Environment	Recommended	Storage
Temperature	15° to 27°C (59° to 80.6°F)	10 to 32.5°C (50 to 90.5°F)
Relative humidity	30% to 70% relative humidity (RH)	10% to 80% relative humidity (RH)

General specifications

Learn about general specifications for printer models.

Table 1-8 General specifications

Item	Specification
ASIC	GigaTron Quad 1.6 GHz ARM A72 + Dual 1.4 GHz ARM A53
Memory	6 GB
Storage	256 GB SSD
Connectivity (I/O standard)	Gigabit LAN USB 3.2 Gen1 (USB 3.0) Device USB 3.2 Gen1 (USB 3.0)/2.0 Host ports TPM
Power Requirement	Input voltage: 110 to 127Vac (+/- 10%), 220 to 240Vac (+/- 10%), 50/60 Hz (+/- 3%)

Table 1-8 General specifications (continued)

Item	Specification
Sound Power Level	Blue Angel UZ-205: • 70ppm: ≤7.6 Bel(A) ISO, Idle: Sound Pressure Level ≤30dB(A)

Print specifications

Learn about the print specifications.

Table 1-9 Print specifications

Item	Specification
Print speed (normal, A4/ Letter)	8601dn, z, z+ : 70 ppm
Resolution	1200 dpi
Print Languages	HP PCL 6, HP Postscript level 3 emulation, PDF (v 1.7), AirPrint™ compatible
Supported Network Protocols	IPv4/IPv6: Apple Bonjour Compatible (Mac OS 10.2.4 or higher), SNMPv1/v2c/v3, HTTP, HTTPS, FTP, TFTP, Port 9100, LPD, WS Discovery, IPP, Secure-IPP, IPsec/Firewall IPv6: DHCPv6, MLDv1, ICMPv6 IPv4: Auto-IP, SLP, Telnet, IGMPv2, BOOTP/DHCP, WINS, IP Direct Mode, WS Print Other: NetWare NDS, Bindery, ePrint
USB printing	Yes

Scan specifications

Learn about the scan specifications.

Table 1-10 Scan specifications

Item	Specification
Scan Speed (normal, A4)	MFP 8601dn models ADF: Simplex 90 ipm / Duplex 180 ipm MFP 8601z, models ADF: Simplex 150 ipm / Duplex 300 ipm MFP 8601z+ models ADF: Simplex 150 ipm / Duplex 300 ipm
Input capacity	MFP 8601dn models ADF: 75 gsm / 200 sheets MFP 8601z, z+ models ADF: 75 gsm / 300 sheets
Grayscale Levels	256
Scan File Format	Digital Send: Hi-Compression PDF, PDF, JPEG, TIFF, MTIFF, XPS, PDF/A Scan to easy access USB: Hi-Compression PDF, PDF, JPEG, TIFF, MTIFF, XPS, PDF/A Print from easy access USB: PDF, PS, JPEG, TIFF, PNG, Print Ready files (.prn, .pcl, .cht)

Table 1-10 Scan specifications (continued)

Item	Specification
Scan Size Maximum	ADF: 297 x 437 mm (11.7 x 17.2 in) Flatbed: 297 x 437 mm (11.7 x 17.2 in)
Scan Size Minimum	ADF: 148 x 210 mm (5.5 x 8.5 in)
Standard Media Size	ADF: Legal, Oficio, Executive, Statement, Ledger, A3, A4, A4R, A5, B4, B5, 16K • Width: 148 - 297 mm (5.8 - 11.7 in) • Length: 148 - 432 mm (5.8 - 17 in)
Media Weights	ADF: • Simplex: 60 to 128 g/m² (16 to 28 lb) • Duplex: 60 to 128 g/m² (16 to 28 lb)

Copy specifications

Learn about the copy specifications.

Table 1-11 Copy specifications

Item	Specification
Copy Speed (Normal, A4, default rate from flatbed or ADF)	MFP 8601dn, z, z+: 70 cpm
Copy Speed (Normal, Letter, default rate from flatbed or ADF)	MFP 8601dn, z, z+: 70 cpm
Copy Speed (Normal, A3, default rate from flatbed or ADF)	MFP 8601dn, z, z+: 35 cpm
Copy Resolution (Black Text)	Up to 600 x 600 dpi
Copier Reduce/enlarge	Flatbed: 25 to 400% ADF: 25 to 400%

Paper handling specifications

Learn about the paper handling specifications.

Table 1-12 **Paper handling specifications**

Item	Specification
Input Capacity	Tray 1: 100 sheets (80 gsm) Tray 2: 520 sheets (80 gsm) Tray 3: 520 sheets (80 gsm) Tray 4: 520 sheets (80 gsm) Tray 5: 520 sheets (80 gsm)
Custom Media Sizes	Tray 1: 98 x 139.7 mm (3.86 x 5.5 in) to 320 x 457 mm (12.6 x 18 in) Tray 2: 98 x 140 mm (3.86 x 5.51 in) to 297 x 390 mm (11.7 x 15.35) Tray 3: 140 x 182 mm (5.51 x 7.16 in) to 320 x 457 mm (12.6 x 18 in) Tray 4: 140 x 182 mm (5.51 x 7.16 in) to 320 x 457 mm (12.6 x 18 in) Tray 5: 140 x 182 mm (5.51 x 7.16 in) to 320 x 457 mm (12.6 x 18 in)
Standard Media Sizes	Tray 1: A3, A4, A4R, A5, A5R, A6, RA4, SRA4, B4 (JIS), B5 (JIS), B6 (JIS), 10x15cm, Oficio, 8K, 16k, Postcard (JIS), Dpostcard (JIS), Envelope B5, Envelop C5,Envelope C6, Envelope DL Tray 2: A4, A5, A6, B6, Letter, Statement, Envelope Monarch, Envelope DL, Envelope C5, Envelope C6, Envelope No. 10, Envelope No. 9, Custom (98 x 140 mm (3.86 x 5.51 in) to 297 x 390 mm (11.7 x 15.35)) B4 (JIS) Tray 3: SRA3, A3, A4, A5, B4, B5(JIS), B5(ISO), Tabloid extra, Ledger, Legal, Letter, Executive, Statement, 8K, 16K, Oficio, Folio, Custom (140 x 182 mm (5.51 x 7.16 in) to 320 x 457 mm (12.6 x 18 in)) Tray 4: SRA3, A3, A4, A5, B4, B5(JIS), B5(ISO), Tabloid extra, Ledger, Legal, Letter, Executive, Statement, 8K, 16K, Oficio, Folio, Custom (140 x 182 mm (5.51 x 7.16 in) to 320 x 457 mm (12.6 x 18 in)) Tray 5: SRA3, A3, A4, A5, B4, B5(JIS), B5(ISO), Tabloid extra, Ledger, Legal, Letter, Executive, Statement, 8K, 16K, Oficio, Folio, Custom (140 x 182 mm (5.51 x 7.16 in) to 320 x 457 mm (12.6 x 18 in))
Media types supported	Tray 1:, 2 Light, Plain, Mid-Weight, Heavy, Extra Heavy, PaperBoard, Mid-Wt Glossy, Cardstock, Envelope, Label, Transparency Tray 3, 4, 5: Light, Plain, Mid-Weight, Heavy, Extra Heavy, PaperBoard, Mid-Wt Glossy, Cardstock, Label, Transparency

Table 1-12 **Paper handling specifications (continued)**

Item	Specification
Media Weights	Tray 1, 2: • Light: 60~70 g/m² • Plain: 71~95 g/m² • Mid-weight: 96~110 g/m² • Heavy: 111~130 g/m² • Extra Heavy: 131~175 g/m² • PaperBoard: 221~255 g/m² • PaperBoard: 256~300 g/m² • PaperBoard: 301+ g/m² • Mid-Wt Glossy: 96~110 g/m² • Cardstock: 176~220 g/m² • Envelope: 76~120 g/m² • Label: 120~150 g/m² • Transparency: 138~146 g/m²
Media Weights	Tray 3, 4, 5: • Light: 60~70 g/m² • Plain: 71~95 g/m² • Mid-weight: 96~110 g/m² • Heavy: 111~130 g/m² • Extra Heavy: 131~175 g/m² • PaperBoard: 221~255 g/m² • PaperBoard: 256~300 g/m² • PaperBoard: 301+ g/m² • Mid-Wt Glossy: 96~110 g/m² • Cardstock: 176~220 g/m² • Envelope: 76~120 g/m² • Label: 120~150 g/m² • Transparency: 138~146 g/m²
Standard Media Sizes (duplex)	139.7 x 182 mm (5.5 x 7.16 in) to 320 x 457 mm (12.6 x 18 in)
Media Weights (duplex)	60 to 300 g/m²
Media types supported (duplex)	Light, Plain, Mid-Weight, Heavy, Extra Heavy, PaperBoard, Mid-Wt Glossy, Cardstock

Table 1-13 **Paper trays and accessories**

Trays and accessories	Availability
Tray 1 (100-sheet capacity)	Included
Tray 2 (520-sheet capacity)	Included
Tray 3 (520-sheet capacity)	Included
Tray 4 (520-sheet capacity)	Included
Tray 5 (520-sheet capacity)	Included
Stapler/stacker finishing accessory (FLOW MFP 8601z+ Only)	Included
HP Second exit	Included
Fax Kit - (MFP 8601dn)	Optional
Fax Kit - (MFP 8601z)	Included
Fax Kit - (MFP 8601z+)	Included
BLE/NFC/Wireless Kit - Optional	Optional

Supplies

Learn about the supplies.

Table 1-14 **Supplies**

Item	Product number	Average yield
HP 176A Black Original Toner Cartridge	W1760A	Approx. 45,000 pages
HP 176A Black Original Imaging Drum	W1766A	600,000 pages
HP LaserJet Toner collection unit (TCU)	9U1Q5A	300,000 pages

[1]Print cartridge life is approximate, based on average A4 /Letter-size page count with ISO coverage. Declared cartridge yield value in accordance with ISO/IEC 19752. Actual yields vary considerably based on images printed and other factors. For more information, visit www.hp.com/go/learnaboutsupplies.

NOTE: Depending on the print pattern and job mode used, the lifespan of the consumable can vary.

IMPORTANT: Toner cartridges or other supplies must be purchased in the same country/region as the printer being used. Otherwise, new toner cartridges or other supplies will be incompatible with the printer. This is due to differing configurations of toner cartridges and other supplies according to the conditions of a specific country/region.

Maintenance parts (Long Life Consumables (LLC))

Learn about the printer maintenance parts.

HP recommends replacing the following maintenance parts at specific intervals to make sure the printer produces quality copies and to extend the service life of the printer.

Some of the printer parts have a shorter lifespan than the life of the printer.

Table 1-15 **Maintenance parts**

Item	Service part number	Life
Developer unit - Black	5PN82-67002	1,200,000 pages
HP 176A Black Original Imaging Drum	W1766-67001	600,000 pages
Fuser unit - 100V Kit NOTE: Only for Japan	5PN53-67001	600,000 pages
Fuser unit - 110V Kit	5PN76-67001	600,000 pages
Fuser unit - 220V	5PN77-67001	600,000 pages
Paper transfer belt (PTB) unit	5PN85-67001	600,000 pages
Pickup/ Forward/ Reverse (separation) roller (for Tray 2-X)	5PN66-67001	360,000 pages
Tray 1 (MP) Pickup/ Forward/ Reverse (separation) Roller	5RC03-67001	200,000 pages
ADF roller kit (z, z+ bundle)	A91Z5-67001	300,000 pages
ADF roller kit (dn bundle)	5851-7202	150,000 pages

NOTE: Depending on print patterns and the job mode used, maintenance part lifespans vary. See *Replacing the maintenance part* for further instructions.

Network and software specifications

Learn about the network and software specifications.

Network interface

Learn about the network interface.

Network OS

Windows

- Windows 10
- Windows 11
- Windows Server 2008 R2
- Windows Server 2012
- Windows Server 2012 R2
- Windows Server 2016
- Windows Server 2019

Mac

- macOS 12(Monterey)
- macOS 11(Big Sur)

- macOS 10.14(Mojave)
- macOS 10.15(Catalina)

Linux

- CentOS 8, 64-bit
- Ubuntu 20.04.2.0 LTS
- Fedora 33
- Red Hat Enterprise Linux 8

Others

- Unix (HP-UX, Solaris, SunOS, SCO)

Table 1-16 Network interfaces

Type	Protocol	Details
Network Protocol	TCP/IP	TCP/IPv4, HTTP, SNMPv1/v2c/v3, LDAP, SMTP, SSL/TLS, IPSec, DNS, WINS, SLP, Bonjour, SSDP, DDNS, DHCP/BOOTP, IPv6
Network Protocol	NetBIOS over TCP/IP	Supported
Network Protocol	Others	HTTPS, IPSec, 802.1x
IP Addressing	Static IP	Supported
IP Addressing	Auto IP	Supported
IP Addressing	BOOTP	Supported
IP Addressing	DHCP	Supported
SNMP/MIB Access	MIB-2 (RFC 1213)	Supported
SNMP/MIB Access	Host Resource MIB (RFC 2790)	Supported
SNMP/MIB Access	Printer MIB (RFC 3805)	Supported
SNMP/MIB Access	Finisher MIB (RFC 3806)	Supported
SNMP/MIB Access	HP Compatibility	Supported partially
SNMP/MIB Access	SNMP Trap	Supported
Printing Protocols	Windows Printing (SMB)	Not supported
Printing Protocols	LPR/LPD	Supported
Printing Protocols	IPP	Supported
Printing Protocols	Port 9100	Supported
Device Discovery	DNS	Supported
Device Discovery	Dynamic DNS	Supported
Device Discovery	Multicast DNS (Bonjour)	Supported
Device Discovery	WSD (including Print and Scan)	Supported (Print and Scan)
Device Discovery	SLP	Supported

Table 1-16 Network interfaces (continued)

Type	Protocol	Details
Device Discovery	uPNP (SSDP)	Supported

Options

Learn about printer options and accessories.

Option specifications

Learn about option specifications.

Table 1-17 HP LaserJet Dual Cassette Department Feeder option specifications

Item	Specification
Capacity	520 x 2 sheets
Media sizes	• Tray 4: 139.7 mm x 182 mm – 320 mm x 457.2 mm (5.5 in x 7.17 in – 12.59 in x 18 in) • Tray 5: 139.7 mm x 182 mm – 320 mm x 457.2 mm (5.5 in x 7.17 in – 12.59 in x 18 in)
Media types	Thin/Plain/Thick/Heavy Weight/Extra Heavy Weight/Letterhead/Pre-Printed/Hole Punched/Colored/Bond/Recycled
Media weight	• Light: 60~70 g/m² • Plain: 71~95 g/m² • Mid-weight: 96~110 g/m² • Heavy: 111~130 g/m² • Extra Heavy: 131~175 g/m² • PaperBoard: 221~255 g/m² • PaperBoard: 256~300 g/m² • PaperBoard: 301+ g/m² • Mid-WtGlossy: 96~110 g/m² • Cardstock: 176~220 g/m² • Envelope: 76~120 g/m² • Label: 120~150 g/m² • Transparency: 138~146 g/m²
Sensing	• H/W install detect: Yes • Paper empty and low level detect: Yes • Paper type detect: No • Paper size detect: Yes
Dimensions	585 mm x 694.6 mm x 312.2 mm (23 in x 27 in x 12 in)
Weight	Net 28.5 kg (62.8 lb), packing 32 kg (70.5 lb)

Table 1-18 HP LaserJet Stapler/Stacker Finisher option specifications

Item	Specification
Capacity	65 sheets stapling, 3,250 sheets stacking
Staple cartridge capacity	5000 staples/cartridge
Stacking	• Top tray: 250 sheets (A4/LT at 80 grams per square meter) • Finishing tray: 3000 sheets (A4/LT at 80 grams per square meter)
Stapling	• Maximum number of sheets: 65 sheets stapling with 90 grams per square meter sheet • Stapling positions: 2 corners (single, 45 degree), center (double)
Offline stapling	Yes
Offset at non-staple job	Yes
Offset at staple job	N/A
Output stacking	Face down

Table 1-19 HP LaserJet Booklet Finisher option specifications

Item	Specification
Capacity	65 sheets stapling, 2000 sheets stacking
Staple cartridge capacity	5000 staples/cartridge
Stacking	• Top tray: 250 sheets (A4/LT at 80 grams per square meter) • Finishing tray: 2000 sheets (A4/LT at 80 grams per square meter)
Stapling	• Maximum number of sheets: 65 sheets stapling with 90 grams per square meter sheet • Stapling positions: 2 corners (single), center (double)
Saddle stapling	Maximum number of sheets: 25 sheets stapling with 80 grams per square meter sheet
Offline stapling	Yes
Offset at non-staple job	Yes
Offset at staple job	N/A
Output stacking	Face down

Table 1-20 HP LaserJet Hole Punch Accessory option specifications

Item	Specification
Part number	HP LaserJet Hole Punch 2/3 Accessory: Y1G10-67901
Available unit	Auto change 2/3 hole or auto change 2/4 hole
Media weight	52–300 grams per square meter

Table 1-21 **Other options**

Part	Part number
HP Accessibility Assistant	478C2A
HP Removable Hard Drive Enclosure	2NR12A
HP Accessibility Kit	2TD64A
HP JetDirect 3100w BLE/NFC/Wireless Accy	3JN69A
HP Legic Reader	4QL32A
HP Internal USB Ports	4XN67A
HP LaserJet Workflow Accelerator Card(z model only)	6HN30A
HP Secure Ultimate Performance TAA Hrd Disk Drive	6HN31A
HP MFP Analog Single Fax 800 Accessory	7ZA08A
HP MFP Analog Single Fax 801 Accessory (BBU only)	7ZA09A
HP Jetdirect LAN Accessory	8FP31A
HP Secure Ultimate Performance Hard Disk Drive	9EQ11A
HP Foreign Interface Harness	B5L31A
HP SmartCard NIPRNet Solution for US Government	CC543B
HP SmartCard SIPRNet Solution for US Government	F8B30A
HP USB Universal Card Reader	X3D03A
HP Card Reader Rotation Adapter Kit[1]	63C82-67029
HP HIP2 Keystroke Reader	Y7C05A
HP SIM for HID iClass for HIP2 Reader	Y7C07A

[1] The Card Reader Rotation Adapter Kit is helpful when the card insertion angle/direction is not aligned with the card reader.

2 Product installation and maintenance

You will learn more about product installation and maintenance.

Product installation

For more information about hardware, engine, and accessory installation for the printer, review the following document.

HP LaserJet Managed MFP - Installation Guides

Maintenance

Learn about preventive maintenance and printer cleaning procedures.

PM table (Preventive Maintenance)

HP recommends cleaning and checking the following maintenance items at the specified intervals.

Some easy items are strongly recommended to be executed during every visit, regardless of the page count, to make sure the printer produces quality copies and to extend the service life of the printer. Also, HP recommends inspecting consumable parts and replacing if needed to reduce the visit count. After replacing, a counter reset should be done to make sure the next replacement window is clear.

NOTE:

- Depending on the printing patterns and the job mode used, consumable part lifespans vary.
- Toner cartridges and the Toner Collection Unit are excluded from this table because they are classified as supplies, not long life consumables (LLCs).

In the table below, the following abbreviations are used:

- **C**: Clean
- **I**: Inspect
- **R**: Replace

The counts below indicate the recommended engine counter value for each item (Engine life 3,600K).

Table 2-1 Preventative Maintenance

Type	Item	360K	600K	1200K 2400K 3600K	1800K	3000K	Notes
Clean/Inspect	Paper dust holder		C	C	C	C	
	CTD Sensor		C	C	C	C	Mandatory after OPC or Deve unit replaced
	Scanner glass	C	C	C	C	C	Recommended at every visit
	ADF CIS (Contact Image Sensor)	C	C	C	C	C	Recommended at every visit
	Deve guide plate	I/C	I/C	I/C	I/C	I/C	Check for contamination, and then clean if necessary.
	Paper guide adjustment check in Trays	I	I	I	I	I	Recommended at every visit

Table 2-1 Preventative Maintenance (continued)

Type	Item	360K	600K	1200K 2400K 3600K	1800K	3000K	Notes
Consumable check	K OPC		I/R	I/R	I/R	I/R	
	Image transfer belt		I/R	I/R	I/R	I/R	
	Fuser		I/R	I/R	I/R	I/R	
	K Deve units			I/R			
	Roller kit for Tray 1	I/R	I/R	I/R	I/R	I/R	Recommended at every visit
	Roller kit for Tray 2-x	I/R	I/R	I/R	I/R	I/R	Recommended at every visit
	ADF Roller kit	I/R	I/R	I/R	I/R	I/R	Recommended at every visit

Cleaning


Use the procedures below to carry out regular cleaning procedures.

Cleaning the paper dust holder


Learn about cleaning the paper dust holder.

The paper dust holder cleaning is recommended at every 600K pages. Be aware that clean the paper dust holder message does not appear to avoid interrupting customer usage. Thus, technicians need to do this task actively. Use the following procedure to complete this task.

1. Remove Trays 2 and 3 from the printer. To remove them, pull the tray almost all of the way out of the printer, and then lift it up to remove it.



2. Remove the paper dust holder. To remove it, locate the handle and pull it in the direction shown by arrow below.






3. Clean the Paper dust holder, and then reassemble it.



4. Insert the paper dust holder back into the printer. When replacing it, push it back in to the same location until you feel it click into place.




5. Insert Trays 2 and 3 back into the printer.

Cleaning the CTD sensor


Use the following procedure to clean the CTD sensor.

The CTD sensor is designed to be cleaned automatically by each paper pass. However, it is strongly recommend that manual cleaning take place during every visit in order to maintain quality copies. Note that once the OPC or Developer unit is replaced, manual cleaning is required in order to clear contamination which might be caused during those replacements.


1. Open the right door.



2. Locate the CTD sensor handle.



3. Clean the sensor by sliding the handle left and right several times.




4. Close the right door.

Cleaning the scanner glass

It is recommended that the scanner glass be cleaned during every maintenance visit. Use the following procedure to complete this task.

1. Open the ADF by lifting it up.
2. Clean the image scanner area and flat-bed glass using a lint-free cloth.



3. Close the ADF.

Cleaning the ADF CIS (Contact Image Sensor)

It is recommended that the ADF CIS (Contact Image Sensor) be cleaned during every maintenance visit. Use the following procedure to complete this task.

1. Open the ADF by lifting it up.

2. Clean the CIS scanning area, located underneath ADF, using a lint-free cloth.



3. Close the ADF.

Cleaning the deve plate guide

Learn about cleaning the deve plate guide.

Inspect the deve plate guide for contamination at every engine counter preventative maintenance visit, and then clean it if necessary. Cleaning the plate guide helps to prevent image quality issues (for example, background).


Use the following procedure to complete this task.

TIP: Cleaning the deve plate guide requires removing the OPC and Deve which is a time consuming activity. Always inspect the plate guide for contamination first, and then only clean the plated guide if it is dirty. If there is no contamination, cleaning is not required.

1. Remove the OPC.
2. Inspect the deve plate guide for contamination.

NOTE: If the deve plate guide is not contaminated, skip the remaining steps.


Figure 2-1 Check for contamination



3. If the deve plate guide is contaminated, do the following to clean it.
   a. Remove the developer unit.
   b. Clean the surfaces of the plate.

TIP: To increase access to the plate, open the right door.

Figure 2-2 Clean the plate



Inspection procedures

Use the following procedures to inspect the printer during maintenance visits.


Inspect paper guide adjustment in trays

Checking paper guide adjustment and paper loading status is recommended during every visit. This is important in order to reduce paper jams. Many paper jams occur due to incorrect paper stacking in the trays.

1. Fan the paper.



2. Load the paper. Make sure the paper guides are correctly adjusted.



Inspect consumables (LLC life remaining)

The check of consumable life remaining is recommended at every visit so that the LLC is replaced at the proper time, and does not exceed its end of life. Active replacement is recommended if the LLC life remaining low. This will maintain the expected print quality and, also help to reduce extra visits.

Find the Print Supplies information report by using the following control panel menu navigation:

1. Select the following control panel menus:

- Support tools
- Service (Enter Pin: 03086025)
- Advanced service
- Service reports

2. Select Supplies information report and click the Print button.

Check the life remaining for each LLC in the Supplies information report. Refer to the following LLC (Long life consumable) list.

Table 2-2 Long life consumables (LLCs)

Item	Service part number	Life	Remark
Developer unit - Black	5PN82-67002	1,200,000 pages	
HP 176A Black Original Imaging Drum	W1766-67001	600,000 pages	Manual counter reset
Fuser unit - 100V Kit NOTE: Only for Japan	5PN53-67001	600,000 pages	Only for Japan
Fuser unit - 110V Kit	5PN76-67001	600,000 pages	
Fuser unit - 220V	5PN77-67001	600,000 pages	
Paper transfer belt (PTB) unit	5PN85-67001	600,000 pages	Manual counter reset
Pickup/ Forward/ Reverse (separation) roller (for Tray 2-X)	5PN66-67001	360,000 pages	Manual counter reset
Tray 1 (MP) Pickup/ Forward/ Reverse (separation) Roller	5RC03-67001	200,000 pages	Manual counter reset
ADF roller kit (z, z+ bundle)	A91Z5-67001	300,000 pages	Manual counter reset
ADF roller kit (dn bundle)	5851-7202	150,000 pages	Manual counter reset

NOTE: Maintenance part lifespans will vary depending upon printing patterns and the job mode used.

Maintenance (remove and replace)

Use the following links to see removal and replacement procedures for long-life consumables (LLCs).

- Black OPC (Drum) on page 840
- Image transfer belt (Paper Transfer Belt (PTB)) on page 543
- Fuser unit on page 880
- Black Developer unit on page 843
- Pickup, forward, separation roller (Tray1) on page 384
- Pickup, forward, and separation rollers (Trays 2-x) on page 399
- ADF roller kit (for 200-sheet Growler+ ADF) on page 1117

- ADF roller kit (for 300-sheet Valiant ADF) on page 1049

Counter reset after LLC replacement

The LLCs listed below require their counter reset manually after replacement. LLCs not listed here have EEPROM/CRUM counters that are reset automatically.

- Image transfer belt (**use steps 1 and 2**)
- Black Developer unit (**use steps 1 and 2**)
- Pickup/Forward/Separation roller (for Tray 2-x) (**use steps 1 and 2**)
- Pickup/Forward/Separation roller (for Tray1) (**use steps 1 and 2**)
- ADF roller kit (for 200-sheet dn bundle ADF or 300-sheet z, z+ bundle ADF) (**use steps 3 and 4**)

Reset the counter from the control panel using the following instructions.

1. **For all LLCs except the ADF roller kit**: Select the following menus:
   - Support tools
   - Service (Enter Pin: 03086025)
   - Reset supplies
2. Select the LLC being replaced, and then click the Reset button.
3. **For the ADF roller kit LLC only**: Select the following menus:
   - Settings
   - Manage Supplies
   - Reset supplies
4. Select the Document Feeder Kit item, and then click the Reset button.

3 Problem solving

Learn about problem solving.

General troubleshooting guide

Learn about general troubleshooting.

Troubleshooting process

Learn about the troubleshooting process.

Determine the problem source

When the printer malfunctions or encounters an unexpected situation, the printer control panel alerts you to the situation. This section contains a pre-troubleshooting checklist to filter out many possible causes of the problem. A troubleshooting flowchart helps you diagnose the root cause of the problem. The remainder of this chapter provides steps for correcting problems.

- Use the troubleshooting flowchart to pinpoint the root cause of hardware malfunctions. The flowchart guides you to the section of this chapter that contains steps for correcting the malfunction.

Before beginning any troubleshooting procedure, check the following issues:

- Are supply items within their rated life?
- Are supply items Genuine HP supplies?
- Does the configuration page reveal any configuration errors?

NOTE: The customer or service provider is responsible for checking supplies and for using supplies that are in good condition.

Power subsystem

Learn about the power subsystem.

Power-on checks

The basic printer functions should start up when the printer is connected into an electrical outlet and the power switch is pushed to the *on* position. If the printer does not start, use the information in this section to isolate and solve the problem.

If the control-panel display remains blank, random patterns display, or asterisks remain on the control-panel display, perform power-on checks to find the cause of the problem.

Power-on troubleshooting overview

If the control panel is blank 1 minute after turning on the printer, check the following items:

During normal operation, a cooling fan begins to spin briefly after the printer power is turned on. Place your hand over the vents at the rear of the printer, next to the formatter, or on the on the rear of the scanner. If the fan is operating, you will feel air passing out of the printer. You can lean close to the printer and hear the fan operating.

A fan begins to blow on the right door (fuser), and then the control panel goes through a series of set up functions. The main motor turns on (unless the left door or cartridge access door is open, a jam condition is sensed, or the paper-path sensors are damaged). You might be able to visually and audibly determine if the main motor is turned on.

If the fan and main motor are operating correctly, the next troubleshooting step is to isolate print engine, formatter, and control panel problems.

1. Make sure that the printer is connected directly into an active electrical outlet (not a power strip) that delivers the correct voltage.
2. Make sure that the power switch is in the *on* position, and then verify that the LED is on.
3. Make sure that the fan runs briefly, which indicates that the power supply is operational.
4. Depress the button on the back of the control panel to test the control panel functionality.
5. Make sure that the control-panel display wire harness is connected.
6. Remove any external solutions, and then try to turn the printer on again.

Troubleshooting a blank display, black display, no display, or no power situation

Customers usually report that the control-panel display is not showing anything. It is very important to collect as much information as possible from the customer about the issue to help resolve it.

Following are some printer behaviors the customer might encounter:

- The control panel is completely blank (no LEDs or back light).
- The control panel is blank, but there might be LEDs illuminated.
- The control panel is blank (LEDs are on or flashing) and the back light is on (but no text visible).

Following are some possible causes of a blank control-panel display:

- No power to the printer.
- The control panel contrast setting is not correctly adjusted.
- The formatter connector(s) are not fully seated into the connector(s) on the DC controller, or the connectors are not fully seated on the formatter.
- A faulty component is installed on the formatter (for example a memory DIMM, fax PCA, network PCA, USB device, or other component).
- The formatter is defective.
- The control panel connector is not fully seated, or the control panel is defective.
- The DC controller is defective.

Following are some questions to ask the customer:

- Was the printer newly install or has the printer been properly functioning?
  - For a new install, investigate to see if there was any shipping damage to the printer.
  - Did the customer notice any damage to the shipping box or any visible damage to the printer?
- What happened just prior to the control panel going blank?
  - Was the printer serviced recently, a power outage occurred?
  - Has a lightning storm recently occurred?
  - Did the customer recently add a memory DIMM or install a third-party component?
- Make sure to get a complete description of the failure.

- Is the control-panel display completely blank (might be faint text and no back light)?
- Is the control-panel display back light on?
- Has a print job been sent to the printer? The customer might report that their print jobs seemed to print but when they go to the printer the control-panel display is blank.

Recommended actions

If the control-panel display is completely blank (no LEDs illuminated or no back light) check to see if the printer is getting power. Listen for fans or any printer initialization sounds when the power is turned on.

If there are no signs of power, then perform the following:

1. Make sure that the printer is plugged directly into an active electrical outlet (not a power strip or interruptible power supply) that delivers the correct voltage.

   TIP: Try using a different power cable if possible.

2. Turn the printer power on, and make sure that the fan(s) run briefly (this indicates that the power supply is operational).
3. Check if the yellow LED on formatter is flashing. If so, there is a communication issue between the formatter and the control panel.
4. Turn the printer power off.
5. Make sure that the control-panel display wire harness (and/or flat cable) is properly connected (and fully seated), and then turn the printer power on again.
6. Check control panel diagnostics by pressing the button on the back of the control panel to run different diagnostic tests.
7. Verify the status LEDs are illuminated, but the control-panel display is blank. If applicable: Check if the contrast setting is adjusted to very low. If so, try turning the contrast knob to see if the control-panel display becomes visible.
8. From a host computer, send a print job to the printer.

   NOTE: If the print job correctly prints, then the problem is most likely to a defective control panel.

9. Turn the printer power off, and then make sure that the memory DIMM is installed in the correct slot and is fully seated.

   NOTE: For some printers, there may be more than one memory DIMM installed. Some printers have third-party solutions/applications or fonts that use memory.

10. Remove all of the components/accessories installed on the formatter (for example, hard drive, solid-state drive, memory DIMM(s), fax PCA, network PCA, USB devices, or other devices).
    - Make sure that the formatter is fully seated.

      IMPORTANT: This is important because the formatter or a component on the formatter might be defective or shorted, which causes the printer to lose power.

11. Reinstall the formatter. Make sure that it makes a good connection and is fully seated.

    Make sure that all of the connectors on the formatter are correctly connected and fully seated.

12. Turn the printer power on, and then check the control-panel display.
13. If the printer control panel is properly working, replace each removed component (one at a time) to determine which one is causing the problem.

> ⚠ **CAUTION:** Turn the printer power off, and then on again, after replacing a component on the formatter.

14. If the control-panel display is still blank after performing the above troubleshooting steps, and the control panel diagnostics do not function, replace the control panel. If the control panel diagnostics are functioning, then replace the formatter.

Control panel checks

Learn about the control panel checks.

Control panel diagnostic flowcharts

Learn about the control panel diagnostic flowcharts.

Use the flowcharts in this section to troubleshoot the following control panel problems.


- Touchscreen is blank, white, or dim (no image).
- Touchscreen is slow to respond or requires multiple presses to respond.
- Touchscreen has an unresponsive zone.
- No control panel sound.
- Hardware integration pocket (HIP) is not functioning (control panel functional).

Touchscreen black, white, or dim (no image)

Learn about the touchscreen black, white, or dim (no image).

> **NOTE:** To open the diagnostic function, press the button on the back of the control panel.

Figure 3-1 Touchscreen blank, white, or dim (no image)




Touchscreen has an unresponsive zone

Learn about how the touchscreen has an unresponsive zone.

NOTE: To open the diagnostic function, press the button on the back of the control panel.

Figure 3-2 Touchscreen has an unresponsive zone




No control panel sound

Learn what to do when there is no control panel sound.

NOTE: To open the diagnostic function, press the button on the back of the control panel.


Figure 3-3 No control panel sound



Hardware integration pocket (HIP) is not functioning (control panel functional)

Learn about when the hardware integration pocket (HIP) is not functioning (control panel functional).

Figure 3-4 Hardware integration pocket (HIP) is not functioning (control panel functional)



Individual component diagnostics

Learn about individual component diagnostics.

Tools for troubleshooting: LED diagnostics

LED, engine, and individual diagnostics can identify and troubleshoot printer problems.

Understand lights on the formatter

Three LEDs on the formatter indicate that the printer is functioning correctly.

Figure 3-5 LEDs




Table 3-1 LEDs

Item	Description
1	Heartbeat LED
2	HP Jetdirect LEDs

HP Jetdirect LEDs

Learn about the HP Jetdirect LEDs.

The embedded HP Jetdirect print server has two LEDs. The yellow LED indicates network activity, and the green LED indicates the link status. A blinking yellow LED indicates network traffic. If the green LED is off, a link has failed.

For link failures, check all the network cable connections. In addition, try to manually configure the link settings on the embedded print server by using the printer control-panel menus.

1. From the Home screen on the printer control panel, select **Settings**.
2. Open the following menus:
   - **Networking**
   - **Ethernet**
   - **Link Speed**
3. Select the appropriate link speed, and then select **OK**.

Tools for troubleshooting: Engine diagnostics

The printer contains extensive internal engine diagnostics that help in troubleshooting print quality, paper path, noise, assembly, and timing issues.

Defeating interlocks

Different tests can be used to isolate different types of issues. For assembly or noise isolation, run the diagnostic test when the toner cartridge door or right door is open.

Defeating the door interlocks allows observation of the paper pick operation (and view the page enter registration).

⚠ **WARNING!** Be careful when performing printer diagnostics to avoid risk of injury. Only trained service personnel should open and run the diagnostics with a door open. Never touch any of the power supplies when the printer is turned on.


Defeat the toner cartridge door interlock

Learn how to defeat the toner cartridge door interlock.

1. Open the toner cartridge door.
2. Insert a folded piece of paper into the slot.

TIP: Fold a stiff piece of paper, for example a business card or index card, into two 10 mm (.375 in) strips, and insert the strips into the slot for the cartridge door logic switches.

Figure 3-6 Defeat the toner cartridge door interlock




Defeat the right door interlock

Learn how to defeat the right door interlock.

1. Open the right door.
2. Insert a folded piece of paper into the slot.

TIP: Fold a stiff piece of paper, for example a business card or index card, into two 10 mm (.375 in) strips, and insert the strips into the slot for the front door logic switches.

Figure 3-7 Defeat the right door interlock



Tools for troubleshooting

Use the procedure below to test various printer mechanical and electromechanical assemblies.

Individual component diagnostics (special-mode test)

Learn about the individual component diagnostics (special-mode test).

This test activates individual parts independently to isolate problems.

Each component test can be performed once or repeatedly.

Each component test can be performed once or repeatedly.

NOTE: The cartridge door interlocks must be defeated to run the component tests.

1. From the Home screen on the printer control panel, scroll to and touch the Support Tools button.
2. Select one of the following tests:
   - Continuous Scan
   - Run Fax Test
3. Select the component test options for the test.

Tools for troubleshooting

Learn about tools for troubleshooting.

Problem-solving checklist

Follow these steps when trying to solve a problem with the printer.

Step 1: Check that the printer power is on

Learn how to check that the printer power is on.

1. Make sure that the printer is plugged in and turned on. The power button should be lit with a white light. If it is not, press the power button. If the power button does not light up, check the following conditions.
   - Make sure that the power cable is connected to the printer and the outlet.
   - Check the power source by connecting the power cable to a different outlet.
2. If the printer motors do not rotate, make sure that the toner cartridges are installed and that the doors are all closed. The control panel displays messages to indicate these problems.

Step 2: Check the control panel for error messages

Learn how to check the control panel for error messages.

The control panel should indicate ready status. If an error message appears, resolve the error.

Print a supplies status page to ensure that the supplies are not at or over end of life.

NOTE: HP long-life consumable and maintenance kit life specifications are estimations. Actual individual life or yield during normal use will vary depending on usage, environment, media, and other factors. Estimated life is not an implied warranty.

Step 3: Test print functionality

Learn how to test print functionality.

1. From the control panel Home screen, touch the Reports button.
2. Open the Reports menu, touch the Configuration/Status Pages menu, select the Configuration Page item, and then touch the Print button to print the report.
3. If the report does not print, make sure that paper is loaded in the tray, and check the control panel to see if paper is jammed inside the printer.

NOTE: Make sure that the paper in the tray meets specifications for this printer.

Step 4: Test copy functionality

Learn how to test copy functionality.

1. Place the configuration page into the ADF and make a copy. If paper does not feed smoothly through the ADF, you might need to clean the ADF rollers and separation pad. Make sure that the paper meets specifications for this printer.
2. Place the configuration page onto the scanner glass and make a copy.
3. If the print quality on the copied pages is not acceptable, clean the scanner glass and the small glass strip.

Step 5: Test the fax sending functionality

Learn how to test the fax sending functionality.

1. From the control panel Home screen, touch the Support Tools button.
2. Open the Troubleshooting menu, and then open the Diagnostics Tools menu. Touch the Run Fax Test button to test the fax functionality.
3. Touch the Fax on the printer control panel, and then touch the Start Fax button.

Step 6: Test the fax receiving functionality

Learn how to test the fax receiving functionality.

1. From the control panel Home screen, touch the Support Tools button.
2. Touch the Troubleshooting menu, and then open the Diagnostics Tests menu. Touch the Run Fax Test button to test the fax functionality.
3. Use another fax machine to send a fax to the printer.
4. Review and reset the printer fax settings.

Step 7: Try sending a print job from a computer

Learn how to try sending a print job from a computer.

1. Use a word-processing program to send a print job to the printer.
2. If the job does not print, make sure that you selected the correct printer driver.
3. Uninstall and then reinstall the printer software.

Step 8: Test the Plug and Print USB Drive printing functionality

Learn how to test the plug and print USB drive printing functionality.

1. Load a .PDF document or .JPEG photo onto a USB flash drive, and insert it in the USB port near the control panel.
2. The USB Flash Drive menu opens. Try printing the document or photo.
3. If no documents are listed, try a different type of USB flash drive.

Factors that affect printer performance

Several factors affect the time it takes to print a job:

- The software program that you are using and its settings
- The use of special paper (such as heavy paper or custom-size paper)
- Printer processing and download time
- The complexity and size of graphics
- The speed of the computer you are using
- The USB or network connection
- Whether the printer is printing in color or in monochrome
- The type of USB drive, if you are using one
- Environmental factors, such as low temperature or high humidity

Print menu map

Learn how to print the menu map.

To more easily navigate individual settings, print a report of the complete Reports menu.

1. From the Home screen on the printer control panel, scroll to and touch the Reports button.
2. Open the Configuration/Status Pages menu.
3. Select the Settings Menu Map option.
4. Touch the Print button to print the report.

TIP: Multiple report pages can be selected, and then printed together.

Print current settings pages

Learn how to print current settings pages.

Printing the current settings page provides a map of the user configurable settings that might be helpful in the troubleshooting process.

1. From the Home screen on the printer control panel, scroll to and touch the Reports button.
2. Open the Configuration/Status Pages menu.
3. Select the Current Settings Page option.

4. Touch the Print button to print the report.

TIP: Multiple report pages can be selected, and then printed together.

Additional tools for troubleshooting

Find additional troubleshooting topics.

Use the links below to go to additional troubleshooting tools topics.

- Pre-boot menu options

  See Pre-boot menu options on page 79.

- Event log (display and print)

  See Event Log on page 224.

Remote Admin

The Remote Admin feature allows remote access the printer Pre-boot menu (BIOS environment). The printer functions as a telnet server which uses the telnet networking protocol to transmit text data. Any computer (with telnet installed and enabled) can function as the telnet client to remotely display and interact with the Pre-boot menu.

IMPORTANT: While the Remote Admin function allows remote access the Pre-boot menu, for security reasons the Remote Admin connection must be initiated by a person that is physically present at the printer.

This section describes the following Remote Admin items.

Required software and network connection

Before using the Remote Admin feature, make sure that the telnet network protocol is installed, and enabled, on the remote telnet client computer.

NOTE: This section describes enabling and configuring the telnet feature for computers using a Windows® operating system.

HP recommends that the telnet client computer be a Windows based system, however, there are other operating systems that support the telnet network protocol. For information about enabling and configuring the telnet network protocol for other operating systems, see the owner's manual for that operating system.


Telnet client

All computers using the Windows operating system have the telnet client installed, however, the telnet client function might not be enabled by default.

NOTE: The figures and menus in this section are for the Windows 7 Enterprise® operating system. Screens and menu selections might vary slightly for other operating systems.


1. Use the **Start** menu to open the **Control Panel**, and then click the **Programs** item to select it.

Figure 3-8 Open the Control Panel



2. Click the **Turn Windows features on or off** item to select it.


Figure 3-9 Turn Windows features on or off



3. In the **Windows Features** box, scroll down to **Telnet Client**. If the check box is not checked, click the box to select it, and then click the **OK** button.

TIP: If the check box is already checked then the telnet client function is already enabled. Click the **Cancel** button.

Figure 3-10 Enable the telnet client feature



Network connection

The remote telnet client computer must have direct network access to the printer for the Remote Admin function to operate. This means that the telnet client computer must be on the same network as the printer. The Remote Admin function cannot be accessed through a network firewall or other remote access network security programs.

If a private network is not accessible, ask the network administrator to set up a virtual private network (VPN) connection to the network.

Connect a remote connection

Learn how to connect a remote connection using telnet.

Start the telnet server function at the printer


For security reasons the Remote Admin feature must be initiated by a person that is physically present at the printer. The following steps must be performed by a person that is physically present at the printer.

NOTE: This person might need to sign in with an administrator or service password depending on how the printer is configured.

1. Turn the printer on.
2. The HP logo displays on the printer control panel. When a "1/8" with an underscore displays, touch the middle of the screen to open the Pre-boot menu.


3. Use the arrow buttons on the touchscreen to scroll down and highlight the **+3:Administrator** item, and then touch the OK button to select it.

Figure 3-11 **Select the +3:Administrator item**



4. Use the arrow buttons on the touchscreen to scroll down and highlight the **+A:Remote Admin** item, and then touch the OK button to select it.

Figure 3-12 **Select the +A:Remote Admin item**



5. Use the arrow buttons on the touchscreen to scroll down and highlight the **1:Start Telnet** item, and then touch the OK button to select it.


Figure 3-13 **Select the 1:Start Telnet item**



6. Do one of the following

- If a connecting message displays briefly, go to step 7.

  Figure 3-14 **Telnet connecting message**

- If an error message displays, use the steps below to identify the problem.

Figure 3-15 Telnet error message



a. The printer network cable is not correctly connected.

b. The BIOS LAN settings are incorrect.

   - The printer should be configured to use a static IP address, but is configured to use DHCP instead.
   - The printer is configured to use a static IP address, but the IP address is incorrect.


c. The printer is correctly configured to use DHCP, but the DHCP server is not turned on or is malfunctioning.

7. When the printer telnet server function is initialized, the following screen appears. Use the information on this screen to connect the remote telnet client computer to the printer.

NOTE: The printer is now ready to receive remote telnet client commands.

- **IP**: The static or dynamically allocated IP address for the printer.
- **Port**: The standard telnet port (23).
- **Pin**: A randomly generated 4-digit personal identification number (PIN).

Figure 3-16 Telnet server function initialized




Start the telnet client function at the remote computer

The following steps establish a Remote Admin connection from a remote computer to the printer.


1. From the **Start** menu click **Run** to open a dialog box, type `cmd` in the **Open** field, and then click the **OK** button to open a Windows command window.

Figure 3-17 Open a command window



2. From any displayed directory, type `telnet` at the prompt, and then press the **Enter** key.

Figure 3-18 Start a telnet session




3. Type `o <IP ADDRESS>` at the telnet prompt, and then press the **Enter** key.

NOTE: For `<IP ADDRESS>`, substitute the IP address that was displayed in step 2 in Start the telnet server function at the printer on page 50.

TIP: If the telnet connection fails to establish a connection, the printer is probably behind a firewall or on a different network that the remote telnet client computer. See Network connection on page 50.

Figure 3-19 Establish a telnet connection



4. Type the PIN that was displayed in step in Start the telnet server function at the printer on page 50 at the prompt, and then press the **Enter** key.

IMPORTANT: Make sure to type the PIN correctly. After five incorrect PIN entries, the printer terminates the Remote Admin connection. The Remote Admin feature must be re-initiated at the printer. See Start the telnet server function at the printer on page 50.

Figure 3-20 Enter the PIN




5. The following screen displays when the correct PIN is entered and the Remote Admin connection is successful. For information about the Pre-boot menu and options, see Pre-boot menu options pre-boot menu options on page 79.

NOTE: Because a Remote Admin connection is an unsecured telnet network protocol connection, the following Pre-boot menu items are disabled for the remote telnet client computer.

- The **+3:Administrator** menu **4:Change Password** item.
- The **+3:Administrator** menu **5:Clear Password** item.
- The **+3:Administrator** menu **6:Disk Manage** item.

Figure 3-21 Remote Admin window



Disconnect a remote connection


Learn how to disconnect a remote connection.

The Remote Admin connection can be terminated from the printer control panel or the remote telnet client computer.

NOTE: The following procedure describes terminating a Remote Admin connection from the remote telnet client computer.


1. From the Pre-boot main menu, use the arrow buttons on the keyboard to scroll down to the **+3:Administrator** item, and then press the **Enter** key.

Figure 3-22 Access the administrator menu



2. Use the arrow buttons on the keyboard to scroll down to the **+A:Remote Admin** item, and then press the **Enter** key.

Figure 3-23 **Access the remote admin menu**



3. Use the arrow buttons on the keyboard to scroll down to the **2:Stop Telnet** item, and then press the **Enter** key. The Remote Admin connection between the printer and the remote telnet client computer terminates.

IMPORTANT: The printer remains in the Pre-boot menu. Have the person that is physically present at the printer do the following:

- Touch the Home button to return to the main Pre-boot menu and highlight the **1:Continue** item, and then touch the OK button. The printer will continue to initialize.

Figure 3-24 **Terminate the telnet connection**



Clear paper jams

Use the procedures in this section to clear jammed paper from the printer paper path.

Paper jam locations

Jams can occur in these locations.




Table 3-2 Jam locations

Item	Description
1	Document feeder
2	Output bin
3	Right door and fuser area
4	Tray 1 (multipurpose tray)
5	Lower right door
6	Tray 2, Tray 3, Tray 4, and Tray 5

Auto-navigation for clearing paper jams

Learn about printer jam clearing auto-navigation.

The auto-navigation feature assists in clearing jams by providing step-by-step instructions on the control panel.

When you complete a step, the printer displays instructions for the next step until you have completed all steps in the procedure.

Experiencing frequent or recurring paper jams?


To reduce the number of paper jams, try these solutions.

1. Use only paper that meets HP specifications for this printer.
2. Use paper that is not wrinkled, folded, or damaged. If necessary, use paper from a different package.
3. Use paper that has not previously been printed or copied on.
4. Make sure the tray is not overfilled. If it is, remove the entire stack of paper from the tray, straighten the stack, and then return some of the paper to the tray.
5. Make sure the paper guides in the tray are adjusted correctly for the size of paper. Adjust the guides so they are touching the paper stack without bending it.
6. Make sure that the tray is fully inserted in the printer.
7. If you are printing on heavy, embossed, or perforated paper, use the manual feed feature and feed sheets one at a time.
8. Open the Trays menu on the printer control panel. Verify that the tray is configured correctly for the paper type and size.
9. Make sure the printing environment is within recommended specifications.


31.13.yz jam error in the document feeder

The following information describes how to clear paper jams in the document feeder. When a jam occurs, the control panel displays an animation that assists in clearing the jam.


1. Open the document-feeder cover.



2. Remove any jammed paper.



3. Close the document-feeder cover.




NOTE: To avoid jams, make sure the guides in the document-feeder input tray are adjusted against the document, without bending the document. To copy narrow documents, use the flatbed scanner. Remove all staples and paper clips from original documents.

NOTE: Original documents that are printed on heavy, glossy paper can jam more frequently than originals that are printed on plain paper.

13.B2.A1, 13.B2.D2 jam error in tray 1 (multipurpose tray)

Use the following procedure to clear paper jams in Tray 1. When a jam occurs, the control panel displays an animation that assists in clearing the jam.

1. Gently remove the jammed paper.



2. Open and then close the front door to resume printing.


13.A2, 13.A3, 13.A4 jam errors in tray 2, tray 3, or the optional 2 x 520-sheet trays

Use the following procedure to check for paper in all possible jam locations related to Tray 2 or Tray 3. When a jam occurs, the control panel might display a message and an animation that assists in clearing the jam.


CAUTION: The fuser can be hot while the printer is in use. Wait for the fuser to cool before handling it.

NOTE: The procedure to clear a paper jam in Tray 3 is the same as for Tray 2. Only Tray 2 is shown here.


1. Open the right door.




2. Gently remove any jammed paper.




3. Close the right door.




4. Open the tray.



5. Gently remove any jammed paper.




6. Close the tray. Printing automatically resumes.



13.E1 jam error in the output bin

Use the following procedure to check for paper in all possible jam locations in the output bin. When a jam occurs, the control panel displays an animation that assists in clearing the jam.

- If paper is visible in the output bin, grasp the leading edge and remove it.




13.B9, 13.B2, 13.FF jam errors in the right door and fuser area


Use the following procedure to clear paper jams in the right door and fuser area. When a jam occurs, the control panel displays an animation that assists in clearing the jam.

NOTE: The fuser is hot while the printer is in use. Wait for the fuser to cool before clearing jams.


1. Open the right door.



2. Gently remove any jammed paper.



3. Close the right door.



Control panel messages document (CPMD)

Learn about the printer control panel messages document (CPMD).

NOTE: A complete CPMD is not included in this manual.

You can use the error code look-up tool from product home page.

Error codes (types and structure)

Error codes and control-panel messages display on the printer control panel to indicate the current printer status or situations that might require action. Error codes are numerical, or alphanumerical, and have a set structure with six characters (example: 13.WX.YZ).

- The first two characters are numeric and represent the system component that is causing the error. For example, in error code `10.22.15`, **10** = **Supplies** for HP LaserJets.
- The remaining four characters (W, X, Y, and Z values) further define the error.

Table 3-3 **ERROR CODES: The first two characters**

Error code	System Component	System Error Description
10.WX.YZ	Supplies (LaserJet)	Supply error or supply memory error.
11.WX.YZ	Real-time clock	Internal error with the clock on the formatter.
13.WX.YZ	Jam (LaserJet)	Paper jam or open door jam error.
15.WX.YZ	Jam (PageWide)	Paper jam or open door jam error.
17.WX.YZ	Supplies (PageWide)	Supply error or supply memory error.
20.WX.YZ	Printer memory	Insufficient memory or buffering error.
21.WX.YZ	Page	Page complexity causing a decompression error when trying to process job.
30.WX.YZ	Scanner	Flatbed scanner error occurring inside the unit.
31.WX.YZ	Document feeder	Document feeder, scanner, or jam error.
32.WX.YZ	Backup, restore, or reset	Backup, restore, or reset notification or error.
33.WX.YZ	Security	Backup, Disk, EFI BIOS, Firmware integrity (SureStart), or Trusted Platform Module (TPM) notification or error.
40.WX.YZ	Input/Output (I/O)	Partition manager, secure erase, or USB accessory error.
41.WX.YZ	Fuser, Laser scanner, or Paper path	Miscellaneous error including general and misprint or mismatch errors typically involving (but not limited to) the fuser, the laser scanner, or the paper path.
42.WX.YZ	Firmware	Firmware failure involving the Event Log, Shell, System Manager, or other component.
44.WX.YZ	Firmware	Firmware failure involving a digital sending component.
45.WX.YZ	OXPd/Web Kit (PageWide)	Informational notifications involving the OXPd Web Kit (communications log).
46.WX.YZ	Engine (LaserJet)	Engine communication error.

Table 3-3 ERROR CODES: The first two characters (continued)

Error code	System Component	System Error Description
47.WX.YZ	Firmware	Job parser or printer calibration error.
48.WX.YZ	Firmware	PJA job accounting, job management, or job pipeline error.
49.WX.YZ	Firmware	Firmware communication error.
50.WX.YZ	Fuser (LaserJet)	Fuser error.
51.WX.YZ	Laser scanner (LaserJet)	Laser scanner beam error.
52.WX.YZ	Laser scanner (LaserJet)	Laser scanner startup error.
54.WX.YZ	Sensor	Sensor error (not jam related).
55.WX.YZ	DC controller (LaserJet)	DC controller communication error.
56.WX.YZ	Paper handling (LaserJet)	Paper input/output or accessory error.
57.WX.YZ	Fan	Fan error.
58.WX.YZ	Sensor	Engine sensor failure.
59.WX.YZ	Motor (LaserJet)	Motor error.
60.WX.YZ	Tray motor error (LaserJet)	Tray lifting or pick up error.
61.WX.YZ	Engine (PageWide)	Print engine error with the 8-bit data package.
62.WX.YZ	System (LaserJet) Print bar (PageWide)	LaserJet internal system error. PageWide print system error.
63.WX.YZ	Engine (LaserJet)	General engine error (electrical, communication, etc.).
65.WX.YZ	Connector	Output accessory connection error.
66.WX.YZ	Output accessory	Output accessory error.
67.WX.YZ	Input accessory	Input accessory connection error
69.WX.YZ	Duplexer	Duplexer error.
70.WX.YZ	DC controller (LaserJet)	DC controller firmware error.
76.WX.YZ	DC controller (LaserJet)	Power supply fluctuations causes formatter and DC controller communication issue and results them not to be in synchronization.
80.WX.YZ	Managed device	Embedded Jetdirect error.
81.WX.YZ	Near Field Communication (NFC)	Wireless, Bluetooth or internal EIO error.
82.WX.YZ	Memory (hard disk, EMMC, etc.)	Disk hardware error.
90.WX.YZ	Internal diagnostics	Internal test of systems (i.e. disk, CPB, display) or interconnection error.
98.WX.YZ	Hard disk	Hard disk partition error.
99.WX.YZ	Firmware installer	Remote Firmware Upgrade (RFU), firmware install (engine or accessory), or disk error.

Print the supplies status page

The supplies status page indicates the cartridge status.

1. From the Home screen on the printer control panel, scroll to and touch the Reports menu icon.
2. Touch the Configuration/Status Pages menu.
3. Touch Supplies Status Page, and then touch the Print icon to print the page.

Print the event log

Learn how to print the event log.

Print the 50 most recent events in the Event Log. For each event, the printed log shows the error number, page count, error code, and description or personality.

1. From the Home screen on the printer control panel, scroll to and touch the Troubleshooting menu icon.
2. Touch Event Log.
3. Touch the Print icon to print the page.

Pre-boot menu options

The Pre-boot menus are available prior to the printer initializing.

CAUTION: The Format Disk option performs a disk initialization for the entire disk. The operating system, firmware files, and third party files (among other files) will be completely lost. HP does not recommend this action unless it is specified as a solution in the CPMD.


TIP: The Pre-boot menu is also remotely accessible by using a telnet network protocol (Remote Admin) to establish an administration connection to the printer.

Open the Pre-boot menu from a touchscreen control panel

Use the following procedure to open the Pre-boot menu from a touchscreen control panel.

1. Turn the printer on.
2. Touch the middle of the control-panel display when you see the 1/8 under the logo.

Figure 3-25 Open the Pre-boot menu



3. On the Pre-boot menu screen, use the following buttons to navigate the tests.

Figure 3-26 Pre-boot menu



Button	Description
	Use this button to see more information about a selected item.
	Use this button to scroll up through menu items.
	Use this button to select a highlighted menu item.
	Use this button to scroll down through menu items.
	Use this button to go back to the previous menu.
	Not used.

4. Use the arrow buttons on the touchscreen to navigate the Pre-boot menu.
5. Touch the OK button to select a menu item.


Cold reset using the Pre-boot menu from a touchscreen control panel

Use the following procedure to perform a cold reset using the Pre-boot menu from a touchscreen control panel.

⚠ **CAUTION:** This procedure resets all printer configurations and settings to factory defaults (customer configurations and settings are lost).

1. Touch the middle of the control-panel display when you see the 1/8 under the logo.

   Figure 3-27 **Open the Pre-boot menu**

2. Use the down arrow ▼ button to highlight the +3:Administrator item, and then touch the OK button.
3. Use the down arrow ▼ button to highlight the +8:Startup Options item, and then touch the OK button.
4. Use the down arrow ▼ button to highlight the 2 Cold Reset item, and then touch the OK button to select it.
5. Touch the Home button to return to the main Pre-boot menu and highlight the 1:Continue item, and then touch the OK button.

NOTE: The printer will initialize.

Remote Admin

Learn about the printer Remote Admin function.

The Remote Admin feature allows remote access the printer Pre-boot menu (BIOS environment). The printer functions as a telnet server which uses the telnet networking protocol to transmit text data. Any computer (with telnet installed and enabled) can function as the telnet client to remotely display and interact with the Pre-boot menu.

IMPORTANT: While the Remote Admin function allows remote access the Pre-boot menu, for security reasons the Remote Admin connection must be initiated by a person that is physically present at the printer.

Required software and network connection

Before using the Remote Admin feature, make sure that the telnet network protocol is installed and enabled on the remote telnet client computer.

NOTE: This section describes enabling and configuring the telnet feature for computers using a Windows® operating system.

HP recommends that the telnet client computer be a Windows-based system; however, there are other operating systems that support the telnet network protocol. For information about enabling and configuring the telnet network protocol for other operating systems, see the owner's manual for that operating system.


Enable the Windows telnet client

All computers using the Windows operating system have the telnet client installed, however, the telnet client function might not be enabled by default.

NOTE: The figures and menus in this section are for the Windows 10® operating system. Screens and menu selections might vary slightly for other operating systems.

1. Use the **Start** menu to open the **Windows Settings** dialog box, and then search for **Turn Windows features on or off**. Click the **Turn Windows features on or off** item.


Figure 3-28 **Open Windows Settings**



2. In the **Windows Features** box, scroll down to **Telnet Client**. If the check box is not checked, click the box to select it, and then click the **OK** button.

TIP: If the check box is already checked then the telnet client function is already enabled. Click the **Cancel** button.

Figure 3-29 Enable the telnet client feature



Network connection

The remote telnet client computer must have direct network access to the printer for the Remote Admin function to operate. This means that the telnet client computer must be on the same network as the printer.

The Remote Admin function cannot be accessed through a network firewall or other remote access network security programs.

If a private network is not accessible, ask the network administrator to set up a virtual private network (VPN) connection to the network.

Connect a remote connection

Use the following procedures to connect a remote connection.

Start the telnet server function at the printer


For security reasons the Remote Admin feature must be initiated by a person that is physically present at the printer. The following steps must be performed by a person that is physically present at the printer.

NOTE: This person might need to sign in with an administrator or service password depending on how the printer is configured.

1. Turn the printer on.
2. The HP logo displays on the printer control panel. When a 1/8 with an underscore displays, touch the middle of the screen to open the Pre-boot menu.


3. Use the arrow buttons on the touchscreen to scroll down and highlight the +3:Administrator item, and then touch the OK button to select it.

Figure 3-30 Select the +3:Administrator item



4. Use the arrow buttons on the touchscreen to scroll down and highlight the +A:Remote Admin item, and then touch the OK button to select it.

Figure 3-31 Select the +A:Remote Admin item



5. Use the arrow buttons on the touchscreen to scroll down and highlight the 1:Start Telnet item, and then touch the OK button to select it.

Figure 3-32 Select the 1:Start Telnet item



6. Do one of the following

- If a connecting message displays briefly, go to 7.

  Figure 3-33 Telnet connecting message

- If an error message displays, use the steps below to identify the problem.

Figure 3-34 **Telnet error message**



a. The printer network cable is not correctly connected.

b. The BIOS LAN settings are incorrect.

   – The printer should be configured to use a static IP address, but is configured to use DHCP instead.

   – The printer is configured to use a static IP address, but the IP address is incorrect.


c. The printer is correctly configured to use DHCP, but the DHCP server is not turned on or is malfunctioning.

7. When the printer telnet server function is initialized, the following screen appears. Use the information on this screen to connect the remote telnet client computer to the printer.

NOTE: The printer is now ready to receive remote telnet client commands.

- **IP**: The static or dynamically allocated IP address for the printer.
- **Port**: The standard telnet port (23).
- **Pin**: A randomly generated 4-digit personal identification number (PIN).

Figure 3-35 **Telnet server function initialized**



Start the telnet client function at the remote computer


The following steps establish a Remote Admin connection from a remote computer to the printer.

1. From the **Start** menu open the **Command Prompt** desktop application.

TIP: Type `cmd` in the application search dialogue box to find the application.

2. From any displayed directory, type `telnet` at the prompt, and then press the **Enter** key.

Figure 3-36 Start a telnet session




3. Type `o <IP ADDRESS>` at the telnet prompt, and then press the **Enter** key.

NOTE: For `<IP ADDRESS>`, substitute the IP address that was displayed in step 7 of the "Start the telnet server function at the printer" topic.

TIP: If the telnet connection fails to establish a connection, the printer is probably behind a firewall or on a different network that the remote telnet client computer.

Figure 3-37 Establish a telnet connection



4. Type the PIN that was displayed in step 7 of then "Start the telnet server function at the printer" topic at the prompt, and then press the **Enter** key.

IMPORTANT: Make sure to type the PIN correctly. After five incorrect PIN entries, the printer terminates the Remote Admin connection. The Remote Admin feature must be re-initiated at the printer. See the "Start the telnet server function at the printer" topic.

Figure 3-38 Enter the PIN




5. The following screen displays when the correct PIN is entered. and the Remote Admin connection is successful. For information about the Pre-boot menu and options, see "Pre-boot menu options" in this printer manual .

NOTE: Because a Remote Admin connection is an unsecured telnet network protocol connection, the following Pre-boot menu items are disabled for the remote telnet client computer.

- The **+3:Administrator** menu **4:Change Password** item.
- The **+3:Administrator** menu **5:Clear Password** item.
- The **+3:Administrator** menu **6:Disk Manage** item.

Figure 3-39 Remote Admin window




Disconnect a remote connection

The Remote Admin connection can be terminated from the printer control panel or the remote telnet client computer.

NOTE: The following procedure describes terminating a Remote Admin connection from the remote telnet client computer.


1. From the Pre-boot main menu, use the arrow buttons on the keyboard to scroll down to the **+3:Administrator** item, and then press the **Enter** key.

Figure 3-40 Access the administrator menu



2. Use the arrow buttons on the keyboard to scroll down to the **+A:Remote Admin** item, and then press the **Enter** key.

Figure 3-41 Access the remote admin menu




3. Use the arrow buttons on the keyboard to scroll down to the **2:Stop Telnet** item, and then press the **Enter** key. The Remote Admin connection between the printer and the remote telnet client computer terminates.

IMPORTANT: The printer remains in the Pre-boot menu. Have the person that is physically present at the printer do the following:

- Touch the Home button to return to the main Pre-boot menu and highlight the **1:Continue** item, and then touch the OK button. The printer will continue to initialize.

Figure 3-42 Terminate the telnet connection



Print the event log

Learn how to print the event log.

Print the 50 most recent events in the Event Log. For each event, the printed log shows the error number, page count, error code, and description or personality.

1. From the Home screen on the printer control panel, scroll to and touch the Troubleshooting menu icon.
2. Touch Event Log.
3. Touch the Print icon to print the page.

4 Control panel menus

You can perform basic printer setup by using the Settings menu. Use the HP Embedded Web Server for more advanced printer setup. To open the HP Embedded Web Server, enter the printer IP address or host name in the address bar of a web browser.

Pre-boot menu options

The Pre-boot menus are available prior to the printer initializing.

⚠ **CAUTION:** The Format Disk option (printers with a hard-disk drive only) performs a disk initialization for the entire disk. The operating system, firmware files, and third party files (among other files) will be completely lost. HP does not recommend this action.


TIP: The Pre-boot menu can be remotely accessed by using a telnet network protocol to establish an administration connection to the printer. See Remote Admin on page 48.

Open the Pre-boot menu from a touchscreen control panel

Learn how to open the Pre-boot menu from a touchscreen control panel.

1. Touch the middle of the control-panel display when you see the 1/8 under the logo.

Figure 4-1 Open the Pre-boot menu



2. On the Pre-boot menu screen, use the following buttons to navigate the tests.

Figure 4-2 Pre-boot menu



Table 4-1 Pre-boot screen buttons

	Use this button to see more information about a selected item.
	Use this button to scroll up through menu items.
	Use this button to select a highlighted menu item.
	Use this button to scroll down through menu items.
	Use this button to go back to the previous menu.
	Not used.
	Use this button to exit a diagnostic test.

3. Use the arrow buttons on the touchscreen to navigate the Pre-boot menu.
4. Touch the OK button to select a menu item.


Cold reset using the Pre-boot menu from a touchscreen control panel

Learn how to cold reset using the Pre-boot menu from a touchscreen control panel.

⚠ CAUTION: This procedure resets all printer configurations and settings to factory defaults (customer configurations and settings are lost).

1. Touch the middle of the control-panel display when you see the 1/8 under the logo.

Figure 4-3 Open the Pre-boot menu



2. Use the ▼ button to highlight the +3:Administrator item, and then touch the OK button.
3. Use the ▼ button to highlight the +8:Startup Options item, and then touch the OK button.
4. Use the ▼ button to highlight the 2 Cold Reset item, and then touch the OK button to select it.
5. Touch the Home button to return to the main Pre-boot menu and highlight the 1:Continue item, and then touch the OK button.

NOTE: The printer will initialize.

NOTE: Some of the pre-boot options in the following tables are not supported by the current version of the printer firmware and are included for information only. Future versions of firmware will support these options.

Table 4-2 Pre-boot menu options (1 of 7)

Menu option	First level	Second level	Third level	Description
Continue				Selecting the Continue item exits the Pre-boot menu and continues the normal boot process. If a selection is not made in the initial menu within 30 seconds, the printer returns to a normal boot (the same as selecting Continue). If the user navigates to another menu, the timeout does not apply.
Sign In				Enter the administrator PIN or service PIN if one is required to open the Pre-boot menu.
Administrator				This item navigates to the Administrator submenus. If authentication is required (and the user is not already signed in) the Sign In prompt displays. The user is required to sign in.
	Download	Network USB USB Thumbdrive		This item initiates a Pre-boot firmware download process. A USB Thumb drive option will work on all FutureSmart printers. USB or Network connections are not currently supported.

Table 4-2 Pre-boot menu options (1 of 7) (continued)

Menu option	First level	Second level	Third level	Description
	Format Disk			This item reinitializes the disk and cleans all disk partitions. **CAUTION:** Selecting the Format Disk item removes **all** data. A delete confirmation prompt is **not** provided. The system is **not** bootable after this action and a **99.09.67** error displays on the control panel. A firmware download must be performed to return the system to a bootable state.
	Partial Clean			This item reinitializes the disk (removing all data except the firmware repository where the master firmware bundle is downloaded and saved). **CAUTION:** Selecting the Partial Clean item removes **all** data except the firmware repository. A delete confirmation prompt is **not** provided. **CAUTION:** This procedure resets all printer configurations and settings to factory defaults (customer configurations and settings are lost). This allows a user to reformat the disk by removing the firmware image from the active directory without having to download new firmware code (printer remains bootable).
	Change Password			Select this item to set or change the administrator password.
	Clear Password			Select the Clear Password item to remove a password from the Administrator menu. Before the password is actually cleared, a message will be shown asking to confirm that the password should be cleared. Press the OK button to confirm the action. When the confirmation prompt displays, press the OK button to clear the password.

Table 4-3 Pre-boot menu options (2 of 7)

Menu option	First level	Second level	Third level	Description
Administrator	Manage Disk	Clear disk		Select the Clear disk item to enable using an external device for job storage. Job storage is normally enabled only for the Boot device. This will be grayed out unless the **99.09.68** error is displayed.
		Lock Disk		Select the Lock Disk item to lock (mate) a new secure disk to this printer. The secure disk already locked to this printer will remain accessible to this printer. Use this function to have more than one encrypted disk accessible by the printer when using them interchangeably. The data stored on the secure disk locked to this printer always remains accessible to this printer.

Table 4-3 Pre-boot menu options (2 of 7) (continued)

Menu option	First level	Second level	Third level	Description
		Leave Unlocked		Select the Leave Unlocked item to use a new secure disk in an unlocked mode for a single service event. The secure disk that is already locked to this printer will remain accessible to this printer and uses the old disk's encryption password with the new disk. The secure disk that is already locked to this printer remains accessible to this printer.
		Clear Disk Pwd		Select the Clear Disk Pwd item to continue using the non-secure disk and clear the password associated with the yet-to-be installed secure disk. **CAUTION:** Data on the missing secure disk will be permanently inaccessible.
		Retain Password		Select the Retain Password item to use the non-secure disk for this session only, and then search for the missing secure disk in future sessions.
		Boot Device	Secure Erase	Select the Secure Erase item to erase all of the data on the disk and unlock it if required. This might take a long time. **NOTE:** The system will be unusable until the system files are reinstalled. The ATA secure-erase command is a one-pass overwrite, which erases the entire disk including firmware. The disk remains an encrypted disk.
			Erase/ Unlock	Select the Erase/Unlock item to cryptographically erase all data on the disk and unlock the disk to allow a user to gain access to it from any printer. **NOTE:** The system will be unusable until the system files are reinstalled. It erases the encryption key. The encryption key is erased, so the disk becomes a non-encrypted disk.
			Get Status	This item provides disk status information if any is available.

Table 4-4 Pre-boot menu options (3 of 7)

Menu option	First level	Second level	Third level	Description
Administrator	Manage Disk	Internal Device		Select the Internal Device item to erase the internal device or get a status about the internal device.
			Secure Erase	Select the Secure Erase item to erase all of the data on the disk and unlock it if required. This might take a long time. **NOTE:** The system will be unusable until the system files are reinstalled. The ATA secure-erase command erases the entire disk, including firmware. The disk remains an encrypted disk.

Table 4-4 Pre-boot menu options (3 of 7) (continued)

Menu option	First level	Second level	Third level	Description
			Erase/ Unlock	Select the Erase/Unlock item to cryptographically erase all of the data on disk and unlock the disk to allow the user to gain access to it from any printer. NOTE: The system will be unusable until the system files are reinstalled. The HP High Performance Secure Hard Disk is erased.
			Get Status	This item provides disk status information if any is available.
		External Device		Select the External Device item to erase the external device or get status about the external device.
			Secure Erase	Select the Secure Erase item to erase all of the data on the disk and unlock it if required. This might take a long time. NOTE: The system will be unusable until the system files are reinstalled. The ATA secure-erase command erases the entire disk, including firmware. The disk remains an encrypted disk.
			Erase/ Unlock	Select the Erase/Unlock item to cryptographically erase all of the data on disk and unlock the disk to allow a user to gain access to it from any printer. NOTE: The system will be unusable until the system files are reinstalled. The encryption key is erased, so the disk becomes a non-encrypted disk.
			Get Status	This item provides disk status information if any is available.

Table 4-5 Pre-boot menu options (4 of 7)

Menu option	First level	Second level	Third level	Description
Administrator	Configure LAN NOTE: This configuration is only active when the Pre-boot menu is open.	IP Mode [DHCP]		The network can be configured to obtain the network settings from a DHCP server or as static. Use this item for automatic IP address acquisition from the DHCP server.
		IP Mode [STATIC]		Use this item to manually assign the network addresses.
			IP Address	Use this item to manually enter the IP addresses.
			Subnet Mask	Use this item to manually enter the subnet mask.
			Default Gateway	Use this item to manually enter the default gateway.
			Save	Select the Save item to save the manual settings.

Table 4-6 **Pre-boot menu options (5 of 7)**

Menu option	First level	Second level	Third level	Description
Administrator	Startup Options			Select the Startup Options item to specify options that can be set for the next time the printer is turned on and initializes to the **Ready** state.
		Show Revision		**Not currently functional**: Select the Show Revision item to allow the printer to initialize and show the firmware version when the printer reaches the **Ready** state. Once the printer power is turned on the next time, the Show Revision item is unchecked so that the firmware revision is not shown.
		Cold Reset		Select the Cold Reset item to clear the IP address and all customer settings. (This item also returns all settings to factory defaults.) **NOTE:** Items in the Service menu are not reset.
		Skip Disk Load		Select the Skip Disk Load item to disable installed third-party applications.
		Skip Cal		Select the Skip Cal item to skip the printer calibration for the very next power-initialization cycle only.
		Lock Service		**CAUTION:** Select the Lock Service item to lock the Service menu access (both in the Pre-boot menu and the Device Maintenance menu). Service personnel must have the administrator remove the Lock Service setting before they can open the Service menu.
		Skip FSCK		Select the Skip FSCK item to disable Chkdisk/ScanVolume during startup.
		First Power		**Not currently functional**: This item allows the printer to initialize as if it is the first time it has been turned on. For example, the user is prompted to configure first-time settings like date/time, language, and other settings. Select this item so that it is enabled for the next time the printer power is turned on. When the printer power is turned on the next time, this item is unchecked so that the pre-configured settings are used during configuration, and the first-time setting prompt is not used.
		Embedded Jetdirect Off		Select the Embedded Jetdirect Off item to disable the embedded HP Jetdirect. By default this item is unchecked so that HP Jetdirect is always enabled.
		WiFi Accessory		Select the WiFi Accessory item to enable the wireless accessory.

Table 4-7 Pre-boot menu options (6 of 7)

Menu option	First level	Second level	Third level	Description
Administrator	Diagnostics			Diagnostic items are useful to diagnose hardware components and their interface connections. Use these items to troubleshoot specific hardware components, and the interface between them and other components.
		Memory	Do Not Run	Use the Do Not Run item to exclude the Memory diagnostic when executing multiple diagnostics.
			Short	Use the Short item to select a brief memory test. **NOTE:** This test requires about four minutes to execute.
			Long	Use the Long item to select an extended memory test. **NOTE:** This test requires about twenty minutes to execute.
		Disk	Do Not Run	Use the Do Not Run item to exclude the Disk diagnostic when executing multiple diagnostics.
			Short	Use the Short item to select a brief firmware self-test. **NOTE:** This test requires about two or three minutes to execute.
			Long	Use the Long item to select an extended firmware self-test. **NOTE:** This test requires about sixty minutes to execute.
			Optimized	Use the Optimized item to select a test that checks the active sectors on the disk. **NOTE:** This test requires about thirty minutes to execute.

Table 4-7 Pre-boot menu options (6 of 7) (continued)

Menu option	First level	Second level	Third level	Description
			Raw	Use the Raw item to select a test that checks every sector on the disk. **NOTE:** This test requires about fifty minutes to execute.
			Smart	Use the Smart item to select a very brief test that checks the drive self-monitoring analysis and reporting technology (SMART) status—the drive detects and reports reliability indicators to help anticipate disk failures (SMART status).
		CPB		Use the CPB item to verify the integrity of the copy processor board (CPB) and the formatter PCA connections.
		Interconnect		Use the Interconnect item to verify the integrity of the interconnect PCA (ICB) and its connections.
		Run Selected		Select the Run Selected item to execute a selected test. **NOTE:** If more than one test is selected, they are executed in sequence.

Table 4-8 Pre-boot menu options (7 of 7)

Menu option	First level	Second level	Third level	Description
Administrator	Remote Admin	Start Telnet		The Remote Admin item allows a service technician to access to the printer Pre-boot menu remotely, and to navigate the menu selections from a remote location. **IMPORTANT:** A Remote Admin connection must be initiated by a person that is physically present at the printer. This person will also need to provide a randomly generated PIN to the remote service technician. **NOTE:** For more information about using the Remote Admin function, see Remote Admin on page 48.

Table 4-8 Pre-boot menu options (7 of 7) (continued)

Menu option	First level	Second level	Third level	Description
		Stop Telnet		
		Refresh IP		
	System Triage	Copy Logs		If the device will not boot to the **Ready** state, or the diagnostic log feature found in the Troubleshooting menu is not accessible, then use the System Triage item to copy the diagnostic logs to a USB flash drive at the next printer start up. The files can then be sent to HP to help diagnose the problem.
	Change Svc PWD			Use this item to change the Service menu personal identification number (PIN).
	Reset Svc PWD			If the Service menu personal identification number (PIN) has been changed. Use this item to reset it to the original PIN.
Service Tools	Reset Password			Use this item to reset the Pre-boot administrator password.
	Subsystems			For manufacturing use only. Do not change these values.
Developer Tools	Netexec			

Remote Admin

The Remote Admin feature allows remote access the printer Pre-boot menu (BIOS environment). The printer functions as a telnet server which uses the telnet networking protocol to transmit text data. Any computer (with telnet installed and enabled) can function as the telnet client to remotely display and interact with the Pre-boot menu.

IMPORTANT: While the Remote Admin function allows remote access the Pre-boot menu, for security reasons the Remote Admin connection must be initiated by a person that is physically present at the printer.

This section describes the following Remote Admin items.

Required software and network connection

Before using the Remote Admin feature, make sure that the telnet network protocol is installed, and enabled, on the remote telnet client computer.

NOTE: This section describes enabling and configuring the telnet feature for computers using a Windows® operating system.

HP recommends that the telnet client computer be a Windows based system, however, there are other operating systems that support the telnet network protocol. For information about enabling and configuring the telnet network protocol for other operating systems, see the owner's manual for that operating system.


Telnet client

All computers using the Windows operating system have the telnet client installed, however, the telnet client function might not be enabled by default.

NOTE: The figures and menus in this section are for the Windows 7 Enterprise® operating system. Screens and menu selections might vary slightly for other operating systems.


1. Use the **Start** menu to open the **Control Panel**, and then click the **Programs** item to select it.

Figure 4-4 Open the Control Panel



2. Click the **Turn Windows features on or off** item to select it.


Figure 4-5 Turn Windows features on or off



3. In the **Windows Features** box, scroll down to **Telnet Client**. If the check box is not checked, click the box to select it, and then click the **OK** button.

TIP: If the check box is already checked then the telnet client function is already enabled. Click the **Cancel** button.

Figure 4-6 Enable the telnet client feature



Network connection

The remote telnet client computer must have direct network access to the printer for the Remote Admin function to operate. This means that the telnet client computer must be on the same network as the printer. The Remote Admin function cannot be accessed through a network firewall or other remote access network security programs.

If a private network is not accessible, ask the network administrator to set up a virtual private network (VPN) connection to the network.

Connect a remote connection

Learn how to connect a remote connection using telnet.

Start the telnet server function at the printer


For security reasons the Remote Admin feature must be initiated by a person that is physically present at the printer. The following steps must be performed by a person that is physically present at the printer.

NOTE: This person might need to sign in with an administrator or service password depending on how the printer is configured.

1. Turn the printer on.
2. The HP logo displays on the printer control panel. When a "1/8" with an underscore displays, touch the middle of the screen to open the Pre-boot menu.


3. Use the arrow buttons on the touchscreen to scroll down and highlight the **+3:Administrator** item, and then touch the OK button to select it.

Figure 4-7 **Select the +3:Administrator item**



4. Use the arrow buttons on the touchscreen to scroll down and highlight the **+A:Remote Admin** item, and then touch the OK button to select it.

Figure 4-8 **Select the +A:Remote Admin item**



5. Use the arrow buttons on the touchscreen to scroll down and highlight the **1:Start Telnet** item, and then touch the OK button to select it.


Figure 4-9 **Select the 1:Start Telnet item**



6. Do one of the following

- If a connecting message displays briefly, go to step 7.

  Figure 4-10 **Telnet connecting message**

- If an error message displays, use the steps below to identify the problem.

Figure 4-11 Telnet error message



a. The printer network cable is not correctly connected.

b. The BIOS LAN settings are incorrect.

   - The printer should be configured to use a static IP address, but is configured to use DHCP instead.
   - The printer is configured to use a static IP address, but the IP address is incorrect.


c. The printer is correctly configured to use DHCP, but the DHCP server is not turned on or is malfunctioning.

7. When the printer telnet server function is initialized, the following screen appears. Use the information on this screen to connect the remote telnet client computer to the printer.

NOTE: The printer is now ready to receive remote telnet client commands.

- **IP**: The static or dynamically allocated IP address for the printer.
- **Port**: The standard telnet port (23).
- **Pin**: A randomly generated 4-digit personal identification number (PIN).

Figure 4-12 Telnet server function initialized




Start the telnet client function at the remote computer

The following steps establish a Remote Admin connection from a remote computer to the printer.


1. From the **Start** menu click **Run** to open a dialog box, type `cmd` in the **Open** field, and then click the **OK** button to open a Windows command window.

Figure 4-13 Open a command window



2. From any displayed directory, type `telnet` at the prompt, and then press the **Enter** key.

Figure 4-14 Start a telnet session




3. Type `o <IP ADDRESS>` at the telnet prompt, and then press the **Enter** key.

NOTE: For `<IP ADDRESS>`, substitute the IP address that was displayed in step 2 in Start the telnet server function at the printer on page 50.

TIP: If the telnet connection fails to establish a connection, the printer is probably behind a firewall or on a different network that the remote telnet client computer. See Network connection on page 50.

Figure 4-15 Establish a telnet connection



4. Type the PIN that was displayed in step in Start the telnet server function at the printer on page 50 at the prompt, and then press the **Enter** key.

IMPORTANT: Make sure to type the PIN correctly. After five incorrect PIN entries, the printer terminates the Remote Admin connection. The Remote Admin feature must be re-initiated at the printer. See Start the telnet server function at the printer on page 50.

Figure 4-16 Enter the PIN




5. The following screen displays when the correct PIN is entered and the Remote Admin connection is successful. For information about the Pre-boot menu and options, see Pre-boot menu options pre-boot menu options on page 79.

NOTE: Because a Remote Admin connection is an unsecured telnet network protocol connection, the following Pre-boot menu items are disabled for the remote telnet client computer.

- The **+3:Administrator** menu **4:Change Password** item.
- The **+3:Administrator** menu **5:Clear Password** item.
- The **+3:Administrator** menu **6:Disk Manage** item.

Figure 4-17 Remote Admin window



Disconnect a remote connection


Learn how to disconnect a remote connection.

The Remote Admin connection can be terminated from the printer control panel or the remote telnet client computer.

NOTE: The following procedure describes terminating a Remote Admin connection from the remote telnet client computer.


1. From the Pre-boot main menu, use the arrow buttons on the keyboard to scroll down to the **+3:Administrator** item, and then press the **Enter** key.

Figure 4-18 Access the administrator menu



2. Use the arrow buttons on the keyboard to scroll down to the **+A:Remote Admin** item, and then press the **Enter** key.

Figure 4-19 Access the remote admin menu



3. Use the arrow buttons on the keyboard to scroll down to the **2:Stop Telnet** item, and then press the **Enter** key. The Remote Admin connection between the printer and the remote telnet client computer terminates.

IMPORTANT: The printer remains in the Pre-boot menu. Have the person that is physically present at the printer do the following:

- Touch the Home button to return to the main Pre-boot menu and highlight the **1:Continue** item, and then touch the OK button. The printer will continue to initialize.

Figure 4-20 Terminate the telnet connection



Reports menu

To display: At the printer control panel, select Reports.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-9 Reports menu

First level	Second level	Values	Description
Configuration/Status Pages	Settings Menu Map	Print View	Shows a map of the entire Settings menu and the selected values for each setting.

Table 4-9 Reports menu (continued)

First level	Second level	Values	Description
	Current Settings Page	Print View	Shows the current printer settings.
	Configuration Page	Print View	Shows the printer settings and installed accessories.
	How to Connect Page	Print View	Shows the IP address, the host name, and the hardware (MAC) address for the printer if it is connected to a network.
	Supplies Status Page	Print View	Shows the approximate remaining life for the supplies; reports statistics on total number of pages and jobs processed, serial number, page counts, and maintenance information. HP provides approximations of the remaining life for the supplies as a customer convenience. The actual remaining supply levels might be different from the approximations provided.
	Usage Page	Print View	Shows a count of all paper sizes that have passed through the printer; lists whether they were simplex, duplex, monochrome, or color; and reports the page count.
	File Directory Page	Print View	Shows the file name and folder name for files that are stored in the printer memory.
	Web Services Status Page	Print View	Shows the detected Web Services for the printer.
	HP Flex Build Configuration Page	Print View	Shows installed Flex Build components and replacement history. NOTE: 877/826/786/731 printers only.
	Event Log	Print View	Displays or prints event logs listing event code, date/time, cycles and repetitions on the printer.
	Paper Path Page	Print View	Shows paper path usage on the printer.
Fax Reports (MFP fax models only)	Fax Activity Log	Print View	Contains a list of the faxes that have been sent from or received by this printer.

Table 4-9 Reports menu (continued)

First level	Second level	Values	Description
	Billing Codes Report	Print View	Provides a list of billing codes that have been used for outgoing faxes. This report shows how many sent faxes were billed to each code.
	Blocked Fax List	Print View	Provides a list of phone numbers that are blocked from sending faxes to this printer.
	Fax Call Report	Print View	Provides a detailed report of the last fax operation, either sent or received.
Other Pages	PCL Font List	Print	Prints the available PCL fonts.
	PS Font List	Print	Prints the available PS fonts.
	Secure Drum Data Erase	Print	Prints the secure drum data erase pattern to overwrite any residual image data that might be left on the drum from the previous print job.

Settings menu

To display: At the printer control panel, select the Settings menu.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-10 Settings menu

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
General	Date/Time Settings	Date/Time Format	Date Format		DD/MMM/YYYY MMM/DD/YYYY YYYY/MMM/DD	Use the Date/Time Settings menu to specify the date and time and to configure date/time settings.
			Time Format		12 hour (AM/PM) 24 hours	Select the format that the printer uses to show the date and time, for example 12-hour format or 24-hour format.
		Date/Time	Date		Select the time zone from a list.	Select the time zone, date, and time that the printer uses.
			Time		Select the date from a pop-up calendar.	

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			Time Zone		Select the time from a pop-up keypad.	
	Energy Settings	Sleep Schedule	A list of scheduled events displays.		+ (Add) Edit Delete	Use to configure the printer to automatically wake up or go to sleep at specific times on specific days. Using this feature saves energy. **NOTE:** You must configure the date and time settings before you can use this feature.
			New event	Event Type		Select whether to add or edit a Wake event or a Sleep event, and then select the time and the days for the wake or sleep event.
				Time		Set the wake or sleep event time parameters.
				Event Days	Select days of the week from a list.	Set the wake or sleep event day parameters.
		Sleep Settings	Sleep After Inactivity Shut Down		Range: 1 to 110 minutes Default = 0 minutes	Set the number of minutes after which the printer enters Sleep or Auto Off mode. Touch the existing number to open the virtual keypad, and then increase or decrease the number of minutes.
	Display Settings	Display Brightness	Manual		The Manual setting uses a slider to manually control the display brightness.	Use to specify the intensity of the LCD control panel display.
		System Sound			On* Off	Use to specify whether you hear a sound when you touch the screen or press buttons on the control panel.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Language Settings	Language		Select from a list of languages that the printer supports.	Use to select a different language for control panel messages and specify the default keyboard layout. When you select a new language, the keyboard layout automatically changes to match the factory default for the selected language.
			Keyboard Layout Flow models only		Each language has a default keyboard layout. To change it, select from a list of layouts.	Select the default keyboard layout that matches the language you want to use.
		Information Screen			Show connection information* Hide connection information	Use this menu item to display or hide connection information on the Home screen.
		Display Date and Time			Yes* No	Select whether to display or hide the date and time on the control panel Home screen.
		Job Status Notifications			Fewer* More	Use this feature to control how many job status notifications appear while a job is proceeding • If the setting is Fewer, there will only be a notification to indicate the job has been added to the job queue (except Fa, which always indicates success or failure). • If the setting is More, there will be status notifications while the job is proceeding including a completion notification.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Inactivity Timeout			Range: 10-300 seconds Default = 60 seconds	Specifies the amount of time that elapses between any activity on the control panel and when the printer resets to the default settings. When the timeout expires, the control panel display returns to the Home menu, and any user signed in to the printer is signed out.
		Clearable Warnings			On Job*	Use this feature to set the period that a clearable warning displays on the control panel. If the On setting is selected, clearable warnings appear until the Clearable Warnings button is pressed. If the Job setting is selected, clearable warnings stay on the display during the job that generated the warning and disappear from the display when the next job starts.
		Continuable Events			Auto-continue (10 seconds)* Touch OK to continue	Use this option to configure the printer behavior when the printer encounters certain errors. If the Auto-continue (10 seconds) option is selected, the job will continue after 10 seconds. If the Touch OK to continue option is selected, the job will stop and require the user to touch the OK button before continuing.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Enable Device USB				Enabled* Disabled	Use this feature to enable or disable the USB port, which allows connecting to a computer by using a USB device.
	Jam Recovery				Auto* Off On	This printer provides a jam recovery feature that reprints jammed pages. Select one of the following options: Auto: The printer attempts to reprint jammed pages when sufficient memory is available. This is the default setting. Off: The printer does not attempt to reprint jammed pages. Because no memory is used to store the most recent pages, performance is optimal. NOTE: When using this option, if the printer runs out of paper and the job is being printed on both sides, some pages can be lost. On: The printer always reprints jammed pages. Additional memory is allocated to store the last few pages printed. This might cause a decrease in overall performance.
	Auto Recovery				Enabled Disabled*	The printer attempts to reprint jammed pages when sufficient memory is available. This is the default setting.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Enable AutoSend				Disabled Enabled*	Use the Enable AutoSend menu to enable or disable the AutoSned feature. The AutoSend feature enables your product to periodically send product configuration information including serial number, event logs, page usage counts, and supplies status information to HP web addresses (URLs), or email addresses. Information sent to HP is used to improve products and services, and to monitor the product if you have a relationship with HP that provides you services such as proactive cartridge replacement, pay-per-page contracts, support agreements, or usage tracking.
	Hold Off Print Job				Enabled* Disabled	Enable this feature if you want to prevent print jobs from starting while a user is initiating a copy job from the control panel. Held print jobs start printing after the copy job is finished, provided that no other copy job is in the print queue.
Copy/Print	Copy Settings	Image Preview				Display a preview of the image before printing it.
	Enable Print from USB Drive				Enabled Disabled*	Enables the printer to open a file from a USB drive.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Manage Stored Jobs	Job Sort Order			Job Name* Date	This option allows you list the jobs either alphabetically or chronologically.
		Retain Temporary Jobs After Reboot			Do not retain* Personal jobs only All temporary jobs	Sets which temporary jobs will be retained in the event of a printer reboot.
		Temporary Job Storage Limit			1-300 Default = 32	Configure global settings for jobs that are stored in the printer memory. The Temporary Job Storage Limit feature specifies the number of temporary jobs that can be stored on the printer. The maximum allowed value is 300.
		Temporary Stored Job Retention			Off* 30 minutes 1 hour 4 hours 1 day 3 days 1 week 4 weeks	Configure global settings for jobs that are stored in the printer memory. The Temporary Stored Job Retention feature specifies the number of temporary jobs that can be stored on the printer. The maximum allowed value is 300.
		Standard Stored Job Retention			Off* 30 minutes 1 hour 4 hours 1 day 3 days 1 week 4 weeks	Configure global settings for jobs that are stored in the printer memory. The Temporary Stored Job Retention feature specifies the number of standard jobs that can be stored on the printer. The maximum allowed value is 300.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Default Print Options	Number of Copies		Range: 1-32000 Default = 1	Sets the default number of copies for a copy job. This default applies when the Copy function or the Quick Copy function is initiated from the printer Home screen.	
		Paper Selection		Select from a list of sizes that the printer supports.	Configures the default paper size used for print jobs.	
		Default Custom Paper Size	X Dimension	Range: 3-8.5 inches Default = 8.5 inches	Configures the default paper size that is used when the user selects **Custom** as the paper size for a print job.	
			Y Dimension	Range: 5-14 inches Default = 14 inches		
			Use Inches	Enabled* Disabled		
		Output Sides			1-sided* 2-sided	Use to indicate whether the original document is printed on one or both sides, and whether the copies should be printed on one or both sides. For example, select the 1-sided original, 2-sided output option when the original is printed on one side, but you want to make two-sided copies.
		Fit to Page (PDF)			On Off*	Use this feature to reduce or enlarge the image/content of each page to fit the currently selected paper size.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Fit to Page (TIFF, BMP, JPG, PNG)			On Off*	Use this feature to reduce or enlarge the image/content of each page to fit the currently selected paper size.
		Quality and Speed			Quick View Normal* Fine Lines	
	Envelope Rotate				Off* 90 Degrees 180 degrees	Use this feature to enable rotation when printing on envelopes. Envelopes are usually loaded into the printer as short-edge feed. However, if the Envelope Rotate function is enabled, you can load envelopes as long-edge feed. The printer rotates the image to be printed so that it appears correctly on the envelopes. • **Off (default):** Load envelopes in short-edge feed direction. • **90 degrees:** Load envelopes in long-edge feed direction. • **180 degrees:** Load envelopes in short-edge feed direction with the flap on the bottom side.
	PCL and PostScript Settings	Suppress Blank Pages			Off* On	When set to On, any blank pages will not be printed.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Courier Font			Regular* Dark	Select which version of the Courier font you want to use. The factory default setting is Regular, which uses an average stroke width. The Dark setting can be used if a heavier Courier font is needed.
		Print PS Errors			Enabled Disabled*	Use this feature to select whether a PostScript (PS) error page is printed when the printer encounters a PS error.
		Print PDF Errors			Enabled Disabled*	Selects whether a PDF error page is printed when the printer encounters a PDF error.
		Personality			Auto* PCL PS PDF	Configures the default print language or personality for the printer. Normally you should not change the printer language. If you change the setting to a specific printer language, the printer does not automatically switch from one language to another unless specific software commands are sent to it.
		PCL	Font Settings	Font Source	Internal Disk resident	Selects the font source for the user-soft default font. The list of available options varies depending on the installed printer options.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
				Font Number	Range: 0-110 Default = 0	Specifies the font number for the user-soft default font using the source that is specified in the Font Source menu. The printer assigns a number to each font and lists it on the PCL font list. The font number displays in the Font # column of the printout.
				Font Pitch	Range: 0.44-99.99 Default = 10	If the Font Source option and the Font Number setting indicate a contour font, then use this feature to select a default pitch (for a fixed-spaced font).
			PCL Settings	Form Length	Range: 5-128 Default = 60	Controls the PCL print-command options. PCL is a set of printer commands that HP developed to provide access to printer features. Use the Form Length feature to select the user-soft default vertical form length.
				Orientation	Portrait* Landscape	Select the orientation that is most often used for copy or scan originals. Select the Portrait option if the short edge is at the top or select the Landscape option if the long edge is at the top.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
				Symbol Set	Select from a list of symbol sets.	Select any one of several available symbol sets from the control panel. A symbol set is a unique grouping of all the characters in a font. The factory default value for this option is PC-8. Either PC-8 or PC-850 are recommended for line-draw characters.
				Append CR to LF	No* Yes	Configure whether a carriage return (CR) is appended to each line feed (LF) encountered in backwards-compatible PCL jobs (pure text, no job control). Select Yes to append the carriage return. The default setting is No. Some environments, such as UNIX, indicate a new line by using only the line-feed control code. This option allows the user to append the required carriage return to each line feed.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
				Media Source Mapping	Standard* Classic	Use to select and maintain input trays by number when you are not using the printer driver, or when the software program has no option for tray selection. The following options are available: Standard: Tray numbering is based on newer HP LaserJet models. Classic: Tray numbering is based on HP LaserJet 4 and older models.
	Print Quality	Adjust paper types			Select from a list of paper types Reset Paper Types	If print quality problems occur, use this menu to adjust the Print Mode for the paper type in use. If a user-defined type (enabled in the Embedded Web Server) has Pre-printed content that makes the sides of the paper different, set the paper type as **Marked Paper**.
		REt			On* Off	Use this feature to enable Resolution Enhancement technology (REt), which produces print output with smooth angles, curves, and edges.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Manage Trays	Use Requested Tray			Exclusively* First	Controls how the printer handles jobs that have specified a specific input tray. Two options are available: Exclusively: The printer never selects a different tray when the user has indicated that a specific tray should be used, even if that tray is empty. First: The printer pulls from another tray if the specified tray is empty, even though the user specifically indicated a tray for the job.
		Manually Feed Prompt			Always* Unless loaded	Indicate whether a prompt should appear when the type or size for a job does not match the specified tray and the printer pulls from the multipurpose tray instead. Two options are available: Always: A prompt always displays before using the multipurpose tray. Unless loaded: A message displays only if the multipurpose tray is empty.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Size/Type Prompt			Display* Do not display	Controls whether the tray configuration message displays whenever a tray is closed. Two options are available: Display: Shows the tray configuration message when a tray is closed. The user is able to configure the tray settings directly from this message. Do not display: Prevents the tray configuration message from automatically appearing.
		Use Another Tray			Allow* Do not allow	Use to turn on or off the control panel prompt to select another tray when the specified tray is empty. Two options are available: Enabled: When this option is selected, the user is prompted either to add paper to the selected tray or to choose a different tray. Disabled: When this option is selected, the user is not given the option of selecting a different tray. The printer prompts the user to add paper to the tray that was initially selected.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Alternative Letterhead Mode			Off* On	Use to load letterhead or Pre-printed paper into the tray the same way for all print jobs, whether you are printing to one side of the sheet or to both sides of the sheet. When this option is selected, load the paper as you would for printing on both sides. See the user documentation that came with the printer for instructions about loading letterhead for printing on both sides. When this option is selected, the printer speed slows to the speed required for printing on both sides.
		Duplex Blank Pages			Automatic* Always	Controls how the printer handles two-sided jobs (duplexing). Two options are available: Auto: Enables Smart Duplexing, which instructs the printer not to process blank pages. Yes: Disables Smart Duplexing and forces the duplexer to flip the sheet of paper even if it is printed on only one side. This might be preferable for certain jobs that use paper types such as letterhead or Pre-punched paper.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Image Rotation			Left to right* Right to left Alternate	The Image Rotation setting allows alternatives affecting how Pre-printed paper is loaded into the tray **NOTE:** For stapled print or copy jobs, make sure the Staple/ Collate setting matches the Image Rotation setting as to which side of paper (left or right) you want stapled. If these setting do not match each other, you will need to change the loading orientation of the paper so that the job is stapled in the correct spot.
		Override A4/Letter			Yes* No	Prints on letter-size paper when an A4 job is sent but no A4-size paper is loaded in the printer (or to print on A4 paper when a letter-size job is sent but no letter-size paper is loaded). This option will also override A3 with ledger-size paper and ledger with A3-size paper.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Unsupported Size Behavior			Use default size automatically* Prompt for user response	Use this feature to print documents that are on a paper size that the product does not support • Select Use default size automatically to use the paper size selected in Default Print Options. • Select Prompt for user response to be asked to use the size selected in Default Print Options or to cancel the job.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Rotate Offset NOTE: When set to Automatic, rotation does not occur if: • The tray is specified in the job and the User Selected Tray setting is set to Exclusively. • The specified bin in the job does not support both orientations. • The job is uncollated. • The job is collated, but only has one sheet per copy. • The job has mixed paper size or type. • The user selects a different paper after the job has started. • A job setting works only with a specific orientation. • The Job Offset setting is available and set to On.			Automatic Off*	Use this feature to separate each copy by rotating its position in the output bin. Two options are available: Off: Jobs are printed normally with separating each copy. Automatic: Copies are rotated automatically.
		Tray Priority			Tray 4 Tray 3 Tray 2 Tray 1	You can set the tray priority. If first setting is Tray 1, the printer automatically prints from Tray 1 after the current tray runs out of paper.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Tray Protection			**NOTE:** You can select all but one of the trays. At least one tray must be unselected at all times Tray 4 Tray 3 Tray 2 Tray 1	When this option is chosen, the selected tray will be protected. This prevents paper from being fed if Use Another Tray is enabled. If you select Tray 1, for example, then Tray 1 is excluded when using another tray.
		Paper Out Action			Auto Continue Time-Out Auto Continue Action	Specify the action the printer will take when the paper configured for the print job does not match the paper loaded in the input tray
Scan/Digital Send	Scan+ Settings			Image Preview	Make optional* Require preview Disable preview	Use this menu to configure settings that affect scan apps.
	E-mail Settings	E-mail Setup **NOTE:** Email Settings only				Use to configure settings that apply to sending documents through email or saving documents to a folder on the network or on a USB multi-drive. The E-mail Setup Wizard feature configures the printer to send scanned images as email attachments. To open the printer HP Embedded Web Server and set up the email notification server, enter the printer IP address into a Web browser.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Image Preview			Make optional* Require preview Disable preview	Defines the default job options for each function. If you do not specify the job options when creating the job, the default options are used. For complete setup, go to the HP Embedded Web Server by typing the IP address of the printer into a Web browser. Use the Image Preview feature to scan a document and display a preview before completing the job. Select whether this feature is available on the printer. Make optional: The feature is optional, depending on the user who is signed in. Require preview Previews are required for all users. Disable preview: Previews are disabled for all users.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Network Folder Settings	Image Preview			Make optional* Require preview Disable preview	Defines the default job options for each function. If you do not specify the job options when creating the job, the default options are used. For complete setup, go to the HP Embedded Web Server by typing the IP address of the printer into a Web browser. Use the Image Preview feature to scan a document and display a preview before completing the job. Select whether this feature is available on the printer. Make optional: The feature is optional, depending on the user who is signed in. Require preview Previews are required for all users. Disable preview: Previews are disabled for all users.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	SharePoint Settings	Image Preview			Make optional* Require preview Disable preview	Defines the default job options for each function. If you do not specify the job options when creating the job, the default options are used. For complete setup, go to the HP Embedded Web Server by typing the IP address of the printer into a Web browser. Use the Image Preview feature to scan a document and display a preview before completing the job. Select whether this feature is available on the printer. Make optional: The feature is optional, depending on the user who is signed in. Require preview Previews are required for all users. Disable preview: Previews are disabled for all users.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Scan to USB Drive Settings	Image Preview			Make optional* Require preview Disable preview	Defines the default job options for each function. If you do not specify the job options when creating the job, the default options are used. For complete setup, go to the HP Embedded Web Server by typing the IP address of the printer into a Web browser. Use the Image Preview feature to scan a document and display a preview before completing the job. Select whether this feature is available on the printer. Make optional: The feature is optional, depending on the user who is signed in. Require preview Previews are required for all users. Disable preview: Previews are disabled for all users.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Digital Sending Software Setup	Allow Use of a DSS Server Allow Transfer to New DSS server			Disabled Enabled*	Configure how the printer interacts with the HP Digital Sending Software (DSS) server. HP DSS handles digital sending tasks, such as faxing, emailing, and sending scanned documents to a network folder or USB storage device. Use the Allow Use of a DSS Server and Allow Transfer to New DSS server options to configure the printer to use HP DSS.
Fax	Internal Fax Modem Setup	Line 1 Line 2				
	Fax Send Settings	Image Preview				
		Fax Dialing Settings	Line Monitor Volume		Off Low* High	These settings control how the fax modem dials the outgoing fax number when faxes are sent.
			Dialing Mode		Tone* Pulse	
			Redial Interval		1-5 Minutes Default = 5 minutes	
			Fax Send Speed		Fast* Medium Slow	
			Dialing Prefix			
			Detect Dial Tone			
			Redial on Error		Range: 0-9 Default = 2	

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			Redial on No Answer		Range: 0-2 Default = 0	
			Redial on Busy		Range: 0-9 Default = 3	
		General Fax Send Settings	Fax Number Confirmation		Enabled Disabled*	If this feature is enabled, you must enter the fax number twice.
			Fax Line Selection		Automatic* Line 1 Line 2	
			PC Fax Send		Enabled* Disabled	Enables users who have the correct driver installed to send faxes through the printer from their computers.
			Error Correction Mode	Line 1* Line 2	Enabled* Disabled	When error-correction mode is enabled and an error occurs during fax transmission, the printer sends or receives the error portion again.
			Fax Header		Prepend* Overlay	Use to prepend or overlay the fax header page.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Billing Code Settings	Enable Billing Codes		Off* On	When billing codes are enabled, a prompt displays that asks the user to enter the billing code for an outgoing fax. This prompt does not appear if the Allow users to edit billing codes check box is not checked. You can also use the billing codes report in the Reports menu to view the list of the billing codes that have been used for faxes that have been sent from the printer. The list is grouped by billing code and also shows fax details. This feature can be used for billing or usage tracking.
			Default Billing Code			Specify a default billing code for faxing. If you specify a default billing code, this code displays in the Billing Code field when the user sends an outgoing fax. If this field is blank, no default billing code is provided for the user.
			Minimum Length		Range: 1-16 Default = 1	Specify the required length of the billing code. Billing codes can be between 1 and 16 characters long.
			Allow users to edit billing codes		Off On*	
	Fax Receive Settings	Fax Receive Setup	Ring Volume		Off Low* High	Use to configure settings for receiving faxes.
			Rings To Answer		Range: 1-6 Default = 1	

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			Fax Receive Speed		Fast* Medium Slow	
		Fax Printing Schedule			Always store faxes Always print faxes* Use Fax Printing Schedule	If you have concerns about the security of private faxes, use this feature to store faxes rather than having them automatically print. Open the Fax Printing Schedule sub-menu, and then you can choose to always store faxes, always print them, or you can set up a schedule for each day of the week.
			Schedule Touch this to set up a fax printing schedule if you selected the Use Fax Printing Schedule option.	+ (Add) Edit Delete (trash can)	Print incoming faxes Store incoming faxes Time Event Days	If you are using a fax printing schedule, use this menu to configure when to print faxes.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Blocked Fax Numbers	Fax Number to Block			The blocked fax list can contain up to 30 numbers. When the printer receives a call from one of the blocked fax numbers, it deletes the incoming fax. It also logs the blocked fax in the activity log along with job-accounting information. Add blocked numbers: Enter a fax number into the Fax Number to Block field, and then touch the arrow button to add a new number to the blocked fax list. To remove blocked numbers: Select a number and touch the Delete button to delete it from the blocked fax list. To clear all blocked numbers: Touch the Delete All button to clear all of the numbers from the blocked fax list. You also can use the Blocked Fax List report in the Information menu to view the list of the fax numbers that have been blocked on this printer.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
		Default Job Options	Notification		Do not notify* Notify when job completes Notify only if job fails	Configure to receive notification about the status of a sent document. Do not notify: Turns off this feature. Notify when job completes: Select to receive notification for this job only. Notify only if job fails: Select to receive notification only if the job is not sent successfully.
					Print E-mail*	E-mail: Select to receive the notification in an email. Touch the text box following Email Address, and then enter the email address for the notification.
				Include Thumbnail		**NOTE:** When sending an analog fax, select Include Thumbnail to receive a thumbnail image of the first page of the fax in your notification.
				Notification E-mail address		Touch this text field, provide the email address to which you want notifications sent, and then touch the OK button.
			Stamp Received Faxes		On Off*	Use this option to add the date, time, sender's phone number, and page number to each page of the faxes that this printer receives.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			Fit to Page		On* Off	Use to shrink faxes that are larger than Letter-size or A4-size so that they can fit onto a Letter-size or A4-size page. If this feature set to Disabled, faxes larger than Letter or A4 will flow across multiple pages.
			Paper Tray		Automatic* Select from a list of the trays.	
			Out Sides		1-sided* 2-sided Page flip up	Use to describe the layout for each side of the original document. First select whether the original document is printed on one side or both sides.
	Fax Forwarding	Enable Fax Forwarding			Disabled* Enabled	Use to forward received faxes to another fax machine.
			Type of Fax Job to Forward		All faxes Sent faxes Received faxes*	Use to select the type of fax jobs that you want forwarded.
			Fax Forwarding Method		IP Fax Internal Modem*	
			Fax Forwarding Number			Provide the forwarding phone number, and then touch the OK button.
	Clear Fax Activity Log					Clears all events from the fax activity log.
Manage Supplies	Low Warning Thresholds			Black Cartridge • ##% Document feeder kit • ##%		Set the estimated percentage at which the printer notifies you when a toner cartridge is very low.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Low Warning Threshold Message				On Off	Displays a message on the control panel when a cartridge is very low.
	Very Low Behavior	Black Cartridge Document Feeder Kit			Stop Continue Prompt to continue	
		Staples			Stop Prompt to continue	
	Delay Very Low Message			Stop Continue	Black Cartridge 0 pages*	After a supply reaches the very low state, the warning message can be delayed by a specified page count.
	Store Usage Data				On supplies Not on supplies	The Store Usage Data provides a way to suppress the toner cartridges from storing most of the information gathered exclusively for the purpose of understanding the usage of the printer. Select the On supplies setting to store the data on the toner cartridge memory chip. Select the Not on supplies setting to suppress the information from being stored on the memory chip.
	Supply Protection				Off* Protect Supplies	Select to permanently protect cartridges so that they can be used only in this product or fleet of products.
	Cartridge Policy				Off* Authorized HP	Set Authorized HP to allow only genuine HP cartridges to be used in this product.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
	Reset Supplies				Document Feeder Kit	After replacing a supply kit, select it from the list and touch "Reset."
Manage Stapler/ Stacker	Job Offset				On Off	
Developer Options						Use this menu to configure developer settings for the product.
Networking	Ethernet	INFORMATION	PRINT SECURITY REPORT		YES NO*	Yes: Prints a page that contains the current security settings on the HP Jetdirect print server. No: A security settings page is not printed.
		TCP/IP	HOST NAME		Use the arrow buttons to edit the host name. **NPIXXXXXX***	An alphanumeric string, up to 32 characters, used to identify the printer. This name is listed on the HP Jetdirect configuration page. The default host name is NPIxxxxxx, where xxxxxx is the last six digits of the LAN hardware (MAC) address.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			IPV4 SETTINGS	CONFIG METHOD	BOOTP DHCP* AUTO IP MANUAL	Specifies the method that TCP/IPv4 parameters will be configured on the HP Jetdirect print server. Bootp (Bootstrap Protocol): Use for automatic configuration from a BootP server. DHCP (Dynamic Host Configuration Protocol): Use for automatic configuration from a DHCPv4 server. If selected and a DHCP lease exists, the DHCP Release menu and the DHCP Renew menu are available to set DHCP lease options. Auto IP: Use for automatic link-local IPv4 addressing. An address in the form 169.254.x.x is assigned automatically. If you set this option to the Manual setting, use the Manual Settings menu to configure TCP/IPv4 parameters.
				DHCP RELEASE	YES NO*	
				DHCP RENEW	YES NO*	
				PRIMARY DNS	RANGE: 0-255 DEFAULT = **xxx.xxx.xx.xx**	Specify the IP address (n.n.n.n) of a Primary Domain Name System (DNS) Server.
				S DNS	Range: 0-255 Default = **0.0.0.0**	Specify the IP address (n.n.n.n) of a Secondary DNS Server.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			IPV6 SETTINGS	ENABLE	OFF ON*	Use this item to enable or disable IPv6 operation on the print server. Off: IPv6 is disabled. On: IPv6 is enabled.
				ADDRESS	MANUAL SETTINGS ENABLE ADDRESS	Use this item to enable and manually configure a TCP/IPv6 address.
				DHCPV6 POLICY	ROUTER SPECIFIED ROUTER UNAVAILABLE* ALWAYS	Router Specified: The stateful auto-configuration method to be used by the print server is determined by a router. The router specifies whether the print server obtains its address, its configuration information, or both from a DHCPv6 server. Router Unavailable: If a router is not available, the print server should attempt to obtain its stateful configuration from a DHCPv6 server. Always: Whether a router is available, the print server always attempts to obtain its stateful configuration from a DHCPv6 server.
				PRIMARY DNS	RANGE: 0-255 DEFAULT = **xxx.xxx.xx.xx**	Specify the IP address (n.n.n.n) of a Primary Domain Name System (DNS) Server.
				SECONDARY DNS	RANGE: 0-255 DEFAULT = **0.0.0.0**	Specify the IP address (n.n.n.n) of a Secondary DNS Server.

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			PROXY SERVER			Specifies the proxy server to be used by embedded applications in the printer. A proxy server is typically used by network clients for Internet access. It caches Web pages, and provides a degree of Internet security for those clients. To specify a proxy server, enter its IPv4 address or fully-qualified domain name. The name can be up to 255 octets. For some networks, you might need to contact your Internet Service Provider (ISP) for the proxy server address.
			PROXY PORT		DEFAULT = **00080**	Enter the port number used by the proxy server for client support. The port number identifies the port reserved for proxy activity on your network, and can be a value from 0 to 65535.
			IDLE TIMEOUT		DEFAULT = **0270**	The time period, in seconds, after which an idle TCP print data connection is closed (default is 270 seconds, 0 disables the timeout).
		SECURITY	SECURE WEB		HTTPS REQUIRED* HTTPS OPTIONAL	
			IPSEC		KEEP DISABLE*	
			FIREWALL		KEEP DISABLE*	

Table 4-10 Settings menu (continued)

First level	Second level	Third level	Fourth level	Fifth level	Values	Description
			802.1X		RESET KEEP*	
			ANNOUNCEMENT AGENT		ENABLE* DISABLE	
			RESET SECURITY		YES NO*	
			FIPS		KEEP RESET & REBOOT DEVICE	
		LINK SPEED			AUTO* 10T HALF 10T FULL 10T AUTO 100TX HALF 100TX FULL 100TX AUTO 1000T FULL	
	I/O Timeout				15 seconds* Range: 5 to 300	

Copy menu

To display: At the printer control panel, select the Copy menu.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-11 Copy menu

First level	Second level	Third level	Values	Description	
Sides	Original Sides		1-sided* 2-sided	Use to indicate whether the original document is printed on one or both sides.	
	Output Sides		1-sided 2-sided	Use to indicate whether the copies should be printed on one or both sides.	
Quick Sets and Defaults			Load Save		

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
Options	Sides	Original Sides	1-sided 2-sided		
		Output Sides	1-sided 2-sided		
	Watermark		None* Text Secure	Use this feature to add a watermark to the document • **Text:** Text is placed at the center of the page. • **Secure:** Background text and pattern that is barely visible on the first copy of a document.	
	Stamps		Top Left Top Center Top Right Bottom Left Bottom Center Bottom Right	Select up to six preset positions for a stamp and configure the content that will be printed there. Some positions might require selecting the stamp from a list of predefined options.	

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
	Image Overlay		Add New Image None*	Use this feature to add an image to each page of a copy job. After scanning and saving the desired image from the control panel, this image will be placed behind the content on each page of the copy job. **NOTE:** To use this feature, the images must be scanned from the scanner glass. Follow these steps to copy using an overlay image. 1. Touch Image Overlay, touch Add New Image, and then follow the on-screen instructions to scan the desired image from the scanner glass. **TIP:** For best results, use the same paper size and the same orientation for the saved image and the copy job. 2. Select the saved image that you want to add to each page of the copy job. 3. Start the copy job, or select the Preview option to preview the output.	

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
	Staple		None* Top left angled Two left Two to Top right angled Two right Top left or right	Sets the position of the staple on the page.	
	Hole Punch		None* Three left Two left Three top Two top Three right Two right Two bottom Four left Four right Four left or top		
		C-fold	Max sheets folded together Inward fold; opens left or up Inward fold; opens right or down Outward fold; opens left or up Outward fold; opens right or down	Controls the C-fold action of the booklet maker.	
	Scan mode		Standard Document Book Mode 2-sided ID	Book Mode allows the user to scan pages from a book. 2-sided ID allows the user to scan both sides of an identification card onto one sheet.	

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
	Reduce/Enlarge		Automatic* Manual • 25% • 50% • 63% (Letter to Statement) • 64% (11x17 to Letter) • 77% (11x17 to Legal) • 78% (Legal to Letter) • 85% (Letter to Exec) • 100% (Letter to Legal) • 105% (Exec to Letter) • 122% (Legal to 11x17) • 131% (Letter to 11x17) • 131% (Statement to Letter) • 150% • 200% • 400% • Custom1 • Custom2	Use to scale the size of the document up or down. Select one of the predefined percentages, or select the Scaling field and type a percentage between 25 and 400. The Auto option automatically scales the image to fit the paper size in the tray. **NOTE:** To reduce the image, select a scaling percentage that is less than 100. To enlarge the image, select a scaling percentage that is greater than 100.	
	Image Shift		Off* Automatically center Manual	Use this feature to shift the content of the page. This is useful for moving the image away from punched holes, staples, folds, or binding edges.	
	Original Size		Select from a list of sizes that the printer supports.	Describes the page size of the original document.	

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
	Paper Selection		Paper Size Paper Type Paper Tray	For the best color and image quality, select the appropriate paper type from the control panel menu or from the print driver.	
	Booklet	Booklet Format	(Checkbox)	Use to copy two or more pages onto one sheet of paper so you can fold the sheets in the center to form a booklet. The printer arranges the pages in the correct order. For example, if the original document has eight pages, the printer prints pages 1 and 8 on the same sheet.	
	Content Orientation		Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait orientation means the short edge of the page is along the top. Landscape orientation means the long edge of the page is along the top. In the Orientation area, select whether the original document has a portrait or landscape orientation.	
	Pages per Sheet		One (1) Two (2) Four (4)	Copies multiple pages onto one sheet of paper. **NOTE:** Before using this screen, use the Content Orientation screen to describe the original document orientation.	

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
	Image Adjustment	Sharpness		Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother.	
		Darkness		Use to improve the overall quality of the copy. Adjust the Darkness setting to increase or decrease the amount of white and black in the colors.	
		Contrast		Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page.	
		Background Cleanup		Adjust the Background Cleanup setting if you are having trouble copying a faint image.	
		Automatic Tone			
		Auto Paper Color Removal			

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
	Optimize Text/ Picture		Text Mixed* Printed picture Photograph	Use this setting to optimize the output for a particular type of content. Use **Text** for documents that contain mostly text. This option is also best suited for scanning documents with highlighter marks. Use **Mixed** for documents that contain a mix of text and graphics. Use **Printed picture** for line drawings and preprinted images, such as magazine clippings or pages from books. If you see bands of irregular intensity on copies, try selecting **Printed picture** to improve the quality. Use **Photograph** for photographic prints.	
	Erase Edges			Front Side • Top Edge • Bottom Edge • Left Edge • Right Edge Back Side • Top Edge • Bottom Edge • Left Edge • Right Edge	Use this feature to remove blemishes, such as dark borders or staple marks, by cleaning the specified edges of the scanned image. In each of the text boxes enter the measurements, in millimeters or inches, for how much of the top edge, bottom edge, left edge, and right edge to clean.

Table 4-11 Copy menu (continued)

First level	Second level	Third level	Values	Description	
	Collate		Collate on (Sets in page order)* Collate off (Pages grouped)	If you are making more than one copy, select the Collate on (Sets in page order) option to assemble the pages in the correct order in each set of copies. Select the Collate off (Pages grouped) option to group the same pages together. For example, if you are making five copies of an original document that has two pages, all five first pages would be grouped together and all five second pages would be grouped together.	
	Blank Page Suppression		Off* Suppress Blank Pages	When enabled, blank pages found in the original document are not included in the output document.	
	Automatically Straighten		Off* Automatically Straighten on	Enable this feature prior to scanning to automatically straighten the scanned image when pages are skewed during scanning.	
	Output Bin		Automatically select Output bin 1 Output bin 2 Alternate bin Lower booklet bin Standard bin Upper bin Middle bin		

Scan menu

To display: At the printer control panel, select the Scan menu.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-12 Scan menu

First level	Second level	Third level	Fourth level	Values	Description
Scan to Email	File Type and Resolution			File Type • PDF* • PDF/A • JPEG • TIFF • MTIFF • XPS Resolution • 600 dpi • 400 dpi • 200 dpi* • 150 dpi • 75 dpi Quality and File Size • Very Low (smaller file) • Low • Medium* • High • Very High (larger file)	Touch Options, and then touch File Type and Resolution to select the file format for the scanned image. Each file type has sub-settings, some of which affect resolution and file size. NOTE: If restricted by your administrator, some file types will be unavailable. • **PDF** (Portable Document Format) provides good image and text quality, and is a good choice for most documents. • **JPEG** is a good choice for most graphics. Most computers have a browser that can view .JPEG files. This file type produces one file per page. • **TIFF/MTIFF** TIFF (Tagged Image File Format) is a standard file format that many graphics programs support. This file type produces one file per page. MTIFF (Mult-page TIFF) saves multiple scanned pages in a single file. • **XPS** (XML Paper Specification) is a good choice for most types of printing. Viewing XPS documents requires a software program that is included with some operating systems.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Original Sides			Auto (keep sides with content) 1-sided* 2-sided Pages Flip Up	Use this feature to describe the layout for each side of the original document Use 1-sided for originals that are printed on one side of the page. Use 2-sided for originals that are printed on both sides of the page. Select Pages Flip Up for originals that flip on the top/bottom edge of the page, such as calendars.
	Color/Black			Automatically detect color or black* Automatically detect color or gray Color Black/Gray Black	Use this feature to enable or disable color scanning. • Select Automatically detect color or black when trying to create smaller file sizes. When pages without color are detected, the product creates an image of the page in 1-bit black if other settings allow. If the other settings don't allow (File Type, for example), the image is in gray. • Select Automatically detect color or gray for the best image quality for non-color pages. • Select Color to scan all documents in color. • Select Black/Gray to scan documents in grayscale. • Select Black to scan documents in black and white with a compressed file size.
	Watermark			None* Text	Use this feature to add a watermark to the document Text: Text is placed at the center of the page.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Stamps			Top Left Top Center Top Right Bottom Left Bottom Center Bottom Right	Select up to six preset positions for a stamp and configure the content that will be printed there. Some positions might require selecting the stamp from a list of predefined options.
	Scan Mode			Standard Document Book 2-sided ID Prompt for Additional Pages	Use this feature to provide information about the type of document to be scanned and to change the format of the output. Use Standard Document to scan regular documents using default scan settings. Use Prompt for Additional Pages to create a single job from multiple scans without having to do a preview. Use Book to scan the pages of an open book and to print the pages on separate sheets of paper. Use 2-sided ID to scan both sides of an ID and print them on one side of a sheet of paper.
	Original Size			Select from a list of sizes that the printer supports.	Describes the page size of the original document.
	Content Orientation			Automatically detect Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait orientation means the short edge of the page is along the top. Landscape orientation means the long edge of the page is along the top. Use Automatically detect when the format of the original document is known to specifically work with the Automatically detect setting. Using Automatically detect is not recommended in other circumstances.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Image Adjustment			Sharpness Darkness Contrast Background Cleanup	Use this feature to improve the overall quality of the scanned image. Adjust the Darkness setting to increase or decrease the amount of white and black in the colors. Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page. Adjust the Background Cleanup setting if you are having trouble copying a faint image. Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother.
	Optimize Text/Picture			Text Mixed* Printed Picture Photograph	Use this setting to optimize the output for a particular type of content. Use Text for documents that contain mostly text. This option is also best suited for scanning documents with a highlighter. Use Mixed for documents that contain a mix of text and graphics. Use Printed Picture for line drawings and Pre-printed images, such as magazine clippings or pages from books. If you see bands of irregular intensity on copies, try selecting Printed Picture to improve the quality. Use Photograph for photographic prints.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Erase Edges			Front Side • Top Edge • Bottom Edge • Left Edge • Right Edge Back Side • Top Edge • Bottom Edge • Left Edge • Right Edge	Use this feature to remove blemishes, such as dark borders or staple marks, by cleaning the specified edges of the scanned image. In each of the text boxes enter the measurements, in millimeters or inches, for how much of the top edge, bottom edge, left edge, and right edge to clean.
	Cropping Options			Do not crop* Crop to Paper Crop to Content	Use this menu item to specify a method to automatically crop the scan for digital sending. Use the Crop to Paper option to crop the scan to the edge of the document being scanned. Use the Crop to Content option to scan the smallest possible area that has detectable content. **NOTE:** The Crop to Paper option is effective only when you scan pages by using the document feeder. It has an unpredictable effect for pages that you scan from the glass.
	Automatically Straighten			Off* Automatically Straighten*	Enable this feature prior to scanning to automatically straighten the scanned image when pages are skewed during scanning.
	Blank Page Suppression			Off* Suppress Blank Pages	Use this feature to prevent blank pages in the original document from being included in the output document.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Create Multiple Files			Off* Maximum Pages Per File	Use this item to enable the product to separate scanned output into multiple files. Touch the Create Multiple Files check box. Enter the maximum number of pages for each output file in the Maximum Pages Per File field. When a file type that does not support multiple pages is selected, such as JPEG or TIFF, this feature is ignored. When scanning front and back sides, two pages are generated per original document. When scanning to email, the configuration option that specifies the maximum six of the email also interacts with this feature. In this case, the more restrictive of the two settings will take effect.
	Notification			Do Not Notify* Notify When Job Completes Notify Only If Job Fails	Use this feature to receive notification about the status of the sent document. • Select Do Not Notify to turn off this feature • Select Notify When Job Completes to receive notification for this job only. • Select Notify Only If Job Fails to receive notification only if the job is not sent successfully
	Signing and Encryption			Signing Signing Encrypt Encrypt	A digitally signed email ensures the recipient that you sent this email. An encrypted message can be opened only by the recipient.
Scan to Network Folder	File Name				
	Folder Paths				
	Quick Sets and Defaults				

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Options	File Type and Resolution		File Type Resolution Quality and File Size High Compression (smaller file) PDF Encryption	
		Original Sides		1-sided* 2-sided Pages Flip Up	Use this feature to describe the layout for each side of the original document Use 1-sided for originals that are printed on one side of the page. Use 2-sided for originals that are printed on both sides of the page. Select Pages Flip Up for originals that flip on the top/bottom edge of the page, such as calendars.
		Stamps		Top Left Top Center Top Right Bottom Left Bottom Center Bottom Right	Select up to six preset positions for a stamp and configure the content that will be printed there. Some positions might require selecting the stamp from a list of predefined options.
		Scan Mode		Standard document* Book 2-sided ID • Prompt for additional pages	Use this feature to provide information about the type of document to be scanned and to change the format of the output Use Standard document to scan regular documents using the default scan settings. Use Prompt for additional pages to create a single job from multiple scans without having to do a preview. Use Book to scan the pages of an open book and to print the pages on separate sheets of paper. Use 2-sided ID to scan both sides of an ID and print them on one side of a sheet of paper.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Original Size		Select from a list of supported sizes.	Use to describe the page size of the original document.
		Content Orientation	Orientation	Automatically Detect Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait orientation means the short edge of the page is along the top. Landscape orientation means the long edge of the page is along the top. In the Orientation area, select whether the original document has a portrait or landscape orientation. Use Automatically Detect when the format of the original document is known to specifically work with the Automatically Detect setting. Using Automatically Detect is not recommended in other circumstances.
		Image Adjustment		Sharpness Darkness Contrast Background Cleanup Automatic Tone Auto Paper Color Removal	Use to improve the overall quality of the copy. Adjust the darkness and sharpness, and you can use the Background Cleanup setting to remove faint images from the background or to remove a light background color. Adjust the Darkness setting to increase or decrease the amount of white and black in the colors. Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page. Adjust the Background Cleanup setting if you are having trouble copying a faint image. Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
			Contrast		Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page.
			Background Cleanup		Adjust the Background Cleanup setting if you are having trouble copying a faint image.
			Sharpness		Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother.
			Automatic Tone		The printer automatically adjusts the Darkness, Contrast, and Background Cleanup settings to the most appropriate for the scanned document.
			Auto Paper Color Removal (Flow models only)		
			Default		Select this to make the selected Image Adjustment setting the default value.
		Optimize Text/Picture	Automatically detect (Flow models only) Text Mixed* Printed picture Photograph		Use this setting to optimize the output for a particular type of content. Use **Text** for documents that contain mostly text. This option is also best suited for scanning documents with highlighter marks. Use **Mixed** for documents that contain a mix of text and graphics. Use **Printed picture** for line drawings and Pre-printed images, such as magazine clippings or pages from books. If you see bands of irregular intensity on copies, try selecting **Printed picture** o improve the quality. Use **Photograph** for photographic prints.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Erase Edges		Use inches Back side erase Front side erase	Use this menu item to remove blemishes, such as dark borders or staple marks, by cleaning the specified edges of the scanned image. In each of the text boxes enter the measurements, in millimeters or inches, for how much of the top edge, bottom edge, left edge, and right edge to clean.
		Cropping Options		Do not crop Crop to content Crop to paper	Use this menu item to automatically crop the scan for digital sending. Use the Crop to content option to scan the smallest possible area that has detectable content.
		Blank Page Suppression		Off* Suppress Blank	Use to prevent blank pages in the original document from being included in the output document.
		Automatically Straighten		Off* Automatically Straighten*	Enable this feature prior to scanning to automatically straighten the scanned image when pages are skewed during scanning.
		Multi-feed Detection		Off On* • Automatically Retry (z and z+ bundles only)	Use this feature to prevent multiple pages being fed through the document feeder during document scans.
		Create Multiple Files		Off* Maximum pages per file Blank page separator (z and z+ bundles only) • White page • Red/pink page • Green page • Yellow page • Any color page Barcode page separator (z and z+ bundles only)	Use this item to enable the product to separate scanned output into multiple files. Touch the Create Multiple Files check box. Enter the maximum number of pages for each output file in the Maximum pages per file field. When a file type that does not support multiple pages is selected, such as JPEG or TIFF, this feature is ignored. When scanning front and back sides, two pages are generated per original document. When scanning to email, the configuration option that specifies the maximum size of the email also interacts with this feature. In this case, the more restrictive of the two settings will take effect.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Notification		Do not notify Notify When Job Completes Notify Only If Job Fails	Configure to receive notification about the status of a sent document. Do not notify: Turns off this feature. Notify When Job Completes: Select to receive notification for this job only. Notify Only If Job Fails: Select to receive notification only if the job is not sent successfully.
Scan to USB Drive	Destination				
	File Name				
	Quick Set Defaults				
	Options	File Type and Resolution		File Type Resolution Quality and File Size High Compression (smaller file) PDF Encryption	
		Original sides		1-sided 2-sided	Use to describe the layout for each side of the original document. First select whether the original document is printed on one side or both sides. Then touch the Orientation setting to indicate whether the original has portrait or landscape orientation. If it is printed on both sides, also select the 2-sided format that matches the original document.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Color/Black		Automatically detect color or black* Automatically detect color or gray Color Black/Gray Black	Use this feature to enable or disable color scanning. • Select Automatically detect color or black when trying to create smaller file sizes. When pages without color are detected, the product creates an image of the page in 1-bit black if other settings allow. If the other settings don't allow (File Type, for example), the image is in gray. • Select Automatically detect color or gray for the best image quality for non-color pages. • Select Color to scan all documents in color. • Select Black/Gray to scan documents in grayscale. • Select Black to scan documents in black and white with a compressed file size.
		Original Size		Select from a list of supported sizes.	Use to describe the page size of the original document.
		Content Orientation		Automatically detect Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait orientation means the short edge of the page is along the top. Landscape orientation means the long edge of the page is along the top. In the Orientation area, select whether the original document has a portrait or landscape orientation. Use Automatically Detect when the format of the original document is known to specifically work with the Automatically Detect setting. Using Automatically Detect is not recommended in other circumstances.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Image Adjustment	Darkness	Sharpness Sharpness Darkness Contrast Background Cleanup Automatic tone Auto Paper Color Removal	Use to improve the overall quality of the copy. Adjust the darkness and sharpness, and you can use the Background Cleanup setting to remove faint images from the background or to remove a light background color. Adjust the Darkness setting to increase or decrease the amount of white and black in the colors. Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page. Adjust the Background Cleanup setting if you are having trouble copying a faint image. Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother.
			Contrast		Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page.
			Background Cleanup		Adjust the Background Cleanup setting if you are having trouble copying a faint image.
			Sharpness		Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother.
			Automatic Tone		The printer automatically adjusts the Darkness, Contrast, and Background Cleanup settings to the most appropriate for the scanned document.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
			Auto Paper Color Removal (Flow models only)		
			Default		Select this to make the selected Image Adjustment setting the default value.
		Optimize Text/Picture		Manually Adjust* Text Printed picture Photograph	Use to optimize the output for a particular type of content. You can optimize the output for text, printed pictures, or a mixture. Manually Adjust: Use to manually optimize the setting for text or for pictures. Text: Use to optimize the text portion of the copy when text and/or pictures are on the original. Printed picture: Use for line drawings and Pre-printed images, such as magazine clippings or pages from books. Photograph: Best suited for making copies of printed pictures.
		Erase Edges		Use inches Back side erase Front side erase	Use this menu item to remove blemishes, such as dark borders or staple marks, by cleaning the specified edges of the scanned image. In each of the text boxes enter the measurements, in millimeters or inches, for how much of the top edge, bottom edge, left edge, and right edge to clean.
		Cropping Options		Do not crop Crop to content Crop to paper	Use this menu item to automatically crop the scan for digital sending. Use the Crop to content option to scan the smallest possible area that has detectable content.
		Automatically Straighten		Off* Automatically Straighten*	Enable this feature prior to scanning to automatically straighten the scanned image when pages are skewed during scanning.
		Blank Page Suppression		Off* Suppress Blank Pages	Use to prevent blank pages in the original document from being included in the output document.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Multi-feed Detection		Off On* • Automatically retry (z and z+ bundles only)	Use this feature to prevent multiple pages being fed through the document feeder during document scans.
		Create Multiple Files		Off* Maximum pages per file Blank page separator (z and z+ bundles only) • White page • Red/pink page • Green page • Yellow page • Any color page Barcode page separator (z and z+ bundles only)	Use this item to enable the product to separate scanned output into multiple files. Touch the Create Multiple Files check box. Enter the maximum number of pages for each output file in the Maximum pages per file field. When a file type that does not support multiple pages is selected, such as JPEG or TIFF, this feature is ignored. When scanning front and back sides, two pages are generated per original document. When scanning to email, the configuration option that specifies the maximum size of the email also interacts with this feature. In this case, the more restrictive of the two settings will take effect.
		Notification		Do not notify Notify When Job Completes Notify Only If Job Fails	Configure to receive notification about the status of a sent document. Do not notify: Turns off this feature. Notify When Job Completes: Select to receive notification for this job only. Notify Only If Job Fails: Select to receive notification only if the job is not sent successfully.
			Include Thumbnail		Select Include Thumbnail to receive a thumbnail image of the first page of the job in your notification.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
Scan to Job Storage	Sides			Original Sides • 1-sided • 2-sided Output Sides • 1-sided • 2-sided	
	Scan Mode			Standard document* Book 2-sided ID	
	Reduce/ Enlarge			Automatic* Manual	
	Image Shift			Off* Automatically center Manual	
	Original Size			Select from a list of supported sizes.	Use to describe the page size of the original document.
	Paper Selection			Paper Size Paper Type Paper Tray	
	Booklet			Booklet Format	
	Content Orientation			Automatically detect Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait orientation means the short edge of the page is along the top. Landscape orientation means the long edge of the page is along the top. Use Automatically detect when the format of the original document is known to specifically work with the Automatically detect setting. Using Automatically detect is not recommended in other circumstances.
	Pages per Sheet			One Two Four (right, then down) Four (down, then right)	

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Image Adjustment			Sharpness Darkness Contrast Background Cleanup	
	Optimize Text/Picture			Automatically detect Text Mixed* Printed picture Photograph	
	Erase Edges			Front Side • Top Edge • Bottom Edge • Left Edge • Right Edge Back Side • Top Edge • Bottom Edge • Left Edge • Right Edge	
	Collate			Collate* Collate off	
	Blank Page Suppression			Off* Suppress Blank Pages	
	Automatically Straighten			Off* Automatically Straighten on	
	Multi-feed Detection			Off On* • Automatically Retry (z and z+ bundles only)	Use this feature to prevent multiple pages being fed through the document feeder during document scans.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
Scan to Sharepoint	Save Settings				Use this feature to save the current settings as the default settings for an app or to create a new Quick Set. First configure the desired options. Then touch Save and choose to either save the current settings as the default settings for the app or as a new Quick Set.
	File Type and Resolution			File Type Resolution Quality and File Size High Compression (smaller file) PDF Encryption	
	Original Sides			1-sided* 2-sided Pages Flip Up	Use this feature to describe the layout for each side of the original document Use 1-sided for originals that are printed on one side of the page. Use 2-sided for originals that are printed on both sides of the page. Select Pages Flip Up for originals that flip on the top/bottom edge of the page, such as calendars.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Color/Black			Automatically detect color or black* Automatically detect color or gray Color Black/Gray Black	Use this feature to enable or disable color scanning. • Select Automatically detect color or black when trying to create smaller file sizes. When pages without color are detected, the product creates an image of the page in 1-bit black if other settings allow. If the other settings don't allow (File Type, for example), the image is in gray. • Select Automatically detect color or gray for the best image quality for non-color pages. • Select Color to scan all documents in color. • Select Black/Gray to scan documents in grayscale. • Select Black to scan documents in black and white with a compressed file size.
	Scan Mode			Standard Document Book 2-sided ID Prompt for Additional Pages	Use this feature to provide information about the type of document to be scanned and to change the format of the output. Use Standard Document to scan regular documents using default scan settings. Use Prompt for Additional Pages to create a single job from multiple scans without having to do a preview. Use Book to scan the pages of an open book and to print the pages on separate sheets of paper. Use 2-sided ID to scan both sides of an ID and print them on one side of a sheet of paper.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Content Orientation			Automatically detect Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait orientation means the short edge of the page is along the top. Landscape orientation means the long edge of the page is along the top. Use Automatically detect when the format of the original document is known to specifically work with the Automatically detect setting. Using Automatically detect is not recommended in other circumstances.
	Image Adjustment			Sharpness Darkness Contrast Background Cleanup Automatic tone Auto Paper Color Removal	Use this feature to improve the overall quality of the scanned image. Adjust the Darkness setting to increase or decrease the amount of white and black in the colors. Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page. Adjust the Background Cleanup setting if you are having trouble copying a faint image. Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother. If you select the Automatic Tone options, the product automatically adjusts the Darkness, Contrast, and Background Cleanup settings to the most appropriate for the scanned document.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Optimize Text/Picture			Automatically detect Text Mixed* Printed picture Photograph	Use this setting to optimize the output for a particular type of content. Use Text for documents that contain mostly text. This option is also best suited for scanning documents with a highlighter. Use Mixed for documents that contain a mix of text and graphics. Use Printed picture for line drawings and Pre-printed images, such as magazine clippings or pages from books. If you see bands of irregular intensity on copies, try selecting Printed Picture to improve the quality. Use Photograph for photographic prints.
	Erase Edges			Front Side • Top Edge • Bottom Edge • Left Edge • Right Edge Back Side • Top Edge • Bottom Edge • Left Edge • Right Edge	Use this feature to remove blemishes, such as dark borders or staple marks, by cleaning the specified edges of the scanned image. In each of the text boxes enter the measurements, in millimeters or inches, for how much of the top edge, bottom edge, left edge, and right edge to clean.
	Cropping Options			Do not crop* Crop to Paper Crop to Content	Use this menu item to specify a method to automatically crop the scan for digital sending. Use the Crop to Paper option to crop the scan to the edge of the document being scanned. Use the Crop to Content option to scan the smallest possible area that has detectable content. **NOTE:** The Crop to Paper option is effective only when you scan pages by using the document feeder. It has an unpredictable effect for pages that you scan from the glass.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
	Blank Page Suppression			Off* Suppress Blank Pages	Use this feature to prevent blank pages in the original document from being included in the output document.
	Create Multiple Files			Off* Maximum pages per file Blank page separator (z and z+ bundles only) Barcode page separator (z and z+ bundles only)	Use this item to enable the product to separate scanned output into multiple files. Touch the Create Multiple Files check box. Enter the maximum number of pages for each output file in the Maximum Pages Per File field. When a file type that does not support multiple pages is selected, such as JPEG or TIFF, this feature is ignored. When scanning front and back sides, two pages are generated per original document. When scanning to email, the configuration option that specifies the maximum six of the email also interacts with this feature. In this case, the more restrictive of the two settings will take effect.
	Notification			Do not notify* Notify When Job Completes Notify Only If Job Fails	Use this feature to receive notification about the status of the sent document. • Select Do not notify to turn off this feature • Select Notify When Job Completes to receive notification for this job only. • Select Notify Only If Job Fails to receive notification only if the job is not sent successfully
Remote Scan Request					Use the Remote Scan Request app to scan and send documents requested by a remote computer. Remote scans are initiated on a computer with applications such as TWAIN Software or other AirPrint Compatible devices

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
Scan+	Common	Scan Shortcuts		Redact and Sign OCR Document Separation Barcode Separation Sticky Notes and Envelopes 2-sided ID	Scan Shortcuts can be used to quickly set up a job for specialty tasks.
		Auto Sense Preset		Fastest Scan Speeds Best Productivity (Recommended)	Auto Sense Presets make it easy to optimize a scan job for fastest scan speeds or best productivity. • Fastest Scan Speeds disables some automatic features, which requires less image processing and allows scanning at the fastest speeds available. • Best Productivity enables several automatic features, including automatic sides, automatic content orientation, automatic image straightening, and automatic image optimization. **NOTE:** Unlike Quick Sets, Auto Sense Preset presets do not affect destinations and recipients.
		Watermark		None* Text	Use this feature to add a watermark to the document • Text: Text is placed at the center of the page.
		Stamps		Top Left Top Center Top Right Bottom Left Bottom Center Bottom Right	Select up to six preset positions for a stamp and configure the content that will be printed there. Some positions might require selecting the stamp from a list of predefined options.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Notification		Do not notify* Notify When Job Completes Notify Only If Job Fails	Use this feature to receive notification about the status of the sent document. • Select Do not notify to turn off this feature • Select Notify When Job Completes to receive notification for this job only. • Select Notify Only If Job Fails to receive notification only if the job is not sent successfully
	Scan	Color/Black		Automatically detect color or black Automatically detect color or gray Color Black/Gray Black	If Automatically detect color or black is selected and the current settings do not allow scanning in black, pages will be scanned in grayscale.
		Create Multiple Files		Off* Maximum pages per file Blank page separator Barcode page separator	Use this item to enable the product to separate scanned output into multiple files. Touch the Create Multiple Files check box. Enter the maximum number of pages for each output file in the Maximum Pages Per File field. When a file type that does not support multiple pages is selected, such as JPEG or TIFF, this feature is ignored. When scanning front and back sides, two pages are generated per original document. When scanning to email, the configuration option that specifies the maximum size of the email also interacts with this feature. In this case, the more restrictive of the two settings will take effect.
		Signing and Encryption		Signing Encrypt	A digitally signed email ensures the recipient that you sent this email. An encrypted message can be opened only by the recipient.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Cropping Options		Do not crop* Crop to Paper Crop to Content	Use this menu item to specify a method to automatically crop the scan for digital sending. Use the Crop to Paper option to crop the scan to the edge of the document being scanned. Use the Crop to Content option to scan the smallest possible area that has detectable content. **NOTE:** The Crop to Paper option is effective only when you scan pages by using the document feeder. It has an unpredictable effect for pages that you scan from the glass.
	Copy	Number of Copies		Copies (1 to 9999)	Use this feature to set the number of printed copies.
		Output Sides		1-sided* 2-sided Pages flip-up	Use this feature to set the layout and format for the output. Select from the following options: • Use 1-sided for originals that are printed on one side of the page. • Use 2-sided for originals that are printed on both sides of the page. • Select Pages flip-up for originals that flip on the top/bottom edge of the page, such as calendars.
		Color/Black		Automatically detect* Color Black/Gray	Automatically detect: Prints color documents in color, and black and white documents in black and white. For mixed documents, the product will determine whether to print in color or black and white. Color: Prints documents in color. Black/Gray: Prints documents in grayscale.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Paper Selection		Paper Size Paper Type Paper Tray	Use this feature to select the paper for the job. Use Paper Size or Paper Type to enable the printer to automatically find the selected paper size or type. Use Paper Tray to select a source tray. Depending on the administrator's setting, the product will either print from that tray first, or it will limit printing from that tray.
	Fax	Resolution		Standard (100 x 200dpi) Fine (200 x 200dpi) Superfine (300 x 300dpi)	Select the resolution for outgoing faxes. If you increase the resolution, faxes might be clearer but they could transmit more slowly.
	Auto Sense	Original Sides		Auto (keep sides with content) 1-sided* 2-sided Pages Flip Up	Use this feature to describe the layout for each side of the original document Use 1-sided for originals that are printed on one side of the page. Use 2-sided for originals that are printed on both sides of the page. Select Pages Flip Up for originals that flip on the top/bottom edge of the page, such as calendars.
		Original Size		Select from a list of supported sizes.	Use to describe the page size of the original document.
		Content Orientation		Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait orientation means the short edge of the page is along the top. Landscape orientation means the long edge of the page is along the top.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Image Adjustment		Sharpness Darkness Contrast Background Cleanup Automatic Tone Auto Paper Color Removal	Use this feature to improve the quality of the scanned image. Adjusting Sharpness clarifies or soften the image. Increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother. Adjusting Darkness increases or decreases the amount of white and black in the colors. Adjusting Contrast increases or decreases the difference between the lightest and darkest color on the page. Adjust Background Cleanup to improve copying a faint image. Automatic Tone options automatically adjusts the Darkness, Contrast, and Background Cleanup settings. The Auto Paper Color Removal option dynamically adjusts the color balance and lightness of the background. Slide left: Most white paper with normal brightness is output as white background in the scanned output. Slider right: Very colorful paper/background colors are converted to white in the scanned output.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Optimize Text/Picture		Automatically detect Text Mixed* Printed picture Photograph	Use this setting to optimize the output for a particular type of content. Use Text for documents that contain mostly text. This option is also best suited for scanning documents with a highlighter. Use Mixed for documents that contain a mix of text and graphics. Use Printed picture for line drawings and Pre-printed images, such as magazine clippings or pages from books. If you see bands of irregular intensity on copies, try selecting Printed Picture to improve the quality. Use Photograph for photographic prints.
		Automatically Straighten		Off* Automatically Straighten	Enable this feature prior to scanning to automatically straighten the scanned image when pages are skewed during scanning.
		Blank Page Suppression		Off* Suppress Blank Pages	Use this feature to prevent blank pages in the original document from being included in the output document.
	Advanced	File Type and Resolution		File Type Resolution Quality and File Size High Compression (smaller file) DF Encryption	Select File Type and Resolution to select the file format for the scanned image. Each file type has sub-settings, some of which affect resolution and file size.

Table 4-12 Scan menu (continued)

First level	Second level	Third level	Fourth level	Values	Description
		Scan Mode		Standard Document Book 2-sided ID Prompt for Additional Pages	Use this feature to provide information about the type of document to be scanned and to change the format of the output. Use Standard Document to scan regular documents using default scan settings. Use Prompt for Additional Pages to create a single job from multiple scans without having to do a preview. Use Book to scan the pages of an open book and to print the pages on separate sheets of paper. Use 2-sided ID to scan both sides of an ID and print them on one side of a sheet of paper.
		Erase Edges		Front Side • Top Edge • Bottom Edge • Left Edge • Right Edge Back Side • Top Edge • Bottom Edge • Left Edge • Right Edge	Use this feature to remove blemishes, such as dark borders or staple marks, by cleaning the specified edges of the scanned image. In each of the text boxes enter the measurements, in millimeters or inches, for how much of the top edge, bottom edge, left edge, and right edge to clean.

Fax menu (when a fax option is installed)

To display: At the printer control panel, select the Fax menu.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-13 Fax menu (fax models only)

First level	Second level	Third level	Values	Description
Dialing Prefix Fax Recipients Quick Sets and Defaults				

Table 4-13 Fax menu (fax models only) (continued)

First level	Second level	Third level	Values	Description
Options	Original Sides		1-sided* 2-sided	Use to describe the layout for each side of the original document. First select whether the original document is printed on one side or both sides. Then touch the Orientation setting to indicate whether the original has portrait or landscape orientation. If it is printed on both sides, also select the 2-sided format that matches the original document.
	Watermark		None* Text • Watermark Text • Text Font • Text Size • Text Color	Use this feature to add a watermark to the document. • Text: Text is placed at the center of the page. **NOTE:** Flow models only.
	Stamps		None* Top Left Top Center Top Right Bottom Left Bottom Center Bottom Right	Select up to six preset positions for a stamp and configure the content that will be printed there. Some positions might require selecting the stamp from a list of predefined options. **NOTE:** Flow models only.
	Resolution		Standard (100 x 200dpi)* Fine (200 x 200dpi) Superfine (300 x 300dpi)	Select the resolution for outgoing faxes. If you increase the resolution, faxes might be clearer but they could transmit more slowly. Some file types, for example a file that will be processed with OCR, require a specific resolution. When these file types are selected, the Resolution setting might be automatically changed to a valid value.
	Original Size		Select from a list of sizes that the printer supports.	Use to describe the page size of the original document.

Table 4-13 Fax menu (fax models only) (continued)

First level	Second level	Third level	Values	Description
	Content Orientation	Orientation	Portrait* Landscape	For some features to work correctly, you must specify the way the content of the original document is placed on the page. Portrait: This setting means the short edge of the page is along the top. Landscape: This setting means the long edge of the page is along the top.
	Image Adjustment		Sharpness Darkness Contrast Background Cleanup Automatic tone Auto Paper Color Removal	Use to improve the overall quality of the copy. Adjust the darkness and sharpness, and you can use the Background Cleanup setting to remove faint images from the background or to remove a light background color. Adjust the Darkness setting to increase or decrease the amount of white and black in the colors. Adjust the Contrast setting to increase or decrease the difference between the lightest and darkest color on the page. Adjust the Background Cleanup setting if you are having trouble copying a faint image. Adjust the Sharpness setting to clarify or soften the image. For example, increasing the sharpness could make text appear crisper, but decreasing it could make photographs appear smoother.

Table 4-13 Fax menu (fax models only) (continued)

First level	Second level	Third level	Values	Description
	Optimize Text/Picture	Manually Adjust* Automatically detect **NOTE:** Flow models only.	Optimize For: Text Mixed Printed picture Photograph	Optimizes the output for a particular type of content. You can optimize the output for text, printed pictures, or a mixture. Manually Adjust: Use to manually optimize the setting for text or for pictures. Text: Use to optimize the text portion of the copy where text and/or pictures are on the original. Printed picture: Use for line drawings and Pre-printed images, such as magazine clippings or pages from books. Photograph: Best suited for making copies of printed pictures.
	Fax Line Selection		Automatic* Line 1 Line 2	HP MFP Analog Dual Fax 810 Accessory needs to be installed
	Blank Page Suppression		Disabled* Enabled	Prevents blank pages in the original document from being included in the output document.
	Automatically Straighten		Off* Automatically Straighten*	Enable this feature prior to scanning to automatically straighten the scanned image when pages are skewed during scanning.

Table 4-13 Fax menu (fax models only) (continued)

First level	Second level	Third level	Values	Description
	Notification		Do not notify* Notify when job completes Notify only if job fails	Use to receive notification about the status of a sent document. Do Not Notify: Turns off this feature. Notify When Job Completes: Select to receive notification for this job only. Notify Only If Job Fails: Select to receive notification only if the job is not sent successfully.

Print menu

To display: At the printer control panel, select the Print menu.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-14 Print Options menu

First level	Second level	Values	Description
Print from Job Storage	Stored Job to Print	Untitled Stored Faxes	Print a job stored on the printer.
Print from USB Drive	USB File to Print	Choose file to print on USB drive.	Print a job stored on a USB drive.
Fax Polling	Fax Polling Number		Use the Fax Polling app to print faxes sent to another fax machine.

Supplies menu

To display: At the printer control panel, select the Supplies menu.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-15 Supplies menu

First level	Values
Supplies Summary	

Table 4-15 Supplies menu (continued)

First level	Values
Black Cartridge	Status Order HP Part Pages Printed Approximate Pages Remaining
Toner Collection Unit Document Feeder Kit Stapler 1	Status Order HP Part

Trays menu

To display: At the printer control panel, select the Trays menu.

In the following table, asterisks (*) indicate the factory default setting.

Table 4-16 Trays menu

First level	Second level	Values	Description
Tray 1 Tray 2-x	Size	Select paper size from a list of supported sizes.	Choose the paper size for the tray
	Type	Select paper type from a list of supported types.	Choose the paper type for the tray.

Support Tools menu

The menus under the Support Tools menu contain the options for maintaining the printer and troubleshooting printer problems. Learn about these menus and settings.

Service menu

Use this menu to access features for diagnosing, maintaining, and repairing the product. You might be required to sign in to gain access to the Service menu.

- Service Access Code: 03086025

Table 4-17 Service menu


First level	Second level	Third level
Event Log		
Counts		
Coverage Report	All	
Coverage Report	Print	
Coverage Report	Copy	
Coverage Report	Fax	
Scanner Settings		
Serial Number		
Service ID		
Cold Reset Paper		
MPS Settings	Low Alerts	
MPS Settings	Reset Supplies Level	
MPS Settings	Consumables Access Control	
Advanced Service	Software Version	
Advanced Service	Service Reports	
Advanced Service	Adjustment	Print Adjustment
Advanced Service	Adjustment	Buckle Adjustment
Advanced Service	Adjustment	Finisher Adjustment
Advanced Service	*Calibration/Cleaning **NOTE:** Refer to the Maintenance menu map.	
Advanced Service	Advanced Diagnostics	Reset Engine NVM
Advanced Service	Advanced Diagnostics	Engine NVM Read/Write
Advanced Service	Advanced Diagnostics	Sensors
Advanced Service	Advanced Diagnostics	Component Tests
Advanced Service	Service Functions	TR Control Mode
Advanced Service	Service Functions	Low-temperature Idling Mode

Table 4-17 Service menu (continued)

First level	Second level	Third level
Advanced Service	Service Functions	Altitude Adjustment
Advanced Service	Service Functions	Humidity
Advanced Service	Service Functions	Vapor Mode
Advanced Service	Service Functions	Footer
Advanced Service	Service Functions	Low Volume Print Mode
PTT Test Mode		
Test Support		
Part Replacement Count		
Reset Supplies		
Fax V.29 Speed		

Event Log

Use this menu to view or print a list of the most recent 50 events in the Event Log. For each event, the log shows the event code, cycle (approximate page count), and description.



Event Log

Device Information

Product Serial Number: XXXXXXXXX

Number	Date and Time	Cycles	Event	Firmware	Description or Personality	Re
50	8/10/2021 3:15:25 PM	1396	44.34.04	debug.release.debug.20210730_0102.245_2481684	Fax Modem 2 failure	0
49	8/10/2021 3:15:25 PM	1396	44.34.03	debug.release.debug.20210730_0102.245_2481684	Fax Modem Failure	0
48	8/10/2021 1:34:25 PM	1396	48.A0.08	debug.release.debug.20210730_0102.245_2481684	The Usage Summary Data was Reset	0
47	8/10/2021 1:30:08 PM	1346	48.A0.08	debug.release.debug.20210730_0102.245_2481684	The Usage Summary Data was Reset	0
46	8/10/2021 1:22:48 PM	1246	48.A0.08	debug.release.debug.20210730_0102.245_2481684	The Usage Summary Data was Reset	0
45	8/10/2021 1:18:17 PM	1196	48.A0.08	debug.release.debug.20210730_0102.245_2481684	The Usage Summary Data was Reset	0
44	8/10/2021 1:05:28 PM	1100	48.A0.08	debug.release.debug.20210730_0102.245_2481684	The Usage Summary Data was Reset	0
43	8/10/2021 12:26:44 PM	1050	48.A0.08	debug.release.debug.20210730_0102.245_2481684	The Usage Summary Data was Reset	0
42	8/10/2021 12:22:22 PM	1050	13.89.A1	debug.release.debug.20210730_0102.245_2481684	Stopped at fuser jam. {0:5} (M2-1334)	0
41	8/10/2021 11:56:06 AM	980	13.89.A1	debug.release.debug.20210730_0102.245_2481684	Stopped at fuser jam. {0:5} (M2-1334)	0
40	8/10/2021 11:52:59 AM	950	48.A0.08	debug.release.debug.20210730_0102.245_2481684	The Usage Summary Data was Reset	0
39	8/10/2021 11:25:06 AM	800	10.99.40	debug.release.debug.20210730_0102.245_2481684	Genuine HP supplies installed	0
38	8/10/2021 11:24:46 AM	800	44.34.03	debug.release.debug.20210730_0102.245_2481684	Fax Modem Failure	0
37	8/10/2021 11:24:46 AM	800	44.34.04	debug.release.debug.20210730_0102.245_2481684	Fax Modem 2 failure	0
36	8/10/2021 11:23:28 AM	0	33.02.02	debug.release.debug.20210730_0102.245_2481684	Save/Recover disabled	0
35	8/10/2021 11:06:50 AM	800	44.34.04	debug.release.debug.20210805_2357.245_2481692	Fax Modem 2 failure	0
34	8/10/2021 11:06:50 AM	800	44.34.03	debug.release.debug.20210805_2357.245_2481692	Fax Modem Failure	0
33	8/10/2021 11:06:36 AM	800	33.02.02	debug.release.debug.20210805_2357.245_2481692	Save/Recover disabled	0
32	8/10/2021 11:05:33 AM	800	44.34.04	debug.release.debug.20210805_2357.245_2481692	Fax Modem 2 failure	0
31	8/10/2021 11:05:33 AM	800	44.34.03	debug.release.debug.20210805_2357.245_2481692	Fax Modem Failure	0
30	8/10/2021 11:03:06 AM	800	44.34.04	debug.release.debug.20210805_2357.245_2481692	Fax Modem 2 failure	0
29	8/10/2021 11:03:06 AM	800	44.34.03	debug.release.debug.20210805_2357.245_2481692	Fax Modem Failure	0
28	8/10/2021 11:02:52 AM	800	33.02.02	debug.release.debug.20210805_2357.245_2481692	Save/Recover disabled	0
27	8/9/2021 4:07:10 PM	800	44.34.04	debug.release.debug.20210805_2357.245_2481692	Fax Modem 2 failure	0
26	8/9/2021 4:07:10 PM	800	44.34.03	debug.release.debug.20210805_2357.245_2481692	Fax Modem Failure	0

Counts

Use this menu to see the total number of pages that have been printed to-date by various product components. Typically, this is only required when a new formatter is installed.

Before replacing the formatter, print a configuration page to obtain the current counts.

- **Service Count**: Total sum of Mono Service Count.
- **Mono Service Count**: This count tracks all media picked from all media sources on the device. For jobs with blank sides or interpreted as mono at the time of media pickup, this count will increment +1 (simplex) or +2 (duplex).
- **Refurbish Count**: Use this item to record the page count when the printer was refurbished.
- **Document Feeder Kit Count**: Total number of pages since the document feeder kit was replaced.
- **Document Feeder Kit Interval**: Use this item to set the interval that causes the printer to prompt the customer to replace document feeder kit.
- **Clean Rollers Count**: Total number of pages since the document feeder rollers were cleaned.
- **Clean Rollers Interval**: Use this item to set the interval that causes the printer to prompt the customer to clean the document feeder rollers and separation pad.
- **ADF Count**: Total pages fed through the document feeder.
- **Flatbed Count**: Total pages scanned form the flatbed.
- **ADF Simplex Count**: Total single-sided pages fed through the document feeder.
- **ADF Duplex Count**: Total two-sided pages fed through the document feeder.
- **Copy Scan Count**: Total copy pages that have been scanned.
- **Send Scan Count**: Number of scanned pages sent to email.
- **Fax Scan Count**: Number of scanned pages that have been faxed.
- **Copy Pages Count**: Number of scanned pages that have been printed.

Coverage Report

Use this menu to print coverage reports based on print, copy, and fax jobs. The Reset button restores all estimation of coverages to default.

- **All:** This will print all average coverage values for a print, copy, and fax job.
- **Print:** This will print the last page coverage and average coverage values for a print job.
- **Copy:** This will print the last page coverage and average coverage values for copy job.

Scanner Settings

Use this menu to adjust Scanner setting value manually when a scanned area is inappropriate.


The Clear All button restores all scanner setting values to default.

NOTE: Select the adjustable items on the control panel and adjust the values accordingly.

- **Glass – Left edge**: Default is 0. It can be adjusted from -20 to +20.
- **Glass – Rear edge**: Default is 0. It can be adjusted from -25 to +25.
- **ADF – Leading front edge**: Default is 0. It can be adjusted from -200 to +200.
- **ADF – Leading back edge**: Default is 0. It can be adjusted from -200 to +200.
- **ADF – Trailing front edge**: Default is 0. It can be adjusted from -200 to +200.
- **ADF – Trailing back edge**: Default is 0. It can be adjusted from -200 to +200.
- **ADF – Left side front**: Default is 0. It can be adjusted from -120 to +120.
- **ADF – Left side back**: Default is 0. It can be adjusted from -120 to +120.


NOTE: Negative values crop the edge less and positive values crop the edge more.

Figure 4-21 **Examples of scanner settings**



- **ADF – Feed direction magnification**: Default is 100%. It can be adjusted from 97% to 103%.

Figure 4-22 Examples of Feed direction magnification settings



Serial Number

Use this menu to set the product serial number.

IMPORTANT: Modify the serial number only after replacing the formatter.

Service ID

Use this menu to display the date that the product was first used.

The Service ID menu eliminates the need to keep paper receipts for proof of warranty.

Cold Reset Paper

Use this menu to reset the default paper size after the replacement of a formatter board in a location using a different standard paper size.

NOTE: The product will restart automatically when this setting changes.

Low Alerts

Use this menu to enable or disable the Supplies Low message.

The Supplies Low message can be enabled or disabled in these locations:

- Control panel
- SNMP alerts
- Remote monitoring tools, such as the Embedded Web Server

Disabling low alerts has the following effects:

- Supplies Low messages are suppressed.
- Supplies Very Low messages still appear.

- The supplies status levels are visible in all locations.
- The control panel menu options for configuring the Low Message and the Low Threshold Settings are available, but they have no effect.

Reset Supplies Level

Use this menu to reset customized settings for Supplies Low and Supplies Very Low messages and alerts.

IMPORTANT: Use this menu for products that are under a service agreement with HP.

- **Reset to Level 1**: When this option is selected, standard menus for Supplies Very Low are available, and the Supplies Low Threshold is set to 0%. The Supplies Low messages are enabled and Low Alerts are enabled. Customer can modify the Supplies Low Threshold and the Low message behavior.
- **Reset to Level 2**: When this option is selected, standard menus for Supplies Very Low are available, and the Supplies Low Threshold is set to 0%. The Supplies Low messages are off and Low Alerts are enabled. Customer can modify the Supplies Low Threshold and the Low message behavior.
- **Reset to Level 3**: When this option is selected, standard menus for Supplies Very Low are available, and the Supplies Low Threshold is set to 0%. The Supplies Low messages are off and Low Alerts are disabled. Customer can modify the Supplies Low Threshold and Low Message settings are set to standard values for a product that is not under a service agreement with HP.
- **Set to non-HP managed mode**: When this option is selected, the menu for Supplies Very Low is removed. The Supplies Low Threshold and Low Message settings are set to standard values for a product that is not under a service agreement with HP.


Consumables Access Control

Use this menu to lock toner cartridges into the product to help prevent early replacement.

Each cartridge will automatically unlock when it reaches the replacement threshold or encounters an error. Signing in with Admin or Service credentials will also unlock all cartridges for the duration of the session.

The settings are as follows:

- **Unchecked**: Disables this function. The Eject button is always selectable.
- **Checked**: Enables this function. If a toner cartridge is in the locked state, the Eject button is not selectable.



Software Version

Use this menu to see the following software versions.

- Engine Firmware Version
- Tray 2 Version
- Tray 3 Version
- Tray 4 Version
- Tray 5 Version
- Finisher Version (*Optional)
- Booklet Version (*Optional)
- Punch Version (*Optional)
- EP Version
- Toner Version
- TR Version
- Fuser Version

Service Reports

Use this menu to print the following reports.

- Supplies Information Report
- Auto Toning History

Print Adjustment

Use this menu to adjust the image position manually and perform the Print Margin Test when the printed area is inappropriate, or the printed image is skewed to one side.

- Image Position

- **Select Tray**: Select the tray that needs to be adjusted.
- **Front-side Horizontal Shift**: Default is 0. It can be adjusted from -4 to +4.

  +: The printed image will be shifted to the right.

  -: The printed image will be shifted to the left.
- **Front-side Vertical Shift**: Default is 0. It can be adjusted from -4 to +4.

  +: The printed image will be shifted downward.

  -: The printed image will be shifted upward.
- **Back-side Horizontal Shift**: Default is 0. It can be adjusted from -4 to +4.


  +: The printed image will be shifted to the right.

  -: The printed image will be shifted to the left.
- **Back-side Vertical Shift**: Default is 0. It can be adjusted from -4 to +4.

  +: The printed image will be shifted downward.

  -: The printed image will be shifted upward.
- **Apply to all Trays**: If it is checked, all trays will be affected.

  Figure 4-23 **Examples of image position shifts**



- Print Margin Test
  - **A3 Skew Pattern**: If this option is selected, the printer will print the A3 skew pattern.
  - **A4 Skew Pattern**: If this option is selected, the printer will print the A4 skew pattern.
  - **11x17 Skew Pattern**: If this option is selected, the printer will print the 11x17 skew pattern.
  - **Letter Skew Pattern**: If this option is selected, the printer will print the Letter skew pattern.


Buckle Adjustment

Use this menu to adjust the Registration Curl value when a printed image has a skew.

IMPORTANT: Check the paper guide on the tray before performing the Buckle Adjustment.

- **Process Speed**: Default is Full. Select the appropriate speed for the paper type.
- **Fast Feed**: Default is Off. If On is selected, the printer will feed paper faster.
- **Print Side**: Default is Simplex. Select the appropriate print side.
- **Paper Source**: Default is Tray 1. Select the appropriate tray.
- **Registration Curl**: Default is 0. It can be adjusted form -5 to +5.

Figure 4-24 **Typical faulty image**



Finisher Adjustment

Use this menu to adjust settings related to the finisher, such as staple position, folding position, punch hole position, tamper position, and eject level.


NOTE: This menu will only be shown when a finisher is installed.

- **Staple position**: Use this menu adjust the staple position on the paper.
  - **Single Front Corner STS**: Use this feature to adjust the front corner staple position on the paper.

    +: Move the staple position towards the center of the paper.

    -: Move the staple position towards the edge of the paper.

Figure 4-25 Front corner staple position




– **Single Rear Corner STS**: Use this feature to adjust the rear corner staple position on the paper.

  +: Move the staple position towards the center of the paper.

  -: Move the staple position towards the edge of the paper.

Figure 4-26 Rear corner staple position




– **Single Front Flat STS**: Use this feature to adjust the front flat staple position on the paper.

  +: Move the staple position towards the center of the paper.

  -: Move the staple position towards the edge of the paper.

Figure 4-27 Front flat staple position




– **Single Rear Flat STS**: Use this feature to adjust the rear flat staple position on the paper.

  +: Move the staple position towards the center of the paper.

  -: Move the staple position towards the edge of the paper.

Figure 4-28 Rear flat staple position




– **Dual Front STS**: Use this feature to adjust the front staple position of the dual staple on the paper

NOTE: This menu will only be shown when a booklet finisher or stapler/stacker finisher is installed.

+: Move the staple position towards the center of the paper.

-: Move the staple position towards the edge of the paper.

Figure 4-29 **Dual front staple position**




– **Dual Rear STS**: Use this feature to adjust the rear staple position of the dual staple on the paper

NOTE: This menu will only be shown when a booklet finisher or stapler/stacker finisher is installed.

+: Move the staple position towards the center of the paper.

-: Move the staple position towards the edge of the paper.

Figure 4-30 Dual rear staple position




– **Dual All STS**: Use this feature to adjust the dual staple position on the paper.

NOTE: This menu will only be shown when an inner finisher is installed

+: Move the staple position towards the center of the paper.

-: Move the staple position towards the edge of the paper.

Figure 4-31 Dual staple position




- **Punch Hole position**: Use this menu to adjust the position of punch holes on the paper.
  – **STS**: Use this feature to adjust the STS position of punched holes on the paper.

NOTE: This menu will only be shown when a booklet finisher or staple/stacker finisher is installed with a punch unit.

+: Move the position of punched holes towards the front of the device.

-: Move the position of punched holes towards the rear of the device.

Figure 4-32 Punched holes position (up/down)




– **DOF**: Use this feature to adjust the DOF position of punched holes on the paper.

NOTE: This menu will only be shown when a booklet finisher, stapler/stacker finisher, or inner finisher is installed with a punch unit.

+: Move the position of punched holes towards the center of the paper.

-: Move the position of punched holes towards the edge of the paper.

Figure 4-33 Punched holes position (left/right)



- **Enable Punch Scan**: Use this feature to enable the detection of leading edge of the paper when the punch is operating.
  – **On (default)**: Detect the leading edge of the paper for every page.


- **Off**: Detect the leading edge of the paper for the first page of the job.

- **Tamper Position**: Use this menu to adjust the tamper position.
  - **Front**: Use this feature to adjust the front tamper position.
  - **Rear**: Use this feature to adjust the rear tamper position.

    +: Move toward the compile center (away from the tamper home).

    -: Move away from the compile center (toward the tamper home).

    Figure 4-34 Tamper position



- **Finisher Eject Level**: Use this feature to adjust the eject level to reduce scattering.

  +: Higher level (increased feed time).

  -: Lower level (decreased feed time).

- **Disable Buffering Option**: Use this feature to align paper for stapling in staple jobs.

  Off (default): The buffering function is enabled.

  On: The buffering function is disabled. This will try to align the paper for stapling, but the job speed will be slower.


- **Manual Staple Position**: Use this feature to adjust the manual staple position.

NOTE: This menu item will only be shown when a booklet finisher or stapler/stacker finisher is installed.

+: Move the staple position towards the center of the paper.

-: Move the staple position towards the edge of the paper.

Figure 4-35 Manual staple position



- **Booklet Staple Position**: Use this menu to adjust the staple position of printed booklets for supported paper sizes.


NOTE: This menu item will only be shown when a booklet finisher is installed.

IMPORTANT: Select paper size you want to use in the menu.

+: Move the staple position towards the leading edge of the paper.

-: Move the staple position towards the trailing edge of the paper.

Figure 4-36 Booklet staple position



- **Booklet Folding Position**: User this menu to adjust the folding position of printed booklets for supported paper sizes.


NOTE: This menu will only be shown when a booklet finisher is installed.

IMPORTANT: Select paper size you want to use in the menu.

+: Move the folding position towards the leading edge of the paper.

-: Move the folding position towards the trailing edge of the paper.

Figure 4-37 Booklet fold position



- **Booklet C-Folding Position**: User this menu to adjust the c-folding of printed pages for supported paper sizes.


NOTE: This menu will only be shown when a booklet finisher is installed.

IMPORTANT: Select paper size you want to use in the menu.

+: Move the folding position towards the leading edge of the paper.

-: Move the folding position towards the trailing edge of the paper.

Figure 4-38 Booklet C-fold position



Reset Engine NVM

Use this menu to initialize the engine NVM (Non-Volatile Memory) read/write values to the default.

Engine NVM Read/Write

Use this menu to adjust the NVM configuration value for the printing engine operation.

Table 4-18 **Engine NVM Read/Write values**

Code	Name	Type	Default
109-0200	StandBy Center Temperature offset	Read/Write	10
109-0201	StandBy Side Temperature offset	Read/Write	10
109-0205	Warmup Center Temperature offset	Read/Write	10
109-0206	Warmup Side Temperature offset	Read/Write	10
109-0255	Light 60-74g Center Temperature offset	Read/Write	10
109-0256	Light 60-74g Side Temperature offset	Read/Write	10
109-0265	Plain Center Temperature offset	Read/Write	10
109-0266	Plain Side Temperature offset	Read/Write	10
109-0275	Heavy 111-130g Center Temperature offset	Read/Write	10
109-0276	Heavy 111-130g Side Temperature offset	Read/Write	10
109-0280	Extra Heavy 131-175g Center Temperature offset	Read/Write	10
109-0281	Extra Heavy 131-175g Side Temperature offset	Read/Write	10
109-0290	Cardstock Center Temperature offset	Read/Write	10
109-0291	Cardstock Side Temperature offset	Read/Write	10
109-0300	Envelope Center Temperature offset	Read/Write	10
109-0301	Envelope Side Temperature offset	Read/Write	10
109-0305	Labels Center Temperature offset	Read/Write	10
109-0306	Labels Side Temperature offset	Read/Write	10
109-0310	Mid-Weight 96-110g Center Temperature Offset	Read/Write	10


Table 4-18 **Engine NVM Read/Write values (continued)**

Code	Name	Type	Default
109-0311	Mid-Weight 96-110g Side Temperature Offset	Read/Write	10
109-0315	Recycled Center Temperature offset	Read/Write	10
109-0316	Recycled Side Temperature offset	Read/Write	10
109-0320	Special Center Temperature offset	Read/Write	10
109-0321	Special Side Temperature offset	Read/Write	10
109-0325	1200 dpi_light 60-74g Center Temperature offset	Read/Write	10
109-0326	1200 dpi_light 60-74g Side Temperature offset	Read/Write	10
109-0330	1200 dpi_plain Center Temperature offset	Read/Write	10
109-0331	1200 dpi_plain Side Temperature offset	Read/Write	10
109-0335	1200 dpi_mid-weight 96-110g Center Temperature offset	Read/Write	10
109-0336	1200 dpi_mid-weight 96-110g Side Temperature offset	Read/Write	10
109-0340	XHvyGlossy 131-175g Center Temperature Offset	Read/Write	10
109-0341	XHvyGlossy 131-175g Side Temperature Offset	Read/Write	10
109-0345	Card Glossy 176-220g Center Temperature Offset	Read/Write	10
109-0346	Card Glossy 176-220g Side Temperature Offset	Read/Write	10
109-0350	Paperboard Center Temperature Offset	Read/Write	10
109-0351	Paperboard Side Temperature Offset	Read/Write	10
109-0355	Heavy Paperboard Center Temperature Offset	Read/Write	10
109-0356	Heavy Paperboard Side Temperature Offset	Read/Write	10

Sensors

Use this menu to check the status of sensors using each sensor's callout on the control panel.

Select the callout to display the status of the sensor.



NOTE: This image may differ from your control panel display.

IMPORTANT: Include this information when escalating related issues to the GBU engineer.

Table 4-19 Sensor types

Name	Reference table
Document Feeder Sensors	Document Feeder sensors
Flatbed Sensors	Flatbed sensors
ACR/CTD	ACR/CTD sensors
Finisher (Option)	Finisher (Option) sensors
Covers	Cover sensors
Developer	Developer sensors
Environment	Environmental sensors
Fuser	Fuser sensors
LSU	LSU sensors
Paper Path	Paper Path sensors
Power Supply	Power Supply sensors
TCU	TCU sensors
Toner	Toner sensors
Toner Residual Amount	Toner Residual Amount sensors
Tray	Tray sensors

Table 4-20 Document Feeder sensors

Name	Type	Status
ADF Top of Form Sensor	Input	High/Low
ADF Paper Path Deskew Sensor	Input	High/Low

Table 4-20 Document Feeder sensors (continued)

Name	Type	Status
ADF Paper Present Sensor	Input	High/Low
ADF Width Sensor	Input	Numeric
ADF Y Length (Short)	Input	High/Low
ADF Y Length (Long)	Input	High/Low
ADF Jam Cover Sensor	Input	High/Low
ADF Paper Path Pick Height Sensor	Input	High/Low
ADF Ultrasonic	Input	Numeric
ADF Pick Success Sensor	Input	High/Low
ADF Top of Form Sensor	Input	High/Low
ADF Paper Path Deskew Sensor	Input	High/Low
ADF Paper Present Sensor	Input	High/Low
ADF Width Sensor	Input	Numeric

Table 4-21 Flatbed sensors

Name	Type	Status
Flatbed Cover Sensor	Input	High/Low
Flatbed Y (length) short Sensor	Input	High/Low
Flatbed Y (length) long Sensor	Input	High/Low
Flatbed Cover Sensor	Input	High/Low

Table 4-22 ACR/CTD sensors

Code	Name	Type	Status
112-0340	Center ID Sensor - P Wave Value	Input	Numeric

Table 4-23 Finisher (Option) sensors

Item	Code	Name	Type	Status
Booklet End Fence	113-3000	Booklet End Fence Home Sensor	Input	High/Low
Booklet Entrance	113-3100	Booklet Entrance Sensor	Input	High/Low
Booklet Exit	113-3120	Booklet Exit Sensor	Input	High/Low
Booklet Fold	113-2202	Booklet Maker Detection	Input	Installed/Not installed

Table 4-23 Finisher (Option) sensors (continued)

Item	Code	Name	Type	Status
Booklet Fold	113-3040	Booklet Blade Home Sensor	Input	High/Low
Booklet Output Tray	113-2150	Booklet Output Tray Sensor	Input	High/Low
Booklet Paddle	113-3050	Booklet C-Fold Blade Home Sensor	Input	High/Low
Booklet Paddle	113-3060	Booklet Diverter Home Sensor	Input	High/Low
Booklet Paddle	113-3090	Booklet Paddle Home Sensor	Input	High/Low
Booklet Paddle	113-3130	Booklet Presser Home Sensor	Input	High/Low
Booklet Stapler	113-3010	Booklet Stapler Head Sensor	Input	High/Low
Booklet Stapler	113-3020	Booklet Front Stapler Cartridge Level Sensor	Input	High/Low
Booklet Stapler	113-3030	Booklet Rear Stapler Cartridge Level Sensor	Input	High/Low
Booklet Tamper	113-3080	Booklet Tamper Home Sensor	Input	High/Low
Booklet Tamper	113-3110	Booklet Tamper Sensor	Input	High/Low
Covers	113-0410	Front Cover Sensor	Input	High/Low
Covers	113-0420	Top Cover Sensor	Input	High/Low
Ejector	113-0461	Ejector1 Home Sensor	Input	High/Low
Ejector	113-0462	Ejector2 Home Sensor	Input	High/Low
Ejector	113-0463	Ejector2 Motor Sensor	Input	High/Low
End Fence	113-0361	End Fence Sensor	Input	High/Low
Entrance	113-0350	Entrance Sensor	Input	High/Low
Exit	113-0360	Exit Sensor	Input	High/Low
Finisher Connection	113-0351	Finisher Detection Sensor	Input	Installed/Not Installed
Output Tray	113-0470	Paper Holding Sensor	Input	High/Low
Output Tray	113-0471	Output Tray Top of Stack Sensor	Input	High/Low
Output Tray	113-0472	Output Tray Lower Limit Sensor	Input	High/Low
Output Tray	113-0473	Output Tray Motor Sensor	Input	High/Low
Paddle	113-0370	Paddle Home Sensor	Input	High/Low
Paper Support	113-0481	Paper Support Home Sensor	Input	High/Low

Table 4-23 Finisher (Option) sensors (continued)

Item	Code	Name	Type	Status
Punch	113-0610	Punch Motor Sensor	Input	High/Low
Punch	113-0612	Punch Home Sensor	Input	High/Low
Punch	113-0620	Punch Waste Box Sensor	Input	Installed/Not Installed
Punch	113-0621	Punch Waste Full Sensor	Input	High/Low
Stapler	113-0430	Stapler Head Sensor	Input	High/Low
Stapler	113-0440	Stapler Cartridge Level Sensor	Input	High/Low
Stapler	113-0451	Stapler Cartridge Detection Sensor	Input	High/Low
Stapler	113-0491	Stapler Front Sensor	Input	High/Low
Stapler	113-0492	Stapler Rear Sensor	Input	High/Low
Stapler	113-0493	Stapler Front Pos Sensor	Input	High/Low
Stapler	113-0494	Stapler Rear Pos Sensor	Input	High/Low
Tamper	113-0380	Rear Tamper Home Sensor	Input	High/Low
Tamper	113-0390	Front Tamper Home Sensor	Input	High/Low
Bridge	113-2070	Bridge Entrance Sensor	Input	High/Low
Bridge	113-2071	Bridge Exit Sensor	Input	High/Low
Bridge	113-2180	Bridge Door Sensor	Input	Closed/Open
Bridge	113-2200	Bridge Detection	Input	Installed/Not Installed
Buffer	113-2100	Buffer Sensor	Input	High/Low
Buffer	113-2210	Buffer Home Sensor	Input	High/Low
Manual Stapler	113-2160	Manual Staple Sensor	Input	High/Low
Manual Stapler	113-2161	Manual Staple Button Sensor	Input	High/Low
Punch Detection	113-2201	Punch Detection	Input	Installed/Not Installed
Punch Detection	113-4000	Punch Scan Home Sensor	Input	High/Low
Punch Detection	113-4060	Punch Type Detection1	Input	High/Low
Punch Detection	113-4061	Punch Type Detection2	Input	High/Low
SCU (Set Clam Unit)	113-2010	Paper Holding Home Sensor	Input	High/Low
SCU (Set Clam Unit)	113-2141	Front Paper Holding Sensor	Input	High/Low

Table 4-23 Finisher (Option) sensors (continued)

Item	Code	Name	Type	Status
SCU (Set Clam Unit)	113-2142	Rear Paper Holding Sensor	Input	High/Low

Table 4-24 Cover sensors

Code	Name	Type	Status
102-0352	DCF Feed Cover Open	Input	Closed/Open
102-0435	Front Cover Sensor	Input	Closed/Open
102-0436	Side Cover Sensor	Input	Closed/Open

Table 4-25 Developer sensors

Code	Name	Type	Status
111-0070	Black Toner Concentration Sensor	Input	Numeric

Table 4-26 Environmental sensors

Code	Name	Type	Status
109-0012	Inner Temperature Sensor	Input	Numeric
109-0013	Outer Temperature Sensor	Input	Numeric
109-0014	Humidity Sensor	Input	Numeric

Table 4-27 Fuser sensors

Code	Name	Type	Status
109-0000	Fuser Temperature A Sensor	Input	Numeric
109-0010	Fuser Temperature B Sensor	Input	Numeric
109-0016	Fuser Temperature C Sensor	Input	Numeric
109-0017	Fuser Temperature D Sensor	Input	Numeric
109-0400	Wrap Jam Sensor	Input	Numeric
109-0140	Fuser Gap Home Sensor	Input	High/Low
109-0141	Fuser Gap Home Sensor (through motor running)	Input	High/Low
109-0300	Fuser Detection	Input	Installed/Not Installed

Table 4-28 LSU sensors

Code	Name	Type	Status
110-0170	LSU HSync4 Sensor	Input	High/Low
110-0200	LSU Detection	Input	High/Low

Table 4-29 Paper Path sensors

Item	Code	Name	Type	Status
Feed	102-0293	Feed2 Sensor	Input	High/Low
Feed	102-0361	Fuser Out Sensor	Input	High/Low
Feed Registration	102-0360	Regi. Sensor	Input	High/Low
Output	101-0190	Out-Bin Full Sensor	Input	High/Low
Output	101-0191	Out-Bin2 Full Sensor (Option)	Input	High/Low
Output Exit	102-0371	Exit2 Sensor	Input	High/Low
Duplex Jam 1	102-0380	Duplex Jam1 Sensor	Input	High/Low
Duplex Jam 2	102-0390	Duplex Jam2 Sensor	Input	High/Low

Table 4-30 Power Supply sensors

Code	Name	Type	Status
109-0200	Fuser Relay Sensor	Input	High/Low
109-0210	Zero Cross Period	Input	Numeric
101-1000	Power 24V	Input	Numeric
106-0200	HVPS Detection	Input	High/Low

Table 4-31 TCU sensors

Code	Name	Type	Status
100-0250	Waste Toner Full Sensor	Input	Numeric
104-0000	Waste Toner Detection Sensor	Input	Installed/Not Installed

Table 4-32 Toner sensors

Code	Name	Type	Status
111-0230	Black Toner Dispense Motor Sensor	Input	High/Low
111-0231	Black Toner Dispense Motor Sensor (through motor running)	Input	High/Low

Table 4-33 Toner Residual Amount sensors

Code	Name	Type	Status
111-0075	Black Toner Residual Amount Sensor	Input	Numeric

Table 4-34 Tray sensors

Item	Code	Name	Type	Status
Tray 1	102-0280	Tray 1 Paper Empty Sensor	Input	High/Low
Tray 2	102-0000	Tray 2 Open Sensor	Input	Closed/Open
Tray 2	102-0010	Tray 2 Paper Empty Sensor	Input	High/Low
Tray 2	102-0041	Tray 2 Paper Size Sensor	Input	Numeric
Tray 2	102-0050	Tray 2 Stack Height Sensor	Input	High/Low
Tray 2	102-0292	Pre Feed2 Sensor	Input	High/Low
Tray 3	102-0070	Tray 3 Open Sensor	Input	Closed/Open
Tray 3	102-0080	Tray 3 Paper Empty Sensor	Input	High/Low
Tray 3	102-0111	Tray 3 Paper Size Sensor	Input	Numeric
Tray 3	102-0120	Tray 3 Stack Height Sensor	Input	High/Low
Tray 3	102-0301	Pre Feed3 Sensor	Input	High/Low
Tray 4 (Option)	102-0730	Tray 4 Knock Up Home Sensor	Input	High/Low
Tray 4 (Option)	102-0731	Tray 4 Shift Tray Paper Empty Sensor	Input	High/Low
Tray 4 (Option)	102-0732	Tray 4 Shift Tray Level Sensor1	Input	High/Low
Tray 4 (Option)	102-0733	Tray 4 Shift Tray Level Sensor2	Input	High/Low
Tray 4 (Option)	102-0734	Tray 4 Shift Plate Home Sensor	Input	High/Low
Tray 4 (Option)	102-0735	Tray 4 Shift Plate End Sensor	Input	High/Low
Tray 4 (Option)	102-0736	Tray 4 Gate Solenoid Home Sensor	Input	High/Low
Tray 4 (Option)	102-0140	Tray 4 Open Sensor	Input	Closed/Open
Tray 4 (Option)	102-0150	Tray 4 Paper Empty Sensor	Input	High/Low
Tray 4 (Option)	102-0181	Tray 4 Paper Size Sensor	Input	Numeric 3 digits


Table 4-34 Tray sensors (continued)

Item	Code	Name	Type	Status
Tray 4 (Option)	102-0190	Tray 4 Stack Height Sensor	Input	High/Low
Tray 4 (Option)	102-0321	Pre Feed4 Sensor	Input	High/Low
Tray 4 (Option)	102-0330	Tray 4 Door Open Sensor	Input	Closed/Open
Tray 4 (Option)	102-0320	Tray 4 Feed Sensor	Input	High/Low
Tray 5 (Option)	102-0210	Tray 5 Open Sensor	Input	Closed/Open
Tray 5 (Option)	102-0220	Tray 5 Paper Empty Sensor	Input	High/Low
Tray 5 (Option)	102-0251	Tray 5 Paper Size Sensor	Input	Numeric
Tray 5 (Option)	102-0260	Tray 5 Stack Height Sensor	Input	High/Low
Tray 5 (Option)	102-0271	Tray 5 Level Sensor1	Input	High/Low
Tray 5 (Option)	102-0272	Tray 5 Level Sensor2	Input	High/Low
Tray 5 (Option)	102-0273	Tray 5 Detection Sensor1	Input	Installed/Not Installed
Tray 5 (Option)	102-0274	Tray 5 Detection Sensor2	Input	Installed/Not Installed
Tray 5 (Option)	102-0343	Pre Feed5 Sensor	Input	High/Low
Tray 5 (Option)	102-0350	Tray 5 Door Open Sensor	Input	Closed/Open
Tray 6 (Option)	102-0480	Tray 6 Paper Empty Sensor	Input	High/Low
Tray 6 (Option)	102-0520	Tray 6 Stack Height Sensor	Input	High/Low
Tray 6 (Option)	102-0531	Tray 6 Level Sensor1	Input	High/Low
Tray 6 (Option)	102-0532	Tray 6 Level Sensor2	Input	High/Low
Tray 6 (Option)	102-0533	Tray 6 Detection Sensor1	Input	Installed/Not Installed
Tray 6 (Option)	102-0534	Tray 6 Detection Sensor2	Input	Installed/Not Installed
Tray 6 (Option)	102-0353	Pre Feed6 Sensor	Input	High/Low
Tray 6 (Option)	102-0351	Tray 6 Door Open Sensor	Input	Closed/Open

Component tests

Use this menu to test components such as a motor, clutch, solenoid, fan, or bias, by selecting each component's callout on the control panel.

Select the callout and touch the Start button to run the component test.



NOTE: This image may differ from your control panel display.

IMPORTANT: Include this information when escalating related issues to the GBU engineer.

Table 4-35 Component types

Name	Reference table
Document Feeder Motors	Document Feeder Motor component tests
Scanner Motors	Scanner Motor component tests
Finisher (Option)	Finisher (Option) component tests
Developer	Developer component tests
Drum	Drum component tests
Duct/Reservoir	Duct/Reservoir component tests
Fan	Fan component tests
Fuser	Fuser component tests
LSU	LSU component tests
Paper Path	Paper Path component tests
Power Supply	Power Supply component tests
TCU	TCU component tests
Toner	Toner component tests
Trays	Tray component tests

Table 4-36 Document Feeder Motor component tests

Name	Type	Status
ADF Tray Lift Motor	Output	Start/Stop
ADF Feed Motor	Output	Start/Stop
ADF Deskew Motor	Output	Start/Stop

Table 4-36 Document Feeder Motor component tests (continued)

Name	Type	Status
ADF Pickup Clutch	Output	Start/Stop
ADF Deskew Clutch	Output	Start/Stop
ADF Pick Roller Up/Down	Output	Start/Stop
ADF Retard Motor	Output	Start/Stop
ADF Exit Motor	Output	Start/Stop

Table 4-37 Scanner Motor component tests

Name	Type	Status
Scanner Motor	Output	Start/Stop

Table 4-38 Finisher (Option) component tests

Item	Code	Name	Type	Status
Booklet End Fence	113-3510	Booklet Fold Motor	Output	On/Off
Booklet End Fence	113-3520	Booklet End Fence Solenoid	Output	On/Off
Booklet End Fence	113-3530	Booklet End Fence Motor	Output	On/Off
Booklet Entrance	113-3500	Booklet Entrance Motor	Output	On/Off
Booklet Entrance	113-3510	Booklet Fold Motor	Output	On/Off
Booklet Entrance	113-3520	Booklet End Fence Solenoid	Output	On/Off
Booklet Entrance	113-3530	Booklet End Fence Motor	Output	On/Off
Booklet Fold	113-3590	Booklet C-Fold Blade Motor	Output	On/Off
Booklet Paddle	113-3560	Booklet Diverter Motor	Output	On/Off
Booklet Paddle	113-3570	Booklet Presser Motor	Output	On/Off
Booklet Paddle	113-3580	Booklet Paddle Motor	Output	On/Off
Booklet Stapler	113-3600	Booklet Stapler Head Motor	Output	On/Off
Booklet Tamper	113-3540	Booklet Tamper Motor	Output	On/Off
Booklet Tamper	113-3550	Booklet Blade Motor	Output	On/Off
Ejector	113-2530	Pre Ejector Motor	Output	On/Off
Ejector	113-2540	Post Ejector Motor	Output	On/Off
Entrance	113-2510	Paper Holding Motor	Output	On/Off

Table 4-38 Finisher (Option) component tests (continued)

Item	Code	Name	Type	Status
Entrance	113-2520	Entrance Motor - Diverter	Output	On/Off
Entrance	113-2570	Entrance Motor - Entrance	Output	On/Off
Exit	113-2500	Main Exit Cam Motor	Output	On/Off
Exit	113-2580	Exit Motor	Output	On/Off
Output Tray	113-2610	Main Output Tray Motor	Output	On/Off
Paddle	113-2600	Paddle Motor	Output	On/Off
Paper Support	113-0571	Paper Support Motor	Output	On/Off
Punch	113-0610	Punch Motor Sensor	Input	High/Low
Punch	113-0600	Punch Motor	Output	On/Off
Punch	113-4500	Punch Scan Motor	Output	On/Off
Stapler	113-0550	Stapler Head Motor	Output	On/Off
Stapler	113-0581	Stapler Position Motor	Output	On/Off
Stapler	113-2620	Stapler Position Motor	Output	On/Off
Stapler	113-2621	Stapler Head Motor	Output	On/Off
Tamper	113-0520	Rear Tamper Motor	Output	On/Off
Tamper	113-0530	Front Tamper Motor	Output	On/Off
Tamper	113-2630	Front Tamper Motor	Output	On/Off
Tamper	113-2640	Rear Tamper Motor	Output	On/Off
Bridge	113-2560	Bridge Motor	Output	On/Off
Buffer	113-2660	Buffer Motor	Output	On/Off
Buffer	113-2670	Buffer Solenoid	Output	On/Off
Covers	113-2650	Top Cover LED - Blue	Output	On/Off
Covers	113-2651	Top Cover LED - Red	Output	On/Off
End Fence	113-2590	End Fence Motor	Output	On/Off

Table 4-39 Developer component tests

Code	Name	Type	Status
111-0140	Black Toner Control Voltage	Output	On/Off
100-0071	Black Deve Motor	Input	High/Low

Table 4-40 Drum component tests

Code	Name	Type	Status
100-0049	Black Drum Motor	Input	High/Low
107-0169	Black Eraser	Input	High/Low

Table 4-41 Duct/Reservoir component tests

Code	Name	Type	Status
111-0330	Black Toner Duct/Reservoir Motor	Output	On/Off

Table 4-42 Fan component tests

Code	Name	Type	Status
100-0270	SMPS Fan	Input	High/Low
100-0271	SMPS Fan2	Input	High/Low
109-0047	Exit Fan	Input	High/Low
109-0022	Exit Fan2	Input	High/Low
109-0024	Exit Fan3	Input	High/Low
109-0026	Exit Fan4	Input	High/Low
110-0020	LSU Fan1	Input	High/Low

Table 4-43 Fuser component tests

Code	Name	Type	Status
109-0034	Fuser Motor - Forward	Input	High/Low
109-0130	Fuser Gap Motor	Output	On/Off

Table 4-44 LSU component tests

Code	Name	Type	Status
110-0000	LSU Motor1	Input	High/Low

Table 4-45 Paper Path component tests

Item	Code	Name	Type	Status
Feed	100-0420	Tray 1 Feed Motor	Output	On/Off
Feed	101-0120	Tray 2 Feed Motor	Output	On/Off
Feed	101-0130	Tray 3 Feed Motor	Output	On/Off
Feed	100-0410	Registration Motor	Output	On/Off

Table 4-45 Paper Path component tests (continued)

Item	Code	Name	Type	Status
Feed	101-0140	Tray 4 Feed Motor (Option)	Output	On/Off
Feed	101-0150	Tray 5 Feed Motor (Option)	Output	On/Off
Feed	101-0160	Tray 6 Feed Motor (Option)	Output	On/Off
Output	100-0430	Exit2 Motor - Forward	Output	On/Off
Output	100-0440	Exit2 Motor - Backward	Output	On/Off
Duplex	100-0140	Duplex Motor	Output	On/Off
Duplex	101-0280	Return Gate Solenoid	Output	On/Off
Duplex	100-0490	Duplex2 Motor	Output	On/Off

Table 4-46 Power Supply component tests

Item	Code	Name	Type	Status
Transfer	107-0033	THV(-) Bias	Output	On/Off
Transfer	107-0034	THV CC Bias	Output	On/Off
Transfer	107-0035	THV CV Bias	Output	On/Off
Drum	105-0030	Black MHV Bias	Output	On/Off
Developer	106-0030	Black Developer Bias	Output	On/Off
Developer	106-0031	Black Developer AC Bias	Output	On/Off

Table 4-47 TCU component tests

Code	Name	Type	Status
100-0241	Waste Toner LED	Output	On/Off

Table 4-48 Toner component tests

Code	Name	Type	Status
111-0030	Black Toner Dispense Motor	Output	On/Off
111-0430	Black Toner Unlock Motor	Output	On/Off

Table 4-49 Tray component tests

Item	Code	Name	Type	Status
Tray 1 Clutch	101-0270	Tray 1 Clutch	Output	On/Off
Tray 1	101-0271	Tray 1 Solenoid	Output	On/Off

Table 4-49 Tray component tests (continued)

Item	Code	Name	Type	Status
Tray 1	101-0272	Tray 1 Pickup Clutch	Output	On/Off
Tray 2	100-0200	Tray 2 Pickup Motor - Lift	Output	On/Off
Tray 2	100-0370	Tray 2 Pickup Motor - Pickup	Output	On/Off
Tray 3	100-0210	Tray 3 Pickup Motor - Lift	Output	On/Off
Tray 3	100-0380	Tray 3 Pickup Motor - Pickup	Output	On/Off
Tray 4 (Option)	100-0220	Tray 4 Pickup Motor - Lift	Output	On/Off
Tray 4 (Option)	100-0390	Tray 4 Pickup Motor - Pickup	Output	On/Off
Tray 4 (Option)	101-0101	Tray 4 Shift Gate Solenoid	Output	On/Off
Tray 4 (Option)	100-0232	Tray 4 Shift Motor	Output	On/Off
Tray 5 (Option)	100-0230	Tray 5 Pickup Motor - Lift	Output	On/Off
Tray 5 (Option)	100-0400	Tray 5 Pickup Motor - Pickup	Output	On/Off
Tray 6 (Option)	100-0231	Tray 6 Elevating Motor	Output	On/Off
Tray 6 (Option)	100-0700	Tray 6 Pickup Motor	Output	On/Off


TR Control Mode

Use this menu to correct transfer related problems. This menu can be used to change the transfer value to optimize image quality for a certain type of paper.

Figure 4-39 Typical faulty images



[Blur]



[Poor Transfer]



[Re-Transfer]



[White Spot]




[OPC Cyclic Ghost]

- T2 Control Mode
  - **T2 PWM**: Default is 0. It can be adjusted from -20 to +20. For example:
    - Blur: Increase T2 PWM value.
    - Poor Transfer: Increase T2 PWM value.
    - Re-Transfer: Decrease T2 PWM value.
    - White Spot: Decrease T2 PWM value.
    - OPC Cyclic Ghost: Decrease T2 PWM value.

Low-temperature Idling Mode

Use this menu to improve print quality in low temperatures (below 7°C/ (44.6 °F)). Environment quality issues include rib marks (duplex), blisters in the printed image, or poor fusing, as show below.

Figure 4-40 Typical faulty images



[Blister and Rib mark]



[Poor fusing]

- **Off (default)**: Disable this function.
- **On**: The printer will perform this function.

NOTE: When this function is enabled, the printer will perform the fuser idle for 4 to 10 minutes before printing, depending on the outside temperature (below 7°C/ (44.6 °F)). Printing speed is therefore slower than when this function is off.

Altitude Adjustment

Use this menu to choose the altitude of the place where the printer is located. The print quality is affected by atmospheric pressure, which is determined by the height of the machine above sea level.

Figure 4-41 Typical faulty images



[Loose toner]



[Light image]

- **Normal (default)**: 0 ~ 1,000 m (3,280 ft)
- **High 1**: 1,000 m (3,280 ft) ~ 2,000 m (6,561 ft)
- **High 2**: 2,000 m (6,561 ft) ~ 3,000 m (9,842 ft)
- **High 3**: 3,000 m (9,842 ft) ~ 4,000 m (13,123 ft)

- **High 4**: 4,000 m (13,123 ft) ~ 5,000 m (16,404 ft)

Humidity

Use this menu to troubleshoot print quality issues such as paper curl, dog ears, and poor paper stacking in the stacker output bins.


Increase the Humidity level from High 1 to High 3 until the print quality issues are resolved.

NOTE: Printing speed will be slow when the Humidity level is set to High 3.

Figure 4-42 Typical faulty images



[Paper curl]



[Dog ears]

- **Normal (default)**
- **High 1**: Preheating Idling for 13 seconds before the first job and increased gap for paper transfer (150 mm (6 in), Simplex only)
- **High 2**: Preheating Idling for 18 seconds before the first job and increased gap for paper transfer (200 mm (7.9 in), Simplex only)
- **High 3**: Preheating Idling for 20 seconds before the first job, increased gap for paper transfer (65 mm (2.5 in), Simplex only), and 50% process speed slow-down

Vapor Mode

Use this menu to prevent moisture on paper from affecting the print quality, including print-quality defects such as Dropouts or Background scatter.

Figure 4-43 Typical faulty images



[Dropouts]



[Background scatter]

- **Off (default)**: Disables this function.
- **On**: Slows the printing speed by 50% and lowers the temperature of the fusing device when printing.
- **Auto**: Detects the temperature and humidity in the machine and adjusts the settings accordingly.

Footer

Use this menu to add printing information at the bottom of the printed page.

- **Off (default)**: Disables this function.
- **On**: The printer performs this function.

PTT Test Mode

Use this menu to determine whether a fax transmission meets local standards.

Test Support

Use this menu to test the items listed below.

- Continuous Scan
- Continuous Copy
- Raw Scan
- Continuous Print From USB
- Automatic Calibrations
- Runtime Configuration

Part Replacement Count

Use this menu to display the number of parts replaced.

Table 4-50 Part Replacement Count items

Item
Black Cartridge
Black Drum
Black Developer Unit
Fuser Kit
Transfer Belt
Tray 1 Roller Kit
Tray 2 Roller Kit
Tray 3 Roller Kit
Tray 4 Roller Kit
Tray 5 Roller Kit

Reset Supplies

Use this menu to reset the supplies counters.

IMPORTANT: After replacing a supply kit, use this function.

Table 4-51 Reset Supplies items

Item
Black Developer Unit
Tray 1 Roller Kit
Tray 2 Roller Kit
Tray 3 Roller Kit
Tray 4 Roller Kit
Tray 5 Roller Kit

Fax V.29 Speed

Use this menu to select Line 1 or 2 of V.29, which will transmit at 9600 bps for faxes over VoIP when the VoIP connection is failing.

Maintenance menu

Use this menu to access features for maintaining the printer.

Table 4-52 Maintenance menu

First level	Second level	Third level
Backup/Restore		
Import/Export		

Table 4-52 Maintenance menu (continued)

First level	Second level	Third level
Calibration/Cleaning	Advanced Calibration Support	Custom Color
Calibration/Cleaning	Advanced Calibration Support	Auto Tone Adjustment
Calibration/Cleaning	Advanced Calibration Support	CTD Sensor Cleaning
Calibration/Cleaning	Advanced Calibration Support	Manual Tone Adjustment
Calibration/Cleaning	Toner Density Calibration	
Calibration/Cleaning	Calibrate Scanner	
USB Firmware Upgrade		
License Management		

Backup/Restore

Use the Back up Data menu to perform manual backups of the printer configuration data to the front panel USB port.

Use the Restore Data menu to restore a backup of the system configuration previously saved on a USB drive.

Import/Export

Use this menu to export files that can be used to configure other devices. Select which settings, contacts, or user accounts to include in the export. The files can be imported to other devices including those with different capabilities. Any imported settings that are not available on the target device will be ignored.

Custom Color

Use this menu to adjust the color density manually in order to meet the customer's needs.

- **Black**: Default is 0. It can be adjusted from -10 to +10.

Auto Tone Adjustment

Use this menu to adjust color tone automatically.

- **Off**: Disables this function.
- **On (Default)**: The printer will perform this function when the following determined conditions have been met.
  - **After Pages Printed**: The printer will perform this function based on the count of printed pages since the last execution.
  - **After Period of Inactivity (Minutes)**: The printer will perform this function when the printer returns from a power save mode and the rest time exceed the configured value.
  - **Adaptive**: Unchecked as a default.

- **Start**: The printer performs this function now.

NOTE: Select Start to manually perform this operation when the control panel displays sensor failure errors such as “CTD sensor calibration failure,” or when imaging parts such as the OPC drum, development unit, or ITB unit are replaced or reinstalled.

CTD Sensor Cleaning

Use this menu to calibrate the CTD sensor after cleaning the CTD and ACR sensor, when the control panel displays sensor errors such as “CTD sensor calibration failure” or “ACR sensor calibration failure.”

- **Start**: The printer performs this function immediately, and the sensor failure error message is cleared from the control panel.

Manual Tone Adjustment

Use this menu to adjust the color tone manually.

This function can adjust Highlights, Midtones, and Shadows.

- **Black**: Default is 0. It can be adjusted from -5 to +5.

Toner Density Calibration

Use this menu to calibrate the product immediately if you see problems with printer density.

- **Start**: The printer will perform this function now.

Calibrate Scanner

Use this menu when messages on the control panel direct you to run the calibration process.

- **Start**: The printer performs this function immediately.

USB Firmware Upgrade

Use this menu to perform a firmware upgrade using a USB flash drive.

Insert the USB flash drive that contains a firmware upgrade bundle into the USB port, and then follow the on-screen instructions.

- **Install**: Executes the firmware upgrade.

License Management

Use this menu to install a speed license, which will configure the engine to print at an upgraded speed.

Use **one** of the following procedures to install the speed license.

- Install a speed license from the HP Cloud using the control panel.

IMPORTANT: When an inner finisher is installed, the printer cannot exceed 60 pages-per minute (ppm). Do not install a speed license higher than 60 ppm for a printer with an inner finisher installed.

1. Connect a network cable to the printer.
2. Turn the printer power on, and wait for it to initialize to the Ready state.

3. Verify that the printer has a valid IP address and a working internet connection.


NOTE: A proxy server might need to be configured now using the Embedded Web Server (EWS) or manually at the control panel.

4. At the printer Home screen, scroll to and then touch the Support Tools button.
5. Select the License Management menu in the left-side navigation pane.
6. Select License from HP Cloud under Upload and Install License.

IMPORTANT: A redemption code must be obtained from the HP Printer License Activation and Management website. https://activation.jamangement.hp.com.

7. Type in the redemption code obtained from the HP Printer License Activation and Management website.
8. Select the Register and Install button.

NOTE: The printer restarts as part of the installation process. Wait at least a few minutes after the printer initializes to the Ready state to allow the speed license installation process to finish completely.



- Install a speed license offline manually using the HP Printer License Activation and Management web site.

IMPORTANT: When an inner finisher is installed, the printer cannot exceed 60 pages-per minute (ppm). Do not install a speed license higher than 60 ppm for a printer with an inner finisher installed.


1. Download the speed license file to the PC from the HP Cloud Server.
   a. Open a browser and go to the HP Printer License Activation and Management website: https://activation.jamanagement.hp.com.
   b. Select the country/region and SIGN IN on the HP Partner Portal.
   c. Select **Activation speed for new HP LaserJets** or select **Product Number**.

d. Type the printer serial number in the **Device Serial Number** field.

e. Use the drop-down menu to select the **Device Product Number**.

f. Type in the redemption code in the **Redemption Code** field.

NOTE: A redemption code must be obtained from the HP Printer License Activation and Management website. https://activation.jamanagement.hp.com.



g. Click the **Register** button.

h. When the registration is complete, download the speed license file to the computer, and then transfer it to a USB storage device.

CAUTION: The license file must be saved in the root directory of the USB device. Do not change the license file name.

2. Use the steps below to manually install the speed license.

a. Turn the printer power on, and wait for it to initialize to the Ready state.

b. Insert the USB into the USB port on the printer.


c. At the printer Home screen, scroll to and then touch the Support Tools button.

d. Select License from the USB under Upload and Install License.

e. Touch the Register and Install button.

IMPORTANT: The printer installs the highest speed license among the license files on the USB device. Remove any license files for speeds above 60 ppm for a printer with an inner finisher installed. Speed upgrades cannot be downgraded.

NOTE: If the USB device is not detected, remove the USB device and turn the printer power off. Reinsert the USB device, and then turn the printer power on.



Troubleshooting menu

Use this menu to access features for troubleshooting the printer.

Table 4-53 Troubleshooting menu

First level	Second level
Reports	Configuration/Status Pages
Reports	Fax Reports
Reports	Other Pages
Fax Tools	Fax T.30 Trace Report
Fax Tools	Fax V.34
Fax Tools	JBIG Compression
Fax Tools	Fax Speaker Mode
Fax Tools	Fax Service Log
Print Quality Pages	PQ Troubleshooting Pages
Print Quality Pages	Advanced Print Quality Pages
Event Log	
Paper Path Page	
Diagnostic Tests	Run Fax Test
Retrieve Diagnostic Data	
Retrieve Fax Diagnostic Data	

Configuration/Status Pages

Use this menu to display ( ) or print ( ) the information listed below.

- Settings Menu Map

- Current Settings Page
- Configuration Page
- How to Connect Page
- Supplies Status Page
- Usage Page
- File Directory Page
- Web Services Status Page
- HP Flex Build Configuration Page

Fax Reports

Use this menu to display ( ) or print ( ) the information listed below.

- Fax Activity Log
- Billing Codes Report
- Blocked Fax List
- Fax Call Report

Other Pages

Use this menu to print the information listed below.

- PCL Font List
- PS Font List
- Secure Drum Data Erase

Fax T.30 Trace Report

Use this menu to print the Fax trace reports with the selected conditions on each Line 1 or Line 2.

The T.30 trace is a printed report which produces a record of all the communications between the sending and receiving fax machines for the last fax transmission or reception. The report has many technical details which are usually beyond the scope of most users. However, the report contains detailed error codes and other information that might be useful in troubleshooting a particular problem related to sending or receiving a fax. The report contents might be requested by an HP service representative when trying to determine the cause of a problem and will help to determine the appropriate action.

- **Never automatically print**: The printer does not print the fax trace report.
- **Print after every fax**: The printer will print the fax trace report after every fax job.
- **Print only after fax send jobs**: The printer will print the fax trace report after sending a fax job.
- **Print only after received faxes**: The printer will print the fax trace report after receiving a fax job.

- **Print only after fax send errors**: The printer will print the fax trace report when a fax sending error occurs.
- **Print only after fax receive errors**: The printer will print the fax trace report when a fax receiving error occurs.
- **Print only after any fax error**: The printer will print the fax trace report when any fax error occurs.
- **Print Now**: The printer prints the fax trace report immediately.

Fax V.34

Use this menu to resolve a fax sending or receiving problem on each Line 1 or Line 2.

The V.34 setting is the modem protocol that the printer uses to send faxes. It is the worldwide standard for full-duplex modems that send and receive data across telephone lines at up to 33,600 bits per second (bps). The factory-set default for the V.34 setting is On.

You should change the V.34 setting only if you are having trouble sending a fax to or receiving a fax from a particular device. Turning off the setting might be useful when you are trying to send a fax overseas, or receive one from overseas, or if you are using a satellite telephone connection.

- **Enable (default)**: The Fax V.34 is activated.
- **Disable**: The Fax V.34 is not activated.

JBIG Compression

Use this menu to resolve a fax sending problem when another receiving fax device cannot support it.

JBIG compression can reduce fax transmission times significantly when enabled. When enabled, documents will be JBIG encoded when sending and receiving with another JBIG capable fax device. When a fax is sent to or received from a non-JBIG capable device, other compression algorithms will be used.

- **On**: JBIG compression is enabled.
- **Off (default)**: JBIG compression is disabled.

Fax Speaker Mode

Use this menu to enable or disable the fax speaker mode.

- **Normal (default)**: The fax modem speaker is turned on during dialing through the initial connection and then shuts off.
- **Diagnostic**: The speaker is turned on and remains on for all fax communications until the setting is returned to Normal mode.

Fax Service Log

Use this menu to print the detailed fax service log.

- **Print**: The printer prints the detailed fax service log.

PQ Troubleshooting Pages

Use this menu to check the print quality with a printed test page.


- **Print**: The printer prints the PQ troubleshooting pages.

The printer returns to the Ready state after printing the PQ troubleshooting pages. Review the PQ troubleshooting pages, and perform the corresponding troubleshooting procedure below.

NOTE: The images below are only examples and may not exactly match your output. Black toner is being used for clarity.

Toner smear

As shown below, the issue may vary in location and appearance.



Description

A portion of the image is smeared in the feed (horizontal) direction. The section that is smeared may be a narrow or wide streak, and may extend across the entire page.

Most likely causes


- Smears occur more commonly after a paper jam, or during the first daily printing in a high-temperature, high-humidity environment.

Troubleshooting and suggestions

1. If the smear was first observed after a paper jam, check the PTB unit for torn pieces of paper. Then go to the next step.
2. Print approximately 10 pages to see if the smear clears. If the toner smear still can be observed, go to the next step.
3. Replace the PTB unit.
4. After replacing the PTB unit, print another set of PQ troubleshooting pages.
5. Look at the new set of PQ troubleshooting test pages. If the issue is not resolved, contact HP.

Sharp banding repeating

As shown below, the issue may vary in location and appearance.



Description

Pages print with sharp, narrow, dark bands repeating.

Most likely causes


- The developer roller in the black image drum.

Troubleshooting and suggestions

1. Replace the black image drum.
2. After replacing the black image drum, print another set of PQ troubleshooting pages.
3. Look at the new set of test pages. If the issue is not resolved, contact HP.

Partial Missing color plane

As shown below, the issue may vary in location and appearance.



Description

The background color of the black test page is missing toner. The boundary between where the toner is present and not present creates a wavy pattern.

Most likely causes

- One of the transfer rollers in the intermediate-transfer belt unit does not have even pressure across the belt.

Troubleshooting and suggestions

1. Check the PTB unit to see whether the bushings are correctly positioned.
2. Print another set of PQ troubleshooting pages.
3. Look at the new set of test pages. If the issue is not resolved, then check the printer toner cartridge.
4. Print and examine another set of PQ troubleshooting pages.
5. If the issue is not resolved by the black image drum test procedure, contact HP.

Advanced Print Quality Pages

Use this menu to print test pages with the selected test page type.

- **Print**: The printer prints the selected quality test pages
  - EP Calibration Pattern2 Halftone
  - Tone Curve Int Calibration K Pattern
  - Engine K Pattern for Optical Density
  - Tone Curve Ext Measurement Page

Event Log

Use this menu to display and print event logs such as an event code, date/time, cycles and repetitions on the printer.

- **Print** (): The printer prints the event logs.

Paper Path Page

Use this menu to display and print a paper path usage on the printer.

- **Print**: The printer prints the paper path usage report.

Run Fax Test

Use this menu to perform tests on specific components within the product to determine whether the components are functioning correctly.

The printer prints a fax test report. The report contains the following possible results.

- **Pass**: The report contains all of the current fax settings. The printer is ready to send and receive faxes.
- **Fail**: The report indicates the nature of the error and contains information on how to resolve the issue.

Retrieve Diagnostic Data

Use this feature to retrieve diagnostic data from the printer and save it to a USB flash drive.

Select from the following options:

- **Debug information file**: This option creates a .zip file.
- **Device data file**: This option creates a device data file.

The exported data might contain personally identifiable information.

Retrieve Fax Diagnostic Data

Use this menu to export Fax diagnostic data from the printer using a USB drive.

Insert a USB drive into the USB port. Click the Save button.

5 Remove and replace

You will learn more about remove and replace.

Safety precautions

Follow these safety protocols when handling or repairing the printer.

Product safety classification: This is a Safety Class I product, which means it has a protective earth terminal. This terminal must be connected to earth ground.

IMPORTANT: Before operation or repair, check the product and review this manual for safety warnings and instructions. Safety warnings for specific procedures are located at appropriate places in the manual.

WARNING: Hazardous voltages exist within the product.

NOTE: HP recommends that only qualified personnel trained in working with high voltage power equipment should service this unit.

Follow these precautions always:

NOTE: If you do not want to disassemble and repair the printer yourself, contact your local HP Service Representative for service, see Contact HP Support on page viii section.

Warnings and Cautions

To ensure the proper use of the printer and to prevent the printer from being damaged, follow the warning and caution symbols marked in this guide. See Conventions used in this guide on page iii.

Electrical precautions

- **Power cord instructions**
  - Make sure your power source is adequate for the product voltage rating. The voltage rating is on the product label.

    Typically, the product uses either 110-127 Vac or 220-240 Vac and 50/60 Hz. Depending on a product, the voltage usage might change (100-127 Vac, for example). It is recommended to refer your product manual for the specified voltage.
  - Connect the power cord between the product and a grounded AC outlet.

    CAUTION: To prevent damage to the product, use only the power cord that is provided with the product.

Do not damage, cut, or repair the power cord. A damaged power cord can cause fire or electric shock. Replace a damaged power cord with an HP-approved power cord.

- Unplug the power cord when disassembling or assembling the printer.

  The printer utilizes a power switch (button) that is turned "ON" or "OFF". Be aware that electricity may flow on the primary side of the printer even when the printer is "OFF".

- Power off the printer and unplug the power cord and fax cord (if available) from the electrical outlet in any of the following cases:
  - When removing product enclosure or covers from the printer or when accessing internal parts of a printer.
  - If there is smoke or an unusual smell coming from the printer.
  - A piece of metal or a liquid (not part of cleaning and maintenance routines) touches internal parts of the printer.
  - During an electrical storm (with thunder and/or lightning).
  - During an electrical power failure.

Electrostatic Discharge (ESD) precautions

Electrostatic discharge (ESD) can damage electronic components inside your printer.

Use these guidelines to protect sensitive parts against damage from electrostatic discharge.

- Touch a metal object that is not painted and is grounded.
- Leave electronic parts such as a memory chip in the bag it was shipped in until you are ready to perform the installation.
- ESD wrist straps can also be used to help release excess electrostatic charge.

  - **CAUTION:** 

    Some parts are sensitive to electrostatic discharge (ESD). Look for the ESD reminder when removing printer parts.

    Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly.

  - Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

Handling toner

HP recommends that you wear gloves when handling toner cartridges and toner system components.

Do not expose toner or toner cartridge to fire or any heat source.

Keep imaging unit and/or toner cartridge away from children. The toner powder contained in the imaging unit and toner cartridge may be harmful, and if swallowed, you should contact a doctor.

Lifting equipment

Follow the recommendations for lifting or moving your printer.

The printed inbox guides and support documentation available on support.hp.com for your printer model will provide the lifting requirements to avoid injury and to safely move the printer.

NOTE: Do not attempt to lift heavy equipment without assistance.

Safety measures during disassembling or reassembling

IMPORTANT: Before disassembling or reassembling a printer, be sure to unplug its power cord from the electrical outlet.

NOTE: Assembly is the reverse of disassembly unless otherwise specified.

- During disassembly, reassembly, or transportation of a printer, remove the toner cartridge as necessary.
- Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used.

  Do not use repaired fuses or short-circuited fuse holders. Doing so, could cause a shock or fire hazard.
- Capacitors inside this product may hold a hazardous charge even if the product has been disconnected from its power source.
- Do not disable safety functions (Interlocks or safety circuits). Safety will not be assured leading to a safety hazard and potential injury.
- Note the length, diameters, and locations of screws as you remove them. When reassembling the printer, be sure to use them in their original locations.
- As a best practice safety rule, do not run the printer with any parts removed.

Ingestion hazards

This product may contain a button cell or coin battery that is not intended to be replaced.

- A swallowed button cell or coin battery can cause internal chemical burns in as little as two (2) hours.

  Death or serious injury can occur if ingested.
- Keep new and used batteries out of reach of children. Used batteries may cause severe injury or death.

  Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body. Call a local poison control center for treatment information.
- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do not dispose of batteries in household trash or incinerate.

Laser radiation hazards

The printer is certified as a Class 1 laser product.

WARNING: Using controls, adjusting or performing procedures other than those specified in the user guide could result in exposure to hazardous radiation. Do not disassemble the laser/scanner unit as the laser beam can injure your eyes. An invisible laser beam is emitted within the laser/scanner unit.

Mechanical hazards

The printer has moving parts that could cause injury. To avoid personal injury, take the following precautions when working close to the printer.

- Keep your clothes and body away from the printer's moving parts.
  - Avoid wearing dangling jewelry or other hanging objects around the printer as it might be caught by moving parts and lead to injury.
  - Keep long hair tied up and away from the paper feed mechanism.
  - Ensure the sleeves or gloves do not get caught in the printer's moving parts.
- Avoid standing close to the fans as it could cause injury and could also affect print quality (by obstructing the air flow).
- Do not touch gears or moving rolls during printing.
- Do not operate the printer when having enclosure covers removed or interlock switches bypassed.
- The product may have internal sharp edges.

  Make sure the wiring does not come into contact with sharp edges, burrs, or other pointed parts. Current can leak, leading to a risk of electrical shock or fire hazard.
- During and after repair, check internal electrical wiring for squeezing, sheaths and any damage.
- – Make sure that all screws, components, wiring, connectors and so forth that were removed, have been reinstalled in the original location.
  - Do not allow any metal parts such as clips, staples and screws to fall into the printer. This could potentially short internal circuits and cause an electrical shock hazard.
  - Do not allow liquids (except those used in HP cleaning kits) to touch the internal parts of the printer. Doing so may cause fire, electric shock, or other serious hazards.

Thermal hazards

Caution: Inspection before repair for fuser

The area around the fuser unit may be hot. Wait for a few minutes until the fuser assembly cools down.

Contact HP Support

HP offers phone support to assist you for printer issues. Ensure to read the following information before contacting HP Support.

Before contacting HP Support

Before contacting support, consider checking the resources available on HP Customer Support.

1. Go to HP Customer Support (https://support.hp.com) to locate your product support page.
2. Review the documents for troubleshooting before contacting HP.

Information required when contacting HP Support

If you call an HP support representative for assistance, ensure you have the following information for HP support to answer your questions quickly:

- **Product model**: Note the printer model, product number, and serial number you are using. The product number and the serial number are typically found on the label at the back of the product.
- **Error code**: If there is an error code or message displaying on the printer control panel, note the error code and message.
- **Computer (operating system)**: Provide the name of the computer/computer operating system you are using.
- Any **special equipment or software** you are using (for example, spoolers, networks, switch-boxes, modems or special software drivers).
  - The type of interface used on your product (USB or network).
  - The software and driver name and firmware version number that you are currently using.
- **Printer service information**: You can obtain the printer service information from the Embedded Web Server (EWS). If you need to send this information by email, download it as a file from your browser, and send the file.

NOTE: Depending on your printer firmware version, the menu items in the EWS might vary.

1. Open a Web browser on your computer, and then enter the IP address of your printer to access the Embedded Web Server.
2. Click **Support** > **Service support** > **Service information** > **Display**.

Phone support

HP phone support is available on the HP support website. For assistance, go to one of the following websites:

- https://support.hp.com/contact or
- https://support.hp.com/contact/help/printer or
- https://www.hp.com/us-en/contact-hp/contact.html.

Base printer

Learn about base printer parts removal and replacement.

Covers

Learn about base printer cover replacement.

Base covers

Review the base cover removal procedures.

Removal and replacement: Rear upper cover

Learn about removing and replacing the rear upper cover.

View a video of removing and replacing the rear upper cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-1 Part information

Part number	Part description
6ER04-40008	Rear upper cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-2 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-3 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-4 **Remove the cover**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Rear lower cover

Learn about removing and replacing the rear lower cover.

View a video of removing and replacing the rear lower cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-2 Part information

Part number	Part description
6ER04-40019	Rear lower cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-5 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-6 Remove the cover



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Controller cover

Learn about removing and replacing the controller cover.

View a video of removing and replacing the controller cover.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-3 Part information

Part number	Part description
6ER04-61005	Controller cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-7 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Exit rear cover

Learn about removing and replacing the exit rear cover.

View a video of removing and replacing the exit rear cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-4 Part information

Part number	Part description
6ER04-40028	Exit rear cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-8 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-9 Remove the cover




2. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-10 Remove the cover



3. Remove the exit rear cover

Use the following procedure to remove and replace the exit rear cover.

- Remove four screws, and then remove the cover.

Figure 5-11 Remove the cover



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Left top cover

Learn about removing and replacing the left top cover.

View a video of removing and replacing the left top cover.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-5 Part information

Part number	Part description
JC63-04862B	Left top cover

Required tools

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-12 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Left upper cover

Learn about removing and replacing the left upper cover.

View a video of removing and replacing the left upper cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-6 Part information

Part number	Part description
6ER04-40027	Left upper cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-13 Remove the cover



2. Remove the left cover

Use the following procedure to remove and replace the left cover.


1. Open the front cover (door) and all installed trays.
2. Remove eight screws.

Figure 5-14 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-15 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-16 Remove the cover




3. Remove the left upper cover

Use the following procedure to remove and replace the left top cover.

- Remove four screws, and then remove the cover.

Figure 5-17 Remove the cover



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Left cover

Learn about removing and replacing the left cover.

View a video of removing and replacing the left cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-7 Part information

Part number	Part description
6ER04-40049	Left cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-18 Remove the cover



2. Remove the left cover

Use the following procedure to remove and replace the left cover.


1. Open the front cover (door) and all installed trays.
2. Remove eight screws.

Figure 5-19 **Remove eight screws**



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-20 **Cover hook locations**



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-21 **Remove the cover**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Middle upper cover

Learn about removing and replacing the middle upper cover.

View a video of removing and replacing the middle upper cover.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-8 Part information

Part number	Part description
6ER04-40026	Middle upper cover

Required tools

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle upper cover

Use the following procedure to remove and replace the middle upper cover.

1. Rotate the control panel into the upright position.

Figure 5-22 **Raise the control panel**



2. Use a pair of tweezers to release the cover, and then remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-23 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right door sHCI dummy cover

Learn about removing and replacing the right door sHCI dummy cover.

View a video of removing and replacing the right door sHCI dummy cover.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-9 Part information

Part number	Part description
JC63-04918B	Right door sHCI dummy cover

Required tools

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right door sHCI dummy cover


Use the following procedure to remove and replace the right door sHCI dummy cover.

- Use a pair of tweezers to release the cover. Remove the cover.

TIP: Position the tweezers as shown below.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-24 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right upper cover

Learn about removing and replacing the right upper cover.

View a video of removing and replacing the right upper cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-10 Part information

Part number	Part description
6ER04-40021	Right upper cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-25 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-26 Remove the cover



2. Remove the keyboard (drawer type)

Use the following procedure to remove and replace the keyboard (drawer type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

1. Do the following:
   - Rotate the control panel into the upright position (callout 1).
   - Use a pair of tweezers to release the cover (callout 2), and then remove the top cover (callout 3).

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.


Figure 5-27 Remove the cover



2. Disconnect two connectors (callout 1), remove three screws (callout 2, and then remove the control panel (callout 3).

NOTE: Lift the control panel straight up to remove it.

Figure 5-28 Remove the control panel



3. Disconnect one connector.

IMPORTANT: The control panel mount bracket and the keyboard must be removed together. They are attached to each other by a film cable.

Figure 5-29 Disconnect one connector



4. Remove four screws.


Figure 5-30 Remove four screws



5. Pull the mount bracket and keyboard assembly straight out and away from the printer to **release** it.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by two hooks.

Figure 5-31 Release the assembly



6. Look up under the mount bracket and keyboard assembly to locate two hooks. Press in on each hook, and then pull the assembly away form the printer to remove it.

Figure 5-32 Remove the assembly



7. **Special instruction for a replacement keyboard**

   a. Dispose of the defective part. See

   NOTE: HP recommends responsible disposal of the defective part.

   http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

b. Unpack the replacement parts supplied in the service kit.

IMPORTANT: Only the control panel mount and keyboard assembly (callout 2) are required to be installed.

Save the additional service kit parts (callouts 1/3/4) for other applications.

Figure 5-33 Service kit parts



3. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.


1. Remove two screws.

Figure 5-34 Remove two screws



2. Open the right door.

Figure 5-35 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-36 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-37 Remove the cover assembly



4. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-38 Remove five screws



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-39 Remove the cover



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right rear cover

Learn about removing and replacing the right rear cover.

View a video of removing and replacing the right rear cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-11 Part information

Part number	Part description
6ER04-61003	Right rear cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-40 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-41 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right front cover

Learn about removing and replacing the right front cover.

View a video of removing and replacing the right front cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-12 Part information

Part number	Part description
6ER04-40005	Right front cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right front cover

Use the following procedure to remove and replace the right front cover.


1. Remove two screws.

Figure 5-42 Remove two screws



2. Open the right door, remove one screw, and then remove the cover.

Figure 5-43 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right middle cover assembly

Learn about removing and replacing the right middle cover assembly.

View a video of removing and replacing the right middle cover assembly.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-13 Part information

Part number	Part description
6ER04-61006	Right middle cover assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-44 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-45 Remove the cover



2. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-46 Remove two screws



2. Open the right door.

Figure 5-47 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-48 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-49 Remove the cover assembly



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right middle cover

Learn about removing and replacing the right middle cover.

View a video of removing and replacing the right middle cover.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-14 Part information

Part number	Part description
6ER04-40025	Right middle cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-50 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-51 **Remove the cover**



2. Remove the keyboard (drawer type)

Use the following procedure to remove and replace the keyboard (drawer type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

1. Do the following:
   - Rotate the control panel into the upright position (callout 1).
   - Use a pair of tweezers to release the cover (callout 2), and then remove the top cover (callout 3).

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.


Figure 5-52 Remove the cover



2. Disconnect two connectors (callout 1), remove three screws (callout 2, and then remove the control panel (callout 3).

NOTE: Lift the control panel straight up to remove it.

Figure 5-53 Remove the control panel



3. Disconnect one connector.

IMPORTANT: The control panel mount bracket and the keyboard must be removed together. They are attached to each other by a film cable.

Figure 5-54 Disconnect one connector



4. Remove four screws.


Figure 5-55 Remove four screws



5. Pull the mount bracket and keyboard assembly straight out and away from the printer to **release** it.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by two hooks.

Figure 5-56 Release the assembly



6. Look up under the mount bracket and keyboard assembly to locate two hooks. Press in on each hook, and then pull the assembly away form the printer to remove it.

Figure 5-57 Remove the assembly



7. **Special instruction for a replacement keyboard**

   a. Dispose of the defective part. See

   NOTE: HP recommends responsible disposal of the defective part.

   http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

b. Unpack the replacement parts supplied in the service kit.

IMPORTANT: Only the control panel mount and keyboard assembly (callout 2) are required to be installed.

Save the additional service kit parts (callouts 1/3/4) for other applications.

Figure 5-58 Service kit parts



3. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-59 Remove two screws



2. Open the right door.

Figure 5-60 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-61 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-62 Remove the cover assembly




4. Remove the right middle cover

Use the following procedure to remove and replace the right middle cover.

- Remove two screws, and then remove the right middle cover.

Figure 5-63 Remove the cover



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Power key

Learn about removing and replacing the power key.

View a video of removing and replacing the power key.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-15 Part information

Part number	Part description
6EQ94-40029	Power key

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-64 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-65 Remove the cover



2. Remove the keyboard (drawer type)

Use the following procedure to remove and replace the keyboard (drawer type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

1. Do the following:
   - Rotate the control panel into the upright position (callout 1).
   - Use a pair of tweezers to release the cover (callout 2), and then remove the top cover (callout 3).

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.


Figure 5-66 Remove the cover



2. Disconnect two connectors (callout 1), remove three screws (callout 2, and then remove the control panel (callout 3).

NOTE: Lift the control panel straight up to remove it.

Figure 5-67 Remove the control panel



3. Disconnect one connector.

IMPORTANT: The control panel mount bracket and the keyboard must be removed together. They are attached to each other by a film cable.

Figure 5-68 Disconnect one connector



4. Remove four screws.


Figure 5-69 Remove four screws



5. Pull the mount bracket and keyboard assembly straight out and away from the printer to **release** it.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by two hooks.

Figure 5-70 Release the assembly



6. Look up under the mount bracket and keyboard assembly to locate two hooks. Press in on each hook, and then pull the assembly away form the printer to remove it.

Figure 5-71 Remove the assembly



7. **Special instruction for a replacement keyboard**

   a. Dispose of the defective part. See

   NOTE: HP recommends responsible disposal of the defective part.

   http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

b. Unpack the replacement parts supplied in the service kit.

IMPORTANT: Only the control panel mount and keyboard assembly (callout 2) are required to be installed.

Save the additional service kit parts (callouts 1/3/4) for other applications.

Figure 5-72 Service kit parts



3. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.


1. Remove two screws.

Figure 5-73 Remove two screws



2. Open the right door.

Figure 5-74 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-75 **Slide the cover**



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-76 Remove the cover assembly




4. Remove the right middle cover

Use the following procedure to remove and replace the right middle cover.

- Remove two screws, and then remove the right middle cover.

Figure 5-77 Remove the cover




5. Remove the power key

Use the following procedure to remove and replace the power key.


1. Remove one screw.

Figure 5-78 Remove one screw



2. Disconnect the power key PCA, remove two screws, and then remove the power key (callout 1).

Figure 5-79 Remove the power key



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Hardware integration pocket (HIP) cover

Learn about removing and replacing the HIP cover.

View a video of removing and replacing the HIP cover.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-16 Part information

Part number	Part description
6EQ94-40032	Hardware integration pocket (HIP) cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the HIP cover

Use the following procedure to remove and replace the HIP cover.

- Use a pair of tweezers to release the cover. Remove the cover.

TIP: Position the tweezers as shown below.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-80 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Middle left cover

Learn about removing and replacing the middle left cover.

View a video of removing and replacing the middle left cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-17 Part information

Part number	Part description
6ER04-40036	Middle left cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-81 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-82 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Exit cover stacker

Learn about removing and replacing the exit cover stacker.

View a video of removing and replacing the exit cover stacker.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-18 Part information

Part number	Part description
6ER04-61004	Exit cover stacker

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-83 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-84 Remove the cover




2. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-85 Remove the cover



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Inner cover

Learn about removing and replacing the inner cover.

View a video of removing and replacing the inner cover.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

NOTE: Before turning the printer power off, use the control panel method to remove the toner cartridges. See the instructions in this section.

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-19 Part information

Part number	Part description
9S185-60007	Inner cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button (located at the bottom right corner of the control panel).

2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-86 **Remove two screws**



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-87 Remove the cover



3. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.


1. Remove two screws.

Figure 5-88 Remove two screws



2. Open the right door.

Figure 5-89 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-90 **Slide the cover**



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-91 Remove the cover assembly




4. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-92 Remove the cover




5. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-93 Remove the TCU




6. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-94 Remove two screws



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-95 Remove the cover




7. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-96 Remove screws and disconnect connector



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-97 Avoid damaging the drum engage lever



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tie stoppers

Learn about removing and replacing the tie stoppers.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

- None

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-20 Part information

Part number	Part description
JC61-04626A	Tie stoppers (front cover restraint - requires 2 tie stoppers)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

- None

Post service test


No post service test is available for this assembly.

1. Remove the tie stoppers

Use the following procedure to remove and replace the tie stoppers.

- Open the front cover, remove four screws, and then remove the tie stoppers.

Figure 5-98 Remove the tie stoppers



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front lower cover

Learn about removing and replacing the front lower cover.

View a video of removing and replacing the front lower cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-21 Part information

Part number	Part description
6ER04-40030	Front lower cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right front cover

Use the following procedure to remove and replace the right front cover.


1. Remove two screws.

Figure 5-99 **Remove two screws**



2. Open the right door, remove one screw, and then remove the cover.

Figure 5-100 **Remove the cover**



2. Remove the front lower cover

Use the following procedure to remove and replace the front lower cover.

1. If Tray 2 and Tray 3 are installed, remove them now.

2. Remove one screw, and then remove the cover.

Figure 5-101 **Remove the cover**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front cover assembly

Learn about removing and replacing the front cover.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-22 Part information

Part number	Part description
6ER08-61001	Front cover assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-102 Remove two screws



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-103 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Feeding system

Learn about feeding system parts removal and replacement.

Right door assembly

Learn about feeding system right door parts removal and replacement.

Removal and replacement: Right door assembly

Learn about removing and replacing the right door.

View a video of removing and replacing the right door.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-23 Part information

Part number	Part description
JC95-02246A	Right door assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-104 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-105 **Remove the cover**



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-106 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-107 Release the hinge



3. Release the right door front link.

Figure 5-108 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-109 **Remove the door**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right door front link

Learn about removing and replacing the right door front link.

View a video of removing and replacing the right door front link.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-24 Part information

Part number	Part description
JC66-04398A	Right door front link

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-110 Remove four screws


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-111 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-112 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-113 Release the hinge



3. Release the right door front link.

Figure 5-114 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-115 Remove the door




3. Remove the right door front link

Use the following procedure to remove and replace the right door front link.

- Use a pair of tweezers to remove one e-ring, and then remove the right door front link.

Figure 5-116 Remove the door link



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right door front damper

Learn about removing and replacing the right door front damper.

View a video of removing and replacing the right door front damper.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-25 Part information

Part number	Part description
JC66-01425A	Right door front damper

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-117 **Remove four screws**


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-118 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-119 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-120 Release the hinge



3. Release the right door front link.

Figure 5-121 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-122 Remove the door




3. Remove the right door front damper

Use the following procedure to remove and replace the right door front damper.

- Remove two screws, and then remove the right door front damper.

Figure 5-123 Remove the door damper



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right door front damper bracket

Learn about removing and replacing the right door front damper bracket.

View a video of removing and replacing the right door front damper bracket.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-26 Part information

Part number	Part description
JC61-08935A	Right door front damper bracket

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.


1. Remove four screws.

   Figure 5-124 **Remove four screws**

2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.
   c. Open the right door, and then remove the right rear cover.

Figure 5-125 Remove the cover




2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-126 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-127 Release the hinge



3. Release the right door front link.

Figure 5-128 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-129 Remove the door




3. Remove the right door front damper bracket

Use the following procedure to remove and replace the right door front damper bracket.

- Remove two screws, remove the right door front damper, and then separate the damper from the bracket.

Figure 5-130 Remove the door damper bracket



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Tray 1 unit

Learn about feeding system Tray 1 unit parts removal and replacement.

Removal and replacement: Tray 1 unit

Learn about removing and replacing the Tray 1 unit.

View a video of removing and replacing the Tray 1 unit.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-27 Part information

Part number	Part description
JC90-01844A	Tray 1 unit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-131 Remove four screws


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-132 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-133 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-134 Release the hinge



3. Release the right door front link.

Figure 5-135 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-136 Remove the door




3. Remove the right door take-away assembly

Use the following procedure to remove and replace the right door take-away assembly.


1. Remove four screws (callout 1).

Figure 5-137 Remove four screws




2. Remove two screws.

Figure 5-138 Remove two screws




3. Remove the lower cable cover.

Figure 5-139 Remove the cover




4. Remove two screws.

Figure 5-140 Remove two screws




5. Remove one screw (on the other side of the door).

Figure 5-141 Remove one screw




6. Remove the feed guide take-away lower.

Figure 5-142 Remove the take-away lower




7. Remove one screw.

Figure 5-143 Remove one screw



8. Remove one screw.

Figure 5-144 Remove one screw



9. Remove one screw.

Figure 5-145 Remove one screw




10. Do the following:

    a. Lift up the feed guide take-away upper to slightly separate it from the door (callout 1).

    b. Disconnect one connector (callout 2).

    c. Remove the take-away assembly from the door (callout 3).

Figure 5-146 Remove the take-away assembly




4. Remove the Tray 1 unit

Use the following procedure to remove and replace the Tray 1 unit.


1. Hold the right door upright. Open Tray 1, and then release the hinge arm (callout 1).

Figure 5-147 Release the hinge arm




2. Remove one screw (callout 1), and then remove the bushing cover (callout 2).

Figure 5-148 **Remove the bushing cover**




3. Remove one e-ring and bushing (callout 1).

Figure 5-149 **Remove one e-ring and bushing**




4. Remove one e-ring and bushing (callout 1; on the other side).

Figure 5-150 Remove one e-ring and bushing




5. Pull the hinge arm up (callout 1), and then remove one screw (callout 2).

Figure 5-151 Remove one screw




6. Release the hinge.

Figure 5-152 **Release the hinge**




7. Remove one screw (callout 1), and then release one retainer (callout 2).

Figure 5-153 **Release one retainer**




8. Remove one screw (callout 1).

Figure 5-154 Remove one screw



9. Lift up on the feed roller assembly (callout 1), and then slide it to the left (callout 2) to release it.


Figure 5-155 Release the feed roller assembly



10. Rotate the feed roller assembly to the side.


⚠ CAUTION: Do not attempt to completely remove the feed roller assembly. It is still attached to the right door.

Figure 5-156 Move the feed roller assembly



11. Remove three screws (callout 1).

Figure 5-157 Remove three screws




12. Remove the duplex lower guide.

Figure 5-158 Remove the duplex lower guide




13. Remove one screw (callout 1).

Figure 5-159 Remove one screw




14. Remove two screws (callout 1).

Figure 5-160 Remove two screws




15. Release one retainer (callout 1), disconnect three connectors (callout 2), and the remove two screws (callout 3).

Figure 5-161 Remove two screws




16. Release the Tray 1 unit form the right door.

Figure 5-162 **Release the Tray 1 unit**



17. Remove the Tray 1 unit.

Figure 5-163 **Remove the Tray 1 unit**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 1 empty sensor

Learn about removing and replacing the Tray 1 empty sensor.

View a video of removing and replacing the Tray 1 empty sensor.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-28 Part information

Part number	Part description
0604-001490	Photo interrupter (Tray 1 empty sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-164 **Remove four screws**


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-165 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-166 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-167 Release the hinge



3. Release the right door front link.

Figure 5-168 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-169 Remove the door




3. Remove the right door take-away assembly

Use the following procedure to remove and replace the right door take-away assembly.


1. Remove four screws (callout 1).

Figure 5-170 Remove four screws




2. Remove two screws.

Figure 5-171 Remove two screws




3. Remove the lower cable cover.

Figure 5-172 Remove the cover




4. Remove two screws.

Figure 5-173 Remove two screws




5. Remove one screw (on the other side of the door).

Figure 5-174 Remove one screw




6. Remove the feed guide take-away lower.

Figure 5-175 Remove the take-away lower




7. Remove one screw.

Figure 5-176 Remove one screw



8. Remove one screw.

Figure 5-177 Remove one screw



9. Remove one screw.

Figure 5-178 Remove one screw




10. Do the following:

    a. Lift up the feed guide take-away upper to slightly separate it from the door (callout 1).

    b. Disconnect one connector (callout 2).

    c. Remove the take-away assembly from the door (callout 3).

Figure 5-179 Remove the take-away assembly




4. Remove the Tray 1 unit

Use the following procedure to remove and replace the Tray 1 unit.


1. Hold the right door upright. Open Tray 1, and then release the hinge arm (callout 1).

Figure 5-180 Release the hinge arm




2. Remove one screw (callout 1), and then remove the bushing cover (callout 2).

Figure 5-181 Remove the bushing cover




3. Remove one e-ring and bushing (callout 1).

Figure 5-182 Remove one e-ring and bushing




4. Remove one e-ring and bushing (callout 1; on the other side).

Figure 5-183 Remove one e-ring and bushing




5. Pull the hinge arm up (callout 1), and then remove one screw (callout 2).

Figure 5-184 Remove one screw




6. Release the hinge.

Figure 5-185 **Release the hinge**




7. Remove one screw (callout 1), and then release one retainer (callout 2).

Figure 5-186 **Release one retainer**




8. Remove one screw (callout 1).

Figure 5-187 Remove one screw



9. Lift up on the feed roller assembly (callout 1), and then slide it to the left (callout 2) to release it.


Figure 5-188 Release the feed roller assembly



10. Rotate the feed roller assembly to the side.


⚠ CAUTION: Do not attempt to completely remove the feed roller assembly. It is still attached to the right door.

Figure 5-189 Move the feed roller assembly



11. Remove three screws (callout 1).

Figure 5-190 Remove three screws




12. Remove the duplex lower guide.

Figure 5-191 Remove the duplex lower guide




13. Remove one screw (callout 1).

Figure 5-192 Remove one screw




14. Remove two screws (callout 1).

Figure 5-193 Remove two screws




15. Release one retainer (callout 1), disconnect three connectors (callout 2), and the remove two screws (callout 3).

Figure 5-194 Remove two screws




16. Release the Tray 1 unit form the right door.

Figure 5-195 **Release the Tray 1 unit**



17. Remove the Tray 1 unit.

Figure 5-196 **Remove the Tray 1 unit**




5. Remove the Tray 1 paper empty sensor

Use the following procedure to remove and replace the Tray 1 paper empty sensor.


1. Locate the Tray 1 paper empty sensor.

Figure 5-197 Locate the sensor



2. Use a pair of tweezers to release two tabs, and then remove sensor.

Figure 5-198 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 1 clutch

Learn about removing and replacing the Tray 1 clutch.

View a video of removing and replacing the Tray 1 clutch.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-29 Part information

Part number	Part description
JC47-00037A	Tray 1 clutch

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-199 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-200 **Remove the cover**



3. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.


Figure 5-201 **Remove four screws**



2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-202 Remove the cover



4. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-203 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-204 Release the hinge



3. Release the right door front link.

Figure 5-205 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-206 Remove the door



5. Remove the feed drive assembly

Use the following procedure to remove and replace the feed drive assembly.


1. Remove one screw.

Figure 5-207 Remove one screw




2. Release one hook, and then remove the gear cover.

Figure 5-208 Remove the gear cover




3. Release three retainers.

Figure 5-209 Release three retainers




4. Disconnect two connectors.

Figure 5-210 **Disconnect two connectors**



5. Remove three screws, and then remove the feed drive assembly

Figure 5-211 **Remove the feed drive assembly**



6. Remove the Tray 1 clutch

Use the following procedure to remove and replace the Tray 1 clutch.


1. Remove one screw.

Figure 5-212 Remove one screw




2. Remove the sheet-metal cover.

Figure 5-213 Remove the cover



3. Remove the clutch.

Figure 5-214 **Remove the clutch**



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 1 roller kit (pickup/forward/reverse)

Learn about removing and replacing the Tray 1 roller kit.

View a video of removing and replacing the Tray 1 roller kit.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-30 Part information

Part number	Part description
5RC03-67001	Tray 1 roller kit NOTE: This kit includes the pickup, forward, and reverse rollers.

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the Tray 1 roller kit

Use the following procedure to remove and replace the Tray 1 roller kit.


1. Release the right- and left side tabs, and then remove the Tray 1 roller cover.

Figure 5-215 **Remove the cover**



2. Release one tab, and then remove the sensor cover.


Figure 5-216 **Remove the cover**



3. Use a pair of tweezers to release the locking tab, and then slide the roller off the shaft to remove it.
   - **Pickup roller**: callout 1
   - **Reverse roller**: callout 2

- **Forward roller**: callout 3

Figure 5-217 **Remove the rollers**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Tray 2-3 units

Learn about feeding system Tray 2-3 units parts removal and replacement.

Removal and replacement: Tray 2 or Tray 3

Learn about removing and replacing Tray 2 or Tray 3.

View a video of removing and replacing Tray 2 or Tray 3.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-31 Part information

Part number	Part description
5QK09-60120	Tray 2
5QK09-60121	Tray 3

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-218 **Remove the tray**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2 pickup assembly

Learn about removing and replacing the Tray 2 pickup assembly.

View a video of removing and replacing the Tray 2 pickup assembly.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-32 Part information

Part number	Part description
JC93-01694A	Tray 2 pickup assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-219 **Remove four screws**


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-220 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-221 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-222 Release the hinge



3. Release the right door front link.

Figure 5-223 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-224 Remove the door




3. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-225 Remove the tray




4. Remove the Tray 3 pickup assembly

Use the following procedure to remove and replace the Tray 3 pickup assembly.


1. Remove one screw, and then remove the gear cover.

Figure 5-226 Remove the cover




2. Release one hook.

Figure 5-227 Release the hook



3. Remove three screws.


Figure 5-228 Remove three screws



4. Rotate the left side of pickup assembly away from the printer.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-229 Rotate the assembly away from the printer




5. Disconnect one connector, and then remove the assembly.

Figure 5-230 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-231 Install the assembly



5. Remove the Tray 2 pickup assembly

Use the following procedure to remove and replace the Tray 2 pickup assembly.

1. Remove three screws.


Figure 5-232 Remove three screws



2. Rotate the left side of the pickup assembly away from the printer.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-233 Rotate the assembly away from the printer




3. Disconnect one connector, and then remove the assembly.

Figure 5-234 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-235 Install the assembly



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2, 3 roller kit (pickup/forward/reverse)

Learn about removing and replacing the Tray 2/3 roller kit.

View a video of removing and replacing the Tray 2 roller kit.

View a video of removing and replacing the Tray 3 roller kit.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-33 Part information

Part number	Part description
5PN66-67001	Tray 2/3 roller kit NOTE: This kit includes the pickup, forward, and reverse rollers.

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-236 Remove the tray




2. Remove the Tray 2/3 roller kit

Use the following procedure to remove and replace the Tray 2/3 roller kit.

1. Locate the return guide inside the tray opening, and then slide the guide toward the front of the printer until it stops.


Reinstallation tip: After installing replacement rollers, make sure to fully slide the return guide towards the rear of the printer to prevent paper jams.

Figure 5-237 **Slide the return guide**



2. Use a pair of tweezers to release the locking tab, and then slide the roller off the shaft to remove it.
   - **Pickup roller**: callout 1
   - **Forward roller**: callout 2
   - **Reverse roller**: callout 3


Figure 5-238 **Remove the rollers**



3. When the rollers are removed, be careful not to dislodge the couplers. If the couplers are dislodged, install them on the shafts as shown below.

NOTE: The figure below shows the pickup assembly removed to more clearly show the rollers and couplers.

Figure 5-239 Rollers and couplers installed



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2 empty and stack height sensors

Learn about removing and replacing the Tray 2 empty and stack height sensors.

View a video of removing and replacing the Tray 2 empty sensor.

View a video of removing and replacing the Tray 2 stack height sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-34 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Tray 2 empty sensor)
3SJ00-60110	Photo interrupter (Tray 2 stack height sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-240 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-241 **Remove the cover**



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-242 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-243 Release the hinge



3. Release the right door front link.

Figure 5-244 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-245 **Remove the door**




3. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-246 Remove the tray




4. Remove the Tray 3 pickup assembly

Use the following procedure to remove and replace the Tray 3 pickup assembly.


1. Remove one screw, and then remove the gear cover.

Figure 5-247 Remove the cover




2. Release one hook.

Figure 5-248 Release the hook



3. Remove three screws.


Figure 5-249 Remove three screws



4. Rotate the left side of pickup assembly away from the printer.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-250 Rotate the assembly away from the printer




5. Disconnect one connector, and then remove the assembly.

Figure 5-251 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-252 Install the assembly



5. Remove the Tray 2 pickup assembly

Use the following procedure to remove and replace the Tray 2 pickup assembly.

1. Remove three screws.


Figure 5-253 Remove three screws



2. Rotate the left side of the pickup assembly away from the printer.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-254 Rotate the assembly away from the printer




3. Disconnect one connector, and then remove the assembly.

Figure 5-255 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-256 Install the assembly




6. Remove the Tray 2 empty and stack height sensors

Use the following procedure to remove and replace the Tray 2 empty and stack height sensors.

1. Locate the Tray 2 empty (callout 1) and stack height (callout 2) sensors, connectors, and locking tabs on the pickup assembly.

Figure 5-257 Locate the sensors




2. Do the following:

NOTE: The black ESD insulator sheet does not need to be removed.


- Release the hooks (callout 1).
- Slide the sensor assembly to the left (callout 2).
- Push the senor assembly as shown (callout 3) to release it.

Figure 5-258 Release the sensors



3. Disconnect the connector and remove the sensor assembly.

Figure 5-259 Remove the sensors



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2 prefeed sensor

Learn about removing and replacing the Tray 2 prefeed sensor.

View a video of removing and replacing the Tray 2 prefeed sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-35 Part information

Part number	Part description
0604-001490	Photo interrupter (Tray 2 prefeed sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-260 **Remove four screws**


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-261 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-262 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-263 Release the hinge



3. Release the right door front link.

Figure 5-264 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-265 Remove the door




3. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-266 Remove the tray




4. Remove the Tray 3 pickup assembly

Use the following procedure to remove and replace the Tray 3 pickup assembly.


1. Remove one screw, and then remove the gear cover.

Figure 5-267 Remove the cover




2. Release one hook.

Figure 5-268 Release the hook



3. Remove three screws.


Figure 5-269 Remove three screws



4. Rotate the left side of pickup assembly away from the printer.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-270 Rotate the assembly away from the printer




5. Disconnect one connector, and then remove the assembly.

Figure 5-271 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-272 Install the assembly



5. Remove the Tray 2 pickup assembly

Use the following procedure to remove and replace the Tray 2 pickup assembly.

1. Remove three screws.


Figure 5-273 **Remove three screws**



2. Rotate the left side of the pickup assembly away from the printer.


⚠ **CAUTION:** Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-274 **Rotate the assembly away from the printer**




3. Disconnect one connector, and then remove the assembly.

Figure 5-275 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-276 Install the assembly



6. Remove the Tray 2 prefeed sensor

Use the following procedure to remove and replace the Tray 2 prefeed sensor.

1. Remove four screws.

Figure 5-277 **Remove four screws**




2. Tightly grasp the sensor guide, and then remove it.

⚠ **CAUTION:** The sheet-metal edges are sharp. Be careful when removing the guide to avoid personal injury.


NOTE: It might take some force to remove the guide form the rail.

Figure 5-278 **Remove the sensor guide**



3. Disconnect one connector, and then remove the Tray 2 prefeed sensor.

Figure 5-279 **Remove the sensor**



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2 open and paper size sensor

Learn about removing and replacing the Tray 2 open and paper size sensor.

NOTE: This procedure removes the front door for better access to the sensor.

View a video of removing and replacing the Tray 2 open and paper size sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-36 Part information

Part number	Part description
JC93-01408A	Tray 2 open and paper size sensor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-280 Remove two screws



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-281 Remove the cover




2. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-282 **Remove the tray**




3. Remove the Tray 2 open and paper size sensor

Use the following procedure to remove and replace the Tray 2 open and paper size sensor.

1. Remove two screws.

Figure 5-283 **Remove two screws**



2. Disconnect one connector, and then remove the sensor assembly.

NOTE: The sensor assembly is located far back in the tray cavity. Hold the sensor as shown below to easily disconnect (and reconnect at installation) the connector.

Figure 5-284 Remove the sensor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2 pickup drive assembly

Learn about removing and replacing the Tray 2 pickup drive assembly.

View a video of removing and replacing the Tray 2 pickup drive assembly.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-37 Part information

Part number	Part description
JC93-01663A	Tray 2 pickup drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-285 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-286 Remove the cover




3. Remove the LVPS FDB fan assembly

Use the following procedure to remove and replace the LVPS FDB fan assembly.


1. Disconnect one connector.

Figure 5-287 **Disconnect one connector**




2. Remove four screws.

Figure 5-288 **Remove four screws**



3. Release one tab, and then remove the LVP FDB fan assembly.

Figure 5-289 Remove the LVP FDB fan assembly




4. Remove the Tray 2 pickup drive assembly

Use the following procedure to remove and replace the Tray 2 pickup drive assembly.

1. Disconnect all of the connectors on the fuser drive board, and then release the wire harnesses form the restraints (callout 1).


NOTE: Some of the connectors have a locking tab must be pressed to remove them.

Figure 5-290 Release the wire harnesses



2. Remove three screws, rotate the top of the sheet-metal cage out and away from the printer, and then remove the PCAs and cage together.

Figure 5-291 **Remove the PCAs and cage**




3. Do the following:

   a. Disconnect one connector (callout 1).

   b. Remove three screws (callout 2).

   c. Remove the Tray 2 pickup drive assembly.

Figure 5-292 **Remove the assembly**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2 pickup motor

Learn about removing and replacing the Tray 2 pickup motor.

View a video of removing and replacing the Tray 2 pickup motor.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-38 Part information

Part number	Part description
JC93-01083A	Drive-motor, step (Tray 2 pickup motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-293 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-294 Remove the cover




3. Remove the Tray 2 pickup motor

Use the following procedure to remove and replace the Tray 2 pickup motor.

- Disconnect one connector, remove two screws, and then remove the motor.

Figure 5-295 Remove the motor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 3 pickup drive assembly

Learn about removing and replacing the Tray 3 pickup drive assembly.

View a video of removing and replacing the Tray 3 pickup drive assembly.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-39 Part information

Part number	Part description
JC93-01663A	Tray 3 pickup drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-296 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-297 Remove the cover




3. Remove the Tray 3 pickup drive assembly

Use the following procedure to remove and replace the Tray 3 pickup drive assembly.

- Disconnect one connector, remove three screws, and then remove the drive assembly.

Figure 5-298 Remove the drive assembly



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 3 pickup motor

Learn about removing and replacing the Tray 3 pickup motor.

View a video of removing and replacing the Tray 3 pickup motor.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-40 Part information

Part number	Part description
JC93-01083A	Drive-motor step (Tray 3 pickup motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-299 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-300 Remove the cover




3. Remove the Tray 3 pickup motor

Use the following procedure to remove and replace the Tray 3 pickup motor.

- Disconnect one connector, remove two screws, and then remove the motor.

Figure 5-301 Remove the motor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 3 pickup assembly

Learn about removing and replacing the tray 3 pickup assembly.

View a video of removing and replacing the tray 3 pickup assembly.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-41 Part information

Part number	Part description
JC93-01695A	Tray 3 pickup assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.


Figure 5-302 Remove four screws



2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-303 Remove the cover




2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-304 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-305 Release the hinge



3. Release the right door front link.

Figure 5-306 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-307 Remove the door




3. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-308 Remove the tray




4. Remove the Tray 3 pickup assembly

Use the following procedure to remove and replace the Tray 3 pickup assembly.


1. Remove one screw, and then remove the gear cover.

Figure 5-309 Remove the cover




2. Release one hook.

Figure 5-310 Release the hook



3. Remove three screws.


Figure 5-311 **Remove three screws**



4. Rotate the left side of pickup assembly away from the printer.


⚠ **CAUTION:** Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-312 **Rotate the assembly away from the printer**




5. Disconnect one connector, and then remove the assembly.

Figure 5-313 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-314 Install the assembly



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 2, 3 roller kit (pickup/forward/reverse)

Learn about removing and replacing the Tray 2/3 roller kit.

View a video of removing and replacing the Tray 2 roller kit.

View a video of removing and replacing the Tray 3 roller kit.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-42 Part information

Part number	Part description
5PN66-67001	Tray 2/3 roller kit NOTE: This kit includes the pickup, forward, and reverse rollers.

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-315 Remove the tray




2. Remove the Tray 2/3 roller kit

Use the following procedure to remove and replace the Tray 2/3 roller kit.

1. Locate the return guide inside the tray opening, and then slide the guide toward the front of the printer until it stops.


Reinstallation tip: After installing replacement rollers, make sure to fully slide the return guide towards the rear of the printer to prevent paper jams.

Figure 5-316 **Slide the return guide**



2. Use a pair of tweezers to release the locking tab, and then slide the roller off the shaft to remove it.
   - **Pickup roller**: callout 1
   - **Forward roller**: callout 2
   - **Reverse roller**: callout 3


Figure 5-317 **Remove the rollers**



3. When the rollers are removed, be careful not to dislodge the couplers. If the couplers are dislodged, install them on the shafts as shown below.

NOTE: The figure below shows the pickup assembly removed to more clearly show the rollers and couplers.

Figure 5-318 Rollers and couplers installed



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 3 empty and stack height sensors

Learn about removing and replacing the Tray 3 empty and stack height sensors.

View a video of removing and replacing the Tray 3 empty sensor.

View a video of removing and replacing the Tray 3 stack height sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-43 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Tray 3 empty sensor)
3SJ00-60110	Photo interrupter (Tray 3 stack height sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-319 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-320 **Remove the cover**



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-321 **Disconnect one connector**



2. Release the hinge.


> ⚠ **CAUTION:** The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-322 **Release the hinge**



3. Release the right door front link.

Figure 5-323 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-324 **Remove the door**




3. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-325 Remove the tray




4. Remove the Tray 3 pickup assembly

Use the following procedure to remove and replace the Tray 3 pickup assembly.


1. Remove one screw, and then remove the gear cover.

Figure 5-326 Remove the cover




2. Release one hook.

Figure 5-327 Release the hook



3. Remove three screws.


Figure 5-328 Remove three screws



4. Rotate the left side of pickup assembly away from the printer.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-329 Rotate the assembly away from the printer




5. Disconnect one connector, and then remove the assembly.

Figure 5-330 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-331 Install the assembly




5. Remove the Tray 3 empty and stack height sensors

Use the following procedure to remove and replace the Tray 3 empty and stack height sensors.

1. Locate the Tray 3 empty (callout 1) and stack height (callout 2) sensors, connectors, and locking tabs on the pickup assembly.

Figure 5-332 Locate the sensors




2. Do the following:

NOTE: The black ESD insulator sheet does not need to be removed.


- Release the hooks (callout 1).
- Slide the sensor assembly to the left (callout 2).
- Push the senor assembly as shown (callout 3) to release it.

Figure 5-333 Release the sensors



3. Disconnect the connector and remove the sensor assembly.

Figure 5-334 Remove the sensors



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 3 prefeed sensor

Learn about removing and replacing the Tray 3 prefeed sensor.

View a video of removing and replacing the Tray 3 prefeed sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-44 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Tray 3 prefeed sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-335 **Remove four screws**


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-336 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-337 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-338 Release the hinge



3. Release the right door front link.

Figure 5-339 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-340 Remove the door




3. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-341 Remove the tray




4. Remove the Tray 3 pickup assembly

Use the following procedure to remove and replace the Tray 3 pickup assembly.


1. Remove one screw, and then remove the gear cover.

Figure 5-342 Remove the cover




2. Release one hook.

Figure 5-343 Release the hook



3. Remove three screws.


Figure 5-344 Remove three screws



4. Rotate the left side of pickup assembly away from the printer.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by a wire harness and connector.

Figure 5-345 Rotate the assembly away from the printer




5. Disconnect one connector, and then remove the assembly.

Figure 5-346 Remove the assembly



Reinstallation tip: When installing the assembly, insert and align the right side first.

Figure 5-347 Install the assembly




5. Remove the Tray 3 prefeed sensor

Use the following procedure to remove and replace the Tray 3 prefeed sensor.


1. Remove one screw (callout 1), and then open the pickup guide (callout 2).

Figure 5-348 **Open the pickup guide**



2. Locate the sensor on the pickup assembly, and then do the following:
   - Disconnect one connector.
   - Remove one screw.
   - Release the Tray 3 prefeed sensor.

Figure 5-349 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 3 open and paper size sensor

Learn about removing and replacing the Tray 3 open and paper size sensor.

NOTE: This procedure removes the front door for better access to the sensor.

View a video of removing and replacing the Tray 3 open and paper size sensor.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-45 Part information

Part number	Part description
JC93-01408A	Tray 3 open and paper size sensor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-350 **Remove two screws**



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-351 Remove the cover




2. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-352 **Remove the tray**




3. Remove the Tray 3 open and paper size sensor

Use the following procedure to remove and replace the Tray 3 open and paper size sensor.

1. Remove two screws.

Figure 5-353 **Remove two screws**



2. Disconnect one connector, and then remove the sensor assembly.

NOTE: The figure below shows the Tray 2 sensor being removed. Removing the Tray 3 sensor (lower) is identical to Tray 2.

TIP: The sensor assembly is located far back in the tray cavity. Hold the sensor as shown below to easily disconnect (and reconnect at installation) the connector.

Figure 5-354 Remove the sensor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray heater (accessory)

Learn about removing and replacing the tray heaters.

View a video of removing and replacing the tray heaters.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-46 Part information

Part number	Part description
Y1G22-67901	Tray heater 110V
Y1G22-67902	Tray heater 220V

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-355 **Remove the tray**



2. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

1. Remove one screw.

Figure 5-356 Remove one screw



2. Do the following:

- Slightly lift up on the front of the heater, and pull it toward the front of the printer.

⚠ CAUTION: Do not attempt to completely remove the heater. It is still attached to the printer by a wire-harness connector.

- Disconnect one connector, and then remove the heater.

Figure 5-357 Remove the heater



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Feed drive assembly

Learn about removing and replacing the feed drive assembly.

View a video of removing and replacing the feed drive assembly.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-47 Part information

Part number	Part description
JC93-01664A	Feed drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-358 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-359 Remove the cover



3. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.


Figure 5-360 Remove four screws



2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-361 Remove the cover



4. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-362 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-363 Release the hinge



3. Release the right door front link.

Figure 5-364 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-365 Remove the door



5. Remove the feed drive assembly

Use the following procedure to remove and replace the feed drive assembly.


1. Remove one screw.

Figure 5-366 Remove one screw




2. Release one hook, and then remove the gear cover.

Figure 5-367 Remove the gear cover




3. Release three retainers.

Figure 5-368 Release three retainers




4. Disconnect two connectors.

Figure 5-369 Disconnect two connectors



5. Remove three screws, and then remove the feed drive assembly

Figure 5-370 Remove the feed drive assembly



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Feed motor

Learn about removing and replacing the feed motor.

View a video of removing and replacing the feed motor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-48 Part information

Part number	Part description
JC31-00189A	Drive-motor step (Feed motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-371 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-372 **Remove the cover**



3. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.


Figure 5-373 **Remove four screws**



2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-374 Remove the cover



4. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-375 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-376 Release the hinge



3. Release the right door front link.

Figure 5-377 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-378 Remove the door



5. Remove the feed drive assembly

Use the following procedure to remove and replace the feed drive assembly.


1. Remove one screw.

Figure 5-379 Remove one screw




2. Release one hook, and then remove the gear cover.

Figure 5-380 **Remove the gear cover**




3. Release three retainers.

Figure 5-381 **Release three retainers**




4. Disconnect two connectors.

Figure 5-382 Disconnect two connectors



5. Remove three screws, and then remove the feed drive assembly

Figure 5-383 Remove the feed drive assembly



6. Remove the Tray 1 clutch

Use the following procedure to remove and replace the Tray 1 clutch.


1. Remove one screw.

Figure 5-384 **Remove one screw**




2. Remove the sheet-metal cover.

Figure 5-385 **Remove the cover**



3. Remove the clutch.

Figure 5-386 **Remove the clutch**



7. Remove the feed motor

Use the following procedure to remove and replace the feed motor.


1. Remove two gears.

Figure 5-387 **Remove two gears**



2. Remove two screws, and then remove the motor.

Figure 5-388 **Remove the motor**



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Feed 2 sensor

Learn about removing and replacing the feed 2 sensor.

View a video of removing and replacing the feed 2 sensor.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-49 Part information

Part number	Part description
0604-001490	Photo interrupter (Feed 2 sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-389 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-390 **Remove the cover**



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-391 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-392 Release the hinge



3. Release the right door front link.

Figure 5-393 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-394 **Remove the door**




3. Remove the right door take-away assembly

Use the following procedure to remove and replace the right door take-away assembly.


1. Remove four screws (callout 1).

Figure 5-395 Remove four screws




2. Remove two screws.

Figure 5-396 Remove two screws




3. Remove the lower cable cover.

Figure 5-397 **Remove the cover**




4. Remove two screws.

Figure 5-398 **Remove two screws**




5. Remove one screw (on the other side of the door).

Figure 5-399 Remove one screw




6. Remove the feed guide take-away lower.

Figure 5-400 Remove the take-away lower




7. Remove one screw.

Figure 5-401 Remove one screw



8. Remove one screw.

Figure 5-402 Remove one screw



9. Remove one screw.

Figure 5-403 Remove one screw




10. Do the following:

    a. Lift up the feed guide take-away upper to slightly separate it from the door (callout 1).

    b. Disconnect one connector (callout 2).

    c. Remove the take-away assembly from the door (callout 3).

Figure 5-404 Remove the take-away assembly




4. Remove the feed 2 sensor

Use the following procedure to remove and replace the feed 2 sensor.

- Disconnect one connector, and then remove the senor form the feed guide take away upper.

Figure 5-405 Remove the sensor



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Registration unit and loop sensing unit

Learn about registration unit and loop sensing unit parts removal and replacement.

Removal and replacement: Registration unit

Learn about removing and replacing the registration unit.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-50 Part information

Part number	Part description
5QK13-60101	Registration unit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.


1. Remove four screws.

   Figure 5-406 **Remove four screws**

2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.
   c. Open the right door, and then remove the right rear cover.

Figure 5-407 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-408 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-409 Release the hinge



3. Release the right door front link.

Figure 5-410 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-411 Remove the door




3. Remove the registration unit

Use the following procedure to remove and replace the registration unit.


1. Remove two screws, and then remove the paper path guide (callout 1).

Figure 5-412 Remove the guide




2. Release one tab and remove the gear cover (callout 1), and then disconnect one connector (callout 2).

Figure 5-413 Disconnect one connector




3. Remove two screws.

Figure 5-414 Remove two screws



4. Release the left side of the registration unit, and then rotate it away form the printer to remove it.

Figure 5-415 Remove the unit



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Registration sensor

Learn about removing and replacing the registration sensor.

View a video of removing and replacing the registration sensor.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-51 Part information

Part number	Part description
0604-001381	Photo interrupter (registration sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-416 Remove four screws




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-417 Remove the cover



Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-418 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-419 Release the hinge



3. Release the right door front link.

Figure 5-420 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-421 **Remove the door**




Remove the registration unit

Use the following procedure to remove and replace the registration unit.


1. Remove two screws, and then remove the paper path guide (callout 1).

Figure 5-422 Remove the guide




2. Release one tab and remove the gear cover (callout 1), and then disconnect one connector (callout 2).

Figure 5-423 Disconnect one connector




3. Remove two screws.

Figure 5-424 Remove two screws



4. Release the left side of the registration unit, and then rotate it away form the printer to remove it.

Figure 5-425 Remove the unit




Remove the registration sensor

Use the following procedure to remove and replace the registration sensor.

1. Remove two screws (callout 1), and then remove the sensor cover (callout 2).

Figure 5-426 **Remove the cover**




2. Remove one screw.

Figure 5-427 **Remove one screw**



3. Turn the registration unit over, release the retainer and wire harness (callout 1), and then remove the sensor (callout 2).

Figure 5-428 Remove the sensor



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Registration drive assembly

Learn about removing and replacing the registration drive assembly.

View a video of removing and replacing the registration drive assembly.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-52 Part information

Part number	Part description
JC93-01665A	Registration drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-429 **Remove the TCU**




2. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.

1. Open the right door.


2. At the front of the printer, remove one screw.

Figure 5-430 Remove one screw



3. Pull the drum unit out of the printer.

Figure 5-431 Remove the unit




3. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-432 Release the lever and disconnect the connector



2. Remove four screws.

Figure 5-433 Remove four screws



3. Pull the developer unit out of the printer.


NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-434 Do not grab lever



Figure 5-435 Remove the unit




4. Remove the developer, drum, and PTB drive assembly

Use the following procedure to remove and replace the developer, drum, and PTB drive assembly.

1. Disconnect three connectors.


Figure 5-436 Disconnect three connectors



2. Remove three screws, and then remove the developer, drum, and PTB drive assembly.

NOTE: Remove the three silver screws (not the gold screws) shown below.

Figure 5-437 Remove three screws




5. Remove the registration drive assembly

Use the following procedure to remove and replace the registration drive assembly.

- Disconnect one connector, remove three screws, and then remove the registration drive assembly.

Figure 5-438 Remove the assembly



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Registration motor

Learn about removing and replacing the registration motor.

View a video of removing and replacing the registration motor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-53 Part information

Part number	Part description
JC31-00189A	Drive-motor step (registration motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-439 Remove the TCU




2. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.


1. Open the right door.
2. At the front of the printer, remove one screw.

Figure 5-440 Remove one screw



3. Pull the drum unit out of the printer.

Figure 5-441 Remove the unit




3. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-442 Release the lever and disconnect the connector



2. Remove four screws.

Figure 5-443 Remove four screws



3. Pull the developer unit out of the printer.

NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-444 Do not grab lever





Figure 5-445 Remove the unit




4. Remove the registration drive assembly

Use the following procedure to remove and replace the registration drive assembly.

- Disconnect one connector, remove three screws, and then remove the registration drive assembly.

Figure 5-446 Remove the assembly




5. Remove the developer, drum, and PTB drive assembly

Use the following procedure to remove and replace the developer, drum, and PTB drive assembly.

1. Disconnect three connectors.


Figure 5-447 Disconnect three connectors



2. Remove three screws, and then remove the developer, drum, and PTB drive assembly.

NOTE: Remove the three silver screws (not the gold screws) shown below.

Figure 5-448 Remove three screws




6. Remove the registration drive assembly

Use the following procedure to remove and replace the registration drive assembly.

- Disconnect one connector, remove three screws, and then remove the registration drive assembly.

Figure 5-449 Remove the assembly




7. Remove the registration motor

Use the following procedure to remove and replace the registration motor.

- Remove two screws (callout 1), disengage the drive belt (callout 2), and then remove the registration motor.

Figure 5-450 Remove the motor



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Paper transfer belt (PBT)

Learn about removing and replacing the paper transfer belt (PTB).

View a video of removing and replacing the PTB.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-54 Part information

Part number	Part description
5PN85-67001	Paper transfer belt (PTB)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-451 Remove four screws


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-452 Remove the cover




2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-453 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-454 Release the hinge



3. Release the right door front link.

Figure 5-455 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-456 Remove the door




3. Remove the paper transfer belt (PTB)

Use the following procedure to remove and replace the PTB.


1. Remove four screws (two screws on each side).

Figure 5-457 Remove four screws




2. Remove one screw, and then remove the cover.

Figure 5-458 Remove the cover



3. Disconnect one connector, and then remove the PTB.

Figure 5-459 Disconnect one connector



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Loop sensor 1

Learn about removing and replacing the loop sensor 1.

View a video of removing and replacing the loop sensor 1.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-55 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (loop sensor 1)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.


1. Remove four screws.

   Figure 5-460 **Remove four screws**

2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.
   c. Open the right door, and then remove the right rear cover.

Figure 5-461 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-462 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-463 Release the hinge



3. Release the right door front link.

Figure 5-464 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-465 Remove the door




3. Remove the paper transfer belt (PTB)

Use the following procedure to remove and replace the PTB.


1. Remove four screws (two screws on each side).

Figure 5-466 Remove four screws




2. Remove one screw, and then remove the cover.

Figure 5-467 Remove the cover



3. Disconnect one connector, and then remove the PTB.

Figure 5-468 Disconnect one connector



4. Remove the loop actuator

Use the following procedure to remove and replace the loop actuator.

1. Remove four screws.


Figure 5-469 Remove four screws



2. Remove the loop actuator.

NOTE: Note the spring position in order to install the actuator correctly.

Figure 5-470 Actuator spring



5. Remove the loop sensor 1

Use the following procedure to remove and replace the loop sensor 1.

1. Locate the sensor inside the cover.

Figure 5-471 Inside the cover






Figure 5-472 Outside the cover



2. To remove a photo sensor, do the following:
   - Release the hooks.
   - Slide the sensor assembly in the direction indicated.
   - Remove the sensor assembly.

Figure 5-473 Release the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Loop sensor 2

Learn about removing and replacing the loop sensor 2.

View a video of removing and replacing the loop sensor 2.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-56 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (loop sensor 2)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-474 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-475 **Remove the cover**



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-476 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-477 Release the hinge



3. Release the right door front link.

Figure 5-478 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-479 **Remove the door**




3. Remove the paper transfer belt (PTB)

Use the following procedure to remove and replace the PTB.


1. Remove four screws (two screws on each side).

Figure 5-480 Remove four screws




2. Remove one screw, and then remove the cover.

Figure 5-481 Remove the cover



3. Disconnect one connector, and then remove the PTB.

Figure 5-482 Disconnect one connector



4. Remove the loop actuator

Use the following procedure to remove and replace the loop actuator.

1. Remove four screws.


Figure 5-483 Remove four screws



2. Remove the loop actuator.

NOTE: Note the spring position in order to install the actuator correctly.

Figure 5-484 Actuator spring



5. Remove the loop sensor 2

Use the following procedure to remove and replace the loop sensor 2.

1. Locate the sensor inside the cover.

Figure 5-485 Inside the cover






Figure 5-486 Outside the cover



2. To remove a photo sensor, do the following:
   - Release the hooks.
   - Slide the sensor assembly in the direction indicated.
   - Remove the sensor assembly.

Figure 5-487 Release the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Loop actuator

Learn about removing and replacing the loop actuator.

View a video of removing and replacing the loop actuator.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-57 Part information

Part number	Part description
JC66-04572A	Loop actuator

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-488 Remove four screws


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-489 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-490 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-491 Release the hinge



3. Release the right door front link.

Figure 5-492 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-493 Remove the door




3. Remove the paper transfer belt (PTB)

Use the following procedure to remove and replace the PTB.


1. Remove four screws (two screws on each side).

Figure 5-494 Remove four screws




2. Remove one screw, and then remove the cover.

Figure 5-495 Remove the cover



3. Disconnect one connector, and then remove the PTB.

Figure 5-496 Disconnect one connector



4. Remove the loop actuator

Use the following procedure to remove and replace the loop actuator.

1. Remove four screws.


Figure 5-497 Remove four screws



2. Remove the loop actuator.

NOTE: Note the spring position in order to install the actuator correctly.

Figure 5-498 Actuator spring



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right door exit assembly

Learn about removing and replacing the right door exit assembly.

View a video of removing and replacing the right door exit assembly.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-58 Part information

Part number	Part description
JC95-02249A	Right door exit assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right door exit assembly

Use the following procedure to remove and replace the right door exit assembly.

1. Open the right door.
2. Remove two screws and the white-plastic molded parts.

Figure 5-499 **Remove the guide**



3. Disconnect one connector, and then remove the right door exit assembly.

Figure 5-500 **Remove the unit**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser out sensor

Learn about removing and replacing the fuser out sensor.

View a video of removing and replacing the fuser out sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-59 Part information

Part number	Part description
0960-5271	Photo interrupter (fuser out sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the right door exit assembly

Use the following procedure to remove and replace the right door exit assembly.

1. Open the right door.

2. Remove two screws and the white-plastic molded parts.

Figure 5-501 **Remove the guide**



3. Disconnect one connector, and then remove the right door exit assembly.

Figure 5-502 **Remove the unit**




2. Remove the fuser out sensor

Use the following procedure to remove and replace the fuser out sensor.


1. Remove two screws and release the wire harness.

Figure 5-503 Remove two screws



2. Release one tab (callout 1), and then remove the fuser out sensor.

Figure 5-504 Remove the sensor



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser out sensor harness

Learn about removing and replacing the fuser out sensor harness.

View a video of removing and replacing the fuser out sensor harness.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-60 Part information

Part number	Part description
5QK03-50001	Fuser out sensor harness

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right door exit assembly

Use the following procedure to remove and replace the right door exit assembly.

1. Open the right door.
2. Remove two screws and the white-plastic molded parts.

Figure 5-505 **Remove the guide**



3. Disconnect one connector, and then remove the right door exit assembly.

Figure 5-506 **Remove the unit**




2. Remove the fuser out sensor harness

Use the following procedure to remove and replace the fuser out sensor harness.


1. Remove two screws and release the wire harness.

Figure 5-507 **Remove two screws**



2. Disconnect one connector, and then remove the fuser out sensor wire harness.

Figure 5-508 Remove the wire harness



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Paper dust holder assembly

Learn about removing and replacing the paper dust holder.

View a video of removing and replacing the paper dust holder.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-61 Part information

Part number	Part description
5QK09-40109	Paper dust holder assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

- Pull the tray almost all of the way out of the printer, and then lift it up to remove it.

Figure 5-509 **Remove the tray**




Remove the paper dust container

Use the following procedure to remove and replace the paper dust container.

1. Locate the paper dust container in the tray cavity.

Figure 5-510 **Locate the paper dust container**



2. Pull the paper dust container straight out of the printer to remove it.

Figure 5-511 Remove the assembly



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Exit unit

Learn about exit unit parts removal and replacement.

Removal and replacement: Exit unit

Learn about removing and replacing the exit unit.

View a video of removing and replacing the exit unit.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-62 Part information

Part number	Part description
JC90-01856A	Exit unit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.

2. Remove four screws.

Figure 5-512 Remove four screws



3. Pull the fuser straight out of the printer to remove it.

Figure 5-513 Remove the fuser



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-514 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-515 Remove the cover



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-516 Remove one screw cap



2. Remove one screw.

Figure 5-517 Remove one screw




3. Remove the cover.

Figure 5-518 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-519 Disconnect one connector



5. Remove four screws.

Figure 5-520 Remove four screws



6. Remove the keyboard.

Figure 5-521 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-522 **Remove two screws**



2. Open the right door.

Figure 5-523 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-524 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-525 Remove the cover assembly



5. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-526 **Remove five screws**



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-527 **Remove the cover**



6. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-528 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-529 **Remove the cover**



7. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-530 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-531 Release the hinge



3. Release the right door front link.

Figure 5-532 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-533 **Remove the door**



8. Remove the exit unit

Use the following procedure to remove and replace the exit unit.


1. Disconnect two connectors, and then remove four screws.

Figure 5-534 Disconnect connectors and remove screws



2. Push in on the white-plastic coupler (callout 1), and then pull the exit unit straight out to remove it (callout 2).

Figure 5-535 Remove the unit



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Output bin 1 sensor

Learn about removing and replacing the output bin 1 sensor.

View a video of removing and replacing the output bin 1 sensor.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-63 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (output bin 1 sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.
2. Remove four screws.

Figure 5-536 **Remove four screws**



3. Pull the fuser straight out of the printer to remove it.

Figure 5-537 Remove the fuser



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-538 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-539 Remove the cover



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-540 Remove one screw cap



2. Remove one screw.

Figure 5-541 Remove one screw




3. Remove the cover.

Figure 5-542 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-543 Disconnect one connector



5. Remove four screws.

Figure 5-544 Remove four screws



6. Remove the keyboard.

Figure 5-545 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-546 **Remove two screws**



2. Open the right door.

Figure 5-547 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ **CAUTION:** Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-548 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-549 Remove the cover assembly



5. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-550 **Remove five screws**



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-551 **Remove the cover**



6. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-552 Remove four screws




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-553 Remove the cover



7. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-554 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-555 Release the hinge



3. Release the right door front link.

Figure 5-556 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-557 **Remove the door**



8. Remove the exit unit

Use the following procedure to remove and replace the exit unit.


1. Disconnect two connectors, and then remove four screws.

Figure 5-558 **Disconnect connectors and remove screws**



2. Push in on the white-plastic coupler (callout 1), and then pull the exit unit straight out to remove it (callout 2).

Figure 5-559 Remove the unit




9. Remove the output bin 1 sensor

Use the following procedure to remove and replace the output bin 1 sensor.


1. Remove one screw.

Figure 5-560 **Remove one screw**



2. Disconnect one connector.

Figure 5-561 **Disconnect one connector**




3. Do the following:

NOTE: The black ESD insulator sheet does not need to be removed.

- Release the hooks (callout 1).
- Slide the sensor assembly to the left (callout 2).

- Remove the sensor.

Figure 5-562 **Remove the sensor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Return gate solenoid

Learn about removing and replacing the return gate solenoid.

View a video of removing and replacing the return gate solenoid.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-64 Part information

Part number	Part description
JC33-00031B	Solenoid, lifting (return gate solenoid)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.

2. Remove four screws.

Figure 5-563 Remove four screws



3. Pull the fuser straight out of the printer to remove it.

Figure 5-564 Remove the fuser



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-565 **Remove two screws**



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-566 **Remove the cover**



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-567 Remove one screw cap



2. Remove one screw.

Figure 5-568 Remove one screw




3. Remove the cover.

Figure 5-569 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-570 Disconnect one connector



5. Remove four screws.

Figure 5-571 Remove four screws



6. Remove the keyboard.

Figure 5-572 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-573 Remove two screws



2. Open the right door.

Figure 5-574 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-575 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-576 Remove the cover assembly



5. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-577 **Remove five screws**



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-578 **Remove the cover**



6. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-579 Remove four screws




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-580 Remove the cover



7. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-581 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-582 Release the hinge



3. Release the right door front link.

Figure 5-583 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-584 Remove the door



8. Remove the exit unit

Use the following procedure to remove and replace the exit unit.


1. Disconnect two connectors, and then remove four screws.

Figure 5-585 **Disconnect connectors and remove screws**



2. Push in on the white-plastic coupler (callout 1), and then pull the exit unit straight out to remove it (callout 2).

Figure 5-586 Remove the unit




9. Remove the return gate solenoid

Use the following procedure to remove and replace the return gate solenoid.

1. Disconnect one connector, and then release the wire harness from the retainer.


Figure 5-587 Disconnect one connector



2. Do the following:


- Remove the black gear (callout 1).
- Use a pair of tweezers to remove one e-ring (callout 2), and then remove the white gear (callout 3)/

Figure 5-588 Remove the gears




3. Remove two screws.

Figure 5-589 Remove two screws



4. Remove the return gate solenoid.

Figure 5-590 Remove the solenoid



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Exit 2 motor

Learn about removing and replacing the exit 2 motor.

View a video of removing and replacing the exit 2 motor.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-65 Part information

Part number	Part description
JC93-00336A	Drive-motor step (exit 2 motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.
2. Remove four screws.

Figure 5-591 **Remove four screws**



3. Pull the fuser straight out of the printer to remove it.

Figure 5-592 **Remove the fuser**



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-593 **Remove two screws**



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-594 Remove the cover



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-595 Remove one screw cap



2. Remove one screw.

Figure 5-596 Remove one screw




3. Remove the cover.

Figure 5-597 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-598 Disconnect one connector



5. Remove four screws.

Figure 5-599 Remove four screws



6. Remove the keyboard.

Figure 5-600 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-601 Remove two screws



2. Open the right door.

Figure 5-602 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-603 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-604 Remove the cover assembly



5. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-605 Remove five screws



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-606 Remove the cover



6. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-607 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-608 **Remove the cover**



7. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-609 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-610 Release the hinge



3. Release the right door front link.

Figure 5-611 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-612 **Remove the door**



8. Remove the exit unit

Use the following procedure to remove and replace the exit unit.


1. Disconnect two connectors, and then remove four screws.

Figure 5-613 **Disconnect connectors and remove screws**



2. Push in on the white-plastic coupler (callout 1), and then pull the exit unit straight out to remove it (callout 2).

Figure 5-614 Remove the unit




9. Remove the exit 2 motor

Use the following procedure to remove and replace the exit 2 motor.

- Disconnect one connector, remove two screws, and then remove the exit 2 motor.

⚠ CAUTION: Do not damage the wire harness when removing the motor.

Figure 5-615 Remove the motor



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Exit 2 sensor

Learn about removing and replacing the exit 2 sensor.

View a video of removing and replacing the exit 2 sensor.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-66 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (exit 2 sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.

2. Remove four screws.

Figure 5-616 Remove four screws



3. Pull the fuser straight out of the printer to remove it.

Figure 5-617 Remove the fuser



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-618 **Remove two screws**



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-619 **Remove the cover**



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-620 Remove one screw cap



2. Remove one screw.

Figure 5-621 Remove one screw




3. Remove the cover.

Figure 5-622 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-623 Disconnect one connector



5. Remove four screws.

Figure 5-624 Remove four screws



6. Remove the keyboard.

Figure 5-625 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-626 **Remove two screws**



2. Open the right door.

Figure 5-627 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ **CAUTION:** Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-628 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-629 Remove the cover assembly



5. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-630 **Remove five screws**



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-631 **Remove the cover**



6. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-632 Remove four screws




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-633 Remove the cover



7. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-634 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-635 Release the hinge



3. Release the right door front link.

Figure 5-636 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-637 Remove the door



8. Remove the exit unit

Use the following procedure to remove and replace the exit unit.


1. Disconnect two connectors, and then remove four screws.

Figure 5-638 **Disconnect connectors and remove screws**



2. Push in on the white-plastic coupler (callout 1), and then pull the exit unit straight out to remove it (callout 2).

Figure 5-639 Remove the unit




9. Remove the exit 2 sensor

Use the following procedure to remove and replace the exit 2 motor.

1. Disconnect one connector.

Figure 5-640 **Disconnect one connector**




2. Do the following:

NOTE: The black ESD insulator sheet does not need to be removed.

- Release the hooks (callout 1).
- Slide the sensor assembly to the left (callout 2).
- Remove the sensor.

Figure 5-641 **Remove the sensor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Duplex jam 1 sensor

Learn about removing and replacing the duplex jam 1 sensor.

View a video of removing and replacing the duplex jam 1 sensor.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-67 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (duplex jam 1 sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.
2. Remove four screws.

Figure 5-642 Remove four screws



3. Pull the fuser straight out of the printer to remove it.

Figure 5-643 Remove the fuser



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-644 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-645 Remove the cover



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-646 Remove one screw cap



2. Remove one screw.

Figure 5-647 Remove one screw




3. Remove the cover.

Figure 5-648 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-649 Disconnect one connector



5. Remove four screws.

Figure 5-650 Remove four screws



6. Remove the keyboard.

Figure 5-651 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-652 **Remove two screws**



2. Open the right door.

Figure 5-653 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ **CAUTION:** Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-654 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-655 Remove the cover assembly



5. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-656 **Remove five screws**



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-657 **Remove the cover**



6. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-658 Remove four screws




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-659 Remove the cover



7. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-660 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-661 Release the hinge



3. Release the right door front link.

Figure 5-662 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-663 **Remove the door**



8. Remove the exit unit

Use the following procedure to remove and replace the exit unit.


1. Disconnect two connectors, and then remove four screws.

Figure 5-664 **Disconnect connectors and remove screws**



2. Push in on the white-plastic coupler (callout 1), and then pull the exit unit straight out to remove it (callout 2).

Figure 5-665 Remove the unit




9. Remove the duplex jam 1 sensor

Use the following procedure to remove and replace the duplex jam 1 sensor.


1. Remove two screws.

Figure 5-666 **Remove two screws**




2. Disconnect one connector.

Figure 5-667 **Disconnect one connector**



3. Release three hooks, and then remove the duplex jam 1 sensor.

Figure 5-668 Remove the sensor



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Duplex 1 motor

Learn about removing and replacing the duplex 1 motor.

View a video of removing and replacing the duplex 1 motor.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-68 Part information

Part number	Part description
JC93-00336A	Drive-motor step (duplex 1 motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.

2. Remove four screws.

Figure 5-669 Remove four screws



3. Pull the fuser straight out of the printer to remove it.

Figure 5-670 Remove the fuser



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-671 **Remove two screws**



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-672 **Remove the cover**



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-673 Remove one screw cap



2. Remove one screw.

Figure 5-674 Remove one screw




3. Remove the cover.

Figure 5-675 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-676 Disconnect one connector



5. Remove four screws.

Figure 5-677 Remove four screws



6. Remove the keyboard.

Figure 5-678 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-679 Remove two screws



2. Open the right door.

Figure 5-680 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-681 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-682 Remove the cover assembly



5. Remove the right upper cover

Use the following procedure to remove and replace the right upper cover.

1. Remove five screws.

Figure 5-683 **Remove five screws**



2. Remove one screw (circled), and then carefully slide the cover as shown below to remove it.

Figure 5-684 **Remove the cover**



6. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-685 Remove four screws




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-686 Remove the cover



7. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-687 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-688 Release the hinge



3. Release the right door front link.

Figure 5-689 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-690 Remove the door



8. Remove the exit unit

Use the following procedure to remove and replace the exit unit.


1. Disconnect two connectors, and then remove four screws.

Figure 5-691 **Disconnect connectors and remove screws**



2. Push in on the white-plastic coupler (callout 1), and then pull the exit unit straight out to remove it (callout 2).

Figure 5-692 Remove the unit




9. Remove the duplex 1 motor

Use the following procedure to remove and replace the duplex 1 motor.

- Disconnect one connector, remove two screws, and then remove the duplex 1 motor.

Figure 5-693 **Remove the motor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Exit stack guide

Learn about removing and replacing the exit stack guide.

View a video of removing and replacing the exit stack guide.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-69 Part information

Part number	Part description
JC90-01865A	Exit stack guide

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the exit stack guide

Use the following procedure to remove and replace the exit stack guide.


- Slide the exit stack guide to the right to remove it.

Figure 5-694 **Remove the guide**



Reinstallation tip: Position the guide over the holder, and then push it down to install it.

Figure 5-695 **Reinstall the guide**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Duplex unit

Learn about duplex unit parts removal and replacement.

Removal and replacement: Duplex assembly

Learn about removing and replacing the duplex assembly.

View a video of removing and replacing the duplex assembly.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-70 Part information

Part number	Part description
JC95-02250A	Duplex assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.


1. Remove four screws.

   Figure 5-696 **Remove four screws**

2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.
   c. Open the right door, and then remove the right rear cover.

Figure 5-697 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-698 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-699 Release the hinge



3. Release the right door front link.

Figure 5-700 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-701 Remove the door




3. Remove the paper transfer belt (PTB)

Use the following procedure to remove and replace the PTB.


1. Remove four screws (two screws on each side).

Figure 5-702 Remove four screws




2. Remove one screw, and then remove the cover.

Figure 5-703 **Remove the cover**



3. Disconnect one connector, and then remove the PTB.

Figure 5-704 **Disconnect one connector**




4. Remove the duplex assembly

Use the following procedure to remove and replace the duplex assembly.

1. Remove one screw, and then disengage the guide rail.


Figure 5-705 Disengage the guide rail



2. Remove one e-ring, and then slide the shaft to the right to release it.

NOTE: To easily remove the e-ring, slightly slide the shaft away from the assembly to loosen the e-ring, and then use a pair of tweezers to remove it.

Figure 5-706 Remove the e-ring



3. Remove one screw (on the side of the assembly).

Figure 5-707 **Remove one screw**




4. Remove one screw (on the side of the assembly).

Figure 5-708 **Remove one screw**




5. Remove three screws (on the right door), and then remove the cover.

Figure 5-709 Remove three screws



6. Disconnect one connector, and then lift the duplex assembly up to remove it.

Figure 5-710 Remove the assembly



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Duplex jam 2 sensor

Learn about removing and replacing the duplex jam 2 sensor.

View a video of removing and replacing the duplex jam 2 sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-71 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (duplex jam 2 sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

   Figure 5-711 **Remove four screws**


2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-712 Remove the cover



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-713 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-714 Release the hinge



3. Release the right door front link.

Figure 5-715 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-716 Remove the door




3. Remove the paper transfer belt (PTB)

Use the following procedure to remove and replace the PTB.


1. Remove four screws (two screws on each side).

Figure 5-717 Remove four screws




2. Remove one screw, and then remove the cover.

Figure 5-718 **Remove the cover**



3. Disconnect one connector, and then remove the PTB.

Figure 5-719 **Disconnect one connector**




4. Remove the duplex assembly

Use the following procedure to remove and replace the duplex assembly.

1. Remove one screw, and then disengage the guide rail.


Figure 5-720 Disengage the guide rail



2. Remove one e-ring, and then slide the shaft to the right to release it.

NOTE: To easily remove the e-ring, slightly slide the shaft away from the assembly to loosen the e-ring, and then use a pair of tweezers to remove it.

Figure 5-721 Remove the e-ring



3. Remove one screw (on the side of the assembly).

Figure 5-722 Remove one screw




4. Remove one screw (on the side of the assembly).

Figure 5-723 Remove one screw




5. Remove three screws (on the right door), and then remove the cover.

Figure 5-724 Remove three screws



6. Disconnect one connector, and then lift the duplex assembly up to remove it.

Figure 5-725 Remove the assembly



5. Remove the duplex jam 2 sensor

Use the following procedure to remove and replace the duplex jam 2 sensor.


1. Remove two screws.

Figure 5-726 Remove two screws




2. Remove the actuator, and then disconnect one connector.

Figure 5-727 Disconnect one connector



3. Turn the duplex assembly over, and then do the following:
   - Release the hooks (callout 1).
   - Slide the sensor assembly to the right (callout 2).
   - Remove the sensor.

Figure 5-728 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Duplex 2 motor

Learn about removing and replacing the duplex 2 motor.

View a video of removing and replacing the duplex 2 motor.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-72 Part information

Part number	Part description
JC93-01085A	Drive-motor step (duplex 2 motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.

Figure 5-729 **Remove four screws**




2. Do the following:

   a. Remove two rear lower cover screws.

   b. Slightly separate the rear lower cover from the printer.

   c. Open the right door, and then remove the right rear cover.

Figure 5-730 **Remove the cover**



2. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-731 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-732 Release the hinge



3. Release the right door front link.

Figure 5-733 **Release the link**




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-734 **Remove the door**




3. Remove the duplex 2 motor

Use the following procedure to remove and replace the duplex 2 motor.

1. Remove one screw, and then remove the cover.

Figure 5-735 Remove the cover



2. Remove one screw.

Figure 5-736 Remove one screw




3. Remove two screws, and then remove the cover.

Figure 5-737 Remove the cover



4. Remove two screws, disconnect one connector, and then remove the duplex 2 motor.

Figure 5-738 Remove the motor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Toner flow

Learn about toner flow parts removal and replacement.

Toner cartridge

Learn about toner cartridge parts removal and replacement.

Removal and replacement: Toner dispense motor assembly

Learn about removing and replacing the toner dispense motor assembly.

View a video of removing and replacing the toner dispense motor assembly.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-73 Part information

Part number	Part description
JC93-01667A	Toner dispense motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-739 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-740 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-741 Remove the screw caps



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-742 **Remove the cover**




4. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-743 **Remove the cover**



5. Remove the left cover

Use the following procedure to remove and replace the left cover.

1. Open the front cover (door) and all installed trays.


2. Remove eight screws.

Figure 5-744 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-745 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-746 Remove the cover




6. Remove the left upper cover

Use the following procedure to remove and replace the left top cover.

- Remove four screws, and then remove the cover.

Figure 5-747 Remove the cover




7. Remove the formatter and formatter bracket

Use the following procedure to remove and replace the formatter and formatter bracket.

NOTE: Always read the instruction carefully to make sure you are performing the correct steps for the printer being serviced.


1. Disconnect all the connectors on the formatter.

Figure 5-748 **Disconnect all connectors**




2. Do one of the following:

- **8601 models**: Remove four screws (callouts 1-2-3-4).



- **8801 models**: Remove five screws (callouts 1-2-3-4-5).




3. **8601 models only**: Support the formatter and bracket, remove one screw, and then remove the formatter and formatter bracket together.

Figure 5-749 **Remove the formatter and bracket**



4. **8801 models only:** Support the formatter and bracket, remove two screws (callout 1), and then remove the formatter and formatter bracket together.

Figure 5-750 **Remove the formatter and bracket**




8. Remove the toner cartridge (disassemble method)

Use the following procedure to remove and replace the toner cartridge.

- On the toner dispense motor assembly, rotate the gear counterclockwise, to mechanically release the toner cartridge. Remove the toner cartridge from the front side of the printer.

Reinstallation tip: To prevent mechanical interference when installing the cartridge, first rotate the gear clockwise to return it to the home position, and then install the cartridge.

Figure 5-751 **Rotate the gear**




9. Remove the toner dispense motor assembly

Use the following procedure to remove and replace the toner dispense motor assembly.

- Remove three screws, and then remove the dispense motor assembly.

NOTE: Disconnect connectors and release wire-harness retainers as needed to remove the assembly.

Figure 5-752 Remove the assembly



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Toner dispense motor

Learn about removing and replacing the toner dispense motor assembly.

View a video of removing and replacing the toner dispense motor.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-74 Part information

Part number	Part description
SS216-80501	Toner dispense motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-753 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-754 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-755 Remove the screw caps



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-756 **Remove the cover**




4. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-757 **Remove the cover**



5. Remove the left cover

Use the following procedure to remove and replace the left cover.

1. Open the front cover (door) and all installed trays.


2. Remove eight screws.

Figure 5-758 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-759 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-760 Remove the cover




6. Remove the left upper cover

Use the following procedure to remove and replace the left top cover.

- Remove four screws, and then remove the cover.

Figure 5-761 Remove the cover




7. Remove the formatter and formatter bracket

Use the following procedure to remove and replace the formatter and formatter bracket.

NOTE: Always read the instruction carefully to make sure you are performing the correct steps for the printer being serviced.


1. Disconnect all the connectors on the formatter.

Figure 5-762 Disconnect all connectors




2. Do one of the following:

- **8601 models**: Remove four screws (callouts 1-2-3-4).



- **8801 models**: Remove five screws (callouts 1-2-3-4-5).




3. **8601 models only**: Support the formatter and bracket, remove one screw, and then remove the formatter and formatter bracket together.

Figure 5-763 **Remove the formatter and bracket**



4. **8801 models only:** Support the formatter and bracket, remove two screws (callout 1), and then remove the formatter and formatter bracket together.

Figure 5-764 **Remove the formatter and bracket**




8. Remove the toner dispense motor

Use the following procedure to remove and replace the toner dispense motor.

- Remove two screws, and then remove the dispense motor.

NOTE: Disconnect connectors and release wire-harness retainers as needed to remove the motor.

Figure 5-765 **Remove the motor**



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Toner dispense motor sensor

Learn about removing and replacing the toner dispense motor sensor.

View a video of removing and replacing the toner dispense motor sensor.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-75 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (toner dispense motor sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-766 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-767 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-768 Remove the screw caps



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-769 Remove the cover




4. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-770 Remove the cover



5. Remove the left cover

Use the following procedure to remove and replace the left cover.

1. Open the front cover (door) and all installed trays.


2. Remove eight screws.

Figure 5-771 **Remove eight screws**



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-772 **Cover hook locations**



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-773 Remove the cover




6. Remove the left upper cover

Use the following procedure to remove and replace the left top cover.

- Remove four screws, and then remove the cover.

Figure 5-774 Remove the cover




7. Remove the formatter and formatter bracket

Use the following procedure to remove and replace the formatter and formatter bracket.

NOTE: Always read the instruction carefully to make sure you are performing the correct steps for the printer being serviced.


1. Disconnect all the connectors on the formatter.

Figure 5-775 **Disconnect all connectors**




2. Do one of the following:

- **8601 models**: Remove four screws (callouts 1-2-3-4).



- **8801 models**: Remove five screws (callouts 1-2-3-4-5).




3. **8601 models only**: Support the formatter and bracket, remove one screw, and then remove the formatter and formatter bracket together.

Figure 5-776 **Remove the formatter and bracket**



4. **8801 models only**: Support the formatter and bracket, remove two screws (callout 1), and then remove the formatter and formatter bracket together.

Figure 5-777 **Remove the formatter and bracket**




8. Remove the toner cartridge (disassemble method)

Use the following procedure to remove and replace the toner cartridge.

- On the toner dispense motor assembly, rotate the gear counterclockwise, to mechanically release the toner cartridge. Remove the toner cartridge from the front side of the printer.

Reinstallation tip: To prevent mechanical interference when installing the cartridge, first rotate the gear clockwise to return it to the home position, and then install the cartridge.

Figure 5-778 **Rotate the gear**




9. Remove the toner dispense motor assembly

Use the following procedure to remove and replace the toner dispense motor assembly.

- Remove three screws, and then remove the dispense motor assembly.

NOTE: Disconnect connectors and release wire-harness retainers as needed to remove the assembly.

Figure 5-779 Remove the assembly



10. Remove the toner dispense motor sensor

Use the following procedure to remove and replace the toner dispense motor sensor.


1. On the back of the toner dispense motor assembly, remove three screws, and then remove the cover.

Figure 5-780 Remove three screws




2. Remove the gear.

Figure 5-781 Remove the gear



3. To release the sensor, do the following:
   - Release the hooks (callout 1).
   - Slide the hook as shown (callout 2) to remove the sensor.

Figure 5-782 Remove the sensor



11. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Toner cartridge (control panel method)

Learn about removing and replacing the toner cartridge.

View a video of removing and replacing the toner cartridges using the control panel.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

No before performing service procedures required.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-76 Part information

Part number	Part description
W1760-67002	Toner cartridge - Standard yield

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button  (located at the bottom right corner of the control panel).

2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Toner cartridge (disassemble method)

Learn about removing and replacing the toner cartridge.

View a video of removing and replacing the toner cartridge by disassembling.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-77 Part information

Part number	Part description
W1760-67002	Toner cartridge - Standard yield

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-783 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-784 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-785 Remove the screw caps



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-786 Remove the cover




4. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-787 Remove the cover



5. Remove the left cover

Use the following procedure to remove and replace the left cover.

1. Open the front cover (door) and all installed trays.


2. Remove eight screws.

Figure 5-788 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-789 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-790 Remove the cover




6. Remove the left upper cover

Use the following procedure to remove and replace the left top cover.

- Remove four screws, and then remove the cover.

Figure 5-791 Remove the cover




7. Remove the formatter and formatter bracket

Use the following procedure to remove and replace the formatter and formatter bracket.

NOTE: Always read the instruction carefully to make sure you are performing the correct steps for the printer being serviced.


1. Disconnect all the connectors on the formatter.

Figure 5-792 Disconnect all connectors




2. Do one of the following:

- **8601 models**: Remove four screws (callouts 1-2-3-4).



- **8801 models**: Remove five screws (callouts 1-2-3-4-5).




3. **8601 models only**: Support the formatter and bracket, remove one screw, and then remove the formatter and formatter bracket together.

Figure 5-793 **Remove the formatter and bracket**



4. **8801 models only:** Support the formatter and bracket, remove two screws (callout 1), and then remove the formatter and formatter bracket together.

Figure 5-794 **Remove the formatter and bracket**




8. Remove the toner cartridge (disassemble method)

Use the following procedure to remove and replace the toner cartridge.

- On the toner dispense motor assembly, rotate the gear counterclockwise, to mechanically release the toner cartridge. Remove the toner cartridge from the front side of the printer.

Reinstallation tip: To prevent mechanical interference when installing the cartridge, first rotate the gear clockwise to return it to the home position, and then install the cartridge.

Figure 5-795 **Rotate the gear**



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Toner CRUM module assembly

Learn about removing and replacing the toner CRUM module assembly.

View a video of removing and replacing the toner CRUM modular jack harness.

View a video of removing and replacing the toner CRUM modular holder.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-78 Part information

Part number	Part description
JC61-02910A	Toner CRUM modular holder
JC39-02214A	Toner CRUM modular jack harness

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-796 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-797 **Remove the cover**




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-798 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-799 Remove the cover




4. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-800 Remove the cover



5. Remove the left cover

Use the following procedure to remove and replace the left cover.

1. Open the front cover (door) and all installed trays.


2. Remove eight screws.

Figure 5-801 **Remove eight screws**



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-802 **Cover hook locations**



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-803 Remove the cover




6. Remove the left upper cover

Use the following procedure to remove and replace the left top cover.

- Remove four screws, and then remove the cover.

Figure 5-804 Remove the cover




7. Remove the formatter and formatter bracket

Use the following procedure to remove and replace the formatter and formatter bracket.


1. Disconnect all of the connectors on the formatter.

Figure 5-805 **Disconnect all connectors**



2. Remove four screws (callouts 1-2-3-4).

Figure 5-806 **Remove four screws**



3. Support the formatter and bracket, remove one screw, and then remove the formatter and formatter bracket together.

Figure 5-807 **Remove the formatter and bracket**




8. Remove the toner CRUM module assembly

Use the following procedure to remove and replace the toner CRUM module assembly.


1. Disconnect one connector, remove one screw, and remove the module.

Figure 5-808 **Remove the module**



2. Remove the toner CRUM modular holder from the toner CRUM modular jack harness.

Figure 5-809 **Remove the holder from the harness**



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Guide toner cartridge and toner residual amount sensor

Learn about removing and replacing the guide toner cartridge assembly.

NOTE: The toner amount residual sensor is a sub-assembly on the guide toner cartridge assembly.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-79 Part information

Part number	Part description
63C82-60006	Guide toner cartridge assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button (located at the bottom right corner of the control panel).

2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-810 **Remove two screws**



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-811 Remove the cover



3. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.


1. Remove two screws.

Figure 5-812 Remove two screws



2. Open the right door.

Figure 5-813 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-814 **Slide the cover**



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-815 Remove the cover assembly




4. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-816 Remove the cover




5. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-817 Remove the TCU




6. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-818 Remove two screws



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-819 Remove the cover




7. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-820 Remove screws and disconnect connector



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-821 **Avoid damaging the drum engage lever**




8. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-822 **Remove the cover**



9. Remove the left cover

Use the following procedure to remove and replace the left cover.


1. Open the front cover (door) and all installed trays.
2. Remove eight screws.

Figure 5-823 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-824 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-825 **Remove the cover**



10. Remove the LSU

Use the following procedure to remove and replace the LSU.

1. Remove two screws

Figure 5-826 **Remove two screws**




2. Disconnect one FFC.

NOTE: The FFC has a locking clip. Release the clip as shown to disconnect the FFC.

Figure 5-827 Locking clip closed



Figure 5-828 Locking clip open



Reinstallation tip: Do not overtighten the screws on the LSU. Overtightening the screws can cause image-distortion issues.

11. Remove the guide toner cartridge assembly

Use the following procedure to remove and replace the guide toner cartridge assembly.


1. Remove one screw.

Figure 5-829 Remove one screw



2. Disconnect the upper connector, and then remove the assembly.

Figure 5-830 Disconnect the upper connector



12. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Reservoir unit

Learn about reservoir unit parts removal and replacement.

Removal and replacement: Reservoir unit

Learn about removing and replacing the reservoir unit.

View a video of removing and replacing the reservoir unit.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-80 Part information

Part number	Part description
X3A79-60003	Reservoir unit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.


- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button (located at the bottom right corner of the control panel).

2. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-831 Remove the TCU




3. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.


1. Open the right door.
2. At the front of the printer, remove one screw.

Figure 5-832 Remove one screw



3. Pull the drum unit out of the printer.

Figure 5-833 Remove the unit



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-834 Remove two screws



2. Open the right door.

Figure 5-835 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-836 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-837 Remove the cover assembly




5. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-838 **Remove the cover**




6. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-839 **Remove two screws**



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-840 Remove the cover




7. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-841 Remove screws and disconnect connector



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-842 **Avoid damaging the drum engage lever**




8. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-843 **Remove the cover**



9. Remove the left cover

Use the following procedure to remove and replace the left cover.


1. Open the front cover (door) and all installed trays.
2. Remove eight screws.

Figure 5-844 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-845 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-846 Remove the cover



10. Remove the LSU

Use the following procedure to remove and replace the LSU.

1. Remove two screws

Figure 5-847 Remove two screws




2. Disconnect one FFC.

NOTE: The FFC has a locking clip. Release the clip as shown to disconnect the FFC.

Figure 5-848 Locking clip closed



Figure 5-849 Locking clip open



Reinstallation tip: Do not overtighten the screws on the LSU. Overtightening the screws can cause image-distortion issues.

11. Remove the guide toner cartridge assembly

Use the following procedure to remove and replace the guide toner cartridge assembly.


1. Remove one screw.

Figure 5-850 **Remove one screw**



2. Disconnect the upper connector, and then remove the assembly.

Figure 5-851 **Disconnect the upper connector**




12. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-852 Release the lever and disconnect the connector



2. Remove four screws.

Figure 5-853 Remove four screws



3. Pull the developer unit out of the printer.


NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-854 Do not grab lever



Figure 5-855 Remove the unit




13. Remove the reservoir unit

Use the following procedure to remove and replace the reservoir unit.

- Disconnect one connector, remove one screw, and then pull the unit toward the front of the printer.

Figure 5-856 Disconnect connector and remove screw



⚠ CAUTION: In order to avoid spilling toner particles inside the printer, use care in removing this unit.

14. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

⚠ CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Reservoir drive assembly

Learn about removing and replacing the reservoir drive assembly.

View a video of removing and replacing the reservoir drive assembly.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-81 Part information

Part number	Part description
X3A79-60003	Reservoir drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:

  a. Select the Supplies menu.

  b. Open the front door.


  c. Select the Eject button (located at the bottom right corner of the control panel).

2. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-857 **Remove the TCU**




3. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.

1. Open the right door.


2. At the front of the printer, remove one screw.

Figure 5-858 Remove one screw



3. Pull the drum unit out of the printer.

Figure 5-859 Remove the unit



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-860 Remove two screws



2. Open the right door.

Figure 5-861 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-862 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-863 Remove the cover assembly




5. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-864 Remove the cover




6. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-865 Remove two screws



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-866 Remove the cover




7. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-867 Remove screws and disconnect connector



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-868 **Avoid damaging the drum engage lever**




8. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-869 **Remove the cover**



9. Remove the left cover

Use the following procedure to remove and replace the left cover.


1. Open the front cover (door) and all installed trays.
2. Remove eight screws.

Figure 5-870 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-871 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-872 Remove the cover



10. Remove the LSU

Use the following procedure to remove and replace the LSU.

1. Remove two screws

Figure 5-873 Remove two screws




2. Disconnect one FFC.

NOTE: The FFC has a locking clip. Release the clip as shown to disconnect the FFC.

Figure 5-874 Locking clip closed



Figure 5-875 Locking clip open



Reinstallation tip: Do not overtighten the screws on the LSU. Overtightening the screws can cause image-distortion issues.

11. Remove the guide toner cartridge assembly

Use the following procedure to remove and replace the guide toner cartridge assembly.


1. Remove one screw.

Figure 5-876 Remove one screw



2. Disconnect the upper connector, and then remove the assembly.

Figure 5-877 Disconnect the upper connector




12. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-878 Release the lever and disconnect the connector



2. Remove four screws.

Figure 5-879 Remove four screws



3. Pull the developer unit out of the printer.


NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-880 Do not grab lever



Figure 5-881 Remove the unit




13. Remove the reservoir unit

Use the following procedure to remove and replace the reservoir unit.

- Disconnect one connector, remove one screw, and then pull the unit toward the front of the printer.

Figure 5-882 Disconnect connector and remove screw




⚠ CAUTION: In order to avoid spilling toner particles inside the printer, use care in removing this unit.

14. Remove the reservoir drive assembly

Use the following procedure to remove and replace the reservoir drive assembly.

- Remove two screws, and then remove the drive assembly from the unit.

Figure 5-883 Remove two screws



15. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Toner collection unit

Learn about toner collection unit parts removal and replacement.

Removal and replacement: Toner collection unit (TCU)

Learn about removing and replacing the toner collection unit.

View a video of removing and replacing the toner collection unit.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-82 Part information

Part number	Part description
9U1Q5-67001	Toner collection unit

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-884 Remove the TCU



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Toner collection unit (TCU) detection sensor

Learn about removing and replacing the toner collection unit detection sensor.

View a video of removing and replacing the toner collection unit detection sensor.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-83 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (toner collection unit detection sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button  (located at the bottom right corner of the control panel).

2. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-885 Remove two screws



2. Open the right door.

Figure 5-886 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-887 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-888 Remove the cover assembly




3. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-889 Remove the cover




4. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-890 Remove the TCU




5. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-891 **Remove two screws**



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-892 **Remove the cover**




6. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-893 Remove screws and disconnect connector



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-894 Avoid damaging the drum engage lever




7. Remove the TCU detection sensor

Use the following procedure to remove and replace the TCU detection sensor.

1. Locate the sensor. and then disconnect the connector.

Figure 5-895 **Disconnect the connector**




2. Open the right door, and then remove the sensor.

   a. Release the hooks (callout 1).

   b. Slide the sensor to the right (callout 2), and then remove the sensor.

Figure 5-896 **Remove the sensor**



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Toner collection unit (TCU) full sensor

Learn about removing and replacing the toner collection unit full sensor assembly.

View a video of removing and replacing the toner collection unit full sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

This procedure requires removing the toner cartridges using the control panel method. Do this prior to turning the power off. For more information, see *Remove the toner cartridges (control panel method)* in this topic.

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-84 Part information

Part number	Part description
JC93-00492A	Toner collection unit full sensor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button  (located at the bottom right corner of the control panel).

2. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-897 Remove two screws



2. Open the right door.

Figure 5-898 Open the right door



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-899 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-900 Remove the cover assembly




3. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-901 Remove the cover




4. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-902 Remove the TCU




5. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-903 Remove two screws



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-904 Remove the cover




6. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-905 Remove screws and disconnect connector



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-906 Avoid damaging the drum engage lever




7. Remove the TCU full sensor assembly

Use the following procedure to remove and replace the TCU full sensor assembly.

1. Remove one screw, and then disconnect the connector.


Figure 5-907 Disconnect the connector



2. On the back of the sensor assembly, release the hook to remove the assembly from the printer.

\

Figure 5-908 Release the hook



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Image creation

Learn about image creation parts removal and replacement.

Laser scanner unit (LSU)

Learn about laser scanner unit parts removal and replacement.

Removal and replacement: Laser scanner unit (LSU)

Learn about removing and replacing the LSU.

View a video of removing and replacing the LSU.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-85 Part information

Part number	Part description
JC97-05147A	Laser scanner unit (LSU)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-909 Remove the cover



2. Remove the left cover

Use the following procedure to remove and replace the left cover.


1. Open the front cover (door) and all installed trays.
2. Remove eight screws.

Figure 5-910 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-911 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-912 Remove the cover



3. Remove the LSU

Use the following procedure to remove and replace the LSU.

1. Remove two screws

Figure 5-913 Remove two screws




2. Disconnect one FFC.

NOTE: The FFC has a locking clip. Release the clip as shown to disconnect the FFC.

Figure 5-914 Locking clip closed



Figure 5-915 Locking clip open



Reinstallation tip: Do not overtighten the screws on the LSU. Overtightening the screws can cause image-distortion issues.

4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Developer and drum

Learn about developer and drum parts removal and replacement.

Removal and replacement: Drum unit

Learn about removing and replacing the drum unit.

View a video of removing and replacing the drum unit.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-86 Part information

Part number	Part description
W1766-67001	HP 176A Black Original Imaging Drum

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-916 **Remove the TCU**




2. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.


1. Open the right door.
2. At the front of the printer, remove one screw.

Figure 5-917 **Remove one screw**



3. Pull the drum unit out of the printer.

Figure 5-918 **Remove the unit**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Black developer unit

Learn about removing and replacing the black developer unit.

View a video of removing and replacing the black developer unit.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-87 Part information

Part number	Part description
5PN82-67002	Black developer unit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

  Figure 5-919 Remove the TCU


  

2. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.


1. Open the right door.
2. At the front of the printer, remove one screw.

   Figure 5-920 Remove one screw

3. Pull the drum unit out of the printer.

Figure 5-921 **Remove the unit**




3. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-922 **Release the lever and disconnect the connector**



2. Remove four screws.

Figure 5-923 Remove four screws



3. Pull the developer unit out of the printer.

NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-924 Do not grab lever





Figure 5-925 Remove the unit



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Developer powder

Learn about filling or refilling the developer powder.

NOTE: Use this procedure to fill or refill an empty developer unit with developer powder.

View a video of removing and refilling the black developer unit .

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-88 Part information

Part number	Part description
5PN82-67001	Black developer powder kit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-926 Remove the TCU




2. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.


1. Open the right door.
2. At the front of the printer, remove one screw.

Figure 5-927 Remove one screw



3. Pull the drum unit out of the printer.

Figure 5-928 **Remove the unit**




3. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-929 **Release the lever and disconnect the connector**



2. Remove four screws.

Figure 5-930 Remove four screws



3. Pull the developer unit out of the printer.

NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-931 Do not grab lever





Figure 5-932 Remove the unit




4. Fill or refill the developer unit with developer powder

Use the following procedure to fill or refill the developer powder in a developer unit.

TIP: If toner gets on the skin or clothing, wipe it off with dry tissue paper and wash in cold water. Hot water sets toner and it might be difficult, or impossible, to remove.

1. Shake the developer powder bottle.

Figure 5-933 Shake the bottle



2. Do one of the following:

- **To *fill* a replacement developer unit**: Skip this step.

- **To *refill* an in-service developer unit**: Remove one cap from the developer unit.

NOTE: Removing the cap might require considerable force.

Figure 5-934 **Install the cap**



3. Attach the bottle to the developer unit.

NOTE: Make sure that the bottle firmly hooks onto the developer unit.

Figure 5-935 **Attach the bottle**



4. Slide the shutter on the developer unit to the open position.


Figure 5-936 Open the shutter



5. Slightly raise the right end of the developer unit (callout 1), and then carefully squeeze the bottle (callout 2) to start toner flowing into the developer unit. Continue this process until there is no toner remaining in the bottle.


TIP: To check the level of powder in the bottle, hold it up to a light source.

Figure 5-937 Open the shutter



6. When the bottle is empty, close the shutter (callout 1) and remove the bottle (callout 2).

Figure 5-938 **Close the shutter**



7. Install the cap (supplied in the kit) in the hole on the developer unit.


NOTE: Installing the cap might require considerable force.

Figure 5-939 **Install the cap**



8. Shake the developer unit back and forth to evenly distribute the toner powder.

Figure 5-940 **Distribute the toner powder**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Developer, drum, and PTB drive assembly

Learn about removing and replacing the developer, drum, and PTB drive assembly.

View a video of removing and replacing the developer, drum, and PTB drive assembly.

Mean time to repair: 20 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-89 Part information

Part number	Part description
JC93-01662A	Developer, drum and PTB drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-941 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-942 Remove the cover




3. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-943 Remove the TCU




4. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.


1. Open the right door.
2. At the front of the printer, remove one screw.

Figure 5-944 Remove one screw



3. Pull the drum unit out of the printer.

Figure 5-945 Remove the unit




5. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-946 Release the lever and disconnect the connector



2. Remove four screws.

Figure 5-947 Remove four screws



3. Pull the developer unit out of the printer.

NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-948 Do not grab lever





Figure 5-949 Remove the unit




6. Remove the developer, drum, and PTB drive assembly

Use the following procedure to remove and replace the developer, drum, and PTB drive assembly.

1. Disconnect three connectors.


Figure 5-950 Disconnect three connectors



2. Remove three screws, and then remove the developer, drum, and PTB drive assembly.

NOTE: Remove the three silver screws (not the gold screws) shown below.

Figure 5-951 Remove three screws



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Drum and PTB motor

Learn about removing and replacing the drum motor.

View a video of removing and replacing the drum and PTB motor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-90 Part information

Part number	Part description
JC31-00123G	Motor 24V (Drum and PTB motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-952 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-953 Remove the cover




3. Remove the drum and PTB motor

Use the following procedure to remove and replace the drum and PTB motor.

- Remove three screws (callout 1), disconnect one connector (callout 2), and then remove the motor.

Figure 5-954 Remove the motor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Developer motor

Learn about removing and replacing the developer motor.

View a video of removing and replacing the developer motor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-91 Part information

Part number	Part description
JC31-00197A	Developer motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-955 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-956 Remove the cover




3. Remove the developer motor

Use the following procedure to remove and replace the developer motor.

- Remove four screws (callout 1), disconnect one connector (callout 2), and then remove the motor.

Figure 5-957 **Remove the motor**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Cable guide

Learn about removing and replacing the cable guide.

View a video of removing and replacing the cable guide.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-92 Part information

Part number	Part description
JC61-06282A	Cable guide

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-958 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-959 Remove the cover




3. Remove the cable guide

Use the following procedure to remove and replace the cable guide.

- Release the cables, remove one screw, and then remove the cable guide.

Figure 5-960 Remove one screw



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: CTD sensor assembly

Learn about removing and replacing the CTD sensor assembly.

View a video of removing and replacing the CTD sensor assembly.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-93 Part information

Part number	Part description
6ER04-60002	CTD sensor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-961 Remove the cover



2. Remove the right rear cover

Use the following procedure to remove and replace the right rear cover.

1. Remove four screws.


Figure 5-962 Remove four screws



2. Do the following:
   a. Remove two rear lower cover screws.
   b. Slightly separate the rear lower cover from the printer.

c. Open the right door, and then remove the right rear cover.

Figure 5-963 Remove the cover



3. Remove the right door assembly

Use the following procedure to remove and replace the right door.

1. Open the right door, and then disconnect one connector.


Figure 5-964 Disconnect one connector



2. Release the hinge.


⚠ CAUTION: The right door hinge is under tension and can be dangerous. To avoid personal injury, be very careful when releasing the hinge.

Figure 5-965 Release the hinge



3. Release the right door front link.

Figure 5-966 Release the link




4. Remove the right door assembly.

NOTE: If a 2x520 DCF or HCI accessory is installed, do the following:

1. Open the lower access door.
2. Open the right door to almost 90 degrees, and then rotate it clockwise to remove it.

CAUTION: To avoid damage to the door, **do not** lower it past 90 degrees when attempting to remove it.

Figure 5-967 Remove the door




4. Remove the CTD sensor assembly

Use the following procedure to remove and replace the CTD sensor assembly.


1. Release the cable clamp. and then disconnect one connector.

Figure 5-968 Disconnect one connector



2. Remove three screws.

Figure 5-969 Remove three screws



3. Before proceeding, take note of the spring installed underneath the cleaner assembly.


⚠ CAUTION: Do not lose the spring when handling the assembly.

Figure 5-970 Cleaner assembly spring



4. Grasp the cleaner and sensor assembly and carefully remove it.

Figure 5-971 Remove the assembly



5. Disconnect two connectors, and then remove the sensor assembly.

NOTE: A service part order might include a base frame due to shipment security. Install all of the replacement parts that are included with the parts order.

Figure 5-972 Remove the sensor assembly



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Fuser unit

Learn about fuser unit parts removal and replacement.

Removal and replacement: Fuser unit

Learn about removing and replacing the fuser unit.

View a video of removing and replacing the fuser unit.

Mean time to repair: 4 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-94 Part information

Part number	Part description
5PN53-67001	Fuser unit 100V
5PN76-67001	Fuser unit 110V
5PN77-67001	Fuser unit 220V

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.

2. Remove four screws.

Figure 5-973 Remove four screws



3. Pull the fuser straight out of the printer to remove it.

Figure 5-974 Remove the fuser



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser and exit drive assembly

Learn about removing and replacing the fuser and exit drive assembly.

View a video of removing and replacing the fuser and exit drive assembly.

NOTE: This video shows the E877 printer. The procedure is similar for the E826 printer.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-95 Part information

Part number	Part description
JC93-01850A	Fuser and exit drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-975 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-976 **Remove the cover**




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-977 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-978 **Remove the cover**




4. Remove the fuser ventilation duct

Use the following procedure to remove and replace the fuser ventilation duct.

- Release the wire harnesses from the retainers (callout 1), remove three screws (callout 2), and then remove the fuser ventilation duct..

Figure 5-979 **Remove the duct**




5. Remove the fuser and exit drive assembly

Use the following procedure to remove and replace the fuser and exit drive assembly.


1. Disconnect two connectors.

Figure 5-980 **Disconnect two connectors**



2. Remove four screws, and then remove the fuser and exit drive unit.

Figure 5-981 **Remove the unit**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser and exit motor

Learn about removing and replacing the fuser and exit motor.

View a video of removing and replacing the fuser and exit motor.

NOTE: This video shows the E877 printer. The procedure is similar for the E826 printer.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-96 Part information

Part number	Part description
JC31-00144G	Motor BLDC (fuser and exit motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-982 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-983 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-984 Remove the screw caps



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-985 Remove the cover




4. Remove the fuser ventilation duct

Use the following procedure to remove and replace the fuser ventilation duct.

- Release the wire harnesses from the retainers (callout 1), remove three screws (callout 2), and then remove the fuser ventilation duct..

Figure 5-986 Remove the duct




5. Remove the fuser and exit motor

Use the following procedure to remove and replace the fuser and exit motor.

- Disconnect one connector (callout 1), remove four screws (callout 2), and then remove the fuser and exit motor.

Figure 5-987 Remove the motor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser gap motor

Learn about removing and replacing the fuser gap motor.

View a video of removing and replacing the fuser gap motor.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-97 Part information

Part number	Part description
JC93-01084A	Drive-motor step (fuser gap motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-988 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-989 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-990 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-991 **Remove the cover**




4. Remove the fuser gap motor

Use the following procedure to remove and replace the fuser gap motor.

- Remove two screws, disconnect one connector, and then remove the fuser gap motor.

Figure 5-992 Remove the motor



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser gap sensor

Learn about removing and replacing the fuser gap sensor.

View a video of removing and replacing the fuser gap sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-98 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (fuser gap sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the fuser assembly

Use the following procedure to remove and replace the fuser assembly.

1. Open the right door.

2. Remove four screws.

Figure 5-993 Remove four screws



3. Pull the fuser straight out of the printer to remove it.

Figure 5-994 Remove the fuser



2. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-995 **Remove two screws**



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-996 **Remove the cover**



3. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-997 Remove one screw cap



2. Remove one screw.

Figure 5-998 Remove one screw




3. Remove the cover.

Figure 5-999 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-1000 Disconnect one connector



5. Remove four screws.

Figure 5-1001 Remove four screws



6. Remove the keyboard.

Figure 5-1002 Remove the keyboard



4. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-1003 **Remove two screws**



2. Open the right door.

Figure 5-1004 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ **CAUTION:** Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-1005 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-1006 Remove the cover assembly




5. Remove the fuser gap sensor

Use the following procedure to remove and replace the fuser gap sensor.


1. Disconnect one connector, remove two screws, and then slide the PCA to the left to remove it.

Figure 5-1007 **Remove the PCA**




2. Disconnect one connector.

Figure 5-1008 **Disconnect one connector**



3. Release the tabs (callout 1), and then remove the fuser gap sensor (callout 2).

Figure 5-1009 **Remove the sensor**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Environmental sensor, switch, and fan

Learn about environmental sensor, switch, and fan parts removal and replacement.

Base sensor, switch, and fan

Review the base sensor, switch, and fan removal procedures.

Removal and replacement: Outer temperature humidity sensor assembly

Learn about removing and replacing the outer temperature humidity sensor assembly, sensor, and holder.

View a video of removing and replacing the outer temperature humidity sensor assembly.

NOTE: These videos show the E877 printer. The procedures are similar for the E826 printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

NOTE: This procedure requires removing the toner cartridges using the control panel method. Do this prior to turning the power off. For more information, see *Remove the toner cartridges (control panel method)* in this topic.

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-99 Part information

Part number	Part description
5QJ90-40002	Outer temperature humidity sensor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button (located at the bottom right corner of the control panel).

2. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.


1. Remove two screws.

Figure 5-1010 Remove two screws



2. Open the right door.

Figure 5-1011 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-1012 **Slide the cover**



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-1013 Remove the cover assembly




3. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-1014 Remove the cover




4. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-1015 Remove the TCU




5. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-1016 Remove two screws



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-1017 Remove the cover




6. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-1018 Remove screws and disconnect connector



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-1019 **Avoid damaging the drum engage lever**




7. Remove the outer temperature humidity sensor assembly

Use the following procedure to remove and replace the outer temperature humidity sensor assembly.


1. Disconnect one connector.

Figure 5-1020 **Disconnect one connector**



2. Release two hooks (callout 1), and then remove the outer temperature humidity sensor assembly (callout 2).

Figure 5-1021 Remove the sensor assembly



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: LVPS fan

Learn about removing and replacing the low-voltage power supply (LVPS) fan.

View a video of removing and replacing the LVPS fan (E877).

NOTE: This video shows the E877 printer. The procedure is similar for MFP 8801.

View a video of removing and replacing the LVPS fan (E826).

NOTE: This video shows the E826 printer. The procedure is similar for the 8601 and 8501 models.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-100 Part information

Part number	Part description
JC31-00198A	Fan (LVPS fan)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1022 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1023 **Remove the cover**




3. Remove the LVPS fan

Use the following procedure to remove and replace the LVPS fan.


1. Disconnect one connector (callout 1), and then release the wire harness from the retainers (callout 2).

Figure 5-1024 **Disconnect one connector**



2. Release two tabs, and then remove the fan.

Figure 5-1025 **Remove the fan**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: FDB fan

Learn about removing and replacing the fuser drive board fan.

View a video of removing and replacing the FDB fan (E877).

NOTE: This video shows the E877 printer. The procedure is similar for MFP 8801.

View a video of removing and replacing the FDB fan (E826).

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-101 Part information

Part number	Part description
JC31-00154A	Fan (FDB fan)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1026 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1027 **Remove the cover**




3. Remove the FDB fan

Use the following procedure to remove and replace the FDB fan.


1. Disconnect one connector (callout 1), and then release the wire harness from the retainers (callout 2).

Figure 5-1028 **Disconnect one connector**



2. Release two tabs, and then remove the fan.

Figure 5-1029 **Remove the fan**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: LVPS FDB fan assembly

Learn about removing and replacing the low-voltage power supply (LVPS) fuser drive board (FDB) fan assembly.

View a video of removing and replacing the LVPS FDB fan assembly (E877).

NOTE: This video shows the E877 printer. The procedure is similar for MFP 8801.

View a video of removing and replacing the LVPS FDB fan assembly (E826).

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-102 Part information

Part number	Part description
JC93-01795A	LVPS FDB fan assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1030 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1031 **Remove the cover**




3. Remove the LVPS FDB fan assembly

Use the following procedure to remove and replace the LVPS FDB fan assembly.


1. Disconnect one connector.

Figure 5-1032 **Disconnect one connector**




2. Remove four screws.

Figure 5-1033 **Remove four screws**



3. Release one tab, and then remove the LVP FDB fan assembly.

Figure 5-1034 **Remove the LVP FDB fan assembly**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Developer fan assembly

Learn about removing and replacing the developer fan assembly.

View a video of removing and replacing the developer fan assembly.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-103 Part information

Part number	Part description
5QK09-40083	Developer fan assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1035 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1036 Remove the cover




3. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

  Figure 5-1037 Remove the TCU


  

4. Remove the black drum unit

Use the following procedure to remove and replace the black drum unit.


1. Open the right door.
2. At the front of the printer, remove one screw.

   Figure 5-1038 Remove one screw

3. Pull the drum unit out of the printer.

Figure 5-1039 **Remove the unit**




5. Remove the black developer unit

Use the following procedure to remove and replace the black developer unit.


1. Release the lever and disconnect the connector.

Figure 5-1040 **Release the lever and disconnect the connector**



2. Remove four screws.

Figure 5-1041 Remove four screws



3. Pull the developer unit out of the printer.

NOTE: If the developer unit is empty, use the steps included in this topic (located after the unpack and recycle step) to fill or refill the developer powder.

During removal and installation, do not grab the unit by the lever. Doing so can result in a toner spill.

Figure 5-1042 Do not grab lever





Figure 5-1043 Remove the unit




6. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-1044 Remove the cover



7. Remove the left cover

Use the following procedure to remove and replace the left cover.

1. Open the front cover (door) and all installed trays.


2. Remove eight screws.

Figure 5-1045 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-1046 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-1047 Remove the cover




8. Remove the developer suction duct

Use the following procedure to remove and replace the developer suction duct.

- Remove one screw, and then pull the duct from the printer.

Figure 5-1048 Remove one screw




9. Remove the developer fan assembly

Use the following procedure to remove and replace the developer fan assembly.

1. Remove one screw.

Figure 5-1049 Remove one screw



2. Disconnect one connector.

Figure 5-1050 Disconnect one connector



3. Inside the right door area, use tweezers to release the tab.

Figure 5-1051 Release the tab



NOTE: See the difference between the hooked tab and the released tab in the pictures below.

Figure 5-1052 Hooked tab



Figure 5-1053 Released tab



4. Inside the left cover, slide the developer fan assembly to the front of the printer, and then remove the assembly.

Figure 5-1054 Remove developer fan assembly



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Developer suction duct

Learn about removing and replacing the developer suction duct.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-104 Part information

Part number	Part description
JC93-01007A	Developer suction duct

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1055 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1056 Remove the cover




3. Remove the developer suction duct

Use the following procedure to remove and replace the developer suction duct.

- Remove one screw, and then pull the duct from the printer.

Figure 5-1057 Remove one screw



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser ventilation duct

Learn about removing and replacing the fuser ventilation duct.

View a video of removing and replacing the fuser ventilation duct.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-105 Part information

Part number	Part description
JC93-01446A	Fuser ventilation duct

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1058 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1059 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1060 Remove the screw caps



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1061 **Remove the cover**




4. Remove the fuser ventilation duct

Use the following procedure to remove and replace the fuser ventilation duct.

- Release the wire harnesses from the retainers (callout 1), remove three screws (callout 2), and then remove the fuser ventilation duct..

Figure 5-1062 **Remove the duct**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: LSU fan

Learn about removing and replacing the laser scanner unit (LSU) fan.

View a video of removing and replacing the LSU fan.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-106 Part information

Part number	Part description
5QK09-64013	LSU fan

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the left top cover

Use the following procedure to remove and replace the left top cover.

- Use a pair of tweezers to carefully release the cover, and then pull straight out to remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-1063 Remove the cover



2. Remove the left cover

Use the following procedure to remove and replace the left cover.


1. Open the front cover (door) and all installed trays.
2. Remove eight screws.

Figure 5-1064 Remove eight screws



3. Before proceeding, take note of the location of the mounting hooks on the inside of the cover.

Figure 5-1065 Cover hook locations



4. Release the cover from the right- to left side. Remove the cover.

Figure 5-1066 Remove the cover




3. Remove the LSU fan

Use the following procedure to remove and replace the LSU fan.

- Disconnect one connector, remove two screws, and then remove the LSU fan.

Figure 5-1067 Remove the fan



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front door switch assembly

Learn about removing and replacing the front door switch.

View a video of removing and replacing the front door switch.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

NOTE: This procedure requires removing the toner cartridges using the control panel method. Do this prior to turning the power off. For more information, see *Remove the toner cartridges (control panel method)* in this topic.

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-107 Part information

Part number	Part description
JC93-00466A	Front door open switch

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the toner cartridge (control panel method)

Use the following procedure to remove and replace the toner cartridge.

- At the printer control panel, do the following:
  a. Select the Supplies menu.
  b. Open the front door.
  c. Select the Eject button  (located at the bottom right corner of the control panel).

2. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-1068 **Remove two screws**



2. Open the right door.

Figure 5-1069 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-1070 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-1071 Remove the cover assembly




3. Remove the exit cover stacker

Use the following procedure to remove and replace the exit cover stacker.

- Remove two screw caps and remove two screws (callout 1), and then remove the exit cover stacker (callout 2).

Figure 5-1072 Remove the cover




4. Remove the toner collection unit (TCU)

Use the following procedure to remove and replace the TCU.

- Open the front door assembly. Push on each tab on the sides of the toner collection unit to release it, and then pull it straight out of the printer.

Figure 5-1073 Remove the TCU




5. Remove the front cover

Use the following procedure to remove and replace the front cover.


1. Remove two screws.

Figure 5-1074 **Remove two screws**



2. Push in on the hook located at the right side of the cover (callout 1), and then remove the cover (callouts 2/3).

Figure 5-1075 **Remove the cover**




6. Remove the inner cover

Use the following procedure to remove and replace the inner cover.


1. Remove nine screws and disconnect the connector.

Figure 5-1076 **Remove screws and disconnect connector**



2. Remove the cover carefully, making sure not to damage the drum engage lever as you remove the cover.

Figure 5-1077 **Avoid damaging the drum engage lever**




7. Remove the front door switch assembly

Use the following procedure to remove and replace the front door switch assembly.

- Disconnect one connector, remove one screw, and then remove the front door switch.

Figure 5-1078 **Remove the switch**



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right door switch assembly

Learn about removing and replacing the right door switch.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-108 Part information

Part number	Part description
JC93-01467A	Switch (right door switch)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1079 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1080 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1081 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1082 **Remove the cover**




4. Remove the right door switch

Use the following procedure to remove and replace the right door switch.

- Open the right door, disconnect one connector, remove one screw, and then remove the right door switch.

NOTE: Release the wire harness from the retainer.

Figure 5-1083 Remove the switch



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Control panel

Learn about control panel parts removal and replacement.

Base control panel

Review the base control panel removal procedures.

Removal and replacement: Control panel

Learn about removing and replacing the control panel.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-109 Part information

Part number	Part description
5QK42-60104	Control-panel assembly 25.6 cm (10.1 in 2nd)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle upper cover

Use the following procedure to remove and replace the middle upper cover.

1. Rotate the control panel into the upright position.

Figure 5-1084 **Raise the control panel**



2. Use a pair of tweezers to release the cover, and then remove the cover.

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.

Figure 5-1085 **Remove the cover**



2. Remove the control panel

Use the following procedure to remove and replace the control panel.


1. Remove one screw.

Figure 5-1086 Remove one screw



2. Disconnect two connectors, remove three screws, and then remove the control panel.

Figure 5-1087 Remove the control panel



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

PCAs

Learn about printed circuit assembly (PCA) parts removal and replacement.

Main PCA

Learn about main printed circuit assembly (PCA) parts removal and replacement.

Removal and replacement: Formatter

Learn about removing and replacing the formatter.

View a video of removing and replacing the formatter.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-110 Part information

Part number	Part description
6CF14-67002	Formatter (main PCA) (Formatter)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1088 Remove the cover




Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1089 **Remove the cover**




Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1090 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1091 **Remove the cover**



Remove the rivet-SSD

Use the following procedure to remove and replace the rivet-SSD.

- Locate the SSD rivets near the formatter interface ports, and then use a pair of tweezers to remove them.

Figure 5-1092 **Remove the rivets**




Remove the SSD

Use the following procedure to remove and replace the SSD.

- Push in and lift up on the lever (callout 1) to release the SSD, and then remove it and the cradle together (callout 2).

Figure 5-1093 Remove the SSD




Remove the formatter

Use the following procedure to remove and replace the formatter.


1. Disconnect all of the connectors on the formatter.

Figure 5-1094 Disconnect all connectors




2. Remove ten screws, and then remove the formatter.

Figure 5-1095 **Remove ten screws**



3. **For replacement formatter installations**: The trusted platform module (TPM) is not a replaceable service part. Remove the TPM from the discarded formatter, and then install it on the replacement formatter.

Figure 5-1096 **Formatter TPM**



4. Install the replacement formatter by tilting the board and lining it up with the four tabs shown.

Figure 5-1097 Four tabs on the printer housing






Figure 5-1098 Tilting the formatter board and lining up the tabs





Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Riser card and cradle

Learn about removing and replacing the riser card and cradle.

View a video of removing and replacing the riser card and cradle.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-111 Part information

Part number	Part description
3SJ01-60002	Riser card-EPS2.0 Riser for SSD
5851-8707	Cradle-Riser card

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1099 **Remove the cover**



Remove the rivet-SSD

Use the following procedure to remove and replace the rivet-SSD.

- Locate the SSD rivets near the formatter interface ports, and then use a pair of tweezers to remove them.

Figure 5-1100 Remove the rivets




Remove the SSD

Use the following procedure to remove and replace the SSD.

- Push in and lift up on the lever (callout 1) to release the SSD, and then remove it and the cradle together (callout 2).

Figure 5-1101 Remove the SSD




Remove the riser card and cradle

Use the following procedure to remove and replace the riser card and cradle.


1. Release the clips on both ends of the cradle (callout 1), and then remove the riser card (callout 2).

Figure 5-1102 Remove the riser card




2. Release the hook.

Figure 5-1103 Release the hook



3. Separate the riser card from the cradle.

Figure 5-1104 **Remove the riser card and cradle**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Rivet-SSD

Learn about removing and replacing the solid state drive rivet.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-112 Part information

Part number	Part description
6ER04-40035	Rivet-SSD

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the rivet-SSD

Use the following procedure to remove and replace the rivet-SSD.

- Locate the SSD rivets near the formatter interface ports, and then use a pair of tweezers to remove them.

Figure 5-1105 Remove the rivets



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Cradle-SSD

Learn about removing and replacing the solid state drive cradle.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-113 Part information

Part number	Part description
5851-8707	Cradle-SSD

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1106 Remove the cover



2. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1107 Remove the screw caps



2. Remove five screws, and then remove the cover.

Figure 5-1108 Remove the cover



3. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove six screws, and then remove the cover.

Figure 5-1109 Remove the cover



4. Remove the rivet-SSD

Use the following procedure to remove and replace the rivet-SSD.

- Locate the SSD rivets near the formatter interface ports, and then use a pair of tweezers to remove them.

Figure 5-1110 Remove the rivets




5. Remove the SSD

Use the following procedure to remove and replace the SSD.

- Push in and lift up on the lever (callout 1) to release the SSD, and then remove it and the cradle together (callout 2).

Figure 5-1111 Remove the SSD




6. Remove the SSD from the cradle

Use the following procedure to remove the SSD from the cradle.

1. Release the clips on both ends of the cradle (callout 1), and then remove the riser card and SSD from the cradle. (callout 2).

Figure 5-1112 **Remove the riser card**



2. Separate the SSD from the cradle.

Figure 5-1113 **Separate the SSD from the cradle**



3. Separate the SSD from the riser card.

Figure 5-1114 Separate the SSD from the riser card



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: SSD 256GB

Learn about removing and replacing the SSD.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-114 Part information

Part number	Part description
0950-5111	SSD 256GB M.2 PCIE NVME 2280 3D-NAND

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1115 Remove the cover



2. Remove the rivet-SSD

Use the following procedure to remove and replace the rivet-SSD.

- Locate the SSD rivets near the formatter interface ports, and then use a pair of tweezers to remove them.

Figure 5-1116 Remove the rivets




3. Remove the SSD

Use the following procedure to remove and replace the SSD.

- Push in and lift up on the lever (callout 1) to release the SSD, and then remove it and the cradle together (callout 2).

Figure 5-1117 Remove the SSD




4. Remove the SSD from the cradle

Use the following procedure to remove the SSD from the cradle.

1. Release the clips on both ends of the cradle (callout 1), and then remove the riser card and SSD from the cradle. (callout 2).

Figure 5-1118 Remove the riser card



2. Separate the SSD from the cradle.

Figure 5-1119 **Separate the SSD from the cradle**



3. Separate the SSD from the riser card.

Figure 5-1120 **Separate the SSD from the riser card**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Sub PCAs

Learn about sub printed circuit assembly (PCA) parts removal and replacement.

Removal and replacement: Accelerator card (optional)

Learn about removing and replacing the accelerator card.

View a video of removing and replacing the accelerator card.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-115 Part information

Part number	Part description
6HN30-67001	Accelerator card

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1121 Remove the cover



2. Remove the rivet-HDD

Use the following procedure to remove and replace the rivet-HDD.

- Locate the HDD rivets near the formatter interface ports, and then use a pair of tweezers to remove them.

Figure 5-1122 Remove the rivets




3. Remove the hard disk and accelerator card assembly

Use the following procedure to remove and replace the HDD and accelerator card assembly.


1. Push in and lift up on the lever (callout 1) to release the assembly, and then remove the hard drive and accelerator card together (callout 2).

Figure 5-1123 Remove the HDD and accelerator card assembly



2. Release two clips (callout 1), and then separate the accelerator card form the riser card to remove it (callout 2).

Figure 5-1124 Remove the accelerator card



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: USB hub PCA

Learn about removing and replacing the USB hub PCA.

View a video of removing and replacing the USB hub PCA.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-116 Part information

Part number	Part description
3SJ04-60002	USB hub PCA

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-1125 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-1126 Remove the cover



2. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-1127 Remove one screw cap



2. Remove one screw.

Figure 5-1128 Remove one screw




3. Remove the cover.

Figure 5-1129 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-1130 Disconnect one connector



5. Remove four screws.

Figure 5-1131 Remove four screws



6. Remove the keyboard.

Figure 5-1132 Remove the keyboard



3. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-1133 **Remove two screws**



2. Open the right door.

Figure 5-1134 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ **CAUTION:** Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-1135 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-1136 Remove the cover assembly




4. Remove the USB hub PCA

Use the following procedure to remove and replace the USB hub PCA.

- Disconnect one connector, remove three screws, and then remove the USB hub PCA.

Figure 5-1137 Remove the PCA



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Island of data (IOD)

Learn about removing and replacing the IOD.

View a video of removing and replacing the IOD.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-117 Part information

Part number	Part description
3SJ06-60001	Island of Data

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1138 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1139 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1140 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1141 **Remove the cover**




4. Remove the IOD

Use the following procedure to remove and replace the IOD.

1. Disconnect one connector.


Figure 5-1142 **Disconnect one connector**



2. Use a pair of tweezers to remove one rivet, and then remove the island of data.

⚠ CAUTION: Be careful when handling the rivet. Do not drop it into the printer engine.

Figure 5-1143 **Remove the PCA**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Power key PCA

Learn about removing and replacing the power key PCA.

View a video of removing and replacing the power key PCA.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-118 Part information

Part number	Part description
3SJ33-60007	Power key PCA

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the middle left cover

Use the following procedure to remove and replace the middle left cover.

1. Remove two screws.

Figure 5-1144 Remove two screws



2. Rotate the control panel into the upright position, and then remove the cover (callout 1).

Figure 5-1145 **Remove the cover**



2. Remove the keyboard (fold type)

Use the following procedure to remove and replace the keyboard (fold type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a drawer type keyboard, follow the instructions in "Removal the keyboard (drawer type)" section in the Service manual.

1. Rotate the keyboard up and out of the way, and then use a pair of tweezers to remove one screw cap.

Figure 5-1146 Remove one screw cap



2. Remove one screw.

Figure 5-1147 Remove one screw




3. Remove the cover.

Figure 5-1148 Remove the cover



4. Disconnect one connector (callout 1), and then release the cable from the retainer (callout 2).

Figure 5-1149 Disconnect one connector



5. Remove four screws.

Figure 5-1150 **Remove four screws**



6. Remove the keyboard.

Figure 5-1151 **Remove the keyboard**



3. Remove the right middle cover assembly

Use the following procedure to remove and replace the right middle cover assembly.

NOTE: If an optional keyboard is installed, remove it now.

1. Remove two screws.

Figure 5-1152 **Remove two screws**



2. Open the right door.

Figure 5-1153 **Open the right door**



3. Move the control panel out of the way, and then slide the cover as shown below to separate it from the printer.


⚠ CAUTION: Do not attempt to completely remove the cover. It is still attached to the printer by a wire harness.

Figure 5-1154 Slide the cover



4. Disconnect one connector, and then remove the right middle cover assembly.

Figure 5-1155 Remove the cover assembly




4. Remove the power key PCA

Use the following procedure to remove and replace the power key PCA.


1. Remove one screw.

Figure 5-1156 Remove one screw



2. Lift the PCA up, disconnect one connector, and then remove the power key PCA.

Figure 5-1157 Remove the PCA



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Keyboard (Flow models)

Learn about removing and replacing the keyboard.

NOTE: There are two types of physical keyboards (fold type and drawer type). Verify the type keyboard to be serviced, and then follow the appropriate instructions in this topic.

View a video of removing and replacing the keyboard (fold type).

Mean time to repair: 15 minutes (folding type)10 minutes (drawer type)

Service level: Medium (folding type and drawer type)

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-119 Part information

Part number	Part description
63C82-67003	E8 Keyboard (Drawer type) Assy-US English

Table 5-119 Part information (continued)

Part number	Part description
63C82-67005	E8 Keyboard (Drawer type) Assy-UK English

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the keyboard (drawer type)

Use the following procedure to remove and replace the keyboard (drawer type).

NOTE: The optional keyboard is for flow models only. For all other models, skip this step.

For a fold type keyboard, follow the instructions in "Remove the keyboard (fold type)" section in the Service manual.

1. Do the following:
   - Rotate the control panel into the upright position (callout 1).
   - Use a pair of tweezers to release the cover (callout 2), and then remove the top cover (callout 3).

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.


Figure 5-1158 Remove the cover



2. Disconnect two connectors (callout 1), remove three screws (callout 2, and then remove the control panel (callout 3).

NOTE: Lift the control panel straight up to remove it.

Figure 5-1159 Remove the control panel



3. Disconnect one connector.

IMPORTANT: The control panel mount bracket and the keyboard must be removed together. They are attached to each other by a film cable.

Figure 5-1160 Disconnect one connector



4. Remove four screws.


Figure 5-1161 Remove four screws



5. Pull the mount bracket and keyboard assembly straight out and away from the printer to **release** it.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by two hooks.

Figure 5-1162 Release the assembly



6. Look up under the mount bracket and keyboard assembly to locate two hooks. Press in on each hook, and then pull the assembly away form the printer to remove it.

Figure 5-1163 Remove the assembly



7. **Special instruction for a replacement keyboard**

   a. Dispose of the defective part. See

   NOTE: HP recommends responsible disposal of the defective part.

   http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

b. Unpack the replacement parts supplied in the service kit.

IMPORTANT: Only the control panel mount and keyboard assembly (callout 2) are required to be installed.

Save the additional service kit parts (callouts 1/3/4) for other applications.

Figure 5-1164 Service kit parts



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fax card (optional)

Learn about removing and replacing the fax card.

View a video of removing and replacing the fax card.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

NOTE: Fax card part numbers can vary by country/region. Check with your genuine HP parts supplier if you are unsure of the correct fax card part number for your country/region.

Table 5-120 Part information

Part number	Part description
7ZA09-67001	Single Fax 801 Accessory (BBU only)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1165 **Remove the cover**




2. Remove the fax card assembly

Use the following procedure to remove and replace the fax card.


1. Disconnect one connector, and then remove one screw.

Figure 5-1166 **Release the fax card**



2. Slightly rotate the fax card away from the formatter PCA (callout 1), and then slide it as shown (callout 2) to remove it.

Figure 5-1167 Remove the fax card



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Power supply PCAs

Learn about power supply printed circuit assembly (PCA) parts removal and replacement.

Removal and replacement: High-voltage power supply (HVPS)

Learn about removing and replacing the HVPS.

View a video of removing and replacing the HVPS.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-121 Part information

Part number	Part description
5QK09-60001	High-Voltage Power Supply (HVPS)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1168 **Remove the cover**




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1169 **Remove the cover**




3. Remove the HVPS

Use the following procedure to remove and replace the HVPS.

- Disconnect all of the connectors, remove three screws, and then remove the HVPS.

Figure 5-1170 Remove the HVPS



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Low-voltage power supply (LVPS)

Learn about removing and replacing the LVPS.

View a video of removing and replacing the LVPS.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-122 Part information

Part number	Part description
JC44-00149C	Low-Voltage Power Supply (LVPS), 110V
JC44-00150C	Low-Voltage Power Supply (LVPS), 220V

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1171 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1172 Remove the cover




3. Remove the LVPS FDB fan assembly

Use the following procedure to remove and replace the LVPS FDB fan assembly.


1. Disconnect one connector.

Figure 5-1173 Disconnect one connector




2. Remove four screws.

Figure 5-1174 Remove four screws



3. Release one tab, and then remove the LVP FDB fan assembly.

Figure 5-1175 **Remove the LVP FDB fan assembly**




4. Remove the LVPS

Use the following procedure to remove and replace the LVPS.

- Do the following:
  - Disconnect all of the connectors on the LVPS.
  - Remove seven screws.
  - Remove the LVPS.

Figure 5-1176 **Remove the PCA**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Fuser-drive board (FDB)

Learn about removing and replacing the FDB.

View a video of removing and replacing the FDB.

Mean time to repair: 8 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-123 Part information

Part number	Part description
JC44-00235C	Fuser-drive board (FDB), 110V
JC44-00236C	Fuser drive board (FDB), 220V

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1177 Remove the cover




Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1178 Remove the cover




Remove the LVPS FDB fan assembly

Use the following procedure to remove and replace the LVPS FDB fan assembly.

1. Disconnect one connector.

Figure 5-1179 Disconnect one connector




2. Remove four screws.

Figure 5-1180 Remove four screws



3. Release one tab, and then remove the LVP FDB fan assembly.

Figure 5-1181 Remove the LVP FDB fan assembly




Remove the FDB

Use the following procedure to remove and replace the FDB.

- Do the following:
  - Disconnect all of the connectors and wire harness retainers on the FDB.
  - Remove four screws.

- Remove the FDB.

Figure 5-1182 **Remove the PCA**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Integrated scanner asset (ISA)

Learn about ISA parts removal and replacement.

Whole unit

You will learn more about the ISA whole unit replacement.

300-Sheet ISA for z, z+ bundle

Learn about ISA removal and replacement.

Removal and replacement: Integrated scanner for Flow bundle (z, z+)

Learn about removing and replacing the ISA.

Mean time to repair: 10 minutes

Service level: Medium

NOTE: This procedure removes the document feeder whole unit including the white backing.

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-124 Part information

Part number	Part description
5QK37-67002	HP LaserJet 300ipm 300 sheet Flow DADF high speed Scanner (z, z+ bundle)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the flatbed glass to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Steps before you begin

Before removing a part in the Integrated scanner assembly (ISA), review the following information.

1. Check the printer keyboard is a drawer type keyboard.

NOTE:



2. Use the appropriate procedures when disassembling the ISA.

NOTE: When **disassembling the ISA for printers with drawer type keyboard**, it is required to remove the keyboard to slide easily the ISA unit toward the front of the printer.



2. Integrated Scanner for Flow models with drawer type keyboard (z, z+ bundles)

Learn how to remove and replace the ISA for Flow printers with a drawer type keyboard.

Remove the drawer type keyboard

Use the following procedure to remove the drawer type keyboard.

1. Perform the following steps:
   - Rotate the control panel into the upright position (callout 1).
   - Use a pair of tweezers to release the cover (callout 2), and then remove the top cover (callout 3).

Reinstallation tip: Position the cover on the printer, and then gently push it straight in to install it.


Figure 5-1183 Remove the cover



2. Disconnect two connectors (callout 1), remove three screws (callout 2), and then remove the control panel (callout 3).

NOTE: Lift the control panel straight up to remove it.

Figure 5-1184 Remove the control panel



3. Disconnect one connector.

IMPORTANT: The control panel mount bracket and the keyboard must be removed together. They are attached to each other by a film cable.

Figure 5-1185 Disconnect one connector



4. Remove four (4) screws.


Figure 5-1186 Remove four screws



5. Pull the mount bracket and keyboard assembly straight out and away from the printer to **release** it.


⚠ CAUTION: Do not attempt to completely remove the assembly. It is still attached to the printer by two hooks.

Figure 5-1187 Release the assembly



6. Look up under the mount bracket and keyboard assembly to locate the two hooks. Press in on each hook, and then pull the assembly away from the printer to remove it.

Figure 5-1188 Remove the assembly



7. Remove four (4) screws and detach the "keyboard lower bracket" from the printer (as shown in the pictures below).

Figure 5-1189 Remove 4 screws




Figure 5-1190 Location of screw on the inner top side above the output bin



Figure 5-1191 Remove the keyboard lower bracket




Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1192 Remove two screw caps



2. Remove two screws, and then remove the scan cover.

Figure 5-1193 **Remove two screws and the cover**




Remove the ISA

Use the following procedure to remove and replace the ISA.

1. Disconnect three connectors (callout 1).


NOTE: For the zero-force insertion (ZIF) flat-flexible cable (FFC) connectors, raise the locking clip to release the cable.

Figure 5-1194 **Disconnect three connectors**



2. Remove two screws (callout 1).


Figure 5-1195 **Remove two screws**



3. Slide the ISA towards the front of the printer until it stops to release it.

NOTE: Sliding the ISA might require considerable force to release the mounting locks.


Figure 5-1196 **Slide the ISA**



4. Lift the ISA up and off of the printer to remove it.

CAUTION: The ISA is heavy. Always use safe lifting practices. HP recommends more than one person lift the ISA.


Figure 5-1197 Remove the ISA



5. When reinstalling the FFCs into the connectors, make sure to push down on the locking clip so that the connector firmly grasps the cable film.

   - **Callout 1**: Unlocked
   - **Callout 2**: Locked

Figure 5-1198 Lock the FFC connector clip



Unpack the replacement assembly (Flow models with drawer type keyboard)

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, ensure to reverse the removal steps in the order listed below:

   a. Reassemble the ISA.

   b. Reassemble the keyboard.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

200-Sheet ISA for dn bundle

Learn about ISA removal and replacement.

Removal and replacement: Integrated scanner for dn bundle (5QK35A for Flex-build)

Learn about removing and replacing the ISA.

Mean time to repair: 10 minutes

Service level: Medium

NOTE: This procedure removes the document feeder whole unit including the white backing.

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-125 Part information

Part number	Part description
5QK35-67002	HP LaserJet 180ipm 200 sheet DADF high speed Scanner (dn bundle)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the flatbed glass to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1199 Remove two screw caps



2. Remove two screws, and then remove the scan cover.

Figure 5-1200 **Remove two screws and the cover**




2. Remove the ISA

Use the following procedure to remove and replace the ISA.

1. Disconnect three connectors (callout 1).


NOTE: For the zero-force insertion (ZIF) flat-flexible cable (FFC) connectors, raise the locking clip to release the cable.

Figure 5-1201 **Disconnect three connectors**



2. Remove two screws (callout 1).


Figure 5-1202 **Remove two screws**



3. Slide the ISA towards the front of the printer until it stops to release it.

NOTE: Sliding the ISA might require considerable force to release the mounting locks.


Figure 5-1203 **Slide the ISA**



4. Lift the ISA up and off of the printer to remove it.

CAUTION: The ISA is heavy. Always use safe lifting practices. HP recommends more than one person lift the ISA.


Figure 5-1204 Remove the ISA



5. When reinstalling the FFCs into the connectors, make sure to push down on the locking clip so that the connector firmly grasps the cable film.

   - **Callout 1**: Unlocked
   - **Callout 2**: Locked

Figure 5-1205 Lock the FFC connector clip



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

ADF (Automatic document feeder)

Learn about ADF parts removal and replacement.

300-Sheet ADF for z, z+ bundles

Learn about ADF parts removal and replacement.

Removal and replacement: ADF (300sh)

Learn about removing and replacing the document feeder.

IMPORTANT: This procedure removes the document feeder whole unit (including the white backing plate).

Special installation instructions are included at the end of this topic (after the unpack and recycle step).

To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

Instruction for installing a replacement white backing plate are also included.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-126 Part information

Part number	Part description
5QK08-67014	300-sheet Flow Automatic Document Feeder (ADF) **NOTE:** The white backing plate is not included. Order 5QK08-67005 (Qty 1) and J8J63-60135 (Qty 9) to receive the SVC-A3 White Backing Kit and White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005) clips.

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1206 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1207 **Remove two screws and the cover**



2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1208 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

CAUTION: Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1209 Disconnect three connectors



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1210 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).

To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

4. Special installation instructions: Document feeder

Use the following instructions to install the document feeder.

NOTE: To avoid damage to the document feeder, reverse the removal steps and follow these special instructions.


1. The flat-flexible cable (FFC) connectors are a Zero Insertion Force (ZIF) type that uses a hinged retainer clip to secure the FFC.

CAUTION: Do not force the FFC into or out of the connector if the hinged retainer is in the locked position.

Forcing the FFC into or out of a locked connector can damage the FFC and cause the document feeder to be in operable.

- **Callout 1**: FFC missing pin
- **Callout 2**: FFC pin pealed back


Figure 5-1211 Damaged FFC



2. Verify that the ZIF connector hinged retainer (callout 1) is unlocked. The image below shows a locked connector.

   - **Callout 2**: Unlock the hinged retainer
   - **Callout 3**: Lock the hinged retainer

Figure 5-1212 ZIF connector hinged retainer




5. Special installation instructions: White backing plate

Use the following instructions to install the white backing plate

1. If the spring and suspension clip have become separated during shipping, install the spring on the clip as shown below.

Figure 5-1213 Spring installed on the suspension clip




2. Position a suspension clip near the mounting feature on the document feeder, and then push it straight in to install it.

Figure 5-1214 Install the suspension clip




3. Remove the protective film from the double-sided tape on the suspension clip.

Figure 5-1215 **Expose the double-sided tape**



4. Repeat these steps for the remaining eight suspension clips.

Figure 5-1216 **Install the remaining suspension clips**



5. Place the white backing plate on the flatbed glass.

NOTE: One corner of the white backing plate has an arrow embossed on it. Place that corner towards the rear left corner of the flatbed glass.


Figure 5-1217 Place the white backing plate



6. Position the white backing plate so that the corner with the embossed arrow fits tightly up against the flatbed glass frame.

NOTE: Make sure that the rear and left edges of the plate are firmly against the flatbed frame.

Figure 5-1218 Register the white backing plate against the frame



7. Fully close the document feeder to install the white backing plate.

NOTE: Open the document feeder and make sure the white backing plate is firmly attached.

Figure 5-1219 Close the document feeder



Removal and replacement: ADF front cover (300sh)

Learn about removing and replacing the document feeder front cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-127 Part information

Part number	Part description
5QJ90-40049	ADF front cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder color panel

Use the following procedure to remove and replace the document feeder color panel.

1. Open the document feeder.
2. Remove three screws (callout 1), release four tabs, and then remove the document feeder color panel (callout 2).

Figure 5-1220 **Remove the color panel**




2. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1221 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1222 **Remove two screws and the cover**



3. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1223 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

CAUTION: Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1224 Disconnect three connectors



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1225 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).

To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

4. Remove the document feeder front cover

Use the following procedure to remove and replace the document feeder front cover.


1. Open the ADF top cover, and then remove two screws.

Figure 5-1226 Remove two screws



2. Use a pair of tweezers to release three hooks, and then remove the document feeder front cover.

Figure 5-1227 Remove the cover



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF CMF panel

Learn about removing and replacing the document feeder color panel.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-128 Part information

Part number	Part description
5QJ90-40056	ADF CMF panel

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder color panel

Use the following procedure to remove and replace the document feeder color panel.

1. Open the document feeder.
2. Remove three screws (callout 1), release four tabs, and then remove the document feeder color panel (callout 2).

Figure 5-1228 **Remove the color panel**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF rear cover (300sh)

Learn about removing and replacing the document feeder rear cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-129 Part information

Part number	Part description
5QJ90-40041	ADF rear cover

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1229 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1230 **Remove two screws and the cover**



Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1231 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

⚠ **CAUTION:** Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1232 **Disconnect three connectors**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1233 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove two screws.

Figure 5-1234 Remove two screws



2. Open the ADF top cover, remove two screws, and then remove the ADF rear cover.

Figure 5-1235 **Remove the cover**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF top cover (300sh)

Learn about removing and replacing the document feeder top cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-130 Part information

Part number	Part description
5QJ90-40054	ADF top cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.


1. Remove the document feeder top cover

Use the following procedure to remove and replace the document feeder top cover.

1. Open the ADF top cover.

2. Remove eight screws, and then remove the ADF top cover.

Figure 5-1236 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF white backing kit (300sh)

Learn about removing and replacing the document feeder white backing.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-131 Part information

Part number	Part description
5QK08-67005	SVC-A3 White Backing Kit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder white backing

Use the following procedure to remove and replace the document feeder white backing.

1. Open the document feeder.

2. Disconnect nine hooks, and then remove the white backing.

Figure 5-1237 **Remove the white backing**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.


NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

3. Special installation instructions: White backing plate

Use the following instructions to install the white backing plate

1. If the spring and suspension clip have become separated during shipping, install the spring on the clip as shown below.

Figure 5-1238 **Spring installed on the suspension clip**




2. Position a suspension clip near the mounting feature on the document feeder, and then push it straight in to install it.

Figure 5-1239 Install the suspension clip




3. Remove the protective film from the double-sided tape on the suspension clip.

Figure 5-1240 Expose the double-sided tape



4. Repeat these steps for the remaining eight suspension clips.

Figure 5-1241 **Install the remaining suspension clips**



5. Place the white backing plate on the flatbed glass.

NOTE: One corner of the white backing plate has an arrow embossed on it. Place that corner towards the rear left corner of the flatbed glass.


Figure 5-1242 **Place the white backing plate**



6. Position the white backing plate so that the corner with the embossed arrow fits tightly up against the flatbed glass frame.

NOTE: Make sure that the rear and left edges of the plate are firmly against the flatbed frame.

Figure 5-1243 Register the white backing plate against the frame



7. Fully close the document feeder to install the white backing plate.

NOTE: Open the document feeder and make sure the white backing plate is firmly attached.

Figure 5-1244 Close the document feeder



Removal and replacement: ADF pickup roller kit (300sh)

Learn about removing and replacing the document feeder pickup roller kit.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-132 Part information

Part number	Part description
A91Z5-67001	ADF roller kit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.


1. Remove the document feeder pickup roller kit

Use the following procedure to remove and replace the document feeder pickup roller kit.

1. Open the ADF top cover.


2. Remove the roller cover.

Figure 5-1245 **Remove the roller cover**




3. Remove the roller assembly.

Figure 5-1246 **Remove the roller assembly**




4. Open the separation roller cover.

Figure 5-1247 **Open the cover**



5. Remove the separation roller.

Figure 5-1248 **Remove the separation roller**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF PCA (300sh)

Learn about removing and replacing the document feeder printed circuit assembly (PCA).

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-133 Part information

Part number	Part description
Z9Y05-60004	300sh ADF PCA

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1249 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1250 **Remove two screws and the cover**



2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1251 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

⚠ **CAUTION:** Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1252 **Disconnect three connectors**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1253 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove two screws.

Figure 5-1254 Remove two screws



2. Open the ADF top cover, remove two screws, and then remove the ADF rear cover.

Figure 5-1255 Remove the cover




4. Remove the document feeder PCA

Use the following procedure to remove and replace the document feeder PCA.

- Disconnect all of the connectors (callout 1), remove one screw (callout 2), and then remove the PCA.

Figure 5-1256 Remove the PCA



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF flat-flexible cable (300sh)

Learn about removing and replacing the document feeder flat-flexible cable (FFC) to SSA.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-134 Part information

Part number	Part description
Z9Y05-50002	ADF FFC cable to SSA

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1257 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1258 **Remove two screws and the cover**



2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1259 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

⚠ **CAUTION:** Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1260 **Disconnect three connectors**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1261 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove two screws.

Figure 5-1262 Remove two screws



2. Open the ADF top cover, remove two screws, and then remove the ADF rear cover.

Figure 5-1263 Remove the cover




4. Remove the document feeder FFC to SSA

Use the following procedure to remove and replace the document feeder FFC to SSA.

- Disconnect the flat-flexible cable (FFC) to SSA, and then remove the FFC.

NOTE: The FFC is located at the bottom left corner of the ADF PCA.

Figure 5-1264 Remove the FFC



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF power cable (300sh)

Learn about removing and replacing the document feeder power cable.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-135 Part information

Part number	Part description
Z9Y05-50003	ADF power cable

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1265 Remove two screw caps



2. Remove two screws, and then remove the scan cover.

Figure 5-1266 **Remove two screws and the cover**



2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1267 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

⚠ **CAUTION:** Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1268 **Disconnect three connectors**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1269 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove two screws.

Figure 5-1270 Remove two screws



2. Open the ADF top cover, remove two screws, and then remove the ADF rear cover.

Figure 5-1271 **Remove the cover**




4. Remove the document feeder power cable

Use the following procedure to remove and replace the document feeder power cable.

- Disconnect the power cable, and then remove the cable.

NOTE: The power cable is located near the bottom left corner of the ADF PCA.

Figure 5-1272 **Remove the power cable**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF hinge kit (300sh)

Learn about removing and replacing the document feeder hinge kit.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-136 Part information

Part number	Part description
5QK08-67003	SVC-Hinge Kit (right, middle, left)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder white backing

Use the following procedure to remove and replace the document feeder white backing.

1. Open the document feeder.
2. Disconnect nine hooks, and then remove the white backing.

Figure 5-1273 **Remove the white backing**




2. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1274 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1275 **Remove two screws and the cover**



3. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1276 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

CAUTION: Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1277 Disconnect three connectors



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1278 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

4. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove two screws.

Figure 5-1279 **Remove two screws**



2. Open the ADF top cover, remove two screws, and then remove the ADF rear cover.

Figure 5-1280 **Remove the cover**




5. Remove the document feeder hinge damper module

Use the following procedure to remove and replace the document feeder hinge damper module.

- Remove five screws, and then remove the hinge damper module.

Figure 5-1281 **Remove the hinge damper module**




6. Remove the document feeder hinge kit

Use the following procedure to remove and replace the document feeder hinge kit.


1. Remove seven screws, and then remove the hinge.

Figure 5-1282 **Remove the hinge**




2. Remove five screw caps.

Figure 5-1283 **Remove five screw caps**



3. Remove eleven screws, and then remove the hinges.

Figure 5-1284 **Remove the hinges**



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF hinge damper module 300sh)

Learn about removing and replacing the document feeder damper module.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-137 Part information

Part number	Part description
Z9Y05-60016	ADF hinge damper module

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder white backing

Use the following procedure to remove and replace the document feeder white backing.

1. Open the document feeder.
2. Disconnect nine hooks, and then remove the white backing.

Figure 5-1285 **Remove the white backing**




2. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1286 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1287 **Remove two screws and the cover**



3. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

NOTE: This procedure removes the document feeder whole unit (including the white backing plate).


To install a replacement document feeder only: The following parts are required:

- SVC-A3 White Backing Kit; 5QK08-67005 (QTY 1)
- White backing suspension (combined into SVC-A3 White Backing Kit PN:5QK08-67005); J8J63-60135 (Qty 9)

NOTE: Nine are required. Make sure the order quantity is nine.

1. Remove two screws.

Figure 5-1288 **Remove two screws**




2. Disconnect one connector and two flat-flexible cables FFCs (callout 1).

CAUTION: Disconnecting one of the FFCs requires opening a retaining clip (callout 2).


Reinstallation tip: Use the special installation instructions in this topic to avoid damaging the FFCs.

Figure 5-1289 Disconnect three connectors



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1290 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

4. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove two screws.

Figure 5-1291 **Remove two screws**



2. Open the ADF top cover, remove two screws, and then remove the ADF rear cover.

Figure 5-1292 **Remove the cover**




5. Remove the document feeder hinge damper module

Use the following procedure to remove and replace the document feeder hinge damper module.

- Remove five screws, and then remove the hinge damper module.

Figure 5-1293 **Remove the hinge damper module**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

200-Sheet ADF for dn bundle

Learn about ADF parts removal and replacement.

Removal and replacement: ADF (200sh)

Learn about removing and replacing the document feeder.

IMPORTANT: This procedure removes the document feeder whole unit (including the white backing plate).

Mean time to repair: 10 minutes

Service level: Medium

NOTE: This procedure removes the document feeder whole unit including the white backing.

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

NOTE: The whole unit replacement parts below include the Kit - white backing A3 (5QJ90-67005).

Table 5-138 **Part information**

Part number	Part description
5QJ90-67011	Automatic document feeder (ADF) (Growler + ENT)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1294 Remove two screw caps



2. Remove two screws, and then remove the scan cover.

Figure 5-1295 Remove two screws and the cover




2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

1. Remove two screws.


Figure 5-1296 **Remove two screws**



2. Disconnect three connectors (callout 1).


NOTE: Release the retainer clip (callout 2) to disconnect one of the FFCs.

Figure 5-1297 **Remove the document feeder**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1298 **Remove the document feeder assembly**



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).

To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.


NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

4. Special installation instructions: White backing plate

Use the following instructions to install the white backing plate

1. If the spring and suspension clip have become separated during shipping, install the spring on the clip as shown below.

Figure 5-1299 **Spring installed on the suspension clip**




2. Position a suspension clip near the mounting feature on the document feeder, and then push it straight in to install it.

Figure 5-1300 **Install the suspension clip**




3. Remove the protective film from the double-sided tape on the suspension clip.

Figure 5-1301 **Expose the double-sided tape**



4. Repeat these steps for the remaining eight suspension clips.

Figure 5-1302 **Install the remaining suspension clips**



5. Place the white backing plate on the flatbed glass.

NOTE: One corner of the white backing plate has an arrow embossed on it. Place that corner towards the rear left corner of the flatbed glass.


Figure 5-1303 **Place the white backing plate**



6. Position the white backing plate so that the corner with the embossed arrow fits tightly up against the flatbed glass frame.

NOTE: Make sure that the rear and left edges of the plate are firmly against the flatbed frame.

Figure 5-1304 Register the white backing plate against the frame



7. Fully close the document feeder to install the white backing plate.

NOTE: Open the document feeder and make sure the white backing plate is firmly attached.

Figure 5-1305 Close the document feeder



Removal and replacement: ADF CMF panel

Learn about removing and replacing the document feeder color panel.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-139 Part information

Part number	Part description
5QJ90-40056	ADF CMF panel

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.


1. Remove the document feeder color panel

Use the following procedure to remove and replace the document feeder color panel.

1. Open the document feeder.

2. Remove three screws (callout 1), release four tabs, and then remove the document feeder color panel (callout 2).

Figure 5-1306 Remove the color panel



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF white backing kit (200sh)

Learn about removing and replacing the document feeder white backing plate.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-140 Part information

Part number	Part description
5QJ90-67005	Kit - white backing A3

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder white backing

Use the following procedure to remove and replace the document feeder white backing.

1. Open the document feeder.

2. Disconnect nine hooks, and then remove the white backing.

Figure 5-1307 **Remove the white backing**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.


NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

3. Special installation instructions: White backing plate

Use the following instructions to install the white backing plate

1. If the spring and suspension clip have become separated during shipping, install the spring on the clip as shown below.

Figure 5-1308 Spring installed on the suspension clip




2. Position a suspension clip near the mounting feature on the document feeder, and then push it straight in to install it.

Figure 5-1309 Install the suspension clip




3. Remove the protective film from the double-sided tape on the suspension clip.

Figure 5-1310 Expose the double-sided tape



4. Repeat these steps for the remaining eight suspension clips.

Figure 5-1311 **Install the remaining suspension clips**



5. Place the white backing plate on the flatbed glass.

NOTE: One corner of the white backing plate has an arrow embossed on it. Place that corner towards the rear left corner of the flatbed glass.


Figure 5-1312 **Place the white backing plate**



6. Position the white backing plate so that the corner with the embossed arrow fits tightly up against the flatbed glass frame.

NOTE: Make sure that the rear and left edges of the plate are firmly against the flatbed frame.

Figure 5-1313 Register the white backing plate against the frame



7. Fully close the document feeder to install the white backing plate.

NOTE: Open the document feeder and make sure the white backing plate is firmly attached.

Figure 5-1314 Close the document feeder



Removal and replacement: ADF pickup roller kit (200sh)

Learn about removing and replacing the document feeder pickup roller kit.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-141 Part information

Part number	Part description
5851-7202	ADF roller kit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder pickup roller kit

Use the following procedure to remove and replace the document feeder pickup roller kit.


1. Release the latch, and then open the ADF top door.

Figure 5-1315 **Open the cover**




2. Rotate the blue locking lever down.

Figure 5-1316 **Rotate the lever**




3. Slide the locking lever toward the front of the printer (callout 1), and then remove the pick roller assembly (callout 2).

Figure 5-1317 Remove the roller assembly




4. Open the separation roller cover.

Figure 5-1318 Open the cover



5. Remove the separation roller.

Figure 5-1319 **Remove the roller**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF PCA (200sh)

Learn about removing and replacing the document feeder printed circuit assembly (PCA).

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-142 Part information

Part number	Part description
5QJ90-67013	ADF PCA_ENT EASE board

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1320 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1321 **Remove two screws and the cover**




2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

1. Remove two screws.


Figure 5-1322 **Remove two screws**



2. Disconnect three connectors (callout 1).


NOTE: Release the retainer clip (callout 2) to disconnect one of the FFCs.

Figure 5-1323 **Remove the document feeder**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1324 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove three screws.

Figure 5-1325 Remove three screws



2. Open the ADF top cover, remove one screw, and then remove the ADF rear cover.

Figure 5-1326 **Remove the cover**




4. Remove the document feeder PCA

Use the following procedure to remove and replace the document feeder PCA.

1. Disconnect all of the connectors.


NOTE: One flat-flexible cable (FFC; callout 1) is connected to the PCA with a zero-insertion force (ZIF) connector. Release the connector locking clip to remove the FFC.

Figure 5-1327 **Disconnect connectors**



2. Remove two screws, and then remove the PCA

Figure 5-1328 **Remove the PCA**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF flat-flexible cable (200sh)

Learn about removing and replacing the document feeder flat-flexible cable (FFC).

Mean time to repair: 2 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-143 Part information

Part number	Part description
5QJ90-67009	ADF flat-flexible cable

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1329 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1330 **Remove two screws and the cover**




2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

1. Remove two screws.


Figure 5-1331 **Remove two screws**



2. Disconnect three connectors (callout 1).


NOTE: Release the retainer clip (callout 2) to disconnect one of the FFCs.

Figure 5-1332 **Remove the document feeder**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1333 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove three screws.

Figure 5-1334 Remove three screws



2. Open the ADF top cover, remove one screw, and then remove the ADF rear cover.

Figure 5-1335 **Remove the cover**




4. Remove the document feeder FFC

Use the following procedure to remove and replace the document feeder FFC.

1. Disconnect the FFC.


NOTE: The FFC (callout 1) is connected to the PCA with a zero-insertion force (ZIF) connector. Release the connector locking clip to remove the FFC.

Figure 5-1336 **Disconnect the FFC**



2. Remove the FFC.

Figure 5-1337 **Remove the FFC**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF power cable (200sh)

Learn about removing and replacing the document feeder power cable.

Mean time to repair: 2 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-144 Part information

Part number	Part description
5QJ90-67010	ADF power cable

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1338 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1339 **Remove two screws and the cover**




2. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

1. Remove two screws.


Figure 5-1340 **Remove two screws**



2. Disconnect three connectors (callout 1).


NOTE: Release the retainer clip (callout 2) to disconnect one of the FFCs.

Figure 5-1341 **Remove the document feeder**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1342 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

3. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove three screws.

Figure 5-1343 Remove three screws



2. Open the ADF top cover, remove one screw, and then remove the ADF rear cover.

Figure 5-1344 **Remove the cover**




4. Remove the document feeder power cable

Use the following procedure to remove and replace the document feeder power cable.


1. Disconnect one connector.

Figure 5-1345 **Disconnect one connector**



2. Remove one screw, and then remove the cable.

Figure 5-1346 **Remove the cable**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF hinge kit (200sh)

Learn about removing and replacing the document feeder hinge kit.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-145 Part information

Part number	Part description
5QJ90-67004	ADF hinge kit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.


1. Remove the document feeder white backing

Use the following procedure to remove and replace the document feeder white backing.

1. Open the document feeder.

2. Before proceeding, take note of the location of the white backing mounting clips.

Figure 5-1347 Locate the clips



3. Disconnect nine clips, and then remove the white backing.

Figure 5-1348 Remove the white backing




2. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1349 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1350 **Remove two screws and the cover**




3. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

1. Remove two screws.


Figure 5-1351 **Remove two screws**



2. Disconnect three connectors (callout 1).


NOTE: Release the retainer clip (callout 2) to disconnect one of the FFCs.

Figure 5-1352 **Remove the document feeder**



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1353 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

4. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove three screws.

Figure 5-1354 Remove three screws



2. Open the ADF top cover, remove one screw, and then remove the ADF rear cover.

Figure 5-1355 **Remove the cover**




5. Remove the document feeder hinge kit

Use the following procedure to remove and replace the document feeder hinge kit.


1. Remove five screw caps.

Figure 5-1356 **Remove five screw caps**




2. Remove six screws, and then remove the hinge.

Figure 5-1357 **Remove the hinge**



3. Remove nine screws, and then remove the hinges.

Figure 5-1358 **Remove the hinges**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: ADF hinge damper module (200sh)

Learn about removing and replacing the document feeder damper module.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-146 Part information

Part number	Part description
5QJ90-67006	Damper module

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Use the document feeder to copy a page, and then verify that the document correctly copies, scans, or prints.

1. Remove the document feeder white backing

Use the following procedure to remove and replace the document feeder white backing.

1. Open the document feeder.
2. Before proceeding, take note of the location of the white backing mounting clips.

Figure 5-1359 **Locate the clips**



3. Disconnect nine clips, and then remove the white backing.

Figure 5-1360 **Remove the white backing**




2. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1361 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1362 **Remove two screws and the cover**




3. Remove the document feeder

Use the following procedure to remove and replace the document feeder.

1. Remove two screws.


Figure 5-1363 **Remove two screws**



2. Disconnect three connectors (callout 1).


NOTE: Release the retainer clip (callout 2) to disconnect one of the FFCs.

Figure 5-1364 Remove the document feeder



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1365 Remove the document feeder assembly



IMPORTANT: Special installation instructions are included at the end of this topic (after the unpack and recycle step).


To avoid damaging the ADF when it is reinstalled, make sure to carefully read and follow the installation instructions.

4. Remove the document feeder rear cover

Use the following procedure to remove and replace the document feeder rear cover.


1. Remove three screws.

Figure 5-1366 **Remove three screws**



2. Open the ADF top cover, remove one screw, and then remove the ADF rear cover.

Figure 5-1367 **Remove the cover**




5. Remove the document feeder hinge damper module

Use the following procedure to remove and replace the document feeder hinge damper module.


1. Remove two screws.

Figure 5-1368 **Remove two screws**



2. Remove five screws, and then remove the hinge damper module.

Figure 5-1369 **Remove the hinge damper module**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Flatbed Scanner (Tarot)

Learn about flatbed scanner parts removal and replacement.

Whole unit

Learn about the flatbed scanner whole unit replacement.

Removal and replacement: Flatbed scanner whole unit

Learn about removing and replacing the flatbed whole unit.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-147 Part information

Part number	Part description
3SJ11-60103	Flatbed scanner (Tarot)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1370 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1371 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1372 Remove the screw caps



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1373 **Remove the cover**




4. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1374 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1375 **Remove two screws and the cover**




5. Remove the document feeder

Use the following procedure to remove and replace the document feeder.


1. Remove two screws.

Figure 5-1376 **Remove two screws**




2. Disconnect three connectors (callout 1), remove one screw (callout 2), and then remove the document feeder.

Figure 5-1377 Remove the document feeder



3. Remove one screw to release a single-wire harness, and then lift the document feeder up to remove it.

Figure 5-1378 Remove the document feeder assembly




6. Remove the flatbed scanner whole unit

Use the following procedure to remove and replace the flatbed scanner.


1. Remove two screws.

Figure 5-1379 **Remove two screws**




2. Disconnect three connectors.

Figure 5-1380 **Disconnect three connectors**



3. Push the flatbed towards the front of the printer to release it, and then remove the flatbed scanner whole unit.

Figure 5-1381 Remove the whole unit



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Covers

Learn about the flatbed scanner covers replacement.

Removal and replacement: Flatbed scanner rear cover

Learn about removing and replacing the flatbed rear cover.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-148 Part information

Part number	Part description
3SJ11-40008	Rear cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1382 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1383 **Remove two screws and the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

PCA, harness, and sensor

Learn about the flatbed scanner PCA, harness, and sensor replacement.

Removal and replacement: Flatbed scanner PCA assembly

Learn about removing and replacing the flatbed PCA.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-149 Part information

Part number	Part description
Y6V12-60035	Flatbed PCA

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1384 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1385 **Remove two screws and the cover**




2. Remove the flatbed PCA

Use the following procedure to remove and replace the flatbed PCA.


1. Disconnect all of the connectors.

Figure 5-1386 **Disconnect all connectors**




2. Remove two screws.

Figure 5-1387 **Remove two screws**



3. Remove the flatbed scanner PCA and bracket assembly.

Figure 5-1388 **Remove the PCA**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Flatbed scanner FFC 50 pin

Learn about removing and replacing the flatbed FFC 50 pin.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-150 Part information

Part number	Part description
5QK08-67011	Flatbed FFC 50 pin

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1389 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1390 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1391 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1392 **Remove the cover**




4. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1393 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1394 **Remove two screws and the cover**




5. Remove the flatbed FFC 50 pin

Use the following procedure to remove and replace the flatbed FFC 50 pin.

- Disconnect two connectors, and then remove the flatbed FFC 50 pin..

Figure 5-1395 Remove the FFC



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Flatbed scanner FFC 68 pin

Learn about removing and replacing the flatbed FFC 68 pin.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-151 Part information

Part number	Part description
5QK08-67012	Flatbed FFC 68 pin

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1396 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1397 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1398 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1399 **Remove the cover**




4. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1400 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1401 **Remove two screws and the cover**




5. Remove the flatbed FFC 68 pin

Use the following procedure to remove and replace the flatbed FFC 68 pin.

- Disconnect two connectors, and then remove the flatbed FFC 68 pin.

Figure 5-1402 Remove the FFC



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Flatbed scanner discrete power cable

Learn about removing and replacing the flatbed power cable.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-152 Part information

Part number	Part description
3SJ11-50006	Flatbed discrete power cable

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the controller cover

Use the following procedure to remove and replace the controller cover.

- Loosen, but do not remove the thumbscrew at the right side of the cover, and then slide the cover as shown to remove it.

Figure 5-1403 Remove the cover




2. Remove the rear lower cover

Use the following procedure to remove and replace the rear lower cover.

- Remove nine screws, and then remove the cover.

Figure 5-1404 Remove the cover




3. Remove the rear upper cover

Use the following procedure to remove and replace the rear upper cover.


1. Use a pair of tweezers to remove the screw caps.

Figure 5-1405 **Remove the screw caps**



2. Remove four screws (callout 1), and then remove the cover.

Figure 5-1406 **Remove the cover**




4. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1407 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1408 **Remove two screws and the cover**




5. Remove the flatbed power cable

Use the following procedure to remove and replace the flatbed power cable.

- Disconnect two connectors, and then remove the flatbed power cable.

Figure 5-1409 **Remove the cable**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Flatbed scanner flatbed open sensor

Learn about removing and replacing the flatbed open sensor.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-153 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (flatbed open sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the flatbed scanner rear cover

Use the following procedure to remove and replace the scan cover.


1. Remove two screw caps.

Figure 5-1410 **Remove two screw caps**



2. Remove two screws, and then remove the scan cover.

Figure 5-1411 **Remove two screws and the cover**




2. Remove the flatbed power cable

Use the following procedure to remove and replace the flatbed power cable.

- Do the following:
  - Release the hooks (callout 1).
  - Separate the sensor from the flatbed (callout 2).

- Disconnect one connector (callout 3), and then remove the flatbed open sensor.

Figure 5-1412 **Remove the sensor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Input device (department)

Learn about input device (department) parts removal and replacement.

DCF (department)

Learn about dual cassette feeder (department) parts removal and replacement.

Covers

Review the DCF cover removal procedures.

Removal and replacement: DCF (Tray 4, 5) right cover

Learn about removing and replacing the dual cassette feeder (DCF) right cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-154 Part information

Part number	Part description
5QK08-40006	DCF (Tray 4, 5) right cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.
2. Remove four screws, and then remove the right cover.

Figure 5-1413 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF (Tray 4, 5) rear cover

Learn about removing and replacing the dual cassette feeder (DCF) rear cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-155 Part information

Part number	Part description
5QK08-40007	DCF (Tray 4, 5) rear cover

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1414 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF (Tray 4, 5) left cover

Learn about removing and replacing the dual cassette feeder (DCF) left cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-156 Part information

Part number	Part description
5QK08-40008	DCF (Tray 4, 5) left cover

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) left cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) left cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the left cover.

Figure 5-1415 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF (Tray 4, 5) right door

Learn about removing and replacing the dual cassette feeder (DCF) right door.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-157 Part information

Part number	Part description
5QK08-61004	DCF (Tray 4, 5) right door

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1416 **Remove the door**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 4, 5 CMF panels

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4, 5 color panel.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-158 Part information

Part number	Part description
5QK08-40011	Tray 4 CMF panel
5QK08-40012	Tray 5 CMF panel

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the Tray 4, 5 CMF panel

Use the following procedure to remove and replace the DCF Tray 4, 5 CMF panel.


1. Remove the Tray 4, 5 cassettes.
2. Push the hook to release it.

Figure 5-1417 **Release the hook**



3. Slide the panel to the left to remove the tray CMF panel.

Figure 5-1418 **Remove the panel**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Caster wheel

Learn about removing and replacing the dual cassette feeder (DCF) caster wheel.

NOTE: Remove the DCF from the printer.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-159 Part information

Part number	Part description
6109-001138	Caster wheel

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the caster wheel

Use the following procedure to remove and replace the DCF caster wheel.

1. Remove the DCF from the printer.


2. Do the following:

   a. Remove two screws (callout 1).

   b. Rotate the caster wheel (callout 2) out of the way, and then remove two screws (callout 3).

   c. Remove the caster wheel.

Figure 5-1419 **Remove the caster**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Holder wheel kit - guide adjust

Learn about removing and replacing the dual cassette feeder (DCF) holder wheel kit.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-160 Part information

Part number	Part description
JC61-04871A	Guide - adjust DCF

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the holder wheel kit

Use the following procedure to remove and replace the DCF holder wheel kit.


1. Remove the DCF from the printer.
2. Turn the holder wheel counterclockwise to remove it.

Figure 5-1420 **Remove the holder wheel**



3. Remove four screws, and then remove the holder wheel mounting bracket.

Figure 5-1421 **Remove the bracket**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Unit

Review the DCF unit parts removal procedures.

Removal and replacement: Tray 4, 5 cassettes

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4, 5 cassette.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-161 Part information

Part number	Part description
5QK08-61007	Tray 4 cassette
5QK08-61005	Tray 5 cassette

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1422 **Remove the cassette**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Roller

Review the DCF roller removal procedures.

Removal and replacement: DCF roller kit

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4, 5 rollers.

Mean time to repair: 5 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-162 Part information

Part number	Part description
5PN66-67001	DCF roller kit Tray 4
5PN66-67001	DCF roller kit Tray 5

Required tools

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1423 **Remove the cassette**



2. Remove the Tray 4, 5 rollers


Use the following procedure to remove and replace the DCF tray rollers.

NOTE: The procedure for removing the rollers is the same for Tray 4 or Tray 5.

1. Inside the tray cavity, slide the return guide toward the front of the printer until it stops.

Reinstallation tip: To prevent jams, make sure to slide the guide toward the rear of the printer after installing replacement rollers.


Figure 5-1424 Move the guide



2. Use a pair of tweezers to release the locking tab, and then slide the roller off the shaft to remove it.

   - **Pickup roller**: callout 1
   - **Forward roller**: callout 2
   - **Reverse roller**: callout 3

Figure 5-1425 Remove the rollers



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Motor

Review the DCF motor removal procedures.

Removal and replacement: DCF pickup drive assembly

Learn about removing and replacing the dual cassette feeder (DCF) pickup drive assembly.

NOTE: Remove the DCF from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-163 Part information

Part number	Part description
JC93-01663A	DCF pickup drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1426 Remove the cover




2. Remove the DCF pickup drive assembly

Use the following procedure to remove and replace the DCF pickup drive assembly.


1. Disconnect one connector, remove three screws, and then remove the Tray 4 pickup drive assembly.

Figure 5-1427 **Remove the assembly (Tray 4)**



2. Disconnect one connector, remove three screws, and then remove the Tray 5 pickup drive assembly.

Figure 5-1428 **Remove the assembly (Tray 5)**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 4 pickup motor

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4 pickup motor.

NOTE: Remove the DCF from the printer.

Mean time to repair: 5 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-164 Part information

Part number	Part description
JC93-01083A	Drive-motor step (Tray 4 pickup motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1429 Remove the cover




2. Remove the DCF Tray 4 pickup motor

Use the following procedure to remove and replace the DCF Tray 4 pickup motor.

- Disconnect one connector, remove two screws, and then remove the Tray 4 pickup motor.

Figure 5-1430 **Remove the motor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 5 pickup motor

Learn about removing and replacing the dual cassette feeder (DCF) Tray 5 pickup motor.

NOTE: Remove the DCF from the printer.

Mean time to repair: 5 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-165 Part information

Part number	Part description
JC93-01083A	Drive-motor step (Tray 5 pickup motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.

2. Remove four screws, and then remove the rear cover.

Figure 5-1431 **Remove the cover**




2. Remove the DCF Tray 5 pickup motor

Use the following procedure to remove and replace the DCF Tray 5 pickup motor.

- Disconnect one connector, remove two screws, and then remove the Tray 5 pickup motor.

Figure 5-1432 **Remove the motor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF feed drive assembly

Learn about removing and replacing the dual cassette feeder (DCF) feed drive assembly.

Mean time to repair: 5 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-166 Part information

Part number	Part description
JC93-01135A	DCF feed drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1433 **Remove the cover**




2. Remove the DCF feed drive assembly

Use the following procedure to remove and replace the DCF feed drive assembly.

- Disconnect one connector, remove three screws, and then remove the feed drive assembly.

Figure 5-1434 Remove the assembly



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF (Tray 4, 5) feed motor

Learn about removing and replacing the dual cassette feeder (DCF) feed motor.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-167 Part information

Part number	Part description
JC31-00177A	Motor, step (DCF Tray 4, 5 feed motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.

2. Remove four screws, and then remove the rear cover.

Figure 5-1435 Remove the cover




2. Remove the DCF feed drive assembly

Use the following procedure to remove and replace the DCF feed drive assembly.

- Disconnect one connector, remove three screws, and then remove the feed drive assembly.

Figure 5-1436 Remove the assembly




3. Remove the DCF feed motor

Use the following procedure to remove and replace the DCF feed motor.

- Remove the belt (callout 1), remove two screws (callout 2), and then remove the feed motor (callout 3).

Figure 5-1437 **Remove the motor**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Sensor

Review the DCF sensor removal procedures.

Removal and replacement: Tray 4, 5 paper size sensors

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4, 5 paper size sensors.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-168 Part information

Part number	Part description
JC93-01408A	Autosize sensor (Paper size Tray 4)
JC93-01408A	Autosize sensor (Paper size Tray 5)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1438 **Remove the cassette**




Remove the Tray 4, 5 paper size sensors

Use the following procedure to remove and replace the DCF tray paper size sensors.

NOTE: The procedure for removing the paper size sensors is the same for Tray 4 or Tray 5.

- Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the paper size sensor.
  - **Callout 3**: Tray 4 paper size sensor
  - **Callout 4**: Tray 5 paper size sensor

Figure 5-1439 Remove the sensor



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 4 pickup assembly

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4 pickup assembly.

NOTE: Remove the DCF from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-169 Part information

Part number	Part description
5QK08-61009	Tray 4 pickup assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1440 **Remove the cassette**




2. Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.
2. Remove four screws, and then remove the right cover.

Figure 5-1441 **Remove the cover**




3. Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1442 **Remove the door**




4. Remove the Tray 4 pickup assembly

Use the following procedure to remove and replace the DCF Tray 4 pickup assembly.


1. Disconnect one connector, and then remove two screws.

Figure 5-1443 **Disconnect connector and remove screws**




2. Remove four screws.

Figure 5-1444 Remove four screws



3. Rotate the pickup assembly up (callout 1), and then out of the DCF (callout 2).

Figure 5-1445 Remove the assembly



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 4 paper empty and stack height sensors

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4 paper empty and stack height sensors.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-170 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Tray 4 paper empty sensor)
3SJ00-60110	Photo interrupter (Tray 4 paper stack height sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1446 **Remove the cassette**



2. Remove the Tray 4, 5 paper empty and stack height sensors


Use the following procedure to remove and replace the DCF tray paper empty and stack height sensors.

NOTE: The procedure for removing the paper empty sensor or the paper stack height sensor is the same for both sensors.

1. Locate the desired sensor to remove (on the Tray 4 pickup assembly).
   - **Callout 1**: Tray 4, 5 paper stack height sensor


- **Callout 2**: Tray 4, 5 paper empty sensor

Figure 5-1447 **Locate the sensor**




2. Do the following:
   - Release the hooks (callout 1).
   - Slide the sensor assembly to the left (callout 2).
   - Release the sensor.

Figure 5-1448 **Release the sensor**



3. Disconnect one connector to remove the sensor.

Figure 5-1449 **Remove the sensor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 4 prefeed sensor

Learn about removing and replacing the dual cassette feeder (DCF) Tray 4 prefeed sensor.

NOTE: Remove the DCF from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-171 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Tray 4 prefeed sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1450 Remove the cassette




Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.
2. Remove four screws, and then remove the right cover.

Figure 5-1451 Remove the cover




Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1452 Remove the door




Remove the Tray 4 pickup assembly

Use the following procedure to remove and replace the DCF Tray 4 pickup assembly.


1. Disconnect one connector, and then remove two screws.

Figure 5-1453 Disconnect connector and remove screws




2. Remove four screws.

Figure 5-1454 Remove four screws



3. Rotate the pickup assembly up (callout 1), and then out of the DCF (callout 2).

Figure 5-1455 Remove the assembly




Remove the Tray 4 prefeed sensor

Use the following procedure to remove and replace the DCF Tray 4 prefeed sensor.


1. Remove one screw.

Figure 5-1456 **Remove one screw**



2. Disconnect one connector (callout 1), and then remove one screw (callout 2) to remove the Tray 4 prefeed sensor.

Figure 5-1457 **Remove the sensor**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 5 pickup assembly

Learn about removing and replacing the dual cassette feeder (DCF) Tray 5 pickup assembly.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-172 Part information

Part number	Part description
5QK08-61010	Tray 5 pickup assembly

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1458 **Remove the cassette**




2. Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.

2. Remove four screws, and then remove the right cover.

Figure 5-1459 Remove the cover




3. Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1460 Remove the door




4. Remove the Tray 4 pickup assembly

Use the following procedure to remove and replace the DCF Tray 4 pickup assembly.


1. Disconnect one connector, and then remove two screws.

Figure 5-1461 **Disconnect connector and remove screws**




2. Remove four screws.

Figure 5-1462 **Remove four screws**



3. Rotate the pickup assembly up (callout 1), and then out of the DCF (callout 2).

Figure 5-1463 Remove the assembly




5. Remove the Tray 5 pickup assembly

Use the following procedure to remove and replace the DCF Tray 5 pickup assembly.

- Disconnect one connector, remove four screws, and then remove the Tray 5 pickup assembly.

Figure 5-1464 Remove the assembly



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 5 paper empty and stack height sensors

Learn about removing and replacing the dual cassette feeder (DCF) Tray 5 paper empty and stack height sensors.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-173 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Tray 5 paper empty sensor)
3SJ00-60110	Photo interrupter (Tray 5 paper stack height sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1465 Remove the cassette




2. Remove the Tray 4, 5 paper empty and stack height sensors

Use the following procedure to remove and replace the DCF tray paper empty and stack height sensors.

NOTE: The procedure for removing the paper empty sensor or the paper stack height sensor is the same for both sensors.


1. Locate the desired sensor to remove (on the Tray 4 pickup assembly).
   - **Callout 1**: Tray 4, 5 paper stack height sensor
   - **Callout 2**: Tray 4, 5 paper empty sensor

   Figure 5-1466 **Locate the sensor**


2. Do the following:
   - Release the hooks (callout 1).
   - Slide the sensor assembly to the left (callout 2).
   - Release the sensor.

Figure 5-1467 Release the sensor



3. Disconnect one connector to remove the sensor.

Figure 5-1468 Remove the sensor



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray 5 prefeed sensor

Learn about removing and replacing the dual cassette feeder (DCF) Tray 5 prefeed sensor.

NOTE: Remove the DCF from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-174 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Tray 5 prefeed sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1469 **Remove the cassette**




2. Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.

2. Remove four screws, and then remove the right cover.

Figure 5-1470 Remove the cover




3. Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1471 Remove the door




4. Remove the Tray 4 pickup assembly

Use the following procedure to remove and replace the DCF Tray 4 pickup assembly.


1. Disconnect one connector, and then remove two screws.

Figure 5-1472 **Disconnect connector and remove screws**




2. Remove four screws.

Figure 5-1473 **Remove four screws**



3. Rotate the pickup assembly up (callout 1), and then out of the DCF (callout 2).

Figure 5-1474 Remove the assembly




5. Remove the Tray 5 pickup assembly

Use the following procedure to remove and replace the DCF Tray 5 pickup assembly.

- Disconnect one connector, remove four screws, and then remove the Tray 5 pickup assembly.

Figure 5-1475 Remove the assembly




6. Remove the Tray 5 prefeed sensor

Use the following procedure to remove and replace the DCF Tray 5 prefeed sensor.


1. Remove one screw.

Figure 5-1476 Remove one screw



2. Disconnect one connector (callout 1), and then remove one screw (callout 2) to remove the Tray 5 prefeed sensor.

Figure 5-1477 Remove the sensor



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF feed sensor

Learn about removing and replacing the dual cassette feeder (DCF) feed sensor.

NOTE: Remove the DCF from the printer.

Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-175 Part information

Part number	Part description
0604-001490	Photo interrupter (DCF feed sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1478 **Remove the cassette**




2. Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.

2. Remove four screws, and then remove the right cover.

Figure 5-1479 Remove the cover




3. Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1480 Remove the door




4. Remove the Tray 4 pickup assembly

Use the following procedure to remove and replace the DCF Tray 4 pickup assembly.


1. Disconnect one connector, and then remove two screws.

Figure 5-1481 Disconnect connector and remove screws




2. Remove four screws.

Figure 5-1482 Remove four screws



3. Rotate the pickup assembly up (callout 1), and then out of the DCF (callout 2).

Figure 5-1483 **Remove the assembly**




5. Remove the DCF feed sensor

Use the following procedure to remove and replace the DCF feed sensor.


1. Remove two screws.

Figure 5-1484 **Remove two screws**



2. Turn the assembly over, disconnect one connector, and then remove the DCF feed sensor.

Figure 5-1485 **Remove the sensor**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

PCA and harness

Review the DCF PCA and harness removal procedures.

Removal and replacement: Tray heater

Learn about removing and replacing the DCF tray heaters.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-176 Part information

Part number	Part description
Y1G22-67901	Tray heater 110V
Y1G22-67902	Tray heater 220V

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

Figure 5-1486 **Remove the cassette**



2. Remove Tray 2 or Tray 3

Use the following procedure to remove and replace Tray 2 or Tray 3.

NOTE: Tray 2 is shown in the figure below. However, removing Tray 3 is identical to Tray 2.

1. Remove one screw.

Figure 5-1487 Remove one screw



2. Do the following:

- Slightly lift up on the front of the heater, and pull it toward the front of the printer.

⚠ CAUTION: Do not attempt to completely remove the heater. It is still attached to the printer by a wire-harness connector.

- Disconnect one connector, and then remove the heater.

Figure 5-1488 Remove the heater



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF (Tray 4, 5) PCA

Learn about removing and replacing the DCF PCA.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-177 Part information

Part number	Part description
6GW47-60001	DCF (Tray4, 5) PCA

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1489 **Remove the cover**




2. Remove the DCF PCA

Use the following procedure to remove and replace the DCF PCA.

- Disconnect all of the connectors (callout 1), remove three screws (callout 2), and then remove the DCF PCA.

Figure 5-1490 Remove the PCA



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF (Tray 4, 5) right door open switch holder assembly

Learn about removing and replacing the DCF right door open switch holder.

NOTE: This procedure describes replacing only the switch holder. To replace the right door open switch, remove and replace the *DCF Dpt door open switch and harness* (JC39-02268A).

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-178 Part information

Part number	Part description
JC90-01385A	DCF (Tray4, 5) right door open switch holder

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.

2. Remove four screws, and then remove the rear cover.

Figure 5-1491 **Remove the cover**




2. Remove the DCF right door open switch holder

Use the following procedure to remove and replace the DCF right door open switch holder.

1. Open the right door.
2. Remove two screws.


Figure 5-1492 **Remove two screws**



3. Remove one screw and then pull the switch and holder out.

TIP: Disconnect one connector (callout 1) and release the wire harness from retainers as needed to create enough wire harness slack to pull the switch-holder assembly out.


Figure 5-1493 Pull out the switch and holder



4. Release two tabs (callout 1) and then remove the switch from the holder to remove it (callout 2).

NOTE: This step is required to replace the switch holder. To replace the right door open switch, remove the *DCF Dpt door open switch and harness* (JC39-02268A).

Figure 5-1494 Remove the holder



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF IF harness

Learn about removing and replacing the DCF IF harness.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-179 Part information

Part number	Part description
JC39-02606A	DCF IF harness

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1495 **Remove the cover**




2. Remove the DCF IF harness

Use the following procedure to remove and replace the DCF IF harness.


1. Disconnect one connector on the DCF PCA.

Figure 5-1496 **Disconnect one connector**



2. Disconnect two connectors, release retainers as needed, and then remove the DCF IF harness.

Figure 5-1497 **Remove the harness**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF door open switch sensor and harness

Learn about removing and replacing the DCF door open switch and harness.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-180 Part information

Part number	Part description
JC39-02268A	DCF door open switch and harness

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1498 **Remove the cover**




2. Remove the DCF right door open switch holder

Use the following procedure to remove and replace the DCF right door open switch holder.

1. Open the right door.

2. Remove two screws.


Figure 5-1499 **Remove two screws**



3. Remove one screw and then pull the switch and holder out.

TIP: Disconnect one connector (callout 1) and release the wire harness from retainers as needed to create enough wire harness slack to pull the switch-holder assembly out.


Figure 5-1500 **Pull out the switch and holder**



4. Release two tabs (callout 1) and then remove the switch from the holder to remove it (callout 2).

NOTE: This step is required to replace the switch holder. To replace the right door open switch, remove the *DCF Dpt door open switch and harness* (JC39-02268A).

Figure 5-1501 Remove the holder




3. Remove the door open switch and harness

Use the following procedure to remove and replace the DCF door open switch and harness.

- Disconnect three connectors, release retainers as needed, and then remove the DCF door open switch and harness.

Figure 5-1502 Remove the harness



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF motor harness 2nd

Learn about removing and replacing the DCF motor harness 2nd.

NOTE: Remove the DCF from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-181 Part information

Part number	Part description
JC39-02268A	DCF motor harness 2nd

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

Figure 5-1503 Remove the cover




2. Remove the motor harness 2nd

Use the following procedure to remove and replace the DCF motor harness 2nd.

- Disconnect two connectors, release retainers as needed, and then remove the DCF motor harness 2nd.

Figure 5-1504 Remove the harness



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF sensor harness 1st

Learn about removing and replacing the DCF sensor harness 1st.

NOTE: Remove the DCF from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-182 Part information

Part number	Part description
JC39-02271A	DCF sensor harness 1st

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.

2. Remove four screws, and then remove the rear cover.

Figure 5-1505 **Remove the cover**




2. Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.
2. Remove four screws, and then remove the right cover.

Figure 5-1506 **Remove the cover**




3. Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1507 Remove the door




4. Remove the sensor harness 1st

Use the following procedure to remove and replace the DCF sensor harness 1st.


1. Disconnect one connector.

Figure 5-1508 Disconnect one connector



2. Disconnect one connector, release retainers as needed, and then remove the DCF sensor harness 1st.

Figure 5-1509 Remove the harness



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF sensor harness 2nd

Learn about removing and replacing the DCF sensor harness 2nd.

NOTE: Remove the DCF from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-183 Part information

Part number	Part description
JC39-02269A	DCF sensor harness 2nd

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.

2. Remove four screws, and then remove the rear cover.

Figure 5-1510 **Remove the cover**




2. Remove the DCF (Tray 4, 5) right cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) right cover.

1. Open the right door.
2. Remove four screws, and then remove the right cover.

Figure 5-1511 **Remove the cover**




3. Remove the DCF (Tray 4, 5) right door

Use the following procedure to remove and replace the DCF (Tray 4, 5) right door.

- Push down on the hook (callout 1), slide the pin (callout 2) as shown below, and then remove the right door.

Figure 5-1512 Remove the door




4. Remove the sensor harness 2nd

Use the following procedure to remove and replace the DCF sensor harness 2nd.


1. Disconnect one connector.

Figure 5-1513 Disconnect one connector



2. Disconnect one connector, release retainers as needed, and then remove the DCF sensor harness 2nd.

Figure 5-1514 Remove the harness



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: DCF size harness

Learn about removing and replacing the DCF size harness.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-184 Part information

Part number	Part description
JC39-02275A	DCF size harness

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


Remove the Tray 4, 5 cassette

Use the following procedure to remove and replace the DCF tray cassette.

NOTE: The procedure for removing a cassette is the same for Tray 4 or Tray 5.

- Partially pull the tray cassette out of the DCF, lift the front edge up, and then remove the cassette.

  Figure 5-1515 Remove the cassette

Remove the DCF (Tray 4, 5) rear cover

Use the following procedure to remove and replace the DCF (Tray 4, 5) rear cover.

1. Remove the Tray 4, 5 cassettes.
2. Remove four screws, and then remove the rear cover.

   Figure 5-1516 Remove the cover


   

Remove the size harness

Use the following procedure to remove and replace the DCF size harness.

1. Disconnect one connector.

Figure 5-1517 Disconnect one connector



2. Disconnect two connectors (inside the tray cavity), release retainers as needed, and then remove the DCF size harness (from the rear of the DCF).

Figure 5-1518 Remove the harness



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Output device

Learn about output device parts removal and replacement.

Stapler/stacker and (or) Booklet finisher

Learn about external finisher stapler/stacker or booklet finishers parts removal and replacement.

Cover

Review the external finisher cover removal procedures.

Removal and replacement: Front door

Learn about removing and replacing the external finisher front door.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-185 Part information

Part number	Part description
5QK09-60106	Front door

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1519 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1520 **Remove the door**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Caster cover

Learn about removing and replacing the external finisher caster cover.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-186 Part information

Part number	Part description
8GS05-40018	Caster cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-1521 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Left lower cover

Learn about removing and replacing the external finisher left lower cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-187 Part information

Part number	Part description
8GS05-60122	Left lower cover (stacker)
8GS05-60124	Left lower cover (booklet)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1522 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1523 Remove the door



Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1524 Remove three screws



2. Remove two screws, and then remove the top cover.

Figure 5-1525 **Remove the cover**




Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1526 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1527 Remove the cover




Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1528 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1529 **Remove the cover**




Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-1530 **Remove the cover**




Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-1531 Remove the cover




Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1532 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1533 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1534 Remove the cover



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Left lower cover

Learn about removing and replacing the external finisher left lower cover.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-188 Part information

Part number	Part description
5QK09-60106	Left lower cover (stacker)

Table 5-188 Part information (continued)

Part number	Part description
8GS05-60124	Left lower cover (booklet)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

Removal and replacement: Left upper cover

Learn about removing and replacing the external finisher left upper cover.

Mean time to repair: 15 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-189 Part information

Part number	Part description
8GS05-60118	Left upper cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1535 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1536 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1537 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1538 **Remove the cover**




3. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1539 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1540 Remove the cover




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1541 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1542 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-1543 **Remove the cover**




6. Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-1544 Remove the cover




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1545 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1546 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1547 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1548 **Lower the tray**



2. Remove six screws (callout 1).

Figure 5-1549 **Remove six screws**




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1550 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1551 Remove the cover



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet output tray

Learn about removing and replacing the external finisher booklet output tray.

Mean time to repair: 2 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-190 Part information

Part number	Part description
8GS05-60126	Booklet output tray

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher booklet output tray

Use the following procedure to remove and replace the external finisher booklet output tray.


1. Rotate the tray up.

Figure 5-1552 **Rotate the tray**



2. Pull the booklet output tray out and away from the finisher to remove it.

Figure 5-1553 **Remove the tray**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Top output tray

Learn about removing and replacing the external finisher top output tray.

Mean time to repair: 1 minute

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-191 Part information

Part number	Part description
5QK09-40027	Top output tray

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top output tray

Use the following procedure to remove and replace the external finisher top output tray.

1. Rotate the tray up.

Figure 5-1554 **Rotate the tray**



2. Pull the top output tray out and away from the finisher to remove it.

Figure 5-1555 **Remove the tray**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray

Learn about removing and replacing the external finisher main output tray.

Mean time to repair: 3 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-192 Part information

Part number	Part description
5QK09-40028	Main output tray

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher main output tray

Use the following procedure to remove and replace the external finisher main output tray.

- Release four tabs, and then remove the main output tray.

Figure 5-1556 **Remove the tray**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Rear cover

Learn about removing and replacing the external finisher rear cover.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-193 Part information

Part number	Part description
5QK09-40021	Rear cover

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1557 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1558 Remove the cover



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front cover

Learn about removing and replacing the external finisher front cover.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-194 Part information

Part number	Part description
5QK09-40019	Front cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1559 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1560 **Remove the door**



Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1561 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1562 **Remove the cover**




Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1563 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1564 Remove the cover



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Punch cover

Learn about removing and replacing the external finisher punch cover.

Mean time to repair: 1 minute

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-195 Part information

Part number	Part description
5QK09-40030	Punch cover

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher punch cover

Use the following procedure to remove and replace the external finisher punch cover.

- Remove two screws, and then remove the punch cover.

Figure 5-1565 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Top cover

Learn about removing and replacing the external finisher top cover.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-196 Part information

Part number	Part description
5QK09-60108	Top cover

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1566 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1567 **Remove the cover**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Top door

Learn about removing and replacing the external finisher top door.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-197 Part information

Part number	Part description
5QK09-60107	Top door

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1568 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1569 **Remove the cover**



2. Remove the external finisher top door

Use the following procedure to remove and replace the external finisher top door.

1. Remove the external finisher from the printer.


2. Remove one screw from the bracket.

Figure 5-1570 **Remove one screw**



3. Slide the top door as shown below to remove it.

Figure 5-1571 **Remove the door**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Right upper cover

Learn about removing and replacing the external finisher right upper cover.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-198 Part information

Part number	Part description
5QK09-60109	Right upper cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1572 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1573 Remove the cover




2. Remove the external finisher right upper cover

Use the following procedure to remove and replace the external finisher right upper cover.

1. Remove the external finisher from the printer.
2. Remove six screws, and then remove the right upper cover.

Figure 5-1574 Remove the cover



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front lower left cover

Learn about removing and replacing the external finisher front lower left cover.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-199 **Part information**

Part number	Part description
5QK09-40047	Front lower left cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1575 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1576 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1577 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1578 Remove the cover




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1579 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1580 Remove the cover




4. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-1581 Remove the cover



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front lower right cover

Learn about removing and replacing the external finisher front lower right cover.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-200 Part information

Part number	Part description
5QK09-40048	Front lower right cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front lower right cover

Use the following procedure to remove and replace the external finisher front lower right cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower right cover.

Figure 5-1582 Remove the cover



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Shaft hinge - door

Learn about removing and replacing the external finisher shaft hinge - door.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-201 Part information

Part number	Part description
JC66-04767A	Shaft hinge - door

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher shaft hinge - door


Use the following procedure to remove and replace the external finisher shaft hinge - door.

⚠ CAUTION: If both the upper and lower shaft hinges are removed the front door will not be attached to the finisher.

1. **Upper shaft hinge - door removal**: Release, and then remove the upper hinge pin.

   ⚠ CAUTION: When the upper shaft hinge is removed the top of the front door is not attached to the finisher. To avoid damage to the door, **do not** let the top of the door separate from the finisher.


   Figure 5-1583 **Remove the hinge pin**

2. **Lower shaft hinge - door removal** Support the door, release and remove the lower hinge pin, and then remove the front door

⚠ **CAUTION:** When the lower shaft hinge is removed the bottom of the front door is not attached to the finisher. To avoid damage to the door, **do not** let the bottom of the door separate from the finisher.

Figure 5-1584 **Remove the hinge pin**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Caster

Learn about removing and replacing the external finisher caster.

NOTE: Remove the external finisher form the printer.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-202 Part information

Part number	Part description
JC61-07452A	Caster

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-1585 **Remove the cover**



2. Remove the external finisher caster

Use the following procedure to remove and replace the external finisher caster.


⚠ WARNING! The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.

2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-1586 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-1587 Remove the caster



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Caster fix nut

Learn about removing and replacing the external finisher caster fix nut.

NOTE: Remove the external finisher form the printer.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-203 Part information

Part number	Part description
JC61-07444A	Caster fix nut

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-1588 Remove the cover



2. Remove the external finisher caster fix nut


Use the following procedure to remove and replace the external finisher caster fix nut.

1. Remove the external finisher from the printer.

2. Remove one fix nut. Repeat these steps for the remaining casters as needed.

NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-1589 Remove the nut



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet front cover

Learn about removing and replacing the external finisher booklet front cover.

NOTE: Remove the external finisher form the printer.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-204 Part information

Part number	Part description
JC90-01478B	Booklet front cover

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-1590 **Remove the cover**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Bridge unit (or) Bridge unit with PQ Diagnostics

Review the external finisher bridge unit removal procedures.

Removal and replacement: Bridge unit (or) Bridge unit with PQ Diagnostics

Learn about removing and replacing the external finisher bridge unit.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-205 **Part information**

Part number	Part description
5QK09-60110	Bridge unit
63C80-60109	Bridge unit with PQ Diagnostics

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher bridge unit

Use the following procedure to remove and replace the external finisher bridge unit.

1. Open the finisher front door.

Figure 5-1591 Open the door



2. Pull the lock straight out of the finisher to release it.

Figure 5-1592 **Release the lock**



3. Slightly separate the finisher and printer, and then disconnect two connectors (or) three connectors in case of Bridge unit with PQ Diagnostics.

Figure 5-1593 **Disconnect two connectors on front side**



Figure 5-1594 For Bridge with PQ Diagnostics, disconnect one connector on formatter.



4. Remove 1 screw.



NOTE: Bridge unit with PQ diagnostics shown. Standard bridge unit will only have one cable on left side.

5. Slide the bridge unit off of the printer to remove it.

Figure 5-1595 **Remove the unit**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Bridge door sensor

Learn about removing and replacing the external finisher bridge door sensor.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-206 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Bridge door sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher bridge unit

Use the following procedure to remove and replace the external finisher bridge unit.

1. Open the finisher front door.

Figure 5-1596 **Open the door**



2. Pull the lock straight out of the finisher to release it.

Figure 5-1597 **Release the lock**



3. Slightly separate the finisher and printer, and then disconnect two connectors (or) three connectors in case of Bridge unit with PQ Diagnostics.

Figure 5-1598 Disconnect two connectors on front side



Figure 5-1599 For Bridge with PQ Diagnostics, disconnect one connector on formatter.



4. Remove 1 screw.



NOTE: Bridge unit with PQ diagnostics shown. Standard bridge unit will only have one cable on left side.

5. Slide the bridge unit off of the printer to remove it.

Figure 5-1600 **Remove the unit**




2. Remove the external finisher bridge door sensor

Use the following procedure to remove and replace the external finisher bridge door sensor.

- Do the following:
  - Disconnect one connector (callout 1).
  - Release the hooks (callout 2).

- Slide the sensor assembly as shown below (callout 3).
- Push the senor assembly as shown (callout 4) to remove it.

Figure 5-1601 **Remove the sensor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Bridge entrance sensor

Learn about removing and replacing the external finisher bridge entrance sensor.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-207 Part information

Part number	Part description
JC32-00020A	Sensor-RP (Bridge entrance sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher bridge unit

Use the following procedure to remove and replace the external finisher bridge unit.

1. Open the finisher front door.

Figure 5-1602 **Open the door**



2. Pull the lock straight out of the finisher to release it.

Figure 5-1603 **Release the lock**



3. Slightly separate the finisher and printer, and then disconnect two connectors (or) three connectors in case of Bridge unit with PQ Diagnostics.

Figure 5-1604 Disconnect two connectors on front side



Figure 5-1605 For Bridge with PQ Diagnostics, disconnect one connector on formatter.



4. Remove 1 screw.



NOTE: Bridge unit with PQ diagnostics shown. Standard bridge unit will only have one cable on left side.

5. Slide the bridge unit off of the printer to remove it.

Figure 5-1606 **Remove the unit**




2. Remove the external finisher bridge entrance sensor

Use the following procedure to remove and replace the external finisher bridge entrance sensor.

- Do the following:
  - Disconnect one connector (callout 1).
  - Release the hooks (callout 2).

- Slide the sensor assembly as shown below (callout 3).
- Push the senor assembly as shown (callout 4) to remove it.

Figure 5-1607 Remove the sensor



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Bridge exit sensor

Learn about removing and replacing the external finisher bridge exit sensor.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-208 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Bridge exit sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher bridge unit

Use the following procedure to remove and replace the external finisher bridge unit.

1. Open the finisher front door.

Figure 5-1608 **Open the door**



2. Pull the lock straight out of the finisher to release it.

Figure 5-1609 **Release the lock**



3. Slightly separate the finisher and printer, and then disconnect two connectors (or) three connectors in case of Bridge unit with PQ Diagnostics.

Figure 5-1610 Disconnect two connectors on front side



Figure 5-1611 For Bridge with PQ Diagnostics, disconnect one connector on formatter.



4. Remove 1 screw.



NOTE: Bridge unit with PQ diagnostics shown. Standard bridge unit will only have one cable on left side.

5. Slide the bridge unit off of the printer to remove it.

Figure 5-1612 **Remove the unit**




2. Remove the external finisher bridge exit sensor

Use the following procedure to remove and replace the external finisher bridge exit sensor.


1. Remove four screws, and then remove the rear cover.

Figure 5-1613 **Remove the cover**




2. Remove four screws, and then remove the sheet-metal holder (callout 1).

Figure 5-1614 **Remove the holder**



3. Open the bridge door.

Figure 5-1615 **Open the door**




4. Remove thirteen screws, and then remove the inner cover.

Figure 5-1616 **Remove the cover**



5. Disconnect one connector, release one tab, and then remove the bridge exit sensor.

Figure 5-1617 **Remove the sensor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Bridge motor

Learn about removing and replacing the external finisher bridge motor.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-209 Part information

Part number	Part description
3SJ19-80501	Bridge motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher bridge unit

Use the following procedure to remove and replace the external finisher bridge unit.

1. Open the finisher front door.

Figure 5-1618 **Open the door**



2. Pull the lock straight out of the finisher to release it.

Figure 5-1619 **Release the lock**



3. Slightly separate the finisher and printer, and then disconnect two connectors (or) three connectors in case of Bridge unit with PQ Diagnostics.

Figure 5-1620 Disconnect two connectors on front side



Figure 5-1621 For Bridge with PQ Diagnostics, disconnect one connector on formatter.



4. Remove 1 screw.



NOTE: Bridge unit with PQ diagnostics shown. Standard bridge unit will only have one cable on left side.

5. Slide the bridge unit off of the printer to remove it.

Figure 5-1622 **Remove the unit**




2. Remove the external finisher bridge motor

Use the following procedure to remove and replace the external finisher bridge motor.


1. Remove four screws, and then remove the rear cover.

Figure 5-1623 **Remove the cover**



2. Remove two screws.

Figure 5-1624 **Remove two screws**



3. Disconnect one connector, and then remove the bridge motor..

Figure 5-1625 **Remove the motor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Entrance unit

Review the external finisher entrance unit removal procedures.

Removal and replacement: Entrance sensor

Learn about removing and replacing the external finisher entrance sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-210 Part information

Part number	Part description
JC32-00020A	Sensor-RP (Entrance sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1626 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1627 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1628 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1629 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1630 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1631 **Remove the cover**



4. Remove the front lower cover

Use the following procedure to remove and replace the front lower cover.

- If Tray 2 and Tray 3 are installed, remove them now.

5. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-1632 **Remove the nut**



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-1633 Remove the caster




6. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1634 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1635 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1636 Remove the cover




7. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1637 **Lower the tray**



2. Remove six screws (callout 1).

Figure 5-1638 **Remove six screws**




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1639 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1640 Remove the cover




8. Remove the external finisher ejector unit

Use the following procedure to remove and replace the external finisher ejector unit.

1. Remove three screws.


NOTE: Removing these screws allows the front tamper to be moved out of the way when the ejector unit is removed.

Figure 5-1641 Release the tamper



2. Remove two screws (located below the front tamper).


Figure 5-1642 Remove two screws



3. Remove three screws.

NOTE: Removing these screws allows the rear tamper to be moved out of the way when the ejector unit is removed.

Figure 5-1643 Release the tamper



4. Remove two screws (located below the rear tamper).

Figure 5-1644 Remove two screws




5. Do the following:

   a. Look inside the finisher through the stapler opening.

   b. Locate the shaft, pull down to release it (callout 1), and then slide it as shown below (callout 2) to remove it.


Figure 5-1645 Remove the shaft



6. Remove two screws, and then remove the ejector unit.

NOTE: Slightly lift up on the tampers to give the ejector unit clearance when removing it..

Figure 5-1646 Remove the unit




9. Remove the external finisher front tamper

Use the following procedure to remove and replace the external finisher front tamper.

- Disconnect three connectors, remove three screws, and then remove the front tamper.

NOTE: If the tamper unit is removed after the ejector unit to gain access to another assembly, the screws have already been removed.

Figure 5-1647 Remove the tamper




10. Remove the external finisher entrance sensor

Use the following procedure to remove and replace the external finisher entrance sensor.


1. Disconnect the connector

Figure 5-1648 Disconnect the connector



2. Do the following:
   - Disconnect one connector (callout 1).
   - Release two hooks (callout 2).
   - Slide the sensor as shown below (callout 3).
   - Remove the entrance sensor.

Figure 5-1649 Remove the sensor



11. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Entrance motor assembly

Learn about removing and replacing the external finisher entrance motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-211 Part information

Part number	Part description
8GS05-60104	Entrance motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1650 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1651 **Remove the cover**




Remove the external finisher entrance motor assembly

Use the following procedure to remove and replace the external finisher entrance motor assembly.


1. Disconnect one connector, and then remove two screws.

Figure 5-1652 **Disconnect connector and remove screws**



2. Slightly separate the entrance motor assembly from the finisher chassis, remove the belt (callout 1), and then remove the entrance motor assembly.

Figure 5-1653 **Remove the assembly**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Entrance motor

Learn about removing and replacing the external finisher entrance motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-212 Part information

Part number	Part description
3SJ19-80501	Entrance motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1654 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1655 Remove the cover




2. Remove the external finisher entrance motor assembly

Use the following procedure to remove and replace the external finisher entrance motor assembly.


1. Disconnect one connector, and then remove two screws.

Figure 5-1656 Disconnect connector and remove screws



2. Slightly separate the entrance motor assembly from the finisher chassis, remove the belt (callout 1), and then remove the entrance motor assembly.

Figure 5-1657 Remove the assembly



3. Remove the external finisher entrance motor

Use the following procedure to remove and replace the external finisher entrance motor.

- Remove two screws, and then remove the entrance motor.

Figure 5-1658 Remove the motor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Punch unit

Review the external finisher punch unit removal procedures.

Removal and replacement: Punch unit

Learn about removing and replacing the external finisher punch unit.

Mean time to repair: 5 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-213 Part information

Part number	Part description
Y1G10-67901	Punch unit (2-3 hole)
Y1G11-67901	Punch unit (2-4 hole)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher punch unit

Use the following procedure to remove and replace the external finisher punch unit.

- Disconnect two connectors, remove one screw, and then remove the punch unit.

Figure 5-1659 Remove the unit



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Tray diverter unit

Review the external finisher tray diverter unit removal procedures.

Removal and replacement: Top jam cover assembly

Learn about removing and replacing the external finisher top jam cover assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-214 Part information

Part number	Part description
JC90-01455A	Top jam cover assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1660 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1661 Remove the cover




2. Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-1662 Remove the assembly




3. Remove the external finisher top jam cover assembly

Use the following procedure to remove and replace the external finisher top jam cover assembly.


1. Remove two screws.

Figure 5-1663 Remove two screws



2. Pull the top jam cover assembly out of the finisher.

Figure 5-1664 Remove the assembly



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray diverter

Learn about removing and replacing the external finisher tray diverter.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-215 Part information

Part number	Part description
NA	Tray diverter

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


   Figure 5-1665 **Remove five screws**

2. Remove seven screws, and then remove the rear cover.

   NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1666 Remove the cover




Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-1667 Remove the assembly




Remove the external finisher top jam cover assembly

Use the following procedure to remove and replace the external finisher top jam cover assembly.


1. Remove two screws.

Figure 5-1668 Remove two screws



2. Pull the top jam cover assembly out of the finisher.

Figure 5-1669 Remove the assembly




Remove the external finisher tray diverter

Use the following procedure to remove and replace the external finisher tray diverter.

- Carefully separate the tray diverter from the top jam cover assembly to remove it.

Figure 5-1670 **Remove the diverter**



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Top door open switch

Learn about removing and replacing the external finisher top door open switch.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-216 Part information

Part number	Part description
JC39-02631A	Top door open switch

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1671 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1672 **Remove the cover**




2. Remove the external finisher top door open switch

Use the following procedure to remove and replace the external finisher top door open switch.


1. Remove one screw.

Figure 5-1673 Remove one screw



2. Separate the top door open switch from the finisher, and then disconnect three connectors to remove it.

Figure 5-1674 Remove the switch



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray diverter cam

Learn about removing and replacing the external finisher tray diverter cam.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-217 Part information

Part number	Part description
JC90-01458A	Tray diverter cam

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1675 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1676 Remove the cover



2. Remove the external finisher entrance motor

Use the following procedure to remove and replace the external finisher entrance motor.

- Remove two screws, and then remove the entrance motor.

Figure 5-1677 Remove the motor




3. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1678 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1679 **Remove the door**



4. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1680 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1681 **Remove the cover**




5. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1682 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1683 **Remove the cover**




6. Remove the external finisher tray diverter home sensor

Use the following procedure to remove and replace the external finisher tray diverter home sensor.


1. Remove the green handle.

Figure 5-1684 **Remove the handle**



2. Use a pair of tweezers to remove one e-ring (callout 1), and then remove the gear and belt (callout 2).


Figure 5-1685 **Remove the gear and belt**



3. Disconnect one connector, remove two screws, and then remove the sensor and bracket.


NOTE: If the tray diverter home sensor assembly is being removed to gain access to another part, stop now.

Figure 5-1686 Remove the sensor and bracket



4. Do the following:
   - Release the hooks (callout 1).
   - Slide the sensor assembly as shown below (callout 2).
   - Remove the tray diverter home position sensor from the bracket.

Figure 5-1687 Remove the sensor




7. Remove the external finisher tray diverter cam

Use the following procedure to remove and replace the external finisher tray diverter cam

- Carefully slide the tray diverter cam off of the shaft to remove it.

Figure 5-1688 **Remove the cam**



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray diverter home sensor

Learn about removing and replacing the external finisher tray diverter home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-218 Part information

Part number	Part description
0604-001415	Photo interrupter (Tray diverter home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1689 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1690 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1691 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1692 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1693 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1694 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1695 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1696 Remove the cover




5. Remove the external finisher tray diverter home sensor

Use the following procedure to remove and replace the external finisher tray diverter home sensor.


1. Remove the green handle.

Figure 5-1697 **Remove the handle**



2. Use a pair of tweezers to remove one e-ring (callout 1), and then remove the gear and belt (callout 2).


Figure 5-1698 **Remove the gear and belt**



3. Disconnect one connector, remove two screws, and then remove the sensor and bracket.

NOTE: If the tray diverter home sensor assembly is being removed to gain access to another part, stop now.


Figure 5-1699 Remove the sensor and bracket



4. Do the following:

   - Release the hooks (callout 1).
   - Slide the sensor assembly as shown below (callout 2).
   - Remove the tray diverter home position sensor from the bracket.

Figure 5-1700 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Top exit unit

Review the external finisher top exit unit removal procedures.

Removal and replacement: Top exit sensor

Learn about removing and replacing the external finisher top exit sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-219 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Top exit sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1701 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1702 Remove the cover




2. Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-1703 Remove the assembly




3. Remove the external finisher top jam cover assembly

Use the following procedure to remove and replace the external finisher top jam cover assembly.


1. Remove two screws.

Figure 5-1704 **Remove two screws**



2. Pull the top jam cover assembly out of the finisher.

Figure 5-1705 **Remove the assembly**




4. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1706 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1707 **Remove the door**



5. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1708 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1709 **Remove the cover**




6. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1710 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1711 **Remove the cover**




7. Remove the external finisher main exit cam motor assembly

Use the following procedure to remove and replace the external finisher main exit cam motor assembly.

- Disconnect two connectors (callout 1), remove two screws (callout 2), and then remove the main exit cam motor assembly.

Figure 5-1712 Remove the assembly




8. Remove the external finisher top lower feed assembly

Use the following procedure to remove and replace the external finisher top lower feed assembly.


1. Disconnect one connector (callout 1), remove three screws (callout 2).

Figure 5-1713 Disconnect connector and remove screws




2. Remove three screws (callout 1).

Figure 5-1714 **Remove three screws**



3. Pull the top lower feed assembly straight up and out of the finisher.

Figure 5-1715 **Remove the assembly**




9. Remove the external finisher top exit sensor

Use the following procedure to remove and replace the external finisher top exit sensor.

- Do the following:
  - Disconnect one connector (callout 1).
  - Release the hooks (callout 2).

- Slide the sensor assembly as shown below (callout 3).
- Remove the top exit sensor (callout 4).

Figure 5-1716 **Remove the sensor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Exit motor assembly

Learn about removing and replacing the external finisher exit motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-220 Part information

Part number	Part description
8GS05-60106	Exit motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1717 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1718 Remove the cover




2. Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-1719 Remove the assembly



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Exit motor

Learn about removing and replacing the external finisher exit motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-221 Part information

Part number	Part description
3SJ19-80501	Exit motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1720 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1721 **Remove the cover**




2. Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-1722 Remove the assembly



3. Remove the external finisher exit motor

Use the following procedure to remove and replace the external finisher exit motor.

- Remove two screws, and then remove the exit motor.

Figure 5-1723 Remove the motor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Top output tray unit

Review the external finisher top output tray unit removal procedures.

Removal and replacement: Top lower feed assembly

Learn about removing and replacing the external finisher top lower feed assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-222 Part information

Part number	Part description
JC90-01454A	Top lower feed assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1724 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1725 Remove the cover




2. Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-1726 Remove the assembly




3. Remove the external finisher top jam cover assembly

Use the following procedure to remove and replace the external finisher top jam cover assembly.


1. Remove two screws.

Figure 5-1727 Remove two screws



2. Pull the top jam cover assembly out of the finisher.

Figure 5-1728 Remove the assembly




4. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1729 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1730 **Remove the door**



5. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1731 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1732 **Remove the cover**




6. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1733 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1734 Remove the cover




7. Remove the external finisher main exit cam motor assembly

Use the following procedure to remove and replace the external finisher main exit cam motor assembly.

- Disconnect two connectors (callout 1), remove two screws (callout 2), and then remove the main exit cam motor assembly.

Figure 5-1735 Remove the assembly




8. Remove the external finisher top lower feed assembly

Use the following procedure to remove and replace the external finisher top lower feed assembly.


1. Disconnect one connector (callout 1), remove three screws (callout 2).

Figure 5-1736 Disconnect connector and remove screws




2. Remove three screws (callout 1).

Figure 5-1737 **Remove three screws**



3. Pull the top lower feed assembly straight up and out of the finisher.

Figure 5-1738 **Remove the assembly**



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Tray extension

Learn about removing and replacing the external finisher tray extension.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-223 Part information

Part number	Part description
5QK09-40029	Tray extension

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top output tray

Use the following procedure to remove and replace the external finisher top output tray.

1. Rotate the tray up.

Figure 5-1739 Rotate the tray



2. Pull the top output tray out and away from the finisher to remove it.

Figure 5-1740 **Remove the tray**




2. Remove the external finisher tray extension

Use the following procedure to remove and replace the external finisher tray extension.

- Release two hooks, and then slide the tray extension away from the top output tray to remove it.

Figure 5-1741 **Remove the tray extension**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Top output tray paper full sensor

Learn about removing and replacing the external finisher top output tray paper full sensor.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-224 Part information

Part number	Part description
JC82-01039A	Tray sensor kit (Top output tray paper full sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1742 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1743 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1744 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1745 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1746 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1747 Remove the cover




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1748 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1749 **Remove the cover**




5. Remove the external finisher main output tray motor drive assembly

Use the following procedure to remove and replace the external finisher main output tray motor drive assembly.

- Disconnect two connectors, remove four screws, and then remove the main output tray motor drive assembly.

Figure 5-1750 **Remove the sensor**




6. Remove the external finisher top output tray paper full sensor

Use the following procedure to remove and replace the external finisher top output tray paper full sensor.


1. Disconnect one connector, and then remove one screw.

Figure 5-1751 Disconnect connector and remove the screw



2. Disconnect one connector, and then remove one screw.

Figure 5-1752 Disconnect connector and remove the screw



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Main exit unit

Review the external finisher main exit unit removal procedures.

Removal and replacement: Main exit sensor

Learn about removing and replacing the external finisher main exit sensor.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-225 Part information

Part number	Part description
JC32-00020A	Sensor-RP (Main exit sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


   Figure 5-1753 **Remove five screws**

2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1754 Remove the cover




2. Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-1755 Remove the assembly




3. Remove the external finisher top jam cover assembly

Use the following procedure to remove and replace the external finisher top jam cover assembly.


1. Remove two screws.

Figure 5-1756 **Remove two screws**



2. Pull the top jam cover assembly out of the finisher.

Figure 5-1757 **Remove the assembly**




4. Remove the external finisher main exit cam motor assembly

Use the following procedure to remove and replace the external finisher main exit cam motor assembly.

- Disconnect two connectors (callout 1), remove two screws (callout 2), and then remove the main exit cam motor assembly.

Figure 5-1758 Remove the assembly




5. Remove the external finisher top lower feed assembly

Use the following procedure to remove and replace the external finisher top lower feed assembly.


1. Disconnect one connector (callout 1), remove three screws (callout 2).

Figure 5-1759 Disconnect connector and remove screws




2. Remove three screws (callout 1).

Figure 5-1760 **Remove three screws**



3. Pull the top lower feed assembly straight up and out of the finisher.

Figure 5-1761 **Remove the assembly**




6. Remove the external finisher main exit sensor

Use the following procedure to remove and replace the external finisher main exit sensor.

- Disconnect one connector (callout 1), and then remove the main exit sensor (callout 2).

Figure 5-1762 Remove the sensor



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main exit cam motor assembly

Learn about removing and replacing the external finisher main exit cam motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-226 Part information

Part number	Part description
JC90-01453A	Main exit cam motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1763 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1764 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1765 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1766 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1767 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1768 Remove the cover




4. Remove the external finisher main exit cam motor assembly

Use the following procedure to remove and replace the external finisher main exit cam motor assembly.

- Disconnect two connectors (callout 1), remove two screws (callout 2), and then remove the main exit cam motor assembly.

Figure 5-1769 Remove the assembly



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main exit cam home sensor

Learn about removing and replacing the external finisher main exit cam home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-227 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Main exit cam home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1770 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1771 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1772 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1773 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1774 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1775 Remove the cover




4. Remove the external finisher main exit cam motor assembly

Use the following procedure to remove and replace the external finisher main exit cam motor assembly.

- Disconnect two connectors (callout 1), remove two screws (callout 2), and then remove the main exit cam motor assembly.

Figure 5-1776 Remove the assembly




5. Remove the external finisher main exit cam home sensor

Use the following procedure to remove and replace the external finisher main exit cam home sensor.

- Do the following:
  - Release the hooks (callout 1).
  - Slide the sensor assembly as shown below (callout 2).
  - Remove the main exit cam home sensor from the bracket (callout 3).

Figure 5-1777 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main exit cam motor

Learn about removing and replacing the external finisher main exit cam motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-228 Part information

Part number	Part description
JC90-01453A	Main exit cam motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1778 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1779 **Remove the door**



Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1780 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1781 **Remove the cover**




Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1782 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1783 Remove the cover




Remove the external finisher main exit cam motor

Use the following procedure to remove and replace the external finisher main exit cam motor.

- Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the main exit cam motor.

Figure 5-1784 Remove the motor



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front door switch

Learn about removing and replacing the external finisher front door switch.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-229 Part information

Part number	Part description
JC39-02309A	Front door switch

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1785 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1786 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1787 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1788 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1789 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1790 Remove the cover



4. Remove the external finisher front door switch

Use the following procedure to remove and replace the external finisher front door switch.

1. Remove one screw, and then separate the switch and holder form the finisher.

⚠ CAUTION: Do not attempt to completely remove the switch. It is still attached by cables to the finisher.

Figure 5-1791 Separate the switch and holder form the finisher



2. Separate the switch from the holder, and then disconnect two connectors to remove the front door switch.

Figure 5-1792 Remove the switch



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Paddle unit

Review the external finisher paddle unit removal procedures.

Removal and replacement: Paddle

Learn about removing and replacing the external finisher paddle.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-230 Part information

Part number	Part description
JC90-01480A	Paddle

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1793 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1794 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1795 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1796 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1797 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1798 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1799 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1800 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-1801 Remove the cover




6. Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-1802 Remove the cover




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1803 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1804 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1805 **Remove the cover**




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1806 **Lower the tray**



2. Remove six screws (callout 1).

Figure 5-1807 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1808 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1809 **Remove the cover**




9. Remove the external finisher paddle

Use the following procedure to remove and replace the external finisher paddle.

- Pull the paddle straight out to remove it.

Figure 5-1810 **Remove the paddle**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Paddle motor assembly

Learn about removing and replacing the external finisher paddle motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-231 Part information

Part number	Part description
JC90-01461A	Paddle motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1811 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1812 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1813 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1814 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1815 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1816 **Remove the cover**




4. Remove the external finisher paddle motor assembly

Use the following procedure to remove and replace the external finisher paddle motor assembly.

- Do the following:
  a. Disconnect two connectors (callout 1).
  b. Remove two screws (callout 2).
  c. Release the wire harness from the retainers (callout 3), and then remove the paddle motor assembly.

Figure 5-1817 **Remove the assembly**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Paddle home sensor

Learn about removing and replacing the external finisher paddle home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-232 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Paddle home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1818 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1819 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1820 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1821 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1822 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1823 **Remove the cover**




4. Remove the external finisher paddle motor assembly

Use the following procedure to remove and replace the external finisher paddle motor assembly.

- Do the following:
  a. Disconnect two connectors (callout 1).
  b. Remove two screws (callout 2).
  c. Release the wire harness from the retainers (callout 3), and then remove the paddle motor assembly.

Figure 5-1824 **Remove the assembly**



5. Remove the external finisher paddle home sensory

Use the following procedure to remove and replace the external finisher paddle home sensor.


- Do the following:

  a. Release the hooks (callout 1).

  b. Slide the sensor assembly as shown below (callout 2).

  c. Remove the paddle home sensor from the bracket (callout 3).

  Figure 5-1825 **Remove the sensor**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Paddle motor

Learn about removing and replacing the external finisher paddle motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-233 Part information

Part number	Part description
JC93-01001A	Drive-motor step (Paddle motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1826 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1827 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1828 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1829 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1830 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1831 **Remove the cover**




4. Remove the external finisher paddle motor

Use the following procedure to remove and replace the external finisher paddle motor.

- Disconnect one connector, remove two screws, and then remove the paddle motor.

Figure 5-1832 **Remove the motor**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

End fence unit

Review the external finisher end fence unit removal procedures.

Removal and replacement: End fence home sensor

Learn about removing and replacing the external finisher end fence home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-234 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (End fence sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1833 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1834 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1835 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1836 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1837 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1838 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1839 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1840 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-1841 **Remove the cover**




6. Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-1842 Remove the cover




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1843 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1844 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1845 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1846 Lower the tray



2. Remove six screws (callout 1).

Figure 5-1847 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1848 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1849 Remove the cover




9. Remove the external finisher ejector unit

Use the following procedure to remove and replace the external finisher ejector unit.

1. Remove three screws.


NOTE: Removing these screws allows the front tamper to be moved out of the way when the ejector unit is removed.

Figure 5-1850 Release the tamper



2. Remove two screws (located below the front tamper).


Figure 5-1851 Remove two screws



3. Remove three screws.

NOTE: Removing these screws allows the rear tamper to be moved out of the way when the ejector unit is removed.

Figure 5-1852 Release the tamper



4. Remove two screws (located below the rear tamper).

Figure 5-1853 Remove two screws




5. Do the following:

   a. Look inside the finisher through the stapler opening.

   b. Locate the shaft, pull down to release it (callout 1), and then slide it as shown below (callout 2) to remove it.


Figure 5-1854 Remove the shaft



6. Remove two screws, and then remove the ejector unit.

NOTE: Slightly lift up on the tampers to give the ejector unit clearance when removing it..

Figure 5-1855 Remove the unit




10. Remove the external finisher front tamper

Use the following procedure to remove and replace the external finisher front tamper.

- Disconnect three connectors, remove three screws, and then remove the front tamper.

NOTE: If the tamper unit is removed after the ejector unit to gain access to another assembly, the screws have already been removed.

Figure 5-1856 Remove the tamper




11. Remove the external finisher end fence home sensory

Use the following procedure to remove and replace the external finisher end fence home sensor.

- Disconnect one connector, and then remove the end fence home sensor.

Figure 5-1857 Remove the sensor



12. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: End fence motor assembly

Learn about removing and replacing the external finisher end fence motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-235 Part information

Part number	Part description
JC90-01467A	End fence motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1858 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1859 Remove the door



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1860 Remove three screws



2. Remove two screws, and then remove the top cover.

Figure 5-1861 **Remove the cover**




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1862 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1863 Remove the cover




4. Remove the external finisher end fence motor assembly

Use the following procedure to remove and replace the external finisher end fence motor assembly.

- Disconnect one connector, remove two screws, and then remove the end fence motor assembly.

Figure 5-1864 Remove the assembly



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: End fence motor

Learn about removing and replacing the external finisher end fence motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-236 Part information

Part number	Part description
JC93-01001A	Drive-motor step (End fence motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1865 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1866 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1867 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1868 Remove the cover




3. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1869 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1870 **Remove the cover**




4. Remove the external finisher end fence motor

Use the following procedure to remove and replace the external finisher end fence motor.

- Disconnect one connector, remove two screws, and then remove the end fence motor.

Figure 5-1871 **Remove the motor**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray top of stack switch guide

Learn about removing and replacing the external finisher main output tray top of stack switch guide.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-237 Part information

Part number	Part description
8GS05-40019	Main output tray top of stack switch guide

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1872 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1873 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1874 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1875 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1876 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1877 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1878 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1879 **Remove the cover**




5. Remove the external finisher main output tray motor drive assembly

Use the following procedure to remove and replace the external finisher main output tray motor drive assembly.

- Disconnect two connectors, remove four screws, and then remove the main output tray motor drive assembly.

Figure 5-1880 **Remove the sensor**



6. Remove the external finisher paddle motor assembly

Use the following procedure to remove and replace the external finisher paddle motor assembly.


- Do the following:

  a. Disconnect two connectors (callout 1).

  b. Remove two screws (callout 2).

  c. Release the wire harness from the retainers (callout 3), and then remove the paddle motor assembly.

  Figure 5-1881 Remove the assembly


  

7. Remove the external finisher main output tray top of stack switch guide

Use the following procedure to remove and replace the external finisher main output tray top of stack switch guide.


1. Remove four screws, and then remove the frame cover.

Figure 5-1882 **Remove the cover**




2. Remove seven screws, and then remove the top output tray.

Figure 5-1883 **Remove the tray**




3. Release two hooks.

Figure 5-1884 **Release two hooks**



4. Remove the main output tray top of stack switch guide.

Figure 5-1885 **Remove the guide**



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray top of stack switch lower guide

Learn about removing and replacing the external finisher main output tray top of stack switch lower guide.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-238 Part information

Part number	Part description
8GS05-40020	Main output tray top of stack switch lower guide

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1886 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1887 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1888 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1889 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1890 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1891 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1892 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1893 Remove the cover




5. Remove the external finisher main output tray motor drive assembly

Use the following procedure to remove and replace the external finisher main output tray motor drive assembly.

- Disconnect two connectors, remove four screws, and then remove the main output tray motor drive assembly.

Figure 5-1894 Remove the sensor



6. Remove the external finisher paddle motor assembly

Use the following procedure to remove and replace the external finisher paddle motor assembly.


- Do the following:

  a. Disconnect two connectors (callout 1).

  b. Remove two screws (callout 2).

  c. Release the wire harness from the retainers (callout 3), and then remove the paddle motor assembly.

  Figure 5-1895 Remove the assembly


  

7. Remove the external finisher main output tray top of stack switch lower guide

Use the following procedure to remove and replace the external finisher main output tray top of stack switch lower guide.


1. Remove four screws, and then remove the frame cover.

Figure 5-1896 Remove the cover




2. Remove seven screws, and then remove the top output tray.

Figure 5-1897 Remove the tray




3. Release two hooks.

Figure 5-1898 **Release two hooks**



4. Remove the main output tray top of stack switch guide.

Figure 5-1899 **Remove the guide**



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Tamper unit

Review the external finisher tamper unit removal procedures.

Removal and replacement: Front tamper

Learn about removing and replacing the external finisher front tamper.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-239 Part information

Part number	Part description
JC82-00901A	Front tamper

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1900 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1901 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1902 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1903 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1904 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1905 Remove the cover




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1906 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1907 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-1908 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-1909 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-1910 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1911 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1912 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1913 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1914 Lower the tray



2. Remove six screws (callout 1).

Figure 5-1915 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1916 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1917 Remove the cover




9. Remove the external finisher front tamper

Use the following procedure to remove and replace the external finisher front tamper.

- Disconnect three connectors, remove three screws, and then remove the front tamper.

NOTE: If the tamper unit is removed after the ejector unit to gain access to another assembly, the screws have already been removed.

Figure 5-1918 Remove the tamper



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front tamper home sensor

Learn about removing and replacing the external finisher front tamper home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-240 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Front tamper home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1919 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1920 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1921 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1922 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1923 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1924 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1925 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1926 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-1927 **Remove the cover**




6. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1928 **Remove four screws**




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1929 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1930 Remove the cover




7. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1931 **Lower the tray**



2. Remove six screws (callout 1).

Figure 5-1932 **Remove six screws**




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1933 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1934 Remove the cover




8. Remove the external finisher front tamper

Use the following procedure to remove and replace the external finisher front tamper.

- Disconnect three connectors, remove three screws, and then remove the front tamper.

NOTE: If the tamper unit is removed after the ejector unit to gain access to another assembly, the screws have already been removed.

Figure 5-1935 Remove the tamper




9. Remove the external finisher front tamper home sensor

Use the following procedure to remove and replace the external finisher front tamper home sensor.


1. Remove one screw, and then remove the tamper.

Figure 5-1936 Remove the tamper



2. Remove one screw, and then remove the bracket.

Figure 5-1937 **Remove the bracket**




3. Do the following:

   a. Release the hooks (callout 1).

   b. Slide the sensor assembly as shown below (callout 2).

   c. Remove the tamper home sensor from the bracket.

Figure 5-1938 **Remove the sensor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Front tamper motor

Learn about removing and replacing the external finisher front tamper motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-241 Part information

Part number	Part description
JC93-01001A	Drive-motor step (Front tamper motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1939 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1940 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1941 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1942 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1943 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1944 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1945 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-1946 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-1947 **Remove the cover**




6. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1948 **Remove four screws**




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1949 **Release the cover**



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1950 Remove the cover




7. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1951 Lower the tray



2. Remove six screws (callout 1).

Figure 5-1952 **Remove six screws**




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1953 **Release the cover**



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1954 Remove the cover




8. Remove the external finisher front tamper

Use the following procedure to remove and replace the external finisher front tamper.

- Disconnect three connectors, remove three screws, and then remove the front tamper.

NOTE: If the tamper unit is removed after the ejector unit to gain access to another assembly, the screws have already been removed.

Figure 5-1955 Remove the tamper




9. Remove the external finisher front tamper motor

Use the following procedure to remove and replace the external finisher front tamper motor.

- Remove two screws, and then remove the front tamper motor.

Figure 5-1956 **Remove the motor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Rear tamper

Learn about removing and replacing the external finisher rear tamper.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-242 Part information

Part number	Part description
JC82-00898A	Rear tamper

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1957 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1958 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1959 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1960 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1961 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1962 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1963 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1964 Remove the cover




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-1965 **Remove the cover**




6. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1966 **Remove four screws**




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1967 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1968 Remove the cover




7. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1969 Lower the tray



2. Remove six screws (callout 1).

Figure 5-1970 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1971 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1972 Remove the cover




8. Remove the external finisher rear tamper

Use the following procedure to remove and replace the external finisher rear tamper.

- Disconnect two connectors, remove three screws, and then remove the rear tamper.

Figure 5-1973 **Remove the tamper**



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Rear tamper home sensor

Learn about removing and replacing the external finisher rear tamper home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-243 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Rear tamper home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1974 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1975 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1976 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1977 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1978 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1979 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1980 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-1981 Remove the cover




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-1982 **Remove the cover**




6. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-1983 **Remove four screws**




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-1984 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-1985 Remove the cover




7. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-1986 Lower the tray



2. Remove six screws (callout 1).

Figure 5-1987 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-1988 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-1989 Remove the cover




8. Remove the external finisher front tamper home sensor

Use the following procedure to remove and replace the external finisher front tamper home sensor.


1. Remove one screw, and then remove the tamper.

Figure 5-1990 **Remove the tamper**



2. Remove one screw, and then remove the bracket.

Figure 5-1991 **Remove the bracket**




3. Do the following:

   a. Release the hooks (callout 1).

   b. Slide the sensor assembly as shown below (callout 2).

   c. Remove the tamper home sensor from the bracket.

Figure 5-1992 Remove the sensor



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Rear tamper motor

Learn about removing and replacing the external finisher rear tamper motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-244 Part information

Part number	Part description
JC93-01001A	Drive-motor step (Rear tamper motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-1993 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-1994 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-1995 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-1996 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-1997 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-1998 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-1999 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2000 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-2001 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2002 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2003 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2004 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2005 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2006 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2007 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2008 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2009 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2010 **Remove the cover**




9. Remove the external finisher rear tamper

Use the following procedure to remove and replace the external finisher rear tamper.

- Disconnect two connectors, remove three screws, and then remove the rear tamper.

Figure 5-2011 **Remove the tamper**




10. Remove the external finisher front tamper motor

Use the following procedure to remove and replace the external finisher front tamper motor.

- Remove two screws, and then remove the front tamper motor.

Figure 5-2012 **Remove the motor**



11. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Stapler unit

Review the external finisher stapler unit removal procedures.

Removal and replacement: Stapler unit

Learn about removing and replacing the external finisher stapler unit.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-245 Part information

Part number	Part description
JC82-00894A	Stapler unit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2013 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2014 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2015 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2016 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2017 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2018 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2019 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2020 **Remove the cover**




5. Remove the external finisher stapler unit

Use the following procedure to remove and replace the external finisher stapler unit.


1. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2021 **Disconnect connector and remove screws**



2. Disconnect three connectors (callout 1), remove two screws (callout 2), and then remove the stapler unit.

Figure 5-2022 **Remove the unit**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Staple cartridge

Learn about removing and replacing the external finisher staple cartridge.

Mean time to repair: 1 minute

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-246 Part information

Part number	Part description
JC81-09882B	Staple cartridge

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher staple unit

Use the following procedure to remove and replace the external finisher staple unit.

- Grasp the blue handle, and then pull the staple cartridge straight out of the finisher to remove it.

Figure 5-2023 **Remove the cartridge**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Stapler front sensor

Learn about removing and replacing the external finisher stapler front sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 25 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-247 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Stapler front sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2024 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2025 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2026 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2027 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2028 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2029 Remove the cover




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2030 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-2031 Remove the cover




5. Remove the external finisher stapler unit

Use the following procedure to remove and replace the external finisher stapler unit.


1. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2032 Disconnect connector and remove screws



2. Disconnect three connectors (callout 1), remove two screws (callout 2), and then remove the stapler unit.

Figure 5-2033 **Remove the unit**




6. Remove the external finisher stapler front sensor

Use the following procedure to remove and replace the external finisher stapler front sensor.

- Do the following:
  - Disconnect one connector (callout 1).
  - Release the hooks (callout 2).
  - Slide the sensor assembly as shown below (callout 3).
  - Remove the stapler front sensor.

Figure 5-2034 Remove the sensor



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Stapler mid-front and mid-rear sensors

Learn about removing and replacing the external finisher stapler mid-front and mid-rear sensors.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-248 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Stapler mid-front sensor)
3SJ00-60110	Photo interrupter (Stapler mid-rear sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2035 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2036 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2037 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2038 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2039 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2040 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2041 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2042 **Remove the cover**




5. Remove the external finisher stapler unit

Use the following procedure to remove and replace the external finisher stapler unit.


1. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2043 **Disconnect connector and remove screws**



2. Disconnect three connectors (callout 1), remove two screws (callout 2), and then remove the stapler unit.

Figure 5-2044 **Remove the unit**



6. Remove the external finisher stapler mid-front and mid-rear sensors


Use the following procedure to remove and replace the external finisher stapler mid-front and mid-rear sensors.

1. Locate the desired sensor.

   - **Callout 1**: Mid-front sensor

- **Callout 2**: Mid-rear sensor


Figure 5-2045 **Locate the sensors**



2. Do the following:
   - Disconnect one connector (callout 1).
   - Release the hooks (callout 2).
   - Slide the sensor assembly as shown below (callout 3).
   - Remove the stapler mid-front sensor.

   NOTE: Repeat this step to remove the stapler mid-rear sensor if necessary.

Figure 5-2046 **Remove the sensor**



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Manual staple sensor

Learn about removing and replacing the external finisher manual staple sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-249 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Stapler manual staple sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2047 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2048 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2049 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2050 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2051 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2052 Remove the cover




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2053 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-2054 Remove the cover




5. Remove the external finisher manual staple sensor

Use the following procedure to remove and replace the external finisher manual staple sensor.

- Disconnect one connector (callout 1), and then remove the manual staple sensor (callout 2).

Figure 5-2055 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Stapler position motor

Learn about removing and replacing the external finisher stapler position motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 25 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-250 **Part information**

Part number	Part description
JC31-00163A	Motor, step (Stapler position motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


   Figure 5-2056 **Remove five screws**

2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2057 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2058 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2059 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2060 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2061 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2062 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2063 Remove the cover




5. Remove the external finisher stapler unit

Use the following procedure to remove and replace the external finisher stapler unit.


1. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2064 Disconnect connector and remove screws



2. Disconnect three connectors (callout 1), remove two screws (callout 2), and then remove the stapler unit.

Figure 5-2065 Remove the unit




6. Remove the external finisher stapler position motor

Use the following procedure to remove and replace the external finisher stapler position motor.

- Remove two screws (callout 1), release the belt (callout 2), and then remove the stapler position motor.

Figure 5-2066 Remove the motor



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Ejector unit

Review the external finisher ejector unit removal procedures.

Removal and replacement: Ejector unit

Learn about removing and replacing the external finisher ejector unit.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-251 Part information

Part number	Part description
JC90-01802A	Ejector unit

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2067 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2068 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2069 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2070 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2071 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2072 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2073 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2074 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-2075 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2076 **Remove the nut**



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2077 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2078 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2079 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2080 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2081 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2082 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2083 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2084 Remove the cover




9. Remove the external finisher ejector unit

Use the following procedure to remove and replace the external finisher ejector unit.

1. Remove three screws.


NOTE: Removing these screws allows the front tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2085 Release the tamper



2. Remove two screws (located below the front tamper).


Figure 5-2086 Remove two screws



3. Remove three screws.

NOTE: Removing these screws allows the rear tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2087 Release the tamper



4. Remove two screws (located below the rear tamper).

Figure 5-2088 Remove two screws




5. Do the following:

   a. Look inside the finisher through the stapler opening.

   b. Locate the shaft, pull down to release it (callout 1), and then slide it as shown below (callout 2) to remove it.


Figure 5-2089 Remove the shaft



6. Remove two screws, and then remove the ejector unit.

NOTE: Slightly lift up on the tampers to give the ejector unit clearance when removing it..

Figure 5-2090 Remove the unit



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Ejector sensor

Learn about removing and replacing the external finisher ejector sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-252 Part information

Part number	Part description
JC32-00020A	Sensor-RP (Ejector sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2091 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2092 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2093 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2094 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2095 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2096 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2097 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2098 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-2099 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2100 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2101 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2102 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2103 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2104 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2105 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2106 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2107 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2108 Remove the cover




9. Remove the external finisher ejector unit

Use the following procedure to remove and replace the external finisher ejector unit.

1. Remove three screws.


NOTE: Removing these screws allows the front tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2109 Release the tamper



2. Remove two screws (located below the front tamper).


Figure 5-2110 Remove two screws



3. Remove three screws.

NOTE: Removing these screws allows the rear tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2111 Release the tamper



4. Remove two screws (located below the rear tamper).

Figure 5-2112 Remove two screws




5. Do the following:

   a. Look inside the finisher through the stapler opening.

   b. Locate the shaft, pull down to release it (callout 1), and then slide it as shown below (callout 2) to remove it.


Figure 5-2113 Remove the shaft



6. Remove two screws, and then remove the ejector unit.

NOTE: Slightly lift up on the tampers to give the ejector unit clearance when removing it..

Figure 5-2114 Remove the unit




10. Remove the external finisher ejector sensor

Use the following procedure to remove and replace the external finisher ejector sensor.

1. Remove the ejector sensor cover.


Figure 5-2115 Release the cover



2. Carefully separate the ejector sensor from the ejector unit.


⚠ CAUTION: Do not attempt to completely remove the sensor. It is still attached to the ejector unit by a wire harness.

Figure 5-2116 Release the sensor



3. Disconnect one connector, and then remove the ejector sensor.

Figure 5-2117 Remove the sensor



11. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Ejector 1 home sensor

Learn about removing and replacing the external finisher ejector 1 home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-253 Part information

Part number	Part description
0604-001415	Photo interrupter (Ejector 1 home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2118 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2119 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2120 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2121 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2122 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2123 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2124 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2125 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-2126 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2127 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2128 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2129 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2130 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2131 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2132 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2133 **Remove six screws**




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2134 **Release the cover**



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2135 **Remove the cover**




9. Remove the external finisher ejector unit

Use the following procedure to remove and replace the external finisher ejector unit.

1. Remove three screws.


NOTE: Removing these screws allows the front tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2136 **Release the tamper**



2. Remove two screws (located below the front tamper).


Figure 5-2137 Remove two screws



3. Remove three screws.

NOTE: Removing these screws allows the rear tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2138 Release the tamper



4. Remove two screws (located below the rear tamper).

Figure 5-2139 **Remove two screws**




5. Do the following:

   a. Look inside the finisher through the stapler opening.

   b. Locate the shaft, pull down to release it (callout 1), and then slide it as shown below (callout 2) to remove it.


Figure 5-2140 **Remove the shaft**



6. Remove two screws, and then remove the ejector unit.

NOTE: Slightly lift up on the tampers to give the ejector unit clearance when removing it..

Figure 5-2141 Remove the unit




10. Remove the external finisher ejector 1 home sensor

Use the following procedure to remove and replace the external finisher ejector 1 home sensor.

- Do the following:
  a. Disconnect one connector (callout 1).
  b. Release the hook (callout 2).
  c. Remove the ejector 1 home sensor (callout 3).

Figure 5-2142 Remove the sensor



11. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Ejector 1 motor sensor

Learn about removing and replacing the external finisher ejector 1 motor sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-254 Part information

Part number	Part description
0604-001415	Photo interrupter (Ejector 1 motor sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2143 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2144 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2145 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2146 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2147 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2148 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2149 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2150 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-2151 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2152 **Remove the nut**



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2153 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2154 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2155 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2156 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2157 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2158 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2159 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2160 Remove the cover




9. Remove the external finisher ejector unit

Use the following procedure to remove and replace the external finisher ejector unit.

1. Remove three screws.


NOTE: Removing these screws allows the front tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2161 Release the tamper



2. Remove two screws (located below the front tamper).


Figure 5-2162 Remove two screws



3. Remove three screws.

NOTE: Removing these screws allows the rear tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2163 Release the tamper



4. Remove two screws (located below the rear tamper).

Figure 5-2164 Remove two screws




5. Do the following:

   a. Look inside the finisher through the stapler opening.

   b. Locate the shaft, pull down to release it (callout 1), and then slide it as shown below (callout 2) to remove it.


Figure 5-2165 Remove the shaft



6. Remove two screws, and then remove the ejector unit.

NOTE: Slightly lift up on the tampers to give the ejector unit clearance when removing it..

Figure 5-2166 Remove the unit



10. Remove the external finisher ejector 1 motor sensor


Use the following procedure to remove and replace the external finisher ejector 1 motor sensor.

- Do the following:
  a. Disconnect one connector (callout 1).
  b. Release the hooks (callout 2).

c. Slide the senor as shown below (callout 3)

d. Remove the ejector 1 motor sensor.

Figure 5-2167 Remove the sensor



11. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Ejector 2 motor sensor

Learn about removing and replacing the external finisher ejector 2 motor sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Difficult

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-255 Part information

Part number	Part description
0604-001415	Photo interrupter (Ejector 2 motor sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2168 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2169 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2170 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2171 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2172 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2173 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2174 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2175 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-2176 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2177 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2178 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2179 **Remove four screws**




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2180 **Release the cover**



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2181 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2182 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2183 **Remove six screws**




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2184 **Release the cover**



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2185 Remove the cover




9. Remove the external finisher ejector unit

Use the following procedure to remove and replace the external finisher ejector unit.

1. Remove three screws.


NOTE: Removing these screws allows the front tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2186 Release the tamper



2. Remove two screws (located below the front tamper).


Figure 5-2187 **Remove two screws**



3. Remove three screws.

NOTE: Removing these screws allows the rear tamper to be moved out of the way when the ejector unit is removed.

Figure 5-2188 **Release the tamper**



4. Remove two screws (located below the rear tamper).

Figure 5-2189 **Remove two screws**




5. Do the following:

   a. Look inside the finisher through the stapler opening.

   b. Locate the shaft, pull down to release it (callout 1), and then slide it as shown below (callout 2) to remove it.


Figure 5-2190 **Remove the shaft**



6. Remove two screws, and then remove the ejector unit.

NOTE: Slightly lift up on the tampers to give the ejector unit clearance when removing it..

Figure 5-2191 Remove the unit




10. Remove the external finisher ejector 2 motor sensor

Use the following procedure to remove and replace the external finisher ejector 2 motor sensor.

- Do the following:
  a. Disconnect one connector (callout 1).
  b. Release the hooks (callout 2).
  c. Slide the senor as shown below (callout 3)
  d. Remove the ejector 2 motor sensor.

Figure 5-2192 Remove the sensor



11. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Main output tray unit

Review the external finisher main output tray unit removal procedures.

Removal and replacement: Main output tray

Learn about removing and replacing the external finisher main output tray.

Mean time to repair: 3 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-256 Part information

Part number	Part description
5QK09-40028	Main output tray

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher main output tray

Use the following procedure to remove and replace the external finisher main output tray.

- Release four hooks, and then remove the main output tray.

Figure 5-2193 Remove the tray



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray top of stack sensor

Learn about removing and replacing the external finisher main output tray top of stack sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-257 Part information

Part number	Part description
1404-001417	Tray sensor kit (Main output tray top of stack sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


   Figure 5-2194 Remove five screws

2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2195 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2196 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2197 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2198 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2199 Remove the cover




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2200 Remove the knob



2. Remove five screws, and then remove the front cover.

Figure 5-2201 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-2202 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2203 **Remove the nut**



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2204 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2205 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2206 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2207 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2208 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2209 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2210 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2211 Remove the cover




9. Remove the external finisher main output tray top of stack sensor

Use the following procedure to remove and replace the external finisher main output tray top of stack sensor.

- Release two hooks, and then remove the main output tray top of stack sensor.

Figure 5-2212 **Remove the sensor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray lower limit sensor

Learn about removing and replacing the external finisher main output tray lower limit sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-258 Part information

Part number	Part description
0604-001415	Photo interrupter (Main output tray lower limit sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2213 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2214 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2215 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2216 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2217 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2218 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2219 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2220 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-2221 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2222 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2223 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2224 **Remove four screws**




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2225 **Release the cover**



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2226 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2227 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2228 **Remove six screws**




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2229 **Release the cover**



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2230 Remove the cover




9. Remove the external finisher main output tray lower limit sensor

Use the following procedure to remove and replace the external finisher main output tray lower limit sensor.

- Disconnect one connector (callout 1), release one hook, and then remove the main output tray lower limit sensor.

Figure 5-2231 Remove the sensor



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray motor sensor

Learn about removing and replacing the external finisher main output tray motor sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-259 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Main output tray motor sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2232 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2233 Remove the cover




2. Remove the external finisher main output tray motor sensor

Use the following procedure to remove and replace the external finisher main output tray motor sensor.

- Do the following:
  a. Disconnect one connector (callout 1).
  b. Release the hooks (callout 2).
  c. Slide the senor as shown below (callout 3)
  d. Remove the main output tray motor sensor (callout 4).

Figure 5-2234 Remove the sensor



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray motor drive assembly

Learn about removing and replacing the external finisher main output tray motor drive assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-260 Part information

Part number	Part description
JC90-01415B	Main output tray motor drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2235 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2236 Remove the cover




2. Remove the external finisher main output tray motor drive assembly

Use the following procedure to remove and replace the external finisher main output tray motor drive assembly.

- Disconnect two connectors, remove four screws, and then remove the main output tray motor drive assembly.

Figure 5-2237 Remove the sensor



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Main output tray top of stack switch

Learn about removing and replacing the external finisher main output tray top of stack switch.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-261 Part information

Part number	Part description
JC82-01039A	Tray sensor kit (Main output tray top of stack switch)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2238 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2239 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2240 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2241 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2242 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2243 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2244 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2245 Remove the cover




5. Remove the external finisher main output tray motor drive assembly

Use the following procedure to remove and replace the external finisher main output tray motor drive assembly.

- Disconnect two connectors, remove four screws, and then remove the main output tray motor drive assembly.

Figure 5-2246 Remove the sensor



6. Remove the external finisher paddle motor assembly

Use the following procedure to remove and replace the external finisher paddle motor assembly.


- Do the following:

  a. Disconnect two connectors (callout 1).

  b. Remove two screws (callout 2).

  c. Release the wire harness from the retainers (callout 3), and then remove the paddle motor assembly.

  Figure 5-2247 Remove the assembly


  

7. Remove the external finisher main output tray top of stack switch

Use the following procedure to remove and replace the external finisher main output tray top of stack switch.


1. Remove four screws, and then remove the frame cover.

Figure 5-2248 **Remove the cover**




2. Remove seven screws, and then remove the top output tray.

Figure 5-2249 **Remove the tray**



3. Release two hooks.


Figure 5-2250 **Release two hooks**



4. Release one hook, and then separate the senor from the assembly.

⚠ **CAUTION:** Do not attempt to completely remove the switch. It is still attached to the finisher by a wire harness and connector.


Figure 5-2251 **Release the sensor**



5. Disconnect one connector, and then remove the main output tray top of stack switch.

NOTE: Release the switch wire harness from the retainers as needed to remove the switch.

Figure 5-2252 Remove the switch



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Paper holding unit

Review the external finisher paper holding unit removal procedures.

Removal and replacement: Front and rear paper holding sensor

Learn about removing and replacing the external finisher front and rear paper holding sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-262 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Front paper holding sensor)
3SJ00-60110	Photo interrupter (Rear paper holding sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2253 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2254 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2255 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2256 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2257 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2258 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2259 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2260 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-2261 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2262 Remove the nut



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2263 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2264 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2265 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2266 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2267 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2268 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2269 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2270 **Remove the cover**




9. Remove the external finisher front and rear paper holding sensor

Use the following procedure to remove and replace the external finisher front and rear paper holding sensor.

1. Locate the desired sensor.

   - **Callout 1**: Front paper holding sensor
   - **Callout 1**: Rear paper holding sensor

Figure 5-2271 **Locate the sensor**




2. Do the following:

   - Disconnect one connector (callout 1).
   - Release two hooks (callout 2).
   - Slide the sensor as shown below (callout 3).
   - Remove the front paper holding sensor.

NOTE: Repeat this step to remove the rear paper holding sensor if necessary

Figure 5-2272 Remove the sensor



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Paper holding home sensor

Learn about removing and replacing the external finisher paper holding home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-263 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Paper holding home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2273 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2274 Remove the cover




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2275 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2276 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2277 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2278 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2279 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2280 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-2281 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2282 **Remove the nut**



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2283 Remove the caster




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2284 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2285 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2286 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2287 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2288 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2289 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2290 Remove the cover




9. Remove the external finisher paper holding home sensor

Use the following procedure to remove and replace the external finisher paper holding home sensor.

- Do the following:
  - Disconnect one connector (callout 1).
  - Release two hooks (callout 2).
  - Slide the sensor as shown below (callout 3).

- Remove the paper holding home sensor.

Figure 5-2291 **Remove the sensor**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Paper holding motor drive assembly

Learn about removing and replacing the external finisher paper holding motor drive assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-264 Part information

Part number	Part description
JC90-01414A	Paper holding motor drive assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2292 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2293 **Remove the cover**




2. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2294 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2295 **Remove the door**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2296 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2297 **Remove the cover**




4. Remove the external finisher front cover

Use the following procedure to remove and replace the external finisher front cover.


1. Release one tab (callout 1), and then pull the jam-access knob away from the finisher to remove it.

Figure 5-2298 **Remove the knob**



2. Remove five screws, and then remove the front cover.

Figure 5-2299 **Remove the cover**




5. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.

2. Remove three screws, and then remove the front lower left cover.

Figure 5-2300 **Remove the cover**



6. Remove the external finisher caster


Use the following procedure to remove and replace the external finisher caster.

⚠ **WARNING!** The external finisher is not stable when one or more casters are removed and can easily tip over. To avoid personal injury or damage to the finisher, make sure to fully support the finisher when removing a caster.

1. Remove the external finisher from the printer.
2. Remove one fix nut.


NOTE: Use a 12mm spanner wrench to remove the nut.

Figure 5-2301 **Remove the nut**



3. Rotate the caster as shown below to remove it. Repeat these steps for the remaining casters as needed.

Figure 5-2302 **Remove the caster**




7. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2303 Remove four screws




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2304 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2305 Remove the cover




8. Remove the external finisher left upper cover

Use the following procedure to remove and replace the external finisher left upper cover.


1. Bring the main output tray down by positioning the shaft of a screwdriver on the clutch (callout 1) and gently pressing to the right to release the clutch. Hold the clutch in the released position and lower the tray (callout 2) to the lowest position.

Figure 5-2306 Lower the tray



2. Remove six screws (callout 1).

Figure 5-2307 Remove six screws




3. Rotate the lower edge of the cover away from the finisher (callout 1), and then slide the cover down (callout 2) to release it from two tabs (callout 3).

CAUTION: The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the two tabs (callout 3) when reinstalling it.

Figure 5-2308 Release the cover



4. Disconnect one connector (callout 1), and then remove the left upper cover.

Figure 5-2309 Remove the cover




9. Remove the external finisher paper holding motor drive assembly

Use the following procedure to remove and replace the external finisher paper holding motor drive assembly.


1. Remove two screws.

Figure 5-2310 Remove two screws



2. Disconnect one connector, release the wire harness from the retainer. and then remove the paper holding motor drive assembly.

Figure 5-2311 Remove the assembly



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Buffer unit

Review the external finisher buffer unit removal procedures.

Removal and replacement: Buffer solenoid assembly

Learn about removing and replacing the external finisher buffer solenoid assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-265 Part information

Part number	Part description
JC90-01675A	Buffer solenoid assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2312 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2313 **Remove the cover**




2. Remove the external finisher right upper cover

Use the following procedure to remove and replace the external finisher right upper cover.

1. Remove the external finisher from the printer.

2. Remove six screws, and then remove the right upper cover.

Figure 5-2314 **Remove the cover**




3. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2315 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2316 Remove the cover




4. Remove the external finisher exit motor assembly

Use the following procedure to remove and replace the external finisher exit motor assembly.

- Disconnect one connector, remove two screws, and then remove the exit motor assembly.

Figure 5-2317 Remove the assembly




5. Remove the external finisher top jam cover assembly

Use the following procedure to remove and replace the external finisher top jam cover assembly.


1. Remove two screws.

Figure 5-2318 **Remove two screws**



2. Pull the top jam cover assembly out of the finisher.

Figure 5-2319 **Remove the assembly**




6. Remove the external finisher buffer solenoid assembly

Use the following procedure to remove and replace the external finisher buffer solenoid assembly.

1. Remove two screws.


Figure 5-2320 Remove two screws



2. Disconnect one connector, and then remove the buffer solenoid assembly.

NOTE: Release the wire harness as necessary to remove the solenoid assembly.

Figure 5-2321 Remove the assembly



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Buffer motor

Learn about removing and replacing the external finisher buffer motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-266 Part information

Part number	Part description
JC93-01152A	Drive-motor step (Buffer motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2322 Remove three screws



2. Remove two screws, and then remove the top cover.

Figure 5-2323 **Remove the cover**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2324 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2325 Remove the cover




3. Remove the external finisher buffer motor

Use the following procedure to remove and replace the external finisher buffer motor.


1. Remove two screws.

Figure 5-2326 Remove two screws



2. Disconnect one connector, and then remove the buffer motor.

Figure 5-2327 **Remove the motor**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Booklet finisher (only)

Learn about booklet finisher (only) parts removal and replacement.

Booklet maker

Review the booklet finisher booklet maker removal procedures.

Removal and replacement: Booklet maker

Learn about removing and replacing the booklet finisher booklet maker.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-267 Part information

Part number	Part description
5QK09-60104	Booklet maker

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

   Figure 5-2328 **Remove the hinge pin**

2. Support the door, release and remove the lower hinge pin, and then remove the front door

   Figure 5-2329 **Remove the door**


   

Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2330 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2331 **Remove the cover**



Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2332 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2333 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2334 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2335 Release the alignment pin




5. Slide the right rail toward the finisher.

Figure 5-2336 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2337 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2338 Remove the booklet maker



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2339 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2340 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2341 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2342 Attach the rail



Removal and replacement: Harness guide

Learn about removing and replacing the booklet finisher harness guide.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-268 Part information

Part number	Part description
JC90-01477A	Harness guide

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2343 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2344 Remove the door




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2345 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2346 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2347 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2348 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2349 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2350 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2351 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2352 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2353 Remove the booklet maker




4. Remove the booklet finisher PCA

Use the following procedure to remove and replace the booklet finisher PCA.


1. Remove two screws (callout 1).

Figure 5-2354 Remove two screws




2. Remove one screw (callout 1).

Figure 5-2355 Remove one screw



3. Disconnect all of the connectors, remove four screws (callout 1), and then remove the booklet finisher PCA.

Figure 5-2356 Remove the PCA




5. Remove the booklet finisher harness guide

Use the following procedure to remove and replace the booklet finisher harness guide.


1. Remove four screws.

Figure 5-2357 Remove four screws



2. Release twelve retainers, and then remove the harness guide.

Figure 5-2358 **Remove the guide**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2359 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2360 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2361 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2362 Attach the rail



Booklet entrance unit

Review the booklet finisher booklet entrance unit removal procedures.

Removal and replacement: Booklet entrance unit

Learn about removing and replacing the booklet finisher entrance unit.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-269 Part information

Part number	Part description
6GW51-60102	Booklet entrance unit

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2363 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2364 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2365 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2366 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2367 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2368 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2369 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2370 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2371 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2372 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2373 Remove the booklet maker



4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2374 **Remove the cover**




5. Remove the booklet finisher booklet entrance unit

Use the following procedure to remove and replace the booklet finisher entrance unit.


1. Remove two screws.

Figure 5-2375 **Remove two screws**




2. Remove two screws.

Figure 5-2376 **Remove two screws**



3. Disconnect one connector.


Figure 5-2377 **Disconnect one connector**



4. Remove the booklet entrance unit.


⚠ CAUTION: The spring and holder on the entrance unit are not captive. Do not lose them when handling the unit.

Figure 5-2378 Remove the unit



5. **Reinstall step**: Make sure that the spring on the unit is correctly positioned on the chassis of the booklet maker.

Figure 5-2379 Reinstall the unit



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2380 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2381 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2382 **Check rail alignment (2 of 2)**



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2383 **Attach the rail**



Removal and replacement: Booklet entrance sensor

Learn about removing and replacing the booklet finisher entrance sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-270 Part information

Part number	Part description
0604-001415	Photo interrupter (Booklet entrance sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2384 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2385 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2386 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2387 Remove the cover



3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2388 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2389 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2390 **Disconnect connector and remove the screw**




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2391 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2392 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2393 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2394 Remove the booklet maker




4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2395 Remove the cover




5. Remove the booklet finisher booklet entrance unit

Use the following procedure to remove and replace the booklet finisher entrance unit.


1. Remove two screws.

Figure 5-2396 **Remove two screws**




2. Remove two screws.

Figure 5-2397 **Remove two screws**



3. Disconnect one connector.


Figure 5-2398 Disconnect one connector



4. Remove the booklet entrance unit.


⚠ CAUTION: The spring and holder on the entrance unit are not captive. Do not lose them when handling the unit.

Figure 5-2399 Remove the unit



5. **Reinstall step**: Make sure that the spring on the unit is correctly positioned on the chassis of the booklet maker.

Figure 5-2400 **Reinstall the unit**



6. Remove the booklet finisher booklet entrance sensor

Use the following procedure to remove and replace the booklet finisher entrance sensor.


1. Remove three screws, and then remove the entrance actuator cover.

Figure 5-2401 **Remove the cover**



2. Disconnect one connector (callout 1), release one tab (callout 2), and then remove the booklet entrance sensor (callout 3).

Figure 5-2402 Remove the sensor



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


8. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2403 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2404 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2405 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2406 Attach the rail



Removal and replacement: Booklet entrance-presser motor assembly

Learn about removing and replacing the booklet finisher entrance-presser motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-271 Part information

Part number	Part description
JC90-01425A	Booklet entrance-presser motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2407 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2408 **Remove the door**




2. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2409 Remove the cover




3. Remove the booklet finisher booklet entrance-presser motor assembly

Use the following procedure to remove and replace the booklet finisher entrance-presser motor assembly.

- Disconnect one connector, remove two screws, and then remove the booklet entrance-presser motor assembly.

Figure 5-2410 Remove the assembly



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet entrance motor

Learn about removing and replacing the booklet finisher entrance motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 5 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-272 Part information

Part number	Part description
JC93-01152A	Drive-motor step (Booklet entrance motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2411 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2412 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2413 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2414 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2415 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2416 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2417 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2418 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2419 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2420 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2421 Remove the booklet maker



4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2422 **Remove the cover**




5. Remove the booklet finisher booklet entrance motor

Use the following procedure to remove and replace the booklet finisher entrance motor.

- Disconnect one connector. remove two screws, and then remove the entrance motor.

Figure 5-2423 **Remove the motor**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2424 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2425 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2426 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2427 Attach the rail



Booklet paddle unit

Review the booklet finisher booklet paddle unit removal procedures.

Removal and replacement: Booklet paddle home sensor

Learn about removing and replacing the booklet finisher paddle home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-273 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Booklet paddle home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2428 Remove the cover




2. Remove the booklet finisher booklet paddle home sensor

Use the following procedure to remove and replace the booklet finisher paddle home sensor.


1. Disconnect one connector.

Figure 5-2429 Disconnect one connector



2. Release two tabs (callout 1), and then remove the booklet paddle home sensor (callout 2).

Figure 5-2430 **Remove the sensor**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet paddle motor assembly

Learn about removing and replacing the booklet finisher paddle motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-274 Part information

Part number	Part description
JC90-01430A	Booklet paddle motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2431 Remove the cover



2. Remove the booklet finisher booklet paddle motor assembly

Use the following procedure to remove and replace the booklet finisher paddle motor assembly.


1. Disconnect two connectors.

Figure 5-2432 Disconnect two connectors




2. Use a pair of tweezers to remove one e-ring.

Figure 5-2433 **Remove the e-ring**




3. Remove the belt and gear.

Figure 5-2434 **Remove the belt and gear**



4. Remove four screws, and then remove the booklet paddle motor assembly.

Figure 5-2435 **Remove the assembly**



3. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet paddle motor

Learn about removing and replacing the booklet finisher paddle motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-275 Part information

Part number	Part description
JC93-01001A	Drive-motor step (Booklet paddle motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2436 **Remove the cover**



2. Remove the booklet finisher booklet paddle motor assembly

Use the following procedure to remove and replace the booklet finisher paddle motor assembly.


1. Disconnect two connectors.

Figure 5-2437 **Disconnect two connectors**




2. Use a pair of tweezers to remove one e-ring.

Figure 5-2438 **Remove the e-ring**




3. Remove the belt and gear.

Figure 5-2439 **Remove the belt and gear**



4. Remove four screws, and then remove the booklet paddle motor assembly.

Figure 5-2440 **Remove the assembly**




3. Remove the booklet finisher booklet paddle motor

Use the following procedure to remove and replace the booklet finisher paddle motor.

- Remove two screws, and then remove the booklet paddle motor.

Figure 5-2441 **Remove the motor**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Booklet end fence unit

Review the booklet finisher booklet end fence unit removal procedures.

Removal and replacement: Booklet end fence home sensor

Learn about removing and replacing the booklet finisher end fence home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 15 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-276 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Booklet end fence home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2442 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2443 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2444 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2445 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2446 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2447 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2448 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2449 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2450 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2451 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2452 Remove the booklet maker



4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2453 **Remove the cover**




5. Remove the booklet finisher booklet end fence home sensor

Use the following procedure to remove and replace the booklet finisher end fence home sensor.


1. Remove two screws.

Figure 5-2454 **Remove two screws**



2. Remove two screws, and then remove the shield-r lower.

Figure 5-2455 **Remove the shield**



3. Move the upper jam guide out of the way.

Figure 5-2456 **Move the guide**




4. Lift up the booklet end fence.

Figure 5-2457 **Lift the fence**



5. Disconnect one connector (callout 1), and then remove the booklet end fence home sensor (callout 2).

Figure 5-2458 **Remove the sensor**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2459 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2460 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2461 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2462 Attach the rail



Removal and replacement: Booklet end fence motor

Learn about removing and replacing the booklet finisher end fence motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 25 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-277 Part information

Part number	Part description
JC93-01155A	Drive-motor step (Booklet end fence motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2463 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2464 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2465 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2466 Remove the cover



3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2467 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2468 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2469 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2470 Release the alignment pin




5. Slide the right rail toward the finisher.

Figure 5-2471 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2472 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2473 Remove the booklet maker




4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2474 Remove the cover




5. Remove the booklet finisher booklet end fence motor

Use the following procedure to remove and replace the booklet finisher end fence motor.


1. Remove two screws.

Figure 5-2475 **Remove two screws**




2. Remove two screws, and then remove the shield-r lower.

Figure 5-2476 **Remove the shield**



3. Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the booklet end fence motor.

Figure 5-2477 Remove the motor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2478 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2479 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2480 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2481 Attach the rail



Booklet presser unit

Review the booklet finisher booklet presser unit removal procedures.

Removal and replacement: Booklet presser home sensor

Learn about removing and replacing the booklet finisher presser home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 25 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-278 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Booklet presser home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip

- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2482 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2483 **Remove the door**




2. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2484 Remove the cover




3. Remove the booklet finisher booklet entrance-presser motor assembly

Use the following procedure to remove and replace the booklet finisher entrance-presser motor assembly.

- Disconnect one connector, remove two screws, and then remove the booklet entrance-presser motor assembly.

Figure 5-2485 Remove the assembly




4. Remove the booklet finisher booklet presser home sensor

Use the following procedure to remove and replace the booklet finisher presser home sensor.

- Do the following:
  - Disconnect one connector (callout 1).
  - Release the hooks (callout 2).
  - Slide the sensor assembly as shown below (callout 3).
  - Remove the booklet presser home sensor from the bracket.

Figure 5-2486 **Remove the sensor**



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet tamper

Learn about removing and replacing the booklet finisher tamper.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-279 Part information

Part number	Part description
JC90-01431A	Booklet tamper

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2487 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2488 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2489 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2490 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2491 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2492 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2493 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2494 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2495 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2496 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2497 Remove the booklet maker



4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2498 **Remove the cover**




5. Remove the booklet finisher booklet tamper

Use the following procedure to remove and replace the booklet finisher tamper.

1. Remove four screws and the sheet-metal plate.

Figure 5-2499 **Remove four screws**




2. Remove two screws.

Figure 5-2500 **Remove two screws**




3. Remove two screws.

Figure 5-2501 **Remove two screws**




4. Remove three screws and the sheet-metal cover.

Figure 5-2502 **Remove three screws**




5. Remove two screws.

Figure 5-2503 Remove two screws



6. Disconnect one connector.

Figure 5-2504 Disconnect one connector



7. Disconnect one connector.

Figure 5-2505 **Disconnect one connector**




8. Remove two screws.

Figure 5-2506 **Remove two screws**




9. Remove three screws.

Figure 5-2507 **Remove three screws**




10. Remove two screws.

Figure 5-2508 **Remove two screws**



11. Remove two screws.

Figure 5-2509 Remove two screws




12. Disconnect one connector.

Figure 5-2510 Disconnect one connector




13. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2511 **Disconnect connector and remove screws**



14. Remove the booklet tamper.

Figure 5-2512 **Remove the tamper**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2513 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2514 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2515 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2516 Attach the rail



Removal and replacement: Booklet tamper home sensor

Learn about removing and replacing the booklet finisher tamper home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-280 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Booklet tamper home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2517 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2518 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2519 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2520 **Remove the cover**



3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2521 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2522 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2523 **Disconnect connector and remove the screw**




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2524 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2525 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2526 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2527 Remove the booklet maker




4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2528 Remove the cover




5. Remove the booklet finisher booklet tamper home sensor

Use the following procedure to remove and replace the booklet finisher tamper home sensor.


1. Remove four screws and the sheet-metal plate.

Figure 5-2529 **Remove four screws**




2. Remove two screws.

Figure 5-2530 **Remove two screws**



3. Remove two screws.

Figure 5-2531 **Remove two screws**




4. Remove two screws.

Figure 5-2532 **Remove two screws**




5. Remove three screws and the sheet-metal cover.

Figure 5-2533 Remove three screws




6. Remove two screws.

Figure 5-2534 Remove two screws



7. Disconnect one connector.

Figure 5-2535 Disconnect one connector



8. Disconnect one connector.

Figure 5-2536 Disconnect one connector




9. Remove two screws.

Figure 5-2537 **Remove two screws**




10. Remove three screws.

Figure 5-2538 **Remove three screws**




11. Remove two screws.

Figure 5-2539 **Remove two screws**



12. Remove two screws.

Figure 5-2540 **Remove two screws**




13. Disconnect one connector.

Figure 5-2541 **Disconnect one connector**




14. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2542 **Disconnect connector and remove screws**



15. Remove four screws (callout 1), remove the cover, and then remove the booklet tamper home sensor (callout 2).

Figure 5-2543 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2544 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2545 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2546 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2547 Attach the rail



Removal and replacement: Booklet tamper motor

Learn about removing and replacing the booklet finisher tamper motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-281 Part information

Part number	Part description
5QJ90-40126	Booklet tamper motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2548 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2549 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2550 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2551 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2552 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2553 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2554 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2555 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2556 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2557 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2558 Remove the booklet maker



4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2559 **Remove the cover**




5. Remove the booklet finisher booklet tamper motor

Use the following procedure to remove and replace the booklet finisher tamper motor.


1. Remove four screws and the sheet-metal plate.

Figure 5-2560 **Remove four screws**




2. Remove two screws.

Figure 5-2561 **Remove two screws**



3. Remove two screws.

Figure 5-2562 **Remove two screws**




4. Remove two screws.

Figure 5-2563 **Remove two screws**




5. Remove three screws and the sheet-metal cover.

Figure 5-2564 **Remove three screws**




6. Remove two screws.

Figure 5-2565 **Remove two screws**



7. Disconnect one connector.

Figure 5-2566 Disconnect one connector



8. Disconnect one connector.

Figure 5-2567 Disconnect one connector




9. Remove two screws.

Figure 5-2568 **Remove two screws**




10. Remove three screws.

Figure 5-2569 **Remove three screws**




11. Remove two screws.

Figure 5-2570 **Remove two screws**



12. Remove two screws.

Figure 5-2571 **Remove two screws**




13. Disconnect one connector.

Figure 5-2572 Disconnect one connector




14. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2573 Disconnect connector and remove screws



15. Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the booklet tamper motor.

Figure 5-2574 **Remove the motor**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2575 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2576 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2577 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2578 Attach the rail



Removal and replacement: Booklet tamper sensor

Learn about removing and replacing the booklet finisher tamper sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 30 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-282 Part information

Part number	Part description
JC32-00020A	Sensor-RP (Booklet tamper sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2579 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2580 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2581 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2582 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2583 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2584 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2585 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2586 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2587 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2588 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2589 Remove the booklet maker



4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2590 **Remove the cover**




5. Remove the booklet finisher booklet tamper sensor

Use the following procedure to remove and replace the booklet finisher tamper sensor.


1. Remove four screws and the sheet-metal plate.

Figure 5-2591 **Remove four screws**




2. Remove two screws.

Figure 5-2592 **Remove two screws**



3. Remove two screws.

Figure 5-2593 Remove two screws




4. Remove two screws.

Figure 5-2594 Remove two screws




5. Remove three screws and the sheet-metal cover.

Figure 5-2595 **Remove three screws**




6. Remove two screws.

Figure 5-2596 **Remove two screws**



7. Disconnect one connector.

Figure 5-2597 **Disconnect one connector**



8. Disconnect one connector.

Figure 5-2598 **Disconnect one connector**




9. Remove two screws.

Figure 5-2599 **Remove two screws**




10. Remove three screws.

Figure 5-2600 **Remove three screws**




11. Remove two screws.

Figure 5-2601 **Remove two screws**



12. Remove two screws.

Figure 5-2602 **Remove two screws**




13. Disconnect one connector.

Figure 5-2603 Disconnect one connector




14. Disconnect one connector (callout 1), and then remove two screws (callout 2).

Figure 5-2604 Disconnect connector and remove screws




15. Remove four screws (callout 2), and then remove the sheet-metal cover.

Figure 5-2605 Remove the cover



16. Disconnect one connector (callout 1), release two tabs (callout 2), and then remove the booklet tamper sensor (callout 3).

Figure 5-2606 Remove the sensor



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2607 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2608 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2609 **Check rail alignment (2 of 2)**



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2610 **Attach the rail**



Booklet stapler unit

Review the booklet finisher booklet stapler unit removal procedures.

Removal and replacement: Booklet stapler

Learn about removing and replacing the booklet finisher stapler.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-283 Part information

Part number	Part description
6GW51-40001	Booklet stapler

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2611 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2612 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2613 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2614 Remove the cover



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2615 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2616 **Remove the cover**



4. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2617 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2618 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2619 **Disconnect connector and remove the screw**




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2620 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2621 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2622 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2623 Remove the booklet maker




5. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2624 Remove the cover




6. Remove the booklet finisher booklet staple cartridge

Use the following procedure to remove and replace the booklet finisher booklet staple cartridge.

1. Open the front door, and then pull the booklet maker out.
2. Remove the booklet staple cartridge.

NOTE: Repeat this step for the remaining cartridge.

Figure 5-2625 **Remove the cartridge**




7. Remove the booklet finisher booklet diverter motor assembly

Use the following procedure to remove and replace the booklet finisher booklet diverter motor assembly.

- Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the booklet diverter motor assembly.

Figure 5-2626 Remove the assembly




8. Remove the booklet finisher booklet c-fold blade assembly

Use the following procedure to remove and replace the booklet finisher c-fold blade assembly.

- Remove four screws, and then remove the c-fold blade assembly.

Figure 5-2627 Remove the assembly




9. Remove the booklet finisher booklet tamper sensor

Use the following procedure to remove and replace the booklet finisher tamper sensor.

1. Remove four screws and the sheet-metal plate.


NOTE: The c-fold blade assembly is shown installed in the figure below. How ever it was remove in the previous step.

Figure 5-2628 Remove four screws




2. Remove one screw.

Figure 5-2629 Remove one screw




3. Remove the black-plastic cover.

Figure 5-2630 **Remove the cover**




4. Disconnect one connector.

Figure 5-2631 **Disconnect one connector**




5. Remove five screws.

Figure 5-2632 Remove five screws



6. Disconnect one connector.

Figure 5-2633 Disconnect one connector




7. Disconnect two connectors.

Figure 5-2634 **Disconnect two connectors**



8. Remove six screws, and then remove the booklet stapler.

Figure 5-2635 **Remove the stapler**



10. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

> **NOTE:** HP recommends responsible disposal of the defective part.
>
> http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


11. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2636 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2637 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2638 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2639 Attach the rail



Removal and replacement: Booklet staple cartridge

Learn about removing and replacing the booklet finisher staple cartridge.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-284 Part information

Part number	Part description
JC81-09881B	Booklet staple cartridge

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.


1. Remove the booklet finisher booklet staple cartridge

Use the following procedure to remove and replace the booklet finisher booklet staple cartridge.

1. Open the front door, and then pull the booklet maker out.
2. Remove the booklet staple cartridge.

> **NOTE:** Repeat this step for the remaining cartridge.

Figure 5-2640 Remove the cartridge



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Booklet fold unit

Review the booklet finisher booklet fold unit removal procedures.

Removal and replacement: Booklet c-fold blade assembly

Learn about removing and replacing the booklet finisher c-fold blade assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-285 Part information

Part number	Part description
JC90-01438A	Booklet c-fold blade assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2641 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2642 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2643 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2644 Remove the cover



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2645 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2646 **Remove the cover**



4. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2647 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2648 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2649 **Disconnect connector and remove the screw**




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2650 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2651 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2652 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2653 Remove the booklet maker




5. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2654 Remove the cover




6. Remove the booklet finisher booklet diverter motor assembly

Use the following procedure to remove and replace the booklet finisher booklet diverter motor assembly.

- Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the booklet diverter motor assembly.

Figure 5-2655 **Remove the assembly**




7. Remove the booklet finisher booklet c-fold blade assembly

Use the following procedure to remove and replace the booklet finisher c-fold blade assembly.

- Remove four screws, and then remove the c-fold blade assembly.

Figure 5-2656 **Remove the assembly**



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


9. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2657 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2658 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2659 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2660 Attach the rail



Removal and replacement: Booklet c-fold blade home sensor

Learn about removing and replacing the booklet finisher c-fold blade home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-286 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Booklet c-fold blade home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2661 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2662 **Remove the door**



2. Remove the external finisher booklet finisher front cover


Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).

b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2663 Remove the cover




3. Remove the booklet finisher booklet c-fold blade motor assembly

Use the following procedure to remove and replace the booklet finisher c-fold blade motor assembly.


1. Disconnect two connectors.

Figure 5-2664 Disconnect two connectors




2. Remove four screws.

Figure 5-2665 Remove four screws



3. Use a pair of tweezers to remove one e-ring (callout 1), remove the gear (callout 2), and then release the belt (callout 3).


Figure 5-2666 Release the belt



4. Remove the booklet c-fold blade motor assembly.

⚠ CAUTION: Do not pull on the shaft (callout 1) while removing the bracket and motor. The shaft might become dislodged at the other end. If the shaft becomes dislodged, remove the booklet finisher PCA shield and PCA bracket to reinstall the shaft.

Figure 5-2667 Remove the assembly




4. Remove the booklet finisher booklet c-fold blade home sensor

Use the following procedure to remove and replace the booklet finisher c-fold blade home sensor.

- Disconnect one connector, and then remove the c-fold blade home sensor.

Figure 5-2668 Remove the sensor



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet c-fold blade motor assembly

Learn about removing and replacing the booklet finisher c-fold blade motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-287 Part information

Part number	Part description
JC90-01396A	Booklet c-fold blade motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2669 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2670 **Remove the door**




2. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2671 Remove the cover




3. Remove the booklet finisher booklet c-fold blade motor assembly

Use the following procedure to remove and replace the booklet finisher c-fold blade motor assembly.


1. Disconnect two connectors.

Figure 5-2672 Disconnect two connectors




2. Remove four screws.

Figure 5-2673 Remove four screws



3. Use a pair of tweezers to remove one e-ring (callout 1), remove the gear (callout 2), and then release the belt (callout 3).


Figure 5-2674 Release the belt



4. Remove the booklet c-fold blade motor assembly.

⚠ CAUTION: Do not pull on the shaft (callout 1) while removing the bracket and motor. The shaft might become dislodged at the other end. If the shaft becomes dislodged, remove the booklet finisher PCA shield and PCA bracket to reinstall the shaft.

Figure 5-2675 Remove the assembly



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet c-fold blade motor

Learn about removing and replacing the booklet finisher c-fold blade motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-288 Part information

Part number	Part description
JC93-01154A	Drive-motor step (Booklet c-fold blade motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2676 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2677 **Remove the door**



2. Remove the external finisher booklet finisher front cover


Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).

b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2678 Remove the cover




3. Remove the booklet finisher booklet c-fold blade motor assembly

Use the following procedure to remove and replace the booklet finisher c-fold blade motor assembly.


1. Disconnect two connectors.

Figure 5-2679 Disconnect two connectors




2. Remove four screws.

Figure 5-2680 Remove four screws



3. Use a pair of tweezers to remove one e-ring (callout 1), remove the gear (callout 2), and then release the belt (callout 3).


Figure 5-2681 Release the belt



4. Remove the booklet c-fold blade motor assembly.

⚠ CAUTION: Do not pull on the shaft (callout 1) while removing the bracket and motor. The shaft might become dislodged at the other end. If the shaft becomes dislodged, remove the booklet finisher PCA shield and PCA bracket to reinstall the shaft.

Figure 5-2682 Remove the assembly




4. Remove the booklet finisher booklet c-fold blade motor

Use the following procedure to remove and replace the booklet finisher c-fold blade motor.

- Remove two screws, and then remove the booklet c-fold blade motor.

Figure 5-2683 Remove the motor



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet blade home sensor

Learn about removing and replacing the booklet finisher blade home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-289 Part information

Part number	Part description
3SJ00-60110	Photo interrupter (Booklet blade home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2684 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2685 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2686 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2687 Remove the cover




3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2688 Slide the booklet maker out




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2689 Disconnect connector and remove the screw




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2690 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2691 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2692 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2693 Remove one screw



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2694 Remove the booklet maker



4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2695 **Remove the cover**




5. Remove the booklet finisher booklet blade home sensor

Use the following procedure to remove and replace the booklet finisher booklet blade home sensor.

1. Remove four screws and the sheet-metal plate.

Figure 5-2696 **Remove four screws**




2. Remove two screws.

Figure 5-2697 **Remove two screws**




3. Remove two screws.

Figure 5-2698 **Remove two screws**




4. Remove three screws and the sheet-metal cover.

Figure 5-2699 **Remove three screws**




5. Remove two screws.

Figure 5-2700 **Remove two screws**



6. Disconnect one connector.

Figure 5-2701 **Disconnect one connector**



7. Disconnect one connector.

Figure 5-2702 **Disconnect one connector**




8. Remove two screws.

Figure 5-2703 **Remove two screws**




9. Remove three screws.

Figure 5-2704 **Remove three screws**




10. Remove two screws.

Figure 5-2705 **Remove two screws**




11. Remove two screws.

Figure 5-2706 Remove two screws




12. Disconnect one connector.

Figure 5-2707 Disconnect one connector



13. Disconnect one connector (callout 1), and then remove the booklet blade home sensor (callout 2).

Figure 5-2708 **Remove the sensor**



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


7. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2709 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2710 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2711 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2712 Attach the rail



Removal and replacement: Booklet blade motor

Learn about removing and replacing the booklet finisher blade motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-290 Part information

Part number	Part description
JC31-00144A	Motor BLDC (Booklet blade motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2713 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2714 Remove the cover




2. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2715 Remove the cover




3. Remove the booklet finisher booklet blade motor

Use the following procedure to remove and replace the booklet finisher blade motor.


1. Remove two screws.

Figure 5-2716 **Remove two screws**




2. Remove two screws.

Figure 5-2717 **Remove two screws**




3. Remove the right lower plate.

Figure 5-2718 **Remove the plate**



4. Disconnect one connector (callout 1), remove four screws (callout 2), and then remove the booklet blade motor.

Figure 5-2719 **Remove the motor**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet fold motor assembly

Learn about removing and replacing the booklet finisher fold motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-291 Part information

Part number	Part description
JC90-01436A	Booklet fold motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2720 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2721 Remove the cover




2. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2722 Remove the cover




3. Remove the booklet finisher booklet fold motor assembly

Use the following procedure to remove and replace the booklet finisher fold motor assembly.

- Disconnect one connector, remove four screws, and then remove the booklet fold motor assembly.

Figure 5-2723 **Remove the assembly**



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet fold motor

Learn about removing and replacing the booklet finisher fold motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-292 Part information

Part number	Part description
JC31-00144A	Motor BLDC (Booklet fold motor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2724 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2725 Remove the cover



2. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.


2. Do the following:

   a. Slide the booklet finisher slightly away from the finisher (callout 1).

   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2726 **Remove the cover**




3. Remove the booklet finisher booklet fold motor

Use the following procedure to remove and replace the booklet finisher fold motor.

- Disconnect one connector (callout 1), remove four screws (callout 2), and then remove the booklet fold motor.

Figure 5-2727 Remove the motor



4. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Booklet diverter unit

Review the booklet finisher booklet diverter unit removal procedures.

Removal and replacement: Booklet diverter

Learn about removing and replacing the booklet finisher diverter.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-293 Part information

Part number	Part description
JC90-01398A	Booklet diverter

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2728 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2729 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2730 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2731 **Remove the cover**



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2732 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2733 **Remove the cover**



4. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2734 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2735 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2736 Disconnect connector and remove the screw




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2737 Release the alignment pin




5. Slide the right rail toward the finisher.

Figure 5-2738 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2739 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2740 Remove the booklet maker




5. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2741 Remove the cover




6. Remove the booklet finisher booklet diverter motor assembly

Use the following procedure to remove and replace the booklet finisher booklet diverter motor assembly.

- Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the booklet diverter motor assembly.

Figure 5-2742 **Remove the assembly**




7. Remove the booklet finisher booklet c-fold blade assembly

Use the following procedure to remove and replace the booklet finisher c-fold blade assembly.

- Remove four screws, and then remove the c-fold blade assembly.

Figure 5-2743 **Remove the assembly**




8. Remove the booklet finisher booklet diverter

Use the following procedure to remove and replace the booklet finisher booklet diverter.


1. Remove two screws.

Figure 5-2744 Remove two screws




2. Remove one screw and the sheet-metal cover.

Figure 5-2745 Remove one screw




3. Remove one screw.

Figure 5-2746 **Remove one screw**




4. Remove the connector cover, and then disconnect one connector.

Figure 5-2747 **Disconnect one connector**




5. Remove two screws.

Figure 5-2748 **Remove two screws**




6. Remove the white-plastic bushing.

Figure 5-2749 **Remove the bushing**




7. Use a pair of tweezers to remove one e-ring (callout 1), and then remove the actuator (callout 2).

Figure 5-2750 **Remove the actuator**




8. Remove the white-plastic bushing.

Figure 5-2751 **Remove the bushing**



9. Remove the booklet diverter.

Figure 5-2752 **Remove the diverter**



9. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


10. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2753 **Position the hooks on the rail**




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2754 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2755 Check rail alignment (2 of 2)



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2756 Attach the rail



Removal and replacement: Booklet diverter home sensor

Learn about removing and replacing the booklet finisher diverter home sensor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-294 Part information

Part number	Part description
0604-001415	Photo interrupter (Booklet diverter home sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2757 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2758 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2759 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2760 Remove the cover



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2761 Remove three screws



2. Remove two screws, and then remove the top cover.

Figure 5-2762 **Remove the cover**




4. Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2763 Remove the cover




5. Remove the booklet finisher booklet diverter motor assembly

Use the following procedure to remove and replace the booklet finisher booklet diverter motor assembly.

- Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the booklet diverter motor assembly.

Figure 5-2764 Remove the assembly




6. Remove the booklet finisher booklet diverter home sensor

Use the following procedure to remove and replace the booklet finisher booklet diverter home sensor.

- Disconnect one connector (callout 1), and then remove the booklet diverter home sensor.

Figure 5-2765 **Remove the sensor**



7. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet diverter motor assembly

Learn about removing and replacing the booklet finisher diverter motor assembly.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-295 Part information

Part number	Part description
JC90-01397A	Booklet diverter motor assembly

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2766 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2767 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2768 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2769 Remove the cover



3. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2770 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2771 **Remove the cover**



4. Remove the external finisher booklet finisher front cover


Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).

b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).

c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2772 Remove the cover




5. Remove the booklet finisher booklet diverter motor assembly

Use the following procedure to remove and replace the booklet finisher booklet diverter motor assembly.

- Disconnect one connector (callout 1), remove three screws (callout 2), and then remove the booklet diverter motor assembly.

Figure 5-2773 Remove the assembly



6. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet diverter motor

Learn about removing and replacing the booklet finisher diverter motor.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-296 Part information

Part number	Part description
JC93-01153A	Booklet diverter motor

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2774 Remove the hinge pin



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2775 **Remove the door**




Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2776 **Remove five screws**



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2777 Remove the cover



Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2778 Remove three screws



2. Remove two screws, and then remove the top cover.

Figure 5-2779 **Remove the cover**




Remove the external finisher booklet finisher front cover

Use the following procedure to remove and replace the external finisher booklet finisher front cover.

1. Open the front door.
2. Do the following:
   a. Slide the booklet finisher slightly away from the finisher (callout 1).
   b. Remove one screw (callout 2), and then slide the green knob away from the booklet finisher to remove it (callout 3).
   c. Remove four screws (callout 4), and then remove the booklet finisher front cover.

Figure 5-2780 Remove the cover




Remove the booklet finisher booklet diverter motor

Use the following procedure to remove and replace the booklet finisher booklet diverter motor.

- Disconnect one connector (callout 1), remove two screws (callout 2), and then remove the booklet diverter motor.

Figure 5-2781 Remove the motor



Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Booklet output tray unit

Review the booklet finisher booklet output tray unit removal procedures.

Removal and replacement: Booklet output tray

Learn about removing and replacing the booklet finisher output tray.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-297 Part information

Part number	Part description
8GS05-60126	Booklet output tray

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the booklet finisher booklet output tray

Use the following procedure to remove and replace the booklet finisher booklet output tray.

- Rotate the front of the tray up, and then pull it away from the finisher to remove it.

Figure 5-2782 Remove the tray



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: Booklet output tray sensor

Learn about removing and replacing the booklet finisher output tray sensor.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-298 Part information

Part number	Part description
JC82-01039A	Tray sensor kit (Booklet output tray sensor)

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2783 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2784 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2785 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2786 Remove the cover




3. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2787 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2788 Remove the cover




4. Remove the external finisher front lower left cover

Use the following procedure to remove and replace the external finisher front lower left cover.

1. Remove the external finisher from the printer.
2. Remove three screws, and then remove the front lower left cover.

Figure 5-2789 Remove the cover




5. Remove the external finisher caster cover

Use the following procedure to remove and replace the external finisher caster cover.

- Remove four screws, and then remove the caster cover.

Figure 5-2790 **Remove the cover**




6. Remove the external finisher left lower cover

Use the following procedure to remove and replace the external finisher left lower cover.

1. Remove four screws (callout 1).

Figure 5-2791 **Remove four screws**




2. Slide the shield down (callout 1) to release it from four tabs (callout 2), and then rotate it away from the finisher (callout 3).

⚠ **CAUTION:** The cover is still attached to the finisher. Do not attempt to completely remove the cover.


Reinstallation tip: Position the cover under the four tabs (callout 2) when reinstalling it.

Figure 5-2792 Release the cover



3. Disconnect two connectors (callout 1), and then remove the left lower cover.

Figure 5-2793 Remove the cover




7. Remove the booklet finisher booklet output tray sensor

Use the following procedure to remove and replace the booklet finisher booklet output tray sensor.

- Disconnect one connector (callout 1), and then remove the booklet output tray sensor (callout 2).

NOTE: Repeat this step for the remaining sensor (callout 3) if necessary.

Figure 5-2794 Remove the sensor



8. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

PCA

Review the booklet finisher PCA removal procedures.

Removal and replacement: Main PCA

Learn about removing and replacing the booklet finisher main PCA.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-299 **Part information**

Part number	Part description
6GW55-60001	Booklet maker main PCA

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2795 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2796 **Remove the door**



2. Remove the external finisher top cover

Use the following procedure to remove and replace the external finisher top cover.


1. Remove three screws.

Figure 5-2797 **Remove three screws**



2. Remove two screws, and then remove the top cover.

Figure 5-2798 **Remove the cover**




3. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2799 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2800 Remove the cover




4. Remove the booklet finisher main PCA

Use the following procedure to remove and replace the booklet finisher main PCA.

- Disconnect all of the connectors, remove four screws (callout 1), and then remove the booklet finisher PCA.

Figure 5-2801 Remove the PCA



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

Removal and replacement: PCA

Learn about removing and replacing the booklet finisher PCA.

NOTE: Remove the external finisher from the printer.

Mean time to repair: 10 minutes

Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable.

WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-300 Part information

Part number	Part description
6GW51-60001	Booklet maker PCA

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test


Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher front door

Use the following procedure to remove and replace the external finisher front door.


1. Release, and then remove the upper hinge pin.

Figure 5-2802 **Remove the hinge pin**



2. Support the door, release and remove the lower hinge pin, and then remove the front door

Figure 5-2803 **Remove the door**




2. Remove the external finisher rear cover

Use the following procedure to remove and replace the external finisher rear cover.

1. Remove five screws.


Figure 5-2804 Remove five screws



2. Remove seven screws, and then remove the rear cover.

NOTE: Thread the power cord through the hole in the cover as it is removed (callout 1).

Figure 5-2805 Remove the cover



3. Remove the booklet finisher booklet maker

Use the following procedure to remove and replace the booklet finisher booklet maker.


1. Slide the booklet maker out of the finisher.

Figure 5-2806 **Slide the booklet maker out**




2. Disconnect one connector (callout 1), and then remove one screw (callout 2).

Figure 5-2807 **Disconnect connector and remove the screw**




3. Release the metal bracket through the opening in the sheet-metal.

Figure 5-2808 **Disconnect connector and remove the screw**




4. Remove one screw (callout 1), and then release the alignment pin (callout 2).

Figure 5-2809 **Release the alignment pin**




5. Slide the right rail toward the finisher.

Figure 5-2810 **Slide the rail in**



6. Remove one screw (callout 1) on the left side of the booklet maker.


Figure 5-2811 **Remove one screw**



7. Lift the booklet maker up on the left side while pulling the right rail away from the finisher chassis to clear the sheet-metal. Remove the booklet maker unit.

IMPORTANT: Make sure to use the special installation instructions in this topic (located after the unpack and recycle step).

Figure 5-2812 Remove the booklet maker




4. Remove the booklet finisher PCA

Use the following procedure to remove and replace the booklet finisher PCA.


1. Remove two screws (callout 1).

Figure 5-2813 Remove two screws




2. Remove one screw (callout 1).

Figure 5-2814 Remove one screw



3. Disconnect all of the connectors, remove four screws (callout 1), and then remove the booklet finisher PCA.

Figure 5-2815 Remove the PCA



5. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: 

Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.


6. Special installation instructions: booklet finisher booklet maker

Use the following procedure to install the booklet finisher booklet maker.

NOTE: Use the special installation instructions to correctly install the booklet maker.


1. When installing the booklet finisher, position the hooks on the rail under the slots on the booklet maker.

Figure 5-2816 Position the hooks on the rail




2. When installed correctly, the arrow on the front of the booklet maker aligns with the arrow on the finisher rail (callout 1).

Figure 5-2817 Check rail alignment (1 of 2)



3. When installed correctly, the arrow on the back of the booklet maker aligns with the arrow on the finisher rail (callout 1).


Figure 5-2818 **Check rail alignment (2 of 2)**



4. Extend the right rail away from the finisher and position it in the booklet maker slot.

NOTE: Continue the installation by reversing the removal steps.

Figure 5-2819 **Attach the rail**



Miscellaneous parts

Review the booklet finisher miscellaneous parts removal procedures.

Removal and replacement: Finisher mounting brackets

Learn about removing and replacing the external finisher mounting brackets.

Mean time to repair: 20 minutes

Service level: Medium

Before performing service

Turn the printer power off

- Disconnect the power cable.

> ⚠ **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer.

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.

Table 5-301 Part information

Part number	Part description
JC90-01442A	Finisher mount bracket

Required tools

- #2 JIS screwdriver with a magnetic tip
- Tweezers

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

Print any pages necessary to make sure the printer is functioning correctly.

1. Remove the external finisher mounting brackets

Use the following procedure to remove and replace the external finisher mounting brackets.

- Remove four screws, and then remove the external finisher mounting brackets.

Figure 5-2820 **Remove the brackets**



2. Unpack the replacement assembly

Follow these steps to unpack the replacement assembly.

1. Dispose of the defective part.

NOTE: HP recommends responsible disposal of the defective part.

http://www8.hp.com/us/en/hp-information/environment/product-recycling.html

2. Unpack the replacement part from the packaging.

CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD-sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer.

IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation.

NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads.

3. To install an assembly, reverse the removal steps.

NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions.

6 Parts and diagrams

Printer parts information including exploded assembly diagrams and part number lists.

Base printer

Learn about the printer engine parts and assemblies.

Covers

Learn about base printer cover service parts.

Parts and diagrams: Covers

Parts diagram and parts list for the printer covers.

Figure 6-1 Covers




Table 6-1 Covers

Ref No	Part number	Description	Qty
1, C1	6ER04-40008	Rear upper cover	1
2, C2	6ER04-40019	Rear lower cover	1

Table 6-1 Covers (continued)

Ref No	Part number	Description	Qty
3, C3	6ER04-61005	Controller cover	1
4, C4	6ER04-40028	Exit rear cover	1
5, C5	JC63-04862B	Left top cover	1
6, C6	6ER04-40027	Left upper cover	1
7< C7	6ER04-40049	Left cover	1
8, C8	6ER04-40026	Middle upper cover	1
9, U1	JC95-02246A	Right door assembly	1
10, C9	JC63-04918B	Right door sHCI dummy cover	1
11, C10	6ER04-40021	Right upper cover	1
12, C11	6ER04-61003	Right rear cover	1
13. C12	6ER04-40005	Right front cover	1
14, C13	6ER04-61006	Right middle cover assembly	1
15	6ER04-40025	Right middle cover	1
16	6EQ94-40029	Power key	1
17, C13	3SJ33-60007	PCA -power key	1
18, C14	6EQ94-40032	HIP cover	1
19,C15	6ER04-40036	Middle left cover	1
20, C16	6ER04-61004	Exit cover stacker	1
21, C17	9S185-60007	Inner cover	1
22, C18	6ER04-40030	Front lower cover	1
23, C19	6ER08-61001	Front cover assembly	1
24	6ER04-40003	Front cover - Blue CMF Panel	1
25	JC61-04626A	Tie stopper	1
26. U3	5QK09-60120	Tray 2 cassette	1
27, C20	5QK09-40055	Tray 2 cover - Blue CMF panel	1
28, U4	5QK09-60121	Tray 3	1
29, C21	5QK09-40058	Tray 3 cover - Blue CMF panel	1
30	63C82-67029	Card reader rotation adapter kit	1
Not Shown	X3A92-67924	Kit-Screws c-clips e-clips kit	1

Feeding system

Learn about base printer feeding system service parts.

Tray 1

Learn about base printer Tray 1 service parts.

Parts and diagrams: Tray 1

Parts diagram and parts list for the printer Tray 1.

Figure 6-2 Tray 1




Table 6-2 Tray 1

Ref No	Part number	Description	Qty
1	JC93-01664A	Feed drive assembly	1
2, M1	JC31-00189A	Drive-motor step (Feed motor)	1
3, CL1	JC47-00037A	Electric clutch (Tray 1 clutch)	1
4, U1	JC95-02246A	Right door assembly	1
5, U2	JC90-01844A	Tray 1 unit	1
6, S1	0604-001490	Photo interrupter (Tray 1 paper empty sensor)	1
7< K1	5RC03-67001	Tray 1 roller kit	1

Table 6-2 Tray 1 (continued)

Ref No	Part number	Description	Qty
8	JC66-04398A	Right door front link	1
9	JC66-01425A	Right door front damper	1
10	JC61-08935A	Right door front damper bracket	1

Tray 2, 3

Learn about base printer Tray 2, 3 service parts.

Parts and diagrams: Tray 2, 3

Parts diagram and parts list for the printer Tray 2, 3.

Figure 6-3 Tray 2, 3




Table 6-3 Tray 2, 3

Ref No	Part number	Description	Qty
1, U3	5QK09-60120	Tray 2 cassette	1
2, U4	5QK09-60121	Tray 3 cassette	1

Table 6-3 Tray 2, 3 (continued)

Ref No	Part number	Description	Qty
3, U5	JC93-01663A	Tray 2 pickup drive assembly	1
4. U6	JC93-01663A	Tray 3 pickup drive assembly	1
5. M2, M3	JC93-01083A	Drive-motor step (Tray 2, 3 pickup motor)	2
6, S5	JC93-01408A	Frame sub-sensor paper size RU (Tray 2 tray open, paper size sensor)	1
7, S9	JC93-01408A	Frame sub-sensor paper size RU (Tray 3 tray open, paper size sensor)	1
8, S10	0604-001490	Photo interrupter (Feed 2 sensor)	1
9, U10	JC93-01664A	Feed drive assembly	1
10, M1	JC31-00189A	Drive-motor step (Feed motor)	1
11. U6	JC93-01694A	Tray 2 pickup assembly	1
12, U8	JC93-01695A	Tray 3 pickup assembly	1
13, K3	5PN66-67001	Tray 2, 3 roller kit	1
14, S2, S6	3SJ00-60110	Photo interrupter (Tray 2, 3 paper empty sensor)	1
15, S3, S7	3SJ00-60110	Photo interrupter (Tray 2, 3 stack height sensor)	1
16, S4	0604-001490	Photo interrupter (Tray 2 prefeed sensor)	1
17, S8	0604-001381	Photo interrupter (Tray 3 prefeed sensor)	1
18, U9-1	Y1G22-67901	Tray heater 110V	1
18, U9-2	Y1G22-67902	Tray heater 220V	1
19	JC93-01370A	Tray sub-auto closing unit	2

Registration and loop sensors

Learn about base printer registration and loop sensors service parts.

Parts and diagrams: Registration and loop sensors

Parts diagram and parts list for the printer registration and loop sensors.

Figure 6-4 Registration and loop sensors




Table 6-4 Registration and loop sensors

Ref No	Part number	Description	Qty
1, U12	5QK13-60101	Registration unit assembly	1
2, S11	0604-001381	Photo interrupter (Registration sensor)	1
3, U13	JC93-01665A	Registration drive assembly	1
4, M4	JC31-00189A	Drive-motor step (Registration motor)	1
5, U1	JC95-02246A	Right door assembly	1
6, U14	5PN85-67001	Paper Transfer Belt (PTB) kit	1
7, S12, S13	3SJ00-60110	Photo interrupter (Loop sensor 1, 2)	1
8	JC66-04572A	Loop actuator	1
9, U15	JC95-02249A	Right door exit assembly	1
10, S14	0960-5271	Paper sensor (Fuser out sensor)	1
11	5QK09-40109	Cover waste	1

Exit unit

Learn about base printer exit unit service parts.

Parts and diagrams: Exit unit

Parts diagram and parts list for the printer exit unit.

Figure 6-5 Exit unit




Table 6-5 Exit unit

Ref No	Part number	Description	Qty
1, U18	JC90-01856A	Exit unit	1
2, U33	JC93-01850A	Fuser and exit drive assembly	1
3, M14	JC31-00144G	Motor BLDC (Fuser and exit motor)	1
4, S14	3SJ00-60110	Photo interrupter (Out bin 1 full sensor)	1
5, SL2	JC33-00031B	Solenoid, lifting (Return gate solenoid)	1
6, M5	JC93-00336A	Drive-motor step (Exit 2 motor)	1
7, S17	3SJ00-60110	Photo interrupter (Exit 2 sensor)	1
8, S18	3SJ00-60110	Photo interrupter (Duplex jam 1 sensor)	1

Table 6-5 Exit unit (continued)

Ref No	Part number	Description	Qty
9, M6	JC93-00336A	Drive-motor step (Duplex 1 motor)	1
10, U19	JC90-01865A	Exit stack guide	1
12, S16	3SJ00-60110	Photo interrupter (Out bin 2 full sensor (optional))	1

Duplex

Learn about base printer duplex service parts.

Parts and diagrams: Duplex

Parts diagram and parts list for the printer duplex).

Figure 6-6 Duplex




Table 6-6 Duplex

Ref No	Part number	Description	Qty
1, U1	JC95-02246A	Right door assembly	1
2< U20	JC95-02250A	Duplex assembly	1
3, S19	3SJ00-60110	Photo interrupter (Duplex jam 2 sensor)	1
4, M7	JC93-01085A	Drive-motor step (Duplex 2 motor)	1

Toner flow

Learn about base printer toner flow service parts.

Toner cartridge

Learn about base printer toner cartridge service parts.

Parts and diagrams: Toner

Parts diagram and parts list for the printer toner.

Figure 6-7 Toner




Table 6-7 Toner

Ref No	Part number	Description	Qty
1, U21	JC93-01667A	Toner dispense motor assembly	1

Table 6-7 Toner (continued)

Ref No	Part number	Description	Qty
2, M8	SS216-80501	Toner dispense motor	1
3, S20	3SJ00-60110	Photo interrupter (Toner dispense motor sensor)	1
4, U22-1	W1760-67002	Toner cartridge -standard yield	1
5	JC61-02910A	Toner CRUM modular holder	1
5	JC39-02214A	Toner CRUM modular jack	1
6	63C82-60006	Guide toner cartridge assembly	1

Reservoir

Learn about base printer reservoir service parts.

Parts and diagrams: Reservoir

Parts diagram and parts list for the printer reservoir.

Figure 6-8 Reservoir




Table 6-8 Reservoir

Ref No	Part number	Description	Qty
1, U23	X3A79-60003	Reservoir unit	1

Toner collection unit (TCU)

Learn about base printer TCU service parts.

Parts and diagrams: Toner collection unit

Parts diagram and parts list for the printer toner collection unit.

Figure 6-9 Toner collection unit




Table 6-9 Toner collection unit

Ref No	Part number	Description	Qty
1, U24	9U1Q5-67001	Toner collection unit	1
2, S23	JC93-00492A	Toner collection full sensor assembly	1
3, S22	3SJ00-60110	Photo interrupter (Toner collection unit detection sensor)	1

Image creation

Learn about base printer image creation service parts.

Laser scanner unit (LSU)

Learn about base printer LSU service parts.

Parts and diagrams: Laser scanner unit

Parts diagram and parts list for the printer laser scanner unit.

Figure 6-10 **Laser scanner unit**




Table 6-10 **Laser scanner unit**

Ref No	Part number	Description	Qty
1, U25	JC97-05147A	Laser scanner unit (LSU)	1

Developer

Learn about base printer developer service parts.

Parts and diagrams: Developer

Parts diagram and parts list for the printer developer.

Figure 6-11 Developer




Table 6-11 Developer

Ref No	Part number	Description	Qty
1, U27	5PN82-67002	SVC_HP LaserJet Black Developer Unit	1
Not shown, K4	5PN82-67001	Developer powder kit	1
2, U28	JC93-01662A	Drum and developer drive assembly	1
3, M12	JC31-00197A	Developer motor	1
4	JC61-06282A	Cable guide	1

Drum

Learn about base printer drum service parts.

Parts and diagrams: Drum

Parts diagram and parts list for the printer drum.

Figure 6-12 Drum




Table 6-12 Drum

Ref No	Part number	Description	Qty
1, U26	W1766-67001	SVC_HP LaserJet Black Managed Imaging Drum	1
2, U28	JC93-01662A	Developer, drum and PTB drive assembly	1
3, M11	JC31-00123G	Drum and PTB motor	1
4	JC61-06282A	Cable guide	1

CTD

Learn about base printer CTD service parts.

Parts and diagrams: CTD

Parts diagram and parts list for the printer drum.

Figure 6-13 CTD




Table 6-13 CTD

Ref No	Part number	Description	Qty
1, U29	6ER04-60002	CTD sensor assembly	1

PTB

Learn about base printer PTB service parts.

Parts and diagrams: PTB

Parts diagram and parts list for the printer drum.

Figure 6-14 PTB




Table 6-14 PTB

Ref No	Part number	Description	Qty
1, U30	5PN85-67001	Paper Transfer Belt (PTB) kit	1
2, U28	JC93-01662A	Developer, drum and PTB drive assembly	1
3, M11	JC31-00123G	Drum and ITB motor	1
4	JC61-06282A	Cable guide	1
5	5QK09-64014	HV rear frame assembly	1

Fuser

Learn about base printer fuser service parts.

Parts and diagrams: PCA

Parts diagram and parts list for the printer covers.

Figure 6-15 PCA




Table 6-15 PCA

Ref No	Part number	Description	Qty
1, U37-1	5QK42-60104	Control-panel assembly 25.6 cm (10.1 in 2nd)	1
2, P11-1	JC44-00150C	Low Voltage Power Supply (LVPS), 220V	1
2, P11-2	JC44-00149C	Low Voltage Power Supply (LVPS), 110V	1
3, P12-1	JC44-00236C	Fuser drive board (FDB), 220V	1
3, P12-2	JC44-00235C	Fuser drive board (FDB), 110V	1

Table 6-15 PCA (continued)

Ref No	Part number	Description	Qty
4, P10	5QK09-60001	High Voltage Power Supply (HVPS)	1
5, P1	6CF14-67002	Formatter	1
6, P7	3SJ06-60001	Island of Data (IOD) PCA	1
7, P8	T3U64-60001 (Not orderable and not used in printer.)	Echo PCA (Not orderable and not used in printer.)	1
8	6ER04-40034 (Not orderable and not used in printer.)	Rivet-Echo PCA (Not orderable and not used in printer.)	1
9, P6	3SJ04-60002	USB Hub PCA	1
10, P5	0950-5111	Solid-state drive 256GB	1
11	6ER04-40035	Rivet-SSD	1
13	5851-8707	Cradle-Riser Card	1
14, P3-1	3SJ01-60002	Riser for SSD	1
14, P3-2	4XN67-67001	SVC-Internal USB Expansion Kit	1
14, P3-3	3SJ02-60001	Riser for HDD, USB ports, Accelerator	1
15, U60-3	63C82-67003	Keyboard (drawer type) Assy – E8 series US English	1
15, U60-4	63C82-67005	Keyboard (drawer type) Assy – E8 series UK English	1
Not shown	5851-6019	Keyboard overlay kit (FR, IT, RU, DE,ES,UK Kybd)	1
Not shown	5851-6020	Keyboard overlay kit (FR-CN, ES-LA, ES,US Kybd)	1
Not shown	5851-6021	Keyboard overlay kit (FR-SW, DE-SW, DA,UK Kybd)	1
Not shown	5851-6022	Keyboard overlay kit (ZHTW, ZHCN)	1
Not shown	5851-6023	Keyboard overlay kit (ES, PT)	1
Not shown	5851-6024	Keyboard overlay kit (JA-KG, JA-KT)	1
15, U38-2	JC93-01743A	Keyboard Assy-UK English	1
16, P4	6HN30-67001	Accelerator (Optional)	1
17, P18-1	7ZA08-67001	Single Fax Card (WW) (Optional)	1
17, P18-2	7ZA09-67001	Single Fax Card (BBU) (Optional)	1
18, P2	3SJ03-60001 (Not Orderable)	TPM	1
19, P13	3SJ33-60007	PCA - power key	1

Sensor and fan

Learn about base printer sensor and fan service parts.

Parts and diagrams: Sensor and fan

Parts diagram and parts list for the printer sensor and fan.

Figure 6-16 Sensor and fan




Table 6-16 Sensor and fan

Ref No	Part number	Description	Qty
1, S32	1404-001417	Thermistor (Inner temperature sensor)	1
2, U34	5QJ90-40002	Outer environment sensor assembly	1
3	JC93-01795A	LVPS FDB fan assembly	1
4, F1	JC31-00198A	Fan (LVPS fan)	1
5, F2	JC31-00154A	Fan (FDB fan)	1
6, U36	5QK09-40083	Developer fan assembly	1
7	JC93-01007A	Developer suction duct	1
8	JC93-01446A	Fuser ventilation duct	1
9, F4	JC31-00154A	Exit fan1, 2, 3, 4	4
10, U36	5QK09-64013	LSU fan assembly	1
11, S34	JC93-00466A	Front door open switch (Front door switch assembly)	1
12, S35	JC93-01467A	Switch (Right door switch assembly)	1

PCA

Learn about base printer PCA service parts.

Parts and diagrams: PCA

Parts diagram and parts list for the printer covers.

Figure 6-17 PCA




Table 6-17 PCA

Ref No	Part number	Description	Qty
1, U37-1	5QK42-60104	Control-panel assembly 25.6 cm (10.1 in 2nd)	1
2, P11-1	JC44-00150C	Low Voltage Power Supply (LVPS), 220V	1
2, P11-2	JC44-00149C	Low Voltage Power Supply (LVPS), 110V	1

Table 6-17 PCA (continued)

Ref No	Part number	Description	Qty
3, P12-1	JC44-00236C	Fuser drive board (FDB), 220V	1
3, P12-2	JC44-00235C	Fuser drive board (FDB), 110V	1
4, P10	5QK09-60001	High Voltage Power Supply (HVPS)	1
5, P1	6CF14-67002	Formatter	1
6, P7	3SJ06-60001	Island of Data (IOD) PCA	1
7, P8	T3U64-60001 (Not orderable and not used in printer.)	Echo PCA (Not orderable and not used in printer.)	1
8	6ER04-40034 (Not orderable and not used in printer.)	Rivet-Echo PCA (Not orderable and not used in printer.)	1
9, P6	3SJ04-60002	USB Hub PCA	1
10, P5	0950-5111	Solid-state drive 256GB	1
11	6ER04-40035	Rivet-SSD	1
13	5851-8707	Cradle-Riser Card	1
14, P3-1	3SJ01-60002	Riser for SSD	1
14, P3-2	4XN67-67001	SVC-Internal USB Expansion Kit	1
14, P3-3	3SJ02-60001	Riser for HDD, USB ports, Accelerator	1
15, U60-3	63C82-67003	Keyboard (drawer type) Assy - E8 series US English	1
15, U60-4	63C82-67005	Keyboard (drawer type) Assy - E8 series UK English	1
Not shown	5851-6019	Keyboard overlay kit (FR, IT, RU, DE,ES,UK Kybd)	1
Not shown	5851-6020	Keyboard overlay kit (FR-CN, ES-LA, ES,US Kybd)	1
Not shown	5851-6021	Keyboard overlay kit (FR-SW, DE-SW, DA,UK Kybd)	1
Not shown	5851-6022	Keyboard overlay kit (ZHTW, ZHCN)	1
Not shown	5851-6023	Keyboard overlay kit (ES, PT)	1
Not shown	5851-6024	Keyboard overlay kit (JA-KG, JA-KT)	1
15, U38-2	JC93-01743A	Keyboard Assy-UK English	1
16, P4	6HN30-67001	Accelerator (Optional)	1
17, P18-1	7ZA08-67001	Single Fax Card (WW) (Optional)	1
17, P18-2	7ZA09-67001	Single Fax Card (BBU) (Optional)	1
18, P2	3SJ03-60001 (Not Orderable)	TPM	1
19, P13	3SJ33-60007	PCA - power key	1

ADF / Image scanner assembly

Learn about the ADF and sub-scanner parts and assemblies.

Image scanner assembly (ISA)

Learn about the integrated-scanner assembly parts and assemblies.

Parts and diagrams: ISA

Parts diagram and parts list for the printer ISA.

Figure 6-18 ISA




Table 6-18 ISA

Ref No	Part number	Description	Qty
1	3SJ11-40008	Cover Rear	1
2	5QK37-67002	HP LaserJet 300ipm 300 sheet Flow DADF Scanner	1
2	5QK35-67002	HP LaserJet 180ipm 200 sheet DADF Scanner	1

Table 6-18 ISA (continued)

Ref No	Part number	Description	Qty
3, U501	5QK08-67014	300sh flow ADF (does not include white backing or suspension clips)	1
3, U601	5QJ90-67011	200sh ADF	1
4, U811	3SJ11-60103	Tarot platen	1

300sh flow ADF

Learn about the 300sh flow ADF parts and assemblies.

Parts and diagrams: 300sh flow ADF (1 of 2)

Parts diagram and parts list for the printer ADF.

Figure 6-19 **300sh flow ADF (1 of 2)**




Table 6-19 **300sh flow ADF (1 of 2)**

Ref No, Callout	Part number	Description	Qty
1, C501	5QJ90-40049	ADF front cover	1
2, C502	5QJ90-40041	ADF rear cover	1
3, C503	5QJ90-40054	ADF top cover	1
4, C505	5QJ90-40056	ADF Blue CMF panel	1

Parts and diagrams: 300sh flow ADF (2 of 2)

Parts diagram and parts list for the printer ADF.

Figure 6-20 300sh flow ADF (2 of 2)




Table 6-20 300sh flow ADF (2 of 2)

Ref No, Callout	Part number	Description	Qty
1, C504 (**Not orderable**)	Not applicable NOTE: This part number is not orderable and not used as a replaceable part.	ADF input tray NOTE: ADF input tray is not used as a replaceable part for the printer.	Not applicable
2, K501	A91Z5-67001	ADF roller kit	1
4, P501	Z9Y05-60004	300sh ADF PCA	1
5	Z9Y05-50002	ADF FFC cable to SSA	1
6	Z9Y05-50003	ADF Power cable	1
7	5QK08-67003	SVC-Hinge Kit (right, middle, left)	1
10	Z9Y05-60016	Damper module	1

Table 6-20 300sh flow ADF (2 of 2) (continued)

Ref No, Callout	Part number	Description	Qty
11	5QK08-67005	SVC-A3 White Backing Kit	1

200sh ADF

Learn about the 200sh ADF parts and assemblies.

Parts and diagrams: 200sh ADF (1 of 2)

Parts diagram and parts list for the printer ADF.

Figure 6-21 200sh ADF (1 of 2)




Table 6-21 200sh ADF (1 of 2)

Ref No, Callout	Part number	Description	Qty
1, C605	5QJ90-40056	ADF Blue CMF panel	1

Parts and diagrams: 200sh ADF (2 of 2)

Parts diagram and parts list for the printer ADF.

Figure 6-22 200sh ADF (2 of 2)




Table 6-22 200sh ADF (2 of 2)

Ref No, Callout	Part number	Description	Qty
1, K601	5851-7202	ADF roller kit	1
3, P601-1	5QJ90-67013	200sh ENT ADF PCA	1
4	5QJ90-67009	ADF FFC cable to SSA	1
5	5QJ90-67010	ADF Power cable	1
6, K602	5QJ90-67004	Hinge Kit	1
7	5QJ90-67006	Damper module	1
8, K603	5QK08-67005	A3 White Backing Kit	1

Tarot platen

Learn about the tarot platen parts and assemblies.

Parts and diagrams: Tarot platen

Parts diagram and parts list for the printer tarot platen.

Figure 6-23 Tarot platen




Table 6-23 Tarot platen

Ref No	Part number	Description	Qty
1, S803	3SJ00-60110	Photo interrupter (ADF open sensor)	1
2, P811	Y6V12-60035	Tarot platen PCA	1
3	3SJ11-50006	Discrete power cable	1
4	5QK08-67011	SVC-Flat Cable, Tarot SCB 50pin	1
5	5QK08-67012	SVC-Flat Cable, Tarot SCB 68pin	1

Input devices

Learn about input device parts and assemblies.

Department Dual cassette feeder (DCF, Tray 4, 5)

Learn about the DCF parts and assemblies.

Parts and diagrams: DCF (1 of 2)

Parts diagram and parts list for the printer DCF.

Figure 6-24 DCF (1 of 2)




Table 6-24 DCF (1 of 2)

Ref No	Part number	Description	Qty
0	6GW47-67001	DCF	1
1	5QK08-40006	DCF right cover	1
2	5QK08-40007	DCF rear cover	1
3	5QK08-40008	DCF left cover	1
4	5QK08-61004	DCF right door	1
5	5QK08-61007	Tray 4 cassette	1
6	5QK08-40011	Tray 4 Blue CMF panel	1
7	5QK08-61005	Tray 5 cassette	1
8	5QK08-40012	Tray 5 Blue CMF panel	1

Table 6-24 DCF (1 of 2) (continued)

Ref No	Part number	Description	Qty
9	6109-001138	Caster wheel	1
10	JC61-04871A	Guide - adjust	1
11	JC90-01677A	Tray sub-auto closing unit	2

Parts and diagrams: DCF (2 of 2)

Parts diagram and parts list for the printer DCF.

Figure 6-25 DCF (2 of 2)




Table 6-25 DCF (2 of 2)

Ref No	Part number	Description	Qty
1	5QK08-61007	Tray 4 cassette	1
2	5QK08-61005	Tray 5 cassette	1
3	JC93-01663A	Tray 4 pickup drive assembly	1
4	JC93-01663A	Tray 5 pickup drive assembly	1
5	JC93-01083A	Drive-motor step (Tray 4, 5 pickup motor)	1
6	JC93-01408A	Frame sub-sensor paper size RU (Tray 4 tray open, paper size sensor)	1
7	JC93-01408A	Frame sub-sensor paper size RU (Tray 5 tray open, paper size sensor)	1
8	JC93-01135A	DCF feed drive assembly	1
9	JC31-00177A	Motor, step (DCF feed motor)	1
10	5QK08-61009	Tray 4 pickup assembly	1

Table 6-25 DCF (2 of 2) (continued)

Ref No	Part number	Description	Qty
11	5QK08-61010	Tray 5 pickup assembly	1
12	5PN66-67001	Tray 4, 5 roller kit	1
13	0604-001381	Photo interrupter (Prefeed 4, 5 sensor)	1
14	3SJ00-60110	Photo interrupter (DCF paper empty sensor)	1
15	3SJ00-60110	Photo interrupter (DCF stack height sensor)	1
16	0604-001490	Photo interrupter (feed sensor)	1
17	JC90-01385A	Right door open switch holder assy	1
17	JC39-02268A	DCF Dpt_Door open switch sensor and harness	1
18	6GW47-60001	PCA-DCF Department	1
19	Y1G22-67901	Tray heater 110V	1
19	Y1G22-67902	Tray heater 220V	1

Output device

Learn about output device parts and assemblies.

Stapler/Stacker finisher

Learn about the stapler/stacker parts and assemblies.

Parts and diagrams: Stapler/Stacker finisher (1 of 4)

Parts diagram and parts list for the stapler/stacker finisher.

Figure 6-26 **Stapler/Stacker finisher (1 of 4)**




Table 6-26 Stapler/Stacker finisher (1 of 4)

Ref No	Part number	Description	Qty
0	6GW55-67001	Stapler/Stacker finisher	1
1	JC90-01442A	Finisher mount bracket	1
2	5QK09-60106	Front door	1
3	8GS05-40018	Caster cover	1
4	8GS05-60122	Left lower cover	1
5	0604-001415	Main output tray lower limit sensor	1
6	8GS05-60118	Left upper cover	1
7	JC82-01039A	Main output tray top of stack sensor	1
8	3SJ00-60110	Front paper holding sensor	1
9	3SJ00-60110	Rear paper holding sensor	1
10	3SJ00-60110	Paper holding home sensor	1
11	5QK09-40027	Top output tray	1
12	5QK09-40028	Main output tray	1
13	5QK09-40029	Tray extension	1
14	5QK09-40021	Rear cover	1
15	5QK09-40030	Punch cover	1
16	5QK09-60108	Top cover	1
17	5QK09-60107	Top door	1
18	5QK09-60109	Right upper cover	1
19	5QK09-40019	Front cover	1
20	5QK09-40020	Front lower cover	1
21	5QK09-40047	Front lower left cover	1
22	5QK09-40048	Front lower right cover	1
23	JC61-07452A	Caster	1
24	JC61-07444A	Caster fix nut	1
25	JC66-04767A	Shaft hinge - door	1

Parts and diagrams: Stapler/Stacker finisher (2 of 4)

Parts diagram and parts list for the stapler/stacker finisher.

Figure 6-27 Stapler/Stacker finisher (2 of 4)




Table 6-27 Stapler/Stacker finisher (2 of 4)

Ref No	Part number	Description	Qty
9	8GS05-60104	Entrance motor assembly	1
10	Y1G10-67901	Punch unit 2-3 hole	1
10	Y1G11-67901	Punch unit 2-4 hole	1
11	JC90-01455A	Top jam cover assembly	1
12	JC90-01458A	Tray diverter cam	1
13	0604-001415	Tray diverter home sensor	1
17	8GS05-60106	Exit motor assembly	1
18	JC82-01039A	Top output tray paper full sensor	1

Table 6-27 Stapler/Stacker finisher (2 of 4) (continued)

Ref No	Part number	Description	Qty
19	JC39-02309A	Front door switch	1
20	JC90-01453A	Main exit cam motor assembly	1
21	3SJ00-60110	Main exit cam home sensor	1
22	JC90-01480A	Paddle	1
23	JC90-01461A	Paddle motor assembly	1
24	3SJ00-60110	Paddle home sensor	1
25	JC90-01467A	End fence motor assembly	1
36	0604-001415	Manual staple senor	1
42	JC90-01415B	Main output tray motor drive assembly	1
43	3SJ00-60110	Main output tray motor sensor	1
44	JC39-02316A	Main output tray top of stack switch	1
45	JC90-01414A	Paper holding motor drive assembly	1
46	JC93-01152A	Buffer motor	1
47	JC90-01675A	Buffer solenoid assembly	1
48	6GW55-60001	Main PCA	1

Parts and diagrams: Stapler/Stacker finisher (3 of 4)

Parts diagram and parts list for the stapler/stacker finisher.

Figure 6-28 **Stapler/Stacker finisher (3 of 4)**




Table 6-28 **Stapler/Stacker finisher (3 of 4)**

Ref No	Part number	Description	Qty
1	5QK09-60110	Bridge unit	1
2	3SJ00-60110	Bridge door sensor	1
3	JC32-00020A	Bridge entrance sensor	1
4	3SJ00-60110	Bridge exit sensor	1
5	3SJ19-80501	Bridge motor	1
14	JC90-01454A	Top lower feed assembly	1
15	JC32-00020A	Main exit sensor	1
16	3SJ00-60110	Top exit sensor	1
17	8GS05-60106	Exit motor assembly	1

Parts and diagrams: Stapler/Stacker finisher (4 of 4)

Parts diagram and parts list for the stapler/stacker finisher.

Figure 6-29 **Stapler/Stacker finisher (4 of 4)**




Table 6-29 **Stapler/Stacker finisher (4 of 4)**

Ref No	Part number	Description	Qty
6	JC82-00901A	Front tamper	1
7	3SJ00-60110	Front tamper home sensor	1
8	JC93-01001A	Front tamper motor	1
26	JC82-00898A	Rear tamper	1
27	3SJ00-60110	Rear tamper home sensor	1
28	JC93-01001A	Rear tamper motor	1
29	JC82-00894A	Staple unit	1
30	JC81-09882B	Staple cartridge	1
31	3SJ00-60110	Staple front sensor	1
32	3SJ00-60110	Staple mid-front sensor	1
33	3SJ00-60110	Staple mid-rear sensor	1
34	3SJ00-60110	Staple rear sensor	1

Table 6-29 Stapler/Stacker finisher (4 of 4) (continued)

Ref No	Part number	Description	Qty
35	JC31-00163A	Staple position motor	1
37	JC90-01802A	Ejector unit	1
38	JC32-00020A	Ejector sensor	1
39	0604-001415	Ejector1 home sensor	1
40	0604-001415	Ejector1 motor sensor	1
41	0604-001415	Ejector2 motor sensor	1

Booklet finisher

Learn about the booklet finisher parts and assemblies.

Parts and diagrams: Booklet finisher (1 of 5)

Parts diagram and parts list for the printer booklet finisher.

Figure 6-30 **Booklet finisher (1 of 5)**




Table 6-30 **Booklet finisher (1 of 5)**

Ref No	Part number	Description	Qty
0	6GW51-67001	Booklet finisher	1
1	JC90-01442A	Finisher mount bracket	1
2	5QK09-60104	Booklet maker unit	1
3	5QK09-60106	Front door	1
4	8GS05-40018	Caster cover	1
5	8GS05-60124	Left lower cover (Booklet)	1
6	0604-001415	Main output tray lower limit sensor	1

Table 6-30 Booklet finisher (1 of 5) (continued)

Ref No	Part number	Description	Qty
7	8GS05-60118	Left upper cover	1
8	JC82-01039A	Main output tray top of stack sensor	1
9	3SJ00-60110	Front paper holding sensor	1
10	3SJ00-60110	Rear paper holding sensor	1
11	3SJ00-60110	Paper holding home sensor	1
12	5QK09-40027	Top output tray	1
13	5QK09-40028	Main output tray	1
14	5QK09-40029	Tray extension	1
15	5QK09-40021	Rear cover	1
16	5QK09-40030	Punch cover	1
17	5QK09-60108	Top cover	1
18	5QK09-60107	Top door	1
19	5QK09-60109	Right upper cover	1
20	5QK09-40019	Front cover	1
21	5QK09-40020	Front lower cover	1
22	5QK09-40047	Front lower left cover	1
23	5QK09-40048	Front lower right cover	1
24	JC61-07452A	Caster	1
25	JC61-07444A	Caster fix nut	1
26	JC66-04767A	Shaft hinge - door	1
27	8GS05-60126	Booklet output tray	1
28	JC82-01039A	Booklet output tray sensor	1

Parts and diagrams: Booklet finisher (2 of 5)

Parts diagram and parts list for the printer booklet finisher.

Figure 6-31 Booklet finisher (2 of 5)




Table 6-31 **Booklet finisher (2 of 5)**

Ref No	Part number	Description	Qty
1	0604-001415	Booklet entrance sensor	1
2	JC90-01425A	Booklet entrance-presser motor assembly	1
3	3SJ00-60110	Booklet paddle home sensor	1
4	JC90-01430A	Booklet paddle motor assembly	1
5	JC90-01432A	Booklet end fence	1
6	3SJ00-60110	Booklet end fence home sensor	1
7	JC93-01155A	Booklet end fence motor	1
8	3SJ00-60110	Booklet presser home sensor	1
9	JC90-01431A	Booklet tamper	1
10	3SJ00-60110	Booklet tamper home sensor	1
11	JC93-01155A	Booklet tamper motor	1
12	JC32-00020A	Booklet tamper sensor	1
13	6GW51-40001	Booklet stapler	1
14	JC81-09881B	Booklet stapler cartridge	1
15	JC90-01437A	Booklet blade	1
16	3SJ00-60110	Booklet blade home sensor	1
17	JC90-01435A	Booklet blade motor assembly	1
18	JC90-01436A	Booklet fold motor assembly	1
19	JC90-01438A	Booklet c-fold blade	1
20	JC90-01396A	Booklet c-fold blade motor assembly	1
21	3SJ00-60110	Booklet c-fold blade home sensor	1
22	JC90-01398A	Booklet diverter	1
23	JC90-01397A	Booklet diverter motor assembly	1
24	0604-001415	Booklet diverter home sensor	1
25	JC32-00020A	Booklet exit sensor	1
26	6GW51-60001	Booklet maker PCA	1
27	JC90-01478B	Booklet front cover	1

Parts and diagrams: Booklet finisher (3 of 5)

Parts diagram and parts list for the printer booklet finisher.

Figure 6-32 **Booklet finisher (3 of 5)**




Table 6-32 **Booklet finisher (3 of 5)**

Ref No	Part number	Description	Qty
9	8GS05-60104	Entrance motor assembly	1
10	Y1G10-67901	Punch unit 2-3 hole	1
10	Y1G11-67901	Punch unit 2-4 hole	1
10	Y1G12-67901	Punch unit Swedish hole	1
11	JC90-01455A	Top jam cover assembly	1
12	JC90-01458A	Tray diverter cam	1
13	0604-001415	Tray diverter home sensor	1
17	8GS05-60106	Exit motor assembly	1

Table 6-32 Booklet finisher (3 of 5) (continued)

Ref No	Part number	Description	Qty
18	JC82-01039A	Top output tray paper full sensor	1
19	JC39-02309A	Front door switch	1
20	JC90-01453A	Main exit cam motor assembly	1
21	3SJ00-60110	Main exit cam home sensor	1
22	JC90-01480A	Paddle	1
23	JC90-01461A	Paddle motor assembly	1
24	3SJ00-60110	Paddle home sensor	1
25	JC90-01467A	End fence motor assembly	1
36	0604-001415	Manual staple senor	1
42	JC90-01415B	Main output tray motor drive assembly	1
43	3SJ00-60110	Main output tray motor sensor	1
44	JC39-02316A	Main output tray top of stack switch	1
45	JC90-01414A	Paper holding motor drive assembly	1
46	JC93-01152A	Buffer motor	1
47	JC90-01675A	Buffer solenoid assembly	1
48	6GW55-60001	Main PCA	1

Parts and diagrams: Booklet finisher (4 of 5)

Parts diagram and parts list for the printer booklet finisher.

Figure 6-33 **Booklet finisher (4 of 5)**




Table 6-33 **Booklet finisher (4 of 4)**

Ref No	Part number	Description	Qty
1	5QK09-60110	Bridge unit	1
2	3SJ00-60110	Bridge door sensor	1
3	JC32-00020A	Bridge entrance sensor	1
4	3SJ00-60110	Bridge exit sensor	1
5	3SJ19-80501	Bridge motor	1
14	JC90-01454A	Top lower feed assembly	1
15	JC32-00020A	Main exit sensor	1
16	3SJ00-60110	Top exit sensor	1
17	8GS05-60106	Exit motor assembly	1

Parts and diagrams: Booklet finisher (5 of 5)

Parts diagram and parts list for the printer booklet finisher.

Figure 6-34 **Booklet finisher (5 of 5)**




Table 6-34 **Booklet finisher (5 of 5)**

Ref No	Part number	Description	Qty
6	JC82-00901A	Front tamper	1
7	3SJ00-60110	Front tamper home sensor	1
8	JC93-01001A	Front tamper motor	1
26	JC82-00898A	Rear tamper	1
27	3SJ00-60110	Rear tamper home sensor	1
28	JC93-01001A	Rear tamper motor	1
29	JC82-00894A	Staple unit	1
30	JC81-09882B	Staple cartridge	1
31	3SJ00-60110	Staple front sensor	1
32	3SJ00-60110	Staple mid-front sensor	1
33	3SJ00-60110	Staple mid-rear sensor	1
34	3SJ00-60110	Staple rear sensor	1

Table 6-34 Booklet finisher (5 of 5) (continued)

Ref No	Part number	Description	Qty
35	JC31-00163A	Staple position motor	1
37	JC90-01802A	Ejector unit	1
38	JC32-00020A	Ejector sensor	1
39	0604-001415	Ejector1 home sensor	1
40	0604-001415	Ejector1 motor sensor	1
41	0604-001415	Ejector2 motor sensor	1

Alphabetical parts list

Table 6-35 Alphabetical parts list

Description	Part number	Table and page
200sh ADF	5QJ90-67011	ISA on page 2183
200sh ENT ADF PCA	5QJ90-67013	200sh ADF (2 of 2) on page 2189
300sh ADF PCA	Z9Y05-60004	300sh flow ADF (2 of 2) on page 2186
300sh flow ADF (does not include white backing or suspension clips)	5QK08-67014	ISA on page 2183
A3 White Backing Kit	5QK08-67005	200sh ADF (2 of 2) on page 2189
ADF Blue CMF panel	5QJ90-40056	300sh flow ADF (1 of 2) on page 2185
ADF Blue CMF panel	5QJ90-40056	200sh ADF (1 of 2) on page 2188
ADF FFC cable to SSA	5QJ90-67009	200sh ADF (2 of 2) on page 2189
ADF FFC cable to SSA	Z9Y05-50002	300sh flow ADF (2 of 2) on page 2186
ADF Power cable	5QJ90-67010	200sh ADF (2 of 2) on page 2189
ADF Power cable	Z9Y05-50003	300sh flow ADF (2 of 2) on page 2186
ADF front cover	5QJ90-40049	300sh flow ADF (1 of 2) on page 2185
ADF input tray	Not applicable	300sh flow ADF (2 of 2) on page 2186
ADF rear cover	5QJ90-40041	300sh flow ADF (1 of 2) on page 2185
ADF roller kit	5851-7202	200sh ADF (2 of 2) on page 2189
ADF roller kit	A91Z5-67001	300sh flow ADF (2 of 2) on page 2186
ADF top cover	5QJ90-40054	300sh flow ADF (1 of 2) on page 2185
Accelerator (Optional)	6HN30-67001	PCA on page 2178
Accelerator (Optional)	6HN30-67001	PCA on page 2178
Booklet blade	JC90-01437A	Booklet finisher (2 of 5) on page 2207
Booklet blade home sensor	3SJ00-60110	Booklet finisher (2 of 5) on page 2207
Booklet blade motor assembly	JC90-01435A	Booklet finisher (2 of 5) on page 2207

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Booklet c-fold blade	JC90-01438A	Booklet finisher (2 of 5) on page 2207
Booklet c-fold blade home sensor	3SJ00-60110	Booklet finisher (2 of 5) on page 2207
Booklet c-fold blade motor assembly	JC90-01396A	Booklet finisher (2 of 5) on page 2207
Booklet diverter	JC90-01398A	Booklet finisher (2 of 5) on page 2207
Booklet diverter home sensor	0604-001415	Booklet finisher (2 of 5) on page 2207
Booklet diverter motor assembly	JC90-01397A	Booklet finisher (2 of 5) on page 2207
Booklet end fence	JC90-01432A	Booklet finisher (2 of 5) on page 2207
Booklet end fence home sensor	3SJ00-60110	Booklet finisher (2 of 5) on page 2207
Booklet end fence motor	JC93-01155A	Booklet finisher (2 of 5) on page 2207
Booklet entrance sensor	0604-001415	Booklet finisher (2 of 5) on page 2207
Booklet entrance-presser motor assembly	JC90-01425A	Booklet finisher (2 of 5) on page 2207
Booklet exit sensor	JC32-00020A	Booklet finisher (2 of 5) on page 2207
Booklet finisher	6GW51-67001	Booklet finisher (1 of 5) on page 2204
Booklet fold motor assembly	JC90-01436A	Booklet finisher (2 of 5) on page 2207
Booklet front cover	JC90-01478B	Booklet finisher (2 of 5) on page 2207
Booklet maker PCA	6GW51-60001	Booklet finisher (2 of 5) on page 2207
Booklet maker unit	5QK09-60104	Booklet finisher (1 of 5) on page 2204
Booklet output tray	8GS05-60126	Booklet finisher (1 of 5) on page 2204
Booklet output tray sensor	JC82-01039A	Booklet finisher (1 of 5) on page 2204
Booklet paddle home sensor	3SJ00-60110	Booklet finisher (2 of 5) on page 2207
Booklet paddle motor assembly	JC90-01430A	Booklet finisher (2 of 5) on page 2207
Booklet presser home sensor	3SJ00-60110	Booklet finisher (2 of 5) on page 2207

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Booklet stapler	6GW51-40001	Booklet finisher (2 of 5) on page 2207
Booklet stapler cartridge	JC81-09881B	Booklet finisher (2 of 5) on page 2207
Booklet tamper	JC90-01431A	Booklet finisher (2 of 5) on page 2207
Booklet tamper home sensor	3SJ00-60110	Booklet finisher (2 of 5) on page 2207
Booklet tamper motor	JC93-01155A	Booklet finisher (2 of 5) on page 2207
Booklet tamper sensor	JC32-00020A	Booklet finisher (2 of 5) on page 2207
Bridge door sensor	3SJ00-60110	Stapler/Stacker finisher (3 of 4) on page 2201
Bridge door sensor	3SJ00-60110	Booklet finisher (4 of 4) on page 2210
Bridge entrance sensor	JC32-00020A	Stapler/Stacker finisher (3 of 4) on page 2201
Bridge entrance sensor	JC32-00020A	Booklet finisher (4 of 4) on page 2210
Bridge exit sensor	3SJ00-60110	Stapler/Stacker finisher (3 of 4) on page 2201
Bridge exit sensor	3SJ00-60110	Booklet finisher (4 of 4) on page 2210
Bridge motor	3SJ19-80501	Stapler/Stacker finisher (3 of 4) on page 2201
Bridge motor	3SJ19-80501	Booklet finisher (4 of 4) on page 2210
Bridge unit	5QK09-60110	Stapler/Stacker finisher (3 of 4) on page 2201
Bridge unit	5QK09-60110	Booklet finisher (4 of 4) on page 2210
Buffer motor	JC93-01152A	Stapler/Stacker finisher (2 of 4) on page 2199
Buffer motor	JC93-01152A	Booklet finisher (3 of 5) on page 2208
Buffer solenoid assembly	JC90-01675A	Stapler/Stacker finisher (2 of 4) on page 2199
Buffer solenoid assembly	JC90-01675A	Booklet finisher (3 of 5) on page 2208
CTD sensor assembly	6ER04-60002	CTD on page 2176
Card reader rotation adapter kit	63C82-67029	Covers on page 2162
Caster	JC61-07452A	Stapler/Stacker finisher (1 of 4) on page 2198

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Caster	JC61-07452A	Booklet finisher (1 of 5) on page 2204
Caster cover	8GS05-40018	Stapler/Stacker finisher (1 of 4) on page 2198
Caster cover	8GS05-40018	Booklet finisher (1 of 5) on page 2204
Caster fix nut	JC61-07444A	Stapler/Stacker finisher (1 of 4) on page 2198
Caster fix nut	JC61-07444A	Booklet finisher (1 of 5) on page 2204
Caster wheel	6109-001138	DCF (1 of 2) on page 2192
Control-panel assembly 25.6 cm 10.1 in 2nd	5QK42-60104	PCA on page 2178
Control-panel assembly 25.6 cm 10.1 in 2nd	5QK42-60104	PCA on page 2178
Controller cover	6ER04-61005	Covers on page 2162
Cover Rear	3SJ11-40008	ISA on page 2183
Cover waste	5QK09-40109	Registration and loop sensors on page 2167
Cradle-Riser Card	5851-8707	PCA on page 2178
Cradle-Riser Card	5851-8707	PCA on page 2178
DCF	6GW47-67001	DCF (1 of 2) on page 2192
DCF Dpt_Door open switch sensor and harness	JC39-02268A	DCF (2 of 2) on page 2194
DCF feed drive assembly	JC93-01135A	DCF (2 of 2) on page 2194
DCF left cover	5QK08-40008	DCF (1 of 2) on page 2192
DCF rear cover	5QK08-40007	DCF (1 of 2) on page 2192
DCF right cover	5QK08-40006	DCF (1 of 2) on page 2192
DCF right door	5QK08-61004	DCF (1 of 2) on page 2192
Damper module	5QJ90-67006	200sh ADF (2 of 2) on page 2189
Damper module	Z9Y05-60016	300sh flow ADF (2 of 2) on page 2186
Developer fan assembly	5QK09-40083	Sensor and fan on page 2180
Developer powder kit	5PN82-67001	Developer on page 2174
Developer suction duct	JC93-01007A	Sensor and fan on page 2180
Developer, drum and PTB drive assembly	JC93-01662A	Drum on page 2175
Discrete power cable	3SJ11-50006	Tarot platen on page 2190
Drive-motor step	JC31-00189A	Tray 1 on page 2164
Drive-motor step	JC31-00189A	Tray 2, 3 on page 2165

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Drive-motor step	JC31-00189A	Registration and loop sensors on page 2167
Drive-motor step	JC93-00336A	Exit unit on page 2168
Drive-motor step	JC93-00336A	Exit unit on page 2168
Drive-motor step	JC93-01083A	Tray 2, 3 on page 2165
Drive-motor step	JC93-01083A	DCF (2 of 2) on page 2194
Drive-motor step	JC93-01085A	Duplex on page 2170
Drum and developer drive assembly	JC93-01662A	Developer on page 2174
Duplex assembly	JC95-02250A	Duplex on page 2170
Echo PCA (Not orderable and not used in printer.)	T3U64-60001 (Not orderable and not used in printer.)	PCA on page 2178
Echo PCA (Not orderable and not used in printer.)	T3U64-60001 (Not orderable and not used in printer.)	PCA on page 2178
Ejector sensor	JC32-00020A	Stapler/Stacker finisher (4 of 4) on page 2202
Ejector sensor	JC32-00020A	Booklet finisher (5 of 5) on page 2211
Ejector unit	JC90-01802A	Stapler/Stacker finisher (4 of 4) on page 2202
Ejector unit	JC90-01802A	Booklet finisher (5 of 5) on page 2211
Ejector1 home sensor	0604-001415	Stapler/Stacker finisher (4 of 4) on page 2202
Ejector1 home sensor	0604-001415	Booklet finisher (5 of 5) on page 2211
Ejector1 motor sensor	0604-001415	Stapler/Stacker finisher (4 of 4) on page 2202
Ejector1 motor sensor	0604-001415	Booklet finisher (5 of 5) on page 2211
Ejector2 motor sensor	0604-001415	Stapler/Stacker finisher (4 of 4) on page 2202
Ejector2 motor sensor	0604-001415	Booklet finisher (5 of 5) on page 2211
Electric clutch	JC47-00037A	Tray 1 on page 2164
End fence motor assembly	JC90-01467A	Stapler/Stacker finisher (2 of 4) on page 2199
End fence motor assembly	JC90-01467A	Booklet finisher (3 of 5) on page 2208
Entrance motor assembly	8GS05-60104	Stapler/Stacker finisher (2 of 4) on page 2199

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Entrance motor assembly	8GS05-60104	Booklet finisher (3 of 5) on page 2208
Exit cover stacker	6ER04-61004	Covers on page 2162
Exit motor assembly	8GS05-60106	Stapler/Stacker finisher (2 of 4) on page 2199
Exit motor assembly	8GS05-60106	Stapler/Stacker finisher (3 of 4) on page 2201
Exit motor assembly	8GS05-60106	Booklet finisher (3 of 5) on page 2208
Exit motor assembly	8GS05-60106	Booklet finisher (4 of 4) on page 2210
Exit rear cover	6ER04-40028	Covers on page 2162
Exit stack guide	JC90-01865A	Exit unit on page 2168
Exit unit	JC90-01856A	Exit unit on page 2168
Fan	JC31-00154A	Sensor and fan on page 2180
Fan	JC31-00198A	Sensor and fan on page 2180
Feed drive assembly	JC93-01664A	Tray 2, 3 on page 2165
Finisher mount bracket	JC90-01442A	Stapler/Stacker finisher (1 of 4) on page 2198
Finisher mount bracket	JC90-01442A	Booklet finisher (1 of 5) on page 2204
Formatter	6CF14-67002	PCA on page 2178
Formatter	6CF14-67002	PCA on page 2178
Frame sub-sensor paper size RU	JC93-01408A	Tray 2, 3 on page 2165
Frame sub-sensor paper size RU	JC93-01408A	Tray 2, 3 on page 2165
Frame sub-sensor paper size RU	JC93-01408A	DCF (2 of 2) on page 2194
Frame sub-sensor paper size RU	JC93-01408A	DCF (2 of 2) on page 2194
Front cover	5QK09-40019	Stapler/Stacker finisher (1 of 4) on page 2198
Front cover	5QK09-40019	Booklet finisher (1 of 5) on page 2204
Front cover - Blue CMF Panel	6ER04-40003	Covers on page 2162
Front cover assembly	6ER08-61001	Covers on page 2162
Front door	5QK09-60106	Stapler/Stacker finisher (1 of 4) on page 2198
Front door	5QK09-60106	Booklet finisher (1 of 5) on page 2204
Front door open switch	JC93-00466A	Sensor and fan on page 2180
Front door switch	JC39-02309A	Stapler/Stacker finisher (2 of 4) on page 2199

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Front door switch	JC39-02309A	Booklet finisher (3 of 5) on page 2208
Front lower cover	5QK09-40020	Stapler/Stacker finisher (1 of 4) on page 2198
Front lower cover	5QK09-40020	Booklet finisher (1 of 5) on page 2204
Front lower cover	6ER04-40030	Covers on page 2162
Front lower left cover	5QK09-40047	Stapler/Stacker finisher (1 of 4) on page 2198
Front lower left cover	5QK09-40047	Booklet finisher (1 of 5) on page 2204
Front lower right cover	5QK09-40048	Stapler/Stacker finisher (1 of 4) on page 2198
Front lower right cover	5QK09-40048	Booklet finisher (1 of 5) on page 2204
Front paper holding sensor	3SJ00-60110	Stapler/Stacker finisher (1 of 4) on page 2198
Front paper holding sensor	3SJ00-60110	Booklet finisher (1 of 5) on page 2204
Front tamper	JC82-00901A	Stapler/Stacker finisher (4 of 4) on page 2202
Front tamper	JC82-00901A	Booklet finisher (5 of 5) on page 2211
Front tamper home sensor	3SJ00-60110	Stapler/Stacker finisher (4 of 4) on page 2202
Front tamper home sensor	3SJ00-60110	Booklet finisher (5 of 5) on page 2211
Front tamper motor	JC93-01001A	Stapler/Stacker finisher (4 of 4) on page 2202
Front tamper motor	JC93-01001A	Booklet finisher (5 of 5) on page 2211
Fuser and exit drive assembly	JC93-01850A	Exit unit on page 2168
Fuser drive board (FDB), 220V	JC44-00236C	PCA on page 2178
Fuser drive board (FDB), 220V	JC44-00236C	PCA on page 2178
Guide - adjust	JC61-04871A	DCF (1 of 2) on page 2192
HIP cover	6EQ94-40032	Covers on page 2162
HP LaserJet 180ipm 200 sheet DADF Scanner	5QK35-67002	ISA on page 2183
HP LaserJet 300ipm 300 sheet Flow DADF Scanner	5QK37-67002	ISA on page 2183
HV rear frame assembly	5QK09-64014	PTB on page 2177
High Voltage Power Supply (HVPS)	5QK09-60001	PCA on page 2178
High Voltage Power Supply (HVPS)	5QK09-60001	PCA on page 2178

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Hinge Kit	5QJ90-67004	200sh ADF (2 of 2) on page 2189
Inner cover	9S185-60007	Covers on page 2162
Island of Data (IOD) PCA	3SJ06-60001	PCA on page 2178
Island of Data (IOD) PCA	3SJ06-60001	PCA on page 2178
Keyboard (drawer type) Assy – E8 series UK English	63C82-67005	PCA on page 2178
Keyboard (drawer type) Assy – E8 series UK English	63C82-67005	PCA on page 2178
Keyboard (drawer type) Assy – E8 series US English	63C82-67003	PCA on page 2178
Keyboard (drawer type) Assy – E8 series US English	63C82-67003	PCA on page 2178
Keyboard Assy-UK English	JC93-01743A	PCA on page 2178
Keyboard Assy-UK English	JC93-01743A	PCA on page 2178
Keyboard overlay kit (ES, PT)	5851-6023	PCA on page 2178
Keyboard overlay kit (ES, PT)	5851-6023	PCA on page 2178
Keyboard overlay kit (FR, IT, RU, DE,ES,UK Kybd)	5851-6019	PCA on page 2178
Keyboard overlay kit (FR, IT, RU, DE,ES,UK Kybd)	5851-6019	PCA on page 2178
Keyboard overlay kit (FR-CN, ES-LA, ES,US Kybd)	5851-6020	PCA on page 2178
Keyboard overlay kit (FR-CN, ES-LA, ES,US Kybd)	5851-6020	PCA on page 2178
Keyboard overlay kit (FR-SW, DE-SW, DA,UK Kybd)	5851-6021	PCA on page 2178
Keyboard overlay kit (FR-SW, DE-SW, DA,UK Kybd)	5851-6021	PCA on page 2178
Keyboard overlay kit (JA-KG, JA-KT)	5851-6024	PCA on page 2178
Keyboard overlay kit (JA-KG, JA-KT)	5851-6024	PCA on page 2178
Keyboard overlay kit (ZHTW, ZHCN)	5851-6022	PCA on page 2178
Keyboard overlay kit (ZHTW, ZHCN)	5851-6022	PCA on page 2178
Kit-Screws c-clips e-clips kit	X3A92-67924	Covers on page 2162
LSU fan assembly	5QK09-64013	Sensor and fan on page 2180
LVPS FDB fan assembly	JC93-01795A	Sensor and fan on page 2180
Laser scanner unit (LSU)	JC97-05147A	Laser scanner unit on page 2173
Left cover	6ER04-40049	Covers on page 2162
Left lower cover	8GS05-60122	Stapler/Stacker finisher (1 of 4) on page 2198
Left lower cover (Booklet)	8GS05-60124	Booklet finisher (1 of 5) on page 2204
Left top cover	JC63-04862B	Covers on page 2162
Left upper cover	8GS05-60118	Stapler/Stacker finisher (1 of 4) on page 2198

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Left upper cover	8GS05-60118	Booklet finisher (1 of 5) on page 2204
Loop actuator	JC66-04572A	Registration and loop sensors on page 2167
Low Voltage Power Supply (LVPS), 110V	JC44-00149C	PCA on page 2178
Low Voltage Power Supply (LVPS), 110V	JC44-00149C	PCA on page 2178
Low Voltage Power Supply (LVPS), 220V	JC44-00150C	PCA on page 2178
Low Voltage Power Supply (LVPS), 220V	JC44-00150C	PCA on page 2178
Main PCA	6GW55-60001	Stapler/Stacker finisher (2 of 4) on page 2199
Main PCA	6GW55-60001	Booklet finisher (3 of 5) on page 2208
Main exit cam home sensor	3SJ00-60110	Stapler/Stacker finisher (2 of 4) on page 2199
Main exit cam home sensor	3SJ00-60110	Booklet finisher (3 of 5) on page 2208
Main exit cam motor assembly	JC90-01453A	Stapler/Stacker finisher (2 of 4) on page 2199
Main exit cam motor assembly	JC90-01453A	Booklet finisher (3 of 5) on page 2208
Main exit sensor	JC32-00020A	Stapler/Stacker finisher (3 of 4) on page 2201
Main exit sensor	JC32-00020A	Booklet finisher (4 of 4) on page 2210
Main output tray	5QK09-40028	Stapler/Stacker finisher (1 of 4) on page 2198
Main output tray	5QK09-40028	Booklet finisher (1 of 5) on page 2204
Main output tray lower limit sensor	0604-001415	Stapler/Stacker finisher (1 of 4) on page 2198
Main output tray lower limit sensor	0604-001415	Booklet finisher (1 of 5) on page 2204
Main output tray motor drive assembly	JC90-01415B	Stapler/Stacker finisher (2 of 4) on page 2199
Main output tray motor drive assembly	JC90-01415B	Booklet finisher (3 of 5) on page 2208
Main output tray motor sensor	3SJ00-60110	Stapler/Stacker finisher (2 of 4) on page 2199
Main output tray motor sensor	3SJ00-60110	Booklet finisher (3 of 5) on page 2208
Main output tray top of stack sensor	JC82-01039A	Stapler/Stacker finisher (1 of 4) on page 2198

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Main output tray top of stack sensor	JC82-01039A	Booklet finisher (1 of 5) on page 2204
Main output tray top of stack switch	JC39-02316A	Stapler/Stacker finisher (2 of 4) on page 2199
Main output tray top of stack switch	JC39-02316A	Booklet finisher (3 of 5) on page 2208
Manual staple senor	0604-001415	Stapler/Stacker finisher (2 of 4) on page 2199
Manual staple senor	0604-001415	Booklet finisher (3 of 5) on page 2208
Middle left cover	6ER04-40036	Covers on page 2162
Middle upper cover	6ER04-40026	Covers on page 2162
Motor BLDC	JC31-00144G	Exit unit on page 2168
Motor, step	JC31-00177A	DCF (2 of 2) on page 2194
Outer environment sensor assembly	5QJ90-40002	Sensor and fan on page 2180
PCA - power key	3SJ33-60007	PCA on page 2178
PCA - power key	3SJ33-60007	PCA on page 2178
PCA -power key	3SJ33-60007	Covers on page 2162
PCA-DCF Department	6GW47-60001	DCF (2 of 2) on page 2194
Paddle	JC90-01480A	Stapler/Stacker finisher (2 of 4) on page 2199
Paddle	JC90-01480A	Booklet finisher (3 of 5) on page 2208
Paddle home sensor	3SJ00-60110	Stapler/Stacker finisher (2 of 4) on page 2199
Paddle home sensor	3SJ00-60110	Booklet finisher (3 of 5) on page 2208
Paddle motor assembly	JC90-01461A	Stapler/Stacker finisher (2 of 4) on page 2199
Paddle motor assembly	JC90-01461A	Booklet finisher (3 of 5) on page 2208
Paper Transfer Belt (PTB) kit	5PN85-67001	PTB on page 2177
Paper holding home sensor	3SJ00-60110	Stapler/Stacker finisher (1 of 4) on page 2198
Paper holding home sensor	3SJ00-60110	Booklet finisher (1 of 5) on page 2204
Paper holding motor drive assembly	JC90-01414A	Stapler/Stacker finisher (2 of 4) on page 2199
Paper holding motor drive assembly	JC90-01414A	Booklet finisher (3 of 5) on page 2208
Paper sensor	0960-5271	Registration and loop sensors on page 2167

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Photo interrupter	0604-001381	Tray 2, 3 on page 2165
Photo interrupter	0604-001381	Registration and loop sensors on page 2167
Photo interrupter	0604-001381	DCF (2 of 2) on page 2194
Photo interrupter	0604-001490	Tray 1 on page 2164
Photo interrupter	0604-001490	Tray 2, 3 on page 2165
Photo interrupter	0604-001490	Tray 2, 3 on page 2165
Photo interrupter	0604-001490	DCF (2 of 2) on page 2194
Photo interrupter	3SJ00-60110	Tray 2, 3 on page 2165
Photo interrupter	3SJ00-60110	Tray 2, 3 on page 2165
Photo interrupter	3SJ00-60110	Registration and loop sensors on page 2167
Photo interrupter	3SJ00-60110	Exit unit on page 2168
Photo interrupter	3SJ00-60110	Exit unit on page 2168
Photo interrupter	3SJ00-60110	Exit unit on page 2168
Photo interrupter	3SJ00-60110	Exit unit on page 2168
Photo interrupter	3SJ00-60110	Duplex on page 2170
Photo interrupter	3SJ00-60110	Toner on page 2170
Photo interrupter	3SJ00-60110	Toner collection unit on page 2172
Photo interrupter	3SJ00-60110	Tarot platen on page 2190
Photo interrupter	3SJ00-60110	DCF (2 of 2) on page 2194
Photo interrupter	3SJ00-60110	DCF (2 of 2) on page 2194
Power key	6EQ94-40029	Covers on page 2162
Punch cover	5QK09-40030	Stapler/Stacker finisher (1 of 4) on page 2198
Punch cover	5QK09-40030	Booklet finisher (1 of 5) on page 2204
Punch unit 2-3 hole	Y1G10-67901	Stapler/Stacker finisher (2 of 4) on page 2199
Punch unit 2-3 hole	Y1G10-67901	Booklet finisher (3 of 5) on page 2208
Punch unit 2-4 hole	Y1G11-67901	Stapler/Stacker finisher (2 of 4) on page 2199
Punch unit 2-4 hole	Y1G11-67901	Booklet finisher (3 of 5) on page 2208
Punch unit Swedish hole	Y1G12-67901	Booklet finisher (3 of 5) on page 2208

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Rear cover	5QK09-40021	Stapler/Stacker finisher (1 of 4) on page 2198
Rear cover	5QK09-40021	Booklet finisher (1 of 5) on page 2204
Rear lower cover	6ER04-40019	Covers on page 2162
Rear paper holding sensor	3SJ00-60110	Stapler/Stacker finisher (1 of 4) on page 2198
Rear paper holding sensor	3SJ00-60110	Booklet finisher (1 of 5) on page 2204
Rear tamper	JC82-00898A	Stapler/Stacker finisher (4 of 4) on page 2202
Rear tamper	JC82-00898A	Booklet finisher (5 of 5) on page 2211
Rear tamper home sensor	3SJ00-60110	Stapler/Stacker finisher (4 of 4) on page 2202
Rear tamper home sensor	3SJ00-60110	Booklet finisher (5 of 5) on page 2211
Rear tamper motor	JC93-01001A	Stapler/Stacker finisher (4 of 4) on page 2202
Rear tamper motor	JC93-01001A	Booklet finisher (5 of 5) on page 2211
Rear upper cover	6ER04-40008	Covers on page 2162
Registration drive assembly	JC93-01665A	Registration and loop sensors on page 2167
Registration unit assembly	5QK13-60101	Registration and loop sensors on page 2167
Reservoir unit	X3A79-60003	Reservoir on page 2171
Right door assembly	JC95-02246A	Covers on page 2162
Right door assembly	JC95-02246A	Tray 1 on page 2164
Right door assembly	JC95-02246A	Registration and loop sensors on page 2167
Right door assembly	JC95-02246A	Duplex on page 2170
Right door exit assembly	JC95-02249A	Registration and loop sensors on page 2167
Right door front damper	JC66-01425A	Tray 1 on page 2164
Right door front damper bracket	JC61-08935A	Tray 1 on page 2164
Right door front link	JC66-04398A	Tray 1 on page 2164
Right door open switch holder assy	JC90-01385A	DCF (2 of 2) on page 2194
Right door sHCI dummy cover	JC63-04918B	Covers on page 2162
Right front cover	6ER04-40005	Covers on page 2162
Right middle cover	6ER04-40025	Covers on page 2162

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Right middle cover assembly	6ER04-61006	Covers on page 2162
Right rear cover	6ER04-61003	Covers on page 2162
Right upper cover	5QK09-60109	Stapler/Stacker finisher (1 of 4) on page 2198
Right upper cover	5QK09-60109	Booklet finisher (1 of 5) on page 2204
Right upper cover	6ER04-40021	Covers on page 2162
Riser for HDD, USB ports, Accelerator	3SJ02-60001	PCA on page 2178
Riser for HDD, USB ports, Accelerator	3SJ02-60001	PCA on page 2178
Riser for SSD	3SJ01-60002	PCA on page 2178
Riser for SSD	3SJ01-60002	PCA on page 2178
Rivet-Echo PCA (Not orderable and not used in printer.)	6ER04-40034 (Not orderable and not used in printer.)	PCA on page 2178
Rivet-Echo PCA (Not orderable and not used in printer.)	6ER04-40034 (Not orderable and not used in printer.)	PCA on page 2178
Rivet-SSD	6ER04-40035	PCA on page 2178
Rivet-SSD	6ER04-40035	PCA on page 2178
SVC-A3 White Backing Kit	5QK08-67005SVC-A3 White Backing Kit	300sh flow ADF (2 of 2) on page 2186
SVC-Flat Cable, Tarot SCB 50pin	5QK08-67011	Tarot platen on page 2190
SVC-Flat Cable, Tarot SCB 68pin	5QK08-67012	Tarot platen on page 2190
SVC-Hinge Kit (right, middle, left)	5QK08-67003	300sh flow ADF (2 of 2) on page 2186
SVC-Internal USB Expansion Kit	4XN67-67001	PCA on page 2178
SVC-Internal USB Expansion Kit	4XN67-67001	PCA on page 2178
SVC_HP LaserJet Black Developer Unit	5PN82-67002	Developer on page 2174
SVC_HP LaserJet Black Managed Imaging Drum	W1766-67001	Drum on page 2175
Shaft hinge - door	JC66-04767A	Stapler/Stacker finisher (1 of 4) on page 2198
Shaft hinge - door	JC66-04767A	Booklet finisher (1 of 5) on page 2204
Single Fax Card (BBU) (Optional)	7ZA09-67001	PCA on page 2178
Single Fax Card (BBU) (Optional)	7ZA09-67001	PCA on page 2178
Single Fax Card (WW) (Optional)	7ZA08-67001	PCA on page 2178
Single Fax Card (WW) (Optional)	7ZA08-67001	PCA on page 2178
Solenoid, lifting	JC33-00031B	Exit unit on page 2168

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Staple cartridge	JC81-09882B	Stapler/Stacker finisher (4 of 4) on page 2202
Staple cartridge	JC81-09882B	Booklet finisher (5 of 5) on page 2211
Staple front sensor	3SJ00-60110	Stapler/Stacker finisher (4 of 4) on page 2202
Staple front sensor	3SJ00-60110	Booklet finisher (5 of 5) on page 2211
Staple mid-front sensor	3SJ00-60110	Stapler/Stacker finisher (4 of 4) on page 2202
Staple mid-front sensor	3SJ00-60110	Booklet finisher (5 of 5) on page 2211
Staple mid-rear sensor	3SJ00-60110	Stapler/Stacker finisher (4 of 4) on page 2202
Staple mid-rear sensor	3SJ00-60110	Booklet finisher (5 of 5) on page 2211
Staple position motor	JC31-00163A	Stapler/Stacker finisher (4 of 4) on page 2202
Staple position motor	JC31-00163A	Booklet finisher (5 of 5) on page 2211
Staple rear sensor	3SJ00-60110	Stapler/Stacker finisher (4 of 4) on page 2202
Staple rear sensor	3SJ00-60110	Booklet finisher (5 of 5) on page 2211
Staple unit	JC82-00894A	Stapler/Stacker finisher (4 of 4) on page 2202
Staple unit	JC82-00894A	Booklet finisher (5 of 5) on page 2211
Stapler/Stacker finisher	6GW55-67001	Stapler/Stacker finisher (1 of 4) on page 2198
Switch	JC93-01467A	Sensor and fan on page 2180
TPM	3SJ03-60001 (Not Orderable)	PCA on page 2178
TPM	3SJ03-60001 (Not Orderable)	PCA on page 2178
Tarot platen	3SJ11-60103	ISA on page 2183
Tarot platen PCA	Y6V12-60035	Tarot platen on page 2190
Thermistor	1404-001417	Sensor and fan on page 2180
Tie stopper	JC61-04626A	Covers on page 2162
Toner cartridge -standard yield	W1760-67002	Toner on page 2170
Toner collection full sensor assembly	JC93-00492A	Toner collection unit on page 2172

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Toner collection unit	9U1Q5-67001	Toner collection unit on page 2172
Toner dispense motor	SS216-80501	Toner on page 2170
Toner dispense motor assembly	JC93-01667A	Toner on page 2170
Top cover	5QK09-60108	Stapler/Stacker finisher (1 of 4) on page 2198
Top cover	5QK09-60108	Booklet finisher (1 of 5) on page 2204
Top door	5QK09-60107	Stapler/Stacker finisher (1 of 4) on page 2198
Top door	5QK09-60107	Booklet finisher (1 of 5) on page 2204
Top exit sensor	3SJ00-60110	Stapler/Stacker finisher (3 of 4) on page 2201
Top exit sensor	3SJ00-60110	Booklet finisher (4 of 4) on page 2210
Top jam cover assembly	JC90-01455A	Stapler/Stacker finisher (2 of 4) on page 2199
Top jam cover assembly	JC90-01455A	Booklet finisher (3 of 5) on page 2208
Top lower feed assembly	JC90-01454A	Stapler/Stacker finisher (3 of 4) on page 2201
Top lower feed assembly	JC90-01454A	Booklet finisher (4 of 4) on page 2210
Top output tray	5QK09-40027	Stapler/Stacker finisher (1 of 4) on page 2198
Top output tray	5QK09-40027	Booklet finisher (1 of 5) on page 2204
Top output tray paper full sensor	JC82-01039A	Stapler/Stacker finisher (2 of 4) on page 2199
Top output tray paper full sensor	JC82-01039A	Booklet finisher (3 of 5) on page 2208
Tray 1 roller kit	5RC03-67001	Tray 1 on page 2164
Tray 1 unit	JC90-01844A	Tray 1 on page 2164
Tray 2 cassette		Tray 2, 3 on page 2165
Tray 2 cover - Blue CMF panel	5QK09-40055	Covers on page 2162
Tray 2 pickup assembly	JC93-01694A	Tray 2, 3 on page 2165
Tray 2 pickup drive assembly	JC93-01663A	Tray 2, 3 on page 2165
Tray 2, 3 roller kit	5PN66-67001	Tray 2, 3 on page 2165
Tray 3	5QK09-60121	Covers on page 2162
Tray 3 cassette	5QK09-60121	Tray 2, 3 on page 2165

Table 6-35 Alphabetical parts list (continued)

Description	Part number	Table and page
Tray 3 cover - Blue CMF panel	5QK09-40058	Covers on page 2162
Tray 3 pickup assembly	JC93-01695A	Tray 2, 3 on page 2165
Tray 3 pickup drive assembly	JC93-01663A	Tray 2, 3 on page 2165
Tray 4 Blue CMF panel	5QK08-40011	DCF (1 of 2) on page 2192
Tray 4 cassette	5QK08-61007	DCF (1 of 2) on page 2192
Tray 4 cassette	5QK08-61007	DCF (2 of 2) on page 2194
Tray 4 pickup assembly	5QK08-61009	DCF (2 of 2) on page 2194
Tray 4 pickup drive assembly	JC93-01663A	DCF (2 of 2) on page 2194
Tray 4, 5 roller kit	5PN66-67001	DCF (2 of 2) on page 2194
Tray 5 Blue CMF panel	5QK08-40012	DCF (1 of 2) on page 2192
Tray 5 cassette	5QK08-61005	DCF (1 of 2) on page 2192
Tray 5 cassette	5QK08-61005	DCF (2 of 2) on page 2194
Tray 5 pickup assembly	5QK08-61010	DCF (2 of 2) on page 2194
Tray 5 pickup drive assembly	JC93-01663A	DCF (2 of 2) on page 2194
Tray diverter cam	JC90-01458A	Stapler/Stacker finisher (2 of 4) on page 2199
Tray diverter cam	JC90-01458A	Booklet finisher (3 of 5) on page 2208
Tray diverter home sensor	0604-001415	Stapler/Stacker finisher (2 of 4) on page 2199
Tray diverter home sensor	0604-001415	Booklet finisher (3 of 5) on page 2208
Tray extension	5QK09-40029	Stapler/Stacker finisher (1 of 4) on page 2198
Tray extension	5QK09-40029	Booklet finisher (1 of 5) on page 2204
Tray heater 110V	Y1G22-67901	Tray 2, 3 on page 2165
Tray heater 110V	Y1G22-67901	DCF (2 of 2) on page 2194
Tray heater 220V	Y1G22-67902	Tray 2, 3 on page 2165
Tray heater 220V	Y1G22-67902	DCF (2 of 2) on page 2194
Tray sub-auto closing unit	JC90-01677A	DCF (1 of 2) on page 2192
Tray sub-auto closing unit	JC93-01370A	Tray 2, 3 on page 2165
USB Hub PCA	3SJ04-60002	PCA on page 2178
USB Hub PCA	3SJ04-60002	PCA on page 2178

Numerical parts list

Table 6-36 Numerical parts list

Part number	Description	Table and page
	Tray 2 cassette	Tray 2, 3 on page 2165
0604-001381	Photo interrupter	Tray 2, 3 on page 2165
0604-001381	Photo interrupter	Registration and loop sensors on page 2167
0604-001381	Photo interrupter	DCF (2 of 2) on page 2194
0604-001415	Booklet diverter home sensor	Booklet finisher (2 of 5) on page 2207
0604-001415	Booklet entrance sensor	Booklet finisher (2 of 5) on page 2207
0604-001415	Ejector1 home sensor	Stapler/Stacker finisher (4 of 4) on page 2202
0604-001415	Ejector1 home sensor	Booklet finisher (5 of 5) on page 2211
0604-001415	Ejector1 motor sensor	Stapler/Stacker finisher (4 of 4) on page 2202
0604-001415	Ejector1 motor sensor	Booklet finisher (5 of 5) on page 2211
0604-001415	Ejector2 motor sensor	Stapler/Stacker finisher (4 of 4) on page 2202
0604-001415	Ejector2 motor sensor	Booklet finisher (5 of 5) on page 2211
0604-001415	Main output tray lower limit sensor	Stapler/Stacker finisher (1 of 4) on page 2198
0604-001415	Main output tray lower limit sensor	Booklet finisher (1 of 5) on page 2204
0604-001415	Manual staple senor	Stapler/Stacker finisher (2 of 4) on page 2199
0604-001415	Manual staple senor	Booklet finisher (3 of 5) on page 2208
0604-001415	Tray diverter home sensor	Stapler/Stacker finisher (2 of 4) on page 2199
0604-001415	Tray diverter home sensor	Booklet finisher (3 of 5) on page 2208
0604-001490	Photo interrupter	Tray 1 on page 2164
0604-001490	Photo interrupter	Tray 2, 3 on page 2165
0604-001490	Photo interrupter	Tray 2, 3 on page 2165
0604-001490	Photo interrupter	DCF (2 of 2) on page 2194
0960-5271	Paper sensor	Registration and loop sensors on page 2167
1404-001417	Thermistor	Sensor and fan on page 2180

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
3SJ00-60110	Booklet blade home sensor	Booklet finisher (2 of 5) on page 2207
3SJ00-60110	Booklet c-fold blade home sensor	Booklet finisher (2 of 5) on page 2207
3SJ00-60110	Booklet end fence home sensor	Booklet finisher (2 of 5) on page 2207
3SJ00-60110	Booklet paddle home sensor	Booklet finisher (2 of 5) on page 2207
3SJ00-60110	Booklet presser home sensor	Booklet finisher (2 of 5) on page 2207
3SJ00-60110	Booklet tamper home sensor	Booklet finisher (2 of 5) on page 2207
3SJ00-60110	Bridge door sensor	Stapler/Stacker finisher (3 of 4) on page 2201
3SJ00-60110	Bridge door sensor	Booklet finisher (4 of 4) on page 2210
3SJ00-60110	Bridge exit sensor	Stapler/Stacker finisher (3 of 4) on page 2201
3SJ00-60110	Bridge exit sensor	Booklet finisher (4 of 4) on page 2210
3SJ00-60110	Front paper holding sensor	Stapler/Stacker finisher (1 of 4) on page 2198
3SJ00-60110	Front paper holding sensor	Booklet finisher (1 of 5) on page 2204
3SJ00-60110	Front tamper home sensor	Stapler/Stacker finisher (4 of 4) on page 2202
3SJ00-60110	Front tamper home sensor	Booklet finisher (5 of 5) on page 2211
3SJ00-60110	Main exit cam home sensor	Stapler/Stacker finisher (2 of 4) on page 2199
3SJ00-60110	Main exit cam home sensor	Booklet finisher (3 of 5) on page 2208
3SJ00-60110	Main output tray motor sensor	Stapler/Stacker finisher (2 of 4) on page 2199
3SJ00-60110	Main output tray motor sensor	Booklet finisher (3 of 5) on page 2208
3SJ00-60110	Paddle home sensor	Stapler/Stacker finisher (2 of 4) on page 2199
3SJ00-60110	Paddle home sensor	Booklet finisher (3 of 5) on page 2208
3SJ00-60110	Paper holding home sensor	Stapler/Stacker finisher (1 of 4) on page 2198
3SJ00-60110	Paper holding home sensor	Booklet finisher (1 of 5) on page 2204

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
3SJ00-60110	Photo interrupter	Tray 2, 3 on page 2165
3SJ00-60110	Photo interrupter	Tray 2, 3 on page 2165
3SJ00-60110	Photo interrupter	Registration and loop sensors on page 2167
3SJ00-60110	Photo interrupter	Exit unit on page 2168
3SJ00-60110	Photo interrupter	Exit unit on page 2168
3SJ00-60110	Photo interrupter	Exit unit on page 2168
3SJ00-60110	Photo interrupter	Exit unit on page 2168
3SJ00-60110	Photo interrupter	Duplex on page 2170
3SJ00-60110	Photo interrupter	Toner on page 2170
3SJ00-60110	Photo interrupter	Toner collection unit on page 2172
3SJ00-60110	Photo interrupter	Tarot platen on page 2190
3SJ00-60110	Photo interrupter	DCF (2 of 2) on page 2194
3SJ00-60110	Photo interrupter	DCF (2 of 2) on page 2194
3SJ00-60110	Rear paper holding sensor	Stapler/Stacker finisher (1 of 4) on page 2198
3SJ00-60110	Rear paper holding sensor	Booklet finisher (1 of 5) on page 2204
3SJ00-60110	Rear tamper home sensor	Stapler/Stacker finisher (4 of 4) on page 2202
3SJ00-60110	Rear tamper home sensor	Booklet finisher (5 of 5) on page 2211
3SJ00-60110	Staple front sensor	Stapler/Stacker finisher (4 of 4) on page 2202
3SJ00-60110	Staple front sensor	Booklet finisher (5 of 5) on page 2211
3SJ00-60110	Staple mid-front sensor	Stapler/Stacker finisher (4 of 4) on page 2202
3SJ00-60110	Staple mid-front sensor	Booklet finisher (5 of 5) on page 2211
3SJ00-60110	Staple mid-rear sensor	Stapler/Stacker finisher (4 of 4) on page 2202
3SJ00-60110	Staple mid-rear sensor	Booklet finisher (5 of 5) on page 2211
3SJ00-60110	Staple rear sensor	Stapler/Stacker finisher (4 of 4) on page 2202
3SJ00-60110	Staple rear sensor	Booklet finisher (5 of 5) on page 2211
3SJ00-60110	Top exit sensor	Stapler/Stacker finisher (3 of 4) on page 2201

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
3SJ00-60110	Top exit sensor	Booklet finisher (4 of 4) on page 2210
3SJ01-60002	Riser for SSD	PCA on page 2178
3SJ01-60002	Riser for SSD	PCA on page 2178
3SJ02-60001	Riser for HDD, USB ports, Accelerator	PCA on page 2178
3SJ02-60001	Riser for HDD, USB ports, Accelerator	PCA on page 2178
3SJ03-60001 (Not Orderable)	TPM	PCA on page 2178
3SJ03-60001 (Not Orderable)	TPM	PCA on page 2178
3SJ04-60002	USB Hub PCA	PCA on page 2178
3SJ04-60002	USB Hub PCA	PCA on page 2178
3SJ06-60001	Island of Data (IOD) PCA	PCA on page 2178
3SJ06-60001	Island of Data (IOD) PCA	PCA on page 2178
3SJ11-40008	Cover Rear	ISA on page 2183
3SJ11-50006	Discrete power cable	Tarot platen on page 2190
3SJ11-60103	Tarot platen	ISA on page 2183
3SJ19-80501	Bridge motor	Stapler/Stacker finisher (3 of 4) on page 2201
3SJ19-80501	Bridge motor	Booklet finisher (4 of 4) on page 2210
3SJ33-60007	PCA - power key	PCA on page 2178
3SJ33-60007	PCA - power key	PCA on page 2178
3SJ33-60007	PCA -power key	Covers on page 2162
4XN67-67001	SVC-Internal USB Expansion Kit	PCA on page 2178
4XN67-67001	SVC-Internal USB Expansion Kit	PCA on page 2178
5851-6019	Keyboard overlay kit (FR, IT, RU, DE,ES,UK Kybd)	PCA on page 2178
5851-6019	Keyboard overlay kit (FR, IT, RU, DE,ES,UK Kybd)	PCA on page 2178
5851-6020	Keyboard overlay kit (FR-CN, ES-LA, ES,US Kybd)	PCA on page 2178
5851-6020	Keyboard overlay kit (FR-CN, ES-LA, ES,US Kybd)	PCA on page 2178
5851-6021	Keyboard overlay kit (FR-SW, DE-SW, DA,UK Kybd)	PCA on page 2178
5851-6021	Keyboard overlay kit (FR-SW, DE-SW, DA,UK Kybd)	PCA on page 2178
5851-6022	Keyboard overlay kit (ZHTW, ZHCN)	PCA on page 2178
5851-6022	Keyboard overlay kit (ZHTW, ZHCN)	PCA on page 2178
5851-6023	Keyboard overlay kit (ES, PT)	PCA on page 2178
5851-6023	Keyboard overlay kit (ES, PT)	PCA on page 2178

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
5851-6024	Keyboard overlay kit (JA-KG, JA-KT)	PCA on page 2178
5851-6024	Keyboard overlay kit (JA-KG, JA-KT)	PCA on page 2178
5851-7202	ADF roller kit	200sh ADF (2 of 2) on page 2189
5851-8707	Cradle-Riser Card	PCA on page 2178
5851-8707	Cradle-Riser Card	PCA on page 2178
5PN66-67001	Tray 2, 3 roller kit	Tray 2, 3 on page 2165
5PN66-67001	Tray 4, 5 roller kit	DCF (2 of 2) on page 2194
5PN82-67001	Developer powder kit	Developer on page 2174
5PN82-67002	SVC_HP LaserJet Black Developer Unit	Developer on page 2174
5PN85-67001	Paper Transfer Belt (PTB) kit	PTB on page 2177
5QJ90-40002	Outer environment sensor assembly	Sensor and fan on page 2180
5QJ90-40041	ADF rear cover	300sh flow ADF (1 of 2) on page 2185
5QJ90-40049	ADF front cover	300sh flow ADF (1 of 2) on page 2185
5QJ90-40054	ADF top cover	300sh flow ADF (1 of 2) on page 2185
5QJ90-40056	ADF Blue CMF panel	300sh flow ADF (1 of 2) on page 2185
5QJ90-40056	ADF Blue CMF panel	200sh ADF (1 of 2) on page 2188
5QJ90-67004	Hinge Kit	200sh ADF (2 of 2) on page 2189
5QJ90-67006	Damper module	200sh ADF (2 of 2) on page 2189
5QJ90-67009	ADF FFC cable to SSA	200sh ADF (2 of 2) on page 2189
5QJ90-67010	ADF Power cable	200sh ADF (2 of 2) on page 2189
5QJ90-67011	200sh ADF	ISA on page 2183
5QJ90-67013	200sh ENT ADF PCA	200sh ADF (2 of 2) on page 2189
5QK08-40006	DCF right cover	DCF (1 of 2) on page 2192
5QK08-40007	DCF rear cover	DCF (1 of 2) on page 2192
5QK08-40008	DCF left cover	DCF (1 of 2) on page 2192
5QK08-40011	Tray 4 Blue CMF panel	DCF (1 of 2) on page 2192
5QK08-40012	Tray 5 Blue CMF panel	DCF (1 of 2) on page 2192
5QK08-61004	DCF right door	DCF (1 of 2) on page 2192
5QK08-61005	Tray 5 cassette	DCF (1 of 2) on page 2192

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
5QK08-61005	Tray 5 cassette	DCF (2 of 2) on page 2194
5QK08-61007	Tray 4 cassette	DCF (1 of 2) on page 2192
5QK08-61007	Tray 4 cassette	DCF (2 of 2) on page 2194
5QK08-61009	Tray 4 pickup assembly	DCF (2 of 2) on page 2194
5QK08-61010	Tray 5 pickup assembly	DCF (2 of 2) on page 2194
5QK08-67003	SVC-Hinge Kit (right, middle, left)	300sh flow ADF (2 of 2) on page 2186
5QK08-67005	A3 White Backing Kit	200sh ADF (2 of 2) on page 2189
5QK08-67005SVC-A3 White Backing Kit	SVC-A3 White Backing Kit	300sh flow ADF (2 of 2) on page 2186
5QK08-67011	SVC-Flat Cable, Tarot SCB 50pin	Tarot platen on page 2190
5QK08-67012	SVC-Flat Cable, Tarot SCB 68pin	Tarot platen on page 2190
5QK08-67014	300sh flow ADF (does not include white backing or suspension clips)	ISA on page 2183
5QK09-40019	Front cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40019	Front cover	Booklet finisher (1 of 5) on page 2204
5QK09-40020	Front lower cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40020	Front lower cover	Booklet finisher (1 of 5) on page 2204
5QK09-40021	Rear cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40021	Rear cover	Booklet finisher (1 of 5) on page 2204
5QK09-40027	Top output tray	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40027	Top output tray	Booklet finisher (1 of 5) on page 2204
5QK09-40028	Main output tray	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40028	Main output tray	Booklet finisher (1 of 5) on page 2204
5QK09-40029	Tray extension	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40029	Tray extension	Booklet finisher (1 of 5) on page 2204
5QK09-40030	Punch cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40030	Punch cover	Booklet finisher (1 of 5) on page 2204

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
5QK09-40047	Front lower left cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40047	Front lower left cover	Booklet finisher (1 of 5) on page 2204
5QK09-40048	Front lower right cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-40048	Front lower right cover	Booklet finisher (1 of 5) on page 2204
5QK09-40055	Tray 2 cover - Blue CMF panel	Covers on page 2162
5QK09-40058	Tray 3 cover - Blue CMF panel	Covers on page 2162
5QK09-40083	Developer fan assembly	Sensor and fan on page 2180
5QK09-40109	Cover waste	Registration and loop sensors on page 2167
5QK09-60001	High Voltage Power Supply (HVPS)	PCA on page 2178
5QK09-60001	High Voltage Power Supply (HVPS)	PCA on page 2178
5QK09-60104	Booklet maker unit	Booklet finisher (1 of 5) on page 2204
5QK09-60106	Front door	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-60106	Front door	Booklet finisher (1 of 5) on page 2204
5QK09-60107	Top door	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-60107	Top door	Booklet finisher (1 of 5) on page 2204
5QK09-60108	Top cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-60108	Top cover	Booklet finisher (1 of 5) on page 2204
5QK09-60109	Right upper cover	Stapler/Stacker finisher (1 of 4) on page 2198
5QK09-60109	Right upper cover	Booklet finisher (1 of 5) on page 2204
5QK09-60110	Bridge unit	Stapler/Stacker finisher (3 of 4) on page 2201
5QK09-60110	Bridge unit	Booklet finisher (4 of 4) on page 2210
5QK09-60121	Tray 3	Covers on page 2162
5QK09-60121	Tray 3 cassette	Tray 2, 3 on page 2165
5QK09-64013	LSU fan assembly	Sensor and fan on page 2180
5QK09-64014	HV rear frame assembly	PTB on page 2177

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
5QK13-60101	Registration unit assembly	Registration and loop sensors on page 2167
5QK35-67002	HP LaserJet 180ipm 200 sheet DADF Scanner	ISA on page 2183
5QK37-67002	HP LaserJet 300ipm 300 sheet Flow DADF Scanner	ISA on page 2183
5QK42-60104	Control-panel assembly 25.6 cm 10.1 in 2nd	PCA on page 2178
5QK42-60104	Control-panel assembly 25.6 cm 10.1 in 2nd	PCA on page 2178
5RC03-67001	Tray 1 roller kit	Tray 1 on page 2164
6109-001138	Caster wheel	DCF (1 of 2) on page 2192
63C82-67003	Keyboard (drawer type) Assy - E8 series US English	PCA on page 2178
63C82-67003	Keyboard (drawer type) Assy - E8 series US English	PCA on page 2178
63C82-67005	Keyboard (drawer type) Assy - E8 series UK English	PCA on page 2178
63C82-67005	Keyboard (drawer type) Assy - E8 series UK English	PCA on page 2178
63C82-67029	Card reader rotation adapter kit	Covers on page 2162
6CF14-67002	Formatter	PCA on page 2178
6CF14-67002	Formatter	PCA on page 2178
6EQ94-40029	Power key	Covers on page 2162
6EQ94-40032	HIP cover	Covers on page 2162
6ER04-40003	Front cover - Blue CMF Panel	Covers on page 2162
6ER04-40005	Right front cover	Covers on page 2162
6ER04-40008	Rear upper cover	Covers on page 2162
6ER04-40019	Rear lower cover	Covers on page 2162
6ER04-40021	Right upper cover	Covers on page 2162
6ER04-40025	Right middle cover	Covers on page 2162
6ER04-40026	Middle upper cover	Covers on page 2162
6ER04-40028	Exit rear cover	Covers on page 2162
6ER04-40030	Front lower cover	Covers on page 2162
6ER04-40034 (Not orderable and not used in printer.)	Rivet-Echo PCA (Not orderable and not used in printer.)	PCA on page 2178
6ER04-40034 (Not orderable and not used in printer.)	Rivet-Echo PCA (Not orderable and not used in printer.)	PCA on page 2178
6ER04-40035	Rivet-SSD	PCA on page 2178
6ER04-40035	Rivet-SSD	PCA on page 2178
6ER04-40036	Middle left cover	Covers on page 2162
6ER04-40049	Left cover	Covers on page 2162

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
6ER04-60002	CTD sensor assembly	CTD on page 2176
6ER04-61003	Right rear cover	Covers on page 2162
6ER04-61004	Exit cover stacker	Covers on page 2162
6ER04-61005	Controller cover	Covers on page 2162
6ER04-61006	Right middle cover assembly	Covers on page 2162
6ER08-61001	Front cover assembly	Covers on page 2162
6GW47-60001	PCA-DCF Department	DCF (2 of 2) on page 2194
6GW47-67001	DCF	DCF (1 of 2) on page 2192
6GW51-40001	Booklet stapler	Booklet finisher (2 of 5) on page 2207
6GW51-60001	Booklet maker PCA	Booklet finisher (2 of 5) on page 2207
6GW51-67001	Booklet finisher	Booklet finisher (1 of 5) on page 2204
6GW55-60001	Main PCA	Stapler/Stacker finisher (2 of 4) on page 2199
6GW55-60001	Main PCA	Booklet finisher (3 of 5) on page 2208
6GW55-67001	Stapler/Stacker finisher	Stapler/Stacker finisher (1 of 4) on page 2198
6HN30-67001	Accelerator (Optional)	PCA on page 2178
6HN30-67001	Accelerator (Optional)	PCA on page 2178
7ZA08-67001	Single Fax Card (WW) (Optional)	PCA on page 2178
7ZA08-67001	Single Fax Card (WW) (Optional)	PCA on page 2178
7ZA09-67001	Single Fax Card (BBU) (Optional)	PCA on page 2178
7ZA09-67001	Single Fax Card (BBU) (Optional)	PCA on page 2178
8GS05-40018	Caster cover	Stapler/Stacker finisher (1 of 4) on page 2198
8GS05-40018	Caster cover	Booklet finisher (1 of 5) on page 2204
8GS05-60104	Entrance motor assembly	Stapler/Stacker finisher (2 of 4) on page 2199
8GS05-60104	Entrance motor assembly	Booklet finisher (3 of 5) on page 2208
8GS05-60106	Exit motor assembly	Stapler/Stacker finisher (2 of 4) on page 2199
8GS05-60106	Exit motor assembly	Stapler/Stacker finisher (3 of 4) on page 2201
8GS05-60106	Exit motor assembly	Booklet finisher (3 of 5) on page 2208

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
8GS05-60106	Exit motor assembly	Booklet finisher (4 of 4) on page 2210
8GS05-60118	Left upper cover	Stapler/Stacker finisher (1 of 4) on page 2198
8GS05-60118	Left upper cover	Booklet finisher (1 of 5) on page 2204
8GS05-60122	Left lower cover	Stapler/Stacker finisher (1 of 4) on page 2198
8GS05-60124	Left lower cover (Booklet)	Booklet finisher (1 of 5) on page 2204
8GS05-60126	Booklet output tray	Booklet finisher (1 of 5) on page 2204
9S185-60007	Inner cover	Covers on page 2162
9U1Q5-67001	Toner collection unit	Toner collection unit on page 2172
A91Z5-67001	ADF roller kit	300sh flow ADF (2 of 2) on page 2186
JC31-00144G	Motor BLDC	Exit unit on page 2168
JC31-00154A	Fan	Sensor and fan on page 2180
JC31-00163A	Staple position motor	Stapler/Stacker finisher (4 of 4) on page 2202
JC31-00163A	Staple position motor	Booklet finisher (5 of 5) on page 2211
JC31-00177A	Motor, step	DCF (2 of 2) on page 2194
JC31-00189A	Drive-motor step	Tray 1 on page 2164
JC31-00189A	Drive-motor step	Tray 2, 3 on page 2165
JC31-00189A	Drive-motor step	Registration and loop sensors on page 2167
JC31-00198A	Fan	Sensor and fan on page 2180
JC32-00020A	Booklet exit sensor	Booklet finisher (2 of 5) on page 2207
JC32-00020A	Booklet tamper sensor	Booklet finisher (2 of 5) on page 2207
JC32-00020A	Bridge entrance sensor	Stapler/Stacker finisher (3 of 4) on page 2201
JC32-00020A	Bridge entrance sensor	Booklet finisher (4 of 4) on page 2210
JC32-00020A	Ejector sensor	Stapler/Stacker finisher (4 of 4) on page 2202
JC32-00020A	Ejector sensor	Booklet finisher (5 of 5) on page 2211
JC32-00020A	Main exit sensor	Stapler/Stacker finisher (3 of 4) on page 2201

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
JC32-00020A	Main exit sensor	Booklet finisher (4 of 4) on page 2210
JC33-00031B	Solenoid, lifting	Exit unit on page 2168
JC39-02268A	DCF Dpt_Door open switch sensor and harness	DCF (2 of 2) on page 2194
JC39-02309A	Front door switch	Stapler/Stacker finisher (2 of 4) on page 2199
JC39-02309A	Front door switch	Booklet finisher (3 of 5) on page 2208
JC39-02316A	Main output tray top of stack switch	Stapler/Stacker finisher (2 of 4) on page 2199
JC39-02316A	Main output tray top of stack switch	Booklet finisher (3 of 5) on page 2208
JC44-00149C	Low Voltage Power Supply (LVPS), 110V	PCA on page 2178
JC44-00149C	Low Voltage Power Supply (LVPS), 110V	PCA on page 2178
JC44-00150C	Low Voltage Power Supply (LVPS), 220V	PCA on page 2178
JC44-00150C	Low Voltage Power Supply (LVPS), 220V	PCA on page 2178
JC44-00236C	Fuser drive board (FDB), 220V	PCA on page 2178
JC44-00236C	Fuser drive board (FDB), 220V	PCA on page 2178
JC47-00037A	Electric clutch	Tray 1 on page 2164
JC61-04626A	Tie stopper	Covers on page 2162
JC61-04871A	Guide - adjust	DCF (1 of 2) on page 2192
JC61-07444A	Caster fix nut	Stapler/Stacker finisher (1 of 4) on page 2198
JC61-07444A	Caster fix nut	Booklet finisher (1 of 5) on page 2204
JC61-07452A	Caster	Stapler/Stacker finisher (1 of 4) on page 2198
JC61-07452A	Caster	Booklet finisher (1 of 5) on page 2204
JC61-08935A	Right door front damper bracket	Tray 1 on page 2164
JC63-04862B	Left top cover	Covers on page 2162
JC63-04918B	Right door sHCI dummy cover	Covers on page 2162
JC66-01425A	Right door front damper	Tray 1 on page 2164
JC66-04398A	Right door front link	Tray 1 on page 2164
JC66-04572A	Loop actuator	Registration and loop sensors on page 2167
JC66-04767A	Shaft hinge - door	Stapler/Stacker finisher (1 of 4) on page 2198
JC66-04767A	Shaft hinge - door	Booklet finisher (1 of 5) on page 2204

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
JC81-09881B	Booklet stapler cartridge	Booklet finisher (2 of 5) on page 2207
JC81-09882B	Staple cartridge	Stapler/Stacker finisher (4 of 4) on page 2202
JC81-09882B	Staple cartridge	Booklet finisher (5 of 5) on page 2211
JC82-00894A	Staple unit	Stapler/Stacker finisher (4 of 4) on page 2202
JC82-00894A	Staple unit	Booklet finisher (5 of 5) on page 2211
JC82-00898A	Rear tamper	Stapler/Stacker finisher (4 of 4) on page 2202
JC82-00898A	Rear tamper	Booklet finisher (5 of 5) on page 2211
JC82-00901A	Front tamper	Stapler/Stacker finisher (4 of 4) on page 2202
JC82-00901A	Front tamper	Booklet finisher (5 of 5) on page 2211
JC82-01039A	Booklet output tray sensor	Booklet finisher (1 of 5) on page 2204
JC82-01039A	Main output tray top of stack sensor	Stapler/Stacker finisher (1 of 4) on page 2198
JC82-01039A	Main output tray top of stack sensor	Booklet finisher (1 of 5) on page 2204
JC82-01039A	Top output tray paper full sensor	Stapler/Stacker finisher (2 of 4) on page 2199
JC82-01039A	Top output tray paper full sensor	Booklet finisher (3 of 5) on page 2208
JC90-01385A	Right door open switch holder assy	DCF (2 of 2) on page 2194
JC90-01396A	Booklet c-fold blade motor assembly	Booklet finisher (2 of 5) on page 2207
JC90-01397A	Booklet diverter motor assembly	Booklet finisher (2 of 5) on page 2207
JC90-01398A	Booklet diverter	Booklet finisher (2 of 5) on page 2207
JC90-01414A	Paper holding motor drive assembly	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01414A	Paper holding motor drive assembly	Booklet finisher (3 of 5) on page 2208
JC90-01415B	Main output tray motor drive assembly	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01415B	Main output tray motor drive assembly	Booklet finisher (3 of 5) on page 2208

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
JC90-01425A	Booklet entrance-presser motor assembly	Booklet finisher (2 of 5) on page 2207
JC90-01430A	Booklet paddle motor assembly	Booklet finisher (2 of 5) on page 2207
JC90-01431A	Booklet tamper	Booklet finisher (2 of 5) on page 2207
JC90-01432A	Booklet end fence	Booklet finisher (2 of 5) on page 2207
JC90-01435A	Booklet blade motor assembly	Booklet finisher (2 of 5) on page 2207
JC90-01436A	Booklet fold motor assembly	Booklet finisher (2 of 5) on page 2207
JC90-01437A	Booklet blade	Booklet finisher (2 of 5) on page 2207
JC90-01438A	Booklet c-fold blade	Booklet finisher (2 of 5) on page 2207
JC90-01442A	Finisher mount bracket	Stapler/Stacker finisher (1 of 4) on page 2198
JC90-01442A	Finisher mount bracket	Booklet finisher (1 of 5) on page 2204
JC90-01453A	Main exit cam motor assembly	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01453A	Main exit cam motor assembly	Booklet finisher (3 of 5) on page 2208
JC90-01454A	Top lower feed assembly	Stapler/Stacker finisher (3 of 4) on page 2201
JC90-01454A	Top lower feed assembly	Booklet finisher (4 of 4) on page 2210
JC90-01455A	Top jam cover assembly	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01455A	Top jam cover assembly	Booklet finisher (3 of 5) on page 2208
JC90-01458A	Tray diverter cam	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01458A	Tray diverter cam	Booklet finisher (3 of 5) on page 2208
JC90-01461A	Paddle motor assembly	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01461A	Paddle motor assembly	Booklet finisher (3 of 5) on page 2208
JC90-01467A	End fence motor assembly	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01467A	End fence motor assembly	Booklet finisher (3 of 5) on page 2208

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
JC90-01478B	Booklet front cover	Booklet finisher (2 of 5) on page 2207
JC90-01480A	Paddle	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01480A	Paddle	Booklet finisher (3 of 5) on page 2208
JC90-01675A	Buffer solenoid assembly	Stapler/Stacker finisher (2 of 4) on page 2199
JC90-01675A	Buffer solenoid assembly	Booklet finisher (3 of 5) on page 2208
JC90-01677A	Tray sub-auto closing unit	DCF (1 of 2) on page 2192
JC90-01802A	Ejector unit	Stapler/Stacker finisher (4 of 4) on page 2202
JC90-01802A	Ejector unit	Booklet finisher (5 of 5) on page 2211
JC90-01844A	Tray 1 unit	Tray 1 on page 2164
JC90-01856A	Exit unit	Exit unit on page 2168
JC90-01865A	Exit stack guide	Exit unit on page 2168
JC93-00336A	Drive-motor step	Exit unit on page 2168
JC93-00336A	Drive-motor step	Exit unit on page 2168
JC93-00466A	Front door open switch	Sensor and fan on page 2180
JC93-00492A	Toner collection full sensor assembly	Toner collection unit on page 2172
JC93-01001A	Front tamper motor	Stapler/Stacker finisher (4 of 4) on page 2202
JC93-01001A	Front tamper motor	Booklet finisher (5 of 5) on page 2211
JC93-01001A	Rear tamper motor	Stapler/Stacker finisher (4 of 4) on page 2202
JC93-01001A	Rear tamper motor	Booklet finisher (5 of 5) on page 2211
JC93-01007A	Developer suction duct	Sensor and fan on page 2180
JC93-01083A	Drive-motor step	Tray 2, 3 on page 2165
JC93-01083A	Drive-motor step	DCF (2 of 2) on page 2194
JC93-01085A	Drive-motor step	Duplex on page 2170
JC93-01135A	DCF feed drive assembly	DCF (2 of 2) on page 2194
JC93-01152A	Buffer motor	Stapler/Stacker finisher (2 of 4) on page 2199
JC93-01152A	Buffer motor	Booklet finisher (3 of 5) on page 2208

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
JC93-01155A	Booklet end fence motor	Booklet finisher (2 of 5) on page 2207
JC93-01155A	Booklet tamper motor	Booklet finisher (2 of 5) on page 2207
JC93-01370A	Tray sub-auto closing unit	Tray 2, 3 on page 2165
JC93-01408A	Frame sub-sensor paper size RU	Tray 2, 3 on page 2165
JC93-01408A	Frame sub-sensor paper size RU	Tray 2, 3 on page 2165
JC93-01408A	Frame sub-sensor paper size RU	DCF (2 of 2) on page 2194
JC93-01408A	Frame sub-sensor paper size RU	DCF (2 of 2) on page 2194
JC93-01467A	Switch	Sensor and fan on page 2180
JC93-01662A	Developer, drum and PTB drive assembly	Drum on page 2175
JC93-01662A	Drum and developer drive assembly	Developer on page 2174
JC93-01663A	Tray 2 pickup drive assembly	Tray 2, 3 on page 2165
JC93-01663A	Tray 3 pickup drive assembly	Tray 2, 3 on page 2165
JC93-01663A	Tray 4 pickup drive assembly	DCF (2 of 2) on page 2194
JC93-01663A	Tray 5 pickup drive assembly	DCF (2 of 2) on page 2194
JC93-01664A	Feed drive assembly	Tray 2, 3 on page 2165
JC93-01665A	Registration drive assembly	Registration and loop sensors on page 2167
JC93-01667A	Toner dispense motor assembly	Toner on page 2170
JC93-01694A	Tray 2 pickup assembly	Tray 2, 3 on page 2165
JC93-01695A	Tray 3 pickup assembly	Tray 2, 3 on page 2165
JC93-01743A	Keyboard Assy-UK English	PCA on page 2178
JC93-01743A	Keyboard Assy-UK English	PCA on page 2178
JC93-01795A	LVPS FDB fan assembly	Sensor and fan on page 2180
JC93-01850A	Fuser and exit drive assembly	Exit unit on page 2168
JC95-02246A	Right door assembly	Covers on page 2162
JC95-02246A	Right door assembly	Tray 1 on page 2164
JC95-02246A	Right door assembly	Registration and loop sensors on page 2167
JC95-02246A	Right door assembly	Duplex on page 2170
JC95-02249A	Right door exit assembly	Registration and loop sensors on page 2167
JC95-02250A	Duplex assembly	Duplex on page 2170
JC97-05147A	Laser scanner unit (LSU)	Laser scanner unit on page 2173

Table 6-36 Numerical parts list (continued)

Part number	Description	Table and page
Not applicable	ADF input tray	300sh flow ADF (2 of 2) on page 2186
SS216-80501	Toner dispense motor	Toner on page 2170
T3U64-60001 (Not orderable and not used in printer.)	Echo PCA (Not orderable and not used in printer.)	PCA on page 2178
T3U64-60001 (Not orderable and not used in printer.)	Echo PCA (Not orderable and not used in printer.)	PCA on page 2178
W1760-67002	Toner cartridge -standard yield	Toner on page 2170
W1766-67001	SVC_HP LaserJet Black Managed Imaging Drum	Drum on page 2175
X3A79-60003	Reservoir unit	Reservoir on page 2171
X3A92-67924	Kit-Screws c-clips e-clips kit	Covers on page 2162
Y1G10-67901	Punch unit 2-3 hole	Stapler/Stacker finisher (2 of 4) on page 2199
Y1G10-67901	Punch unit 2-3 hole	Booklet finisher (3 of 5) on page 2208
Y1G11-67901	Punch unit 2-4 hole	Stapler/Stacker finisher (2 of 4) on page 2199
Y1G11-67901	Punch unit 2-4 hole	Booklet finisher (3 of 5) on page 2208
Y1G12-67901	Punch unit Swedish hole	Booklet finisher (3 of 5) on page 2208
Y1G22-67901	Tray heater 110V	Tray 2, 3 on page 2165
Y1G22-67901	Tray heater 110V	DCF (2 of 2) on page 2194
Y1G22-67902	Tray heater 220V	Tray 2, 3 on page 2165
Y1G22-67902	Tray heater 220V	DCF (2 of 2) on page 2194
Y6V12-60035	Tarot platen PCA	Tarot platen on page 2190
Z9Y05-50002	ADF FFC cable to SSA	300sh flow ADF (2 of 2) on page 2186
Z9Y05-50003	ADF Power cable	300sh flow ADF (2 of 2) on page 2186
Z9Y05-60004	300sh ADF PCA	300sh flow ADF (2 of 2) on page 2186
Z9Y05-60016	Damper module	300sh flow ADF (2 of 2) on page 2186

Glossary of terms

802.11

802.11 is a set of standards for wireless local area network (WLAN) communication, developed by the IEEE LAN/MAN Standards Committee (IEEE 802).

802.11b/g/n

802.11b/g/n can share the same hardware and use the 2.4 GHz band. 802.11b supports bandwidth up to 11 Mbps, 802.11n supports bandwidth up to 150 Mbps. 802.11b/g/n devices might occasionally suffer interferences from microwave ovens, cordless telephones, and Bluetooth devices.

AC

An electric current that reverses its direction many times a second at regular intervals. For example, the 110V line current found in a typical US electrical wall receptacle.

AC Control Module (PageWide)

The AC Control Module controls the heating elements in the airflow assembly. Functions include voltage monitoring (ensuring correct operation in a low-quality-power environment), isolation (low voltage heater control signals are isolated from the high voltage AC power for safety), AC switching (power is switched on/off to the heater), and heating element configuration (heating element configuration is changed between series and parallel for temperature predictability).

ADF

An Automatic Document Feeder (ADF) is a device that automatically feeds an original sheet (or multiple sheets) of paper into the image scanner. The document feeder is a component of the integrated scanner assembly (ADF and image scanner).

Airflow System (PageWide)

The airflow system conditions the printed pages to avoid page curling due to the ink on the page. The airflow system functionally consists of a fan and heating elements. The pressurized air is blown on the page through the nozzles that are placed on the paper path of the airflow system between print and eject zone.

BOOTP

Bootstrap Protocol. A network protocol used by a network client to obtain its IP address automatically. This is usually done in the bootstrap process of computers or operating systems running on them. The BOOTP servers assigns an IP address from a pool of addresses to each client. BOOTP enables “diskless workstation” computers to obtain an IP address prior to loading any advanced operating system.

CCD

A Charged Coupled Device (CCD) is the scanner module which enables a scan job. A CCD locking mechanism is used to hold the CCD module to prevent any damage when the printer is moved.

CIS

A Contact Image Sensor (CIS) scanner captures an image using the printer's optical path. Red, green, and blue LEDs sequentially illuminate a small strip of the document (often called a raster line), and the optical system captures each color in a single row of Charged Coupled Device (CCD) sensors that cover the entire page width.

Collation

Collation is a process of printing a multiple-copy job in sets. When collation is selected, the device prints an entire set before printing additional copies.

Control Panel

The control panel is a flat, typically vertical panel or screen where the user can control and/or monitor the printer. The control panel is found on the front of the printer.

Coverage

Coverage is the printing term used for a toner usage measurement on printing. For example, 5% coverage means that an A4 sided paper has about 5% image or text on it. If the paper or original has complicated images or a large amount of text, the coverage will be higher and at the same time, a toner usage will be as much as the coverage.

DC

An electric current flowing in one direction only. Typically, a low voltage load current supplied to an electrical assembly.

DCC

The DC controller (DCC) controls the operation of the printer sub-systems and electrical components. the DCC sends out various signals to operate motors, solenoids, and other printer components based on the print command and image data that the host computer sends the formatter.

Default

The value or setting that is in effect when a printer is unboxed, reset, or initialized.

DHCP

Dynamic Host Configuration Protocol (DHCP) is a client-server networking protocol. A DHCP server provides configuration parameters specific to the DHCP client host requesting, generally, information required by the client host to participate on an IP network. The DHCP also provides a mechanism for allocation of IP addresses to client hosts.

Digital Send Software

Digital send software allows a mufti-function printer (MFP) to scan and send information quickly and securely to email, network folders, other printers, and fax services.

DIMM

A Dual Inline Memory Module (DIMM) is a small circuit board that holds memory. The DIMM stores all data within the printer, such as printing data and received fax data.

DPI

Dots Per Inch (DPI) is a measurement of resolution that is used for scanning and printing. Generally, higher DPI results in a higher resolution (more visible detail in the image and a larger file size).

Duplex

A mechanism that automatically turns over a sheet of paper so that the printer can print (or scan) on both sides of the paper. A printer equipped with a duplex unit can print on both sides of the paper during one print cycle.

Duty Cycle

Duty cycle is the page quantity which does not affect printer performance for a month. Generally, the printer has the lifespan limitation such as pages per year. The lifespan means the average capacity of print-outs, usually within the warranty period. For example, if the duty cycle is 48,000 pages per month the printer limit is 2,400 pages a day (assuming 20 working days/month).

Dynamic Security

Dynamic Security is a toner cartridge design and process for authenticating genuine HP supplies. HP printers use toner cartridges that have security chips or electronic circuitry. Cartridges using a non-HP chip, or modified chip, or non-HP circuitry might not work (now or in the future).

e-Duplex

Single-pass electronic duplex (e-Duplex) printer use two separate scan modules to scan the front-side and back-side of an e-duplex copy job page in a single pass through the document feeder.

EMC

EMC is a measure of a device's ability to operate as intended in its shared operating environment while, at the same time, not affecting the ability of other equipment within the same environment to operate as intended.

EMI

EMI is the electromagnetic energy which affects the functioning of an electronic device. Electronic devices (like printers) are a source of EMI. Because it is rare for electronics to operate in isolation, products are generally engineered to function in the presence of some amount of EMI.

eMMC

An embedded Multi-Media Card is a compact memory device consisting of NAND flash memory and a simple storage controller.

Emulation

Emulation is a technique of one machine obtaining the same results as another. An emulator duplicates the functions of one system with a different system, so that the second system behaves like the first system. Emulation focuses on exact reproduction of external behavior. This is different from simulation, which concerns an abstract model of the system being simulated, often considering its internal state.

EPS

Encapsulated PostScript (EPS) is a PostScript (PS) code file which is used for storing font and vector graphic image information.

ESD

An electrostatic discharge (ESD) is a sudden flow of electricity between two electrically charged objects caused by contact, an electrical short, or dielectric breakdown. Discharge of built up static electricity.

Ethernet

Ethernet is a frame-based computer networking technology for local area networks (LANs). It defines wiring and signaling for the physical layer, and frame formats and protocols for the media access control (MAC)/data link layer of the OSI model. Ethernet is mostly standardized as IEEE 802.3. Ethernet has become the most widespread LAN technology in use during the 1990s to present.

Ferrite

A ferrite is used to reduce the amount of radio frequency noise (or interference) in a wire or cable. A ferrite enables proper EMC/EMI performance for regulatory purposes.

FFC

Flat Flexible Cables (FFCs) are designed for Printed Circuit Assembly (PCA) to PCA connections (for example, connecting a fax PCA to the formatter).

FIH

A Foreign Interface Harness (FIH) is a port that enables HP multifunction printers (MFPs) to use third-party devices to extend the capabilities of the MFP.

Firmware

The formatter stores the printer firmware. A remote firmware upgrade process is used to overwrite and upgrade the firmware.

Flash memory

Flash memory is non-volatile, meaning it retains stored data even when the power is turned off.

Flow integrated scanner assembly

A printer scanner assembly that includes a slide-out external physical keyboard.

Formatter (LaserJet)

The formatter controls printer functions like receiving and processes print data, developing and coordinating data placement and timing with the DC controller PCA, storing font and customer configuration information, communicating with the host computer, and monitoring control panel functions and relaying printer status information through the control panel.

FTP

FTP stands for File Transfer Protocol. FTP is a protocol designed for transferring files over the Internet. Files stored on an FTP server can be accessed using an FTP client, such as a web browser, FTP software program, or a command line interface.

Fuser Unit

The fuser unit is part of a laser printer that adheres the toner onto the printed page. It consists of a heat roller and a pressure roller. After toner is transferred onto the paper, the fuser unit applies heat and pressure to make sure that the toner stays on the paper permanently (which is why paper is warm when it comes out of a laser printer).

Gateway

A connection between computer networks, or between a computer network and a telephone line. A gateway is used to connect two different computer networks, especially a connection to the Internet.

Grayscale

Shades of gray that represent light and dark portions of a color image printed in monochrome. Colors are represented by a range of gray shades from white to black.

Halftone

Halftone is a way of reproducing a photograph or other image in which the various tones of gray or color are produced by variously sized dots of ink or toner. Halftone simulates grayscale by varying the number of dots. Highly colored areas consist of a large number of dots, while lighter areas consist of a smaller number of dots.

HDD

A Hard-Disk Drive (HDD) (commonly referred to as a hard drive or hard disk) is a non-volatile storage device which stores digitally-encoded data on rapidly rotating platters with magnetic surfaces.

IEEE

The Institute of Electrical and Electronics Engineers (IEEE) is an international non-profit, professional organization for the advancement of technology related to electricity.

Image scanner

The image scanner (or Sub Scanner Assembly) contains the components to digitally scan an original source document. The image scanner is a component of the integrated scanner assembly (ADF and image scanner).

IP address

An Internet Protocol (IP) address is a unique number that a device uses in order to identify and communicate with other devices on a network utilizing the Internet Protocol standard.

IPM

The Images Per Minute (IPM) is a method of measuring the speed of a printer. An IPM rate indicates the number of single-sided sheets a printer can complete in one minute.

IPP

The Internet Printing Protocol (IPP) defines a standard protocol for printing and managing print jobs, media size, resolution, etc. IPP can be used locally, or over the internet to reach hundreds of printers. IPP also supports access control, authentication, and encryption, making it a capable and secure printing solution.

ISA

The Integrated Scanner Assembly (ISA) includes the document feeder and image scanner.

ISO

The International Organization for Standardization (ISO) is an international standard-setting body composed of representatives from national standards bodies. In produces world-wide industrial and commercial standards.

JBIG

Joint Bi-level Image Experts Group (JBIG) is an image compression standard with no loss of accuracy or quality. It was designed for compression of binary images, particularly for faxes, but can also be used for other images.

JPEG

Joint Photographic Experts Group (JPEG) is a commonly used standard method of loss compression for photographic images. It is the format used for storing and transmitting photographs on the World Wide Web.

LDAP

The Lightweight Directory Access Protocol (LDAP) is a networking protocol for querying and modifying directory services running over TCP/IP.

LED

A Light-Emitting Diode (LED) is a semiconductor device that can indicate the status of a printer (formatter LEDs) or a component in a contact image sensor (CIS) scanner that helps capture an image.

LEDM

Low end data model (LEDM) provides one consistent data representation method and defines the dynamic and capabilities tickets shared between clients and devices, as well as the access protocol, event, security, and discovery methods.

LVPS - SMPS

Low Voltage Power Supplies (LVPS) and Switching Mode Power Supplies (SMPS) supply direct current (DC) voltages to various printer components and assemblies.

MAC address

Media Access Control (MAC) address is a unique identifier associated with a network adapter. MAC address is a unique 48-bit identifier usually written as 12 hexadecimal characters grouped in pairs (for example, 00-00-0c-34-11-4e). This address is usually hard-coded into a Network Interface Card (NIC) by the manufacturer and used as an aid for routers trying to locate machines on a large network.

MEt

HP Memory Enhancement technology (MEt) effectively doubles the standard memory through a variety of font- and data-compression methods. MEt is available only in Printer Command Language (PCL) mode; it is not functional when printing in PostScript (PS) mode.

MFP

A Multi Function Printer (MFP) is a printer that incorporates multiple functionalities in a single physical body. For example, an MFP printer can scan, digitally send, fax, copy, and print.

MHV

Miniature High Voltage (MHV) is designed for high voltage applications of BNC connectors (DC voltage between 500 V and 5 kV).

Modem

A device that modulates a carrier signal to encode digital information, and also demodulates such a carrier signal to decode transmitted information.

MPCA (PageWide)

The MPCA integrates both formatter (LaserJet) and engine control electronics (DC controller) into a single assembly. The Main PCA (MPCA) controls printer functions like receiving and processes print data, developing and coordinating data placement, storing font and customer configuration information, communicating with the host computer, and monitoring control panel functions and relaying printer status information through the control panel.

NAND

NAND is not an acronym (the term is short for **NOT AND** a Boolean operator and logic gate). NAND (flash) memory is non-volatile, meaning it retains stored data even when the power is turned off.

NVRAM

Nonvolatile random access memory (NVRAM) is used to store I/O and information about the print environment configuration (stored data even when the power is turned off).

OPC

Organic Photo Conductor (OPC) is a mechanism that makes a virtual image for print using a laser beam emitted from a laser printer. It is usually green or rust colored and has a cylinder shape. An imaging unit containing a drum slowly wears the drum surface during its usage in the printer, and it should be replaced appropriately due to wear from contact with the cartridge development brush, cleaning mechanism, and paper.

Originals

The first example of something, such as a document, photograph, or text which is copied, reproduced, or translated to produce additional copies. The original itself is not copied or derived from something else.

PCA

Printed Circuit Assembly (PCA). Once the printed circuit board (PCB) is complete, electronic components must be assembled to form a functional printed circuit assembly or PCA.

PCL

Printer Command Language (PCL) is a Page Description Language (PDL) developed by HP as a printer protocol. PCL has become an industry standard. Originally developed for early Inkjet printers, PCL has been released in varying levels for thermal, dot matrix printers and laser printers.

PDF

Portable Document Format (PDF) is a proprietary file format developed by Adobe Systems. A PDF represents two dimension documents in a device independent and resolution independent format.

PJL

Printer job language (PJL) is an integral part of printer configuration, in addition to the standard PCL and PostScript (PS). With standard cabling, the printer can use PJL to perform a variety of functions like dynamic I/O switching, context-sensitive switching, and isolation of print environment settings from one print job to the next.

PML

Printer management language (PML) allows remote configuration of the printer and status read-back from the printer through the I/O ports.

PostScript (PS)

PostScript (PS) is a Page Description Language (PDL) and programming language used primarily in electronic and desktop publishing. PostScript is run in an interpreter to generate an image.

PPM

Pages Per Minute (PPM) is a method of measurement for determining how fast a printer works, meaning the number of pages a printer can produce in one minute.

Print Media

Media like paper, envelopes, labels, and transparencies which can be used in a printer, scanner, fax, or copier.

Printer Driver

A program used to send commands and transfer data from the computer to the printer.

Printhead (PageWide)

The printhead converts the digital firing instructions from the printer electronics into properly formed and timed microscopic drops of the four ink colors.

Printhead Wiper (PageWide)

The printhead wiper system keeps the printhead nozzles firing correctly throughout the life of the printer as it performs the wiping and capping functions. The wiping function cleans the nozzles of ink residue and particulates. The capping function keeps the nozzles moist during storage and when the printer is idle.

Protocol

A convention or standard that controls or enables the connection, communication, and data transfer between two computing endpoints.

RAM

Random Access Memory (RAM) is the printer memory device where the data in current use is kept so it can be quickly retrieved by the device's processor. This memory is an important factor in avoiding errors and printing documents properly. Printer memory is used to store, and process print jobs as they are sent to the printer from a computer. After printing, the job is cleared from the memory to make room for more print jobs. Printer memory is directly linked to two print characteristics: speed and print quality. More memory allows you to print faster and print larger, high-quality graphics.

REDI sensor

An optical reflective edge detection interrupter (REDI) sensor. Usually used in conjunction with mirrors to sense the presence or absence of paper in the paper path. These sensors are carefully aligned and calibrated at the factory, so care must be taken when servicing these sensors.

Resolution

The sharpness of an image is measured in Dots Per Inch (DPI). The higher the DPI, the greater the resolution.

SCB

The Scanner Control Board (SCB) controls the functions of the image scanner components in the Sub Scanner Assembly (SSA).

Service fluid and aerosol management systems (PageWide)

There are two types of service fluid, shipping fluid and ink. The service fluid management system is contained entirely within the duplex module. Service fluid is discharged as droplets from the printhead, and then collected in a container inside the duplex module. Some of the droplets are called aerosol because they are lighter than air. Aerosol can float inside the printer and collect on the lens of optical sensors, producing false failures. The aerosol management system transports the aerosol and collects it in a safe place. Aerosol management consists of an aerosol fan, mounted on the rear wall of the air flow assembly, which creates air flow that pulls the aerosol through the holes in the platen and into the aerosol filter inside the duplex module.

SFP

A single-function printer only processes print jobs sent from a host computer or from an USB port on the printer.

SMB

Server Message Block (SMB) is a network protocol mainly applied to share files, printers, serial ports, and miscellaneous communications between nodes on a network. SMB also provides an authenticated inter-process communication mechanism.

SMTP

Simple Mail Transfer Protocol (SMTP) is the standard for email transmissions across the internet. SMTP is a relatively simple, text-based protocol, where one or more recipient of a message is specified, and the message text is transferred. It is a client server protocol where the client transmits an email message to the server.

SODIMM

Small outline dual in-line memory module (SODIMM) is a thin profile memory storage device (a smaller alternative to a standard DIMM device).

SSA

The Sub-Scanner Assembly is the image scanner component of the Integrated Scanner Assembly (ISA, which includes the document feeder and the image scanner).

Subnet Mask

The subnet mask is used in conjunction with the network address to determine which part of the address is the network address and which part is the host address.

TCP/IP

The Transmission Control Protocol (TCP) and the Internet Protocol (IP) are the set of communications protocols that implement the protocol stack on which the internet and most commercial networks run.

TIFF

Tagged Image File Format (TIFF) is a variable-resolution bit mapped image format. TIFF describes image data that typically come from scanners. TIFF images use tags, keywords defining the characteristics of the image that is included in the file. This flexible and platform-independent format can be used for pictures that have been made by various image processing applications.

Toner Cartridge

A bottle or container that holds toner, which is used in a machine like a printer. Toner is a powder used in laser printers and photocopiers. The toner forms the text and images on printed paper. Toner can be fused by a combination of heat/pressure from the fuser, causing it to bind the fibers in the paper.

TPM

The HP Trusted Platform Module (TPM) is a security accessory for printers. The TPM strengthens protection of encrypted credentials and data stored on your printer. Certificate private keys are both generated by and protected by the TPM. Once installed, the printer and the TPM are sealed, and the printer owns the TPM. The TPM may not be moved to another device without losing its ownership from the original printer. Installing a TPM accessory might necessitate a firmware upgrade. The TPM prevents the printer from starting if the TPM is missing. If the TPM is removed from the printer, a control-panel error message appears indicating that the TPM is missing.

NOTE: The TPM is not a service part for some printer models.

TWAIN

An industry standard for scanners and software. By using a TWAIN compliant scanner with TWAIN-compliant software, a scan can be initiated from the program. TWAIN is an image capture API for Microsoft Windows and Apple Macintosh operating systems.

URL

Uniform Resource Locator (URL) is the global address of documents and resources on the internet. The first part of the address indicates what protocol to use. The second part specifies the IP address or the domain name where the resource is located.

USB

Universal Serial Bus (USB) is a standard that was developed by the USB Implementers Forum, Inc., to connect computers and peripherals. Unlike the parallel port, USB is designed to concurrently connect a single computer USB port to multiple peripherals.

Walk-up USB

Some printers support direct printing from a USB flash drive (the walk-up USB port is usually near the control panel).

Watermark

A watermark is a recognizable image or pattern in paper that appears lighter when viewed by transmitted light. Watermarks were first introduced in Bologna, Italy in 1282. Watermarks have been used by paper makers to identify their product, and also on postage stamps, currency, and other government documents to discourage counterfeiting.

XPS

XML Paper Specification (XPS) is a specification for a Page Description Language (PDL) and a new document format developed by Microsoft. This has benefits for portable document and electronic documents. It is an XML-based specification based on a new print path and vector-based, device-independent document format.

ZIF Connector

Zero insertion force (ZIF) connectors use a mechanical locking method to secure Flat Flexible Cables (FFCs) to a Printed Circuit Assembly (PCA).

Index

Symbols/Numerics

200sh ADF
  parts and diagrams 2188
200sh ADF 1 of 2
  parts 2188
200sh ADF 2 of 2
  parts 2189
300sh flow ADF
  parts and diagrams 2185
300sh flow ADF 1 f 2
  parts 2185
300sh flow ADF 2 of 2
  parts 2186
520-sheet trays
  jams 61
76.00.24 66

A

accelerator card
  removal and replacement 987
accessories
  dimensions 1, 9
  weight 1, 9
acoustic specifications 1, 9
ADF
  removal and
    replacement 1049
ADF FFC
  automatic document
    feeder 1143
ADF, 200-sheet
  dn bundle 1117
ADF, 200sh
  parts and diagrams 2188
ADF, 200sh 1 of 2
  parts 2188
ADF, 200sh 2 of 2
  parts 2189
ADF, 300-sheet
  z , z+ bundle 1049
ADF, 300sh flow
  parts and diagrams 2185
ADF, 300sh flow 1 of 2
  parts 2185
ADF, 300sh flow 2 of 2
  parts 2186
ADF, tarot platen
  parts and diagrams 2189
automatic document feeder
  200-sheet dn bundle 1117
  300-sheet z z+ bundle 1049
  removal and
    replacement 1049
  removal and replacement,
    5QJ90-67011,
    5QJ90-67012 1117
automatic document feeder color
  panel
  removal and
    replacement 1065, 1124
automatic document feeder
  damper module
  removal and replacement 1110
  removal and replacement,
    5QJ90-67011,
    5QJ90-67012 1162
automatic document feeder FFC
  removal and
    replacement 1143
automatic document feeder flat-
  flexible cable
  removal and
    replacement 1090
automatic document feeder front
  cover
  removal and
    replacement 1059
automatic document feeder hinge
  kit
  removal and
    replacement 1102
  removal and replacement,
    5QJ90-67011,
    5QJ90-67012 1155
automatic document feeder
  pickup roller kit
  removal and
    replacement 1080
  removal and replacement,
    5QJ90-67011,
    5QJ90-67012 1132
automatic document feeder power
  cable
  removal and
    replacement 1096, 1149
automatic document feeder
  printed circuit assembly
  removal and
    replacement 1084
  removal and replacement,
    5QJ90-67011,
    5QJ90-67012 1137
automatic document feeder rear
  cover
  removal and
    replacement 1067
automatic document feeder top
  cover
  removal and
    replacement 1073
automatic document feeder white
  backing
  removal and
    replacement 1075, 1127

B

backup error
  32.WX.YZ error 34, 65
  reset error 34, 65
  restore error 34, 65
base printer
  covers, remove and
    replace 231
  covers, service parts 2161
  CTD, service parts 2175
  developer, service parts 2173

drum, service parts 2174
duplex , service parts 2169
exit unit , service parts 2168
fan, service parts 2179
feeding system, service parts 2163
fuser, service parts 2177
image creation, service parts 2173
laser scanner unit, service parts 2173
parts and diagrams 2161
PCA, service parts 2180
PTB, service parts 2176
registration and loop sensors, service parts 2166
remove and replace parts 231
reservoir , service parts 2171
sensor, service parts 2179
toner cartridge, service parts 2170
toner collection unit, service parts 2172
toner flow, service parts 2170
tray 1, service parts 2164
tray 2, 3, service parts 2165
bin, output
locating 2
black developer unit.
removal and replacement 843
booklet finisher
booklet maker, remove and replace 1846
diverter unit, remove and replace 2097
end fence unit, remove and replace 1919
entrance unit, remove and replace 1867
fold unit, remove and replace 2039
miscellaneous parts, remove and replace 2156
output tray unit, remove and replace 2131
paddle unit, remove and replace 1907
parts and diagrams 2204
PCA, remove and replace 2141
presser unit, remove and replace 1943
stapler unit, remove and replace 2019
booklet finisher 1 of 5
parts 2204
booklet finisher 3 of 5
parts 2208
booklet finisher 4 of 5
parts 2210
booklet finisher 5 of 5
parts 2211
booklet finisher booklet blade home sensor
removal and replacement 2067
booklet finisher booklet blade motor
removal and replacement 2084
booklet finisher booklet diverter home sensor
removal and replacement 2113
booklet finisher booklet fold motor
removal and replacement 2093
booklet finisher booklet fold motor assembly
removal and replacement 2089
booklet finisher booklet maker
removal and replacement 1846
booklet finisher booklet maker PCA
removal and replacement 2146
booklet finisher c-fold blade assembly
removal and replacement 2039
booklet finisher c-fold blade home sensor
removal and replacement 2050
booklet finisher c-fold blade motor
removal and replacement 2062
booklet finisher c-fold blade motor assembly
removal and replacement 2056
booklet finisher diverter
removal and replacement 2097
booklet finisher diverter motor
removal and replacement 2125
booklet finisher diverter motor assembly
removal and replacement 2120
booklet finisher end fence home sensor
removal and replacement 1919
booklet finisher end fence motor
removal and replacement 1931
booklet finisher entrance motor
removal and replacement 1897
booklet finisher entrance sensor
removal and replacement 1879
booklet finisher entrance unit
removal and replacement 1867
booklet finisher entrance-presser motor assembly
removal and replacement 1893
booklet finisher harness guide
removal and replacement 1855
booklet finisher main PCA
removal and replacement 2141
booklet finisher output tray
removal and replacement 2131
booklet finisher output tray sensor
removal and replacement 2133
booklet finisher paddle home sensor
removal and replacement 1908
booklet finisher paddle motor
removal and replacement 1915
booklet finisher paddle motor assembly
removal and replacement 1911
booklet finisher presser home sensor
removal and replacement 1943
booklet finisher staple cartridge
removal and replacement 2036

booklet finisher stapler
removal and replacement 2020
booklet finisher tamper
removal and replacement 1948
booklet finisher tamper home sensor
removal and replacement 1965
booklet finisher tamper motor
removal and replacement 1983
booklet finisher tamper sensor
removal and replacement 2001
booklet finisher, only
removal and replacement 1846
booklet maker
booklet finisher, remove and replace 1846
booklet or stapler/stacker finishers
removal and replacement 1306
bridge unit
external finisher, remove and replace 1372
buffer unit
external finisher, remove and replace 1835

C

cable guide
removal and replacement 870
cables
automatic document feeder, power 1096, 1149
Calibrate/Cleaning menu, control panel 34, 45, 78
caution iii
cleaning page 34, 45, 78
cleaning the paper dust stick 24
cleaning the scan glass 24
clutches
Tray 1 clutch 374
component test
special mode test 34, 35, 42, 44
components
diagnostic tests 34, 35, 42, 44
connector error
65.WX.YZ error 34, 66
control panel
Advanced Print Quality Pages 224
Altitude Adjustment 211
Auto Tone Adjustment 215
Backup/Restore 215
Backup/Restore menu 34, 45, 78
Buckle Adjustment 185
Calibrate Scanner 216
Calibrate/Cleaning menu 34, 45, 78
Cold Reset Paper 181
Component tests 203
Configuration/Status Pages 219
Consumables Access Control 182
Copy menu (MFP only) 34, 45, 78, 134
Counts 179
coverage report 179
CPMD 34
CTD Sensor Cleaning 216
Custom Color 215
Engine NVM Read/Write 194
Event Log 178, 224
Fax menu (fax models only) 34, 45, 78, 171
Fax Reports 220
Fax Service Log 221
Fax Speaker Mode 221
Fax T.30 Trace Report 220
Fax V.29 Speed 214
Fax V.34 221
Finisher Adjustment 185
Footer 213
Humidity 212
Import/Export 215
JBIG Compression 221
License Management 216
locating 2
locating features 5
Low Alerts 181
Low-temperature Idling Mode 210
Maintenance menu 214
Manual Tone Adjustment 216
Other Pages 220
Paper Path Page 224
Part Replacement Count 213
PQ Troubleshooting Pages 221
Print Adjustment 183
Print menu 34, 45, 78, 175
PTT Test Mode 213
remove and replace parts 960
Reports menu 34, 45, 78, 96
Reset Engine NVM 194
Reset Supplies 214
Reset Supplies Level 182
Retrieve Diagnostic Data 225
Retrieve Fax Diagnostic Data 225
Run Fax Test 224
Scan menu 143
Scan menu (MFP only) 34, 45, 78
Scanner Settings 179
Sensors 195
Serial Number 181
Service ID 181
Service menu 177
Service Reports 183
Settings menu 34, 45, 78, 98
Software Version 183
Supplies menu 34, 45, 78, 175
Test Support 213
Toner Density Calibration 216
TR Control Mode 209
Trays menu 34, 45, 78, 176
troubleshooting menu 34, 45, 78
Troubleshooting menu 219
USB Firmware Upgrade 216
USB Firmware Upgrade menu 34, 45, 78
Vapor Mode 212
control panel diagnostic flowcharts 34, 35, 38
control panel menus 34, 45, 78
control panel messages 65
control panel, 10.1 inch
removal and replacement 960
control panel, 8 inch
removal and replacement 960
controller cover
removal and replacement 237
conventions used iii
Copy menu (MFP only), control panel 34, 45, 78, 134
copy specifications 1, 9
covers
base printer, remove and replace 231
base printer, service parts 2161
controller 237
DCF left cover 1207
DCF rear cover 1205
DCF right cover 1203

DCF right door 1209
DCF Tray 4, 5 color panel 1211
DCF, remove and replace 1203
document feeder color panel 1065, 1124
document feeder front 1059
document feeder rear 1067
document feeder top 1073
dual cassette feeder left cover 1207
dual cassette feeder rear cover 1205
dual cassette feeder right cover 1203
dual cassette feeder right door 1209
dual cassette feeder Tray 4, 5 color panel 1211
exit cover stacker 299
exit rear cover 239
external finisher, remove and replace 1306
flatbed scanner 1177
front cover 315
front lower cover 312
hardware integration pocket [HIP] 294
HIP 294
inner cover 302
left cover 248
left top cover 242
left upper cover 244
middle left 296
middle upper cover 252
parts 2161
power key 284
rear lower 234
rear upper 231
removal and replacement, external finisher booklet front cover 1370
removal and replacement, external finisher booklet output tray 1329
removal and replacement, external finisher caster 1364
removal and replacement, external finisher caster cover 1308
removal and replacement, external finisher caster fix nut 1367
removal and replacement, external finisher front cover 1339
removal and replacement, external finisher front door 1306
removal and replacement, external finisher front lower left cover 1354
removal and replacement, external finisher front lower right cover 1359
removal and replacement, external finisher left lower cover 1310, 1318
removal and replacement, external finisher left upper cover 1319
removal and replacement, external finisher main output tray 1334
removal and replacement, external finisher punch cover 1343
removal and replacement, external finisher rear cover 1336
removal and replacement, external finisher right upper cover 1351
removal and replacement, external finisher shaft hinge - door 1361
removal and replacement, external finisher top cover 1345
removal and replacement, external finisher top door 1348
removal and replacement, external finisher top jam cover assembly 1423
removal and replacement, external finisher top output tray 1332
right door 317
right door front damper 327
right door front damper bracket 332
right door front link 322
right door sHCI dummy cover 254
right front cover 268
right middle 275
right middle assembly 271
right rear cover 266
right upper 256
tie stoppers 310
tray 1 unit 337
CPMD 65
CRUM module assembly
removal and replacement 765
CTD
parts 2175
CTD sensor assembly
removal and replacement 873
current settings pages 34, 45

D

DC controller communication error
55.WX.YZ error 34, 66
DC controller firmware error
70.WX.YZ error 34, 66
DCF
covers, remove and replace 1203
harness, remove and replace 1275
motor, remove and replace 1224
PCA, remove and replace 1275
roller, remove and replace 1221
sensor, remove and replace 1238
unit parts, remove and replace 1219
DCF (department)
removal and replacement 1203
DCF 1 of 2
parts 2192
DCF 2 of 2
parts 2194
DCF caster wheel
removal and replacement 1214
DCF feed drive assembly
removal and replacement 1232
DCF feed motor
removal and replacement 1235
DCF feed sensor
removal and replacement 1269
DCF holder wheel kit
removal and replacement 1216

DCF IF harness
removal and replacement 1284
DCF left cover
removal and replacement 1207
DCF motor harness 2nd
removal and replacement 1291
DCF PCA
removal and replacement 1278
DCF pickup drive assembly
removal and replacement 1224
DCF rear cover
removal and replacement 1205
DCF right cover
removal and replacement 1203
DCF right door
removal and replacement 1209
DCF right door open switch holder
removal and replacement 1281
DCF sensor harness 1st
removal and replacement 1294
DCF sensor harness 2nd
removal and replacement 1298
DCF size harness
removal and replacement 1302
DCF Tray 4 paper empty sensor
removal and replacement 1245
DCF Tray 4 paper stack height sensor
removal and replacement 1245
DCF Tray 4 pickup assembly
removal and replacement 1241
DCF Tray 4 pickup motor
removal and replacement 1227
DCF Tray 4 prefeed sensor
removal and replacement 1249
DCF Tray 4, 5 cassette
removal and replacement 1219
DCF Tray 4, 5 color panel
removal and replacement 1211
DCF Tray 4, 5 paper size sensors
removal and replacement 1238
DCF Tray 4, 5 rollers
removal and replacement 1221
DCF Tray 5 paper empty sensor
removal and replacement 1259
DCF Tray 5 paper stack height sensor
removal and replacement 1259
DCF Tray 5 pickup assembly
removal and replacement 1254
DCF Tray 5 pickup motor
removal and replacement 1230
DCF Tray 5 prefeed sensor
removal and replacement 1263
DCF tray heaters
removal and replacement 1275
decoding
message 34
defeating
interlocks 34, 35, 42, 43
definitions and terms
glossary 2245
determine problem source 34, 35
developer
parts 2174
developer and drum
remove and replace parts 840
developer drive assembly
removal and replacement 857
developer fan assembly
removal and replacement 926
developer motor K
removal and replacement 867
developer powder.
removal and replacement 848
developer suction duct
removal and replacement 937
developer unit.
removal and replacement 843
diagnostics
adjustment 34
component 34, 35, 42, 44
engine 34, 35, 42, 43
fax 34
image management 34
LED 34, 35, 42
print test patterns 34
scanner 34
digital sending error (firmware)
44.WX.YZ error 34, 65
dimensions
accessories 1, 9
printer 1, 9
diverter unit
booklet finisher, remove and replace 2097
document feeder
jams 58
locating 2
document feeder / image scanner assembly
parts and diagrams 2183
document feeder error
31.WX.YZ error 34, 65
document feeder skew (LX du models) 34
door open switch and harness
removal and replacement 1287
drivers, supported 1, 9
drives
feed drive assembly 485
tray 2 pickup drive assembly 431
tray 3 pickup drive assembly 439
drum
parts 2174
drum drive assembly
removal and replacement 857
drum motor
removal and replacement 864
drum unit
removal and replacement 840
dual cassette feeder
covers, remove and replace 1203
harness, remove and replace 1275
motor, remove and replace 1224
parts and diagrams 2192
PCA, remove and replace 1275
roller, remove and replace 1221
sensor, remove and replace 1238
unit parts, remove and replace 1219

dual cassette feeder (department)
removal and
replacement 1203
dual cassette feeder 1 of 2
parts 2192
dual cassette feeder 2 of 2
parts 2194
dual cassette feeder caster wheel
removal and
replacement 1214
dual cassette feeder door open switch and harness
removal and
replacement 1287
dual cassette feeder feed drive assembly
removal and
replacement 1232
dual cassette feeder feed motor
removal and
replacement 1235
dual cassette feeder feed sensor
removal and
replacement 1269
dual cassette feeder holder wheel kit
removal and
replacement 1216
dual cassette feeder IF harness
removal and
replacement 1284
dual cassette feeder left cover
removal and
replacement 1207
dual cassette feeder motor harness 2nd
removal and
replacement 1291
dual cassette feeder PCA
removal and
replacement 1278
dual cassette feeder pickup drive assembly
removal and
replacement 1224
dual cassette feeder rear cover
removal and
replacement 1205
dual cassette feeder right cover
removal and
replacement 1203
dual cassette feeder right door
removal and
replacement 1209
dual cassette feeder right door open switch holder
removal and
replacement 1281
dual cassette feeder sensor harness 1st
removal and
replacement 1294
dual cassette feeder sensor harness 2nd
removal and
replacement 1298
dual cassette feeder size harness
removal and
replacement 1302
dual cassette feeder Tray 4 paper empty sensor
removal and
replacement 1245
dual cassette feeder Tray 4 paper stack height sensor
removal and
replacement 1245
dual cassette feeder Tray 4 pickup assembly
removal and replacement 1241
dual cassette feeder Tray 4 pickup motor
removal and
replacement 1227
dual cassette feeder Tray 4 prefeed sensor
removal and
replacement 1249
dual cassette feeder Tray 4, 5 cassette
removal and
replacement 1219
dual cassette feeder Tray 4, 5 color panel
removal and replacement 1211
dual cassette feeder Tray 4, 5 paper size sensors
removal and
replacement 1238
dual cassette feeder Tray 4, 5 rollers
removal and
replacement 1221
dual cassette feeder Tray 5 paper empty sensor
removal and
replacement 1259
dual cassette feeder Tray 5 paper stack height sensor
removal and
replacement 1259
dual cassette feeder Tray 5 pickup assembly
removal and
replacement 1254
dual cassette feeder Tray 5 pickup motor
removal and
replacement 1230
dual cassette feeder Tray 5 prefeed sensor
removal and
replacement 1263
dual cassette feeder tray heaters
removal and
replacement 1275
duplex
parts 2169
duplex 1 motor
removal and replacement 681
duplex 2 motor
removal and replacement 718
duplex assembly
removal and replacement 698
duplex jam 1 sensor
removal and replacement 664
duplex jam 2 sensor
removal and replacement 707
duplex unit
remove and replace parts 698
duplexer error
69.WX.YZ error 34, 66

E

easy-access USB port
locating 2
ejector unit
external finisher, remove and replace 1685
electrical specifications 1, 9
Embedded Jetdirect error
80.WX.YZ error 34, 66
end fence unit
booklet finisher, remove and replace 1919
external finisher, remove and replace 1540
engine
control panel, remove and replace parts 960

covers, remove and replace 231
covers, service parts 2161
CTD, service parts 2175
developer and drum, remove and replace parts 840
developer, service parts 2173
diagnostics 34, 35, 42, 43
drum, service parts 2174
duplex , service parts 2169
duplex unit, remove and replace parts 698
environmental sensor, switch, and fan 907
exit unit , service parts 2168
exit unit, remove and replace parts 585
fan, service parts 2179
feeding system, remove and replace parts 317
feeding system, right door assemblies remove and replace parts 317
feeding system, service parts 2163
feeding system, Tray 1 unit remove and replace parts 337
feeding system, Tray 2-3 units remove and replace parts 387
fuser unit, remove and replace parts 880
fuser, service parts 2177
image creation, remove and replace parts 834
image creation, service parts 2173
laser scanner unit, remove and replace parts 834
laser scanner unit, service parts 2173
loop sensing unit, remove and replace parts 514
LSU, remove and replace parts 834
main PCAs, remove and replace parts 963
main printed circuit assembly, remove and replace parts 963
PCA, service parts 2180
PCAs, remove and replace parts 963
power supply PCAs, remove and replace parts 1021
power supply printed circuit assembly, remove and replace parts 1021
printed circuit assembly, remove and replace parts 963
PTB, service parts 2176
registration and loop sensors, service parts 2166
registration unit, remove and replace parts 514
remove and replace parts 231
reservoir , service parts 2171
reservoir unit, remove and replace parts 786
sensor, service parts 2179
sub PCAs, remove and replace parts 987
sub printed circuit assembly, remove and replace parts 987
toner cartridge, remove and replace parts 724
toner cartridge, service parts 2170
toner collection unit, remove and replace parts 816
toner collection unit, service parts 2172
toner flow, remove and replace parts 724
toner flow, service parts 2170
tray 1, service parts 2164
tray 2, 3, service parts 2165
engine error (LaserJet)
46.WX.YZ error 34, 65
63.WX.YZ error 34, 66
engine error (PageWide)
61.WX.YZ error 34, 66
engine, printer
parts and diagrams 2161
entrance unit
booklet finisher, remove and replace 1867
external finisher, remove and replace 1400
environmental sensor, switch, and fan
remove and replace parts 907
error
fault 34
Ethernet (RJ-45)
locating 5
event log 34, 45, 67, 77
clear using touchscreen control panel 34, 45
find links to information 48
event log error (firmware)
42.WX.YZ error 34, 65
exit 2 motor
removal and replacement 633
exit 2 sensor
removal and replacement 649
exit cover stacker
removal and replacement 299
exit rear cover
removal and replacement 239
exit stack guide
removal and replacement 696
exit unit
parts 2168
removal and replacement 586
remove and replace parts 585
external booklet 2 of 5
parts 2206
external finisher
bridge unit, remove and replace 1372
buffer unit, remove and replace 1835
covers, remove and replace 1306
ejector unit, remove and replace 1685
end fence unit, remove and replace 1540
entrance unit, remove and replace 1400
main exit unit, remove and replace 1486
main output tray unit, remove and replace 1758
paddle unit, remove and replace 1514
paper holding unit, remove and replace 1799
punch unit, remove and replace 1421
stapler unit, remove and replace 1649
tamper unit, remove and replace 1582
top exit unit, remove and replace 1451
top output tray unit, remove and replace 1467
tray diverter unit, remove and replace 1423

external finisher booklet front cover
removal and replacement 1370
external finisher booklet output tray
removal and replacement 1329
external finisher bridge door sensor
removal and replacement 1377
external finisher bridge entrance sensor
removal and replacement 1382
external finisher bridge exit sensor
removal and replacement 1387
external finisher bridge motor
removal and replacement 1394
external finisher bridge unit
removal and replacement 1372
external finisher buffer motor
removal and replacement 1841
external finisher buffer solenoid assembly
removal and replacement 1835
external finisher caster
removal and replacement 1364
external finisher caster cover
removal and replacement 1308
external finisher caster fix nut
removal and replacement 1367
external finisher ejector 1 home sensor
removal and replacement 1715
external finisher ejector 1 motor sensor
removal and replacement 1729
external finisher ejector 2 motor sensor
removal and replacement 1744
external finisher ejector sensor
removal and replacement 1699
external finisher ejector unit
removal and replacement 1685
external finisher end fence home sensor
removal and replacement 1540
external finisher end fence motor
removal and replacement 1559
external finisher end fence motor assembly
removal and replacement 1554
external finisher entrance motor
removal and replacement 1417
external finisher entrance motor assembly
removal and replacement 1414
external finisher entrance sensor
removal and replacement 1400
external finisher exit motor
removal and replacement 1464
external finisher exit motor assembly
removal and replacement 1461
external finisher front cover
removal and replacement 1339
external finisher front door
removal and replacement 1306
external finisher front door switch
removal and replacement 1508
external finisher front lower left cover
removal and replacement 1354
external finisher front lower right cover
removal and replacement 1359
external finisher front paper holding sensor
removal and replacement 1799
external finisher front tamper
removal and replacement 1582
external finisher front tamper home sensor
removal and replacement 1594
external finisher front tamper motor
removal and replacement 1605
external finisher left lower cover
removal and replacement 1310, 1318
external finisher left upper cover
removal and replacement 1319
external finisher main exit cam home sensor
removal and replacement 1498
external finisher main exit cam motor
removal and replacement 1503
external finisher main exit cam motor assembly
removal and replacement 1493
external finisher main exit sensor
removal and replacement 1486
external finisher main output tray
removal and replacement 1334, 1758
external finisher main output tray lower limit sensor
removal and replacement 1772
external finisher main output tray motor drive assembly
removal and replacement 1786
external finisher main output tray motor sensor
removal and replacement 1783
external finisher main output tray top of stack sensor
removal and replacement 1760
external finisher main output tray top of stack switch
removal and replacement 1789

external finisher main output tray top of stack switch guide
removal and replacement 1564
external finisher main output tray top of stack switch lower guide
removal and replacement 1573
external finisher mounting brackets
removal and replacement 2156
external finisher paddle
removal and replacement 1514
external finisher paddle home sensor
removal and replacement 1529
external finisher paddle motor
removal and replacement 1535
external finisher paddle motor assembly
removal and replacement 1524
external finisher paper holding home sensor
removal and replacement 1811
external finisher paper holding motor drive assembly
removal and replacement 1823
external finisher punch cover
removal and replacement 1343
external finisher punch unit
removal and replacement 1421
external finisher rear cover
removal and replacement 1336
external finisher rear paper holding sensor
removal and replacement 1799
external finisher rear tamper
removal and replacement 1616
external finisher rear tamper home sensor
removal and replacement 1626
external finisher rear tamper motor
removal and replacement 1637
external finisher right upper cover
removal and replacement 1351
external finisher shaft hinge - door
removal and replacement 1361
external finisher staple cartridge
removal and replacement 1655
external finisher stapler front sensor
removal and replacement 1657
external finisher stapler manual staple sensor
removal and replacement 1672
external finisher stapler mid-front sensor
removal and replacement 1665
external finisher stapler mid-rear sensor
removal and replacement 1665
external finisher stapler position motor
removal and replacement 1678
external finisher stapler unit
removal and replacement 1649
external finisher stapler/stacker or booklet finishers
removal and replacement 1306
external finisher top cover
removal and replacement 1345
external finisher top door
removal and replacement 1348
external finisher top door open switch
removal and replacement 1432
external finisher top exit sensor
removal and replacement 1451
external finisher top jam cover assembly
removal and replacement 1423
external finisher top lower feed assembly
removal and replacement 1467
external finisher top output tray
removal and replacement 1332
external finisher top output tray paper full sensor
removal and replacement 1479
external finisher tray diverter
removal and replacement 1427
external finisher tray diverter cam
removal and replacement 1435
external finisher tray diverter home sensor
removal and replacement 1444
external finisher tray extension
removal and replacement 1476
external finisher, booklet maker
parts and diagrams 2204
external finisher, stapler/stacker
parts and diagrams 2197

F

fan error
58.WX.YZ error 34, 66
fans
FDB fan 918
laser scanner unit fan 944
LVPS fan 915
parts 2179
fax card
removal and replacement 1018
Fax menu (fax models only), control panel 34, 45, 78, 171
FDB
removal and replacement 1028
FDB fan
removal and replacement 918
feed 2 sensor
removal and replacement 504
feed drive assembly
removal and replacement 485
feed motor
removal and replacement 493

feeding system
remove and replace parts 317
right door assemblies, remove and replace parts 317
Tray 1 unit, remove and replace parts 337
Tray 2-3 units, remove and replace parts 387
FFC
automatic document feeder 1090
firmware communication error
49.WX.YZ error 34, 66
firmware install error
99.WX.YZ error 34, 66
hard disk error 34, 66
remote firmware upgrade error 34, 66
flat-flexible cable
automatic document feeder 1090
flatbed scanner
covers 1177
harness 1180
PCA 1180
sensor 1180
whole unit replacement 1169
flatbed scanner (Tarot)
removal and replacement 1169
flatbed, FFC 50 pin
removal and replacement 1184
flatbed, FFC 68 pin
removal and replacement 1189
flatbed, open sensor
removal and replacement 1199
flatbed, PCA
removal and replacement 1180
flatbed, power cable
removal and replacement 1194
flatbed, rear cover
removal and replacement 1177
flatbed, whole unit
removal and replacement 1169
flow ADF skew (LX du models) 34
fold unit
booklet finisher, remove and replace 2039
formatter
locating 1-3
removal and replacement 963
formatter lights 34, 35, 42
front cover
removal and replacement 315
front door
locating 2
front door switch
removal and replacement 948
front lower cover
removal and replacement 312
fuser
jams 63
fuser and exit drive assembly
removal and replacement 883
fuser and exit motor
removal and replacement 888
fuser drive board
removal and replacement 1028
fuser drive board fan
removal and replacement 918
fuser error
41.WX.YZ error 34, 65
laser scanner error 34, 65
paper path error 34, 65
fuser error (LaserJet)
50.WX.YZ error 34, 66
fuser gap motor
removal and replacement 893
fuser gap sensor
removal and replacement 897
fuser out sensor
removal and replacement 576
fuser out sensor harness
removal and replacement 579
fuser unit
removal and replacement 880
remove and replace parts 880
fuser ventilation duct
removal and replacement 940

G

General Settings menu, control panel 34, 45, 78, 98
general specifications 1, 9
glossary
terms and definitions 2245
guide toner cartridge assembly
removal and replacement 774
guides
cable guide 870

H

hard disk partition error
98.WX.YZ error 34, 66
hardware integration pocket (HIP)
locating 2
hardware integration pocket (HIP) is not functioning 34, 35, 38, 41
hardware integration pocket [HIP]
removal and replacement 294
harnesses
DCF, remove and replace 1275
flatbed scanner 1180
removal and replacement, DCF IF harness 1284
removal and replacement, dual cassette feeder door open switch and harness 1287
removal and replacement, dual cassette feeder IF harness 1284
removal and replacement, dual cassette feeder motor harness 2nd 1291
removal and replacement, dual cassette feeder sensor harness 1st 1294
removal and replacement, dual cassette feeder sensor harness 2nd 1298
removal and replacement, dual cassette feeder size harness 1302
HDD, riser card and cradle
removal and replacement 970
Help button
locating 5
Hi-Speed USB 2.0 printing port
locating 5
high-voltage power supply
removal and replacement 1021
hinge kit
automatic document feeder 1102
automatic document feeder, 5QJ90-67011, 5QJ90-67012 1155
Home button
locating 5
home button is unresponsive 34, 35, 38
HP Jetdirect print server
lights 34, 35, 42
HP Support viii, 229

HVPS
removal and replacement 1021

I

image creation
remove and replace parts 834
image quality
black lines, vertical 34
blurred image 34
flow ADF or ADF skew (LX du models) 34
foggy image 34
jitter image 34
light image 34
light lines, vertical 34
periodic black dots, horizontal 34
periodic black lines, horizontal 34
periodic light/dark dots, horizontal 34
periodic light/dark lines, horizontal 34
poor fusing 34
skewed image 34
stain on back side 34
standard tone, setting 34
uneven pitch 34
white lines, vertical 34
image scanner
covers, flatbed 1177
harness, flatbed 1180
PCA, flatbed 1180
sensor, flatbed 1180
whole unit replacement 1169
image scanner assembly
parts and diagrams 2183
image scanner assembly/ document feeder
parts and diagrams 2183
individual component
diagnostics 34, 35, 42
information
general 34
print reports 34
software version 34
supply status 34
inner cover
removal and replacement 302
input accessory error
67.WX.YZ error 34, 66
input device (department)
removal and replacement 1203
input devices
parts and diagrams 2191
input/output error
40.WX.YZ error 34, 65
integrated scanner assembly
flatbed (Tarot), removal and replacement 1169
removal and replacement 1034
removal and replacement dn bundle 1044
integrated scanner asset
200-sheet dn bundle, whole unit replacement 1044
300-sheet z bundle, whole unit replacement 1034
removal and replacement z, z+ bundle 1034
whole unit replacement 1034
integrated scanner z , z+
bundle 1035
integrated-scanner assembly
parts 2183
interface ports
locating 3, 5
interlocks
defeating 34, 35, 42, 43
internal diagnostics error
90.WX.YZ error 34, 66
video display error 34, 66
IOD
removal and replacement 999
ISA
drawer type keyboard 1035
parts 2183
parts and diagrams 2183
removal and replacement 1034
removal and replacement dn bundle 1044
removal and replacement flatbed, FFC 50 pin 1184
removal and replacement flatbed, FFC 68 pin 1189
removal and replacement flatbed, open sensor 1199
removal and replacement flatbed, PCA 1180
removal and replacement flatbed, power cable 1194
removal and replacement flatbed, rear cover 1177
removal and replacement flatbed, whole unit 1169
removal and replacement z z+ bundle 1034
whole unit replacement 1034
ISA, 200-sheet
dn bundle, whole unit replacement 1044
ISA, 300-sheet
z bundle, whole unit replacement 1034
z+ bundle, whole unit replacement 1034
island of data
removal and replacement 999

J

jam error (LaserJet)
13.WX.YZ error 34, 65
jam error (PageWide)
13.WX.YZ error 34, 65
jams
520-sheet trays 61
auto-navigation 57
causes of 58
document feeder 58
fuser 63
locations 34, 56
output bin 62
right door 63
Tray 1 60
Tray 2 61
Tray 3 61
Jetdirect print server
lights 34, 35, 42
job accounting error (firmware)
48.WX.YZ error 34, 66
job management error (firmware) 34, 66
job pipeline error (firmware) 34, 66
job parser error (firmware)
47.WX.YZ error 34, 66
printer calibration error 34, 66

K

keyboard
removal and replacement 1012
kits
tray 1 roller 384
tray 2/3 rollers 399, 453

L

LAN port
  locating 5
laser scanner error (LaserJet)
  51.WX.YZ error 34, 66
  52.WX.YZ error 34, 66
laser scanner unit
  parts 2173
  removal and replacement 834
  remove and replace parts 834
laser scanner unit fan
  removal and replacement 944
LEDs
  See lights
left cover
  removal and replacement 248
left top cover
  removal and replacement 242
left upper cover
  removal and replacement 244
lights
  formatter 34, 35, 42
  troubleshooting with 34, 35, 42
local area network (LAN)
  locating 5
loop actuator
  removal and replacement 566
loop sensing unit
  remove and replace parts 514
loop sensor 1
  removal and replacement 549
loop sensor 2
  removal and replacement 558
low-voltage power supply
  removal and replacement 1024
low-voltage power supply fan
  removal and replacement 915
low-voltage power supply fuser drive board fan assembly
  removal and replacement 922
LSU
  parts 2173
  removal and replacement 834
  remove and replace parts 834
LSU fan
  removal and replacement 944
LVPS
  removal and replacement 1024
LVPS fan
  removal and replacement 915
LVPS FDB fan assembly
  removal and replacement 922

M

machine cleaning for
  maintenance 24
  cleaning the ADF) 24
  cleaning the paper dust stick 24
  cleaning the scan glass 24
main exit unit
  external finisher, remove and replace 1486
main output tray unit
  external finisher, remove and replace 1758
main printed circuit assembly
  remove and replace parts 963
maintenance 24
  machine cleaning for maintenance 24
  preventive maintenance 24
maintenance counts
  part replacement count 34
Maintenance menu, control panel 214
maintenance parts 1, 9, 17
memory error
  82.WX.YZ error 34, 66
  EMMC error 34, 66
  hard disk error 34, 66
menu
  Support Tools menu 177
menu map 34, 45
menus, control panel
  Advanced Print Quality Pages 224
  Altitude Adjustment 211
  Auto Tone adjustment 215
  Backup/Restore 215
  Buckle Adjustment 185
  Calibrate Scanner 216
  Calibrate/Cleaning 34, 45, 78
  Cold Reset Paper 181
  Component tests 203
  Configuration/Status Pages 219
  Consumables Access Control 182
  Copy (MFP only) 34, 45, 78, 134
  Counts 179
  coverage report 179
  CTD Sensor Cleaning 216
  Custom Color 215
  Engine NVM Read/Write 194
  Event Log 178, 224
  Fax (fax models only) 34, 45, 78, 171
  Fax Reports 220
  Fax Service Log 221
  Fax Speaker Mode 221
  Fax T.30 Trace Report 220
  Fax V.29 Speed 214
  Fax V.34 221
  Finisher Adjustment 185
  Footer 213
  General Settings 34, 45, 78, 98
  Humidity 212
  Import/Export 215
  JBIG Compression 221
  License Management 216
  Low Alerts 181
  Low-temperature Idling Mode 210
  Maintenance 214
  Manage Trays 34, 45, 78, 176
  Manual Tone Adjustment 216
  Other Pages 220
  Paper Path Page 224
  Part Replacement Count 213
  PQ Troubleshooting Pages 221
  Print 34, 45, 78, 175
  Print Adjustment 183
  PTT Test Mode 213
  Reports 34, 45, 78, 96
  Reset Engine NVM 194
  Reset Supplies 214
  Reset Supplies Level 182
  Retrieve Diagnostic Data 225
  Retrieve Fax Diagnostic Data 225
  Run Fax Test 224
  Scan 143
  Scan (MFP only) 34, 45, 78
  Scanner Settings 179
  Sensors 195
  Serial Number 181
  Service 177
  Service ID 181
  Service Reports 183
  Software Version 183
  Supplies 34, 45, 78, 175
  Test Support 213
  Toner Density Calibration 216
  TR Control Mode 209
  Troubleshooting 219
  USB Firmware Upgrade 216
  Vapor Mode 212

middle left cover
removal and replacement 296
middle upper cover
removal and replacement 252
miscellaneous parts
booklet finisher, remove and replace 2156
motor error (LaserJet)
59.WX.YZ error 34, 66
motors
DCF, remove and replace 1224
developer motor K 867
drum, removal and replacement 864
duplex 1 motor 681
duplex 2 motor 718
exit 2 motor 633
feed motor 493
fuser and exit motor 888
fuser gap motor 893
PTB, removal and replacement 864
registration motor 536
removal and replacement, booklet finisher booklet blade motor 2084
removal and replacement, booklet finisher booklet fold motor 2093
removal and replacement, booklet finisher booklet fold motor assembly 2089
removal and replacement, booklet finisher c-fold blade motor 2062
removal and replacement, booklet finisher c-fold blade motor assembly 2056
removal and replacement, booklet finisher diverter motor 2125
removal and replacement, booklet finisher diverter motor assembly 2120
removal and replacement, booklet finisher end fence motor 1931
removal and replacement, booklet finisher entrance motor 1897
removal and replacement, booklet finisher entrance-presser motor assembly 1893
removal and replacement, booklet finisher paddle motor 1915
removal and replacement, booklet finisher paddle motor assembly 1911
removal and replacement, booklet finisher tamper motor 1983
removal and replacement, DCF feed motor 1235
removal and replacement, DCF Tray 4 pickup motor 1227
removal and replacement, DCF Tray 5 pickup motor 1230
removal and replacement, dual cassette feeder feed motor 1235
removal and replacement, dual cassette feeder Tray 4 pickup motor 1227
removal and replacement, dual cassette feeder Tray 5 pickup motor 1230
removal and replacement, external finisher bridge motor 1394
removal and replacement, external finisher buffer motor 1841
removal and replacement, external finisher end fence motor 1559
removal and replacement, external finisher end fence motor assembly 1554
removal and replacement, external finisher entrance motor 1417
removal and replacement, external finisher entrance motor assembly 1414
removal and replacement, external finisher exit motor 1464
removal and replacement, external finisher exit motor assembly 1461
removal and replacement, external finisher front tamper motor 1605
removal and replacement, external finisher main exit cam motor 1503
removal and replacement, external finisher main exit cam motor assembly 1493
removal and replacement, external finisher main output tray motor drive assembly 1786
removal and replacement, external finisher paddle motor 1535
removal and replacement, external finisher paddle motor assembly 1524
removal and replacement, external finisher paper holding motor drive assembly 1823
removal and replacement, external finisher rear tamper motor 1637
removal and replacement, external finisher stapler mid-front and mid-rear sensors 1678
toner dispense motor 734
toner dispense motor assembly 724
tray 2 pickup motor 436
tray 3 pickup motor 442

N

Near Field Communication error
81.WX.YZ error 34, 66
Bluetooth error 34, 66
external I/O card error 34, 66
internal EIO error 34, 66
wireless error 34, 66
network and software specifications 1, 9, 18
network interface 1, 9, 18
no control panel sound 34, 35, 38, 40
note iii

O

on/off button
locating 2
operating systems, supported 1, 9
operating-environment range
printer 12
option specifications 1, 9, 20
optional configurations 1, 9, 20
options list 1, 9, 20

other errors
drive unit 34
electrical circuit 34
feeding system 34
flow ADF 34
fuser 34
image system 34
laser scanner assembly 34
scanner 34
outer temperature humidity sensor assembly, sensor and holder
removal and replacement 907
output accessory error
66.WX.YZ error 34, 66
output bin
clear jams 62
locating 2
output bin 1 sensor
removal and replacement 600
output device
parts and diagrams 2196
removal and replacement 1306
output tray unit
booklet finisher, remove and replace 2131
OXPd/Web kit error
45.WX.YZ error 34, 65

P

paddle unit
booklet finisher, remove and replace 1907
external finisher, remove and replace 1514
page error
21.WX.YZ error 34, 65
paper
jams 58
paper dust holder
removal and replacement 583
paper handling error (LaserJet)
56.WX.YZ error 34, 66
paper handling specifications 1, 9
paper holding unit
external finisher, remove and replace 1799
paper jams
520-sheet trays 61
document feeder 58
fuser 63
locations 34, 56
output bin 62
right door 63
Tray 1 60
Tray 2 61
Tray 3 61
paper transfer belt (PTB)
removal and replacement 543
parts
200sh ADF 1 of 2 2188
200sh ADF 2 of 2 2189
300sh flow ADF 1 of 2 2185
300sh flow ADF 2 of 2 2186
booklet finisher 1 of 5 2204
booklet finisher 3 of 5 2208
booklet finisher 4 of 5 2210
booklet finisher 5 of 5 2211
covers 2161
CTD 2175
DCF 1 of 2 2192
DCF 2 of 2 2194
developer 2174
drum 2174
dual cassette feeder 1 of 2 2192
dual cassette feeder 2 of 2 2194
duplex 2169
exit unit 2168
external booklet 2 of 5 2206
fan 2179
integrated-scanner assembly 2183
ISA 2183
laser scanner unit 2173
LSU 2173
PCA 2177, 2181
PTB 2176
registration and loop sensors 2166
reservoir 2171
sensor 2179
stapler/stacker finisher 1 of 4 2197
stapler/stacker finisher 2 of 4 2199
stapler/stacker finisher 3 of 4 2201
stapler/stacker finisher 4 of 4 2202
tarot platen 2190
TCU 2172
toner 2170
toner collection unit 2172
tray 1 2164
tray 2, 3 2165
parts and diagrams
200sh ADF 2188
300sh flow ADF 2185
ADF / image scanner assembly 2183
base printer 2161
base printer, covers 2161
base printer, CTD 2175
base printer, developer 2173
base printer, drum 2174
base printer, duplex 2169
base printer, exit unit 2168
base printer, fan 2179
base printer, feeding system 2163
base printer, fuser 2177
base printer, image creation 2173
base printer, laser scanner unit 2173
base printer, PCA 2180
base printer, PTB 2176
base printer, registration and loop sensors 2166
base printer, reservoir 2171
base printer, sensor 2179
base printer, toner cartridge 2170
base printer, toner collection unit 2172
base printer, toner flow 2170
base printer, tray 1 2164
base printer, tray 2, 3 2165
booklet finisher 2204
DCF 2192
document feeder / image scanner assembly 2183
dual cassette feeder 2192
engine, printer 2161
image scanner assembly 2183
image scanner assembly / ADF 2183
input devices 2191
ISA 2183
output device 2196
stapler/stacker 2197
tarot platen 2189
parts, miscellaneous
booklet finisher, remove and replace 2156
PCA
automatic document feeder 1084

automatic document feeder, 5QJ90-67011, 5QJ90-67012 1137
PCAs
accelerator card 987
booklet finisher, remove and replace 2141
DCF, remove and replace 1275
fax card 1018
FDB 1028
flatbed scanner 1180
formatter 963
fuser drive board 1028
high-voltage power supply 1021
HVPS 1021
IOD 999
island of data 999
low-voltage power supply 1024
LVPS 1024
parts 2177, 2181
power key PCA 1003
removal and replacement, booklet finisher booklet finisher main PCA 2141
removal and replacement, booklet finisher booklet maker PCA 2146
removal and replacement, DCF 1278
removal and replacement, dual cassette feeder 1278
remove and replace parts 963
USB hub PCA 991
PCAs, main
remove and replace parts 963
PCAs, power supply
remove and replace parts 1021
PCAs, sub
remove and replace parts 987
pickup assembly, tray 2
removal and replacement 389
pickup assembly, tray 3
removal and replacement 445
ports
locating 5
power
consumption 1, 9
power key
removal and replacement 284
power key PCA
removal and replacement 1003
power subsystem 34, 35
power supply
troubleshooting 34, 35
power supply printed circuit assembly
remove and replace parts 1021
power-on troubleshooting
overview 34, 35
pre-boot menu options 34, 45, 67, 79
find links to information 48
precautions
disassemble or reassemble iv, 226
electrical iv, 226
ingestion hazard iv, 226
laser radiation hazard iv, 226
mechanical hazard iv, 226
thermal hazard iv, 226
presser unit
booklet finisher, remove and replace 1943
print bar error (PageWide)
62.WX.YZ error 34, 66
print drivers, supported 1, 9
Print menu, control panel 34, 45, 78, 175
print quality troubleshooting 34
flow ADF skew adjust 34
image quality 34
other errors 34
print specifications 1, 9
Print Test Page 34, 45, 78, 98
printed circuit assembly
automatic document feeder 1084
automatic document feeder, 5QJ90-67011, 5QJ90-67012 1137
remove and replace parts 963
printer
dimensions 1, 9
operating-environment range 12
weight 1, 9
printer engine
parts and diagrams 2161
printer memory error
20.WX.YZ error 34, 65
Process Cleaning Page 34, 45, 78
Product installation 23
Product maintenance 23
product number
locating 1, 2
location 3
PTB
parts 2176
removal and replacement 543
PTB drive assembly
removal and replacement 857
PTB motor
removal and replacement 864
punch unit
external finisher, remove and replace 1421

R

real-time clock error
11.WX.YZ error 34, 65
rear lower cover
removal and replacement 234
rear upper cover
removal and replacement 231
registration and loop sensors
parts 2166
registration drive assembly
removal and replacement 529
registration motor
removal and replacement 536
registration sensor
removal and replacement 521
registration unit
removal and replacement 514
remove and replace parts 514
removal and replacement
accelerator card 987
automatic document feeder 1049
automatic document feeder color panel 1065, 1124
automatic document feeder damper module 1110
automatic document feeder damper module, 5QJ90-67011, 5QJ90-67012 1162
automatic document feeder FFC 1143
automatic document feeder flat-flexible cable 1090
automatic document feeder front cover 1059
automatic document feeder hinge kit 1102
automatic document feeder hinge kit, 5QJ90-67011, 5QJ90-67012 1155
automatic document feeder pickup roller kit 1080

automatic document feeder pickup roller kit, 5QJ90-67011, 5QJ90-67012 1132
automatic document feeder power cable 1096, 1149
automatic document feeder printed circuit assembly 1084
automatic document feeder printed circuit assembly, 5QJ90-67011, 5QJ90-67012 1137
automatic document feeder rear cover 1067
automatic document feeder top cover 1073
automatic document feeder white backing 1075, 1127
automatic document feeder, 5QJ90-67011, 5QJ90-67012 1117
black developer unit 843
booklet finisher booklet blade home sensor 2067
booklet finisher booklet blade motor 2084
booklet finisher booklet diverter home sensor 2113
booklet finisher booklet fold motor 2093
booklet finisher booklet fold motor assembly 2089
booklet finisher booklet maker 1846
booklet finisher booklet maker PCA 2146
booklet finisher c-fold blade assembly 2039
booklet finisher c-fold blade home sensor 2050
booklet finisher c-fold blade motor 2062
booklet finisher c-fold blade motor assembly 2056
booklet finisher diverter 2097
booklet finisher diverter motor 2125
booklet finisher diverter motor assembly 2120
booklet finisher end fence home sensor 1919
booklet finisher end fence motor 1931
booklet finisher entrance motor 1897
booklet finisher entrance sensor 1879
booklet finisher entrance unit 1867
booklet finisher entrance-presser motor assembly 1893
booklet finisher harness guide 1855
booklet finisher main PCA 2141
booklet finisher output tray 2131
booklet finisher output tray sensor 2133
booklet finisher paddle home sensor 1908
booklet finisher paddle motor 1915
booklet finisher paddle motor assembly 1911
booklet finisher presser home sensor 1943
booklet finisher staple cartridge 2036
booklet finisher stapler 2020
booklet finisher tamper 1948
booklet finisher tamper home sensor 1965
booklet finisher tamper motor 1983
booklet finisher tamper sensor 2001
booklet finisher, only 1846
cable guide 870
control panel, 10.1 inch 960
control panel, 8 inch 960
controller cover 237
CTD sensor assembly 873
DCF (department) 1203
DCF caster wheel 1214
DCF door open switch and harness 1287
DCF feed drive assembly 1232
DCF feed motor 1235
DCF feed sensor 1269
DCF holder wheel kit 1216
DCF IF harness 1284
DCF left cover 1207
DCF motor harness 2nd 1291
DCF PCA 1278
DCF pickup drive assembly 1224
DCF rear cover 1205
DCF right cover 1203
DCF right door 1209
DCF right door open switch holder 1281
DCF sensor harness 1st 1294
DCF sensor harness 2nd 1298
DCF size harness 1302
DCF Tray 4 paper empty sensor 1245
DCF Tray 4 paper stack height sensor 1245
DCF Tray 4 pickup assembly 1241
DCF Tray 4 pickup motor 1227
DCF Tray 4 prefeed sensor 1249
DCF Tray 4, 5 cassette 1219
DCF Tray 4, 5 color panel 1211
DCF Tray 4, 5 paper size sensors 1238
DCF Tray 4, 5 rollers 1221
DCF Tray 5 paper empty sensor 1259
DCF Tray 5 paper stack height sensor 1259
DCF Tray 5 pickup assembly 1254
DCF Tray 5 pickup motor 1230
DCF Tray 5 prefeed sensor 1263
DCF tray heaters 1275
developer drive assembly 857
developer fan assembly 926
developer motor K 867
developer powder 848
developer suction duct 937
developer unit 843
drum drive assembly 857
drum motor 864
drum unit 840
dual cassette feeder (department) 1203
dual cassette feeder caster wheel 1214
dual cassette feeder door open switch and harness 1287
dual cassette feeder feed drive assembly 1232
dual cassette feeder feed motor 1235
dual cassette feeder feed sensor 1269
dual cassette feeder holder wheel kit 1216

dual cassette feeder IF harness 1284
dual cassette feeder left cover 1207
dual cassette feeder motor harness 2nd 1291
dual cassette feeder PCA 1278
dual cassette feeder pickup drive assembly 1224
dual cassette feeder rear cover 1205
dual cassette feeder right cover 1203
dual cassette feeder right door 1209
dual cassette feeder right door open switch holder 1281
dual cassette feeder sensor harness 1st 1294
dual cassette feeder sensor harness 2nd 1298
dual cassette feeder size harness 1302
dual cassette feeder Tray 4 paper empty sensor 1245
dual cassette feeder Tray 4 paper stack height sensor 1245
dual cassette feeder Tray 4 pickup assembly 1241
dual cassette feeder Tray 4 pickup motor 1227
dual cassette feeder Tray 4 prefeed sensor 1249
dual cassette feeder Tray 4, 5 cassette 1219
dual cassette feeder Tray 4, 5 color panel 1211
dual cassette feeder Tray 4, 5 paper size sensors 1238
dual cassette feeder Tray 4, 5 rollers 1221
dual cassette feeder Tray 5 paper empty sensor 1259
dual cassette feeder Tray 5 paper stack height sensor 1259
dual cassette feeder Tray 5 pickup assembly 1254
dual cassette feeder Tray 5 pickup motor 1230
dual cassette feeder Tray 5 prefeed sensor 1263
dual cassette feeder tray heaters 1275
duplex 1 motor 681
duplex 2 motor 718
duplex assembly 698
duplex jam 1 sensor 664
duplex jam 2 sensor 707
exit 2 motor 633
exit 2 sensor 649
exit cover stacker 299
exit rear cover 239
exit stack guide 696
exit unit 586
external finisher booklet front cover 1370
external finisher booklet output tray 1329
external finisher bridge door sensor 1377
external finisher bridge entrance sensor 1382
external finisher bridge exit sensor 1387
external finisher bridge motor 1394
external finisher bridge unit 1372
external finisher buffer motor 1841
external finisher buffer solenoid assembly 1835
external finisher caster 1364
external finisher caster cover 1308
external finisher caster fix nut 1367
external finisher ejector 1 home sensor 1715
external finisher ejector 1 motor sensor 1729
external finisher ejector 2 motor sensor 1744
external finisher ejector sensor 1699
external finisher ejector unit 1685
external finisher end fence home sensor 1540
external finisher end fence motor 1559
external finisher end fence motor assembly 1554
external finisher entrance motor 1417
external finisher entrance motor assembly 1414
external finisher entrance sensor 1400
external finisher exit motor 1464
external finisher exit motor assembly 1461
external finisher front cover 1339
external finisher front door 1306
external finisher front door switch 1508
external finisher front lower left cover 1354
external finisher front lower right cover 1359
external finisher front paper holding sensor 1799
external finisher front tamper 1582
external finisher front tamper home sensor 1594
external finisher front tamper motor 1605
external finisher left lower cover 1310, 1318
external finisher left upper cover 1319
external finisher main exit cam home sensor 1498
external finisher main exit cam motor 1503
external finisher main exit cam motor assembly 1493
external finisher main exit sensor 1486
external finisher main output tray 1334, 1758
external finisher main output tray lower limit sensor 1772
external finisher main output tray motor drive assembly 1786
external finisher main output tray motor sensor 1783
external finisher main output tray top of stack sensor 1760
external finisher main output tray top of stack switch 1789

external finisher main output tray top of stack switch guide 1564
external finisher main output tray top of stack switch lower guide 1573
external finisher mounting brackets 2156
external finisher paddle 1514
external finisher paddle home sensor 1529
external finisher paddle motor 1535
external finisher paddle motor assembly 1524
external finisher paper holding home sensor 1811
external finisher paper holding motor drive assembly 1823
external finisher punch cover 1343
external finisher punch unit 1421
external finisher rear cover 1336
external finisher rear paper holding sensor 1799
external finisher rear tamper 1616
external finisher rear tamper home sensor 1626
external finisher rear tamper motor 1637
external finisher right upper cover 1351
external finisher shaft hinge - door 1361
external finisher staple cartridge 1655
external finisher stapler front sensor 1657
external finisher stapler manual staple sensor 1672
external finisher stapler mid-front sensor 1665
external finisher stapler mid-rear sensor 1665
external finisher stapler position motor 1678
external finisher stapler unit 1649
external finisher stapler/stacker or booklet finishers 1306
external finisher top cover 1345
external finisher top door 1348
external finisher top door open switch 1432
external finisher top exit sensor 1451
external finisher top jam cover assembly 1423
external finisher top lower feed assembly 1467
external finisher top output tray 1332
external finisher top output tray paper full sensor 1479
external finisher tray diverter 1427
external finisher tray diverter cam 1435
external finisher tray diverter home sensor 1444
external finisher tray extension 1476
fax card 1018
FDB 1028
FDB fan 918
feed 2 sensor 504
feed drive assembly 485
feed motor 493
flatbed, FFC 50 pin 1184
flatbed, FFC 68 pin 1189
flatbed, open sensor 1199
flatbed, PCA 1180
flatbed, power cable 1194
flatbed, rear cover 1177
flatbed, whole unit 1169
formatter 963
front cover 315
front door switch 948
front lower cover 312
fuser and exit drive assembly 883
fuser and exit motor 888
fuser drive board 1028
fuser gap motor 893
fuser gap sensor 897
fuser out sensor 576
fuser out sensor harness 579
fuser unit 880
fuser ventilation duct 940
guide toner cartridge assembly 774
hardware integration pocket [HIP] 294
high-voltage power supply 1021
HVPS 1021
inner cover 302
input device (department) 1203
integrated scanner assembly dn bundle 1044
integrated scanner asset z z+ bundle 1034
IOD 999
island of data 999
keyboard 1012
laser scanner unit 834
laser scanner unit fan 944
left cover 248
left top cover 242
left upper cover 244
loop actuator 566
loop sensor 1 549
loop sensor 2 558
low-voltage power supply 1024
LSU 834
LVPS 1024
LVPS fan 915
LVPS FDB fan assembly 922
middle left cover 296
middle upper cover 252
outer temperature humidity sensor assembly, sensor and holder 907
output bin 1 sensor 600
output device 1306
paper dust holder 583
paper transfer belt (PTB) 543
pickup assembly, tray 3 445
power key 284
power key PCA 1003
PTB drive assembly 857
PTB motor 864
rear lower cover 234
rear upper cover 231
registration drive assembly 529
registration motor 536
registration sensor 521
registration unit 514
reservoir drive assembly 801
reservoir unit 786
return gate solenoid 617
right door 317
right door exit assembly 573
right door front damper 327
right door front damper bracket 332
right door front link 322

right door sHCI dummy cover 254
right door switch 956
right front cover 268
right middle cover 275
right middle cover assembly 271
right rear cover 266
right upper cover 256
riser card and cradle 970
solid state drive 983
solid state drive rivet 975
SSD cradle 977
tie stoppers 310
toner cartridge, control panel 755
toner cartridge, disassemble 756
toner collection unit 816
toner collection unit detection sensor 818
toner collection unit full sensor assembly 826
toner CRUM module assembly 765
toner dispense motor 734
toner dispense motor assembly 724
toner dispense motor sensor 743
toner residual senor 774
Tray 1 clutch 374
tray 1 empty sensor 355
tray 1 roller kit 384
tray 1 unit 337
tray 2 empty sensor 403
tray 2 open and paper size sensor 427
tray 2 or tray 3 387
tray 2 pickup assembly 389
tray 2 pickup drive assembly 431
tray 2 pickup motor 436
tray 2 prefeed sensor 415
tray 2 stack height sensor 403
tray 2/3 roller kit 399, 453
tray 3 empty sensor 457
tray 3 open and paper size sensor 477
tray 3 pickup drive assembly 439
tray 3 pickup motor 442
tray 3 prefeed sensor 467
tray 3 stack height sensor 457
tray heaters 482
USB hub PCA 991
Remove and replace 226
remove and replace parts
base printer 231
control panel 960
developer and drum 840
duplex unit 698
environmental sensor, switch, and fan 907
exit unit 585
feeding system 317
feeding system, right door assemblies 317
feeding system, Tray 1 unit 337
feeding system, Tray 2-3 units 387
fuser unit 880
image creation 834
laser scanner unit 834
loop sensing unit 514
LSU 834
main PCAs 963
main printed circuit assembly 963
PCAs 963
power supply PCAs 1021
power supply printed circuit assembly 1021
printed circuit assembly 963
registration unit 514
reservoir unit 786
sub PCAs 987
sub printed circuit assembly 987
toner cartridge 724
toner collection unit 816
toner flow 724
reports
event log 67, 77
supplies status page 67
Reports menu, control panel 34, 45, 78, 96
reservoir
parts 2171
reservoir drive assembly
removal and replacement 801
reservoir unit
removal and replacement 786
remove and replace parts 786
return gate solenoid
removal and replacement 617
right door
jams 63
locating 2
removal and replacement 317
right door exit assembly
removal and replacement 573
right door front damper
removal and replacement 327
right door front damper bracket
removal and replacement 332
right door front link
removal and replacement 322
right door sHCI dummy cover
removal and replacement 254
right door switch
removal and replacement 956
right front cover
removal and replacement 268
right middle cover
removal and replacement 275
right middle cover assembly
removal and replacement 271
right rear cover
removal and replacement 266
right upper cover
removal and replacement 256
riser card and cradle
removal and replacement 970
rivet, solid state drive
removal and replacement 975
RJ-45 port
locating 5
rollers
automatic document feeder pickup roller kit 1080
automatic document feeder pickup roller kit, 5QJ90-67011, 5QJ90-67012 1132
DCF, remove and replace 1221
removal and replacement, DCF 1221

S

safety precautions iv, 226
Scan menu (MFP only), control panel 34, 45, 78
Scan menu, control panel 143
scan specifications 1, 9
scanner error
30.WX.YZ error 34, 65
security error
33.WX.YZ error 34, 65
senors
toner residual senor, removal and replacement 774
sensor error
54.WX.YZ error 34, 66

58.WX.YZ error 34, 66
sensors
base printer service parts, registration and loop sensors 2166
CTD sensor assembly 873
DCF, remove and replace 1238
duplex jam 1 sensor 664
duplex jam 2 sensor 707
exit 2 sensor 649
feed 2 sensor 504
flatbed scanner 1180
fuser gap sensor 897
fuser out sensor 576
fuser out sensor harness 579
loop actuator 566
loop sensor 1 549
loop sensor 2 558
outer temperature humidity sensor assembly 907
output bin 1 sensor 600
parts 2179
registration sensor 521
removal and replacement flatbed, open sensor 1199
removal and replacement, booklet finisher booklet blade home sensor 2067
removal and replacement, booklet finisher booklet diverter home sensor 2113
removal and replacement, booklet finisher c-fold blade home sensor 2050
removal and replacement, booklet finisher end fence home sensor 1919
removal and replacement, booklet finisher entrance sensor 1879
removal and replacement, booklet finisher output tray sensor 2133
removal and replacement, booklet finisher paddle home sensor 1908
removal and replacement, booklet finisher presser home sensor 1943
removal and replacement, booklet finisher tamper sensor 2001
removal and replacement, DCF feed sensor 1269
removal and replacement, DCF paper size 1238
removal and replacement, DCF Tray 4 paper empty sensor 1245, 1259
removal and replacement, DCF Tray 4 paper stack height sensor 1245
removal and replacement, DCF Tray 4 prefeed sensor 1249
removal and replacement, DCF Tray 5 paper stack height sensor 1259
removal and replacement, DCF Tray 5 prefeed sensor 1263
removal and replacement, external finisher bridge door sensor 1377
removal and replacement, external finisher bridge entrance sensor 1382
removal and replacement, external finisher bridge exit sensor 1387
removal and replacement, external finisher ejector 1 home sensor 1715
removal and replacement, external finisher ejector 1 motor sensor 1729
removal and replacement, external finisher ejector 2 motor sensor 1744
removal and replacement, external finisher ejector sensor 1699
removal and replacement, external finisher end fence home sensor 1540
removal and replacement, external finisher entrance sensor 1400
removal and replacement, external finisher front paper holding sensor 1799
removal and replacement, external finisher front tamper home sensor 1594
removal and replacement, external finisher main exit cam home sensor 1498
removal and replacement, external finisher main exit sensor 1486
removal and replacement, external finisher main output tray lower limit sensor 1772
removal and replacement, external finisher main output tray motor sensor 1783
removal and replacement, external finisher main output tray top of stack sensor 1760
removal and replacement, external finisher paddle home sensor 1529
removal and replacement, external finisher paper holding home sensor 1811
removal and replacement, external finisher rear paper holding sensor 1799
removal and replacement, external finisher rear tamper home sensor 1626
removal and replacement, external finisher stapler front sensor 1657
removal and replacement, external finisher stapler manual staple sensor 1672
removal and replacement, external finisher stapler mid-front and mid-rear sensors 1665
removal and replacement, external finisher top exit sensor 1451
removal and replacement, external finisher top output tray paper full sensor 1479
removal and replacement, external finisher tray diverter home sensor 1444
toner collection unit detection sensor 818
toner collection unit full sensor assembly 826
toner dispense motor 743
tray 1 empty sensor 355
tray 2 empty sensor, removal and replacement 403
tray 2 open and paper size sensor, removal and replacement 427
tray 2 prefeed sensor, removal and replacement 415

tray 2 stack height sensor, removal and replacement 403
tray 3 empty sensor, removal and replacement 457
tray 3 open and paper size sensor, removal and replacement 477
tray 3 prefeed sensor, removal and replacement 467
tray 3 stack height sensor, removal and replacement 457
serial number
locating 1-3
service functions
capture log 34
debug log 34
envelope rotate 34
main memory clear 34
transfer assembly control 34
Service menu, control panel 177
service mode 34
diagnostics 34
entering service mode 34
information 34
maintenance counts 34
mode menu tree 34
service functions 34
service parts
base printer, covers 2161
base printer, CTD 2175
base printer, developer 2173
base printer, drum 2174
base printer, duplex 2169
base printer, exit unit 2168
base printer, fan 2179
base printer, feeding system 2163
base printer, fuser 2177
base printer, image creation 2173
base printer, laser scanner unit 2173
base printer, PCA 2180
base printer, PTB 2176
base printer, registration and loop sensors 2166
base printer, reservoir 2171
base printer, sensor 2179
base printer, toner cartridge 2170
base printer, toner collection unit 2172
base printer, toner flow 2170
base printer, tray 1 2164
base printer, tray 2, 3 2165
Sign In button
locating 5
Sign Out button
locating 5
software and solutions 1, 9, 18
solenoids
removal and replacement, external finisher buffer solenoid assembly 1835
return gate solenoid 617
solid state drive
removal and replacement 983
solid state drive rivet
removal and replacement 975
solve problems
control panel messages 65
CPMD 65
specifications 1, 9
copy specifications 1, 9
electrical and acoustic 1, 9
general specifications 1, 9
maintenance parts 1, 9, 17
network interface 1, 9, 18
network specifications 1, 9, 18
option 20
options 1, 9, 20
options list 1, 9, 20
paper handling specifications 1, 9
print specifications 1, 9
scan specifications 1, 9
software and solutions 1, 9, 18
software specifications 1, 9, 18
supplies 1, 9, 17
SSA
flatbed (Tarot), removal and replacement 1169
SSD
removal and replacement 983
SSD cradle
removal and replacement 977
SSD, cradle
removal and replacement 977
stapler unit
booklet finisher, remove and replace 2019
external finisher, remove and replace 1649
stapler/stacker finisher
parts and diagrams 2197
stapler/stacker finisher 1 of 4
parts 2197
stapler/stacker finisher 2 of 4
parts 2199
stapler/stacker finisher 3 of 4
parts 2201
stapler/stacker finisher 4 of 4
parts 2202
stapler/stacker or booklet finishers
removal and replacement 1306
sub printed circuit assembly
remove and replace parts 987
supplies
toner cartridge, control panel 755
toner cartridge, disassemble 756
supplies error (LaserJet)
10.WX.YZ error 34, 65
supplies error (PageWide)
17.WX.YZ error 34, 65
Supplies menu, control panel 34, 45, 78, 175
supplies status page 67
switches
front door switch 948
removal and replacement, DCF door open switch and harness 1287
removal and replacement, DCF right door open switch holder 1281
removal and replacement, dual cassette feeder right door open switch holder 1281
removal and replacement, external finisher front door switch 1508
removal and replacement, external finisher main output tray top of stack switch 1789
removal and replacement, external finisher main output tray top of stack switch guide 1564
removal and replacement, external finisher main output tray top of stack switch lower guide 1573
removal and replacement, external finisher top door open switch 1432
right door switch 956
system error (LaserJet)
62.WX.YZ error 34, 66

system requirements
minimum 1, 9

T

tamper unit
external finisher, remove and replace 1582
tarot platen
parts 2190
parts and diagrams 2189
TCU
parts 2172
removal and replacement 816
terms and definitions
glossary 2245
tie stoppers
removal and replacement 310
tip iii
toner
parts 2170
toner cartridge
remove and replace parts 724
toner cartridge, control panel
removal and replacement 755
toner cartridge, disassemble
removal and replacement 756
toner collection unit
parts 2172
removal and replacement 816
remove and replace parts 816
toner collection unit detection sensor
removal and replacement 818
toner collection unit full sensor assembly
removal and replacement 826
toner CRUM module assembly
removal and replacement 765
toner dispense motor
removal and replacement 734
toner dispense motor assembly
removal and replacement 724
toner dispense motor sensor
removal and replacement 743
toner flow
remove and replace parts 724
toner residual senor
removal and replacement 774
tools, additional
troubleshooting 48
top exit unit
external finisher, remove and replace 1451
top output tray unit
external finisher, remove and replace 1467
touchscreen
locating features 5
touchscreen blank, white, or dim (no image) 34, 35, 38
touchscreen has an unresponsive zone 34, 35, 38, 39
tray 1
base printer, service parts 2164
parts 2164
Tray 1
jams 60
jams, clearing 34
locating 2
Tray 1 clutch
removal and replacement 374
tray 1 empty sensor
removal and replacement 355
tray 1 roller kit
removal and replacement 384
tray 1 unit
removal and replacement 337
tray 2
removal and replacement 387
Tray 2
jams 61
jams, clearing 34
locating 2
tray 2 empty sensor
removal and replacement 403
tray 2 open and paper size sensor
removal and replacement 427
tray 2 pickup assembly
removal and replacement 389
tray 2 pickup drive assembly
removal and replacement 431
tray 2 pickup motor
removal and replacement 436
tray 2 prefeed sensor
removal and replacement 415
tray 2 stack height sensor
removal and replacement 403
tray 2, 3
base printer, service parts 2165
parts 2165
tray 2/3 roller kit
removal and replacement 399, 453
tray 3
removal and replacement 387
Tray 3
jams 61
jams, clearing 34
locating 2
tray 3 empty sensor
removal and replacement 457
tray 3 open and paper size sensor
removal and replacement 477
tray 3 pickup assembly
removal and replacement 445
tray 3 pickup drive assembly
removal and replacement 439
tray 3 pickup motor
removal and replacement 442
tray 3 prefeed sensor
removal and replacement 467
tray 3 stack height sensor
removal and replacement 457
tray diverter unit
external finisher, remove and replace 1423
tray heaters
removal and replacement 482
tray motor error (LaserJet)
60.WX.YZ error 34, 66
tray selection - use requested tray 34, 45, 78, 98
trays
jams, clearing 34
locating 2
removal and replacement, DCF 1219
tray 2 or tray 3, remove and replace 387
tray heaters, remove and replace 482
Trays menu, control panel 34, 45, 78, 176
troubleshooting
additional tools 48
checklist 34, 45
control panel checks 34, 35, 38
event log 67, 77
jams 56, 58
lights, using 34, 35, 42
power 34, 35
process 34, 35
supplies status page 67
Troubleshooting menu, control panel 219
troubleshooting tools
control panel messages 65
CPMD 65

U

understand lights on the formatter
    formatter lights 34, 35, 42
understand the lights on the formatter
    formatter
    HP Jetdirect LEDs 34, 35, 42
unit parts
    DCF, remove and replace 1219
USB hub PCA
    removal and replacement 991
USB port
    locating 5
Use Requested Tray 34, 45, 78, 98

W

warning iii
weight
    accessories 1, 9
    printer 1, 9
white backing 1075, 1127
whole unit replacement
    flatbed scanner 1169
    integrated scanner
        asset 1034