

SonicWall® Secure Mobile Access 6210/7210 Hard Drive Installation and Replacement

This document provides instructions for removing and installing a replacement hard drive in your SonicWall Secure Mobile Access 6210/7210 appliance.

A replacement hard drive can be inserted into either one of the two drive slots on the back of your SMA 6210/7210 appliance.

Rear view of the Secure Mobile Access 6210



Rear view of the Secure Mobile Access 7210



Removing the Defective Hard Drive from the Appliance

To remove a defective hard drive from the SonicWall Secure Mobile Access 6210/7210:

- 1 There is no need to power down the appliance.
- 2 Press the square button with the orange circle on the left side of the defective drive to pop-out the drive handle.
- 3 Grasp the drive handle and pull the drive straight out to remove it from the slot.



Installing a New Hard Drive into the Appliance

WARNING: Do NOT insert anything except the Secure Mobile Access 6210/7210 replacement hard drive into the appliance slot.

To install the new hard drive in the SMA 6210/7210 appliance:

- 1 Remove the new hard drive from the shipping package.
- 2 Pop open the drive handle on the new hard drive by pressing the square button with the orange circle on the side of the drive.
- 3 Insert the new drive into the empty slot, label side up with the handle sticking out.
- 4 Press the drive firmly into place to seat the connectors, and then close the handle.

Installation et remplacement du disque dur de l'appareil

Ce document indique la marche à suivre pour retirer et installer un disque dur de remplacement dans votre appareil SonicWall Secure Mobile Access 6210/7210.

Vous pouvez insérer un disque dur de remplacement dans l'un des deux logements de disque situés à l'arrière de votre appareil SMA 6210/7210.

Retrait du disque dur défectueux de l'appareil

Pour retirer un disque dur défectueux du SonicWall Secure Mobile Access 6210/7210 :

- 1 Il n'est pas nécessaire de débrancher l'appareil.
- 2 Appuyez sur le bouton carré avec un cercle orange situé à la gauche du disque défectueux pour faire sortir la poignée du disque.
- 3 Saisissez la poignée du disque et tirez ce dernier droit vers l'arrière pour le retirer de son logement.

Installation d'un nouveau disque dur dans l'appareil

AVERTISSEMENT : N'INSÉREZ AUCUN OBJET autre qu'un disque dur de remplacement pour appareil Secure Mobile Access 6210/7210 dans le logement de l'appareil.

Pour installer un nouveau disque dur dans l'appareil SMA 6210/7210

- 1 Retirez le nouveau disque dur de son emballage.
- 2 Appuyez sur le bouton carré avec un cercle orange situé à côté du disque pour faire sortir la poignée du nouveau disque.
- 3 Insérez le nouveau disque dans le logement vide, avec l'étiquette vers le haut et la poignée en saillie hors de l'appareil.
- 4 Poussez le disque fermement pour que les connecteurs se mettent en place, puis fermez la poignée.

Austausch der Festplatte und Installation

Dieses Dokument enthält Anweisungen zum Entfernen und Installieren von schwer Ersatz-Festplatte in Ihrem SonicWall Appliance fahren.

Eine Ersatz-Festplatte kann in keinem von den zwei Festplatten-Slots auf der Vorderseite des Gerätes eingefügt werden.

Entfernen der Defekten Festplatte vom Gerät

Führen Sie die folgenden Schritte aus, um eine defekte Festplatte von der Vorderseite des SonicWall entfernen:

- 1 Es ist nicht erforderlich, das Gerät auszuschalten
- 2 Drücken Sie die Quadrat-Taste mit dem Orangen Kreis auf der linken Seite des fehlerhaften Laufwerks Pop-out der Griff des.
- 3 Fassen Sie den Griff des und ziehen Sie das Laufwerk gerade heraus, um es aus dem Steckplatz heraus.

Installation einer Neuen Festplatte in das Gerät

WARNING: Stecken Sie nichts außer die SMA 6210/7210 Festplatte im Gerät-Steckplatz.

Um eine neue Festplatte zu installieren, führen Sie die folgenden Schritte aus:

- 1 Entfernen Sie die neue Festplatte aus den Versand Paket.
- 2 Pop öffnen Sie den Laufwerk-Griff auf die neue Festplatte durch Drücken der Quadrat-Taste mit dem Orangen Kreis auf der Seite des Laufwerks.
- 3 Legen Sie das neue Laufwerk in den leeren Steckplatz, bedruckten Seite nach oben mit dem Griff herausragen.
- 4 Drücken Sie das Laufwerk fest einrastet, die Anschlüsse zu setzen, und schließen Sie dann das Handle.

SonicWall SMA 6210/7210 硬碟更換和安裝

該文件規定了拆除和安裝在 SMA 6210/7210 網絡安全設備更換硬碟的說明。

要更換的硬碟可以插入到 SonicWall 裝置的前方兩個硬碟插槽中的任一個。

從 SonicWall 裝置移除故障的硬碟

完成以下的步驟以便於從 SonicWall 裝置移除故障的硬碟：

- 1 不需要關閉設備電源
- 2 按下故障硬碟左側圓形橘色的方形按鈕讓硬碟的把手彈出。
- 3 握住硬碟手柄，將硬碟直直地拉出，將其從插槽中取出。

安裝新的硬碟到設備

 **警告：**不插入任何除 SMA 6210/7210 硬碟到設備插槽。

要安裝新的 SMA 6210/7210 硬碟完成以下步驟：

- 1 拆除新硬碟的包裝。
- 2 按下新硬碟左側圓形橘色的方形按鈕，讓硬碟的把手彈出。
- 3 將新的硬碟插入空插槽，標籤的一面朝上用手柄露在外面。
- 4 將硬碟按下讓硬碟與連接器連接，並闔上硬碟把手。

This hard drive is for use only with SonicWall appliances indicated below. Use of this hard drive with a SonicWall appliance that is not approved will void the warranty for that appliance. This hard drive is provided as a replacement and is provided on an “as is” basis without warranty of any kind.

This hard drive, 02-SSC-1007 SONICWALL SMA 6210/7210 1TB HDD, is approved for use with:

02-SSC-0976 SonicWall Secure Mobile Access 6210

02-SSC-0978 SonicWall Secure Mobile Access 7210

For information and related documents, see the following Web site:

<https://sonicwall.com/support>

SonicWall® Secure Mobile Access 6210/7210 Hard Drive

Installation Guide

Copyright © 2019 SonicWall Inc. All rights reserved.

SonicWall is a trademark or registered trademark of SonicWall Inc. and/or its affiliates in the U.S.A. and/or other countries. All other trademarks are property of their respective owners.

The information in this document is provided in connection with SonicWall Inc. and/or its affiliates' products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document. SonicWall Inc. and/or its affiliates do not make any commitment to update the information contained in this document. For more information, visit <http://sonicwall.com/legal>.

Legend



WARNING: A WARNING icon indicates a potential for property damage, personal injury, or death.



CAUTION: A CAUTION icon indicates potential damage to hardware or loss of data if instructions are not followed.



IMPORTANT, NOTE, TIP, MOBILE, or VIDEO: An information icon indicates supporting information.

Secure Mobile Access 6210/7210 Hard Drive Installation Guide
Updated - August 2019
232-004846-51 Rev A



SONICWALL®