Maintenance and Service Guide
HP Z4 G6i Workstation Desktop PC

SUMMARY

This guide provides maintenance information about such topics as spare parts, removal and replacement of parts, security, and backing up.

Legal information

© Copyright 2026 HP Development Company, L.P.

AMD is a trademark of Advanced Micro Devices, Inc. Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. Intel, Thunderbolt, and Xeon are trademarks of Intel Corporation in the U.S. and other countries. Linux is the registered trademark of Linus Torvalds in the U.S. and other countries. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. NVIDIA and RTX are trademarks and/or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Red Hat, Inc, Red Hat, and the Red Hat logo are trademarks or registered trademarks of Red Hat, Inc. or its subsidiaries in the United States and other countries. USB Type-C, USB-C, and the USB 5 Gbps, USB 10 Gbps, and USB 20 Gbps port logos are trademarks or registered trademarks of USB Implementers Forum. DisplayPort and the DisplayPort logo are trademarks owned by the Video Electronics Standards Association (VESA) in the United States and other countries.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: April 2026

Document Part Number: P74997-001

Product notice

This guide describes features that are common to most models. Some features may not be available on your computer.

Not all features are available in all editions or versions of Windows. Systems may require upgraded and/or separately purchased hardware, drivers, software or BIOS update to take full advantage of Windows functionality. Windows is automatically updated, which is always enabled. High-speed internet and Microsoft account required. ISP fees may apply and additional requirements may apply over time for updates. See http://www.windows.com. **If your product ships with Windows in S Mode:** Windows in S Mode works exclusively with apps from the Microsoft Store within Windows. Certain default settings, features, and apps cannot be changed. Some accessories and apps that are compatible with Windows may not work (including some antivirus, PDF writers, driver utilities, and accessibility apps), and performance may vary, even if you switch out of S Mode. If you switch to Windows, you cannot switch back to S Mode. Learn more at Windows.com/SmodeFAQ.

To access the latest user guides, go to http://www.hp.com/support, and follow the instructions to find your product. Then select **Manuals**.

Software terms

By installing, copying, downloading, or otherwise using any software product preinstalled on this computer, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a full refund subject to the refund policy of your seller.

For any further information or to request a full refund of the price of the computer, please contact your seller.

Not all features are available in all editions of Windows. This computer may require upgraded and/or separately purchased hardware, drivers and/or software to take full advantage of Windows functionality. Go to http://www.microsoft.com for details.

Table of contents

1 Computer features 1

Front 1

Rear 2

Left 4

Labels 5

Product specifications 6

2 Illustrated parts catalog 7

Computer major components 7

Miscellaneous parts 11

3 Routine care, drive guidelines, and disassembly preparation 15

Electrostatic discharge information 15

Generating static electricity 15

Preventing electrostatic damage to equipment 16

Personal grounding methods and equipment 16

Grounding the work area 17

Recommended materials and equipment 17

Operating guidelines 18

Routine care 18

General cleaning safety precautions 18

Removing dirt and debris from your computer 19

Cleaning your computer with a disinfectant 19

Cleaning the computer case 20

Cleaning the keyboard 20

Cleaning the monitor 21

Cleaning the mouse 21

Service considerations 21

Tools and software requirements 21

Screws 22

Cables and connectors 22

Hard drives 22

Lithium coin cell battery 23

SATA hard drives 23

Cable management 23

4 Removal and replacement procedures 25

Preparation for disassembly 25

Identifying computer components 25

Feet 26

Access panel 27
Top cover 28
Rack rail installation 29
Access panel card retainer 30
Solid-state drive 31
Battery 34
Memory cooler 36
Memory modules (DIMMs) 37
Expansion card 40
5.25-inch drive holder 44
Hard drive 44
Optical drive 46
Rear fan 48
Lower front card guide and fan 49
Upper front card guide and fan 50
Front I/O assembly 52
Network card 53
Flex I/O board 54
Front bezel 55
Interlock assembly 56
Panel latch 58
Heat sink 59
Power supply 60
Processor 62
System board 64
5 Troubleshooting without diagnostics 67
Before you call for technical support 67
Helpful hints 68
Solving general problems 68
Cannot access the Computer Setup (F10) Utility when booting the computer 68
Computer appears locked up and will not turn off when the power button is pressed 69
Computer will not respond to keyboard or mouse 69
Computer date and time display is incorrect 69
There is no sound or sound volume is too low 69
Poor performance 70
Solving power problems 70
Computer will not turn on 70
Three red blinks then seven white blinks 70
Solving hard drive problems 71

Hard drive error occurs 71
Disk drive transaction problem 71
Drive not found (identified) 71
Nonsystem disk/NTLDR missing message 71
Computer will not boot from hard drive 72
Computer seems to be locked up 72
Solving audio problems 72
Sound cuts in and out 72
Sound does not come out of the speaker or headphones 73
Computer appears to be locked up while recording audio 73
Line-in jack is not functioning properly 73
Solving printer problems 73
Printer will not print 74
Printer will not turn on 74
Printer prints garbled information 74
Solving keyboard and mouse problems 74
Keyboard commands and typing are not recognized by the computer 74
Mouse does not respond to movement or is too slow 75
Solving hardware installation problems 75
A new device is not recognized as part of the system 76
Computer will not start 76
Solving network problems 76
Network driver does not detect network controller 76
Network status link light never blinks 77
Diagnostics reports a failure 77
Diagnostics passes, but the computer does not communicate with the network 78
Network controller stopped working when an expansion board was added to the computer 78
Network controller stops working without apparent cause 78
Cannot connect to network server when attempting remote system installation 78
Solving memory problems 78
System will not boot or does not function properly after installing additional memory modules 79
Out of memory error 79
Memory count during POST is wrong 79
Insufficient memory error during operation. 79
Solving USB flash drive problems 79
USB flash drive is not seen as a drive letter in Windows 80
USB flash drive not found (identified) 80
System will not boot from USB flash drive 80
Solving internet access problems 80
Unable to connect to the internet 80
Cannot automatically launch internet programs 81
Solving software problems 81
Computer will not start up and the HP logo does not appear 81
“Illegal Operation has Occurred” error message is displayed 81
6 Computer Setup (F10) Utility 82

Using Computer Setup (F10) Utilities 82
Computer Setup Main 83
Computer Setup Security 87
Computer Setup Advanced 92
7 POST error messages 102
POST numeric codes and text messages 102
Interpreting POST diagnostic front panel lights and audible codes 109
8 Password security and resetting CMOS 111
Changing a setup or power-on password 111
Deleting a setup or power-on password 111
9 Backing up, restoring, and recovering 113
Backing up information and creating recovery media 113
Using Windows tools for backing up 113
Using the HP Cloud Recovery Download Tool to create a recovery USB flash drive (select products only) 113
Restoring and recovering your system 114
Creating a system restore 114
Restoring and recovery methods 114
Recovering using the HP Recovery USB flash drive 114
Changing the computer boot order 115
Using HP Sure Recover (select products only) 115
10 Using HP PC Hardware Diagnostics 116
Using HP PC Hardware Diagnostics Windows (select products only) 116
Using an HP PC Hardware Diagnostics Windows hardware failure ID code 116
Accessing HP PC Hardware Diagnostics Windows 116
Accessing HP PC Hardware Diagnostics Windows from HP Support Assistant (select products only) 116
Accessing HP PC Hardware Diagnostics Windows from the Start menu (select products only) 117
Downloading HP PC Hardware Diagnostics Windows 117
Downloading the latest HP PC Hardware Diagnostics Windows version from HP 117
Downloading the HP PC Hardware Diagnostics Windows from the Microsoft Store 117
Downloading HP Hardware Diagnostics Windows by product name or number (select products only) 117
Installing HP PC Hardware Diagnostics Windows 118
Using HP PC Hardware Diagnostics UEFI 118
Using an HP PC Hardware Diagnostics UEFI hardware failure ID code 118
Starting HP PC Hardware Diagnostics UEFI 118
Starting HP PC Hardware Diagnostics UEFI through HP Hotkey Support software (select products only) 119
Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive 119
Downloading the latest HP PC Hardware Diagnostics UEFI version 119
Downloading HP PC Hardware Diagnostics UEFI by product name or number (select products only) 120
Using Remote HP PC Hardware Diagnostics UEFI settings (select products only) 120
Downloading Remote HP PC Hardware Diagnostics UEFI 120
Downloading the latest Remote HP PC Hardware Diagnostics UEFI version 120
Downloading Remote HP PC Hardware Diagnostics UEFI by product name or number 120
Customizing Remote HP PC Hardware Diagnostics UEFI settings 121

11 Statement of memory volatility 122
Current BIOS steps 122
Nonvolatile memory usage 124
Questions and answers 125
Using HP Sure Start (select products only) 126
12 Power cord set requirements 127
General requirements 127
Japanese power cord requirements 127
Country-specific requirements 127
13 Specifications 129
14 Linux technical notes 131
Audio 131
NVIDIA graphics workstations 131
AMD graphics workstations 132
Index 133

1 Computer features

This chapter provides you with an overview of your computer's features.

IMPORTANT: Your keyboard might include a Copilot key. Copilot in Windows® requires Windows 11. Some features require a neural processing unit. The timing of feature delivery and availability varies by market and device. You must have a Microsoft account to use the Copilot feature. Where the Copilot feature is not available, pressing the Copilot key opens the Bing search engine. See http://aka.ms/WindowsAIFeatures.

Front

Use this illustration and table to identify the front panel components.

NOTE: Your computer model might look slightly different from the illustration in this section.




Table 1-1 Front components and their descriptions

Item	Icon	Component	Item	Icon	Component
1		Power button	5		USB 5 Gbps port Connects a USB device, provides high-speed data transfer, and (for select products) charges small devices (such as a smartphone) when the computer is on or in sleep mode. **NOTE:** Use a standard USB Type-A charging cable or cable adapter (purchased separately) when charging a small external device.

Table 1-1 Front components and their descriptions (continued)

Item	Icon	Component	Item	Icon	Component
2		Drive light	6		USB Type-C® 20 Gbps ports with HP Sleep and Charge (2) Connect a USB device, provide high-speed data transfer, and charge small devices (such as a smartphone), even when the computer is off. **NOTE:** Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device. **NOTE:** These ports are USB Type-A ports on select models.
3		CTIA only jack Connects optional powered stereo speakers, headphones, earbuds, a headset, or a television audio cable. Also connects an optional headset microphone. This jack does not support optional standalone microphones.	7		SD card reader (select products only) Reads optional memory cards that store, manage, share, or access information.
4		USB 5 Gbps port with HP Sleep and Charge Connects a USB device, provides high-speed data transfer, and charges small devices (such as a smartphone), even when the computer is off. **NOTE:** Use a standard USB Type-A charging cable or cable adapter (purchased separately) when charging a small external device.			

NOTE: Your model might have additional components available from HP.

NOTE: The light on the power button is normally white when the power is on. If the light blinks red, the computer displays a diagnostic code to indicate a problem. See the Interpreting POST diagnostic front panel lights and audible codes on page 109 to interpret the code.

Rear

Use this illustration and table to identify the rear panel components.

NOTE: Your computer model might look slightly different from the illustrations in this section.




Table 1-2 Rear components and their descriptions

Item	Icon	Component	Item	Icon	Component
1		Rear handle pocket	8		Accessory security cable loop
2		Power connector Connects an AC adapter.	9		Remote interface (select products only)
3		Expansion slots	10		Network port (select products only)
4		Power button	11		Audio-out (headphone)/Audio-in (microphone) combo jack Universal Audio Jack supports OMTP and CTIA plus line-in, mic-in, line-out, etc.
5		Status LED	12		HP flex I/O port (select products only)
6		RJ-45 (network) jack Connects a network cable.	13	5Gbps	USB 5 Gbps ports (5) Connect a USB device, provide high-speed data transfer, and (for select products) charge small devices (such as a smartphone) when the computer is on or in sleep mode. **NOTE:** Use a standard USB Type-A charging cable or cable adapter (purchased separately) when charging a small external device.

Table 1-2 Rear components and their descriptions (continued)

Item	Icon	Component	Item	Icon	Component
7	10Gbps	USB Type-C 10 Gbps port Connects a USB device, provides data transfer, and (for select products) charges small devices (such as a smartphone) when the computer is on or in sleep mode. **NOTE:** Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device.	14		Security cable slot

NOTE: The labels for the rear panel connectors use industry-standard icons and colors.

NOTE: Your model might have additional components available from HP.

Left

Use this illustration and table to identify the left panel component.

NOTE: Your computer model might look slightly different from the illustration in this section.

NOTE: Your computer will not turn on if the optional Safety Interlock is installed and the left cover is open or removed.




Table 1-3 Left component and its description

Component	Description
Vent	Enables airflow to cool internal components. **NOTE:** The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.

Labels

The labels affixed to the computer provide information you might need when you troubleshoot system problems or travel internationally with the computer. Labels might be in paper form or imprinted on the product.

NOTE: Check the following locations for the labels described in this section: the bottom and top of the computer, the rear and side panels of the computer, or under the service door.

- Service label—Provides important information to identify your computer. When contacting support, you might be asked for the serial number, the product number, or the model number. Locate this information before you contact support.

  Your service label will resemble one of the examples shown below. Refer to the illustration that most closely matches the service label on your computer.





- 

  Takes you to serial-number-specific information to assist with setting up and using the product as well as provides you with access to support information.

- Regulatory labels—Provide regulatory information about the computer.
- Wireless certification labels—Provide information about optional wireless devices and the approval markings for the countries or regions in which the devices have been approved for use.

Product specifications

Read this section to learn where to find the technical specifications about your computer.

To find the QuickSpecs for your product, go to http://www.hp.com/go/quickspecs, and then select the **Search all QuickSpecs** link. Type your model name in the search box, and then select **Go**.

You can also go to http://www.hp.com/support, and follow the instructions to find your product. Select **Product Information**, and then select your computer specifications.

2 Illustrated parts catalog

Use this information to determine the spare parts that are available for the computer.

NOTE: HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to https://partsurfer.hp.com/, select your country or region, and then follow the on-screen instructions.

Computer major components

To identify the computer major components, use this illustration and table.




Table 2-1 Computer major components and their descriptions

Item	Description	CSR category*	Spare part numbers
(1)	**Access panel**	A	P79667-001
	Extended side panel	A	P77863-001
(2)	**Graphics cards** (appearance varies)		
	NVIDIA® RTX™ PRO 6000, WS, Ed	C	P20285-002
	NVIDIA RTX PRO 6000 MaxQ	C	P20286-002

Table 2-1 Computer major components and their descriptions (continued)

Item	Description	CSR category*	Spare part numbers
	NVIDIA RTX PRO 5000	C	P20287-001
	NVIDIA RTX PRO 4500	C	P20288-002
	NVIDIA RTX PRO 4000	C	P20289-001
	NVIDIA RTX PRO 2000	C	P37340-001
	NVIDIA RTX™ 5080	C	P29237-001
	NVIDIA RTX 5070	C	P31915-002
	NVIDIA RTX 5060	C	P47615-001
	NVIDIA RTX A800	C	N55304-001
	NVIDIA RTX A1000	C	N91236-003
	NVIDIA RTX A400	C	N91237-003
	Expansion cards	C	
	HP Z Turbo Drive Quad Pro	C	N86446-001
	HP Dual Thunderbolt™ 5	C	N99677-002
	Ethernet network adapter AT-2911T 2	C	N19988-002
	Fiber NIC AT-2914SX/LC-901	C	L49966-001
	BCM5720-2P 1 GbE RJ-45 NIC, PCIe	C	N99038-001
	Intel® Ethernet Network Adapter I226-T1	C	P64467-001
	Intel E810-CQDA2 100 Gb Dual-Port PCI Express 4.0 x16	C	P87041-005
	NVIDIA Mellanox ConnectX-6 LX Smart NIC	C	M52493-001
(3)	**Memory cooler**	A	P77867-001
(4)	**Rear fan**	A	P78936-001
(5)	**Power supply**		
	1350 W	B	P19535-002
	775 W	B	P19534-001
(6)	**Side panel latch**	B	P79676-001
	Barrel lock	B	P77868-001
(7)	**Hard drive** (3.5 in)		
	12 TB	A	N04492-001
	8 TB (not made in China [NMIC])	A	P55244-001
	4 TB	A	L53021-001
(8)	**Hard drive holder**	A	L10316-001
(9)	**Front I/O assembly**		
	Premium	A	P17776-001
	Entry	A	P17777-001

Table 2-1 Computer major components and their descriptions (continued)

Item	Description	CSR category*	Spare part numbers
(10)	**Optical drive**		
	DVD writer	A	L66553-001
	DVD-ROM	A	L36404-001
	BD writer	A	781417-001
(11)	**Drive carrier**	A	L38179-001
(12)	**Access panel card retainer**	A	P79668-001
(13)	**Heat sink** (premium)	C	P50178-001
	Heat sink (standard)		P29118-001
(14)	**Processor**		
	Intel® Xeon® 678X	C	P83905-003
	Intel Xeon 676X	C	P83907-003
	Intel Xeon 674X	C	P83906-003
	Intel Xeon 658X	C	P83908-003
	Intel Xeon 656	C	P83913-003
	Intel Xeon 654	C	P83912-003
	Intel Xeon 638	C	P83911-003
	Intel Xeon 636	C	P83910-003
	Intel Xeon 634	C	P83909-003
(15)	**System board**	C	P10838-601
(16)	**Memory modules** (DDR5-6400, ECC)		
	64 GB (NMIC)	A	P75309-001
	64 GB (non-Micron [nM])	A	P44984-001
	32 GB (NMIC)	A	P75308-001
	32 GB (nM)	A	P44983-001
	16 GB (NMIC)	A	P54883-001
	16 GB (nM)	A	P44982-001
(17)	**System board latch**	B	P79675-001
(18)	**Expansion card release latch**	B	P79677-001
(19)	**Solid-state drive (SSD)**		
	8 TB, PCIe-4 × 4 (NMIC)	A	P59454-001
	4 TB, PCIe-4 × 4, triple-level cell (TLC)	A	N06219-001
	4 TB, PCIe-4 × 4, TLC (NMIC)	A	P41681-001
	4 TB, PCIe-4 × 4, self-encrypted drive (SED), TLC (NMIC)	A	P52614-001
	4 TB, PCIe-5 × 4, TLC	A	P78536-001

Table 2-1 Computer major components and their descriptions (continued)

Item	Description	CSR category*	Spare part numbers
	2 TB, PCIe-4 × 4, TLC (nM)	A	N77396-001
	2 TB, PCIe-3 × 4, SED, FIPS, TLC, 3 × 4	A	P31844-001
	2 TB, PCIe-3 × 4, SED, TLC, 3 × 4, Citadel	A	P31847-001
	2 TB, PCIe-4× 4, SED, TLC	A	N23414-001
	2 TB, PCIe-5 × 4	A	P33282-001
	2 TB, PCIe-5 × 4, SED	A	P33283-001
	1 TB, PCIe-3 × 4, SED, FIPS, TLC	A	P31843-001
	1 TB, PCIe-3 × 4, SED, TLC, Citadel	A	P31846-001
	1 TB, PCIe-4 × 4, TLC (nM)	A	N77395-001
	1 TB, PCIe-4 × 4, SED, TLC (nM)	A	N86919-001
	1 TB, PCIe-5 × 4, SED	A	P33281-001
	1 TB, PCIe-5 × 4	A	P50452-001
	1 TB, PCIe-5 × 4, ZTurbo	A	Q03190-001
	512 GB, PCIe-3 × 4, SED, FIPS, TLC	A	P20782-001
	512 GB, PCIe-3 × 4, SED, TLC, Citadel	A	P31845-001
	512 GB, PCIe-4 × 4, TLC (nM)	A	N77393-001
	512 GB, PCIe-4 × 4, SED, TLC (nM)	A	N86921-001
(20)	**M.2 SSD clip**	A	P78946-001
(21)	**Lower front card guide and fan**	A	P77864-001
	Lower front card guide extra long graphics (not illustrated)	A	P77866-001
(22)	**Upper front card guide and fan**	A	P77864-001
(23)	**Interlock switch**	A	P78929-001
(24)	**Front bezel**	A	P79678-001
*	**WLAN module**		
*	MediaTek MT7925 Wi-Fi® 7 + Bluetooth® 5.4	A	N64647-001
*	Intel WNC with Bluetooth	A	803598-001
*	**WLAN antenna** (includes left and right wireless antenna cables and transceivers)	B	P79064-001
*	**Feet**	A	P78926-001

*not illustrated

Table 2-2 CSR part categories*

Category	Description	Replacement responsibility
CSR A	Self-service parts	Customers can replace these easily replaceable parts. Replacement by trained technicians might incur additional cost.

Table 2-2 CSR part categories* (continued)

Category	Description	Replacement responsibility
CSR B/C	Optional self-service parts	Skilled customers can replace these parts. Warranty replacement available via trained technicians.
CSR N	Non-self-service parts	Only trained service technicians should replace these complex parts.

Miscellaneous parts

To identify the various computer parts, use this table.

Table 2-3 Miscellaneous parts and their descriptions

Miscellaneous parts	Spare part number
HP Z Remote System Controller	N12744-001
HP Z Remote System Controller bulkhead	N45389-001
Carrier, 3.5-in hard drive in optical drive bay	683870-001
Carrier, hard drive	L10316-001
Carrier, slim optical drive in half-height optical drive bay	L38179-001
Real-time clock (RTC) battery cover	P78945-001
Front NVMe dual PCIe storage	P16055-001
Extended side panel fan	P78948-001
Card guide duct	P78728-001
Brackets	
A2000 mid extender bracket (R/L)	N22955-001
GeForce RTX 5090 graphics card extender	P50488-001
RTX 3080 graphics card extender	N45107-001
RTX Pro 6000 graphics card extender	P50489-001
Metal serial port bracket	P77858-001
Control VROC SSD module (premium)	L23096-001
Control VROC SSD module (standard)	L23097-001
Adapters	
Ethernet network adapter	N19988-001
HP DisplayPort™-to-HDMI 2.0 adapter	940274-002
HP Mini-DisplayPort-to-VGA adapter	708463-001
Cables	
DisplayPort-to-mini-DisplayPort (30 cm [11.8 in])	N45392-001
DisplayPort-to-mini-DisplayPort	N45399-001
Internal USB 12-pin, male-to-male	N45407-001
Interlock jumper cable	P84270-001

Table 2-3 Miscellaneous parts and their descriptions (continued)

Miscellaneous parts	Spare part number
CAT5e Ethernet cable (1.0 m)	N45394-001
SATA cable, 50 cm (19.5 in), straight, right angle	N35663-001
SATA cable, 45.7 cm (18.0 in), right angle, right angle	687225-001
16p-to-dual 8p adapter, 50 mm	P27735-001
Graphics power cable, 8 pin-to-dual 6 + 2 pin	N22636-002
Graphics power cable, CPU 8 pin-to-straight 16 pin, 300 W	P78726-001
Bluetooth USB 10-6 cable	P99584-001
External power/data cable (10-pin, 1.0 m) for the HP Z Remote System Controller (300 mm)	N45396-001
External power/data cable (10-pin, 1.0 m) for the HP Z Remote System Controller (120 mm)	N45406-001
External power/data cable (10 pin, 1.0 m)	N45395-001
USB Type-A, Generation 1 cable (male-to-male, 1.0 m)	N45393-001
NVMe cable kit	P78769-001
Premium front I/O cable	P80523-001
Internal antennas	P79064-001
External WLAN antennas	N07482-001
Internal USB3 port, with clip	N23157-001
Keyboard (country codes are listed following this table)	
HP USB Slim Smart Card Keyboard	P10664-001
HP 125 Wired Keyboard	P10665-001
HP USB Keyboard	P10674-001
HP 725 Wireless Keyboard + Mouse	P33679-001
Mouse	
HP USB mouse	L95713-001
HP USB mouse, PCR	P10675-001
HP 125 Wired Mouse	M27884-001
HP 125 Wired Mouse, PCR	P10666-001
HP 128 Laser Wired Mouse	M27885-001
HP 128 Laser Wired Mouse, PCR	P10669-001
Power cord (C13, 1.83 m, conventional with sticker)	
For use in Argentina	M82819-001
For use in Australia	M82822-001
For use in the Brazil	M82820-001
For use in Denmark	M82829-001
For use in Denmark (halogen free)	P23965-001

Table 2-3 Miscellaneous parts and their descriptions (continued)

Miscellaneous parts	Spare part number
For use in Europe	M82827-001
For use in Europe (halogen free)	P23967-001
For use in Israel	M82830-001
For use in Israel (halogen free)	P23969-001
For use in Italy	M82831-001
For use in North America	N39601-001
For use in the People's Republic of China (PRC)	M82823-001
For use in South Africa	M82832-001
For use in Switzerland	M82833-001
For use in Switzerland (halogen free)	P23966-001
For use in Taiwan	M82826-001
For use in the United Kingdom	M82834-001
For use in the United Kingdom (halogen free)	P23968-001
Power cord (C13, 1.83 m [6.0 ft], FLG, CWP, BL)	P10529-001
Power cord (C13, 1.83 m [6.0 ft], red, conventional)	P79414-001
Power cord (C13, 2.0 m, 12 A)	
Japan	N49834-001
Power cord (C13, 2.5 m, 10 A)	
India	N73274-001
Power cord (0.1 m, conventional, right angle)	
Japan	N62714-001
Power cord (C13 - C14, 2.0 m, 10 A, 200 - 240 V)	N69182-001
Power cord (C13 - C14, 2.0 m, 15 A, 100 - 127 V)	N69183-001

Table 2-4 Spare part country codes

For use in country or region	Spare part number	For use in country or region	Spare part number	For use in country or region	Spare part number
Belgium	-181	Hungary	-211	Russia	-251
BHCSY (Bosnia/ Herzegovina/Croatia/ Slovenia/Yugoslavia)	-B41	India	-D61	Saudi Arabia	-171
Brazil	-201	International	-L31	South Korea	-KD1
Bulgaria	-261	Israel	-BB1	Spain	-071
Chile	-161	Italy	-061	Sweden	-101
Czech/Slovakia	-CG1	Japan	-291	Switzerland	-111

Table 2-4 Spare part country codes (continued)

For use in country or region	Spare part number	For use in country or region	Spare part number	For use in country or region	Spare part number
Denmark	-081	Kazakhstan	-DF1	Taiwan	-AB1
France	-051	Netherlands	-DX1	Thailand	-281
French Arabic	-DE1	Norway	-091	Turkey	-141
French Canada	-121	PRC	-AA1	Ukraine	-BD1
Germany	-041	Portugal	-131	United Kingdom	-031
Greece	-151	Romania	-271	United States	-001

3 Routine care, drive guidelines, and disassembly preparation

This information provides general service information for the computer. Adherence to the procedures and precautions is essential for proper service.

IMPORTANT: When the computer is plugged into an AC power source, DC voltage is always applied to the system board. You must disconnect the power cord(s) from the power source before opening the computer to prevent electric shock, system board, or component damage.

Electrostatic discharge information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs.

An electronic device exposed to electrostatic discharge (ESD) might not appear to be affected at all and can work perfectly throughout a normal cycle. The device might function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

IMPORTANT: To prevent damage to the device when you are removing or installing internal components, observe these precautions:

- Keep components in their electrostatic-safe containers until you are ready to install them.
- Before touching an electronic component, discharge static electricity by using the guidelines described in this section.
- Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.
- If you remove a component, place it in an electrostatic-safe container.

Generating static electricity

This table shows how humidity affects the electrostatic voltage levels generated by different activities. A product can be degraded by 700 V of static electricity.

- Different activities generate different amounts of static electricity.
- Static electricity increases as humidity decreases.

Multiple electronic components can be packaged in plastic tubes, trays, or polystyrene foam.

Table 3-1 Static electricity occurrence based on activity and humidity

	Relative humidity 55%	Relative humidity 40%	Relative humidity 10%
Event			

Table 3-1 Static electricity occurrence based on activity and humidity (continued)

	Relative humidity 55%	Relative humidity 40%	Relative humidity 10%
Walking across carpet	7500 V	15,000 V	35,000 V
Walking across vinyl floor	3000 V	5000 V	12,000 V
Motions of bench worker	400 V	800 V	6000 V
Removing DIPs (dual in-line packages) from plastic tube	400 V	700 V	2000 V
Removing DIPs from vinyl tray	2000 V	4000 V	11,500 V
Removing DIPs from polystyrene foam	3500 V	5000 V	14,500 V
Removing bubble pack from PCB (printed circuit board)	7000 V	20,000 V	26,500 V
Packing PCBs in foam-lined box	5000 V	11,000 V	21,000 V

Preventing electrostatic damage to equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent static electricity damage to electronic components.

- To avoid hand contact, transport products in static-safe containers such as tubes, bags, or boxes.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their container.
- Always be properly grounded when touching a sensitive component or assembly.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

Personal grounding methods and equipment

Use this equipment to prevent static electricity damage to electronic components.

- **Wrist straps** are flexible straps with a maximum of 1 MΩ ±10% resistance in the ground cords. To provide proper ground, wear a strap snug against bare skin. Verify that the ground cord is connected and fits snugly into the banana plug connector on the grounding mat or workstation.
- **Heel straps/Toe straps/Boot straps** can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of 1 MΩ ±10% resistance between the operator and ground.

Table 3-2 Static shielding protection levels

Static shielding protection levels	
Method	**Voltage**

Table 3-2 Static shielding protection levels (continued)

Static shielding protection levels	
Antistatic plastic	1500 V
Carbon-loaded plastic	7500 V
Metalized laminate	15,000 V

Grounding the work area

To prevent static damage at the work area, use these precautions.

- Cover the work surface with approved static-dissipative material. Provide a wrist strap connected to the work surface and properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.
- Keep work area free of nonconductive materials such as ordinary plastic assembly aids and polystyrene foam.
- Use field service tools, such as cutters, screwdrivers, and vacuums, that are conductive.

Recommended materials and equipment

HP recommends these materials and equipment to prevent static electricity.

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of 1 MΩ ±10% resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing 1 MΩ ±10% resistance
- Material handling packages
- Conductive plastic bags
- Conductive plastic tubes
- Conductive tote boxes

- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

Operating guidelines

This information details how to prevent overheating and help prolong the life of the computer.

- Keep the computer away from excessive moisture, direct sunlight, and extremes of heat and cold.
- Operate the computer on a sturdy, level surface. Leave a 10.2 cm (4 inch) clearance on all vented sides of the computer and above the monitor to permit the required airflow.
- Do not restrict the airflow into the computer by blocking any vents or air intakes. Do not place the keyboard, with the keyboard feet down, directly against the front of the desktop unit as this also restricts airflow.
- Occasionally clean the air vents on all vented sides of the computer. Lint, dust, and other foreign matter can block the vents and limit the airflow. Be sure to unplug the computer before cleaning the air vents.
- Do not operate the computer with the cover or side panel removed.
- Do not stack computers on top of each other or place computers so near each other that they are subject to each other's recirculated or preheated air.
- If the computer is to be operated within a separate enclosure, intake and exhaust ventilation must be provided on the enclosure, and the same operating guidelines listed previously still apply.
- Keep liquids away from the computer and keyboard.
- Do not cover the ventilation slots on the monitor with any type of material.
- Install or enable power management functions of the operating system or other software, including sleep states.

Routine care

Use this information to properly care for your computer.

General cleaning safety precautions

Use this information to safely clean your computer.

⚠ **CAUTION:** To prevent electric shock or damage to components, never clean a product while it is turned on or plugged in.

- Never use solvents or flammable solutions to clean the computer.
- Never immerse any parts in water or cleaning solutions; apply any liquids to a clean cloth and then use the cloth on the component.
- Always unplug the computer when cleaning with liquids or damp cloths.
- Always unplug the computer before cleaning the keyboard, mouse, or air vents.

- Disconnect the keyboard before cleaning it.
- Wear safety glasses equipped with side shields when cleaning the keyboard.

Removing dirt and debris from your computer

Here are the recommended steps to clean dirt and debris from your computer.

1. Wear disposable gloves made of latex (or nitrile gloves, if you are latex-sensitive) when cleaning the surfaces.
2. Turn off your device and unplug the power cord and other connected external devices. Remove any installed batteries from items such as wireless keyboards.

CAUTION: To prevent electric shock or damage to components, never clean a product while it is turned on or plugged in.

3. Moisten a microfiber cloth with water. The cloth should be moist, but not dripping wet.

IMPORTANT: To avoid damaging the surface, avoid abrasive cloths, towels, and paper towels.

4. Wipe the exterior of the product gently with the moistened cloth.

IMPORTANT: Keep liquids away from the product. Avoid getting moisture in any openings. If liquid makes its way inside your HP product, it can cause damage to the product. Do not spray liquids directly on the product. Do not use aerosol sprays, solvents, abrasives, or cleaners containing hydrogen peroxide or bleach that might damage the finish.

5. Start with the display (if applicable). Wipe carefully in one direction, and move from the top of the display to the bottom. Finish with any flexible cables, like power cord, keyboard cable, and USB cables.
6. Be sure that surfaces have completely air-dried before turning the device on after cleaning.
7. Discard the gloves after each cleaning. Clean your hands immediately after you remove the gloves.

See Cleaning your computer with a disinfectant on page 19 for recommended steps to clean the high-touch, external surfaces on your computer to help prevent the spread of harmful bacteria and viruses.

Cleaning your computer with a disinfectant

The World Health Organization (WHO) recommends cleaning surfaces, followed by disinfection, as a best practice for preventing the spread of viral respiratory illnesses and harmful bacteria.

After cleaning the external surfaces of your computer using the steps in Removing dirt and debris from your computer on page 19, you might also choose to clean the surfaces with a disinfectant. A disinfectant that is within HP's cleaning guidelines is an alcohol solution consisting of 70% isopropyl alcohol and 30% water. This solution is also known as rubbing alcohol and is sold in most stores.

Follow these steps when disinfecting high-touch, external surfaces on your computer:

1. Wear disposable gloves made of latex (or nitrile gloves, if you are latex-sensitive) when cleaning the surfaces.

2. Turn off your device and unplug the power cord and other connected external devices. Remove any installed batteries from items such as wireless keyboards.

CAUTION: To prevent electric shock or damage to components, never clean a product while it is turned on or plugged in.

3. Moisten a microfiber cloth with a mixture of 70% isopropyl alcohol and 30% water. The cloth should be moist, but not dripping wet.

CAUTION: Do not use any of the following chemicals or any solutions that contain them, including spray-based surface cleaners: bleach, peroxides (including hydrogen peroxide), acetone, ammonia, ethyl alcohol, methylene chloride, or any petroleum-based materials, such as gasoline, paint thinner, benzene, or toluene.

IMPORTANT: To avoid damaging the surface, avoid abrasive cloths, towels, and paper towels.

4. Wipe the exterior of the product gently with the moistened cloth.

IMPORTANT: Keep liquids away from the product. Avoid getting moisture in any openings. If liquid makes its way inside your HP product, it can cause damage to the product. Do not spray liquids directly on the product. Do not use aerosol sprays, solvents, abrasives, or cleaners containing hydrogen peroxide or bleach that might damage the finish.

5. Start with the display (if applicable). Wipe carefully in one direction, and move from the top of the display to the bottom. Finish with any flexible cables, like power cord, keyboard cable, and USB cables.

6. Be sure that surfaces have completely air-dried before turning the device on after cleaning.

7. Discard the gloves after each cleaning. Clean your hands immediately after you remove the gloves.

Cleaning the computer case

Follow all safety precautions before cleaning the computer case.

To clean the computer case, follow these procedures:

NOTE: You can also use these procedures to clean the tops of the keys, keyboard body, monitor body, or mouse body.

- To remove light stains or dirt, use plain water with a clean, lint-free cloth or swab.
- For stronger stains, use a mild dishwashing liquid diluted with water. Rinse well by wiping it with a cloth or swab dampened with clear water.
- For stubborn stains, use isopropyl (rubbing) alcohol. No rinsing is needed because the alcohol evaporates quickly and does not leave a residue.
- After cleaning, always wipe the unit with a clean, lint-free cloth.
- Occasionally clean the air vents on the computer. Lint and other foreign matter can block the vents and limit the airflow.

Cleaning the keyboard

Use this information to properly clean the keyboard. Follow all safety precautions before cleaning the keyboard.

To clean the tops of the keys or the keyboard body, follow the procedures described in Cleaning the computer case on page 20.

When cleaning debris from under the keys, review all rules in General cleaning safety precautions on page 18 before following these procedures.

CAUTION: Use safety glasses equipped with side shields before attempting to clean debris from under the keys.

- You can remove visible debris underneath or between the keys by vacuuming or shaking.
- You can use canned, pressurized air to clean debris from under the keys. Use caution because too much air pressure can dislodge lubricants applied under the wide keys.
- If you remove a key, use a specially designed key puller to prevent damage to the keys. This tool is available through many electronic supply outlets.

IMPORTANT: Never remove a wide leveled key (like the space bar) from the keyboard. If these keys are improperly removed or installed, the keyboard might not function properly.

- You can clean under a key with a swab moistened with isopropyl alcohol and squeezed out. Be careful not to wipe away lubricants necessary for proper key functions. Use tweezers to remove any fibers or dirt in confined areas. Allow the parts to air dry before reassembly.

Cleaning the monitor

Follow all safety precautions before cleaning dirt and debris from your computer. Use this information to properly clean the monitor.

- Wipe the monitor screen with a clean cloth moistened with water or with a towelette designed for cleaning monitors. Do not use sprays or aerosols directly on the screen; the liquid can seep into the housing and damage a component. Never use solvents or flammable liquids on the monitor.
- To clean the monitor body, follow the procedures in Cleaning the computer case on page 20.

Cleaning the mouse

Follow all safety precautions before cleaning your mouse. Use this information to properly clean the mouse.

To clean the mouse body, follow the procedures in Cleaning the computer case on page 20.

Service considerations

Keep these considerations in mind during the disassembly and assembly of the computer.

Tools and software requirements

Servicing the computer requires these tools.

- Torx T-15 screwdriver
- Torx T-30 screwdriver
- Flat-bladed screwdriver (can sometimes be used in place of the Torx screwdriver)
- Phillips P1 screwdriver

- Needle nose pliers
- Nonconductive, nonmarking pry tool
- Diagnostics software

Screws

The screws used in the computer are not interchangeable. They could have standard or metric threads and might be of different lengths.

If you use an incorrect screw during the reassembly process, it can damage the unit. HP strongly recommends that you keep all screws that you remove during disassembly with the removed part and then return them to their proper locations.

IMPORTANT: As you remove each subassembly from the computer, place it away from the work area to prevent damage.

Cables and connectors

Use this information to properly handle cables.

Apply only the tension required to seat or unseat the cables during insertion or removal from the connector. Handle cables by the connector whenever possible. In all cases, avoid bending or twisting the cables, and route the cables so that they cannot be caught or snagged by parts being removed or replaced.

Graphics cards adapter cables

To prevent electrical issues, only use high-quality, HP certified 12VHPWR adapter cables. Be sure to fully insert the 12VHPWR connector into a graphics card until it clicks into place. A loose connection can cause overheating and could be a potential fire hazard. Do not sharply bend the cable near the connector. Maintain at least a 35 mm bending radius to prevent strain on the connection. Check for discoloration, burnt smell, or signs of damage before and after use. If you find any abnormalities, immediately stop using the cable.

IMPORTANT: When servicing this computer, be sure to place cables in their proper location during the reassembly process. Improper cable placement can damage the computer.

Hard drives

Handle hard drives as delicate, precision components, and avoid all physical shock and vibration. This advice applies to failed drives as well as replacement spares.

- If a drive must be mailed, place the drive in a bubble-pack mailer or other suitable protective packaging and label the package “Fragile: Handle With Care.”
- Do not remove hard drives from the shipping package for storage. Keep hard drives in their protective packaging until they are actually mounted in the computer.
- Avoid dropping drives from any height onto any surface.
- If you are inserting or removing a hard drive, turn off the computer. Do not remove a hard drive while the computer is on or in standby mode.
- Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector.
- Do not use excessive force when inserting a drive.

- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

Lithium coin cell battery

The battery that comes with the computer provides power to the real-time clock and has a minimum lifetime of approximately three years.

See the removal and replacement chapter for replacement instructions.

⚠ **WARNING!** This computer contains a lithium battery. There is a risk of fire and chemical burn if the battery is handled improperly. Do not disassemble, crush, puncture, short external contacts, dispose of in water or fire, or expose it to temperatures higher than 140°F (60°C). Do not attempt to recharge the battery.

NOTE: Do not dispose of batteries, battery packs, and accumulators with general household waste. To forward them to recycling centers for proper disposal, use the public collection system or return them to HP, their authorized partners, or their agents.

SATA hard drives

The Self Monitoring Analysis and Recording Technology (SMART) ATA drives for the HP Personal Computers have built-in drive failure prediction that warns the user or network administrator of an impending failure or crash of the hard drive.

The SMART drive tracks fault prediction and failure indication parameters such as reallocated sector count, spin retry count, and calibration retry count. If the drive determines that a failure is imminent, it generates a fault alert.

Table 3-3 SATA hard drive characteristics

Serial ATA hard drive characteristics	
Number of pins/conductors in data cable	7/7
Number of pins in power cable	15
Maximum data cable length	100 cm (39.37 in)
Data interface voltage differential	400 mV–700 mV
Drive voltages	3.3 V, 5 V, 12 V
Jumpers for configuring drive	N/A
Data transfer rate	6.0 Gbps

Always use an HP-approved SATA 6.0 Gbps cable because it is fully backwards compatible with the SATA 1.5 Gbps drives. Current HP desktop products ship with SATA 6.0 Gbps hard drives.

SATA data cables are susceptible to damage if overflexed. Never crease a SATA data cable and never bend it tighter than a 30 mm (1.18 in) radius.

The SATA data cable is a thin, seven-pin cable designed to transmit data for only a single drive.

Cable management

Always follow good cable management practices when working inside the computer.

- Take a picture of cable routing before moving cables to make it easier to reinstall the cables in their original positions for optimum airflow.
- Keep cables away from major heat sources like the heat sink.
- Keep cables clear of sliding or moveable parts to prevent them from being cut or crimped when the parts are moved.
- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases can damage the wires.
- Do not bend any cable sharply. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in) radius.
- Never crease a SATA data cable.

4 Removal and replacement procedures

This chapter provides removal and replacement procedures.

NOTE: The HP Support YouTube Channel (in English) has videos that provide step-by-step removal and replacement instructions for many common parts and models.

NOTE: Details about your computer, including model, serial number, product key, and length of warranty, are on the service tag.

NOTE: HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to https://partsurfer.hp.com/, select your country or region, and then follow the on-screen instructions.

IMPORTANT: Adherence to these procedures and precautions is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.

NOTE: Not all features listed in this guide are available on all computers.

Preparation for disassembly

Use this information to properly prepare to disassemble and reassemble the computer.

See Routine care, SATA drive guidelines, and disassembly preparation on page 15 for initial safety procedures.

1. Turn off the computer. If you are unsure whether the computer is off or in hibernation, turn the computer on, and then shut it down through the operating system.

   IMPORTANT: Turn off the computer before disconnecting any cables.

   Regardless of the power state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems, the cooling fan is on even when the computer is in the standby or suspend modes. Always disconnect the power cord(s) before servicing a unit.

2. Disconnect the power from the computer by unplugging the power cord(s) from the computer.
3. Disconnect all external devices from the computer

CAUTION: Beware of sharp edges inside the chassis.

NOTE: During disassembly, label each cable as you remove it, and note its position and routing. Keep all screws with the removed components.

Identifying computer components

Use this illustration and table to identify the computer components.




Table 4-1 Computer components

Item	Description	Item	Description
(1)	Extended side panel fans	**(8)**	Upper front card guide and fan
(2)	Rear fan	**(9)**	Interlock switch
(3)	Network card	**(10)**	Front I/O module
(4)	Power supply	**(11)**	5.25-inch drive bay
(5)	Heat sink	**(12)**	3.5-inch hard drive bay
(6)	System board	**(13)**	Lower front card guide and fan
(7)	M.2 SSDs	**(14)**	Memory cooler

Feet

Use this procedure to remove the feet.

Table 4-2 Feet description and part number

Description	Spare part number
Feet	P78926-001


Before removing the feet, follow this step:

- Prepare the computer for disassembly (see Preparation for disassembly on page 25).

Remove the feet:

1. Remove two screws **(1)** from each foot.

2. Remove the feet **(2)** from the computer.



Reverse the removal procedure to install the feet.

Access panel

Use this procedure to remove the access panel.

Table 4-3 Access panel descriptions and part numbers

Description	Spare part number
Access panel	P79667-001
Access panel, extended side panel	P77863-001

NOTE: Your computer will not turn on if the optional Safety Interlock is installed and the left access panel is open or removed.


Before removing the access panel, follow this step:

- Prepare the computer for disassembly (see Preparation for disassembly on page 25).

Remove the access panel:

1. Position the computer with the left side toward you.
2. Press and release the access panel release button **(1)**.
3. Pull the top edge of the access panel **(2)** out to release it.

4. Remove the access panel **(3)** by lifting it up and away from the computer.



Reverse the removal procedure to install the access panel.

Top cover

Use this procedure to remove the top cover.

Table 4-4 Top cover description and part number


Description	Spare part number
Top cover	P79669-001

Before removing the top cover, follow this step:

- Prepare the computer for disassembly (Preparation for disassembly on page 25).

Remove the top cover:

- Lift the back of the top cover **(1)**, and then pull the cover **(2)** off the computer.



Reverse the removal procedures to install the top cover.

Rack rail installation

Use this procedure to mount rack rails onto the computer.


Before installing rack rails, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the top cover (see Top cover on page 28).

Install the rack rails:

1. Install shoulder screws **(1)** into the three rack rail mounting locations on the top and bottom of the computer.

2. Position rails **(2)** on the computer so that the holes in the rails align with the screws on the computer, and then slide the rails toward the front of the computer until they lock into place.



Reverse the installation procedure to remove the rack rails.

Access panel card retainer

Use this procedure to remove the access panel card retainer.

Table 4-5 Access panel card retainer description and part number

Description	Spare part number
Access panel card retainer	P79668-001


Before removing the access panel card retainer, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).


Remove the access panel card retainer:

1. Position the access panel upside down.
2. Press the tabs **(1)** on the bottom of the card retainer.
3. Lift the retention **(2)** off the access panel.

NOTE: Use the same removal procedure for both card retainers.



4. If necessary, adjust the retainer by moving any of the removable blocks within the retainer. To remove an individual block, press the tab **(1)** at the bottom of the block, and then lift the block **(2)** from the assembly.



Reverse the removal procedure to install the access panel card retainer.

Solid-state drive

Use this procedure to remove the SSD.

Table 4-6 SSD descriptions and part numbers

Description	Spare part number
8 TB, PCIe-4 × 4 (NMIC)	P59454-001

Table 4-6 SSD descriptions and part numbers (continued)


Description	Spare part number
4 TB, PCIe-4 × 4, triple-level cell (TLC)	N06219-001
4 TB, PCIe-4 × 4, TLC (NMIC)	P41681-001
4 TB, PCIe-4 × 4, self-encrypted drive (SED), TLC (NMIC)	P52614-001
4 TB, PCIe-5 × 4, TLC	P78536-001
2 TB, PCIe-4 × 4. TLC (nM)	N77396-001
2 TB, PCIe-3 × 4, SED, FIPS, TLC, 3 × 4	P31844-001
2 TB, PCIe-3 × 4, SED, TLC, 3 × 4, Citadel	P31847-001
2 TB, PCIe-4× 4, SED, TLC	N23414-001
2 TB, PCIe-5 × 4	P33282-001
2 TB, PCIe-5 × 4, SED	P33283-001
1 TB, PCIe-3 × 4, SED, FIPS, TLC	P31843-001
1 TB, PCIe-3 × 4, SED, TLC, Citadel	P31846-001
1 TB, PCIe-4 × 4,TLC (nM)	N77395-001
1 TB, PCIe-4 × 4, SED, TLC (nM)	N86919-001
1 TB, PCIe-5 × 4, SED	P33281-001
1 TB, PCIe-5 × 4	P50452-001
512 GB, PCIe-3 × 4, SED, FIPS, TLC	P20782-001
512 GB, PCIe-3 × 4, SED, TLC, Citadel	P31845-001
512 GB, PCIe-4 × 4, TLC (nM)	N77393-001
512 GB, PCIe-4 × 4, SED, TLC (nM)	N86921-001
1 TB, PCIe-5 × 4, ZTurbo	Q03190-001
SSD heat sink	P50179-001

Before removing the SSD, follow these steps:


1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the SSD:


1. Slide the release latch **(1)** back, and then pull the drive **(2)** out of the socket.



2. If replacing M.2 SSD clip, twist it 90° **(1)**, and then lift it **(2)** out of the slot.



The following illustration shows SSD locations and installation order.



Reverse the removal procedure to install the SSD.

Battery

Use this procedure to replace the battery. The battery that comes with the computer provides power to the real-time clock. When replacing the battery, use a battery equivalent to the battery originally installed in the computer. The computer comes with a 3 V lithium coin cell battery.

⚠ **WARNING!** The computer contains an internal lithium manganese dioxide battery. There is a risk of fire and burns if the battery is not handled properly. To reduce the risk of personal injury:

- Do not attempt to recharge the battery.
- Do not expose to temperatures higher than 60°C (149°F).
- Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.
- Replace the battery only with the HP spare part that is designated for this product.

IMPORTANT: Before replacing the battery, back up the computer CMOS settings. When the battery is removed or replaced, the CMOS settings are cleared.

Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object.

NOTE: You can extend the lifetime of the lithium battery by plugging the computer into an AC outlet. The lithium battery is used only when the computer is not connected to AC power.


HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, go to http://www.hp.com/recycle.

Before removing the battery, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the battery:

1. Squeeze the latch **(1)**, and then lift the cover **(2)** to open it.



2. To release the battery from its holder, squeeze the metal clamp **(1)** that extends above one edge of the battery. When the battery **(2)** pops up, lift it out.



3. With the positive side up, insert the new battery **(1)** onto the battery socket at an angle, and then press the battery **(2)** down until it locks into place. The battery holder automatically secures the battery in the proper position.



4. Rotate the cover **(1)** onto the battery socket, and then press the cover **(2)** down until it locks into place.



Memory cooler

Use this procedure to remove the memory cooler.

Table 4-7 Memory cooler description and part number

Description	Spare part number
Memory cooler	P77867-001


Before removing the memory cooler, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the memory cooler:

1. Squeeze the two blue release latches **(1)** on each end of the cooler.

2. Lift the cooler **(2)** straight up to remove it.



Reverse the removal procedure to install the memory cooler.

IMPORTANT: To avoid damaging the components, when installing a memory cooler, be sure there is sufficient space for the memory cooler and that there are no obstructions between the connector and the receptacle on the system board.

Memory modules (DIMMs)

Use this information and procedure to remove the memory modules.

Table 4-8 Memory module descriptions and part numbers

Description	Spare part number
Memory modules (DDR5-6400, ECC)	
64 GB (NMIC)	P75309-001
64 GB (nM)	P44984-001
32 GB (NMIC)	P75308-001
32 GB (nM)	P44983-001
16 GB (NMIC)	P54883-001
16 GB (nM)	P44982-001

The memory sockets on the system board are populated with at least one preinstalled memory module. To achieve the maximum memory support, you can populate the system board with up to 512 GB of PC5-6400 or PC5-5600 MHz DDR5, registered, ECC DIMMs configured in a high-performing dual-channel mode.

NOTE: The system might not operate properly if you install unsupported memory modules.

There are eight memory sockets on the system board, four memory controllers with one channel per memory controller for a total of four channels and two sockets per channel.

For maximum memory performance, evenly distribute total desired memory capacity across all operational channels. Proper individual DIMM capacity selection is essential to maximizing performance.

Platform capabilities

System speed is determined by several factors:

For 1 DIMM per channel configurations, the max memory speed is 6400 MHz.

For 2 DIMM per channel configurations, the max memory speed is 5200 MHz.

Memory will operate at the slower of the following two speeds: the platform max speed or the installed DIMM max speed. For example, if using 6400 MHz DIMMs at two DIMMs per channel, the speed will be 5200 MHz; if using 5600 MHz DIMMs at one DIMM per channel, the speed will be 5600 MHz.

Mixing of DIMMs in a system

Mixing of x4 DRAMs with x8 DRAMs is not supported.

- 16 GB and 32 GB RDIMMs supported by HP are x8 and can be mixed in a system.
- 64 GB RDIMMs supported by HP are x4 and cannot be mixed with other sized DIMMs in a system.

Recommendations for upgrading memory

To make sure that the system can run at maximum speed:

- Use the same capacity memory that is already installed in the computer.
- Buy modules in pairs.


Memory features

- Single-bit errors are automatically corrected.
- Detected multi-bit errors cause the system to immediately reboot and halt with an F1 prompt error message.

Loading rules

- Load the memory modules in order of size, starting with the largest module and finishing with the smallest module.
- Each channel includes two DIMM sockets; black and white connector pairs represent a channel. The DIMMs should be loaded first in the black sockets and then in the white sockets. The DIMMs should be loaded starting with the DIMM furthest from the CPU, with the first DIMM loaded in the right-most socket and alternating sides of the CPU.

  See the following illustration for loading order.



IMPORTANT: You must disconnect the power cord and wait approximately 30 seconds for the power to drain before adding or removing memory modules. Regardless of the power state, voltage is always supplied to the memory modules as long as the computer is plugged into an active AC outlet. Adding or removing memory modules while voltage is present can cause irreparable damage to the memory modules or system board.

The memory module sockets have gold-plated metal contacts. When upgrading the memory, it is important to use memory modules with gold-plated metal contacts to prevent corrosion, oxidation, or both resulting from having incompatible metals in contact with each other.

Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, be sure that you are discharged of static electricity by briefly touching a grounded metal object. For more information, see Electrostatic discharge information on page 15.


When handling a memory module, be careful not to touch any of the contacts. Doing so can damage the module.

Before replacing the memory modules, follow these steps:


1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).

Replace a memory module:

1. To remove a memory module, open both latches of the memory module socket **(1)**, and then remove the memory module from the socket **(2)**.



2. To install a memory module, open both latches of the memory module socket **(1)**, and insert the memory module into the socket **(2)**. Press the module down into the socket so that the module is fully inserted and properly seated. Be sure that the latches are in the closed position **(3)**.



NOTE: A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

The computer automatically recognizes the additional memory when you turn on the computer.

Expansion card

The computer has three PCI Express ×16 Gen5 expansion sockets, one PCI Express ×4 Gen5 expansion socket, and one PCI Express ×4 Gen4 expansion socket.

Table 4-9 Expansion card descriptions and part numbers

Description	Spare part number
Graphics cards	
NVIDIA RTX PRO 6000, WS, Ed	P20285-002
NVIDIA RTX PRO 6000 MaxQ	P20286-002
NVIDIA RTX PRO 5000	P20287-001
NVIDIA RTX PRO 4500	P20288-002
NVIDIA RTX PRO 4000	P20289-001
NVIDIA RTX PRO 2000	P37340-001
NVIDIA RTX 5080	P29237-001
NVIDIA RTX 5070	P31915-002
NVIDIA RTX 5060	P47615-001
NVIDIA RTX A800	N55304-001
NVIDIA RTX A1000	N91236-003
NVIDIA RTX A400	N91237-003
Expansion cards	
HP Z Turbo Drive Quad Pro	N86446-001
HP Dual Thunderbolt 5	N99677-002
Ethernet network adapter AT-2911T 2	N19988-002
Fiber NIC AT-2914SX/LC-901	L49966-001
BCM5720-2P 1 GbE RJ-45 NIC, PCIe	N99038-001
Intel Ethernet Network Adapter I226-T1	P64467-001
Intel E810-CQDA2 100 Gb Dual-Port PCI Express 4.0 x16	P87041-005
NVIDIA Mellanox ConnectX-6 Lx Smart NIC	M52493-001


NOTE: You can install a PCI Express ×1, ×2, ×4, ×8, or ×16 expansion card in the PCI Express ×16 socket. For dual graphics card configurations, the first (primary) card must be installed in the PCI Express ×16 socket.

Before replacing the expansion modules, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

To remove an expansion card:


1. Pinch the blue tab to lift the PCIe card release latch **(1)** straight up, and then rotate it **(2)** over until at a 90° angle.




2. If you are removing a PCI Express ×16 card, lift the blue release lever **(1)** toward the power supply, hold the card at each end, and then carefully rock it back and forth until the connectors pull free from the socket. Lift the card **(2)** straight up and then away from the inside of the chassis to remove it. Be sure not to scrape the card against other components.

NOTE: Before removing an installed expansion card, disconnect any cables that are attached to the expansion card.

Card appearance might vary.




3. If you are installing an expansion card that is in a location with a slot cover installed, remove the cover by pulling it straight up and away from the inside of the chassis.



4. To remove the expansion slot release latch, while the latch is open **(1)**, push on both sides of the latch **(2)**, and then rotate the assembly **(3)** toward the rear of the computer.

NOTE: You can use the same process to remove the top release latch.



5. Store a removed card in antistatic packaging.

6. If you are not installing a new expansion card, install an expansion slot cover to close the open slot.

CAUTION: After removing an expansion card, you must replace it with a new card or expansion slot cover for proper cooling of internal components during operation.

7. Reverse the removal procedures to install a new expansion card. Be sure to rotate the slot cover retention latch down into place after installation.
8. After installing an expansion card, connect external cables to the installed card and internal cables to the system board, if needed.
9. Reassemble and reconfigure the computer, if necessary.

5.25-inch drive holder

Use this procedure to remove the drive holder.

Table 4-10 Drive holder description and part number


Description	Spare part number
5.25-inch drive holder	L38179-001

Before removing the drive holder, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the drive holder:

1. Release the drive holder by lifting up on the drive release bar **(1)** under the blue tab.
2. Remove the drive holder **(2)**.



Reverse the removal procedure to install the drive holder.

Hard drive

Use this procedure to remove the hard drive.

Table 4-11 Hard drive descriptions and part numbers

Description	Spare part number
12 TB	N04492-001
8 TB (NMIC)	P55244-001
4 TB	L53021-001

IMPORTANT: To prevent loss of work and damage to the computer or drive:

- If you are inserting or removing a drive, shut down the operating system properly, turn off the computer, and unplug the power cord. Do not remove a drive while the computer is on or in standby mode.
- Before handling a drive, be sure that you are discharged of static electricity. While handling a drive, avoid touching the connector.
- Handle a drive carefully; do not drop it.
- Do not use excessive force when inserting a drive.
- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.
- If a drive must be mailed, place the drive in a bubble-pack mailer or other protective packaging and label the package “Fragile: Handle With Care.”


Before removing the hard drive, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).


Remove the hard drive:

1. Disconnect the power cable and data cable **(1)** from the hard drive.
2. Squeeze and hold the blue drive holder release tabs **(2)**.

3. Lift the hard drive assembly **(3)** out of the drive cage.



4. Separate the drive holder retention arms **(1)** from the hard drive, making sure the retention pins **(2)** fully release from the drive.
5. Remove the hard drive **(3)** from the drive holder.



Reverse the removal procedure to replace the hard drive.

Optical drive

Use this procedure to remove the optical drive.

Table 4-12 Optical drive descriptions and part numbers


Description	Spare part number
DVD writer	L66553-001
DVD-ROM	L36404-001
BD writer	781417-001
Optical drive blank	P87543-001

Before removing the optical drive, follow these steps:


1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the optical drive:

1. Disconnect the power cable and data cable **(1)** from the drive.
2. Release the drive by lifting up on the drive release bar **(2)** under the blue tab.
3. Remove the drive **(3)**.



4. To remove the drive from the carrier, press the blue release latch **(1)**, and then slide the drive **(2)** out of the carrier.



Reverse the removal procedure to install the optical drive.

Rear fan

Use this procedure to remove the rear fan.

Table 4-13 Rear fan description and part number

Description	Spare part number
Rear fan	P78936-001


Before removing the rear fan, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).

Remove the rear fan:

1. Disconnect the fan cable from the system board **(1)**.
2. From the rear of the computer, press the two tabs **(2)** on the top of the fan.

3. Pull the top of the fan **(3)** into the computer, and then lift the fan **(4)** out of the computer.



Reverse the removal procedure to install the rear fan.

Lower front card guide and fan

Use this procedure to remove the lower front card guide and fan.

Table 4-14 Lower front card guide and fan description and part number

Description	Spare part number
Lower front card guide and fan	P77864-001


Before removing the lower front card guide and fan, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the lower front card guide and fan:


1. Disconnect the fan cable from the system board **(1)**.
2. Press down on the two tabs **(2)** to release the assembly.

3. Rotate the guide **(3)** forward and lift it out of the computer.



To install the lower front card guide and fan:

1. Insert the tabs **(1)** on the bottom of the guide into the holes **(2)** in the chassis.
2. Rotate the guide **(3)** into place, and then connect the fan cable to the system board.



Upper front card guide and fan

Use this procedure to remove the upper front card guide and fan.

Table 4-15 Upper front card guide and fan descriptions and part numbers


Description	Spare part number
Upper front card guide and fan	P77864-001
Duct	P78728-001

Before removing the upper front card guide and fan, follow these steps:


1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the upper front card guide and fan:

1. Disconnect the fan cable from the system board **(1)**.
2. Press down on the two tabs **(2)** to release the assembly.
3. Rotate the guide **(3)** forward and lift it out of the computer.



4. (Select products only) To install the duct onto the upper front card guide and fan, insert the tabs **(1)** on the duct onto the slots **(2)** on the guide, and then rotate the duct **(3)** into place.



Reverse this procedure to install the upper front card guide and fan.

Front I/O assembly

Use this procedure to remove the front I/O assembly.

Table 4-16 Front I/O assembly descriptions and part numbers


Description	Spare part number
Premium	P17776-001
Entry	P17777-001

Before removing the front I/O assembly, follow these steps:


1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).

Remove the front I/O assembly:

1. Disconnect the following cables from the system board, as applicable:
   - I/O front audio cable **(1)**
   - I/O assembly UI cable **(2)**
   - I/O assembly USB cable **(3)**
   - I/O assembly memory card reader cable **(4)**
   - I/O assembly FIOUI-Premium (OCuLink) cable **(5)**



2. Release the front I/O assembly by lifting up on the drive release bar **(1)**.
3. Remove the front I/O assembly **(2)**.



Reverse the removal procedure to install the front I/O assembly.

Network card

Use this procedure to remove the network card.

Table 4-17 Network card descriptions and part numbers

Description	Spare part number
10 Gbe SFP+ SR	N33073-002

Table 4-17 Network card descriptions and part numbers (continued)


Description	Spare part number
25 Gbe SFP28 SR	N33074-002
Dual 25 GbE Fiber NIC	N86445-001
Dual 10 GbE NIC	M41249-001

Before removing the network card, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).

Remove the network card:

1. Disconnect the cable from the system board **(1)**.
2. From the rear of the computer, remove the screw **(2)** that secures the card.
3. Rotate the top of the card into the computer, and then remove the card **(3)** from the computer.



Reverse the removal procedure to install the network card.

Flex I/O board

Use this procedure to remove the flex I/O board.

Table 4-18 Flex I/O board descriptions and part numbers

Description	Spare part number
1 GbE Fiber LC single port	M27481-001

Table 4-18 Flex I/O board descriptions and part numbers (continued)


Description	Spare part number
1 GbE single port NIC	M09717-001
2.5 GbE single port	P07166-001
10 GBase-T Flex, v2	P64388-001
HP serial port, v3	N07478-001
Dual USB Type-C 3.2, 15 W out, v2	P27711-001
Dual USB Type-A 3.2, v2	P37127-001
MediaTek MT7925 Wi-Fi 7 + Bluetooth 5.4 WLAN with internal antenna	N23020-001

Before removing the flex I/O board, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).

Remove the flex I/O board:

1. Remove the two screws **(1)** that secure the board to the computer.
2. Use your fingers to release the board **(2)** from the connector on the system board.



Reverse the removal procedure to install the flex I/O board.

Front bezel

Use this procedure to remove the front bezel.

Table 4-19 Front bezel description and part number


Description	Spare part number
Front bezel	P79678-001

Before removing the front bezel, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove all components from the front I/O bay and the 5.25-inch drive bay.

Remove the front bezel:

1. Position the computer on its right side with the bottom toward you.
2. Release the two latches **(1)** at the bottom of the inside of the computer.
3. Pull the bottom of the bezel **(2)** away first, then remove the bezel.



Reverse the removal procedure to install the front bezel.

Interlock assembly

Use this procedure to remove the interlock assembly.

Table 4-20 Interlock assembly description and part number

Description	Spare part number
Interlock switch (includes plastic housing)	P78929-001

Interlock/intrusion removal and installation notes:


- The system board includes several headers for interlock/intrusion - P124, P125, P126.
- To enable interlock, a jumper has to be installed on P126. The interlock switches plug into P125 and P126.
- When a jumper is on P126, you can use BIOS settings to enable or disable interlock. Mexico and India require interlock control from the factory, which results in jumper installation. Interlock is not required or enabled in other regions unless specifically requested. If not requested, P126 does not have a jumper installed.
- All system board spare parts ship without a jumper installed on P124, P125, or P126, which disables BIOS control of interlock/intrusion.
- When replacing the system board, be sure to take note of the configuration of P124, P125, and P126 before servicing, and then duplicate this configuration on the replacement board.

Before removing the interlock assembly, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).
4. Remove the upper front card guide and fan (see Upper front card guide and fan on page 50).

Remove the interlock assembly:

1. Disconnect the cable **(1)** from the system board.
2. Remove the cable from the clips **(2)** on the front of the computer chassis.
3. Use a screwdriver to press the release tab **(3)** under the metal bracket.
4. Pull the switch with the cable **(4)** up and out of the chassis.



5. Remove the interlock jumper.

Reverse the removal procedure to install the interlock assembly.

Panel latch

Use this procedure to remove the panel latch.

Table 4-21 Panel latch description and part number


Description	Spare part number
Panel latch	P79676-001

Before removing the panel latch, follow these steps:


1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the upper front card guide and fan (see Upper front card guide and fan on page 50).

Remove the panel latch:

1. Remove the two screws **(1)** that secure the latch to the computer.
2. Remove the panel latch **(2)**.



3. To remove the latch from the bracket, lift the latch straight up and out of the bracket.



Reverse the removal procedure to install the panel latch.

Heat sink

Use this procedure to remove the heat sink.

Table 4-22 Heat sink descriptions and part numbers

Description	Spare part number
Heat sink, standard	N29118-001
Heat sink, premium	P50178-001

NOTE: The heat sink spare part kit includes replacement thermal material.

Before removing the heat sink, follow these steps:

NOTE: When replacing the heat sink, be sure that the processor (see Processor on page 62) is removed from the defective heat sink and installed on the replacement heat sink.

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).

Remove the heat sink:

1. Disconnect the heat sink fan cable from the system board **(1)**.


2. In the sequence indicated on the label on the heat sink, loosen the four slotted Torx30 captive screws **(2)** that secure the heat sink to the computer.

IMPORTANT: Remove heat sink retaining screws in diagonally opposite pairs (as in an X) to even the downward forces on the processor. The pins on the socket are fragile, and damage to them might require replacing the system board.

3. Pull the levers **(3)** located on the outside of each screw toward each other.
4. Remove the heat sink **(4)** from the computer.

NOTE: The processor is attached to the bottom of the heat sink. When the heat sink is removed, it is recommended that the heat sink be left resting upside down, with the processor resting on top of the heat sink. Failure to follow this caution can result in damage to the processor.

NOTE: Before installing a heat sink, wipe off all old thermal paste and reapply new thermal paste.



Reverse the removal procedure to replace the heat sink.

NOTE: Be sure the orientation of the heat sink is correct by matching the triangle on the heat sink with the triangle on the system board.

Power supply

Use this procedure to remove the power supply.

Table 4-23 Power supply descriptions and part numbers

Description	Spare part number
1350 W	P19535-002

Table 4-23 Power supply descriptions and part numbers (continued)

Description	Spare part number
775 W	P19534-001


TIP: Take a picture of the cable routing before moving cables to make it easier to reinstall the cables in their original positions for optimum airflow.

Before removing the power supply, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).


Remove the power supply:

1. Disconnect the cables from the system board connectors labeled PWR P2 **(1)**, PWR_PS5 **(2)**, and PWR_P1 **(3)**.



2. Disconnect power cables connected to any expansion cards and remove the expansion cards. Unplug the I/O cables and any other necessary cables for easier access to the power supply cables.
3. Remove the four Torx screws **(1)** that secure the power supply to the back of the computer.
4. Press the release button **(2)** at the front of the power supply.

5. Lift the power supply **(3)** out of the computer.



Reverse the removal procedures to install the power supply.

Processor

Use these procedures to remove the processor.

Table 4-24 Processor descriptions and part numbers


Description	Spare part number
Intel Xeon 678X	P83905-003
Intel Xeon 676X	P83907-003
Intel Xeon 674X	P83906-003
Intel Xeon 658X	P83908-003
Intel Xeon 656	P83913-003
Intel Xeon 654	P83912-003
Intel Xeon 638	P83911-003
Intel Xeon 636	P83910-003
Intel Xeon 634	P83909-003

Before removing the processor, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).
4. Remove the heat sink (see Heat sink on page 59).

Remove the processor:


1. Position the heat sink upside down.
2. Release the four clips **(1)** that secure the processor holder to the heat sink.
3. Remove the processor holder **(2)** from the heat sink by lifting it straight up.
4. Carefully release the processor holder clips **(3)**.
5. Remove the processor **(4)** from the processor holder by lifting it straight up.



IMPORTANT: Do not handle the pins in the processor socket. These pins are fragile, and handling them could cause irreparable damage. If pins are damaged, you might have to replace the system board.

The thermal material must be thoroughly cleaned from the surfaces of the processor and the heat sink and reinstalled each time the processor is removed. Replacement thermal material is included with the processor and heat sink spare part kits.

When installing the processor into the processor holder, make sure the corner of the processor with the triangle icon **(1)** is aligned with the corner of the processor holder with the triangle icon **(2)**, and the notches **(3)** in the processor are aligned with the ribs **(4)** on the processor holder clips. When installing the processor and processor holder onto the heat sink, make sure the corner of the processor holder with the triangle icon **(2)** is aligned with the corner of the heat sink with the triangle icon **(5)**. Failure to follow this caution can result in damage to the processor and system board and system failure.



System board

Use this procedure to remove the system board.

Table 4-25 System board description and part number

Description	Spare part number
System board	P10838-601

NOTE: All system board spare part kits include replacement thermal material.


Before removing the system board, follow these steps:

1. Prepare the computer for disassembly (see Preparation for disassembly on page 25).
2. Remove the access panel (see Access panel on page 27).
3. Remove the memory cooler (see Memory cooler on page 36).
4. Remove the rear fan (see Rear fan on page 48).
5. Remove all expansion cards, M.2 modules, and network cards, and unplug all cables.
6. When replacing the system board, be sure that the heat sink (see Heat sink on page 59) is removed from the defective system board and installed on the replacement system board.


Remove the system board:

1. Turn the two release latches **(1)** clockwise 90° to the vertical position.


2. Slide the system board **(2)** toward the front of the computer, and then lift the system board **(3)** up and out of the computer.



3. To remove a system board latch, remove the screw **(1)** that secures it, and then remove the latch **(2)** from the computer.



Use the following illustration to determine the location of system board components.



Reverse the removal procedure to install the system board.

5 Troubleshooting without diagnostics

Use this chapter to identify and correct minor problems.

⚠ **CAUTION:** Misuse of the computer or failure to establish a safe and comfortable work environment can result in discomfort or serious injury. For more information, see the *Safety & Regulatory Information* guide.

Before you call for technical support

If you are having problems with the computer, try these solutions to isolate the exact problem before calling for technical support.

- Run the HP diagnostic tool.
- Run the hard drive self-test in Computer Setup.
- Check the power light on the front of the computer to see if it is blinking red. The blinking lights are error codes that will help you diagnose the problem.
- If you are working on a network, plug another computer with a different cable into the network connection. There might be a problem with the network plug or cable.
- If you recently added new hardware, remove the hardware and see if the computer functions properly.
- If you recently installed new software, uninstall the software and see if the computer functions properly.
- Boot the computer to Safe Mode to see if it will boot without all of the drivers loaded. When booting the operating system, use “Last Known Configuration.”
- See the comprehensive online technical support at http://www.hp.com/support.

Access HP Business Solutions at https://www.hp.com/us-en/solutions/business-solutions.html for the latest online support information, software and drivers, proactive notification, and worldwide community of peers and HP experts.

If it becomes necessary to call for technical assistance, be prepared to do the following tasks to ensure that your service call is handled properly:

- Be in front of your computer when you call.
- Before you call, write down the computer serial number and product ID number.
- Spend time troubleshooting the problem with the service technician.
- Restore the system from the Recovery Disc Set that you created or restore the system to its original factory condition in System Software Requirement Disks (SSRD).

IMPORTANT: Restoring the system will erase all data on the hard drive. Be sure to back up all data files before running the restore process.

NOTE: For sales information and warranty upgrades (Care Packs), call your local authorized service provider or dealer.

Helpful hints

If you encounter problems with the computer or software, see this list of general suggestions before taking further action.

- Check that the computer is plugged into a working electrical outlet.
- Check that the computer is turned on and the white power light is on.
- Check the power light on the front of the computer to see if it is blinking red. The blinking lights are error codes that help you diagnose the problem.
- Press and hold any key if the system beeps. Then the keyboard should be operating correctly.
- Check all cable connections for loose connections or incorrect connections.
- Wake the computer by pressing any key on the keyboard or pressing the power button. If the system remains in suspend mode, shut down the computer by pressing and holding the power button for at least 10 seconds, and then press the power button again to restart the computer. If the system does not shut down, unplug the power cord, wait a few seconds, and then plug it in again. The computer will restart if it is set to turn on automatically as soon as power is restored in Computer Setup.
- Be sure that all the needed device drivers have been installed. For example, if you are using a printer, you need a driver for that model printer.
- Remove all bootable media (such as a USB device) from the system before turning it on.
- If you have installed an operating system other than the factory-installed operating system, check to be sure that it is supported on the system.

NOTICE: When the computer is plugged into an AC power source, voltage is always being applied to the system board. You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

Solving general problems

You might be able to easily resolve the general problems described in this section. If a problem persists and you cannot resolve it yourself or if you feel uncomfortable about performing the operation, contact an authorized dealer or reseller.

⚠ **CAUTION:** When the computer is plugged into an AC power source, voltage is always being applied to the system board. To reduce the risk of personal injury from electrical shock, hot surfaces, or both, be sure to disconnect the power cord(s) from the AC outlet and allow the internal system components to cool before touching.

Cannot access the Computer Setup (F10) Utility when booting the computer

Use this information to troubleshoot the computer.

Cause	Solution
The Computer Setup (F10) Utility is set to Fast Boot, causing the F10 access screen to display too briefly when booting the computer.	Complete one of these tasks: - Before turning on the computer, press and hold f10. Turn on the computer and continue to hold F10 until the Computer Setup (F10) Utility is displayed. - Follow the Windows instructions for rebooting the computer into the Computer Setup (F10) Utility.

Computer appears locked up and will not turn off when the power button is pressed

Use this information to troubleshoot the computer.

Cause	Solution
Software control of the power switch is not functional.	1. Press and hold the power button for at least 10 seconds until the computer turns off. 2. Disconnect the power cord from the electrical outlet.

Computer will not respond to keyboard or mouse

Use this information to troubleshoot the computer.

Cause	Solution
Computer is in sleep state.	To resume from sleep state, press the power button. **IMPORTANT:** When attempting to resume from sleep state, do not hold down the power button for more than 10 seconds. Otherwise, the computer shuts down and you lose any unsaved data.
System has locked up.	Restart computer.
USB cables might not be seated properly.	Disconnect, and then reconnect USB cables to keyboard and mouse.

Computer date and time display is incorrect

Use this information to troubleshoot the computer.

Cause	Solution
RTC battery might need to be replaced.	Reset the date and time under **Control Panel**. You can also use Computer Setup to update the RTC date and time. If the problem persists, replace the RTC battery. To access Control Panel in Windows, type `control panel` in the taskbar search box, and then select Control Panel.

There is no sound or sound volume is too low

Use this information to troubleshoot the computer.

Cause	Solution
System volume might be set low or muted.	1. Check the front panel to see if an amber light indicates the system has been muted. Tap the touch-sensitive button to toggle the mute on and off. 2. Check the Computer Setup settings to be sure that the internal system speaker is not muted. This setting does not affect the external speakers. 3. Be sure that the external speakers are properly connected and powered on and that speaker volume control is set correctly. 4. Use the system volume control available in the operating system to be sure that the speakers are not muted or to increase the volume.

Poor performance

Use this information to troubleshoot the computer.

Cause	Solution
Processor is too hot.	1. Be sure that airflow to the computer is not blocked. Leave a 10.2 cm (4 inch) clearance on all vented sides of the computer to permit the required airflow. 2. Be sure that fans are connected and working properly (some fans only operate when needed). 3. Be sure that the processor heat sink is installed properly.
Hard drive is full.	Transfer data from the hard drive to create more space on the hard drive.
Low on memory.	Add more memory.
Hard drive fragmented.	Defragment hard drive.
Program previously accessed did not release reserved memory back to the system.	Restart the computer.
Virus resident on the hard drive.	Run virus protection program.
Too many applications running.	1. Close unnecessary applications to free memory. 2. Add more memory. 3. Some applications run in the background and can be closed by right-clicking their corresponding icons in the task tray.
Some software applications, especially games, are stressful on the graphics subsystem.	1. Lower the display resolution for the current application or consult the documentation that came with the application for suggestions on how to improve performance by adjusting parameters in the application. 2. Add more memory. 3. Upgrade the graphics subsystem.
Cause unknown.	Restart the computer.

Solving power problems

This table provides common causes and solutions for power problems.

Computer will not turn on

Use this information to troubleshoot the computer.

Cause	Solution
The left cover is open or not installed.	Be sure the left cover is installed. The computer will not turn on if the left cover is open or removed.

Three red blinks then seven white blinks

Computer will not turn on, power light blinks red three times and then blinks white seven times.

Cause	Solution
Computer cover not properly installed.	■ Be sure that the computer cover is installed firmly in place.

Solving hard drive problems

These tables provide common causes and solutions for hard drive problems.

Hard drive error occurs

Use this information to troubleshoot the computer.

Cause	Solution
Hard disk has bad sectors or has failed.	1. In Windows, type `file` in the taskbar search box, and then select **File Explorer** from the list of applications. In the left column, expand **This PC**, right-click a drive, select **Properties**, and then select the **Tools** tab. Under **Error checking**, select **Check**. 2. Use a utility to locate and block usage of bad sectors. If necessary, reformat the hard disk.

Disk drive transaction problem

Use this information to troubleshoot the computer.

Cause	Solution
Either the directory structure is bad or there is a problem with a file.	In Windows, type `file` in the taskbar search box, and then select **File Explorer** from the list of applications. In the left column, expand **This PC**, right-click a drive, select **Properties**, and then select the **Tools** tab. Under **Error checking**, select **Check**.

Drive not found (identified)

Use this information to troubleshoot the computer.

Cause	Solution
Cable could be loose.	Check cable connections.
The system might not have automatically recognized a newly installed device.	See reconfiguration directions in the Solving hardware installation problems on page 75 section. If the system still does not recognize the new device, check to see if the device is listed in Computer Setup. If it is listed, the probable cause is a driver problem. If it is not listed, the probable cause is a hardware problem. If this is a newly installed drive, run the Computer Setup utility, and add a POST delay under **Advanced** > **Boot Options**.
The device is attached to a SATA port that has been hidden in Computer Setup.	Run the Computer Setup utility and be sure that **Device Available** is selected for the device's SATA port in **Advanced** > **Port Options**.
Drive responds slowly immediately after startup.	Run Computer Setup and increase the POST Delay in **Advanced** > **Boot Options**.

Nonsystem disk/NTLDR missing message

Use this information to troubleshoot the computer.

Cause	Solution
The system is trying to start from the hard drive, but the hard drive might have been damaged.	Perform Drive Protection System (DPS) testing in system ROM.
System files missing or not properly installed.	1. Insert bootable media and restart the computer. 2. Boot to the windows installation media, and select the recovery option. If only a restore kit is available, select the **File Backup Program** option, and then restore the system. 3. Install system files for the appropriate operating system.
Hard drive boot has been disabled in Computer Setup.	Run the Computer Setup utility, and enable the hard drive entry in the **Advanced** > **Boot Options** list.
Bootable hard drive is not attached as first in a multiple hard drive configuration.	If attempting to boot from a hard drive, be sure that it is attached to the system board dark blue SATA connector.
Bootable hard drive is not listed first in the Boot Order.	Run the Computer Setup utility, and select **Advanced** > **Boot Options**, and be sure that the bootable hard drive is listed immediately under the **Hard Drive** entry.

Computer will not boot from hard drive

Use this information to troubleshoot the computer.

Cause	Solution
The device is attached to a SATA port that has been hidden in Computer Setup.	1. Check SATA cable connections. 2. Run the Computer Setup utility, and be sure that **Device Available** is selected for the device's SATA port in **Advanced** > **Port Options**.
Boot order is not correct.	Run the Computer Setup utility, and change the boot sequence in **Advanced** > **Boot Options**.
Hard drive is damaged.	Observe whether the front panel power light is blinking red and whether any beeps are heard. See the Worldwide Limited Warranty for terms and conditions.

Computer seems to be locked up

Use this information to troubleshoot the computer.

Cause	Solution
Program in use has stopped responding to commands.	1. Use the task manager to close programs that do not respond. 2. Attempt the normal Windows shutdown procedure. If this fails, press the power button for 4 or more seconds to turn off the power. To restart the computer, press the power button again.

Solving audio problems

If the computer has audio features and you encounter audio problems, see the common causes and solutions listed in these tables.

Sound cuts in and out

Use this information to troubleshoot the computer.

Cause	Solution
Processor resources are being used by other open applications.	Shut down all open processor-intensive applications.

Sound does not come out of the speaker or headphones

Use this information to troubleshoot the computer.

Cause	Solution
Software volume control is turned down or muted.	Double-click the **Speaker** icon on the taskbar, be sure that **Mute** is not selected, and use the volume slider to adjust the volume. You can perform this action with the touch-sensitive buttons on the front of the computer.
Audio is hidden in Computer Setup.	Enable the audio in Computer Setup: **Advanced** > **Built-in Device Options**.
The external speakers are not turned on.	Turn on the external speakers.
Headphones or devices connected to the line-out connector mute the internal speaker.	Turn on and use headphones or external speakers, if connected, or disconnect headphones or external speakers.
Computer is in the sleep state.	Press the power button to resume from the sleep state. **IMPORTANT:** When attempting to resume from the sleep state, do not hold down the power button for more than 4 seconds. Otherwise, the computer will shut down, and you will lose any unsaved data.
Internal speaker is disabled in Computer Setup.	Enable the internal speaker in Computer Setup. Select **Advanced** > **Built-in Device Options**.
Some applications can select which audio output device is used.	Be sure that the application has selected the correct audio device.
The operating system controls might be set to use a different audio device as the default output device than what is expected.	Set the operating system to use the correct audio device.

Computer appears to be locked up while recording audio

Use this information to troubleshoot the computer.

Cause	Solution
The hard disk might be full.	Before recording, be sure that there is enough free space on the hard disk. You can also try recording the audio file in a compressed format.

Line-in jack is not functioning properly

Use this information to troubleshoot the computer.

Cause	Solution
Jack has been reconfigured in the audio driver or application software.	In the audio driver or application software, reconfigure the jack or set the jack to its default value.

Solving printer problems

If you encounter printer problems, see the documentation that came with the printer and the common causes and solutions listed in these tables.

Printer will not print

Use this information to troubleshoot the computer.

Cause	Solution
Printer is not turned on and online.	Turn the printer on and be sure that it is online.
The correct printer driver for the application is not installed.	1. Install the correct printer driver for the application. 2. Try printing using the MS-DOS command: `DIR C:\ > [printer port]` where `[printer port]` is the address of the printer being used. If the printer works, reload the printer driver. To run MS-DOS commands, press the Windows key + r, type `cmd` in the **Open** box, and then select **OK**.
If you are on a network, you might not have made the connection to the printer.	Make the proper network connections to the printer.
Printer might have failed.	Run printer self-test.
The printer might be out of paper.	Check the paper tray, and refill it if it is empty.

Printer will not turn on

Use this information to troubleshoot the computer.

Cause	Solution
The cables might not be connected properly.	Reconnect all cables, and check the power cord and electrical outlet.

Printer prints garbled information

Use this information to troubleshoot the computer.

Cause	Solution
The correct printer driver for the application is not installed.	Install the correct printer driver for the application.
The cables might not be connected properly.	Reconnect all cables.
Printer memory might be overloaded.	Reset the printer by turning it off for 1 min, and then turn it back on.

Solving keyboard and mouse problems

If you encounter keyboard or mouse problems, see the documentation that came with the equipment and the common causes and solutions listed in these tables.

Keyboard commands and typing are not recognized by the computer

Use this information to troubleshoot the computer.

Cause	Solution
Keyboard connector is not properly connected.	Shut down the computer, reconnect the keyboard, and then restart the computer.
Program in use has stopped responding to commands.	Shut down your computer using the mouse, and then restart the computer.
Keyboard needs repairs.	See the Worldwide Limited Warranty for terms and conditions.
Computer is in the sleep state.	Press the power button to resume from the sleep state. **IMPORTANT:** When attempting to resume from the sleep state, do not hold down the power button for more than 4 seconds. Otherwise, the computer will shut down, and you will lose any unsaved data.

Mouse does not respond to movement or is too slow

Use this information to troubleshoot the computer.

Cause	Solution
Mouse needs to be cleaned	Clean the mouse. For more information, see Cleaning the mouse on page 21.
Mouse connector is not properly plugged into the back of the computer.	Shut down the computer using the keyboard. 1. Press the ctrl and esc keys at the same time, or press the Windows logo key, to display the **Start** menu. 2. Use the arrow keys to scroll to and select the power icon at the top right on the menu, and then press enter. 3. Use the arrow keys to select **Shut Down**, and then press enter. 4. After the shutdown is complete, plug the mouse connector into the back of the computer (or the keyboard) and restart.
Program in use has stopped responding to commands.	Shut down the computer using the keyboard, and then restart the computer.
Mouse might need repair.	See the Worldwide Limited Warranty for terms and conditions.
Computer is in the sleep state.	Press the power button to resume from the sleep state. **IMPORTANT:** When attempting to resume from the sleep state, do not hold down the power button for more than 10 seconds. Otherwise, the computer will shut down, and you will lose any unsaved data.
If using a wireless mouse, you might need to resynchronize the mouse with the computer.	Follow the instructions that came with the mouse.

Solving hardware installation problems

You might need to reconfigure the computer when you add or remove hardware, such as an additional drive or expansion card.

If you install a plug and play device, Windows automatically recognizes the device and configures the computer. If you install a device that is not plug and play, you must reconfigure the computer after completing installation of the new hardware. In Windows, use the **Add Hardware Wizard**, and follow the instructions that appear on the screen.

To open the Add Hardware Wizard, open a command prompt and type **hdwwid.exe**.

⚠ **WARNING!** When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock, hot surfaces, or both, be sure to disconnect the power cord(s) from the AC outlet and allow the internal system components to cool before touching.

A new device is not recognized as part of the system

Use this information to troubleshoot the computer.

Cause	Solution
Cables of new external device are loose or power cables are unplugged.	Be sure that all cables are properly and securely connected and that pins in the cable or connector are not bent down.
Power switch of new external device is not turned on.	Turn off the computer, turn on the external device, and then turn on the computer to integrate the device with the computer system.
When the system advised you of changes to the configuration, you did not accept them.	Reboot the computer and follow the instructions for accepting the changes.
A plug and play board might not automatically configure when added if the default configuration conflicts with other devices.	Use Windows Device Manager to clear the automatic settings for the board, and choose a basic configuration that does not cause a resource conflict. You can also use Computer Setup to reconfigure or disable devices to resolve the resource conflict. To access Device Manager in Windows, type `device manager` in the taskbar search box, and then select **Device Manager** from the list of applications.
USB ports on the computer are disabled in Computer Setup.	Run the Computer Setup utility and ensure that **Device available** is selected for appropriate USB ports under **Advanced** > **Port Options**.

Computer will not start

Use this information to troubleshoot the computer.

Cause	Solution
Incorrect memory modules were used in the upgrade, or memory modules were installed in the wrong location.	1. Review the documentation that came with the system to determine if you are using the correct memory modules and to verify the proper installation. **NOTE:** DIMM1 or XMM1 must always be installed. DIMM1 must be installed before DIMM3. 2. Observe the beeps and lights on the front of the computer. Beeps and blinking lights are codes for specific problems. 3. If you still cannot resolve the issue, contact Customer Support.

Solving network problems

Some common causes and solutions for network problems are listed in these tables. The guidelines do not discuss the process of debugging the network cabling.

Network driver does not detect network controller

Use this information to troubleshoot the computer.

Cause	Solution
Network controller is disabled.	1. Run Computer Setup and enable network controller. 2. Enable the network controller in the operating system using Device Manager. To access Device Manager in Windows, type `device manager` in the taskbar search box, and then select **Device Manager** from the list of applications.
Incorrect network driver.	Check the network controller documentation for the correct driver or obtain the latest driver from the manufacturer's website.

Network status link light never blinks

Use this information to troubleshoot the computer.

NOTE: The network status light is supposed to blink when there is network activity.

Cause	Solution
No active network is detected.	Check cabling and network equipment for proper connection.
Network controller is not set up properly.	Check for the device status within Windows, such as Device Manager for driver load and the Network Connections applet within Windows for link status. To access Device Manager in Windows, type `device manager` in the taskbar search box, and then select **Device Manager** from the list of applications.
Network controller is disabled.	1. Run Computer Setup and enable network controller. 2. Enable the network controller in the operating system using Device Manager. To access Device Manager in Windows, type `device manager` in the taskbar search box, and then select **Device Manager** from the list of applications.
Network driver is not properly loaded.	Reinstall network drivers.
System cannot autosense the network.	Disable autosensing capabilities, and force the system into the correct operating mode.

Diagnostics reports a failure

Use this information to troubleshoot the computer.

Cause	Solution
The cable is not securely connected.	Be sure that the cable is securely attached to the network connector and that the other end of the cable is securely attached to the correct device.
The cable is attached to the incorrect connector.	Be sure that the cable is attached to the correct connector.
There is a problem with the cable or a device at the other end of the cable.	Be sure that the cable and device at the other end are operating correctly.
The network controller is defective.	Contact an authorized service provider.

Diagnostics passes, but the computer does not communicate with the network

Use this information to troubleshoot the computer.

Cause	Solution
Network drivers are not loaded, or driver parameters do not match current configuration.	Be sure that the network drivers are loaded and that the driver parameters match the configuration of the network controller. Be sure that the correct network client and protocol are installed.
The network controller is not configured for this computer.	Select the **Network and Sharing Center** icon in the **Control Panel**, and configure the network controller. To access Control Panel in Windows, type `control panel` in the taskbar search box, and then select **Control Panel** from the list of applications.

Network controller stopped working when an expansion board was added to the computer

Use this information to troubleshoot the computer.

Cause	Solution
The network controller requires drivers.	Verify that the drivers were not accidentally deleted when the drivers for a new expansion board were installed.

Network controller stops working without apparent cause

Use this information to troubleshoot the computer.

Cause	Solution
The cable is not securely connected.	Be sure that the cable is securely attached to the network connector, and that the other end of the cable is securely attached to the correct device.
The network controller is defective.	Contact an authorized service provider.

Cannot connect to network server when attempting remote system installation

Use this information to troubleshoot the computer.

Cause	Solution
The network controller is not configured properly.	Verify that network connectivity exists, a DHCP Server is present, and the Remote System Installation Server contains the network interface card (NIC) drivers for your NIC.

Solving memory problems

If you encounter memory problems, some common causes and solutions are listed in these tables.

IMPORTANT: Depending on the Management Engine (ME) settings, power can still be supplied to the DIMMs when the computer is turned off. To avoid damage to the DIMMs or the system board, you must unplug the computer power cord(s) before attempting to reseat, install, or remove a memory module.

For those systems that support error correction code (ECC) memory, HP does not support mixing ECC and non-ECC memory. Otherwise, the computer will not boot the operating system.

NOTE: The memory count will be affected by configurations with the ME enabled. The ME uses 8 MB of system memory in single-channel mode or 16 MB of memory in dual-channel mode to download, decompress, and execute the ME firmware for Out-of-Band (OOB), third-party data storage, and other management functions.

System will not boot or does not function properly after installing additional memory modules

Use this information to troubleshoot the computer.

Cause	Solution
A memory module is not installed in the DIMM1 or XMM1 socket.	Verify that a memory module is installed in the DIMM1 or XMM1 socket on the system board. This socket must be populated with a memory module.
Memory module is not the correct type or speed grade for the system, or the new memory module is not seated properly.	Replace module with the correct industry-standard device for the computer. On some models, ECC and non-ECC memory modules cannot be mixed.

Out of memory error

Use this information to troubleshoot the computer.

Cause	Solution
You have run out of memory to run the application.	Check the application documentation to determine the memory requirements.

Memory count during POST is wrong

Use this information to troubleshoot the computer.

Cause	Solution
The memory modules might not be installed correctly.	Check that the memory modules have been installed correctly and that proper modules are used.
Integrated graphics might use system memory.	No action required.

Insufficient memory error during operation.

Use this information to troubleshoot the computer.

Cause	Solution
Too many Terminate and Stay Resident programs (TSRs) are installed.	Delete any TSRs that you do not need.
You have run out of memory for the application.	Check the memory requirements for the application or add more memory to the computer.

Solving USB flash drive problems

If you encounter USB flash drive problems, common causes and solutions are listed in these tables.

USB flash drive is not seen as a drive letter in Windows

Use this information to troubleshoot the computer.

Cause	Solution
The drive letter after the last physical drive is not available.	Change the default drive letter for the flash drive in Windows.

USB flash drive not found (identified)

Use this information to troubleshoot the computer.

Cause	Solution
The device is attached to a USB port that has been hidden in Computer Setup.	Run the Computer Setup utility and enable the USB ports in **Advanced** > **Port Options**.
The device was not properly seated before startup.	Be sure that the device is fully inserted into the USB port before applying power to the system

System will not boot from USB flash drive

Use this information to troubleshoot the computer.

Cause	Solution
Boot order is not correct.	Run the Computer Setup utility, and change the boot sequence in **Advanced** > **Boot Options**.
Removable Media Boot is disabled in the Computer Setup utility.	Run the Computer Setup utility, and enable booting to removable media in **Advanced** > **Boot Options**. Be sure that USB is enabled in **Storage** > **Boot Order**.

Solving internet access problems

If you encounter internet access problems, consult your internet service provider (ISP), or see the common causes and solutions listed in these tables.

Unable to connect to the internet

Use this information to troubleshoot the computer.

Cause	Solution
ISP account is not set up properly.	Verify internet settings, or contact your ISP for assistance.
Web browser is not set up properly.	Verify that the web browser is installed and set up to work with your ISP.
Cable/DSL modem is not plugged in.	Plug in the cable/DSL modem. You should see a power light on the front of the cable/DSL modem.
Cable/DSL service is not available or has been interrupted due to bad weather.	Try connecting to the internet at a later time or contact your ISP. If the cable/DSL service is connected, the cable light on the front of the cable/DSL modem will be on.
The CAT5 UTP cable is disconnected.	Connect the CAT5 UTP cable between the cable modem and the computer's RJ-45 connector. If the connection is good, the PC light on the front of the cable/DSL modem will be on.

IP address is not configured properly.	Contact your ISP for the correct IP address.
Cookies are corrupted. A *cookie* is a small piece of information that a web server can store temporarily with the web browser. Cookies are useful because they enable the browser to remember some specific information that the web server can later retrieve.	1. Type `control panel` in the taskbar search box, and then select **Control Panel** from the list of applications. 2. Select **Internet Options**. 3. In the **Browsing history** section, select the **Delete** button. 4. Select the **Cookies and website data** check box, and select the **Delete** button.

Cannot automatically launch internet programs

Use this information to troubleshoot the computer.

Cause	Solution
You must log on to your ISP before some programs will start.	Log on to your ISP and launch the program.

Solving software problems

Most software problems occur as a result of these situations:

- The application was not installed or configured correctly.
- Insufficient memory is available to run the application.
- A conflict exists between applications.
- All the necessary device drivers might not have been installed.
- If you have installed an operating system other than the factory-installed operating system, it might not be supported on the system.

If you encounter software problems, see the applicable solutions listed in the following table.

Computer will not start up and the HP logo does not appear

Use this information to troubleshoot the computer.

Cause	Solution
ROM issue - POST error has occurred.	Observe the beeps and lights on the front of the computer. See the Worldwide Limited Warranty for terms and conditions.

“Illegal Operation has Occurred” error message is displayed

Use this information to troubleshoot the computer.

Cause	Solution
Software being used is not Microsoft-certified for your version of Windows.	Verify that the software is certified by Microsoft for your version of Windows (see program packaging for this information).
Configuration files are corrupt.	If possible, save all data, close all programs, and restart the computer.

6 Computer Setup (F10) Utility

This information provides details of the functions of the Computer Setup Utility.

- Change settings from the defaults or restore the settings to default values.
- View the system configuration, including settings for processor, graphics, memory, audio, storage, communications, and input devices.
- Modify the boot order of bootable devices such as hard drives or USB flash media devices.
- Enter the Asset Tag or property identification number assigned by the company to this computer.
- Enable the power-on password prompt during system restarts (warm boots) as well as during startup.
- Establish an administrator password that controls access to the Computer Setup (F10) Utility and the settings described in this section.
- Establish minimum requirements for valid passwords, including length and required types of characters.
- Secure integrated I/O functionality, including the serial, USB, audio, or embedded NIC, so that they cannot be used until they are unsecured.
- Enable or disable different types of boot sources.
- Configure features such as Secure Boot, power management, virtualization support, and language and keyboard type used in Setup and POST. VTD and VTX are not configurable.
- Replicate the system setup by saving system configuration information about a USB device and restoring it on one or more computers.
- Enable or disable DriveLock security or securely erase a hard drive.

Using Computer Setup (F10) Utilities

You can access Computer Setup only by turning the computer on or restarting the system.

To access the Computer Setup Utilities menu, complete these steps:

1. Turn on or restart the computer.
2. Repeatedly press f10 when the power button light turns white to access the utility.

   You can also press esc to see a menu that allows you to access different options available at startup, including the Computer Setup utility.

   A choice of four headings appears in the Computer Setup Utilities menu: Main, Security, Advanced, and UEFI Drivers.

   NOTE: If you do not press f10 at the appropriate time, you must restart the computer and again repeatedly press f10 when the power button light turns white to access the utility.

3. Use the arrow (left and right) keys to select the appropriate heading. Use the arrow (up and down) keys to select the option you want, and then press enter. To return to the Computer Setup Utilities menu, press esc.

4. To apply and save changes, select **Main** > **Save Changes and Exit**.

   - If you have made changes that you do not want applied, select **Ignore Changes and Exit**.
   - To restore settings from the Advanced and Main menus to original values, select **Apply Factory Defaults and Exit**.
   - To restore settings from the Advanced and Main menus to those previously saved by **Save Custom Defaults**, select **Apply Custom Defaults and Exit**. If no custom defaults have been saved, factory defaults are used.

NOTE: You cannot modify settings in the Security menu by selecting **Apply Defaults**. You reset those values by selecting **Restore Security Settings to Factory Defaults** at the bottom of the **Security** menu.

NOTE: Not all settings shown in the following sections are available for all models.

IMPORTANT: Do not turn computer power off while the BIOS is saving the Computer Setup (F10) changes because the settings could become corrupted. It is safe to turn off the computer only after exiting the F10 Setup screen.

Computer Setup Main

This table provides information about the Computer Setup Main menu.

NOTE: Support for specific Computer Setup options can vary, depending on the hardware configuration.

Table 6-1 Computer Setup Main

Option	Description
System Information	Lists all information in following list if **Advanced System Information** is selected. Lists smaller subset if **Basic System Information** is selected. • Product name • Installed memory size • Processor type • Processor cache size (L1/L2/L3) • Processor speed • MicroCode revision • Processor stepping • Memory speed • DIMM size (for each installed module) • System BIOS version • ME Firmware version • Reference code revision • Super I/O firmware version • USB Type-C® controller firmware version • Power Delivery Controller firmware version • Serial number • SKU number • UUID (Universally Unique Identifier) • Asset tracking number • Feature byte • Build ID • Product family • System board ID • System board CT number • Integrated MAC Address • Memory size • Storage devices • ME firmware mode • PMC firmware version • PCH firmware version • Audio controller • Intel VROC upgrade key version • Embedded LAN controller (AMT) MAC • HP Remote System Controller – MainBoard connector detected – USB device detected

Table 6-1 Computer Setup Main (continued)

Option	Description
System Diagnostics	If the hard drive has the HP Advanced Diagnostics installed, the application launches. If HP Advanced Diagnostics is not installed, a basic version that is built into the BIOS provides the capability to perform the following functions: • Memory Test • Hard Drive Check • Language
BIOS Event Log	**View BIOS Event Log** Displays a list of events, alerts, or warnings that have been logged since the log was last cleared. **Export to USB Key** Saves a file named BiosEventLog.txt containing the log entries to an inserted USB storage device. **Clear BIOS Event Log on Next Boot** When selected, the BIOS clears the event log when the user saves and exits. Default is disabled.
Update System BIOS	Lets you update the system BIOS from www.hp.com or another network server, from a removable USB drive, or from a file located on the hard drive. **Check [current selection] for BIOS Updates** The string that appears here depends on the setting in **BIOS Update Preferences**. **Lock BIOS Version** If this option is selected, the system is locked to the current BIOS version, and updates are not allowed. **Native OS Firmware Update Service** Allows the operating system to drive firmware updates (for example, Windows Update). **BIOS Rollback Policy** • Unrestricted Rollback to older BIOS: Lets you roll back to any previous version of BIOS. Note that rollback might be restricted by BIOS anti-rollback policies for security reasons. • Restricted Rollback to older BIOS: If selected, **Minimum BIOS Version** becomes active, which lets you manually enter the minimum BIOS version that you can roll back to. **Minimum BIOS Version** Defaults to current version. Read-only unless restricted rollback is selected. **Allow BIOS Updates Using a Network** Lets you configure scheduled, automatic BIOS updates through the network. **BIOS Update Preferences** • Check for Update on Next Reboot: Default is disabled. • BIOS Source: Lets you select either HP.com or a custom URL. If **Custom URL** is selected, **Edit Custom URL** becomes active. HP recommends using a custom URL only for a managed IT environment.

Table 6-1 Computer Setup Main (continued)

Option	Description
Update System BIOS (cont.)	**Automatic BIOS Update Setting** Allows configuration of a periodic check for updates: **NOTE:** If Microsoft® Windows® BitLocker Drive Encryption (BDE) is enabled, it must be temporarily suspended before the BIOS is flashed. • Do not update • Checking for updates and prompt the user to accept or reject the update at that time • Checking for updates and install all new versions • Checking for updates and install only new versions marked important **BIOS Update Frequency** • Daily • Weekly • Monthly (default) **Network Configuration Settings** Lets you configure the network connection to the server that is the host for system firmware updates. **Update BIOS Using Local Media** Lets you update system date and time. Lets you access files on either USB storage or the hard drive. The HP BIOS Update and Recovery application included in BIOS Softpaqs at www.hp.com copies the BIOS file to the correct location on the hard drive or USB device.
System IDs	Lets you set the following values: • Asset Tracking Number • Ownership Tag
Replicated Setup	Lets you set the following values: • **Backs up current settings to USB device** Saves system configuration to a formatted USB flash media device. • **Restores current settings from USB device** Restores system configuration from a USB flash media device.
Save Custom Defaults	Saves the current system configuration settings as the custom default set.
Apply Custom Defaults and Exit	Applies the custom default settings to the computer after rebooting. Does not apply to options in the **Security** menu.
Apply Factory Defaults and Exit	Restores the factory system configuration settings to the computer after rebooting. Does not apply to options in the **Security** menu.
Ignore Changes and Exit	Exits Computer Setup without applying or saving any changes.
Save Changes and Exit	Saves changes to current system configuration, exits Computer Setup, and reboots.

Computer Setup Security

This table provides information about the Computer Setup Security menu.

NOTE: Support for specific Computer Setup options can vary, depending on the hardware configuration.

Table 6-2 Computer Setup Security

Option	Description
Create BIOS Administrator Password	Lets you set and enable a BIOS administrator password, which controls access to the following features: • Setup Menu (F10) • Update system ROM • WMI commands that change system settings • BIOS Configuration Utility (BCU) • Power-on password **NOTE:** Creating a BIOS user disables the Fast Boot option.
Change BIOS Administrator Password (This selection is active only if a BIOS administrator password is set.)	Lets you change the BIOS administrator password. You must know the current password to be able to change it.
Create POST Power-On Password	Lets you change or delete power-on password. The power-on password prompt appears after a power cycle or reboot. If the user does not enter the correct power-on password, the unit will not boot.
Change POST Power-On Password (This selection is active only if a BIOS administrator password is set.)	Lets you change the POST power-on password. You must know the current password to be able to change it.
Password Policies	Let you set the guidelines for a valid password. Options include: • Password minimum length • Requires at least one symbol • Requires at least one number • Requires at least one uppercase character • Requires at least one lowercase character • Allow spaces
Administrator Authentication Policies	Let you set limitations on some boot features restricting them to admin only, including: • Prompt for administrator authorization to access: – Boot menu in POST – System Recovery – Network boot – BIOS update • Allow the use of administrator credentials to modify the power-on password.

Table 6-2 Computer Setup Security (continued)

Option	Description
Security Configuration	**Trusted Platform Module (TPM) Embedded Security** • **TPM Specification Version** Displays the current TPM version. • **TPM Device** Lets you set the TPM as available or hidden. Default is available. • **TPM State** Select to enable the TPM. Default is disabled. • **Clear TPM** Select to reset the TPM to an unowned state. After the TPM is cleared, it is also turned off. To temporarily suspend TPM operations, turn the TPM off instead of clearing it. Default is no. **IMPORTANT:** Clearing the TPM resets it to factory defaults and turns it off. You will lose all created keys and data protected by those keys. • **TPM Activation Policy** ○ F1 to boot ○ Allow user to reject (default) ○ No prompts **BIOS Sure Start** • Verify Boot Block on every boot: Select to enable HP Sure Start. Default is disabled. • Network Controller Configuration Restore: Select to restore the network controller parameters to the factory state saved in the HP Sure Start Private nonvolatile (flash) memory. This setting is available only on computers with built-in NIC. **NOTE:** This process can take up to 30 seconds. You need to restore this only when the Network Controller Configuration mismatch warning is set. • Dynamic Runtime Scanning of Boot Block: Verifies the integrity of the BIOS boot block region several times each hour while the computer is running. Default is enabled. • Sure Start BIOS Settings Protection: When enabled, HP Sure Start locks all critical BIOS settings and provides enhanced protection for these settings using nonvolatile (flash) memory. Default is off. **NOTE:** An administrator password must be set to activate this setting. • Sure Start Secure Boot Keys Protection: Saves a backup copy of Secure Boot Keys so that they can be recovered if someone attempts to alter them in an unauthorized manner. • Enhanced HP Firmware Runtime Intrusion Prevention and Detection: Enables monitoring of HP system firmware executing out of main memory while the operating system is running. Any anomalies detected in HP system firmware that is active while the operating system is running will result in a Sure Start security event being generated.

Table 6-2 Computer Setup Security (continued)

Option	Description
Security Configuration (cont.)	• Sure Start Security Event Policy. Controls HP Sure Start behavior upon identifying a critical security event, such as any modification to HP firmware, while the operating system is running. – Log Event Only: HP Sure Start will log all critical security events in the HP Sure Start audio log within the HP Sure Start nonvolatile (flash) memory. – Log Event and notify user: In addition to logging all critical security events, HP Sure Start will notify the user within the operating system that a critical event has occurred. – Log Event and power off system: In addition to logging all critical security events, HP Sure Start turns off the computer upon detecting a HP Sure Start Security Event. Because of the potential for data loss, HP recommends this setting only in situations where security integrity of the system is a higher priority than the risk of potential data loss. • Sure Start Security Event Boot Notification: Lets you enable a warning message on the startup screen if there is a Sure Start event (BIOS recovery, Memory intrusion, etc.) • Virtualization Based BIOS Protection: Uses virtualization hardware to protect HP BIOS from the UEFI Expansion Driver and PCI Expansion ROM driver modules. Default is enabled. • Virtualization Based BIOS Protection Manual Recovery: Default is disabled. **Secure Boot Configuration**. Lets you be sure that an operating system is legitimate before booting to it, making Windows resistant to malicious modification from preboot to full operating system booting, preventing firmware attacks. UEFI and Windows Secure Boot only allow code signed by preapproved digital certificates to run during the firmware and OS boot process. **NOTE:** An administrator password must be set to activate this setting. Secure Boot must also be enabled. • Secure Boot: Default is disabled. • Secure Boot Key Management: Lets you manage the custom key settings. **NOTE:** Access to these settings requires Sure Start Secure Boot Keys Protection to be disabled. - Import Custom Secure Boot Keys: Default is disabled. - Clear Secure Boot keys: Lets you delete any previously loaded custom boot keys. Clearing keys will disable secure boot. Default is disabled. - Reset Secure Boot keys to factory defaults: Default is disabled. - Enable MS UEFI CA key: Disabling this setting alters the Secure Boot key list to further restrict the allowed software components. Set this option to disable to support Device Guard. Default is enabled. • Ready BIOS for Device Guard Use: Requires BIOS Administrator password to be configured and Secure Boot to be enabled. **Trusted Execution Technology (TXT)** Enables or disables this Intel hardware-based security feature. Default is disabled. **NOTE:** Enabling this feature disables OS management of TPM, prevents a reset of the TPM, and constrains the configuration of TPM. **Memory Encryption (TME)** Enables or disables memory encryption. **Total Memory Encryption Multi-Tenant (TME-MT)** Enables or disables TME-MT. **DMA Protection** Enables or disables DMA protection. **Pre-boot DMA Protection** Enables or disables DMA protection during pre-OS execution. **Measure Additional DMA Settings**

Table 6-2 Computer Setup Security (continued)

Option	Description
Security Configuration (cont.)	**Secure Platform Management (SPM)** • Deactivate HP Sure Run: Requires BIOS Administrator password to be configured. **Physical Presence Interface** When set to enabled, the user is notified at system power up when changes are made to system security policy. The user must manually agree to those changes before the change is confirmed. Default is enabled. **Smart Cover** (select products only) The Smart Cover Lock is a software-controllable solenoid lock that restricts unauthorized access to system internal components. • Safety Interlock: Automatically shuts down the system if the cover is removed. • Cover Removal Sensor: Lets you disable the cover sensor or configure what action is taken if the computer cover is removed. Settings include disable, notify user, and administrator credential. Default is disabled. • Cover Removal Timeout Prompt: Lets you set a timeout for user notification when the cover is removed • Clear TPM on boot after cover removal. • Last Cover Removal and Count: Displays the number of times the cover has been removed.

Table 6-2 Computer Setup Security (continued)

Option	Description
Utilities	**Hard Drive Utilities** • **Save/Restore GPT of System Hard Drive** Enabling this feature saves the GUID Partition Table (GPT) of the system hard drive. If the GPT is subsequently changed, the user is prompted to choose whether to restore GPT. Default is disabled. • **Boot Sector (GPT) Recovery Policy** Allows selection of the default action when a GPT event occurs. • **DriveLock/Automatic DriveLock** Allows you to assign or modify a master or user password for hard drives. When this feature is enabled, the user is prompted to provide one of the DriveLock passwords during POST. If neither is successfully entered, the hard drive remains inaccessible until one of the passwords is successfully provided during a subsequent cold-boot sequence. **NOTE:** This selection appears only when at least one drive that supports the DriveLock feature is attached to the system. **IMPORTANT:** Be aware that these settings take place immediately. It is not necessary to save. **IMPORTANT:** Be sure to document the DriveLock password. Losing a DriveLock password will render a drive permanently locked. **NOTE:** Disable DriveLock on NVMe drives before using applications for hardware-based encryption. After you select a drive, the following options are available: – Set DriveLock Master Password: Sets the drive's master password but does not enable DriveLock. – Enable DriveLock: Sets the drive's user password and enables DriveLock. • **Secure Erase** Lets you select a hard drive to completely erase. After you erase a hard drive with a program that uses Secure Erase firmware commands, no file recovery program, partition recovery program, or other data recovery method can extract data from the drive. • **Allow OPAL Hard Drive SID Authentication** BIOS supports drive encryption using the DriveLock feature by creating the storage device's ownership key. If BIOS creates the key, any third-party applications (including other encryption software) are not allowed to perform certain drive operations such as establishing their own key using SID. Encryption software applications may or may not be limited by SID authentication lockout depending on how they are designed. Default is disabled.
Absolute Persistence Module Current State	Shows the current state of the Absolute Persistence module. Yes: Disabled No: Available
System Management Command	Allows authorized personnel to reset security settings during a service event. Default is enabled.
Restore Security Settings to Factory Default	This action resets security devices, clears BIOS passwords (not including DriveLock), clears TPM, and restores settings in the **Security menu** to factory defaults.

Computer Setup Advanced

This table provides information about the Computer Setup Advanced menu.

NOTE: Support for specific Computer Setup options can vary, depending on the hardware configuration.

Table 6-3 Computer Setup Advanced (for advanced users)

Option	Heading
Display Language	Lets you select the language of the menus in F10 Setup and the keyboard layout.
Scheduled Power-On	This feature wakes the system when it is off at a specified day and time.
Boot Options	Select the devices that the computer can boot from, as well as other options, including: • Startup Delay (sec): Enabling this feature adds a user-specified delay to the POST process. One purpose for the delay is to provide additional time to activate hotkeys such as esc for the Startup Menu or f10 for Computer Setup. • Fast Boot: Default is disabled. • CD-ROM Boot (select products only): Default is enabled. • USB Storage Boot: Default is enabled. • SD Card Boot • Network (PXE) Boot: Default is enabled. • Network Boot TFTP Window Size. Lowering the setting can help poor/lossy networks. • Network (PXE) Boot Configuration: – IPv4 Before IPv6 (default) – IPv6 Before IPv4 – IPv4 Disabled – IPv6 Disabled • After Boot Device Not Found ■ Stop: Shows boot failed message only if no boot devices are found. ■ UEFI Diagnostics: Start the HP UEFI Diagnostics Tool to check if device issues found. ■ Restart: Restarts the computer to if boot device is not found. • After Power Loss: Default is Power Off. – Power off: Causes the computer to remain off when power is restored. – Power on: Causes the computer to turn on automatically as soon as power is restored. – Previous state: Causes the computer to turn on automatically as soon as power is restored, if it was on when power was lost. • Prompt on Memory Size Change: Default is enabled. • Prompt on Fixed Storage Change: Default is disabled.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
Boot Options	• Network TFTP Window Size • Audio Alerts During Boot: Default is enabled. When disabled, most audible beeps from errors, warnings, and password prompts during boot up are suppressed. • Numlock on at boot: Default is disabled. • UEFI Boot Order: Specify the order in which UEFI boot sources are checked for a bootable operating system image. The default boot order is: 1. USB 2. SATA CD 3. M.2 devices 4. SATA hard drives 5. New mass storage 6. Network boot **NOTE:** Use the UP and DOWN arrows to highlight an item. Press enter to select. Use the UP and DOWN arrows to move a selected item. Press f5 to enable or disable. Press esc to exit. **Shortcut to Temporarily Override Boot Order** To boot **one time** from a device other than the default device specified in Boot Order, restart the computer and press esc (to access the Startup menu) and then f9 (Boot Menu), or only f9 (skipping the Startup menu) when the power button light turns white. After POST is completed, a list of bootable devices is displayed. Use the arrow keys to select the preferred bootable device and press enter. The computer then boots from the selected non-default device for this one time.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
HP Sure Recover	**HP Sure Recover** If enabled and HP Sure Recover is launched, the system firmware honors local and remote requests to reinstall the operating system. If it is disabled, all requests to reinstall the operating system are ignored. Default is enabled. **Recover from Network** Allows system firmware to retrieve the recovery agent from the network. If disabled, system firmware retrieves the recovery agent from a local drive. Default is enabled. **Recover after Boot Failure** If enabled and no bootable UEFI operating system is found, system firmware launches HP Sure Recover. Default is disabled. **Recover before Boot Failure Recovery** If enabled and HP Sure Recover is launched because of a boot failure, the user is notified of the boot failure and asked to choose whether to start or cancel HP Sure Recover. This setting is displayed only if **Recover after Boot Failure** is selected. **Recovery Agent** Displays recovery agent information. This information is displayed only if **Recover from Network** is selected. **Recovery Image** Displays recovery image information. This information is displayed only if **Recover from Network** is selected. **OS Recovery Image Version**. Displays the version of the recovery image stored in the embedded secure storage device. This information is displayed only if an embedded secure storage device is installed. **OS Recovery Driver Version** Displays the version of the recovery driver stored in the embedded secure storage device. This information is displayed only if an embedded secure storage device is installed.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
System Options	**Intel VROC NVME Raid** Enables VMD RAID on individual NVME storage controllers. Default is disabled. **SATA Controller** Default is enabled. **SATA Controller RAID Mode** Default is disabled. **PCIe ACS** Default is enabled. **Disable Fan POST Errors** Selecting this feature might cause the hardware to throttle and thereby decrease in system performance. Over time this might also cause damage to system hardware. Default is disabled. **WMI Events** Enable HP Notifications to receive WMI events from BIOS. This feature requires HP Notifications version 1.1.26.1 or later. Default is disabled. **Power Button Override** (disable/10 sec/15 sec/30 sec) Lets you enable and select the number of seconds you have to hold down the power button for it to force the system to turn off. Default is 10 sec. **Accelerate USB Enumeration** Lets you reduce the time of USB enumeration on specific USB devices. Default is disabled. **USB Type-C Connector System Software Interface (UCSI)** (select products only) Allows UCSI to be exposed to the operating system (ACPI table). **Reset Factory Defaults on Battery Loss** Lets you return settings to default values in the case of battery power loss. Default is Apply Default Settings. **HP Application Driver** Provides ACPI structure to enable HP common software application framework. The driver is provided in the latest HP support software that you can download from the web. **NOTE:** Device Manager shows an alert if this setting is enabled without the HP application driver installed.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
Built-In Device Options	**Embedded LAN Controller (AMT)** (select products only) Select to show the device in the operating system. Default is enabled. **Wake On LAN** Lets you either disable the Wake On LAN feature or configure where the computer boots, including the network or hard drive. Default is boot to network. **Audio Device** Select to show audio devices in the operating system, including integrated microphone, internal speakers, and headphone out. When selected, operating system visibility of each audio device is controlled independently. When this setting is cleared, all audio devices are hidden from the operating system. Individual audio device settings are also disabled. Default is enabled. **Microphone** Clear to disable the integrated microphone. This does not affect devices plugged into audio jacks. The disable and lock setting prevents other audio ports from being remapped to the microphone function in the operating system. Default is enabled. **Internal Speakers** (does not affect external speakers) Clear to disable the chassis speaker or speakers. This function is applicable to normal audio playback in the operating system and does not affect the error or warning beeps during POST. Default is enabled. **Increase Idle Fan Speed (%)** Increases the minimum fan speeds over the normal settings while still enabling normal control using the internal thermal sensors. **Increase PCIe Idle Fan Speed (%)** Governs the idle fan speed for fans blowing air into the PCIe add-in cards. **PCIe Idle Fan Tracking Mode** Alternate mode for the PCIe Idle Fan speed control. The rear fan tracks the front fan, which results in a lower rear fan RPM. Default is disabled.
Port Options	**SATA0** Lets you hide SATA ports from the operating system. Default is enabled (not hidden). **SATA1** Lets you hide SATA ports from the operating system. Default is enabled (not hidden). **Restrict USB Devices** Limited to pre-OS only. Default is Allow All USB Devices.
Network Settings	**Extended DHCP Timeout** Default is enabled. **Network TCP Buffer Size** Increasing this setting can enhance performance in high-bandwidth scenarios, while reducing this setting can reduce packet loss in low-bandwidth scenarios. Default is 65536.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
Power Management Options	**Runtime Power Management** Allows certain operating systems to reduce processor voltage and frequency when the current software load does not require the full capabilities of the processor. Default is enabled. **Hardware P-States** Setting to disabled causes hardware to choose a P-state based on OS request (legacy P-States). Setting to enabled causes hardware to choose a P-state based on OS guidance. Default is enabled. **Energy/Performance Bias Control** • OS Controls EPB • BIOS Controls EPB (default) **BIOS Energy/Performance Bias** • Performance • Balanced Performance (default) • Balanced Power • Power **S4/S5 Maximum Power Savings** Enabling this feature reduces the power of the system as much as possible in the S4 or S5 state. Power is removed from the wake-up circuitry, the expansion slots, and any management features while in S4 or S5. Default is disabled. **SATA Power Management** Enables or disables SATA bus, device power management, or both. Default is enabled. **PCI Express Power Management** Enabling this option permits the PCI Express links to use Active Power State Management (ASPM) to enter lower power states while not in use. Default is enabled. **Unique Sleep State Blink Rates** This feature is designed to provide a visual indication of what sleep state the system is in. Each sleep state has a unique blink pattern. Default is disabled. **NOTE:** A normal shutdown goes to the S4 state. • S0 (On) = solid white light. • S3 (Stand By) = 3 blinks at 1 Hz (50% duty cycle) followed by a pause of 2 seconds (white light), repeated cycles of 3 blinks and a pause. • S4 (Hibernation) = 4 blinks at 1 Hz (50% duty cycle) followed by a pause of 2 seconds (white light), repeated cycles of 4 blinks and a pause. • S5 (Soft Off) = light is off.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
Performance Options	**Performance Control** (Performance Mode/Ultra Performance Mode/Quiet Mode) (default Performance Mode) This setting controls the tradeoff between performance and thermals. Controls the tradeoff between performance and thermals. • Performance Mode balances performance and acoustic noise for most configurations and workloads. • Ultra Performance Mode significantly increases performance and acoustic noise for some configurations and workloads. The highest performance gain is with high core-count CPUs running demanding multithreaded workloads. • Quiet Mode limits noise emissions and may result in slightly lower performance on demanding workloads. Not recommended at ambient temperatures above 30° C/86° F. **Turbo-Boost** Allows Intel Turbo Boost Technology to improve performance when operation conditions allow. Default is enabled. **Hyperthreading** Lets you control processor capability. Default is enabled. **Active CPU Cores Per Processor** (all, 1, 2, 4, 8, 12, 16) Default is all. **Sub-NUMA Clustering** Default is disabled. **Workload Configuration** (balanced, I/O focused) Default is balanced. **CPU C1 Auto Demotion** Default is enabled. **CPU C6 Report** Default is enabled.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
Slot Settings	**NOTE:** Slot setting options might vary. **PCI Express (x16/x4/x1) slots** Lets you enable or disable PCIe slots. Default is enabled. **Option ROM Download** Lets you enable whether the ROM option can run on the device installed in this slot. **Current PCIe Speed** Lets you view the speed of the PCI Express devices. **Limit PCIe Speed** Lets you restrict the maximum speed of the PCI Express devices to previous generations. • Auto • Gen 1 (2.5 Gbps) • Gen 2 (5 Gbps) • Gen 3 (8 Gbps) • Gen 4 (16 Gbps) • Gen 5 (32 Gbps) **Bifurcation** • x8x8 • x4x4x4x4 Default is Auto. **Resizable BARs** Default is disabled. **PCIe Data Link Feature** **SMBUS Isolation** **GFX Sensor Feature** **GFX Sensor Restore Feature**
USB Device Ignore List	Lets you enter vendor/device IDs of USB devices for the BIOS to ignore while the system is booting. The menu shows current devices in the ignore list and allows you to remove devices from the ignore list.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
Remote Management Options (Intel only)	**Intel Management Engine(ME)** Lets you enable the Intel Management Engine. Default is enabled. **Intel Active Management Technology (AMT)** Allows you to discover, repair, and protect networked computing devices. Default is disabled. **USB Key Provisioning Support** Enables AMT provisioning using a USB storage device. Default is disabled. **USB Redirection Support** USB redirection allows USB devices plugged into a client computer to be transparently redirected to the guest operating system. Default is enabled. **Unconfigure AMT on next boot**. Resets AMT configuration options on next boot. Default is Do Not Apply. **SOL Terminal Emulation Mode** SOL (serial-over-LAN) terminal emulation mode is only activated during remote AMT (Active Management Technology) redirection operations. The emulation options allow administrators to select which mode works best with their console. Default is ANSI. **Show Unconfigure ME Confirmation Prompt** Requires user confirmation when unconfiguring the Intel Management Engine. Default is enabled. **Verbose Boot Messages** Verbose boot shows additional logging information during startup, which is mainly for debugging if something goes wrong during bootup. Default is enabled. **Watchdog Timer** Allows you to set the amount of time for an operating system and BIOS watchdog alert to be sent if the timers are not deactivated. BIOS watchdog is deactivated by BIOS and would indicate that a halt occurred during execution if the alert is sent to the management console. An operating system alert is deactivated by the operating system image and would indicate that a hang occurred during its initialization. Default is enabled. • OS Watchdog Timer (min.). Default is 5 min. • BIOS Watchdog Timer (min.). Default is 5 min. **CIRA Timeout (min.)** CIRA is Customer Initiated Remote Assistance, an Intel service to help users employing Active Management Technology (AMT). Default is 1.
Remote HP PC Hardware Diagnostics	**Settings** Sets the configuration for Remote HP PC Hardware Diagnostics, including the URLs used for download and upload and scheduled execution frequency. **Execute Remote HP PC Hardware Diagnostics** Select to immediately execute Remote HP PC Hardware Diagnostics based on the how settings are configured. Any unsaved BIOS settings will be lost.

Table 6-3 Computer Setup Advanced (for advanced users) (continued)

Option	Heading
UEFI Drivers	**IPv6 Network Configuration**
	IPv4 Network Configuration
	VLAN Configuration
	Intel Ethernet Connection (19) i219-LM (MAC ADDRESS)
	Lets you configure various settings related to the i219.
	iSCSI Configuration
	Lets you configure settings related to iSCSI.

7 POST error messages

This section lists the error codes, error messages, and the various indicator light and audible sequences that you might encounter during Power-On Self-Test (POST) or computer restart, the probable source of the problem, and steps you can take to resolve the error condition.

POST Message Disabled suppresses most system messages during POST, such as memory count and non-error text messages. If a POST error occurs, the screen will display the error message. To manually switch to the POST Messages Enabled mode during POST, press any key except f10, f11, or f12. The default mode is POST Message Disabled.

The POST mode selection determines the speed at which the computer loads the operating system and the extent to which it is tested.

Quick Boot is a fast startup process that does not run all of the system level tests, such as the memory test. Full Boot runs all of the ROM-based system tests and takes longer to complete.

You can enable Full Boot to run every 1 to 30 days on a regularly scheduled basis. To establish the schedule, reconfigure the computer to the Full Boot Every x Days mode, using Computer Setup.

POST numeric codes and text messages

This section identifies those POST errors that have numeric codes associated with them. The section also includes some text messages that you might encounter during POST.

NOTE: The computer beeps once after a POST text message is displayed on the screen.

Table 7-1 POST numeric codes and text messages

Control panel message	Description	Recommended action
002-Option ROM Checksum Error	System ROM or expansion board option ROM checksum.	1. Verify the correct ROM. 2. Flash the ROM if needed. 3. If an expansion board was recently added, remove it to see if the problem remains. 4. Clear CMOS. 5. If the message disappears, there might be a problem with the expansion card. 6. Replace the system board.
003-System Board Failure	DMA or timers.	1. Clear CMOS. 2. Replace the system board.
005-Real-Time Clock Power Loss	Invalid time or date in configuration memory. RTC battery might need to be replaced.	Reset the date and time under Control Panel (you can also use Computer Setup). If the problem persists, replace the RTC battery.

Table 7-1 POST numeric codes and text messages (continued)

Control panel message	Description	Recommended action
008–Microcode Patch Error	Processor is not supported by the BIOS.	1. Upgrade BIOS to proper version. 2. Change the processor. **NOTE:** When an update to the BIOS is performed using a Softpaq, HP CMSL or Windows Update, the installation process copies files to the EFI partition on the operating system storage device. The EFI partition must be at least 300 MB for this process to complete successfully. If you are not using the HP image from the factory, you must create an EFI partition that is at least 300 MB when installing the operating system.
009–PMM Allocation Error During MEBx Download	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	1. Reboot the computer. 2. Unplug the power cord, reseat the memory modules, and reboot the computer. 3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer. 4. If the error persists, replace the system board.
00A-Product Information Not Valid	The product information programmed into the system board is missing or invalid.	Use Computer Setup to update this information.
00B-MEBx Module Did Not Checksum Correctly	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	1. Reboot the computer. 2. Unplug the power cord, reseat the memory modules, and reboot the computer. 3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer. 4. If the error persists, replace the system board.
00C-PMM Deallocation Error During MEBx Cleanup	Memory error during POST execution of the Management Engine (ME) BIOS Extensions option ROM.	1. Reboot the computer. 2. Unplug the power cord, reseat the memory modules, and reboot the computer. 3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer. 4. If the error persists, replace the system board.

Table 7-1 POST numeric codes and text messages (continued)

Control panel message	Description	Recommended action
00D-Setup Error During MEBx Execution	MEBx selection or exit resulted in a setup failure.	1. Reboot the computer. 2. Unplug the power cord, reseat the memory modules, and reboot the computer. 3. If the memory configuration was recently changed, unplug the power cord, restore the original memory configuration, and reboot the computer. 4. If the error persists, replace the system board.
00E-Inventory Error During MEBx Execution	BIOS information passed to the MEBx resulted in a failure.	1. Reboot the computer. 2. If the error persists, update to the latest BIOS version. 3. If the error still persists, replace the system board. **NOTE:** When an update to the BIOS is performed using a Softpaq, HP CMSL or Windows Update, the installation process copies files to the EFI partition on the operating system storage device. The EFI partition must be at least 300 MB for this process to complete successfully. If you are not using the HP image from the factory, you must create an EFI partition that is at least 300 MB when installing the operating system.
00F-Interface Error During MEBx Execution	MEBx operation experienced a hardware error during communication with the ME.	1. Reboot the computer. 2. If the error persists, update to the latest BIOS version. 3. If the error still persists, replace the system board. **NOTE:** When an update to the BIOS is performed using a Softpaq, HP CMSL or Windows Update, the installation process copies files to the EFI partition on the operating system storage device. The EFI partition must be at least 300 MB for this process to complete successfully. If you are not using the HP image from the factory, you must create an EFI partition that is at least 300 MB when installing the operating system.
100-Front Audio Not Connected	Front audio cable has been detached or unseated from the system board.	Reconnect or replace front audio cable.
2E1-Memory Size Error	Memory amount has changed since the last boot (memory added or removed).	The system memory size is different from the last startup. The most common reason is the removal of memory from the system board. Press the f1 key to save the memory changes.

Table 7-1 POST numeric codes and text messages (continued)

Control panel message	Description	Recommended action
2E2-Memory Error	Memory module configuration failed during startup.	1. Be sure that memory modules are correctly installed. 2. Verify proper memory module type. 3. Remove and replace the identified faulty memory modules. 4. If the error persists after replacing memory modules, replace the system board.
2E3-Incompatible Memory Module in Memory Socket(s) X, X, ...	A memory module in the memory socket(s) identified in the error message is missing critical SPD information, or is incompatible with the chipset.	1. Verify proper memory module type. 2. Try another memory socket. 3. Replace with a supported module.
2E4-DIMM Configuration Warning	Populated DIMM Configuration is not optimized.	Rearrange the DIMMs so that each channel has the same amount of memory.
2E5-ECC Memory Module Detected on Unsupported Platform	Recently added memory modules support ECC memory error correction.	1. If additional memory was recently added, remove it to see if the problem remains. 2. Check product documentation for memory support information.
2E6–Memory Not Configured Correctly for Proper MEBx Execution	DIMM1 is not installed.	Be sure that a memory module is in the DIMM1 socket and that it is properly seated.
300–Configuration Change Warning	A change in storage configuration has been detected (see the **Boot Options** menu in BIOS Setup to enable this feature). Either the installed hardware has changed, storage or firmware mode might have been changed, or a storage device might have failed to respond.	If no changes were made before this warning, check that the drives are connected properly to power cables and system board. User Diagnostics (f2 during startup) might help identify any problem with specific devices.
301-Hard Disk 1: SMART Hard Drive Detects Imminent Failure	Hard drive will soon fail. Some hard drives have a hard drive firmware patch that will fix an erroneous error message.	1. Determine whether hard drive is giving correct error message. Run the Drive Protection System (DPS) test using F2 Diagnostics when booting the computer. 2. Apply hard drive firmware patch if applicable. The patch is available at http://www.hp.com/support. 3. Back up contents and replace hard drive.
302-Hard Disk 2: SMART Hard Drive Detects Imminent Failure	Hard drive will soon fail. Some hard drives have a hard drive firmware patch that will fix an erroneous error message.	1. Determine whether hard drive is giving correct error message. Run the DPS test using F2 Diagnostics when booting the computer. 2. Apply hard drive firmware patch if applicable. The patch is available at http://www.hp.com/support. 3. Back up contents and replace hard drive.

Table 7-1 POST numeric codes and text messages (continued)

Control panel message	Description	Recommended action
309 – 30C: Hard Disk 3–6: SMART Hard Drive Detects Imminent Failure	Hard drive will soon fail. Some hard drives have a hard drive firmware patch that will fix an erroneous error message.	1. Determine whether hard drive is giving correct error message. Run the DPS test using F2 Diagnostics when booting the computer. 2. Apply hard drive firmware patch if applicable. The patch is available at http://www.hp.com/support. 3. Back up contents and replace hard drive.
3F0–Boot Device Not Found	Boot device not found.	Insert boot device or load operating system.
3F1–Hard Disk 1 Error	Hard disk 1 error.	1. Check cables and replace if necessary. 2. Clear CMOS. 3. Replace the hard disk drive.
3F2–Hard Disk 2 Error	Hard disk 2 error.	1. Check cables and replace if necessary. 2. Clear CMOS. 3. Replace the hard disk drive.
400-Serial Port A Address Conflict Detected	Both external and internal serial ports are assigned to the same resources.	1. Remove any serial port expansion cards. 2. Clear CMOS. 3. Reconfigure card resources, run Computer Setup or Windows utilities, or do both if needed.
401-Serial Port B Address Conflict Detected	Both external and internal serial ports are assigned to the same resources.	1. Remove any serial port expansion cards. 2. Clear CMOS. 3. Reconfigure card resources, run Computer Setup or Windows utilities, or do both if needed.
402-Serial Port C Address Conflict Detected	Both external and internal serial ports are assigned to the same resources.	1. Remove any serial port expansion cards. 2. Clear CMOS. 3. Reconfigure card resources, run Computer Setup or Windows utilities, or do both if needed.
403-Serial Port D Address Conflict Detected	Both external and internal serial ports are assigned to the same resources.	1. Remove any serial port expansion cards. 2. Clear CMOS. 3. Reconfigure card resources, run Computer Setup or Windows utilities, or do both if needed.
419-Out of Memory Space for Option ROMs	Recently added PCI expansion card contains an option ROM too large to download during POST.	If a PCI expansion card was recently added, remove it to see if the problem remains.

Table 7-1 POST numeric codes and text messages (continued)

Control panel message	Description	Recommended action
41A-Front USB1/USB2 Not Connected	Front USB cable has been detached or unseated from system board.	Reconnect or replace front USB cable.
41B-Device in PCI Express Slot Failed To Initialize	There is an incompatibility or problem with a PCIe device and the system or PCIe link could not be configured to a valid bus width or speed.	Try rebooting the system. If the error reoccurs, the device might not work with this system
43A-USB Type-C I2C Not Connected	Cable is required between I2C on card and USB-C on the system board.	Install cable between I2C on card and USB-C on the system board.
43B-More Than One USB Type-C Card Installed	More than one USB Type-C card is installed.	Remove USB Type-C card so that only one is installed.
500-BIOS Recovery	A system BIOS recovery has occurred.	Not applicable.
513-(GFX) Configuration requires a front chassis fan and this fan is not detected.	The system does not detect a front chassis fan assembly when installing a graphics card.	Install a front chassis fan assembly.
517-Memory configuration requires a memory fan and this fan is not detected.	The system does not detect a memory fan when installing a memory module.	Install a memory fan.
519-Aux fan not detected	The system does not detect a PCIe retainer fan assembly when installing a graphics card.	Install a PCIe retainer fan assembly.
520-Memory configuration requires a second memory fan and this fan is not detected.	The system does not detect a memory fan when installing a memory module.	Install a memory fan.
525-(GFX) Configuration requires a second front chassis fan and this fan is not detected.	The system does not detect a front chassis fan assembly when installing a graphics card.	Install a front chassis fan assembly.
70x-Wireless Mode Not Supported	The system has detected a wireless module installed in the system that is not supported and has been disabled.	Replace with a supported module.
800-Keyboard Error	Keyboard failure.	1. Reconnect keyboard with computer turned off. 2. Check connector for bent or missing pins. 3. Be sure that none of the keys are pressed. 4. Replace keyboard.
801-Keyboard or System Unit Error	Keyboard failure.	1. Reconnect the keyboard with computer turned off. 2. Be sure that none of the keys are pressed. 3. Replace the keyboard. 4. Replace the system board.
900-CPU Fan Not Detected	CPU fan is not connected or might have malfunctioned.	1. Reseat fan. 2. Reseat fan cable. 3. Replace fan.

Table 7-1 POST numeric codes and text messages (continued)

Control panel message	Description	Recommended action
901-Chassis, Rear Chassis, Front Chassis, or PCIe Blower Fan Not Detected	Fan is not connected or might have malfunctioned.	1. Reseat fan. 2. Reseat fan cable. 3. Replace fan.
904-SATA Cabling Error	One or more SATA devices are improperly attached. For optimal performance, the SATA0, SATA1, and SATA2 ports should be used for hard drives before other ports.	Be sure that SATA connectors are used in ascending order. For one device, use SATA0. For two devices, use SATA0 and SATA1. For three devices, use SATA0, SATA1, and SATA2.
90B-Fan Failure	The system has detected that a cooling fan is not operating correctly.	1. Reseat fan. 2. Reseat fan cable. 3. Replace fan.
90D-System Temperature	Thermal shutdown occurred. The system BIOS has detected that your machine was previously shut down to avoid overheating. Overheating might occur if the cooling vents are blocked or the operating temperature exceeds the system specifications. The machine should return to normal operation once the situation is resolved.	Be sure system has proper airflow.
90E-Power Supply Fan Not Detected	Power supply fan is not connected or might have malfunctioned.	1. Reseat power supply fan. 2. Reseat fan cable. 3. Replace power supply fan.
910–Filter Warning	Airflow filter is dirty.	Replace the airflow filter.
911–Graphics Module Fan Not Detected	Graphics card fan is not connected or might have malfunctioned.	1. Reseat graphics card fan. 2. Reseat fan cable. 3. Replace graphics card fan.
912–Incorrect CPU Cooler Installed For This Configuration	The processor cooler/heat sink does not match processor power requirement.	Replace the cooler/heat sink to match the processor power requirement.
915–Front Panel OcuLink Cable Not Connected	The cable from the system board to the front panel is not connected or might have malfunctioned.	1. Reseat cable. 2. Replace the cable.
961–Thunderbolt is not installed on the supported slots	Supported slots include slot 1, slot 4, and slot 5.	Install the Thunderbolt module in a supported slot.

Interpreting POST diagnostic front panel lights and audible codes

This section identifies the front panel light codes as well as the audible codes that can occur before or during POST that might not have an error code or text message associated with them.

⚠ **CAUTION:** When the computer is plugged into an AC power source, voltage is always applied to the system board. To reduce the risk of personal injury from electrical shock or hot surfaces, be sure to disconnect the power cord(s) from the AC outlet and allow the internal system components to cool before touching.

During the system validation phase that occurs at system startup, the BIOS validates the functionality of the following subsystems and conditions:

- AC adapter
- System board power
- Processor failure
- BIOS corruption
- Memory failure
- Graphics failure
- System board failure
- BIOS authentication failure

If an error is detected, specific patterns of long and short blinks, accompanied by long and short beeps (where applicable) are used to identify the error. These patterns make up a two-part code:

- Major: The category of the error
- Minor: The specific error within the category

NOTE: Single beep and blink codes are not used.

Table 7-2 Beep pattern error identification

Number of long beeps or blinks	Error category
1	Not used
2	BIOS
3	Hardware
4	Thermal
5	System board

Patterns of blink/beep codes are determined by using the following parameters:

- 1-second pause occurs after the last major blink.
- 2-second pause occurs after the last minor blink.
- Beep error code sequences occur for the first five iterations of the pattern and then stop.

- Blink error code sequences continue until the computer is unplugged or the power button is pressed.

NOTE: Not all diagnostic lights and audible codes are available on all models.

The red LED blinks to represent the major error category (long blinks). The white LED blinks to represent the minor error category (short blinks). For example, *3.5* indicates 3 long red blinks and 5 short white blinks to communicate the processor is not detected.

Table 7-3 Interpreting POST diagnostic front panel lights and audible codes

Category	Major/minor code	Description
BIOS	2.2	The main area (DXE) of BIOS has become corrupted, and there is no recovery binary image available.
	2.3	The embedded controller policy requires the user to enter a key sequence.
	2.4	The embedded controller is checking or recovering the boot block.
Hardware	3.2	The embedded controller has timed out waiting for BIOS to return from memory initialization.
	3.3	The embedded controller has timed out waiting for BIOS to return from graphics initialization.
	3.4	The system board displays a power failure (crowbar).*
	3.5	The processor is not detected.*
	3.6	The processor does not support an enabled feature.
	3.7	A removable side panel is not installed or properly closed.* **NOTE:** On workstations, the computer will not turn on if a removable side panel is not installed. This only applies to SKUs that have safety interlock enabled.
Thermal	4.2	A processor over-temperature condition has been detected.*
	4.3	An ambient temperature over-temperature condition has been detected.
	4.4	An MXM over-temperature condition has been detected.
System board	5.2	The embedded controller cannot find valid firmware.
	5.3	The embedded controller has timed out waiting for the BIOS.
	5.4	The embedded controller has timed out waiting for BIOS to return from system board initialization.
	5.5	The embedded controller rebooted the system after a possible lockup condition had been detected through the use of a System Health Timer, Automated System Recovery Timer, or other mechanism.

* Indicates a hardware-triggered event; BIOS controls all other events.

8 Password security and resetting CMOS

This computer supports two security password features that you can establish through the Computer Setup Utilities menu: administrator password and power-on password.

When you establish only an administrator password, any user can access all the information on the computer except Computer Setup. When you establish only a power-on password, the power-on password is required to access Computer Setup and any other information on the computer. When you establish both passwords, only the administrator password will give you access to Computer Setup.

When both passwords are set, you can use the administrator password in place of the power-on password as an override to log in to the computer. This feature is useful for a network administrator.

IMPORTANT: Back up the BIOS settings or save them as custom defaults in case you need them later. You can back up in Computer Setup or with the BiosConfigUtility tool available from www.hp.com.

Changing a setup or power-on password

Use this procedure to change a password.

To change the power-on or setup password, complete the following steps:

1. Turn on or restart the computer.
   - To change the setup password, go to step 2.
   - To change the power-on password, go to step 3.
2. To change the setup password, as soon as the computer turns on:
   - Press esc while the “Press the ESC key for Startup Menu” message is displayed.
   - Press f10 to enter Computer Setup.
3. When the key icon appears, type your current password, a slash (/) or alternate delimiter character, your new password, another slash (/) or alternate delimiter character, and your new password again as shown:

   `current password/new password/new password`

   NOTE: Type the new password carefully because the characters do not appear on the screen.
4. Press enter.

The new password will take effect the next time the computer is restarted.

Deleting a setup or power-on password

Use this procedure to delete a password.

To delete the power-on or setup password, complete the following steps:

1. Turn on or restart the computer.
   - To delete the setup password, go to step 2.
   - To delete the power-on password, go to step 3.
2. To delete the setup password, as soon as the computer turns on:
   - Press esc while the “Press the ESC key for Startup Menu” message is displayed.
   - Press f10 to enter Computer Setup.
3. When the key icon appears, type your current password, a slash (/) or alternate delimiter character, your new password, another slash (/) or alternate delimiter character, and your new password again as shown:

   current password/
4. Press enter.

9 Backing up, restoring, and recovering

You can use Windows tools or HP software to back up your information, create a restore point, reset your computer, create recovery media, or restore your computer to its factory state. Performing these standard procedures can return your computer to a working state faster.

IMPORTANT: If you are performing recovery procedures on a tablet, the tablet battery must be at least 70% charged before you start the recovery process.

IMPORTANT: For a tablet with a detachable keyboard, connect the tablet to the keyboard base before beginning any recovery process.

NOTE: When an update to the BIOS is performed using a Softpaq, HP CMSL or Windows Update, the installation process copies files to the EFI partition on the operating system storage device. The EFI partition must be at least 300 MB for this process to complete successfully. If you are not using the HP image from the factory, you must create an EFI partition that is at least 300 MB when installing the operating system.

Backing up information and creating recovery media

These methods of creating recovery media and backups are available on select products only.

Using Windows tools for backing up

HP recommends that you back up your information immediately after initial setup. You can do this task either using Windows Backup locally with an external USB flash drive or using online tools.

NOTE: If computer storage is 32 GB or less, Microsoft System Restore is disabled by default.

Using the HP Cloud Recovery Download Tool to create a recovery USB flash drive (select products only)

You can use the HP Cloud Recovery Download Tool to create an HP Recovery bootable USB flash drive.

For details:

- Go to http://www.hp.com, search for HP Cloud Recovery, and then select the result that matches the type of computer that you have and follow the on-screen instructions.

NOTE: In select countries, if you cannot create the HP Recovery USB flash drive yourself, contact support. Go to http://www.hp.com/support, select your country or region, and then follow the on-screen instructions.

IMPORTANT: HP recommends that you follow the Restoring and recovery methods on page 114 to restore your computer before you obtain and use the HP USB flash drive. Using a recent backup can return your machine to a working state sooner than using the HP USB flash drive. After the system is restored, reinstalling all the operating system software released since your initial purchase can be a lengthy process.

Restoring and recovering your system

You have several tools available to recover your system both within and outside of Windows if the desktop cannot load.

HP recommends that you attempt to restore your system using the Restoring and recovery methods on page 114.

Creating a system restore

System Restore is available in Windows. The System Restore software can automatically or manually create restore points, or snapshots, of the system files and settings on the computer at a particular point.

When you use System Restore, it returns your computer to its state at the time you made the restore point. Your personal files and documents should not be affected.

Restoring and recovery methods

After you run the first method, test to see whether the issue still exists before you proceed to the next method, which might now be unnecessary.

1. Run a Microsoft System Restore.
2. Run Reset this PC.

   NOTE: The options **Remove everything** and then **Fully clean the drive** can take several hours to complete and leave no information on your computer. It is the safest way to reset your computer before you recycle it.

3. Recover using the HP Recovery USB flash drive. For more information, see Recovering using the HP Recovery USB flash drive on page 114.

For more information about the first two methods, see the Get Help app:

- Select the **Start** button, select **All apps**, select the **Get Help** app, and then enter the task you want to perform.

NOTE: You must be connected to the internet to access the Get Help app.

Recovering using the HP Recovery USB flash drive

You can use the HP Recovery USB flash drive to recover the operating system and drivers that were installed at the factory. On select products, you can create recovery media on a bootable USB flash drive using the HP Cloud Recovery Download Tool.

For details, see Using the HP Cloud Recovery Download Tool to create a recovery USB flash drive (select products only) on page 113.

NOTE: In select countries, if you cannot create the HP Recovery USB flash drive yourself, contact support. Go to http://www.hp.com/support, select your country or region, and then follow the on-screen instructions.

To recover your system:

- Insert the HP Recovery USB flash drive, and then restart the computer.

NOTE: HP recommends that you follow the Restoring and recovery methods on page 114 to restore your computer before you obtain and use the HP USB flash drive. Using a recent backup can return your machine to

a working state sooner than using the HP USB flash drive. After the system is restored, reinstalling all the operating system software released since your initial purchase can be a lengthy process.

Changing the computer boot order

If your computer does not restart using the HP Recovery USB flash drive, you can change the computer boot order, which is the order of devices listed in BIOS for startup information.

IMPORTANT: For a tablet with a detachable keyboard, connect the tablet to the keyboard base before beginning these steps.

To change the boot order:

1. Insert the HP Recovery USB flash drive.
2. Access the system **Startup** menu.
   - For computers or tablets with keyboards attached, turn on or restart the computer or tablet, quickly press esc, and then press f9 for boot options.
   - For tablets without keyboards, turn on or restart the tablet, and then quickly press and hold one of the following buttons:
     - Volume up
     - Volume down

     Then select **f9**.
3. Select the USB flash drive to boot from, and then follow the on-screen instructions.

Using HP Sure Recover (select products only)

Select computer models are configured with HP Sure Recover, a PC operating system (OS) recovery solution built into the hardware and software. HP Sure Recover can fully restore the HP OS image without installed recovery software.

Using HP Sure Recover, an administrator or user can restore the system and install:

- Latest version of the OS
- Platform-specific device drivers
- Software applications, in the case of a custom image

To access the latest documentation for HP Sure Recover, go to http://www.hp.com/support. Follow the on-screen instructions to find your product and locate your documentation.

10 Using HP PC Hardware Diagnostics

You can use the HP PC Hardware Diagnostics utility to determine whether your computer hardware is running properly. The three versions are HP PC Hardware Diagnostics Windows, HP PC Hardware Diagnostics UEFI (Unified Extensible Firmware Interface), and (for select products only) Remote HP PC Hardware Diagnostics UEFI, a firmware feature.

Using HP PC Hardware Diagnostics Windows (select products only)

HP PC Hardware Diagnostics Windows is a Windows-based utility that allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs within the Windows operating system to diagnose hardware failures.

If HP PC Hardware Diagnostics Windows is not installed on your computer, you must download and install it. To download HP PC Hardware Diagnostics Windows, see Downloading HP PC Hardware Diagnostics Windows on page 117.

Using an HP PC Hardware Diagnostics Windows hardware failure ID code

When HP PC Hardware Diagnostics Windows detects a failure that requires hardware replacement, a 24-digit failure ID code is generated for select component tests. For interactive tests, such as keyboard, mouse, or audio and video palette, you must perform troubleshooting steps before you can receive a failure ID.

You have several options after you receive a failure ID:

- Select **Next** to open the Event Automation Service (EAS) page, where you can log the case.
- Scan the QR code with your mobile device, which takes you to the EAS page, where you can log the case.
- Select the box next to the 24-digit failure ID to copy your failure code and send it to support.

Accessing HP PC Hardware Diagnostics Windows

After HP PC Hardware Diagnostics Windows is installed, you can access it from HP Support Assistant or the Start menu.

Accessing HP PC Hardware Diagnostics Windows from HP Support Assistant (select products only)

After HP PC Hardware Diagnostics Windows is installed, follow these steps to access it from HP Support Assistant.

1. Complete one of the following tasks:
   - Select the **Search** icon in the taskbar, type `support` in the search box, and then select the **HP Support Assistant** app.
   - Select the question mark icon in the taskbar.
2. Select **Fixes & Diagnostics**.

3. Select **Run hardware diagnostics**, and then select **Launch**.
4. When the tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.

NOTE: To stop a diagnostic test, select **Cancel**.

Accessing HP PC Hardware Diagnostics Windows from the Start menu (select products only)

After HP PC Hardware Diagnostics Windows is installed, follow these steps to access it from the Start menu.

1. Select the **Start** button, and then select **All apps**.
2. Select **HP PC Hardware Diagnostics Windows**.
3. When the tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.

NOTE: To stop a diagnostic test, select **Cancel**.

Downloading HP PC Hardware Diagnostics Windows

The HP PC Hardware Diagnostics Windows downloading instructions are provided in English only. You must use a Windows computer to download this tool because only .exe files are provided.

Downloading the latest HP PC Hardware Diagnostics Windows version from HP

To download HP PC Hardware Diagnostics Windows from HP, follow these steps.

1. Go to http://www.hp.com/go/techcenter/pcdiags. The HP PC Diagnostics home page is displayed.
2. Select **Diagnose PC Hardware issues in Windows**, scroll down to the expanded window that appears, and then select **Download**.
3. A pop-up that asks what you want to do with the file opens. Select **Open** or **Save As**. The latest version of the diagnostics tool opens or downloads to the selected location.

Downloading the HP PC Hardware Diagnostics Windows from the Microsoft Store

You can download the HP PC Hardware Diagnostics Windows from the Microsoft Store.

1. Select the Microsoft Store app on your desktop or select the **Search** icon in the taskbar, and then type `Microsoft Store` in the search box.
2. Type `HP PC Hardware Diagnostics Windows` in the **Microsoft Store** search box.
3. Follow the on-screen directions.

The tool downloads to the selected location.

Downloading HP Hardware Diagnostics Windows by product name or number (select products only)

You can download HP PC Hardware Diagnostics Windows by product name or number.

NOTE: For some products, you might have to download the software to a USB flash drive by using the product name or number.

1. Go to http://www.hp.com/support.
2. Select **Software and Drivers**, select your type of product, and then enter the product name or number in the search box that is displayed.
3. In the **Diagnostics** section, select **Download**, and then follow the on-screen instructions to select the specific Windows diagnostics version to be downloaded to your computer or USB flash drive.

The tool downloads to the selected location.

Installing HP PC Hardware Diagnostics Windows

To install HP PC Hardware Diagnostics Windows, navigate to the folder on your computer or the USB flash drive where the .exe file downloaded, double-click the .exe file, and then follow the on-screen instructions.

Using HP PC Hardware Diagnostics UEFI

HP PC Hardware Diagnostics Unified Extensible Firmware Interface (UEFI) allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs outside the operating system so that it can isolate hardware failures from issues that are caused by the operating system or other software components.

NOTE: For some products, you must use a Windows computer and a USB flash drive to download and create the HP UEFI support environment because only .exe files are provided. For more information, see Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive on page 119.

If your PC does not start in Windows, you can use HP PC Hardware Diagnostics UEFI to diagnose hardware issues.

Using an HP PC Hardware Diagnostics UEFI hardware failure ID code

When HP PC Hardware Diagnostics UEFI detects a failure that requires hardware replacement, a 24-digit failure ID code is generated.

For assistance in solving the problem, complete one of these tasks:

- Select **Contact HP**, accept the HP privacy disclaimer, and then use a mobile device to scan the failure ID code that appears on the next screen. The HP Customer Support - Service Center page appears with your failure ID and product number automatically filled in. Follow the on-screen instructions.
- Contact support, and provide the failure ID code.

Starting HP PC Hardware Diagnostics UEFI

To start HP PC Hardware Diagnostics UEFI, follow this procedure.

1. Turn on or restart the computer, and quickly press esc.
2. Press f2.

   The BIOS searches three places for the diagnostic tools, in the following order:

   a. Connected USB flash drive

   NOTE: To download the HP PC Hardware Diagnostics UEFI tool to a USB flash drive, see Downloading the latest HP PC Hardware Diagnostics UEFI version on page 119.

b. Hard drive

c. BIOS

3. When the diagnostic tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.

Starting HP PC Hardware Diagnostics UEFI through HP Hotkey Support software (select products only)

This section describes how to start HP PC Hardware Diagnostics UEFI through HP Hotkey Support software.

NOTE: You must disable Fast Boot to access HP PC Hardware Diagnostics UEFI from the HP System Information application.

To disable Fast Boot:

1. Turn on or restart the computer, and when the HP logo appears, press f10 to enter Computer Setup.
2. Select **Advanced**, and then select **Boot Options**.
3. Clear **Fast Boot**.
4. Select **Save Changes and Exit**, and then select **Yes**.

To start HP PC Hardware Diagnostics UEFI through HP Hotkey Support software, follow this procedure:

1. From the **Start** menu, open the HP System Information Application or press fn+esc.
2. In HP System Information screen, select **Run System Diagnostics**, select **Yes** to run the application, and then select **Restart**.

IMPORTANT: To prevent loss of data, save your work in all open apps before restarting your computer.

NOTE: When the restart is complete, the computer opens the HP PC Hardware Diagnostics UEFI Application. Proceed with the troubleshooting tests.

Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive

Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive can be useful in some situations.

- HP PC Hardware Diagnostics UEFI is not included in the preinstallation image.
- HP PC Hardware Diagnostics UEFI is not included in the HP Tool partition.
- The hard drive is damaged.

NOTE: The HP PC Hardware Diagnostics UEFI downloading instructions are provided in English only, and you must use a Windows computer to download and create the HP UEFI support environment because only `.exe` files are provided.

Downloading the latest HP PC Hardware Diagnostics UEFI version

To download the latest HP PC Hardware Diagnostics UEFI version to a USB flash drive, follow these steps.

1. Go to http://www.hp.com/go/techcenter/pcdiags. The HP PC Diagnostics home page is displayed.

2. Select **Diagnose PC Hardware Issues outside of the OS**, scroll down to the expanded window that appears, and then select **Download**.

3. A pop-up that asks what you want to do with the file opens. Select **Open** or **Save As**. The latest version of the diagnostics tool opens or downloads to the selected location.

Downloading HP PC Hardware Diagnostics UEFI by product name or number (select products only)

You can download HP PC Hardware Diagnostics UEFI by product name or number (select products only) to a USB flash drive.

NOTE: For some products, you might have to download the software to a USB flash drive by using the product name or number.

1. Go to http://www.hp.com/support.

2. Enter the product name or number, select your computer, and then select your operating system.

3. In the **Diagnostics** section, follow the on-screen instructions to select and download the specific UEFI Diagnostics version for your computer.

Using Remote HP PC Hardware Diagnostics UEFI settings (select products only)

Remote HP PC Hardware Diagnostics UEFI is a firmware (BIOS) feature that downloads HP PC Hardware Diagnostics UEFI to your computer. It can then run the diagnostics on your computer, and it might upload results to a preconfigured server.

For more information about Remote HP PC Hardware Diagnostics UEFI, go to http://www.hp.com/go/techcenter/pcdiags, select **Diagnose Other Potential Issues**, scroll down to **Remote PC Hardware Diagnostics UEFI**, and then select **Learn More**.

Downloading Remote HP PC Hardware Diagnostics UEFI

Remote HP PC Hardware Diagnostics UEFI is also available as a SoftPaq that you can download to a server.

Downloading the latest Remote HP PC Hardware Diagnostics UEFI version

You can download the latest Remote HP PC Hardware Diagnostics UEFI version to a USB flash drive.

1. Go to http://www.hp.com/go/techcenter/pcdiags. The HP PC Diagnostics home page is displayed.

2. Select **Diagnose PC Hardware Issues outside of the OS**, scroll down to the expanded window that appears, and then select **Download**.

3. A pop-up that asks what you want to do with the file opens. Select **Open** or **Save As**. The latest version of the diagnostics tool opens or downloads to the selected location.

Downloading Remote HP PC Hardware Diagnostics UEFI by product name or number

You can download Remote HP PC Hardware Diagnostics UEFI by product name or number.

NOTE: For some products, you might have to download the software by using the product name or number.

1. Go to http://www.hp.com/support.

2. Select **Software and Drivers**, select your type of product, enter the product name or number in the search box that is displayed, select your computer, and then select your operating system.
3. In the **Diagnostics** section, follow the on-screen instructions to select and download the **Remote UEFI** version for the product.

Customizing Remote HP PC Hardware Diagnostics UEFI settings

Using the Remote HP PC Hardware Diagnostics setting in Computer Setup (BIOS), you can perform several customizations.

- Set a schedule for running diagnostics unattended. You can also start diagnostics immediately in interactive mode by selecting **Execute Remote HP PC Hardware Diagnostics UEFI**.
- Set the location for downloading the diagnostic tools. This feature provides access to the tools from the HP website or from a server that has been preconfigured for use. Your computer does not require the traditional local storage, such as a hard drive or USB flash drive, to run remote diagnostics.
- Set a location for storing the test results. You can also set the user name and password that you use for uploads.
- Display status information about the diagnostics run previously.

To customize Remote HP PC Hardware Diagnostics UEFI settings, follow these steps:

1. Turn on or restart the computer, and when the HP logo appears, press f10 to enter Computer Setup.
2. Select **Advanced**, and then select **Settings**.
3. Make your customization selections.
4. Select **Main**, then select **Save Changes and Exit** to save your settings.

Your changes take effect when the computer restarts.

11 Statement of memory volatility

For general information regarding nonvolatile memory in HP business computers, and to restore nonvolatile memory that can contain personal data after the system has been turned off and the hard drive has been removed, use these instructions.

HP business computer products that use Intel®-based or AMD®-based system boards contain volatile DDR memory. The amount of nonvolatile memory present in the system depends upon the system configuration. Intel-based and AMD-based system boards contain nonvolatile memory subcomponents as originally shipped from HP, with the following assumptions:

- No subsequent modifications were made to the system.
- No applications, features, or functionality were added to or installed on the system.

Following system shutdown and removal of all power sources from an HP business computer system, personal data can remain on volatile system memory (DIMMs) for a finite period of time and also remains in nonvolatile memory. Use the following steps to remove personal data from the computer, including the nonvolatile memory found in Intel-based and AMD-based system boards.

NOTE: If your tablet has a keyboard base, connect to the keyboard base before beginning steps in this chapter.

Current BIOS steps

Use these instructions to restore nonvolatile memory.

1. Follow these steps to restore the nonvolatile memory that can contain personal data. Restoring or reprogramming nonvolatile memory that does not store personal data is neither necessary nor recommended.

   a. Turn on or restart the computer, and then quickly press esc.

   NOTE: If the system has a BIOS administrator password, type the password at the prompt.

   b. Select **Main**, select **Apply Factory Defaults and Exit**, and then select **Yes** to load defaults. The computer restarts.

   c. During the restart, press esc while the "Press the ESC key for Startup Menu" message is displayed at the bottom of the screen.

   NOTE: If the system has a BIOS administrator password, type the password at the prompt.

   d. Select the **Security** menu, select **Restore Security Settings to Factory Defaults**, and then select **Yes** to restore security level defaults. The computer restarts.

   e. During the restart, press esc while the "Press the ESC key for Startup Menu" message is displayed at the bottom of the screen.

   NOTE: If the system has a BIOS administrator password, type the password at the prompt.

f. If an asset or ownership tag is set, select the **Security** menu and scroll down to the **Utilities** menu. Select **System IDs**, and then select **Asset Tracking Number**. Clear the tag, and then make the selection to return to the prior menu.

g. If a DriveLock password is set, select the **Security** menu, and scroll down to **Hard Drive Utilities** under the **Utilities** menu. Select **Hard Drive Utilities**, select **DriveLock**, and then clear the check box for **DriveLock password on restart**. Select **OK** to proceed.

h. Select the **Main** menu, and then select **Reset BIOS Security to factory default**. Select **Yes** at the warning message. The computer restarts.

i. During the restart, press esc while the "Press the ESC key for Startup Menu" message is displayed at the bottom of the screen.

NOTE: If the system has a BIOS administrator password, type the password at the prompt.

j. Select the **Main** menu, select **Apply Factory Defaults and Exit**, select **Yes** to save changes and exit, and then select **Shutdown**.

k. Restart the system. If the system has a TPM, fingerprint reader, or both, one or two prompts will appear—one to clear the TPM and the other to Reset Fingerprint Sensor. Press or tap f1 to accept or f2 to reject.

l. Remove all power and system batteries for at least 24 hours.

2. Complete one of the following tasks:

- Remove and retain the storage drive.
- Clear the drive contents by using a third-party utility designed to erase data from an SSD.
- Clear the contents of the drive by using the following BIOS Setup Secure Erase command option steps:

NOTE: If you clear data using Secure Erase, you cannot recover it.

a. Turn on or restart the computer, and then quickly press esc.

b. Select the **Security** menu and scroll down to the esc menu.

c. Select **Hard Drive Utilities**.

d. Finish by completing one of these tasks:

- Under **Utilities**, select **Secure Erase**, select the hard drive storing the data you want to clear, and then follow the on-screen instructions to continue.
- Clear the contents of the drive using the following Disk Sanitizer commands steps:

i. Turn on or restart the computer, and then quickly press esc.

ii. Select the **Security** menu and scroll down to the **Utilities** menu.

iii. Select **Hard Drive Utilities**.

iv. Under **Utilities**, select **Disk Sanitizer**, select the hard drive with the data that you want to clear, and then follow the on-screen instructions to continue.

NOTE: The amount of time it takes for Disk Sanitizer to run can be several hours. Plug the computer into an AC outlet before starting.

Nonvolatile memory usage

Use this table to troubleshoot nonvolatile memory usage.

Table 11-1 Troubleshooting information for nonvolatile memory usage

Description	Volatility description	Storage user data	How to erase
Primary storage device, holds the OS, applications, and application settings	Nonvolatile eMMC or NVMe SSD storage, removable	Yes[1]	See Current BIOS steps on page 122 for information about erasing the primary storage device.
System memory (RAM), holds transient data during system operation	Volatile, DIMM socket. Removable (16 GB/32 GB/64 GB)	Yes	Unplug unit from power.
Permanent system BIOS settings	Nonvolatile, 16 KB, stored	No[2]	See Current BIOS steps on page 122 for information about clearing BIOS settings.
System boot ROM (BIOS)	Nonvolatile memory, 512 Mbit (64 MB) socketed, removable	No	Download the latest BIOS for your model from the HP website and follow the instructions to flash the BIOS that are on the website.
RTC (CMOS) RAM	Volatile memory, 256 bytes located in AMD embedded System on Chip (SoC)	No	**Desktop computers with a CMOS button:** Unplug unit from main power, remove top cover and press the **Clear CMOS** button. **Notebook and desktop computers without a CMOS button:** 1. Press and hold power button for 12 seconds. 2. Press Windows key + V, and then press power button.
Keyboard/mouse (ROM)	Nonvolatile, 2 KB embedded in the super I/O controller (SIO2)	Yes	N/A
Keyboard/mouse (RAM)	Volatile, 256 bytes embedded in the super I/O controller (SIO2)	No	Unplug unit from main power.
LOM EEPROM	Nonvolatile, 2 MB embedded in LAN controller	No	N/A
TPM	Nonvolatile, 51 KB ROM for firmware and 38 KB system parametric data	No[3]	See Current BIOS steps on page 122 for information about clearing TPM.

[1] Under typical operation, the only user data stored on the primary storage device are preferences for device configuration and settings for connections. However, the administrator can configure the system to allow users to store data locally.

[2] The only user data potentially stored in BIOS Settings are the ownership and asset tags, administrator password, and startup password.

[3] The TPM might contain encrypted passwords or certificates generated from user or administrator input.

Questions and answers

Use this section to answer your questions about nonvolatile memory.

1. **How can the BIOS settings be restored (returned to factory settings)?**

IMPORTANT: The restore defaults feature does not securely erase any information on your hard drive. See question and answer 6 for steps to securely erase information.

The restore defaults feature does not reset the Custom Secure Boot keys. See question and answer 7 for information about resetting the keys.

   a. Turn on or restart the computer, and then quickly press esc.

   b. Select **Main**, and then select **Apply Factory Defaults and Exit**.

   c. Follow the on-screen instructions.

   d. Select **Main**, select **Save Changes and Exit**, and then follow the on-screen instructions.

2. **What is a UEFI BIOS?**

   The Unified Extensible Firmware Interface (UEFI) BIOS is an industry-standard software interface between the platform firmware and an operating system (OS). It replaces the older legacy BIOS architecture.

   The UEFI BIOS provides an interface to display the system information and configuration settings and to change the configuration of your computer before an OS is loaded. BIOS provides a secure runtime environment that supports a GUI. In this environment, you can use either a pointing device (touch screen, touchpad, pointing stick, or USB mouse) or the keyboard to navigate and make menu and configuration selections. The UEFI BIOS also contains basic system diagnostics.

   In addition, the UEFI BIOS works to initialize the computer's hardware before loading and executing the OS; the runtime environment allows the loading and execution of software programs from storage devices to provide more functionality, such as advanced hardware diagnostics (with the ability to display more detailed system information) and advanced firmware management and recovery software.

3. **Where is the UEFI BIOS located?**

   The UEFI BIOS is located on a flash memory chip. You must use a utility to write to the chip.

4. **What kind of configuration data is stored on the DIMM Serial Presence Detect (SPD) memory module? How would this data be written?**

The DIMM SPD memory contains information about the memory module, such as size, serial number, data width, speed and timing, voltage, and thermal information. This information is written by the module manufacturer and stored on an EEPROM. You cannot write to this EEPROM when the memory module is installed in a computer. Third-party tools do exist that can write to the EEPROM when the memory module is not installed in a computer. Various third-party tools are available to read SPD memory.

5. **What is meant by “Restore the nonvolatile memory found in Intel-based system boards”?**

   This message relates to clearing the Real Time Clock (RTC) CMOS memory that contains computer configuration data.

6. **How can the BIOS security be reset to factory defaults and erase the data?**

IMPORTANT: Resetting results in the loss of information.

These steps do not reset Custom Secure Boot Keys. See question and answer 7 for information about resetting the keys.

   a. Turn on or restart the computer, and then quickly press esc.

   b. Select **Main**, and then select **Reset Security to Factory Defaults**.

   c. Follow the on-screen instructions.

   d. Select **Main**, select **Save Changes and Exit**, and then follow the on-screen instructions.

7. **How can the Custom Secure Boot Keys be reset?**

   Secure Boot is a feature to ensure that only authenticated code can start on a platform. If you enabled Secure Boot and created Custom Secure Boot Keys, disabling Secure Boot does not clear the keys. You must also select to clear the Custom Secure Boot Keys. Use the same Secure Boot access procedure that you used to create the Custom Secure Boot Keys, but select to clear or delete all Secure Boot Keys.

   a. Turn on or restart the computer, and then quickly press esc.

   b. Select the **Security** menu, select **Secure Boot Configuration**, and then follow the on-screen instructions.

   c. At the **Secure Boot Configuration** window, select **Secure Boot**, select **Clear Secure Boot Keys**, and then follow the on-screen instructions to continue.

Using HP Sure Start (select products only)

Select computer models are configured with HP Sure Start, a technology that continuously monitors your computer’s BIOS for attacks or corruption.

If the BIOS becomes corrupted or is attacked, HP Sure Start restores the BIOS to its previously safe state, without user intervention. Those select computer models ship with HP Sure Start configured and enabled. HP Sure Start is configured and already enabled so that most users can use the HP Sure Start default configuration. Advanced users can customize the default configuration.

To access the latest documentation on HP Sure Start, go to http://www.hp.com/support.

12 Power cord set requirements

The power supplies on some computers have external power switches.

The power cord set received with the computer meets the requirements for use in the country where you purchased the equipment.

Power cord sets for use in other countries must meet the requirements of the country where you use the computer.

General requirements

These requirements are applicable to all countries.

1. The power cord must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord set will be installed.
2. The power cord set must have a current capacity of 15A minimum for North America, 13A minimum for Taiwan, 12A minimum for Japan, and 10A minimum for all other countries and a nominal voltage rating of 125 V AC or 250 V AC, as required by each country's power system.
3. The diameter of the wire must be a minimum of 14 AWG for North America, a minimum of 1.25 mm^2 for Taiwan and Japan, and a minimum of 1.0 mm^2 for all other countries, and the length of the cord must be greater than 1.8 m (6.0 ft) and less than 3.0 m (9.8 ft).

The power cord should be routed so that it is not likely to be walked on or pinched by items placed upon it or against it. Particular attention should be paid to the plug, electrical outlet, and the point where the cord exits from the product.

⚠ **WARNING!** Do not operate this product with a damaged power cord set. If the power cord set is damaged in any manner, replace it immediately.

Japanese power cord requirements

For use in Japan, use only the power cord received with this product.

IMPORTANT: Do not use the power cord received with this product on any other products.

Country-specific requirements

This information provides additional requirements specific to a country.

Table 12-1 Power cord country-specific requirements

Country	Accrediting Agency	Country	Accrediting Agency
Australia (1)	EANSW	Italy (1)	IMQ
Austria (1)	OVE	Japan (3)	METI
Belgium (1)	CEBC	Norway (1)	NEMKO
Canada (2)	CSA	Sweden (1)	SEMKO
Denmark (1)	DEMKO	Switzerland (1)	SEV
Finland (1)	SETI	United Kingdom (1)	BSI
France (1)	UTE	United States (2)	UL
Germany (1)	VDE		

1. The flexible cord must be Type HO5VV-F, 3-conductor, 1.0 mm^2 conductor size. Power cord set fittings (appliance coupler and plug) must bear the certification mark of the agency responsible for evaluation in the country where it will be used.
2. The flexible cord must be Type SVT or equivalent, No. 14 AWG, 3 conductor. The plug must be a 2-pole grounding type with a NEMA 5-15P (15 A, 125 V) or NEMA 6-15P (15 A, 250 V) configuration.
3. Appliance coupler, flexible cord, and plug must bear a T mark and registration number in accordance with the Japanese Dentori Law. Flexible cord must be Type VCT or VCTF, 3-conductor, 1.25 mm^2 conductor size. Plug must be a 2-pole grounding type with a Japanese Industrial Standard C8303 (12 A, 125 V) configuration.

13 Specifications

This section provides specifications for your computer.

Table 13-1 Specifications

	Metric	U.S.
Dimensions (with standard side panel)		
Height	438.2 mm	17.2 in
Width	175.0 mm	6.9 in
Depth	469.9 mm	18.5 in
Dimensions (with max side panel)		
Height	438.2 mm	17.2 in
Width	209.8 mm	8.3 in
Depth	469.9 mm	18.5 in
Approximate weight (starting at)	10.5 kg	23.2 lbs
Temperature range		
Operating*	5°C to 40°C	40°C to 104°F
Nonoperating	–40°F to 60°C	–40°F to 140°F
Maximum altitude (unpressurized)*		
Operating (with solid-state drives)	5,000 m	16,404 ft
Operating (with hard drives)	3,048 m	10,000 ft
Nonoperating	12,192 m	40,000 ft
Relative humidity (noncondensing)		
Operating (35°C max wet bulb)	8% to 85%	
Nonoperating (35°C max wet bulb)	8% to 90%	
Power supply	775 W, platinum rated (92% efficient) 1350 W @110 V or 1700 W @ 200 V or higher, platinum rated (92% efficient)	
Efficiency	92% efficient	

*40°C has been validated for all supported configurations.

*Above 1,524 m (5,000 feet) altitude, maximum operating temperature is reduced by 1° C (1.8° F) per 305 m (1,000 feet) elevation increase.

NOTE: Operating temperature is derated 1.0°C per 300 m (1000 ft) to 3000 m (10,000 ft) above sea level; no direct sustained sunlight. Maximum rate of change is 10° C/Hr. The upper limit might be limited by the type and number of options installed.

14 Linux technical notes

HP offers a variety of Linux® solutions for HP workstation customers:

- HP supports Ubuntu on HP workstations, including preinstall options on most desktop workstations and some mobile workstations.
- HP supports Red Hat® Enterprise Linux (RHEL) on HP workstations.
- HP certifies and supports SUSE Linux Enterprise Desktop (SLED) on HP workstations.

For details on supported Linux distributions for Z Series Workstations, see the HP Linux Hardware Support Matrix document at www.hp.com/support/linux_hardware_matrix.

NOTE: After you set up the operating system, make sure that the latest BIOS, drivers, and software updates are installed.

CAUTION: Do not add optional hardware or third-party devices to the workstation until the operating system is successfully installed. Adding hardware might cause errors and prevent the operating system from installing correctly.

Audio

All HP workstations come with built-in audio hardware. The audio hardware is supported by the Advanced Linux Sound Architecture (ALSA) drivers included with all modern Linux distributions.

The audio hardware provides basic playback and recording features. The ability to simultaneously play audio from multiple sources, such as applications and CDs, is provided in the ALSA driver that provides audio mixing.

After the driver is installed, the optional NVIDIA and AMD graphics cards that are supported in HP workstations also provide audio functionality over HDMI. The signal can be passed through the DisplayPort™ connector to a monitor with audio capabilities. The vendor driver must be installed. Such a configuration might present two audio hardware choices. If you do not hear sound through the speakers, one possible reason is that the graphics card (default) is selected for audio output instead of the DisplayPort. Check the audio settings (for example, **Sound** in gnome-control-center).

In some systems, embedded Intel HD graphics may also present a similar HDMI audio device that can be used through the DisplayPort interface. No proprietary driver is needed for this device, just a sufficiently recent kernel.

NVIDIA graphics workstations

Z Series workstation configurations come with NVIDIA ProViz graphics hardware. HP recommends the use of NVIDIA drivers for best results on Linux systems.

HP provides recommended versions of the drivers with RPM-compatible installers for RHEL and SLED distributions. These are available from workstation driver repositories on hp.com. When HP installers are used, their contents and documentation links are located in the /opt/hp/nvidia folder.

When installing Linux on a workstation that contains an NVIDIA card, administrators should select a VESA-compatible driver to avoid the instability that is experienced with some open-source versions of the Nouveau and DRM drivers.

Open-source versions of Nouveau drivers and NVIDIA drivers cannot coexist in the same runtime environment because they use the same hardware resources. If administrators create their own Linux environments using NVIDIA drivers but choose not to use HP-packaged versions, HP recommends that they manually append the following boot loader parameters to properly suppress the Nouveau driver at runtime (grub example below):

```
kernel /vmlinuz ... rdblacklist=nouveau nouveau.modeset=0
```

This action is applied by HP installers but must be applied and restored under other circumstances.

To customize display characteristics and resolutions when the computer is using an NVIDIA driver, run the following command:

```
/usr/bin/nvidia-settings
```

To create and manipulate the **/etc/X11/xorg.conf** file, run:

```
/usr/bin/nvidia-xconfig
```

AMD graphics workstations

Some workstation configurations include AMD graphics hardware. All of the supported Linux distributions should have an “in-box” driver that supports the hardware well enough for either Wayland or the X server to run without additional driver or additions..

Xorg drivers that might be loaded as the server starts are as follows:

- The Radeon® in-box X driver will associate with some older GPUs.
- The *fbdev* or *vesa X* driver might activate for certain other cards.
- The newer *amdgpu* driver will be present in all recent distributions but it does not support all AMD GPUs.
- There is also a generic *modesetting* driver in some distributions.

Index

A

access panel
  illustrated 7
  locked 68
  removal and replacement 27
access panel card retainer
  removal and replacement 30
accessory security cable loop,
  identifying 3
Advanced menu, Computer
  Setup 92
audible codes 109
audio problems 72
audio-out (headphone)/audio-in
  (microphone) combo jack,
  identifying 2, 3

B

backup, creating 113
backups 113
battery
  disposal 15, 21, 23
battery replacement 34
beep codes 109
blinking lights 109
boot order, changing 115
booting options
  Full Boot 102
  Quick Boot 102

C

cable management 15, 23
cable pinouts, SATA data 23
changing a Power-On password 111
changing a Setup password 111
cleaning
  computer 15, 18, 20
  mouse 15, 18, 21
  safety precautions 15, 18
cleaning your computer
  disinfecting 19
  removing dirt and debris 19
CMOS
  clearing and resetting 111
components
  front 1
  left 4
  rear 2
computer cleaning 15, 18, 20
computer components
  identifying 25
computer features 1
computer major components
  illustrated 7
Computer Setup
  access problem 68
  Advanced menu 92
  Main menu 83
  Security menu 87
Computer Setup Utility 82
connectors
  power 3
country power cord set
  requirements 127
Customer Support 67

D

deleting a Power-On password 111
deleting a Setup password 111
drive carrier
  illustrated 9
drive holder
  removal and replacement 44
drive light, identifying 2

E

electrostatic discharge (ESD) 15
  preventing damage 15, 16
error
  codes 102, 109
error messages 102
expansion card
  illustrated 7
  removal 40
expansion card guide
  illustrated 10

F

F10 Setup 82
  access problem 68
feet
  removal and replacement 26
flash drive problems 79
flex I/O board
  removal and replacement 54
front bezel
  illustrated 10
  removal and replacement 55
front card guide and fan
  illustrated 10
front I/O assembly
  illustrated 8
  removal and replacement 52

G

general problems 68
grounding methods 15, 16

H

hard drive
  illustrated 8
  proper handling 15, 21, 22
  removal 44
  SATA characteristics 23
hard drive problems 71
hardware installation problems 75
heat sink
  removal and replacement 59
helpful hints 68
HP PC Hardware Diagnostics UEFI
  downloading 119
  failure ID code 118
  HP Hotkey Support
    software 119
  starting 118, 119
  using 118
HP PC Hardware Diagnostics
  Windows
  accessing 116, 117
  downloading 117
  failure ID code 116
  installing 118
  using 116
HP Recovery media
  recovery 114
HP Sure Recover 115
HP Sure Start 122, 126

I

illustrated parts catalog 7

installing
battery 34
memory 37
interlock assembly
removal and replacement 56
interlock switch
illustrated 10
internet access problems 80

J

jacks
audio-out (headphone)/audio-in (microphone) 2, 3
network 3
RJ-45 (network) 3

K

keyboard
cleaning 15, 18, 20
keyboard problems 74

L

lights
blinking PS/2 keyboard 109
Linux technical notes 131
lower front card guide and fan
removal and replacement 49

M

Main menu, Computer Setup 83
memory
installation 37
nonvolatile 122
problems 78
socket population 37
volatile 122
memory cooler
removal and replacement 36
miscellaneous parts 11
mouse
cleaning 15, 18, 21
problems 74
mouse, spare part numbers 12

N

network card
removal and replacement 53
network jack, identifying 3
network problems 76
nonvolatile memory 122
numeric error codes 102

O

operating guidelines 15, 18
optical drive
removal and replacement 46
overheating, prevention 15, 18

P

panel latch
removal and replacement 58
password
Power-On 111
security 111
Setup 111
ports
USB 5 Gbps port 1, 3
USB 5 Gbps port with HP Sleep and Charge 2
USB Type-C 4
USB Type-C 20 Gbps with HP Sleep and Charge 2
POST error messages 102
power button, identifying 1, 3
power connector
identifying 3
power cord set requirements
country specific 127
power cord, spare part numbers 12, 13
power problems 70
power supply
illustrated 8
operating voltage range 129
removal and replacement 60
Power-On password 111
printer problems 73
problems
audio 72
Computer Setup 68
F10 Setup 68
flash drive 79
general 68
hard drive 71
hardware installation 75
internet access 80
keyboard 74
memory 78
mouse 74
network 76
power 70
printer 73
software 81
processor
illustrated 9
removal and replacement 62
product ID location 5

R

rack rails
removal and replacement 29
rear fan
illustrated 8
removal and replacement 48
rear handle pocket, identifying 3
recovery 113, 114
discs 114
media 114
USB flash drive 114
recovery media 113
creating using HP Cloud Recovery Download Tool 113
creating using Windows tools 113
Remote HP PC Hardware Diagnostics UEFI settings
customizing 121
using 120
removal and replacement
access panel card retainer 30
drive holder 44
feet 26
flex I/O board 54
front bezel 27, 55
front I/O assembly 52
heat sink 59
interlock assembly 56
lower front card guide and fan 49
memory cooler 36
network card 53
optical drive 46
panel latch 58
power supply 60
processor 62
rack rails 29
rear fan 48
solid-state drive 31
system board 64
top cover 28
upper front card guide and fan 50
removing
battery 34
expansion card 40
hard drive 44
removing personal data from volatile system memory 122
restoring 113

restoring and recovery methods 114
RJ-45 (network) jack, identifying 3

S

safety precautions
  cleaning 15, 18
SATA
  connectors on system board 23
  data cable pinouts 23
  hard drive characteristics 23
screws, correct size 15, 21, 22
security cable slot, identifying 4
Security menu, Computer Setup 87
serial number location 5
service considerations 15, 21
Setup password 111
side panel latch
  illustrated 8
slots
  microSD memory card reader 2
  SD card reader 2
software
  problems 81
  servicing computer 15, 21
solid-state drive
  illustrated 9
  removal and replacement 31
specifications
  computer 129
specifications, product 6
SSD clip
  illustrated 10
static electricity 15
system board
  illustrated 9
  removal and replacement 64
  SATA connectors 23
system memory, removing personal
  data from volatile 122
system restore 114
system restore point, creating 113

T

temperature control 15, 18
tools, servicing 15, 21
top cover
  removal and replacement 28
Torx T15 screwdriver 15, 21
troubleshooting without
  diagnostics 67

U

upper front card guide and fan
  removal and replacement 50
USB 5 Gbps port with HP Sleep and
  Charge, identifying 2
USB 5 Gbps port, identifying 1, 3
USB Type-C 20 Gbps ports with HP
  Sleep and Charge, identifying 2
USB Type-C port, identifying 4
using Computer Setup Utilities 82

V

vent, identifying 5
ventilation, proper 15, 18

W

Windows
  backup 113
  recovery media 113
  system restore point 113
Windows tools, using 113