Instrument Security Procedures

Model:

Fluke 377/377 FC/378/ 378 FC

Product Name:

Clamp Meter

Instrument Description:

The Clamp Meter measures true-rms ac current and voltage, dc current and voltage, inrush current, resistance, capacitance, frequency, and dc millivolts.

Memory Description:

Fluke 377, 377 FC, 378, and 378 FC has two devices with internal memory:

- U37, microcontroller, TI MSP432P4111, 256 kB of RAM, 2048 kB of flash
- microcontroller, CC2530, 8 kB of RAM, 256 kB of flash

Memory Cleaning Instructions:

1. The Device Name is erased with the Fluke Connect mobile app.
2. The Logging Memory is erased by:
   a. Turn off the Clamp.
   b. Push and hold HOLD as you turn the control knob to $\widetilde{V}$. The Clamp goes into the option mode.
   c. Push ▭ to go through the options until CLr shows on the display.
   d. Push MIN MAX to finish the request.
   e. Release HOLD to exit the options mode.