



NOTE: It is recommended to transfer this template to a piece of wood (1/2" to 1" thickness) to ensure proper anchor bolt placement.