

Align the hand strap and the two brackets with A140. Put them in place and tighten four screws.

