LOAD BAGS ONTO HOOKS. TUBE, PUSH BUTTON UNTIL CLIP SNAPS. INSERT TUBE WITH THE HOOKS INTO LOWER ABOVE INSTRUCTIONS FOR SECOND TUBE. INSERT TUBE WITHOUT HOOKS INTO BASE, PUSH BUTTON UNTIL CLIP SNAPS, FOLLOW

