

ASSEMBLY INSTRUCTIONS

STOREX

1. Using the level and a tape measure, mark two level hole locations spaced 13 3/8" apart.
2. Drill 3/16" holes, and insert the wall anchors. Install the screws until their head are 1/4" from the wall.
3. Install the wall pocket by lining up the holes to the screws on the wall.
4. Additional wall pockets can be installed by simply aligning the hooks on the additional pocket to the rails on the first pocket. Push the new pocket into place until you hear a click.

