




MOBILE PLAN CENTER






■ Using the wrench supplied, firmly screw (N) Casters with Brakes and (O) Casters without Brakes into threaded inserts found in (O) Lower Crosspieces. Note: Install both casters with brake into same crosspiece.




Adjust (A) L-Frames to length of hanger to be used. Secure using two (Q) Knob Bolts, four (R) Washers, and two (P) Wing Nuts as shown. Note: In all cases, hole at END of each L-frame must be used.




Fasten © Lower Crosspiece, with casters installed, to L-frame as shown, using two Long Bolts and two Acorn Nuts. Tighten with wrench. Repeat for opposite side.


Install (E) Bottom Panels to each side of unit, using (K) Short Screws as shown. (Examine circled illustration to identify bottom panels.)




Fasten ® Upper Crosspieces to INSIDE of frame, using DLong Bolts and Acorn Nuts as shown. Note: the surface of the crosspiece with holes nearest the ends faces UP.




Install a ① Top Panel in the position shown, using three ⑥ Short Screws. Next, fasten two ⑥ Plastic Spacers to ends of crosspiece using ① Long Screws. Cover spacers and screws with ① Black Plastic Caps.



Peel paper from a S Black Plastic Strip. Position it, with the sticky side down, along the INSIDE top edge of the upper crosspiece as shown, and press down. Note: strip must be even with edge for unit to work properly. Repeat for other side.



Position clamps as shown.



For questions or concerns, please call **Safco Consumer Hot Line 1-800-664-0042** available Monday-Friday 8:00 AM to 4:30 PM (Central Time)

(English-speaking operators)