

**Item Number**  
RAM-VB-160

# RAM No-Drill™ Seat Bases

RAM Mounting Systems

## Vehicle base for the CHEVROLET IMPALA NON-POWERED SEATS (2006-2009)

### SPECIFICATIONS

#### Placement

Between the seat cushion and seat frame on  
passenger side

#### Drilling Required

None - uses existing seat bolts

#### Seat Configuration

Bucket

#### Construction/Finish

Steel/Black Powdercoat

#### Pole or Pedestal

Ordered Separately

#### Dimensions

A = 14.75", B = 8.75"  
Hole Centers = 12.25"

#### Weight

4.8 lbs.

### Features

Installs in minutes with no drilling required  
Won't interfere with levers or factory-installed console

### Notes.

The RAM-VB-160-SW1 will not work with any vehicles that have powered seats. View the (RAM-VB-182-SW1) for Chevrolet Impala's with powered seats.

**RAM Mounting Systems**  
8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
www.rammount.com  
support@rammount.com



Shown In Use



RAM-VB-160



RMR-INS-VB-160

**Item Number** \_\_\_\_\_  
**RAM-VB-160**

# RAM No-Drill™ Seat Bases

RAM Mounting Systems

## Vehicle base for the **CHEVROLET IMPALA NON-POWERED SEATS** (2006-2009)

### INSTALLATION INSTRUCTIONS

Two nuts hold the seat cushion to a u-shaped cross member under the seat. These two nuts need to be loosened to allow placement of the No-Drill™ base. You will need a 15MM socket wrench and 15MM end wrench for this installation.

1. Move the passenger side seat to its most forward position.
2. Using a 15MM socket wrench, remove the two bolts holding the seat frame/track to the floor board. These are located within two round opening.
3. Once removed, move seat to its most rearward position.
4. Using reclining lever, put seat back at a 45 degree angle.
5. Lift seat back upward and pull it backward to release the front seat legs from their slots. You cannot see these but they are located under the plastic trim where the seat frame meets the floor board at front.
6. Once the seat is free from all attachment points, lay it on its back so that the under side of the seat is facing the dash.
7. IMPORTANT! Use caution when laying the seat back as there is a wire harness and connector that goes from the floor board to the seat cushion bottom. Take care so as not to stretch or damage this connection.
8. Locate the two nuts that hold the seat cushion to the u-shaped cross member. Using a 15MM end wrench, loosen these two nuts so that an 1/8" gap is created between the nut and the u-shaped cross member.
9. Slide the no drill base into place with the Tele-Pole platform closest to the center of the vehicle. Align the notches with the seat cushion studs and retighten the nuts.
10. Now that the No-Drill™ base is in place, lift the back of the seat upward and reinsert the front seat legs into their slots.
11. Once aligned and in place, lower the seat back down and move the seat to its most forward position.
12. Use the 15MM socket wrench and reinstall the two seat bolts previously removed and tighten.



**RAM Mounting Systems**  
8410 Dallas Ave S  
Seattle, WA 98108  
Phone: (206) 763-8361  
Fax: (206) 763-9615  
[www.rammount.com](http://www.rammount.com)  
[support@rammount.com](mailto:support@rammount.com)



RMR-INS-VB-160