

Desk Clamp Base VESA:200x100

Step 1

Option A

Option B

Min. 8.0mm

0.3"-2" 8-50mm

Step 2

D

E

2.5mm

Grommet Mount Base

Step 1

0.3"-2" 8-50mm

L

M

N

6mm

Step 2

D

E

2.5mm

Desk Stand

Step 1

I

L

Step 2

D

E

2.5mm

Desk Clamp Base VESA:100x100

Step 1

Option A

Option B

Min. 8.0mm

0.3"-2" 8-50mm

C

5mm

Step 2

D

E

2.5mm

Kensington lock hole

Installation Process VESA:200x100 1~3

Step 3

H

F

D

E

2.5mm

Step 4

A

G

R

E

2.5mm

Step 5

Lock up

Step 6

B

Lock up

Installation Process VESA:100x100 7~12

Step 3

H

F

D

E

2.5mm

Step 4 Single Monitor

A

B

Step 4-1

Step 3

H

F

D

E

2.5mm

Step 4 Dual Monitor

A

B

C

5mm

Step 4-1

Step 5

G

Lock up

Step 6

Do Not Tighten the screws!

Lock up

Step 6-1

Tighten the screws!

Step 5

G

Lock up

Step 6

Do Not Tighten the screws!

Lock up

Step 6-1

Tighten the screws!

Step 5

G

Lock up

Step 6

Do Not Tighten the screws!

Lock up

Step 6-1

Tighten the screws!

Step 6

Do Not Tighten the screws!

Lock up

Step 6-1

Tighten the screws!

Tilt

+/-15°

Cable Management

Swivel

+/-20°

Tilt

+/-20°

Step 7

Do Not Tighten the screws!

Lock up

Step 7-1

Tighten the screws!

Rotate(Pivot)

360°

Torque Adjust

5 mm Allen wrench

Rotate(Pivot)

360°

Cable Management

Torque Adjust

2.5mm Allen wrench

Additional Installation Process (For Extend Model only) 4~6

Step 1

K

Step 2

D

E

2.5mm

Step 5

A

B

H

F

Step 3

A

B

D

H

F

K

Step 4

J

D

K

E

2.5mm

Step 5

A

B

H

F

K

Additional Installation Process (For Extend Model only) 10~12

Step 1

K

Step 2

D

E

2.5mm

Step 5

A

B

H

F

I

Step 3

A

B

D

H

F

K

Step 4

J

D

K

E

2.5mm

Step 5

A

B

H

F

K