















HIGH BACK FABRIC CHAIR

ITEM#:VL630

PARTS LIST

PART #		DESCRIPTION	QTY
A		BACK CUSHION	1PC
B		SEAT CUSHION	1PC
D		SEAT PLATE	1PC
E		ARMREST	2PCS
F		GAS LIFT	1PC
G		TELESCOPIC COVER	1PC
H		NYLON BASE	1PC
I		CASTER	5PCS
J		SCREWS(1-1/4")	2PCS
K		SCREWS(1")	10PCS
L		WASHERS Ø18.8	12PCS
M		ALLEN WRENCH	1PC
N		SCREWS(3/8" 24mm)	1PC
O		WASHERS Ø22	1PC

ATTENTION: Make certain that all screws are fully tightened before using the chair.

