



Assembly Instruction

Carefully unpack all parts and identify them with parts list before attempting to assemble:

IMPORTANT: DO NOT TIGHTEN BOLTS AND SCREWS UNTIL YOU HAVE COMPLETED ASSEMBLY.

1. Install casters (G) (from caster pack) by inserting caster stems into holes in bottom of nylon base (F) and firmly pressing until casters snap into place. If necessary, use the rubber mallet to tap casters until caster snaps into place.
2. Set nylon base assembly upright onto floor. Insert gas lift (E) into center hole of base assembly.
3. Attach the pre-assembled back unit to the seat assembly (B) by using screws (D) with washers (D1)
4. Insert top of gas lift into hole in center of chair control (attached to bottom of seat cushion). Press down firmly on seat cushion to fully seat onto gas lift.
5. Lubricate all moving parts and tighten all bolts every 6 months.

PARTS LIST:

A.	BACK ASSEMBLY	1 PC
B.	SEAT ASSEMBLY.....	1 PC
C.	ARM REST.....	1 PC
D.	SCREWS FOR SEAT AUPPORT(M8*25)	3 PCS
D1.	WASHER	3 PCS
E.	GAS LIFT.....	1 PC
F.	NYLON BASE	1 PC
G.	CASTER.....	5 PCS