



1 Attach Tray(P3) using 4 Screws (A).



2 Lock Legs(P2) in the open position and attach to Board (P-1) using 4 Screws (A) .




Board height may be adjusted in 2 positions.
Board shown in the highest position.

**Should you require
assistance during assembly, please call our
Customer Service Department
Monday - Friday 8 a.m. - 5 p.m.
Central Standard Time
Toll-Free Customer Service
1-800-749-2258**

Parts List

P1		Markerboard	1 EA
P2		Leg Frame	1 EA
P3		Tray	1 EA

Hardware List

A		Screw M4x25mm	8 EA
---	---	---------------	------

#745 - 11/10/08

BEST-RITE®
"It's A Better Board"

**#745
Presentation Easel**

