


#89863 Flipper-72 72"Conference Table



Assembly Instructions

Flipper-72

72"Conference Table

Part Drawing	Description	Qty	Part Drawing Descrip	otion Qty
P1 %	Top Platform	1 EA	P8 Lower C	rossbrace 1 EA
P2	Left Leg	1 EA	Deg Upper C	rossbrace 1 EA
	3		Hardware	List
P3	Right Leg (with Spring)	1 EA	A 9/16" Sock A1 9/16" Sock	
P4	Metal Stability Pan	el 1EA	B 6 1-7/8" Sock	
			C Plastic Gror D 2" Locking (
P5	Welded Rod Assen	nbly 1 EA	E Allen Wrenc	
P6	Left Side Handle	1 EA	F Caster Wren	nch 1 EA
P7	Right Side Handle	1 EA	We recommend that yo unit on a ta	

Missing Parts or UPS Damaged Parts

For Your Convenience you can EMAIL us at

<u>furniture@baltinc.com</u> 24HOURS 7 DAYS A WEEK Should you require assistance during assembly, please call our Customer Service Department Monday - Friday 8 a.m. - 5 p.m.

Central Standard Time 1-800-749-2258


Do not use unless all screws are tight. At least every six months, check all screws to be sure they are tight. If parts are missing, broken, damaged, or worn, stop use of the product until repairs are made by your dealer using factory authorized parts.


Flipper-72 Assembly Diagram



READ THROUGH INSTRUCTIONS FROM BEGINNING TO END BEFORE STARTING TO ASSEMBLE UNIT.

- 1.) Identify and Separate all the Parts and Hardware.
- 2.) Slide the Right Side Handle (P7) Through the Right Leg (P-3) and into the Welded Rod (P5) as shown in illustration #1. Rotate Right Side Handle (P7) until holes are aligned (See illustration#1). Secure using 1 Screw (A).
- 3.) Slide the Left Side Handle (P6) Through the Left Leg (P-2) and into the Welded Rod (P5) as shown in illustration #1. Rotate Left Side Handle (P6) until holes are aligned (See illustration #1). Secure using 1 Screw (A).






- 7.) Place the Top Platform (P1) with the insert nuts facing up. Attach Right Leg (P-3) and Left Leg (P2) using 4 each (B) screws as shown in illustration #4. (Finger tighten only)
- 8.) Attach 4 each (D) Locking Casters to the front and back of the Right Leg (P-3) and Left Leg (P2). Tighten Casters using Caster Wrench (F).

(Tighten all screws using Allen Wrench (E).)





(B) Screw M6 X 1-7/8" For Scale only



- 9.) To install Grommet (C), separate parts and press Grommet Sleeve in rectangular openings in Top Platform (P1) as shown in illustration #5.
- 10.) Snap 2 plastic Caps over top of Sleeve as shown in illustration #5.
- 11.) Repeat Steps 9 & 10 for second Grommet (C).

Grommet(D) installation Illustration #5





The Balt product you have purchased is guaranteed against material and workmanship defects. This guarantee extends 1 year from date of purchase. Should this product fail to function satisfactorily under normal use due to defect or imperfection, the defective part or product will be replaced. Damage caused by common carriers during shipment is not included in this guarantee.

This guarantee sets forth all applicable guarantees and remedies. No other warranty, expressed or implied shall apply. Failure to follow instructions found in Important Information Section of Owner Sheet shall void the guarantee. Consequential or incidental damages and or costs are not refundable.