



Bowling Ball with Locking Wrist Strap

for Wii™



Turn every Wii bowling experience into a perfect 300 with the Bowling Ball for Wii. This ultra-realistic accessory, allows you to mimic all the critical motions a 'striking' performance requires. This Wii peripheral is the first of its kind to be fashioned after an authentic bowling ball, turning your wii-mote into the optimum performance-enhancing accessory!

Pack includes:


- (1) Bowling ball Wii remote container with tightening wrist strap
- (6) Removable bowling ball finger plugs

Compatible with the following Wii games:

- Wii™ Sports (Bowling)
- Brunswick Pro Bowling
- Ten Pin Alley 2
- AMF Bowling: World Lanes
- AMF Bowling: Pinbusters!
- Wii™ Sports Resort

And any other Wii Bowling games that require the Wii Remote

Instructions: To operate simply press the release button to open the ball in half, place the Wii remote inside (even with a Wii Motion Plus adapter connected) and close the ball. Once the remote is set inside, plug the three holes with your fingers as you would an actual bowling ball. Lastly, make sure to wear the wrist strap securely around your wrist, this will prevent the ball from accidentally flying out of your hand, and you are ready to bowl virtual strikes like a Pro!



	Quantity	Width	Height	Depth	Weight	UPC Barcode
Packaging	1	8	8	8	1.8 lbs	6 56777 00216 9
Master	4	16.5	9	16.5	10.7 lbs	10656777002166