



SINGER® | Signature™

Model 9340



Feature	Benefit
340 Built-In Stitches	Basic, stretch, decorative, buttonholes, alphanumeric
10 Fully Automatic 1-Step Buttonholes	A simple, one-step simple process that creates balanced buttonholes.
Removable Stitch Chart	A handy, removable stitch chart easily attaches to the handle of the machine to provide visual references for each stitch.
Automatic Electronic Thread Cutter	Press the thread cutter button and the machine automatically trims the top and bobbin threads when you are done sewing.
Automatic Needle Threader	Sewing's biggest timesaver! This feature makes threading the eye of the needle quick and easy.
Automatic Stitch Length & Width	Optimal settings for stitch length and width are automatically set, but can be overridden for more personalized sewing.
Extension Table Included	The included optional extension table provides a larger working area, an essential for quilting, home decor sewing or when working with a larger project.
Programmable Needle Up/Down	The needle can be programmed to stop in the highest <i>up</i> position, making it easier to remove fabric from the machine. The needle can also be programmed to stop in the <i>down</i> position which is ideal for pivoting, appliquing and quilting.
Top Drop-In Bobbin System	The bobbin loads from the top, so it is easy to insert the bobbin. Simply follow the illustrations pictured on the machine. The thread blade trims the excess bobbin thread. The clear cover makes it easy to monitor the bobbin thread supply.



SINGER | Signature™

Model 9340



Feature	Benefit
2 Built-In Alphabets	Personalize projects by adding a monogram, name or phrase with the built-in block or script style numbers and alphabets, both available in upper and lower case, stitched at 5mm stitch width.
Mirror Imaging and Elongation Functions	With just a touch of a button selected stitches can be mirrored imaged, adding even more stitch variety. Press the Elongation button and selected stitches can be made up to 5 times longer.
Large Back-Lit LCD Screen	Provides clear and easy viewing of stitch functions including stitch length, stitch width, tension settings, recommended presser foot, needle up/down position and more!
Electronic Auto Pilot	Unplug the foot control, press the Start button and the machine sews. You are still in complete control over the speed - just slide the Speed Lever to the desired speed.
Four Memory Modules	Four Memory Modules each hold up to 20 entries. Place names, simple phrases and decorative stitch sequences in each of these four modules, then retrieve them anytime, even if the machine has been turned off.
Editing Capabilities	It's easy to change or replace your selections within the Modules.
Pattern Override Memory	Select a pattern, override the width and/or length, place the stitch in a Memory Module, and the machine will remember those changes for future use.
Drop Feed	A conveniently located lever lowers the feed dogs for free-motion embroidery, monograms and button sewing.
Heavy Duty Metal Frame	The internal rigid support holds all the mechanisms in perfect alignment for skip-free sewing and overall durability.



SINGER® | Signature™

Model 9340



Feature	Benefit
Horizontal Threading	Quality stitches begin with proper thread delivery. Placing the thread spool in the horizontal position allows for the thread to feed more evenly, reducing poor stitch formation and thread breakage.
Center Zigzag Taper	When tapering with the zigzag stitch, the stitch tapers to the center, not the left or right. This feature is especially valuable when appliquing, because it provides a more attractive look when tapering into or out from a point.
Automatic Presser Foot Pressure Control	The amount of pressure exerted on the fabric by the presser foot against the feed dogs is adjusted automatically. Sew from the lightest weight tricots to the heaviest denim, without making presser foot pressure adjustments.
Automatic Tension	This system ensures stable stitch quality regardless of fabric type.
Automatic Locking Stitch Function	Tie-off decorative and utility stitches with just a push of the Auto Lock button. Three tiny tacking stitches reinforce patterns and stitches to prevent unraveling.
Automatic Single Stitch Function	On select stitches, the Auto Lock button sews a single unit of the stitch and three tiny tacking stitches, allowing for complete creativity.
Electronic Twin Needle Control	Select stitches automatically adjust for twin needle sewing with just the touch of a button.
Error Warning	An audible warning alerts the sewer if something is incorrect. The audible warning can be deactivated, if desired.
7-Segment Feeding System	This is a specially designed feed dog that ensures that the fabric is picked up and supported from the front of the presser foot to the rear. This provides for much more accurate feeding of the fabric.
Box Feed	This is a function that moves the feed dogs in a box motion, rather than the historic arc motion. Box motion assures perfect feeding throughout the entire feed process, as the feed dogs are always in perfect and equal contact with the fabric and presser foot.



SINGER | Signature™

Model 9340



Feature	Benefit
Extra-High Presser Foot Lifter	Advantageous when placing multiple layers or bulky fabric under the presser foot.
7mm Stitch Width	Select stitches can be set for a maximum width of 7mm creating attractive satin and decorative stitches.
Free Arm	Provides professional results and easy access to cuffs, collars, pant hems and other difficult-to-reach areas.
Automatic Reverse	Push the conveniently located Automatic Reverse Button to sew in reverse and reinforce the stitch.
Sewing Speed	With a maximum sewing speed of 750 stitches-per-minute, projects can be sewn quickly.
On Board Storage	Accessories can be conveniently stored in the removable sewing table.
Snap-On Presser Feet	Easily change most presser feet without use of a screwdriver.
Standard Accessories	All-Purpose Foot, Buttonhole Foot, Button Sewing Foot, Blind Hem Foot, Satin Stitch Foot, Zipper Foot, Overcasting Foot, Screwdrivers (2), Bobbins (4), Spool caps (2), Seam Ripper / Lint Brush, Auxiliary Spool Pin, Quilting Guide, Needles
Value Added Accessories	Narrow Rolled Hem Foot, Cording Foot, Gathering Foot, Darning / Freehand Embroidery Foot, Even Feed / Walking Foot, Sew & Serge / Side Cutter, Roller Foot, Straight Stitch Foot, Open Toe Foot, 1/4" Piecing Foot, Invisible Zipper Foot, Non-Stick Foot, Piping Foot, Narrow Braid Cord Foot with Guide
Warranty	Limited 25-year warranty including 5-year electronic components and 1-year adjustments




SINGER | Signature™


Model 9340




A Group Patterns-10 (Direct Patterns)



B Group Patterns-50




C Group Patterns-96





SINGER® | Signature™

Model 9340



● Alphabets

Block style

01 02 03 04 05 06 07 08 09 10
1 2 3 4 5 6 7 8 9 0

11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62
a b c d e f g h i j k l m n o p q r s t u v w x y z

63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88
Ä Å Æ Ñ Ö Ø Ç Ü ä å æ è é ê ñ ö ø ï ç ü û ß &

89 90 91 92 93 94 95 96 97
? ! ' , - ()

Script style

01 02 03 04 05 06 07 08 09 10
1 2 3 4 5 6 7 8 9 0

11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62
a b c d e f g h i j k l m n o p q r s t u v w x y z

63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88
Å Á Æ Ñ Ö Ø Ç Ü ä à á è é è ñ ö ø ø i ç ü ù á ß &

89 90 91 92 93 94 95 96 97
? ! , , . - ()