

Russound®

**AirGo**   
**Outdoor** <sup>TM</sup>

**Amplified Outdoor Speaker  
with AirPort Express® Dock**  
**Owners Manual**



**Outdoor Sound Station**

## Product Description

The AirGo™ Outdoor Sound System is a portable amplifier/speaker dock for an Apple® AirPort Express. With the AirGo Outdoor you can stream music from an AirPlay® compatible device via the Apple AirPort Express.

Since the Apple AirPort Express also has the ability to act as a Wi-Fi repeater, you now have the ability to have an outdoor Wi-Fi hotspot and listen to music at the same time<sup>1</sup>. A special pocket within the unit, the APX, protects the AirPort Express from the elements.


The AirGo Outdoor is a high performance, quality outdoor sound system. A single large stereo speaker provides excellent sound quality and a wide sound stage.

Place it on the deck near the house to cover the deck and backyard while having a cookout. Put it on the driveway near the garage when washing the car. Place it on the ground near the front door during seasonal events to play music and sound effects of your choice to match the occasion!

The AirGo Outdoor is easy and fun to use. With the Apple AirPort Express installed, stream music from your iPhone®, iPad®, Mac®, iTunes® or PC<sup>2</sup> and surf the net from your Internet appliance at the same time. The AirGo Outdoor is fun, sounds great and brings hanging outside to another level.

1 Dependant upon AirPort Express configuration

2 Requires iTunes or AirFoil



## Configuration of the AirPort Express®

The AirPort Express will need to be configured before it is installed in the APX Pocket. Please refer to the AirPort Express installation manual for complete directions.

## Removing the APX cover

To begin, unravel the AirGo Outdoor's main power cord and remove the APX cover. Use a standard Phillips screwdriver to remove the two Phillips screws that secure the APX cover in place. Don't worry about losing the screws, they're captive screws so they won't fall out. Be careful not to dislodge the gasket that is fitted to the APX cover. It is important that it be intact when reinstalling the cover to keep moisture out of the APX Pocket. See **figure 2**




Figure 2

## Installing the AirPort Express® into the AirGo Outdoor

1. Remove the detachable electrical prongs from the AirPort Express by sliding the Power Adapter off of the AirPort Express. See **Figure 3**
2. Take the 3.5mm audio plug located in the APX Pocket and insert it into the Audio Output Jack of the AirPort Express. See **Figures 4 & 5**
3. Take the power cord from the APX Pocket and insert it into the Power Input jack of the AirPort Express. See **Figure 5**
4. Carefully place the AirPort Express and all of the connected wires into the APX Pocket.


**NOTE:** Make sure the APX cover is seated securely in place and fastened tightly in place by the philips screws to ensure a proper seal of the compartment.

5. Place the cover back onto the APX Pocket and tighten the screws until they are snug.

6. Plug the Main Power Cord into a grounded electrical outlet. Turn the Power Switch ON and wait for the AirPort Express to boot up.

**NOTE:** The status of the AirPort Express and its booting process can be observed at the Status Light window located on the AirPort Express Pocket Cover. See **Figure 2**


**NOTE 2:** Never plug the AirGo Outdoor into an ungrounded electrical outlet, ungrounded electrical cord or use a ground lifting adapter to remove the safety ground.




**Figure 3**



**Figure 4**



**Figure 5.** Installed AirPort Express®



Your AirGo Outdoor is shipped with the speaker in the downward position. For optimal sound dispersion, adjust the speaker to the upward position before use.

**Figure 6.** Speaker angle adjustment

### Speaker Angle Adjustment

The AirGo Outdoor Speaker is shipped with the speaker in the downward position. For optimal sound dispersion, adjust the speaker to the upward position before use by grasping the speaker on the sides and tilting it upward. See **Figure 6**

### Taking Care of Your AirGo™ Outdoor

The AirGo Outdoor is made of durable materials that need very little care. All we recommend is an occasional wiping with a soft, damp cloth. Do not use any harsh detergents, chemical solvents, or abrasive materials. Also, do not spray water or other liquids into the grilles.

While the AirGo Outdoor can be left out in the rain it is recommended to bring the product inside when not in use or to expose it to prolonged inclement weather. This will keep the product clean, maximizing its longevity and performance.

## Specifications

### Loudspeaker type:

Passive two-way, dual input

US: 100-130VAC, 60Hz, 72W MAX

### Dimensions:

Width: 12.9" (32.8cm)

Length: 10.2" (25.9cm)

Height: 12.6" (32.1cm)

**Weight:** 16.25 lbs, 7.37Kg

## FCC

This device complies with part 15 of the FCC rules.  
Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.



This product meets our  
highest standards for  
eco-friendly products.  
**For more information  
visit: [AirGo.Russound.com](http://AirGo.Russound.com)**

## Warranty

The Russound AirGo Outdoor Sound System has a 90 days warranty against defects in materials and workmanship. During the warranty period, Russound will replace any defective part and correct any defect in workmanship without charge for either parts or labor.

Russound may replace returned speakers with a product of equal value and performance. In such cases, some modifications to the mounting may be necessary and are not Russound's responsibility.

For this warranty to apply, the unit must be utilized according to its written instructions. If repairs are necessary, they must be performed by Russound. The unit must be returned to Russound at the owner's expense and with prior written permission. Proof of purchase must accompany all claims. Accidental damage and shipping damage are not considered defects, nor is damage resulting from abuse or from servicing performed by an agency or person not specifically authorized in writing by Russound.

This warranty does not cover:

- Damage caused by abuse, accident, misuse, negligence, or improper operation or installation.
- Products that have been altered or modified.
- Any product whose identifying number or serial number has been altered, defaced, or removed.
- Normal wear and maintenance.

To return for repairs, the unit must be shipped to Russound at the owner's expense, along with a note explaining the nature of service required. Be sure to pack the speaker in the original box or a corrugated container with at least 3 inches of resilient material to protect the unit from damage in transit.

Before returning a speaker for repair, call Russound at 603.659.5170 for a Return Authorization number. Write the RA number on the shipping label and ship to: Russound, ATTN: Service, 5 Forbes Road, Newmarket NH 03857.

Russound sells products only through authorized channels to ensure that customers obtain proper support and service. Any Russound product purchased from an unauthorized dealer or source, will not be honored or serviced under existing Russound warranty policy. Any sale of products by an unauthorized source or other manner not authorized by Russound shall void the warranty on the applicable product.

**REGISTER ONLINE TODAY AT: [AirGo.Russound.com](http://AirGo.Russound.com)**



Scan this code  
to go directly  
to the page

# AirGo

Outdoor



Russound 5 Forbes Road, Newmarket, NH 03857, USA

Ph. (855) MYAIRGO Fx. 603.659.5388

[AirGo.Russound.com](http://AirGo.Russound.com)

©2011 Russound. All rights reserved. All trademarks are property of their respective owners. Specifications are subject to change without notice. Russound is not responsible for typographical errors or omissions.

PATENT PENDING

AirPlay, AirPort Express, iPad, iPhone, iPod touch, iTunes and Mac are trademarks of Apple Inc. MANUAL r8