


2-in-1 Kitchen Mount Stand


for 7–13 Inch Tablets

PAD-KMS

INSTRUCTION MANUAL

Thank you for choosing CTA Digital's product. We hope that you will enjoy using it. Please follow the guidelines and instructions as laid out in this instruction manual.







Product Component		
Item	Description	Qty.
1	iPKD Stand	1
2	iPKD Mount Base	2
3	Universal Holder	1
Hardware Kit		
A-A	3mm Allen Wrench	1
A-B	4mm Allen Wrench	1
A-C	5mm Allen Wrench	1
B-A	Ø5*1" Wood Screw	2
B-B	White Anchor	2
C-A	Ø5*19mm Wood Screw	2

Special Function			
Item	Description		
А	Attachment Button		
В	iPKD Legs		
С	Attachment Socket		
D	Button for Vertical Extension		
Е	Up Bracket		
F	Down Bracket		

Diagram of Operable Parts






XPlease adjust the tightness of the joints when they are loose after use for a while.

Use "A-A" + "A-B" to adjust the tightness of (I) & (J).

Use "A-B" + "A-C" to adjust (K).


Use "A-B" to adjust (L).

(Please remove $\textcircled{G} \ \& \ \textcircled{H} \$ to adjust $\textcircled{J} \ \& \ \textcircled{K} \$ and install them back on their positions when done.)




Mount Base Installation:

- 1. Drill hole of 7*30mm and then push B-B into wall. Use B-A to screw (2).
- \times If to install 2 on wood wall or cabinet, drill hole of \emptyset 4*20mm. Use C-A instead of B-A. There is no need to use B-B.



2. Fold B and insert it into 2 .

* Note: After attaching, please check if these two items are fastened well for preventing tablet sliding and damaged.




Mount Base under cabinet

Note for Table-top Stand


Forward position:

Do not let tablet exceed the front end of
B, plane
in to prevent
from toppling and damaging tablet.





Backward position:


When in backward position, do not let 1 exceed plane B to prevent 1 from topping backwardly and damaging tablet.





Dimension of Folded Stand












Attachment Description 1 : Press D and stretch F till larger than the length of tablet. Then release D .

Attachment Description 3: After tablet is fastened, release (D).


* Note: After attaching, please check if these two items are fastened well for preventing tablet sliding and damaged.



Attachment Description 4 : Press (A) to take off or attach (C) .

* Note: After attaching, please check if these two items are fastened well for preventing tablet sliding and damaged.





Attachment Description 5: After attaching, turn tablet clockwise or anti-clockwise to get the best view.