

HL7 Instructions:

Battery Installation

- The HL7 uses three AAA alkaline batteries.
- The batteries are housed in the rear of the headlamp.
- To access the battery compartment, pull the elastic head band slightly away from the battery pack.
- Remove the rubber battery case cover by grasping the tab at the top of cover and pulling it away from the battery pack.
- Insert the batteries in the direction indicated inside the battery pack.
- Replace rubber battery case cover, making sure that the cover is paced evenly over the rim of the case.

Head strap adjustment

- To adjust the HL7 to fit your head, slide the buckle on left side of the head strap. It may be necessary to slide the head of the light and battery pack on the head strap to center the light once the head band is adjusted to the proper size.

Light Operation

- To turn on the light, depress the red switch on top of the light.
- To turn off the light, depress the red switch on top of the light.
- To adjust the brightness, slide the VLT (Variable Light Technology) Dimmer on top of the battery pack. Move to the right to increase the brightness. Move the switch to the left to decrease the brightness.

Beam Position and Focus Adjustment

- This headlamp is equipped with COAST's Pure Beam™ Focusing Optic allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot™ beam for long distance illumination.
- To adjust the beam into the broad, flood light mode, when the light is on your head, turn the Focus Ring around the lens of the light to your right (counter clockwise when looking at the front of the light.) In the flood mode, the COAST logo on the Focus Ring around the lens will be at the top, lined up with the red on/off switch.
- To adjust the beam into the Bulls-Eye Spot™ mode, when wearing the light, turn the Focus Ring around the lens of the light to your left (counterclockwise when looking at the front of the light.)
- The beam can be used in any position, from full flood beam to spot beam.
- The hinged beam adjustment allows you to tilt the beam of light down into position to illuminate objects directly in front of you or in your hands. To adjust, grasp the head of the light at the top and bottom between your thumb and index finger. Pull the red button away from your head and down.

Helmet Clips

- The boxed version of the HL7 includes helmet clips for use with hard hat style safety helmets.
- Attach the clips to the strap of the headlamp, evenly spaced with two on each side, one each at the 2:30, 4:30, 7:30 and 10:30 positions.
- Attach the clips to the rim of the helmet.