



SoundPODS™

User Manual

www.bluetigerusa.com | 1-800-935-1165

Thank you for purchasing SoundPODS™ by Blue Tiger®. Please review the manual before using this product to ensure your best experience.


Product Features

SoundPODS™ are designed to allow you to listen to music from your phone or Bluetooth® enabled computer or MP3 player. When connected to your phone using Bluetooth®, the SoundPOD will also act as a speakerphone.

The SoundPOD delivers high-quality sound in a small form factor. Our engineers made speaker performance a top priority. You can hear and *feel* the difference in quality!

Getting Familiar with SoundPODS™

SoundPODS™ are designed for simple, hassle-free operation. Below, you will find a diagram that will help you get acquainted with SoundPODS™ design and operation.



Battery Care

Before using your SoundPOD the first time, charge the POD for at least 3 hours.

At maximum volume using Mp3 mode, the SoundPOD can play for up to 5 hours. At 30% volume the battery could last for up to 10 hours.

However, some factors, including Bluetooth mode, will decrease the total amount of usage time available.

Bluetooth Pairing Instructions

1. Make certain your SoundPOD is in the "Off" position.
2. Switch the OFF toggle all the way to the right for Bluetooth. Upon activating Bluetooth, the LED light will flash to blue for a few seconds and then begin flashing blue and red.
3. Follow the operating instructions for your phone to allow your device to search for a new Bluetooth connection.
4. Select "soundPODS" on your Bluetooth device list on your phone and when asked, select "Yes" to confirm the connection.
5. If a PIN, Passkey, or Passcode is required, enter "0000."

MicroSD Card Playback

1. Save all .mp3 or .wav to the microSD root directory. (i.e.- if the card is recognized as "F:" then the files should read like this:
"F:/songfile.wav"
2. After inserting the microSD card, switch the POD to Mp3 mode.
3. Press play. Songs will play in the order in which they are stored on the card. You may skip forward or rewind to the previous track using the multi-function wheel.

Using the Auxiliary Cable

You can plug your SoundPOD into just about any device that has a 3.5mm headphone jack. Just plug it in and switch the POD to Mp3 mode. All music functions will be controlled by the device, not the POD.

Please note, you can adjust the volume from both the POD and the device. For maximum volume, you must turn the volume up all the way on both devices.

Operation

Multi-Function Wheel:

+/>> Short press skips to the next song. Long press increases volume. Does not work in Aux mode.

-/<< Short press goes to previous song. Long press decreases volume. Does not work in Aux mode.

▶ || Bluetooth Mode: and will answer and end a phone call when using it as a speaker phone.

MP3/SD Mode: Short press plays or pauses your music.

Understanding the LED Indicator

Green flash: Speaker is in SD/MP3 mode

Green solid: SD/MP3 pause or indicates that the Aux cable is active.

Blue flash: Indicates Bluetooth mode

Red and blue alternating: Indicates pairing mode

Red solid: indicates charging (turns off when fully charged)

Red flash: Low battery indicator

1 Year Manufacturer Warranty

Your SoundPOD is covered by a 1 year manufacturer warranty. See website for details.

Check out these other products from Blue Tiger! Check with your retailer for availability or go to bluetigerusa.com.



**SoundTRAX Bluetooth
Stereo Headphones**

**SoundPODS
in White**