


Custom Flex Wall Mount

PAD-CFWM

INSTRUCTION - MANUAL


CONTENTS:




INSTRUCTIONS:

1. Attaching Foam Pad to Tablet Holder

Select the appropriate foam pad (D) according to the thickness of your tablet (or tablet in its case), then press adhesive side into center of the tablet holder.




Foam Pad Thickness:	Tablet Thickness:
1mm	0.67-1.06in / 17-27mm
5mm	0.51- 0.91in / 13-23mm
10mm	0.31- 0.71in / 8-18mm



Use the table above to determine the appropiate foam pad (D) to use with your tablet.


Note: sizes refer to total

tablet size with or without






3. Inserting Tablet to Holder



3a. Press quick release button on side of tablet holder (A) to release the adjustable end.




3b. Insert tablet corner against the spring arm. Push adjustable arm down against opposite corner (A). Be sure it is as snug as possible. Be sure to not place on the corner where camera would be on tablet or else it will block.

Adjusting Flex Arm

Twist the screw knob of the arms counter-clockwise to release the connection. Adjust the arms to your preferred position and then tighten the screw knob clockwise.

Adjusting Tablet Holder



Tablet holder rotates 360° for custom viewing angles.

**WARNING - DO NOT attempt to adjust, tilt, or rotate any ball socket joints while it is fully tightened. Any such action will result in possible damage and loss of integrity of product functioning at full capacity. Manufacturer will not be responsible for any such actions by any person.