
Universal Case-Compatible

Security Kiosk Stand for 7-13 inch tablets



PAD-UCCSK

Contents

Stand x 1



Manual x 1





Cable x 1

Screws x 4 (4.2x25mm)




Foam Pad x 4 kinds







Adjustable Angle






Install the Tablet PC






2. Adjust the frame to fit your Tablet PC.


Lock the Security Frame




1. Loop the cable around a secure object.



Unlock the Security Frame




1. Insert the key into the lock button to release the cable.



2. Take out cable and key to unlock.

Fixed Base



Screws included if need to fix on wooden surface.