

MAG Series

LCD Monitor

MAG 275CQRF-QD (3CD2) MAG 325CQRF-QD (3DC6)

User Guide

Contents

Getting Started	3
Package Contents	3
Installing the Monitor Stand	4
Adjusting the Monitor	5
Monitor Overview	7
Connecting the Monitor to PC	10
OSD Setup	11
Navi Key	11
Hot Key	11
OSD Menus	12
Gaming	12
Professional	15
Image	16
Input Source	16
Navi Key	17
Setting	17
Specifications	19
Preset Display Modes	21
Troubleshooting	23
Safety Instructions	24
TÜV Rheinland Certification	26
Regulatory Notices	27

Revision

V1.1, 2023/06

Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents

Monitor	MAG 275CQRF-QD		
	MAG 325CQRF-QD		
Documentation	Quick Start Guide		
	Stand with Screw(s)		
	Stand Base with Screw(s)		
Accessories	Screw(s) for Wall Mount Bracket(s)		
	Power Cord		
	External Power Supply		
	DisplayPort Cable (Optional)		
Cables	Premium High Speed HDMI™ Cable (Optional)		
	USB Upstream Cable (Optional) (for USB Type-B Upstream Port)		




Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stand

- 1. Leave the monitor in its protective foam packaging. Align the stand bracket to the monitor groove.
- 2. Tighten the stand bracket with screws.
- **3.** Connect the base to the stand and tighten the base screw to secure the base.
- 4. Make sure the stand assembly is properly installed before setting the monitor upright.



Important

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for proper wall mount kit.
- This product comes with NO protective film to be removed by the user! Any mechanical damages to the product including removal of the polarizing film may affect the warranty!



Adjusting the Monitor


This monitor is designed to maximize your viewing comfort with its adjustment capabilities.




/ Important


Avoid touching the display panel when adjusting the monitor.


MAG 275CQRF-QD






MAG 325CQRF-QD





Monitor Overview



	Power LED
	Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange when the monitor is in Stand-by mode.
2	Macro Key
9	To activate OSD Application.
3	Navi Key
4	Power Button
5	Cable Routing Hole
6	Kensington Lock
7	Power Jack
8	DisplayPort
	Supports 2560x1440@170Hz as specified in DisplayPort 1.2a.
9	HDMI™ Connector HDMI ™
	Supports HDMI™ CEC, 2560x1440@144Hz as specified in HDMI™ 2.0b.
10	HDMI™ Connector H⊃mi [™]
	Supports 2560x1440@144Hz as specified in HDMI™ 2.0b.
0	USB Type-C Port
_	This port supports DisplayPort Alternate (DP Alt) Mode and up to 5V/3A (15W) power delivery.
	1mportant
	Your USB-C signal source and cable must support DisplayPort Alternate Mode to enable video output to the monitor.
12	Headphone Jack




USB 2.0 Type-B Upstream Port

For USB Upstream Cable.



Check the package for USB Upstream Cable and connect it to the PC and monitor. Once this cable is connected, the USB Type-A Downstream Ports on the monitor will be ready for use.






USB 2.0 Type-A Port

Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- **3.** Assemble the external power supply & power cord. (Figure A)
- **4.** Connect the external power supply to the monitor power jack. (Figure B)
- **5.** Plug the power cord into the electrical outlet. (Figure C)
- **6.** Turn on the monitor. (Figure D)
- 7. Power on the computer and the monitor will auto detect the signal source.



OSD Setup

This chapter provides you with essential information on OSD Setup.




Important

All information is subject to change without prior notice.

Navi Key

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



Up/ Down/ Left/ Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus


Press (OK):

- launching the On-Screen Display (OSD)
- entering submenus
- · confirming a selection or setting

Hot Key

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

OSD Menus





1mportant

The following settings will be grayed out when HDR signals are received:

- Night Vision
- MPRT
- Low Blue Light
- HDCR

- Brightness
- Contrast
- Color Temperature

Gaming

1st Level Menu	2nd/3rd Level Menu	Description
Game Mode	Premium Color	Use Up or Down Button to select and
	User	preview mode effects. • Press the OK Button to confirm and
	FPS	apply your mode type.
	Racing	
	RTS	
	RPG	

1st Level Menu	2nd/3rd Level Menu		Description	
Night Vision	OFF Normal		This function optimizes background brightness and is recommended for FPS games.	
	Strong			
	Strongest			
	A.I.			
Response Time	Normal		Setting to Fastes	
	Fast		shortest respons improve blurred	e time and help images when playing
	Fastest		very fast games.	
MPRT	OFF ON		Activating MPRT will affect:	
			Affected Function	Function Status
			» Brightness » Response Time	Unable to select
			» HDCR » Adaptive-Sync Set to OF	Set to OFF
			MPRT is available rate is over 85 Hz	
Refresh Rate	Location	Left Top	Location is adjustable in OSD Men	
	Right		Press the OK Button to confirm and apply your Refresh Rate Location.	
	Left	Left Bottom	This monitor follows and works at t	
	Right Bottom		Operating System's Refresh Rate.	's preset Screen
		Customize		
	OFF			
	ON			

1st Level Menu	2nd/3rd L	evel Menu	Description
Alarm Clock	OFF 15:00 30:00 45:00 60:00	Left Top Right Top Left Bottom Right Bottom Customize 00:01 ~ 99:59	After setting the time, press the OK Button to activate the timer. Users have to manually restore their preset Alarm Clock after any AC power loss and reconnection.
KVM	Auto Upstream Type C		 Auto allows the monitor to automatically switch between USB input sources, such as keyboards, mice or other USB devices. Users can also designate Upstream port or USB Type-C as the only USB signal source.
Smart Crosshair	Icon	None [+]!!!	 Through Al algorithm, this function enhances the visibility of in-game crosshair. Users can select the color and position of the crosshair.
	Color Position Reset	White Red Auto	
Adaptive-Sync	OFF ON		Adaptive-Sync prevents screen tearing. Activating Adaptive-Sync will affect: Affected Function Function Status Bet to OFF

Professional

1st Level Menu	2nd Level Menu	Description	
Pro Mode	Eco User Anti-Blue Movie Office sRGB Adobe RGB Display P3	Use Up or Down preview mode ef	Button to select and fects. tton to confirm and apply
Low Blue Light	OFF ON	blue light. When adjusts the scree more yellow glov • When Pro Mode	rotects your eyes against enabled, Low Blue Light en color temperature to a v. is set to Anti-Blue, it is able Low Blue Light.
HDCR	OFF ON	HDCR enhances increasing the co Activating HDCR Affected Function Brightness MPRT	ontrast of images.
MPRT	OFF	Activating MPRT	will affect:
	ON	Affected Function	Function Status
		» Brightness » Response Time » HDCR » Adaptive-Sync • MPRT is availabl	Unable to select Set to OFF e when the refresh rate is
		over 85 Hz.	
Image Enhancement	OFF		nent enhances image
Limancement	Weak	edges to improve their acutance.	
	Medium		
	Strong		
	Strongest		

Image

1st Level Menu	2nd/3rd Level Menu		Description	
Brightness	0-100		Properly adjust E according to the lighting.	
Contrast	0-100		 Properly adjust (your eyes. 	Contrast to relax
Sharpness	0-5		Sharpness improductails of images	,
Color	Cool		Use Up or Down Button to select	
Temperature	Normal		and preview mode effects.	
	Warm		Press the OK Button to confirm and apply your mode type.	
	Customization R (0-100) G (0-100)		Users can adjust Color	
			Temperature in Customization mode.	Customization
		B (0-100)		
Screen Size	Auto		Users can adjust Screen Size in	
	4:3		any mode, any resolution and any screen refresh rate.	
	16:9		Activating Screen Size 16:10 will	
	16:10		affect:	
			Affected Function	Function Status
			» DP Overclocking	Unable to select

Input Source

1st Level Menu	2nd Level Menu	Description
HDMI™1		Users can adjust Input Source in any mode.
HDMI™2		
DP		
Type C		
Auto Scan	OFF	Users can use the Navi Key to select Input
	ON	Source at below status:
		 While "Auto Scan" is set to "OFF" with the monitor at power saving mode;
		While "No Signal" message box is shown on the monitor.

Navi Key

1st Level Menu	2nd Level Menu	Description
Up	OFF	All Navi Key items can be adjusted via OSD
Down	Brightness	Menus.
Left	Game Mode	
Right	Smart Crosshair	
	Alarm Clock	
	Input Source	
	Refresh Rate	
	Info. On Screen	
	Night Vision	
	KVM	

Setting

1st Level Menu	2nd Level Menu	Description
Language	繁體中文	Users have to press the OK Button to
	English	confirm and apply the Language setting.
	Français	Language is an independent setting. Users' own language setting will override
	Deutsch	the factory. When users set Reset to Yes, Language will not be changed.
	Italiano	Language with not be enanged.
	Español	
	한국어	
	日本語	
	Русский	
	Português	
	简体中文	
	Bahasa Indonesia	
	Türkçe	
	(More languages coming soon)	
Transparency	0~5	Users can adjust Transparency in any mode.

1st Level Menu	2nd Level Menu	Description
OSD Time Out	5~30s	Users can adjust OSD Time Out in any mode.
RGB LED	OFF	Users can adjust RGB LED to ON or OFF.
	ON	
Power Button	OFF	When set to OFF, users can press the power button to turn off the monitor.
	Standby	When set to Standby, users can press the power button to turn off the panel and backlight.
Info. On Screen	OFF	The information of the monitor status will
	ON	be shown on the right side of the screen.
DP OverClocking	OFF	To overclock the monitor refresh rate,
	ON	users have to set DP OverClocking to ON.
HDMI™ CEC	OFF	HDMI™ CEC (Consumer Electronics
	ON	Control) supports Sony PlayStation®, Nintendo® Switch™, Xbox Series X S consoles and various audio-visual devices that are CEC-capable.
		If HDMI™ CEC is set to ON:
		The monitor will automatically power on when the CEC device is turned on.
		The CEC device will enter power saving mode when the monitor is turned off.
		 When Sony PlayStation®, Nintendo® Switch™, or Xbox Series X S console is connected, Game Mode and Pro Mode will be automatically set to default modes and can be adjusted to users' preferred modes later.
Type C PD	OFF	Type C PD Charge enables users to charge
Charge		their devices through a USB Type-C connector, which can deliver up to 15W (5V/3A).
Reset	YES	Users can Reset and restore settings to
	NO	original OSD Default in any mode.

Specifications

Monitor	MAG 275CQRF-QD	MAG 325CQRF-QD		
Size	27 inch	31.5 inch		
Curvature	1000R			
Panel Type	Rapid VA			
Resolution	2560 x 1440			
Aspect Ratio	16:9			
Brightness	300 nits (typ.)			
	• Brightness 0~75%: 5V/3A	• 5V/3A		
USB Type-C Power Delivery	• Brightness 76~100%: 5V/2A			
	HDR & HDCR: 5V/2A			
Contrast Ratio	4000:1	3500:1		
Refresh Rate	170Hz (Default 165Hz)			
Response Time	1ms (GTG) 1ms (MPRT)			
	HDMI™ Connector x2			
	• DisplayPort x1			
1/0	USB Type-C Port x1			
1/0	• USB 2.0 Type-A Port x2			
	• USB 2.0 Type-B Upstream Port x1			
	Headphone Jack x1			
View Angles	178°(H) , 178°(V)			
DCI-P3*/ sRGB	96% / 127% 96.8% / 128.5%			
Surface Treatment	Anti-glare			
Display Colors	1.07B (8 bit + FRC)			
Monitor Power Options	20V == 3.25A 20V == 4.5A			
External Power Supply	Model: ADPC2065 Model: ADPC2090			
Power Input	100~240Vac, 50~60Hz, 100~240Vac, 50~60H 1.5A 1.3A			
Power Output	20V === 4.5A			

Monitor		MAG 275CQRF-QD	MAG 325CQRF-QD	
Adjustment (Height)		0 ~ 130mm	0 ~ 100mm	
Adjustment (Tilt)		-5° ~ 20°		
Kensington Lock		Yes		
VESA Mounting		• Plate Type: 100 x 100 mm		
		• Screw Type: M4 x 10 mm		
		• Thread Diameter: 4 mm		
		• Thread Pitch: 0.7 mm		
		• Thread Length: 10 mm		
Dimension (W	x H x D)	607 x 427 x 267 mm 701 x 480 x 270 mm		
Weight	Net	6.2 kg	7.7 kg	
	Gross	9.3 kg	10.3 kg	
		Temperature: 0°C to 40°C		
	Operating	Humidity: 20% to 90%, non-condensing		
Environment		• Altitude: 0 ~ 5000m		
	C1	• Temperature: -20°C to 60°C		
	Storage	• Humidity: 10% to 90%, no	n-condensing	

^{*} Based on CIE1976 test standards.

Preset Display Modes



All information is subject to change without prior notice.

Character d	B I		Standard Mode		
Standard Resolution			HDMI™	DP	USB-C
VGA	640x480	@60Hz	V	V	V
		@67Hz	V	V	V
		@72Hz	V	V	V
		@75Hz	V	V	٧
SVGA	800x600	@56Hz	V	V	٧
		@60Hz	V	V	٧
		@72Hz	٧	٧	٧
		@75Hz	V	V	٧
XGA	1024x768	@60Hz	٧	٧	٧
		@70Hz	٧	٧	٧
		@75Hz	٧	٧	٧
SXGA	1280x1024	@60Hz	٧	٧	٧
		@75Hz	V	٧	٧
WXGA+	1440x900	@60Hz	V	V	٧
WSXGA+	1680x1050	@60Hz	V	٧	٧
Full HD	1920x1080	@60Hz	V	V	٧
		@120Hz	V	٧	٧
QHD	2560x1440	@60Hz	V	V	٧
		@120Hz	V	V	V
		@144Hz	V	V	V
		@165Hz		V	V
		@170Hz		V *	V *

Standard	Resolution	Standard Mode		
		HDMI™	DP	USB-C
Video Timing Resolution	480P	V	V	V
	576P	V	V	V
	720P	V	V	V
	1080P @60Hz	V	V	V
	1080P @120Hz	V	V	V
	2160P @30Hz	V		
	2160P @50Hz	V		
	2160P @60Hz	V		

Chandand	Basslution		Screen Size 16:10 without HDR		
Standard Resolution			HDMI™	DP	USB-C
QHD	2560x1600	@60Hz	٧	V	V
		@120Hz	V	V	V
		@144Hz		V	V

^{*} Users have to set DP OverClocking to ON. This is the highest refresh rate supported by DP OverClocking. If any monitor error occurs during overclocking, please downscale the refresh rate.

Troubleshooting

The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

The screen image is not properly sized or centered.

• Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

The icons, font or screen are fuzzy, blurry or have color problems.

- · Avoid using any video extension cables.
- · Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

Battery

Please take special precautions if this device comes with a battery.

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.
- Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, which can result in an explosion.
- Avoid leaving a battery in an extremely high temperature or extremely low air pressure environment that can result in an explosion or the leakage of flammable liquid or gas.
- Do not ingest battery. If the coin/button cell battery is swallowed, it can cause severe internal burns and can lead to death. Keep new and used batteries away from children.

European Union:



Batteries, battery packs, and accumulators should not be disposed of as unsorted household waste. Please use the public collection system to return, recycle, or treat them in compliance with the local regulations.

BSMI:



廢雷池請回收

For better environmental protection, waste batteries should be collected separately for recycling or special disposal.

California. USA:



The button cell battery may contain perchlorate material and requires special handling when recycled or disposed of in California. For further information please visit: https://dtsc.ca.gov/perchlorate/

Environment

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.
- If any of the following situations arises, get the device checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and damaged.
 - The device has obvious sign of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.

TÜV Rheinland Flicker Free Certification

• TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.



- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 - 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)

Regulatory Notices

CE Conformity

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), ErP Directive (2009/125/EC) and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA [626] 913-0828

www.msi.com

WFFF Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017, № 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS

As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- · Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.



- · Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.

Warning!

Overuse of screens is likely to affect eyesight.

Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Copyright and Trademarks Notice

Copyright © Micro-Star Int'l Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int'l Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI™, HDMI™ High-Definition Multimedia Interface, HDMI™ Trade dress and the HDMI™ Logos are trademarks or registered trademarks of HDMI™ Licensing Administrator, Inc.

Technical Support

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.