

Quick Start Guide




SAMSUNG Galaxy XCover7 Pro

Rated IP68: Dust-tight. Tested for submersion in up to 5 feet of fresh water for up to 30 minutes. Rinse residue/dry after wet.



QR code for
Samsung use
Printed in Korea
GH68-56875A

What's in the box



Phone and Battery



SIM card



Charging cable

[Quick Start Guide](#)
[Terms & Conditions](#)

USB Type-C 3A cable included. For more information about charging, visit <https://www.samsung.com/us/support/answer/ANS10001612/>

Use only compatible charging devices and accessories. Damage caused by use of accessories which are not compatible may not be covered by warranty.

Get to know your device




Get connected

Upgrading or replacing your phone?
Transferring your number to AT&T?

If so, activate your phone at
www.att.com/activations

Insert the SIM card into your
phone as shown



1

Rear cover

Remove the cover
and battery.

When replacing the cover,
press down all around
the edge to ensure it is
completely closed.

2

SIM card

Insert the SIM card in
the SIM card slot.

To get all the benefits
of our network, make
sure to use the SIM
card that shipped with
your new phone.

Get started


You may need your Google ID and password
and Wi-Fi password

Power on device



Side button
Press and hold

Follow the setup screens
and transfer content to your new phone



Need help?

Learn more about your phone with
the **Device Help** app



To launch, scan this code
with your camera



or visit www.att.com/device-support

Call our customer care team at
1-800-331-0500 or prepaid **1-800-901-9878**