

Quick Start Guide

1


PLUG IN SENTRY ONE

- Wait for up to 30 seconds.
- No need to restart your computer.
- Drive letters vary with computer.

2


SETUP/UNLOCK*

Device autostarts or **Double-click & Run**



3

WORK



Manage Files



Sentry ONE locks when it is unplugged, powered down, timed out, locked from the menu or when you log out.

* If this window does not appear, open it manually:

- Windows: Start > This PC > Unlocker > Unlocker
- Mac: Finder > Unlocker > Unlocker

A one time activation is required upon first use. Enter the activation code or connection token provided by your account administrator.

For more info visit datalocker.com/central-management