



QUICK GUIDE

Gaming | Content Creation | Business & Productivity



English

Product Overview (for reference only)

1. Webcam / Webcam LED/ Internal Microphone
2. Power Key / Power LED/ GPU Mode LED / Battery Reset
3. Status LED
4. Keyboard
5. Fingerprint Sensor (optional)
6. Touchpad
7. Status LED
8. USB 3.2 Gen 2 Port
9. Mini-DisplayPort
10. RJ-45 Connector
11. Thunderbolt (Type-C) (optional)
12. HDMI Connector
13. USB 3.2 Gen 2 Port
14. Combo Audio Port
15. Power Connector
16. Card Reader
17. Status LED
18. Ventilator
19. Tweeter Speaker
20. Ventilator
21. Battery Reset Hole (optional)
22. Stereo Speakers

Battery Status:
Continuously blinking if the battery fails. If the problem persists, please contact your local authorized retailer or service center.

Buttons:
Caps Lock
Num Lock
Fingerprint Sensor (optional)
Touchpad
Status LED

Ports:
Caps Lock
Num Lock
USB 3.2 Gen 2 Port
Mini-DisplayPort
RJ-45 Connector
Thunderbolt (Type-C) (optional)
HDMI Connector

Getting Started (for reference only)

Connect the AC Power

Power On the Notebook

I- Connect the AC Power
It is strongly recommended to connect the AC/DC adapter to the notebook and use the AC power while using this notebook for the first time since some models may require the AC/DC adapter to be connected in order to power on the notebook safely and properly.

II- Power On the Notebook
When the AC power is connected, press the power button to turn the notebook on.

Function Keys

III- Function Keys

IV- Connect the AC Power

II- Power On the Notebook

Norsk

Produktoversikt

I- Koble til vekselstrømmen

II- Slå på strømmen til den bærbare PC-en

III- Hurtigtastarknapp [Fn]

IV- Slå på strømmen til den bærbare PC-en

Suomi

Tuotekuvaus

I- Verkkovirran liittäminen

II- Käynnistäminen

III- Pikäkäynnistyspainikkeet, [Fn]-painikkeet

IV- Käynnistäminen

Русский

Общие сведения об устройстве

I- Подключение к сети переменного тока

II- Включение ноутбука

III- Функциональные клавиши

IV- Подключение к сети переменного тока

Eesti

Toote ülevaade

I- Ühendamine vahelduvvooluvõrku

II- Lülitage sissevoolu sisse

III- Funktsiooniklahvid

Magyar

Termékekintés

I- A hálózati adapter csatlakoztatása

II- A netezsgép bekapcsolása

III- Funkcióbillentyűk

CE Conformity

Products with Radio Frequency (EMF)

Restrictions for Products with Radio Frequency (select products only)

CAUTION:

Radio frequency bands and maximum power levels

Find User Manual at C:\Windows\User Manual\User Manual

Deutsch

Produktübersicht (dient nur als Referenz)

1. Webkamera / Webkamera LED/ Mikrophon

2. Power Key / Power LED/ GPU Modus-LED/ Akku-Reset

3. Status-LED

4. Tastatur

5. Fingerdrucksensor (optional)

6. Touchpad

7. Status-LED

8. USB 3.2 Gen 2-Port

9. Mini-DisplayPort / Ausgang

10. RJ-45-Buchse

11. Thunderbolt (Typ-C) (optional)

12. HDMI-Buchse

13. USB 3.2 Gen 2-Port

14. Kombiniertes Audioanschluss

15. Netzanschluss

16. Kartenleser

17. Status-LED

18. Lüfter

19. Hochdrücker

20. Lüfter

21. Akku-Resetöffnung (optional)

22. Stereo-Lautsprecher

Batteriestatus:
Leuchtet dauerhaft bei nahezu erschöpftem Akku. Wenn der Fehler weiterhin besteht, wenden Sie sich an den autorisierten Fachhändler oder Kundendienstzentrum.

Buttons:
Caps Lock
Num Lock
Fingerprintdrucksensor (optional)
Touchpad
Status-LED

Ports:
Caps Lock
Num Lock
USB 3.2 Gen 2-Port
Mini-DisplayPort
RJ-45-Buchse
Thunderbolt (Typ-C) (optional)
HDMI-Buchse
Kombiniertes Audioanschluss
Netzanschluss

Erste Schritte (dient nur als Referenz)

• Netzteil Anschließen

• Schalten Sie das Notebook

I- Netzteil Anschließen

II- Schalten Sie das Notebook

III- Funktionstasten

Français

Vue ouverte du dessus (pour référence uniquement)

• Connexion de l'adaptateur secteur

• Mettre le notebook sous tension

I- Connexion de l'adaptateur secteur

II- Mettre le notebook sous tension

III- Touches fonction

Touches fonction

Pour commencer (pour référence uniquement)

• Connexion de l'adaptateur secteur

• Mettre le notebook sous tension

I- Connexion de l'adaptateur secteur

II- Mettre le notebook sous tension

III- Touches fonction

Latviski

Produkta pārskats

I- Produkta pārskats

II- Piezīmēšana ieslēgšana

III- Funkciju taustiņi

Lietuvių

Produktų apžvalga

I- Kintamosios sąrašas (AC) maitinimo priėjimas

II- Nėsiuojamo kompiuterio maitinimas

III- Funkciniai mygtukai

IV- Nėsiuojamo kompiuterio maitinimas

Ελληνικά

Σύντομη παρουσίαση προϊόντος

I- Συντόμημη παρουσίαση προϊόντος

II- Ενεργοποίηση του φορητού υπολογιστή

III- Λειτουργικές πλήκτρα

Svenska

Produktöversikt

I- Anslutning av växelströmsförsörjning

II- Slå på den bärbara datorn

III- Snabbstartsknapp [Fn]

Dansk

Produktoversigt

I- Tilslutning af AC strøm

II- Sådan tændes for den bærbare

III- Generelle [Fn]-taster

Nederlands

Productoverzicht

I- De notebook aansluiten

II- De notebook inschakelen

III- Algemene [Fn]-toetsen