


## SonicWall® TZ600P / TZ570P / TZ300P Power Supply

### Reference Guide

September 2020

SonicWall power supplies are for use only with approved SonicWall appliances. See the table below for the current list of approved SonicWall appliances and supported power supplies.

 **CAUTION:** Use of this power supply with SonicWall appliances that are not approved will void the warranty for that SonicWall appliance and will create an unsafe condition.

Refer to the *SonicWall Quick Start Guide* or *Safety and Regulatory Information* documentation for your appliance platform for full installation and safety instructions.

This power supply is provided as a replacement for a missing power supply or as an additionally required power supply and is provided on an “as is” basis without warranty of any kind.

#### Power Supply Information

SKU	Power Supply Specifications	Supported Platforms
02-SSC-0614	SONICWALL TZ600/TZ570 POE FRU POWER SUPPLY	TZ600P
	Output 54 VDC, 3.34 A	TZ570P
	Input 100-240 VAC	
02-SSC-0613	SONICWALL TZ300 POE FRU POWER SUPPLY	TZ300P
	Output 54 VDC, 1.2 A	
	Input 100-240 VAC	

For Ecodesign requirements, visit:

<https://www.sonicwall.com/legal/environmental-and-regulatory-affairs.aspx>.

# About This Document

## Legend



**WARNING:** A WARNING icon indicates a potential for property damage, personal injury, or death.



**CAUTION:** A CAUTION icon indicates potential damage to hardware or loss of data if instructions are not followed.



**IMPORTANT, NOTE, TIP, MOBILE, or VIDEO:** An information icon indicates supporting information.

## Copyright © 2020 SonicWall Inc. All rights reserved.

This product is protected by U.S. and international copyright and intellectual property laws. SonicWall is a trademark or registered trademark of SonicWall Inc. and/or its affiliates in the U.S.A. and/or other countries. All other trademarks and registered trademarks are property of their respective owners.

The information in this document is provided in connection with SonicWall Inc. and/or its affiliates' products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of SonicWall products. EXCEPT AS SET FORTH IN THE TERMS AND CONDITIONS AS SPECIFIED IN THE LICENSE AGREEMENT FOR THIS PRODUCT, SONICWALL AND/OR ITS AFFILIATES ASSUME NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON- INFRINGEMENT. IN NO EVENT SHALL SONICWALL AND/OR ITS AFFILIATES BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF SONICWALL AND/OR ITS AFFILIATES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SonicWall and/or its affiliates make no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserve the right to make changes to specifications and product descriptions at any time without notice. SonicWall Inc. and/or its affiliates do not make any commitment to update the information contained in this document.

For more information, visit <https://www.sonicwall.com/legal>.

To view the SonicWall End User Product Agreement, go to: <https://www.sonicwall.com/legal/license-agreements>.

Last updated: 9/15/2020

232-005251-51 Rev A

