


## 4K 60 Hz HDMI over Wireless Extender Kit

B127-1A1-WHD4CH

(USB-C Mini Transmitter + HDMI Mini Receiver)



Este manual está disponible en español en la página de Eaton: [Tripplite.Eaton.com/support](http://Tripplite.Eaton.com/support)

Ce manuel est disponible en français sur le site Web de Eaton : [Tripplite.Eaton.com/support](http://Tripplite.Eaton.com/support)

Dieses Handbuch ist in deutscher Sprache auf der Eaton-Website verfügbar: [Tripplite.Eaton.com/support](http://Tripplite.Eaton.com/support)

Questo manuale è disponibile in italiano sul sito web di Eaton: [Tripplite.Eaton.com/support](http://Tripplite.Eaton.com/support)

Purchased product may differ from image.

# EATON

Powering Business Worldwide

## Important Safety Instructions



- Do not expose this device to rain or place it near water. Any liquid that goes into the device may cause a failure, fire, or electric shock.
- Never insert anything metallic into the open parts of this device. This may cause an electric shock.
- The device should be repaired only by a qualified technician.
- Do not place this device near or over a radiator or heat register, or where it is exposed to direct sunlight.

## Features

- Supports up to 3840 x 2160 @ 60 Hz resolution, backward compatible.
- Supports wireless transmission up to 65 ft. / 20 m (line of sight).
- Supports SSID pairing and channel switching to avoid interference.
- Supports 5G wireless frequency bands, for strong anti-interference.
- Supports firmware upgrade via Micro USB port.
- Portable design, plug and play.

## Package Contents



Transmitter x1



Receiver x1



Micro USB cable x2




User Documentation x1

## Installation Requirements

- USB-C source device (DVD, game console, PC, etc.)
- HDMI display device (TV, projector, LED screen, etc.)

## Product Description


### Transmitter (TX)



- |                                |   |
|--------------------------------|---|
| <b>1 USB-C input</b>           | Connects to a USB-C source device   |
| <b>2 WiFi indicator</b>        | Slow flash: waiting for connection<br>Steady on: connection succeeded<br>Quick flash: SSID Pairing mode           |
| <b>3 Power indicator</b>       | The indicator will turn red when the power is turned on   |
| <b>4 Channel switch button</b> | Press to switch channels<br>Press and hold 5s for SSID pairing<br>Press and hold 10s for restore factory settings |
| <b>5 Signal indicator</b>      | Light off: no HDMI signal<br>Steady on: HDMI signal is transmitting<br>Quick flash: restore factory settings      |
| <b>6 Micro USB port</b>        | Firmware upgrade  |

## Product Description

### Receiver (RX)




- |                                |   |
|--------------------------------|---|
| <b>1 HDMI output</b>           | Connects to an HDMI display device  |
| <b>2 WiFi indicator</b>        | Slow flash: waiting for connection<br>Steady on: connection succeeded<br>Quick flash: SSID Pairing mode                                     |
| <b>3 Power indicator</b>       | The indicator will turn red when the power is turned on   |
| <b>4 Channel switch button</b> | After connecting with TX, press to switch channels<br>Press and hold 5s for SSID pairing<br>Press and hold 10s for restore factory settings |
| <b>5 Signal indicator</b>      | Light off: no HDMI signal<br>Steady on: HDMI signal is transmitting<br>Quick flash: restore factory settings                                |
| <b>6 Micro USB port</b>        | For power input and firmware upgrade  |

# Installation

## 1. Connection Diagram

One to one connection



## 2. Connection Instructions

1. Connect the transmitter to the USB-C output port of the signal source device.
2. Connect the receiver to the HDMI input port of the display device.
3. Plug the power supply into the devices to get started.

**Note:** Please connect the Micro USB cable to the 5V 1A wall charger when transmitting 4K video, for long-distance use, or when the picture is not smooth.

## 3. SSID Pairing

1. Enter the SSID pairing mode by holding the transmitter and receiver's channel switch buttons for five seconds. Both WiFi connection indicators will flash quickly in blue.
2. When the SSID pairing is successful, the WiFi indicators on the transmitter and receiver will change from quick flashing to slow flashing or steady on.

NO.	Frequency
Channel 1	5.180 GHz
Channel 2	5.200 GHz
Channel 3	5.220 GHz
Channel 4	5.240 GHz

## FAQ

**Q:** Why the receiver and transmitter cannot be connected, showing "Search ipcolor Tx..." on the screen?

- A:**
- 1) Move transmitter and receiver closer.
  - 2) Re-power the transmitter or receiver.
  - 3) Re-pair the transmitter and receiver.

**Q:** Why is the Wi-Fi indicator steady on, but showing "Please check the TX input signal"?

- A:**
- 1) Make sure the TX has a USB Type-C input and that the resolution is within the specified range.
  - 2) Try to connect the signal source directly to the display device, or change the signal source and test again.

**Q:** Why is the display stuttering or unstable?

- A:**
- 1) Place the transmitter or receiver within the signal coverage and minimize obstructions between the transmitter and receiver.
  - 2) Switch to a different channel to avoid interference from other wireless signals.
  - 3) Re-power the receiver or transmitter.

## Specifications

<b>Power Supply</b>	Voltage/Current	Micro USB power supply (5V/1A)
	Power consumption	TX < 5W, RX < 3.5W
<b>HDMI Performance and Interface</b>	HDMI version	HDMI 2.0
	HDCP version	HDCP 1.4/HDCP 2.2
	Maximum transfer rate	18 Gbps
	Resolution supported	3840x2160@24/30/50/60 Hz (YUV 4:4:4, YUV 4:2:2 and RGB), 1080p@50/60 Hz, 720p@50/60 Hz, 1920x1200@60 Hz
	Input and output TMDS signal	0.7~1.2Vp-p (TMDS)
	Input and output DDC signal	5Vp-p (TTL)
<b>Transmission</b>	Wi-Fi Frequency bands	5.18-5.24 GHz
	Transmission distance	≤ 20m
	Latency	100~250ms
	Connection types	One to one
	SSID pairing	Supported
<b>Protection Level</b>	ESD protection	1a Contact discharge level 3 1b Air discharge level 3 Standard: IEC61000-4-2



## Specification

<b>Operating Environment</b>	Operating temperature	-4~122°F (-20~50°C)
	Storage temperature	-22~158°F (-30~70°C)
	Humidity (non-condensing)	0~90% RH
<b>Physical Properties</b>	Dimensions [W x L x H]	TX / RX: 1.6 x 9 x 0.6 in. (40 x 230 x 15 mm)
	Color	Black
	Material	ABS
	Net weight	TX: 0.1 lb. (47 g); RX: 0.11 lb. (54 g)

## Warranty and Product Registration

### 1-Year Limited Warranty

We warrant our products to be free from defects in materials and workmanship for a period of one (1) year from the date of initial purchase. Our obligation under this warranty is limited to repairing or replacing (at its sole option) any such defective products. Visit **[Tripplite.Eaton.com/support/product-returns](https://www.tripplite.com/support/product-returns)** before sending any equipment back for repair. This warranty does not apply to equipment which has been damaged by accident, negligence or misapplication or has been altered or modified in any way.

EXCEPT AS PROVIDED HEREIN, WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL WE BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, we are not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise.

### Product Registration

Visit [Tripplite.Eaton.com/warranty](https://www.tripplite.com/warranty) today to register your new product. You'll be automatically entered into a drawing for a chance to win a FREE Eaton Tripp Lite series product!\*

\* No purchase necessary. Void where prohibited. Some restrictions apply. See website for details.

### Regulatory Compliance Identification Numbers

For the purpose of regulatory compliance certifications and identification, your product has been assigned a unique series number. The series number can be found on the product nameplate label, along with all required approval markings and information. When requesting compliance information for this product, always refer to the series number. The series number should not be confused with the marking name or model number of the product.

## Warranty and Product Registration

### WEEE Compliance Information for Customers and Recyclers (European Union)

Under the Waste Electrical and Electronic Equipment (WEEE) Directive and implementing regulations, when customers buy new electrical and electronic equipment from Eaton, they are entitled to:



- Send old equipment for recycling on a one-for-one, like-for-like basis (this varies depending on the country)
- Send the new equipment back for recycling when this ultimately becomes waste

Eaton has a policy of continuous improvement. Specifications are subject to change without notice.



Eaton  
1000 Eaton Boulevard  
Cleveland, OH 44122  
United States  
Eaton.com

© 2023 Eaton  
All Rights Reserved  
Publication No. 23-10-177 /  
93-4994\_revA  
December 2023

Eaton is a registered  
trademark.

All trademarks are property  
of their respective owners.