



200 x 200 VESA Adaptor Plate



COMPONENTS CHECKLIST



A
Plate
(x1)




B
CSK
Screw
M5x10mm
(x4)



C
Nylock
Nut
M5
(x4)



D
Screw
M6x14mm
(x4)



E
Screw
M8x20mm
(x4)



F
Screw
M4x12mm
(x4)



G
Screw
M4x10mm
(x4)



H
Nut
M4
(x4)



I
Washer
M5
(x4)



J
Spacer
M8 x 5mm
(x8)



K
Washer
M8
(x4)

REQUIRED TOOLS

- Phillips Head Screw Driver
- Spanners

IMPORTANT INFORMATION


- ! Please ensure this product is installed as per these installation instructions.
- ! Flush Configuration - Recommended for greater than 12kg (26.45lbs)
- ! Spacer Configuration - Suitable for all loads unable to be flush mounted
- ! This product reduces the working capacity of the monitor arm by 1kg.
- ! Maximum load for plate only is 30kg (66lbs)
- ! The manufacturer accepts no responsibility for incorrect installation.




Max - 30kg (66lbs)

1. Flush mounting configuration - Recommended for loads greater than 12kg (26.45lbs)



1.1 Fasten adaptor plate to VESA head



1.2 Mount adaptor plate to monitor




1.3 Check fitment




2. Spacer configuration - Suitable for loads up to the maximum which are unable to be flush mounted

2.1 Fasten adaptor plate to VESA head



2.2 Mount adaptor plate to monitor



2.3 Check fitment

