

1x



2x



2x



Quick Installation Guide

Elo Fingerprint Reader

Elo Technical Support

Online self-help: www.elotouch.com/support

America

800-ELO-TOUCH
Tel +1 408 597 8000
EloSales.NA@elotouch.com

Asia-Pacific

Tel +86 (21) 3329 1385
EloAsia@elotouch.com

Europe(EMEA)

Tel +32 (0)16 930 136
EMEA.Sales@elotouch.com

Revision B
P/N E550867

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo and the Elo logo are either trademarks or registered trademarks of Elo Touch Solutions, Inc.



Installation

Please go to www.elotouch.com/support to verify you have the latest drivers before installing this device.


1



Select location to mount the fingerprint reader.


Elo recommends the righthand location in either portrait or landscape orientation.

2




Remove the selected peripheral cover from the touchmonitor.

3



Gently insert the fingerprint reader into the peripheral bay taking care to ensure the connector mates properly.

4



Install the 2 flat head screws included with the kit and cover the screws with the adhesive mylar covers if desired.