




Using the T800 Magnetic Stripe and Smart Card Reader

Introduction

This snap-on module is a 2-in-1 card reader that can read:

- Smart cards
- Magnetic stripe cards

Hardware Installation



1. Align the module with the back of T800, engage the module's bottom tab first and then snap the top tab into place.
2. Firmly press the connector area to ensure the connection. The module has an icon  indicating where to press.
3. Tighten four screws.



Inserting Smart Cards

CAUTION: Do not insert smart cards when the temperature of T800 is high.


1. Open the cover of the smart card slot.
2. With the smart card's chip facing the module and pointing toward the slot, insert the card into the slot until reaching the end.
3. Close the cover.



Reading Magnetic Stripe Cards

With the card's magnetic stripe facing T800, swipe the card through the slot from either side.

NOTE: Make sure to press the magnetic stripe firmly against the reader when swiping the card. A poor contact or an incomplete swipe action will result in an unsuccessful reading.



5 6 1 5 1 2 2 1 0 0 5 R 0 0