

https://www.hp.com/support

RMN/型號/型号: HSN-IX04

© Copyright 2025 HP Development Company, L.P.

USB Type-C, USB-C, and the USB 5 Gbps and USB 10 Gbps port logos are registered trademarks of USB Implementers Forum. DisplayPort and the DisplayPort logo are trademarks owned by the Video Electronics Standards Association (VESA) in the United States and other countries.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.


First Edition: October 2025

PRINTER: Replace this box with Printed- In (PI) Statement(s) as per spec.

NOTE: This box is simply a placeholder. PI Statement(s) do not have to fit inside the box but should be placed in this area.

P57967-B21


1




2




3



4




5




6




7




8



9



10



Three displays are supported, but only when the notebook lid is closed.

يتم دعم ثلاث شاشات عرض، لكن فقط عندما يكون غطاء الكمبيوتر الدفتري مغلقًا.

Mendukung tiga layar, tetapi hanya saat penutup notebook ditutup.

Поддържат се три дисплея, но само когато капакът на преносимия компютър е затворен.

Podporovány jsou tři displeje, ale pouze když je víko notebooku zavřené.

Tre skærme understøttes, men kun når den bærbare computers låg er lukket.

Es werden bis zu 3 Displays unterstützt (nur bei geschlossenem Notebook).

Admite tres pantallas, pero solo cuando se cierra la tapa del notebook.

Υποστηρίζονται τρεις οθόνες, αλλά μόνο όταν το καπάκι του φορητού υπολογιστή είναι κλειστό.

Trois écrans sont pris en charge, mais uniquement lorsque le capot de l'ordinateur portable est fermé.

Podržava tri zaslona, ali samo kada je poklopac prijenosnog računala zatvoren.

Sono supportati tre display, ma solo quando il coperchio del notebook è chiuso.

მხარდაჭერილია სამი ეკრანი, თუმცა მხოლოდ იმ შემთხვევაში, როდესაც ნოუთბუქი დახურულია.

Ноутбук қақпағы жабылған кезде ғана, үш дисплейге қолдау көрсетіледі.

Tiek atbalstīti trīs displeji, taču tikai ar aizvērtu piezīmjdatora vāku.

Palaikomi trys ekranai, tačiau tik užvėrus nešiojamojo kompiuterio ekraną.

Három képernyő támogatott, de csak akkor, ha a notebook fedele le van csukva.

Met ondersteuning voor drie beeldschermen als de klep van de notebook gesloten is.

Tre skjermer støttes, men bare når lokket til den bærbare PC-en er lukket.

Obsługiwane są trzy ekrany, ale tylko wtedy, gdy pokrywa laptopa jest zamknięta.

São suportados três monitores, mas apenas quando a tampa do computador portátil estiver fechada.

Há suporte para três monitores, mas somente quando a tampa do notebook está fechada.

Sunt acceptate trei afișaje, dar numai când capacul notebook-ului este închis.

Поддерживаются три дисплея, но только если крышка ноутбука закрыта.

Podporované sú tri displeje, no len vtedy, keď je zatvorený kryt prenosného počítača.

Podprti so trije zasloni, vendar samo, ko je pokrov prenosnega računalnika zaprt.

Kolmea näyttöä tuetaan, mutta vain, kun kannettavan tietokoneen kansi on suljettu.

Podržana su tri ekrana, ali samo kad je poklopac prenosnog računara zatvoren.

Tre bildskärmar kan användas, men bara när notebook-datorns lock stängs.

รองรับจอแสดงผล 3 จอภาพ เฉพาะขณะที่ปิดฝาโน้ตบุ๊กไว้เท่านั้น

Üç ekran desteklenmektedir, ancak yalnızca dizüstü bilgisayarın kapağı kapalı olduğunda.

Підтримуються три дисплеї, але лише якщо кришку ноутбука закрито.

ノートブック コンピューターのカバーが閉じられている場合のみ、3台のディスプレイに対応します。

노트북 덮개가 닫혀 있는 경우에만 3개의 디스플레이가 지원됩니다.

支持三个显示屏，但仅可在笔记本电脑盖合上时使用。

支援三個顯示器，前提是必須闔上筆記型電腦上蓋。

11

