
## Y25-30 Simplified service manual for dismantling

Model Name: Lenovo Y25-30



## 1. Precaution

Please read the precaution as follows to prevent any damages to the LCD Monitor.

Make sure all power connector is removed. Be sure that the LCD Monitor is in power off status.


Prepare soft cloth and sponge as working platform to place LCD monitor horizontally.




Hold LCD by the side carefully and DON'T touch or press panel directly.

## 2. Appropriate tools

Select the Appropriate tools for disassembly and re-assembly.





## 3. Disassembly SOP

Put the monitor on a flat surface (Put the EPE on under the monitor)	
	OI OI

Remove the screw * 1pcs Tool : Screwdriver #2	
Pull out stand	
Remove the back cover	
Remove All tape and foil	

Unplug light bar line and LVDS line	
Remove All screw. Release the keypad pcb from the the middle frame	
Tool : Screwdriver #2	
Remove All screw. Remove All tape	3 4
Tool : Screwdriver #2	1 2 M3*8双垫片 5 7 6
Take out the PCB board	
Remove All screw. Tool : Screwdriver #2	THE PARTY OF THE P

Remove the middle frame.

The panel

